

Configuration — System Avaya Ethernet Routing Switch 5000 Series

© 2012 Avaya Inc.

All Rights Reserved.

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of this documentation unless such modifications, additions, or deletions were performed by Avaya. End User agree to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation(s) provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on this product. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product, while under warranty, is available to Avaya customers and other parties through the Avaya Support Web site: http://www.avaya.com/support. Please note that if you acquired the product from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/ ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER, AND AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation(s) and Product(s) provided by Avaya. All content on this site, the documentation(s) and the product(s) provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is

protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil, offense under the applicable law.

Third-party components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: http://www.avaya.com/support/Copyright/.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the documentation(s) and product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the documentation(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All other trademarks are the property of their respective owners.

Downloading documents

For the most current versions of documentation, see the Avaya Support Web site: http://www.avaya.com/support

Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: http://www.avaya.com/support

Contents

Chapter 1: New in this release	11
Features	11
Other changes	14
Chapter 2: Introduction	17
ACLI command modes	17
Chapter 3: System configuration fundamentals	21
Feature licensing	
User access limitations	<u>22</u>
Customizing ACLI banner	<u>22</u>
TFTP server	23
Configuration downloads to a switch	23
Multiple switch configuration management	25
Secure Shell File Transfer Protocol (SFTP over SSH)	25
Stacking fundamentals	25
Avaya Energy Saver	31
Boot agent image	32
Supported BootP modes	36
IPv6 management	37
Dynamic Host Configuration Protocol	46
Simple Network Time Protocol	47
Ping enhancement	47
Auto-MDI X	48
Auto-polarity	48
Autosensing and autonegotiation	
Rate Limiting Configuration	53
Quick install	
Set IP parameters using IP.CFG file on a USB memory device	55
Chapter 4: Power over Ethernet fundamentals	59
PoE overview	60
Power source	
Stacking	61
Power pairs	61
Diagnosing and correcting PoE problems	62
Power management	
Chapter 5: LLDP fundamentals	67
Link Layer Discover Protocol (IEEE 802.1ab) Overview	67
LLDP operational modes	68
Connectivity and management information	
802.1AB MED network policies	
Avaya Automatic QoS enhancement for LLDP-MED	72
Chapter 6: System configuration with ACLI	73
General switch administration with ACLI	
Stack manager	75
Multiple switch configurations	76

New Unit Quick Configuration	. 78
IP blocking	. 80
Assigning and clearing IP addresses	. 81
Assigning and clearing IP addresses for specific units	86
Displaying interfaces	. 87
Setting port speed	. 88
Testing cables with the Time Domain Reflectometer	. 91
Enabling Autotopology	92
Enabling flow control	. 94
Enabling rate-limiting	. 96
Using Simple Network Time Protocol	. 100
Real time clock configuration	106
Custom Autonegotiation Advertisements	. 108
Connecting to Another Switch	. 110
Domain Name Server (DNS) Configuration	111
Auto Unit Replacement using the ACLI	114
Viewing Auto Unit Replacement using the ACLI	. 115
Enabling Auto Unit Replacement using the ACLI	. 115
Disabling AUR using the ACLI	116
Restoring the default setting for AUR using the ACLI	. 116
Configuring AUR operation settings using the ACLI	116
Avaya Energy Saver configuration using the ACLI	. 117
Configuring global AES using the ACLI	. 118
Configuring port-based AES using the ACLI	. 119
Activating or deactivating AES manually using the ACLI	. 120
Configuring AES scheduling using the ACLI	
Disabling AES scheduling using the ACLI	
Configuring AES scheduling to default using the ACLI	. 123
Viewing AES scheduling using the ACLI	
Viewing AES savings using the ACLI	
Viewing the global AES configuration using ACLI	
Viewing port-based AES configuration using the ACLI	
Changing switch software in the ACLI	
Configuration files in ACLI	
Displaying the current configuration	
Storing the current configuration	
Restoring a system configuration	
Saving the current configuration	
Automatically downloading a configuration file with ACLI	
Terminal setup	
Setting the default management interface	
Setting Telnet access	
telnet-access command	
no telnet-access command	
default telnet-access command	
Setting boot parameters	
Defaulting to BootP-when-needed.	. 139

	Configuring with the command line interface	
	ip bootp server command	139
	no ip bootp server command	140
	default ip bootp server command	140
shutd	lown command	140
reload	d command	141
ACLI	Help	142
Clear	ing the default TFTP server with ACLI	142
Confi	guring a default TFTP server with ACLI	143
Displa	aying the default TFTP server with ACLI	143
Secu	re Transfer File Protocol configuration	143
	Uploading a config file to an SFTP server	144
	Downloading a config file to an SFTP server	145
	Host keys	146
	Enabling DSA authentication	147
	Disabling DSA authentication	147
	Enabling Password authentication	
	Disabling Password authentication	
	Setting the Transmission Control Protocol port	
	Setting timeout	
	Viewing SFTP	
Confi	guring daylight savings time with ACLI	150
	guring default clock source with ACLI	
	guring local time zone with ACLI	
Confi	guring Dual Agent with ACLI	153
	Enhanced download command	
	Set the next boot Image	154
	Show agent images	155
	guring IPv6 with ACLI	
	Enabling IPv6 interface on the management VLAN	
	Configuring IPv6 interface on the management VLAN	
	Displaying the IPv6 interface information	
	Displaying IPv6 interface addresses	
	Configuring an IPv6 address for a switch or stack	159
	Displaying the IPv6 address for a switch or stack	
	Configuring IPv6 management interface	160
	Disabling IPv6 globally	161
	Returning IPv6 to default settings	
	Configuring IPv6 global properties	
	Displaying the global IPv6 configuration	
	Configuring an IPv6 default gateway for the switch or stack	
	Displaying the IPv6 default gateway	
	Configuring the IPv6 neighbor cache	164
	Displaying the IPv6 neighbor information	165
	Displaying IPv6 interface ICMP statistics	165
	Displaying IPv6 interface statistics	166
		167

	Displaying IPv6 TCP connections	167
	Displaying IPv6 TCP listeners	
	Displaying IPv6 UDP statistics and endpoints	168
Conf	iguring LLDP with ACLI	168
	lldp command	169
	lldp port command	170
	lldp tx-tlv command	170
	lldp tx-tlv dot1 command	171
	lldp tx-tlv dot3 command	172
	lldp tx-tlv med command	173
	Ildp location-identification coordinate-base command	173
	Ildp location-identification civic-address command	174
	Ildp location-identification ecs-elin command	176
	default lldp command	176
	default lldp port command	177
	default lldp tx-tlv command	177
	default lldp tx-tlv dot1 command	178
	default lldp tx-tlv dot3 command	179
	default lldp tx-tlv med command	180
	no lldp port command	180
	no lldp tx-tlv command	180
	no lldp tx-tlv dot1 command	181
	no lldp tx-tlv dot3 command	181
	no lldp tx-tlv med command	181
	show lldp command	182
	show lldp port command	183
	Configuring LLDP MED policies for switch ports	184
	Setting Ildp med-network-policies to the default values	185
	Disabling LLDP MED policies for switch ports	186
	Viewing Ildp med-network-policies	186
	Configuring LLDP	187
Conf	iguring PoE detection method with ACLI	195
	Configuring PoE with ACLI	195
	Set port power enable or disable	195
	Set port power priority	196
	Set power limit for channels	196
	Set traps control	197
	Show main power status	197
	Set power usage threshold	197
	Setting PoE detection method	198
	Show port power status	
	Show port power measurement	198
Cust	omizing ACLI banner with ACLI	
	show banner command	199
	banner command	199
	no banner command	200
Disp	laying complete GBIC information.	200

	Displaying hardware information	201
	Configuring AUR with ACLI	201
	show stack auto-unit-replacement command	201
	stack auto-unit-replacement enable command	202
	no stack auto-unit-replacement enable command	203
	default stack auto-unit-replacement enable command	203
	stack auto-unit-replacement config save enable	203
	stack auto-unit-replacement config save disable	203
	stack auto-unit-replacement config restore unit	
	stack auto-unit-replacement config save unit	204
	Agent Auto Unit Replacement (AAUR)	204
	stack auto-unit-replacement-image enable command	
	no stack auto-unit-replacement-image-enable command	
	default stack auto-unit-replacement-image enable command	
	show stack auto-unit-replacement-image command	
	Enabling Autosave	206
	Disabling Autosave	
	Setting Stack Forced Mode	
	Configuring stack forced-mode	
	Enabling feature license files	
	Setting user access limitations	
	Setting the read-only and read-write passwords	
	Enabling and disabling passwords	
	Configuring RADIUS authentication	
	Related RADIUS Commands	
	Configuring serial console port and USB host port	
	Restoring factory default	216
Cha	pter 7: System configuration with Enterprise Device Manager	217
	Configuring Quick Start using EDM	218
	Configuring remote access using EDM	
	Configuring the IPv4 remote access list using EDM	
	Configuring the IPv6 remote access list using EDM	
	Viewing PoE ports with Enterprise Device Manager	
	General Switch Administration with Enterprise Device Manager	
	Displaying the Unit dialog box	
	Displaying the Chassis dialog box	
	Displaying the Switch/Stack dialog box	
	Displaying the Ports dialog box	
	Displaying the Environment dialog box	
	Avaya Energy Saver configuration using Enterprise Device Manager	
	Global AES configuration	
	AES schedule configuration	
	Port-based AES configuration	
	Viewing AES information using EDM	
	Bridge configuration using Enterprise Device Manager	
	Displaying bridge information	
	Displaying the Transparent tab	

Displaying the Forwarding tab	259
File System configuration using Enterprise Device Manager	260
Config/Image/Diag file tab	261
ASCII file tab	264
Configuring the license file	267
File configuration	268
Displaying Boot Image information	270
Displaying the Help File Path tab	27 1
ADAC Configuration using Enterprise Device Manager	27 1
Displaying the ADAC tab	27 1
Displaying the ADAC MAC Ranges tab	272
Displaying the ADAC Ports tab	273
Topology configuration using Enterprise Device Manager	274
Viewing topology information	275
Viewing topology table information	275
System Log configuration using Enterprise Device Manager	276
Viewing system log settings	
Viewing remote system log properties	278
Viewing system logs	278
LLDP configuration using Enterprise Device Manager	279
Configuring LLDP transmit properties	280
Configuring LLDP ports	283
TX Stats	285
RX Stats	286
Viewing LLDP local system properties	288
Viewing LLDP local port properties	290
Viewing LLDP management properites	291
Viewing LLDP remote management properties	292
Viewing unknown TLVs received	
Viewing LLDP organizationally-specific properties	
LLDP Port dot1 configuration using Enterprise Device Manager	
Viewing LLDP VLAN ID properties	
Viewing LLDP protocol VLAN properties	
Viewing LLDP VLAN Name properties	
Viewing LLDP protocol properties.	
Viewing LLDP VLAN ID properties	
Viewing LLDP Neighbor Protocol VLAN properties	
Viewing LLDP VLAN Name properties	
Viewing LLDP Neighbor Protocol properties	
LLDP Port dot3 configuration using Enterprise Device Manager	
Viewing LLDP auto-negotiation properties	
Viewing LLDP PoE porperties	
Viewing LLDP link aggregation properties	
Viewing LLDP maximum frame size properties	
Viewing LLDP neighbor auto-negotiation properties	
Viewing LLDP neighbor PoE properties	
Viewing LLDP neighbor link aggregation properties	307

Viewing LLDP neighbor maximum frame size properties	308
LLDP Port MED configuration using Enterprise Device Manager	309
Viewing local policy properties	309
Local Location	310
Viewing LLDP local PoE PSE properties	314
Viewing LLDP neighbor capabilities properties	314
Viewing LLDP neighbor policy properties	315
Neighbor Location	316
Viewing LLDP neighbor PoE properties	318
Viewing LLDP neighbor PoE PSE properties	319
Viewing LLDP neighbor PoE PD properties	
Viewing LLDP neighbor inventory properties	
LLDP MED policy management using Enterprises Device Manager	323
Viewing LLDP MED policies	323
Creating LLDP MED policies	324
Editing LLDP MED policies	326
Deleting LLDP MED policies	
SNTP configuration using Enterprise Device Manager	327
Displaying the Simple Network Time Protocol tab	328
Setting the local time zone	329
Configuring daylight savings time	
Displaying the Summer Time Recurring tab	331
Power over Ethernet configuration with Enterprise Device Manager	332
Viewing global PoE properties for a unit	332
Viewing PoE properties for a port	
IPv6 configuration using Enterprise Device Manager	334
Configuring IPv6 global properties	
Displaying the ICMP Stats tab	
Displaying the ICMP Msg Stats tab	
Viewing SFP GBIC ports	337
napter 8: Configuration reference	
Factory default configuration	
dex	

10

Chapter 1: New in this release

The following sections detail what's new in Avaya Ethernet Routing Switch 5000 Series software release 6.2.

- Features on page 11
- Other changes on page 14

Features

See the following sections for feature changes:

- Software Licensing enhancements on page 11
- Running configuration ACLI display command enhancements on page 12
- Avaya Energy Saver on page 12
- Route scaling on page 12
- Secure Shell File Transfer Protocol (SFTP over SSH) on page 12
- SFP support on page 13
- 802.1AB (LLDP) MED Network Policy on page 14

Software Licensing enhancements

Software Licensing is a mechanism that allows you to use designated features, according to the license level that you purchase. In Release 6.2 the licensing process is simplified so that if you purchase a license, it remains valid when you upgrade to a version of software that includes additional features included in the license level—that is, you do not have to regenerate the license file, remove the old license from your switches and reload a new license file. Licensing is further simplified for a stack scenario. Automatic Unit Replacement has been updated to enable automatic update of a license for any replacement stack unit, including the Base Unit. For more information, see:

- Auto Unit Replacement (AUR) on page 28
- Auto Unit Replacement using the ACLI on page 114
- Configuring AUR on page 229

Running configuration ACLI display command enhancements

The show running-config ACLI command enhancements change the operation of the show running-configuration command. By default, show running-configuration displays only parameters that differ from the default configuration. You can use the verbose qualifier to display the entire ASCII configuration for the switch or stack. You can also use the module qualifier in the command to display the ASCII configuration for a specific feature. For more information, see <u>Displaying the current configuration</u> on page 128

The operation of the copy running-config tftp ACLI command is modified. By default, copy running-config tftp copies the complete contents of the running configuration file to a specified file on the TFTP server. With Release 6.2, you can use the module qualifier in the command to display the ASCII configuration for a specific feature, or you can use the verbose qualifier to copy the entire ASCII configuration for the switch or stack. For more information, see Storing the current configuration on page 129

Avaya Energy Saver

Avaya Energy Saver (AES) can reduce network infrastructure power consumption without impact to network connectivity. AES reduces direct power consumption by up to 40% because it uses intelligent switching capacity reduction in off-peak mode. AES can also use Power over Ethernet (PoE) port power priority levels to shut down PoE ports and provide more power savings. For more information, see .

- Avaya Energy Saver on page 31
- Avaya Energy Saver configuration using the ACLI on page 117
- Avaya Energy Saver configuration using Enterprise Device Manager on page 248

Route scaling

Up to 4000 routes, a doubling of routes available in the previous release, are available for the Ethernet Routing Switch 5600 Series products.

Secure Shell File Transfer Protocol (SFTP over SSH)

For enhanced network security, Secure FTP for secure file transfer over an SSH session is available in this release. For more information, see

- Secure Shell File Transfer Protocol (SFTP over SSH) on page 25
- Secure Transfer File Protocol configuration on page 143

12 Configuration — System October 2012

SFP support

Release 6.2 supports the following additional SFPs:

- AA1419050-E6
- AA1419051-E6
- AA1419051-E6
- AA1419053-E6
- AA1419054-E6
- AA1419055-E6
- AA1419056-E6
- AA1419057-E6
- AA1419058-E6
- AA1419059-E6
- AA1419059-E6
- AA1419060-E6
- AA1419061-E6
- AA1419062-E6
- AA1419063-E6
- AA1419064-E6
- AA1419065-E6
- AA1419066-E6
- AA1419067-E6
- AA1419068-E6
- AA1419071-E6
- AA1403007-E6
- AA1419074-E6
- AA1419075-E6
- AA1419076-E6
- AA1419077-E6

For more information, see Avaya Ethernet Routing Switch 5000 Series — Installation SFPs and XFPs, (NN47200-302).

802.1AB (LLDP) MED Network Policy

You can configure 802.1AB MED network policies to dynamically configure voice VLAN, DSCP, priority, and VLAN tagging on the switch for voice traffic received from an IP phone. When you enable LLDP and configure the MED network policies on the switch, the switch sends the network policies to the IP Phone. The IP phone processes the data in the LLDP PDU and transmits the voice traffic with the appropriate VLAN ID, VLAN tagging, DSCP and priority information.

When Automatic QoS is enabled, MED network policy is changed from the user defined DSCP value to DSCP 47 (0x2F).

You can configure MED network policies on a switch port that has ADAC enabled. The network policies have priority over the ADAC configuration on the port. For more information, see:

- 802.1AB MED network policies on page 72
- Configuring LLDP MED policies for switch ports on page 184
- Setting Ildp med-network-policies to the default values on page 185
- <u>Disabling LLDP MED policies for switch ports</u> on page 186
- Viewing Ildp med-network-policies on page 186
- <u>LLDP MED policy management using Enterprises Device Manager</u> on page 323

Other changes

See the following sections for information about changes that are not feature-related:

- Enterprise Device Manager on page 14
- Multiple Port Configuration on page 14

Enterprise Device Manager

Enterprise Device Manager (EDM) replaces both the Java-based Device Manager and Web-based management user interfaces. EDM is an embedded element management and configuration application for Ethernet Routing Switch 5000 Series switches. EDM provides a Web-based graphical user interface through a standard web browser for the convenience of full configuration and management on the switch, and retains the look and feel of Device Manager. For more information, see System configuration with Enterprise Device Manager on page 217.

Multiple Port Configuration

Among the many functions available in EDM, you can configure port-specific features for a single port, a group of ports, or all ports. Multiple Port Configuration appears as a pane in the

14 Configuration — System October 2012

work area wherever this function is available. By default the pane appears and you can close and open it with a click of the task bar. For more information about EDM, see Ethernet Routing Switch 5000 Series Fundamentals, (NN47200-104).

New in this release

Chapter 2: Introduction

This document provides the information and procedures required to configure the software for the Avaya Ethernet Routing Switch 5000 Series.

Unless otherwise indicated, this information applies to:

- Avaya Ethernet Routing Switch 5510-24T
- Avaya Ethernet Routing Switch 5510-48T
- Avaya Ethernet Routing Switch 5520-24T-PWR
- Avaya Ethernet Routing Switch 5520-48T-PWR
- Avaya Ethernet Routing Switch 5530-24TFD
- Avaya Ethernet Routing Switch 5698-TFD
- Avaya Ethernet Routing Switch 5698-TFD-PWR
- Avaya Ethernet Routing Switch 5650-TD
- Avaya Ethernet Routing Switch 5650-TD-PWR
- Avaya Ethernet Routing Switch 5632-FD

The term "Ethernet Routing Switch 5000 Series" is used in this document to describe the features common to the switches mentioned above.

A switch is referred to by its specific name while describing a feature exclusive to the switch.

The Avaya Ethernet Routing Switch 5000 Series switches operate in the Stand-alone Mode and Stacking Mode in this product release. A switch can be in Stand-alone Mode or in Stacking Mode, not both.

ACLI command modes

ACLI provides the following command modes:

- User EXEC
- Privileged EXEC
- Global Configuration
- Interface Configuration
- Router Configuration

Mode access is determined by access permission levels and password protection.

If no password is set, you can enter ACLI in User EXEC mode and use the enable command to move to the next level (Privileged EXEC mode). However, if you have read-only access, you

cannot progress beyond User EXEC mode, the default mode. If you have read-write access you can progress from the default mode through all of the available modes.

With sufficient permission, you can use the rules in the following table to move between the command modes.

Command mode and sample prompt	Entrance commands	Exit commands
User EXEC	No entrance command, default mode	exit
5530-24TFD>	aciaal mode	logout
Privileged EXEC	enable	exit
5530-24TFD#		or logout
Global Configuration	configure	mode, enter:
5530-24TFD(config)#		or exit To exit ACLI completely, enter: logout
Interface Configuration	From Global Configuration mode: To configure a port,	To return to Global Configuration mode, enter:
5530-24TFD(config-if)#	enter:	Exit
interface vlan	<pre>interface fastethernet <port number=""></port></pre>	To return to Privileged EXEC mode, enter: end
	To configure a VLAN, enter:	To exit ACLI completely, enter:
	fastethernet <vlan number=""></vlan>	logout
Router Configuration	From Global Configuration mode: To configure OSPF,	To return to Global Configuration mode, enter:
5530-24TFD(config-if)#	enter:	Exit
	router ospf To configure RIP, enter:	To return to Privileged EXEC mode, enter:
	router rip To configure VRRP, enter: router vrrp	end To exit ACLI completely, enter: logout

See Avaya Ethernet Routing Switch 5000 Series Fundamentals (NN47200-104) for more information about ACLI command modes.

Navigation

- System configuration fundamentals on page 21
- Power over Ethernet fundamentals on page 59
- LLDP fundamentals on page 67
- System configuration with ACLI on page 73
- System configuration with Enterprise Device Manager on page 217
- Configuration reference on page 339

Introduction

Chapter 3: System configuration fundamentals

The following sections contain system configuration fundamentals for the Avaya Ethernet Routing Switch 5000 Series.

Feature licensing

An Advanced License or a Trial license is required to enable certain features. These software licenses support the following six features:

- Split Multi-Link Trunking (SMLT)
- Open Shortest Path First (OSPF)
- Virtual Router Redundancy Protocol (VRRP)
- Equal Cost Multi Path (ECMP)
- PIM-SM
- IPv6 Forwarding

For more information about licenses, see Avaya Ethernet Switch 5000 Fundamentals (NN47200-104).

Trial license

Beginning with release 6.0, the switch offers a Trial License which enables OSPF, ECMP, VRRP, and SMLT, or any combination thereof for a period of 30 days. At the end of the 30 day trial period, the features will be disabled, with the exception of SMLT.

For more information about licenses, see Avaya Ethernet Switch 5000 Fundamentals (NN47200-104).

User access limitations

ACLI enables the administrator to limit user access through the creation and maintenance of passwords for Telnet and Console access. This is a two-step process that requires first creating the password and then enabling it.

Ensure that Global Configuration mode is entered in ACLI before you begin these tasks.



When a username and password is set to default, the change is only applied to the unit on which the command was run.

Customizing ACLI banner

The banner presented when a user logs in to the switch through ACLI can be configured to a user-defined value. The banner cannot exceed 1539 bytes, or 19 rows by 80 columns plus line termination characters.

The banner control setting is saved to NVRAM, and both the banner file and control setting are distributed to all units within a stack.

To customize ACLI banner with ACLI, refer to the following procedures:

- show banner command on page 199
- banner command on page 199
- no banner command on page 200

To customize ACLI banner with Enterprise Device Manager, refer to the following procedures:

- Displaying the Banner tab on page 227
- Displaying the Custom Banner tab on page 228

22 Configuration — System October 2012

TFTP server

Many of the processes in the switch can make use of a Trivial File Transfer Protocol (TFTP) server. The following sections detail how to set a default TFTP server for the switch and to clear these defaults through the command line interface:

- Configuring a default TFTP server with ACLI on page 143
- Displaying the default TFTP server with ACLI on page 143
- Clearing the default TFTP server with ACLI on page 142

Configuration downloads to a switch

The following sections provide information about configuration downloads.

Navigation:

- Updating switch software on page 23
- LED activity during software download on page 24
- Unit quick configuration feature on page 24
- ASCII configuration file on page 24

Updating switch software

Updating switch software is a necessary part of switch configuration and maintenance. Updating the version of software running on the switch can be accomplished through ACLI.

Before attempting to change the switch software, ensure that the following prerequisites are in place:

- The switch has been given a valid IP address.
- A Trivial File Transfer Protocol (TFTP) server is present on the network that is accessible by the switch and that has the desired software version loaded.
- If you change the switch software on an Avaya Ethernet Routing Switch 5530-24TFD or 5600 series with software stored on a USB Mass Storage Device, ensure that the Mass Storage Device has the desired software version loaded on it and is inserted into the front panel USB port.
- If you use ACLI, ensure that ACLI is in Privileged EXEC mode.

For details on updating switch software, refer to the following sections

- Changing switch software in the ACLI on page 126
- Config/Image/Diag file tab on page 261

LED activity during software download

During the software download process, the port LEDs light one after another in a chasing pattern except for ports 11, 12, 23, and 24 on an Avaya Ethernet Routing Switch 5510-24T and ports 35, 36, 47, and 48 on an Avaya Ethernet Routing Switch 5510-48T.

This chasing pattern is initially fast as the software image is downloaded but gradually slows as the switch erases the flash memory. This pattern speeds up again as the switch programs the new image into the flash memory.

When the process is complete, the port LEDs are no longer lit and the switch resets.

Unit quick configuration feature

You can use the quick configuration commands to automatically integrate a new unit into a stack. See New Unit Quick Configuration on page 78 for more information and the commands.

ASCII configuration file

With the Avaya Ethernet Routing Switch 5500 Series you can download a user-editable ASCII configuration file from a TFTP server.

After you download the file, the configuration file automatically configures the switch or stack according to ACLI commands in the file.

With this feature, you can generate command configuration files that can be used by several switches or stacks with minor modifications.

The maximum size for an ASCII configuration file is 500 KB; split large configuration files into multiple files.

Use a text editor to edit the ASCII configuration. The command format is the same as that of ACLI.

Download the ASCII configuration file to the base unit by using ACLI commands. The ASCII configuration script completes the process.

See Retrieving an ASCII configuration file on page 267 for more information and ACLI commands.

October 2012 24 Configuration — System

Multiple switch configuration management

The Avaya Ethernet Routing Switch 5000 Series supports the storage of two switch configurations in flash memory. The switch can use either configuration and must be reset in order for the configuration change to take effect.

A regular reset of the switch synchronizes any configuration changes to the active configuration whereas a reset to defaults causes the active configuration to be set to factory defaults. The inactive block is not affected.

In stack configurations, all units in the stack must use the same active configuration. If a unit joins a stack, a check is performed between the unit's active configuration and the stack's active configuration. If the two are not the same, the new stack unit resets and loads the stack's active configuration.

- show nvram block command on page 77
- copy config nvram block command on page 77
- copy nvram config block command on page 77

Secure Shell File Transfer Protocol (SFTP over SSH)

With this feature, you can securely transfer a binary configuration file from a switch or stack to an SFTP server or from an SFTP server to the switch or stack using the SFTP protocol with SSH version 2.

Release 6.2 supports the following SFTP features:

- a binary configuration file upload to an SFTP server
- a binary configuration file download from a SFTP the server
- DSA-key authentication
- password authentication
- host key generation
- 1024-bit DSA-key use for authentication

Stacking fundamentals

The following sections provide information on stacking fundamentals.

Navigation:

- Stacking capabilities on page 26
- Stack monitor on page 27
- Agent Auto Unit Replacement (AAUR) on page 28
- Auto Unit Replacement (AUR) on page 28
- Stack Forced Mode on page 30
- IP blocking on page 31
- Avaya Energy Saver on page 31

Stacking capabilities

You can use the Avaya Ethernet Routing Switch 5000 Series switches in either of the following configurations:

- stand-alone
- stack

The Avaya Ethernet Routing Switch 5000 Series switches have a built-in cascade port to stack up to eight units.

A stack can consist of any combination of Avaya Ethernet Routing Switch 5000 Series switches.

Important:

All units in the stack must use the same software version.

To set up a stack, perform the following procedure.

Procedure steps

- 1. Power down all switches.
- 2. Set the Unit Select switch in the back of the non base units to the off position.
- 3. Set the Unit Select switch in the back of the base unit to base position.
- 4. Ensure all the cascade cables are properly connected and screwed into the unit.
- 5. Power up the stack.

Important:

In a hybrid stack of Avaya Ethernet Routing Switch 5000 Series, you must set an Avaya Ethernet Routing Switch 5600 Series switch type as the base unit.

October 2012 26 Configuration — System

Stack monitor

The Avaya Ethernet Routing Switch 5000 series stacks support the following two modes of operation:

- Pure
- Hvbrid

You can create a pure stack with up to eight Avaya Ethernet Routing Switch 5500 Series switches or eight Avaya Ethernet Routing Switch 5600 Series switches.

You can create a hybrid or mixed stack of up to eight switches that is a combination of Avaya Ethernet Routing Switch 5500 Series switches and Avaya Ethernet Routing Switch 5600 Series switches.

Important:

In a hybrid stack of Avaya Ethernet Routing Switch 5000 Series, you must set an Avaya Ethernet Routing Switch 5600 Series switch type as the base unit.

Stack manager is responsible for the following functions that form and maintain a stack.

- Base unit selection.
- Unit discovery.
- Unit number assignment.
- Database exchange.
- Join stack handling.
- Programming the hardware for the stack to function as a system.

Stack manager also handles link events from the Hello module when a unit is added or removed from the stack. Based on the event, the stack manager again runs through the state machine to discover the newly added unit or change the stack configuration. Stack manager supports following stack configurations:

- Ring topology: All the units are connected as a ring.
- Upstream: All the non-base units are upstream to the base unit.
- Downstream: All the non-base units are downstream to the base unit.
- Up Down: Non base units are both upstream and downstream of the base unit.

Stack manager supports a maximum of eight switches in a pure or hybrid stack. Although the design does not restrict the number of ports in a stack, Avaya recommends that the number does not exceed 400 ports.

To create a hybrid stack, you must first set the mode parameter on the Avaya Ethernet Routing Switch 5600 Series switches to hybrid mode. Avaya Ethernet Routing Switch 5500 Series switches do not have a mode parameter.

See <u>Stack manager</u> on page 75 for more information about the stack manager and the procedure and ACLI commands to set the stack manager.

Agent Auto Unit Replacement (AAUR)

Software Release 4.2 and later supports Agent Auto Unit Replacement (AAUR), an enhancement to Auto Unit Replacement.

Enabled by default, AAUR inspects non base replacement units joining a stack. If the replacement units do not contain the same software image as the base unit, AAUR downloads the software image from the base unit to the replacement units.

You can use ACLI commands to manage and configure AAUR.

How AAUR works

- When you insert a replacement unit into an AAUR-enabled stack, AAUR compares the switch software image on the replacement unit to the stack software image.
- If the replacement unit software image differs from the stack software image, AAUR downloads the stack software image from the base unit to the replacement unit.
- The system resets the new unit.
- The new unit becomes a member of the stack after reboot.

Once the replacement unit joins the stack, unless you have disabled Auto Unit Replacement (AUR), AUR installs the configuration from the old unit onto the replacement unit if it has the same hardware configuration, and the system resets the replacement unit. Now all units are running the same software version and the configurations are restored. For more information, see Auto Unit Replacement (AUR) on page 28

For more information about AAUR and ACLI commands, see <u>Agent Auto Unit Replacement</u> (<u>AAUR</u>) on page 204.

Auto Unit Replacement (AUR)

Enabled by default, Auto Unit Replacement (AUR) restores the configuration of the original unit to the replacement unit when you replace a unit in a stack. The new unit must be the same hardware configuration as the old, including the same number of ports. If you add a new unit with a different hardware configuration, the system uses the configuration of the new unit.

From Release 6.2 and later, Automatic Unit Replacement (AUR) can automatically update a software feature license for any replacement stack unit, including the Base Unit.

28 Configuration — System October 2012

You can disable AUR with ACLI and the switch retains the AUR state after a reset. Logs messages are available for AUR.

AUR is not compatible with software versions prior to 4.1.

Important:

For Auto Unit Replacement to operate, stack power must be on during the unit replacement because configuration images are retained in the stack DRAM.

AUR does not work on a stack of only two units because, if a unit fails, the remaining unit becomes a standalone switch and AUR does not load the configuration of the failed unit if it is replaced.

Important:

Avaya recommends that the replacement unit runs the same version of diagnostics as the stack base unit.

When AUR is enabled, you can

- manually restore an associated configuration (same unit number) to a non base unit, regardless of the MAC address
- manually configure a non base unit to the base unit regardless of the state of AUR

When AUR is enabled, you cannot

- manually restore configuration for a base unit
- manually save a configuration for a base unit

Important:

If you reset the base unit before you restore the configuration, the base unit erases the saved configuration information for non base units.

After you reboot a stack, you can use ACLI command show stack auto-unitreplacement from a unit console to determine whether that unit is ready for replacement.

Following is an example of the command output:

```
Auto Unit Replacement Auto-Restore: Enabled Auto Unit Replacement Auto-Save: Disabled
Unit # Last Configuration-Save Time-Stamp 1 3 days 10:23:02 2 0 days 00:01:40 3 3 days 10:12:33 6 3 days 10:12:33 6 3 days 10:12:35
```

Figure 1: show stack auto-unit replacement

For information about configuring AUR with ACLI, see Configuring AUR with ACLI on page 201.

For information about configuring AUR with Enterprise Device Manager, see Configuring AUR on page 229.

Stack Forced Mode

Stack Forced Mode allows one or both units to become stand-alone switches if a stack of two units breaks. The Stack Forced Mode allows you to manage one of the stand-alone devices from a broken stack of two with the previous stack IP address.

If you enable Stack Forced Mode on a stack, you enable Stack Forced Mode on all units in the stack. Stack Forced Mode becomes active only if the stack fails.

For instructions to configure stack forced mode with ACLI, see <u>Setting Stack Forced Mode</u> on page 207.

Stack Forced Mode applies to a stand-alone switch that is part of a stack of two units. When functioning in this mode, the stand-alone switch keeps the previous stack IP settings (IP address, netmask, gateway). That allows an administrator to reach the device through an IP connection by telnet or Enterprise Device Manager.

If one unit fails, the remaining unit (base or non-base unit) keeps the previous stack IP settings. The remaining unit issues a gratuitous ARP packet when it enters Stack Forced Mode, in order for other devices on the network to update their ARP cache.

If the stack connection between the two units fails (a stack cable failure, for example), both stand-alone units retain the IP settings. To detect if the other stack partner is also using the previous stack IP settings, each device issues an ARP request on the IP address.

When a failure occurs in a stack of 2 units when forced stack mode is enabled, the previous non-base unit will send out a gratuitous ARP onto the management network. The purpose of sending out this gratuitous ARP is so that the non-base unit of a failed 2 unit stack can determine if the base unit is still operational and using the stack IP address. Such a failure situation in which both the base unit and non-base unit were operational, but not part of a stack could be possible if the 2 units in a stack were connected by a single stack cable and that stack cable were then removed or failed. If the previous non-base unit receives a reply from the previous base unit of the stack, then the previous non-base unit knows that the previous base unit is still operational and does not take over ownership of the stack IP address, but instead will use the local switch IP address if configured. If on the other hand the previous non-base unit does not receive a response from the previous base-unit; the previous non-base unit will now take over ownership of the stack IP address and issue a gratuitous ARP with it's own MAC address to ensure that all devices on the management VLAN have their ARP caches appropriately updated.

Stack Forced Mode allows non-EAP clients connected to the device to still authenticate themselves and maintain connectivity to the network. Non-EAP clients authenticate by the device with RADIUS, which is based on the stack IP address. In Stack Forced Mode, the device retains the IP settings of the stack of two.

The functional unit stays in Stack Forced Mode until either a reboot or it joins a stack.

A settlement timer prevents several stack failures that occur at an interval of a few seconds to lead to a device entering Stack Forced Mode after it was part of a stack larger than two units. A device enters Stack Forced Mode if and only if it was part of a stack of two for 30 seconds or longer.

If the switch is in Stack Force mode and you want to set a switch IPv6 address, you must first delete the active IPv6 interface and then configure the switch IPv6 address. If you use Telnet, SSH or Enterprise Device Manager to change the settings, the switch will lose IPv6 connectivity to the switch. Avaya recommends that you change the settings with the Console Interface to switch or use an IPv4 address for management.

IP blocking

Along with IP Routing, you can use Blocking Mode in two modes: full and none. The following paragraphs show how blocking mode acts for a stack.

You have a stack with IP Routing enabled and some Layer 3 VLANs. Assign VLANs ports from all the units. Set IP blocking-mode to Full on the base unit. Remove all the units from stack. All of the units will run in Layer 2 mode. No Layer 3 settings will be available on these units.

You have a stack with IP Routing enabled, and some Layer 3 VLANs. Assign VLANs ports from all the units. Set the IP blocking-mode to None on the base unit. Remove all of the units from stack. The Layer 3 settings made on the stack will be available on these units. By default IP blocking-mode is None.

Avaya Energy Saver

You can use Avaya Energy Saver (AES) to reduce network infrastructure power consumption without impacting network connectivity. AES uses intelligent switching capacity reduction in off-peak mode to reduce direct power consumption by up to 40%. AES can also use Power over Ethernet (PoE) port power priority levels to shut down low priority PoE ports and provide more power savings.

The power consumption savings of each switch is determined by the number of ports with AES enabled and by the power consumption of PoE ports that are powered off. If AES for a port is set to disabled, the port is not powered off, irrespective of the PoE configuration. AES turns off the power to a port only when PoE is enabled globally, the port AES is enabled, and the PoE priority for the port is configured to low.

You can schedule AES to enter lower power states during specified periods of time. These time periods can be a complete week, complete weekend, or individual days.

Avaya recommends disabling AES on uplink copper ports since activating or deactivating AES on copper ports will trigger a link down followed rapidly by a link up event. The best solution is to use fiber ports for uplinks since link status will not change when AES is activated or deactivated.

! Important:

If a switch is reset while energy-saver is activated, the PoE power saving calculation may not accurately reflect the power saving, and in some cases may display zero savings. This is because the switch did not have sufficient time to record PoE usage between the reset of the switch and energy-saver being reactivated. When energy saver is next activated, the PoE power saving calculation will be correctly updated.

Boot agent image

The Dual Agent feature provides support for two agents for Ethernet Routing Switch 5500 or 5600 series in stand-alone, pure stack or for a mixed (hybrid) stack configuration. Dual Agent functionality is not supported on Ethernet Routing Switch 5510.

The Dual Agent feature provides two agent images, the Agent Primary image and the Agent Secondary image. The Agent Primary image represents the agent image used for the next boot. User is able to select either image for the next boot.

An Ethernet Routing Switch 56xx unit has two combo images in the flash. In another word, an Ethernet Routing Switch 5600 unit has two Ethernet Routing Switch 56xx agent images and two Ethernet Routing Switch 55XX agent images in the flash. An Ethernet Routing Switch 55XX unit has two Ethernet Routing Switch 55XX images in the flash.

In a mixed stack with both Ethernet Routing Switch 5500 units and Ethernet Routing Switch 5600 units, an Ethernet Routing Switch 5600 must be the base unit. For a mixed stack to use the Dual Agent feature, the following conditions must be met:

- All Ethernet Routing Switch 5600 units must have the same agent software version.
- All Ethernet Routing Switch 5500 units must have the same agent software version.
- All unit agent software must have the same Interop Software Version Number (ISVN).

Special Case: If an Ethernet Routing Switch 5510 is the base unit, Dual Agent is disabled in the stack.

The Dual Agent Boot flag determines which agent image is the boot image. The diagnostics and agent software must use the same value for the Dual Agent Boot flag.

If the Dual Agent Boot flag is not set, the unit will boot from Agent 1 (default).

Configuration — System October 2012

Next Boot image and system Boot-up in Dual Agent

The Next Boot image in Dual Agent is an agent image that is stored in the flash memory to be used for the next boot. In Dual Agent, there are two agent images in the flash memory, but only one image is assigned as the Next Boot image at a time.

When an agent image is downloaded to the switch, the unit resets and boots up with the newly downloaded image regardless of the value of the Next Boot image indicator. If an agent image is downloaded to the switch without a reset of the unit, the newly downloaded image becomes the Next Boot image.

You can change the Next Boot image at any time. The Next Boot image indicator (a value to indicate which agent image in the flash memory is used in the next boot) is stored in the NVRAM. This value, combined with other factors in the stack discovery process, determines which Dual Agent image the switch uses.

System boot-up for stand-alone

A stand-alone unit boots up with the Next Boot image from the NVRAM.

System boot-up for stack

The following lists the boot-up sequence:

- All the units in the stack start up with the Next Boot image.
- The stack does the following operations in the stack discovery phase:
 - The Next Boot image in the BU is used as the reference image.
 - If the Next Boot image in the NBU matches with the BU Next Boot image, the NBU continue to boot with the current Next Boot image.
 - If both images in the NBU do not match with the BU Next Boot image, the unit continues to boot with the current Next Boot image.
 - If the Next Boot image in the NBU does not match with the BU Next Boot image, but the other image in the NBU is matched, the matched image is selected as the Next Boot image then the unit is reset.

Dual Agent and Ethernet Routing Switch 5510

Dual Agent supports an Ethernet Routing Switch 5510 NBU with AAUR.

The following example shows how Dual Agent uses AAUR in a stack that contains Ethernet Routing Switch 5510 NBUs if you toggle the Next Boot image:

- All units in the stack reset with the new Next Boot image except for the Ethernet Routing Switch 5510 NBUs that will reset with only the agent image because they do not have the second image.
- All the units join stack except for the Ethernet Routing Switch 5510 units that now become stand-alone units because the agent image is now different from the one from in the stack.
- The Ethernet Routing Switch 5510 stand-alone units get the new image from the stack through AAUR and join the stack.

The following graphic shows what happens when you toggle the Next Boot image:

```
5650TD (config)#show boot image
UNIT
           PRIMARY
                          SECONDARY
                                          ACTIVE
          6.1.0.141
                         6.1.0.140
                                         6.1.0.141
          6.1.0.141
                         6.1.0.140
                                         6.1.0.141
                         6.1.0.140
5650TD (config)#toggle-next-boot-image
5650TD (config)#show boot image
UNIT
           PRIMARY
                          SECONDARY
                                          ACTIVE
 1
         6.1.0.140
                         6.1.0.141
                                         6.1.0.141
         6.1.0.140
                         6.1.0.141
                                         6.1.0.141
 3
         6.1.0.140
                         6.1.0.141
                                         6.1.0.141
5650TD (config)#boot
```

Figure 2: show boot image

5650TD (config)#show boot image

After the restart, the device starts up with version 6.2.0.140. This becomes the active image:

```
UNIT PRIMARY SECONDARY ACTIVE

1 6.1.0.140 6.1.0.141 6.1.0.140
2 6.1.0.140 6.1.0.141 6.1.0.140
3 6.1.0.140 6.1.0.141 6.1.0.140
```

Figure 3: show boot image after restart

Combination image

The Combination (Combo) Agent Image contains the header of the image and two agent images, a 56xx agent image and a 55XX agent image.

Download combination image

Any 55xx software release before release 6.0 does not support the Combo image.

A stand-alone unit or a stack that uses the Ethernet Routing Switch 5000 Series Software Release 6.2 can download a combo image. Release 6.2 is available in two different formats: a file in Combo format version 6.2 and a file in 55xx image format version 6.2.

The 55xx image format in this release is necessary because not all of the current 55xx releases support the Combo image.

Ethernet Routing Switch 5600 stand-alone

The unit downloads the combo image through the TFTP or USB port then stores the image in a flash device.

Ethernet Routing Switch 5000 Series mixed stack

The base unit receives the combo image through the TFTP or USB port then transfers the image to the non-base units. The Ethernet Routing Switch 5600 unit non-base units receive the combo image and the Ethernet Routing Switch 5500 non-base units receive the 5500 series image that is extracted from the combo image.

All of the units in the stack store the received image in flash devices.

Ethernet Routing Switch 5500 stand-alone

The unit extracts the 5500 series image from the combo image through the TFTP or USB port then stores the image in a flash device.

Ethernet Routing Switch 5000 Series mixed stack

The base unit extracts the 5500 series image through the TFTP or USB port then transfers the image to the non-base units.

All of the units in the stack store the received image in flash devices.

Combo Diagnostic Image

The Combo Diagnostic Image contains the header of the image and two Diagnostic images: a 56xx diagnostic image and a 55xx diagnostic image.

Any 55xx software release before release 6.0 does not support the Combo Diagnostic image.

A stand-alone unit or a stack that uses the Ethernet Routing Switch 5000 Series software release 6.0 can download a combo diagnostic image.

This diagnostic release for the new software release 6.2 is available in two different formats: a file in Combo format and a file in 55xx format. The 55xx image format in this release is necessary because all the current 55xx releases do not support the Combo diagnostic image.

The considerations for downloading a Combo Agent Image also apply to downloading a Combo Diagnostic Image.

Supported BootP modes

The following section describes the supported BootP modes.

Navigation:

• BootP mode on page 36

BootP mode

The Avaya Ethernet Routing Switch 5000 Series supports the Bootstrap protocol (BootP).

BootP enables you to retrieve an ASCII configuration file name and configuration server address.

A properly configured BootP server enables the switch to automatically learn its assigned IP address, subnet mask and the IP address of the default router (default gateway).

The Avaya Ethernet Routing Switch 5000 Series has a unique 48-bit hardware address, or MAC address, that is printed on a label on the back panel. Use this MAC address when you configure the network BootP server to recognize the Avaya Ethernet Routing Switch 5000 Series BootP requests.

The BootP modes supported by the Avaya Ethernet Routing Switch 5000 Series are:

- BootP or Last Address mode
- BootP When Needed. This is the default mode.
- BootP Always
- BootP Disabled. Disabling BootP also disables DHCP.

IPv6 management

This module provides information about the IPv6 management feature of the Avaya Ethernet Routing Switch 5000 Series switch platforms.

Navigation

- The IPv6 header on page 38
- IPv6 addresses on page 38
- Table 1: IPv6 address format on page 38
- Interface ID on page 38
- Address formats on page 39
- IPv6 extension headers on page 39
- Comparison of IPv4 and IPv6 on page 40
- ICMPv6 on page 41
- Neighbor discovery on page 41
- ND messages on page 43
- Neighbor discovery cache on page 44
- Router discovery on page 45
- Path MTU discovery on page 46
- Router discovery on page 45
- Router advertisement on page 45
- Router solicitation on page 45
- Path MTU discovery on page 46

IPv6 Management allows the user to configure an IPv6 address on the management VLAN. This enables IPv6 connectivity. The management VLAN can have both an IPv4 and an IPv6 address configured simultaneously (Avaya Ethernet Routing Switch 5000 Series switches function as a dual stack network node).

IPv6 routing is supported in the current phase. You can perform IPv6 interface configuration with ACLI or SNMP (Enterprise Device Manager). For more control over IPv6, use ACLI or Enterprise Device Manager.

IPv6 Management adds support for new standard MIBs (IP-MIB — RFC 4293, TCP-MIB — RFC 4022, UDP-MIB — RFC 4113) as well as the enterprise MIB rclpv6.

The IPv6 header

The IPv6 header contains the following fields:

- a 4-bit Internet Protocol version number, with a value of 6
- an 8-bit traffic class field, similar to Type of Service in IPv4
- a 20-bit flow label that identifies traffic flow for additional Quality of Service (QoS)
- a 16-bit unsigned integer, the length of the IPv6 payload
- an 8-bit next header selector that identifies the next header
- an 8-bit hop limit unsigned integer that decrements by 1 each time a node forwards the packet (nodes discard packets with hop limit values of 0)
- a 128-bit source address
- a 128-bit destination address

IPv6 addresses

IPv6 addresses are 128 bits in length. The address identifies a single interface or multiple interfaces. IPv4 addresses, in comparison, are 32 bits in length. The increased number of possible addresses in IPv6 solves the inevitable IP address exhaustion inherent to IPv4.

The IPv6 address contains two parts: an address prefix and an IPv6 interface ID. The first 3 bits indicate the type of address that follows.

The following table shows the IPv6 address format.

Table 1: IPv6 address format

Type Address	Interface ID (or token)
--------------	-------------------------

An example of a unicast IPv6 address is 1080:0:0:0:8:8000:200C:417A

Interface ID

The interface ID is a unique number that identifies an IPv6 node (a host or a router). For stateless autoconfiguration, the ID is 64 bits in length.

In IPv6 stateless autoconfiguration, the interface ID is derived by a formula that uses the link layer 48-bit MAC address. (In most cases, the interface ID is a 64-bit interface ID that contains the 48-bit MAC address.) The IPv6 interface ID is as unique as the MAC address.

October 2012 Configuration — System

If you manually configure interface IDs or MAC addresses (or both), no relationship between the MAC address and the interface ID is necessary. A manually configured interface ID can be longer or shorter than 64 bits.

Address formats

The format for representing an IPv6 address is

n:n:n:n:n:n:n

n is the hexadecimal representation of 16 bits in the address. An example is as follows:

FF01:0:0:0:0:0:0:0:43

Each nonzero field must contain at least one numeral. Within a hexadecimal field, however, leading zeros are not required.

Certain classes of IPv6 addresses commonly include multiple contiguous fields containing hexadecimal 0. The following sample address includes five contiguous fields containing zeroes with a double colon (::):

FF01"43

You can use a double colon to compress the leading zero fields in a hexadecimal address. A double colon can appear once in an address.

An IPv4-compatible address combines hexadecimal and decimal values as follows:

x:x:x:x:x:d.d.d.d

x:x:x:x:x:x is a hexadecimal representation of the six high-order 16-bit pieces of the address, and d.d.d.d is a decimal representation of the four 8-bit pieces of the address. For example:

0:0:0:0:0:0:13.1.68.3

or

::13.1.68.3

IPv6 extension headers

IPv6 extension headers describe processing options. Each extension header contains a separate category of options. A packet can include zero or more extension headers. The following graphic shows the IPv6 header and extension headers:




Figure 4: IPv6 header and extension headers

IPv6 examines the destination address in the main header of each packet it receives; this examination determines whether the router is the packet destination or an intermediate node in the packet data path. If the router is the destination of the packet, IPv6 examines the header extensions that contain options for destination processing. If the router is an intermediate node, IPv6 examines the header extensions that contain forwarding options.

By examining only the extension headers that apply to the operations it performs, IPv6 reduces the amount of time and processing resources required to process a packet.

IPv6 defines the following extension headers:

- The hop-by-hop extension header contains optional information that all intermediate IPv6 routers examine between the source and the destination.
- The end-to-end extension header contains optional information for the destination node.
- The source routing extension header contains a list of one or more intermediate nodes that define a path for the packet to follow through the network, to its destination. The packet source creates this list. This function is similar to the IPv4 source routing options.
- The fragmentation extension header uses an IPv6 source to send packets larger than the size specified for the path maximum transmission unit (MTU).
- The authentication extension header and the security encapsulation extension header, used singly or jointly, provide security services for IPv6 datagrams.

Comparison of IPv4 and IPv6

The following table compares key differences between IPv4 and IPv6.

Table 2: IPv4 and IPv6 differences

Feature	IPv4	IPv6
¹ Ethernet Routing Switch 5000 Series does not support IPsec. ² Ethernet Routing Switch 5000 Series does not perform Router discovery or advertise as a router. ³ Ethernet Routing Switch 5000 Series does not implement any form of automatic configuration of IPv6 address in release 6.0.		
Address length	32 bits	128 bits
IPsec support ¹	Optional	Required

Feature	IPv4	IPv6
QoS support	Limited	Improved
Fragmentation	Hosts and routers	Hosts only
Minimum MTU (packet size)	576 bytes	1280 bytes
Checksum in header	Yes	No
Options in header	Yes	No
Link-layer address resolution	ARP (broadcast)	Multicast Neighbor Discovery Messages
Multicast membership	IGMP	Multicast Listener Discovery (MLD)
Router discovery ²	Optional	Required
Uses broadcasts	Yes	No
Configuration ³	Manual, DHCP	Automatic, DHCP

ICMPv6

Internet Control Message Protocol (ICMP) version 6 maintains and improves upon features from ICMP for IPv4. ICMPv6 reports the delivery of forwarding errors, such as destination unreachable, packet too big, time exceeded, and parameter problem. ICMPv6 also delivers information messages such as echo request and echo reply.

Important:

ICMPv6 plays an important role in IPv6 features such as neighbor discovery, Multicast Listener Discovery, and path MTU discovery.

Neighbor discovery

IPv6 nodes (routers and hosts) on the same link use neighbor discovery (ND) to discover link layer addresses and to obtain and advertise various network parameters and reachability information. ND combines the services provided for IPv4 with the Address Resolution Protocol (ARP) and router discovery. Neighbor discovery replaces ARP in IPv6.

Hosts use ND to discover the routers in the network that you can use as the default routers, and to determine the link layer address of their neighbors attached on their local links. Routers also use ND to discover their neighbors and their link layer information. Neighbor discovery also updates the neighbor database with valid entries, invalid entries, and entries migrated to different locations.

Neighbor discovery protocol provides you with the following:

- Address and prefix discovery: hosts determine the set of addresses that are on-link for the given link. Nodes determine which addresses or prefixes are locally reachable or remote with address and prefix discovery.
- Router discovery: hosts discover neighboring routers with router discovery. Hosts establish neighbors as default packet-forwarding routers.
- Parameter discovery: host and routers discover link parameters such as the link MTU or the hop limit value placed in outgoing packets.
- Address autoconfiguration: nodes configure an address for an interface with address autoconfiguration.
- Duplicate address detection: hosts and nodes determine if an address is assigned to another router or a host.
- Address resolution: hosts determine link layer addresses (MAC for Ethernet) of the local neighbors (attached on the local network), provided the IP address is known.
- Next-hop determination: hosts determine how to forward local or remote traffic with next-hop determination. The next hop can be a local or remote router.
- Neighbor unreachability detection: hosts determine if the neighbor is unreachable, and address resolution must be performed again to update the database. For neighbors you use as routers, hosts attempt to forward traffic through alternate default routers.
- Redirect: routers inform the host of more efficient routes with redirect messages.

Neighbor discovery uses three components:

- host-router discovery
- host-host communication component
- redirect

The following graphic shows the neighbor discovery components:




Figure 5: Neighbor discovery components

42 Configuration — System October 2012

ND messages

The following table shows new ICMPv6 message types.

Table 3: IPv6 and IPv4 neighbor comparison

IPv4 neighbor function	IPv6 neighbor function	Description
ARP Request message	Neighbor solicitation message	A node sends this message to determine the link-layer address of a neighbor or to verify that a neighbor is still reachable through a cached link-layer address. You can also use neighbor solicitations for duplicate address detection.
ARP Reply message	Neighbor advertisement	A node sends this message either in response to a received neighbor solicitation message or to communicate a link layer address change.
ARP cache	Neighbor cache	The neighbor cache contains information about neighbor types on the network.
Gratuitous ARP	Duplicate address detection	A host or node sends a request with its own IP address to determine if another router or host uses the same address. The source receives a reply from the duplicate device. Both hosts and routers use this function.
Router solicitation message (optional)	Router solicitation (required)	The host sends this message upon detecting a change in a network interface operational state. The message requests that routers generate router advertisement immediately rather than at the scheduled time.
Router advertisement message (optional)	Router advertisement (required)	Routers send this message to advertise their presence together with various links

IPv4 neighbor function	IPv6 neighbor function	Description
		and Internet parameters either periodically or in response to a router solicitation message. Router advertisements contain prefixes that you use for on- link determination or address configuration, and a suggested hop limit value.
Redirect message	Redirect message	Routers send this message to inform hosts of a better first hop for a destination.

Neighbor discovery cache

The neighbor discovery cache lists information about neighbors in your network.

The neighbor discovery cache can contain the following types of neighbors:

• static: a configured neighbor

• local: a device on the local system

• dynamic: a discovered neighbor

The following table describes neighbor cache states.

Table 4: Neighbor cache states

State	Description
Incomplete	A node sends a neighbor solicitation message to a multicast device. The multicast device sends no neighbor advertisement message in response.
Reachable	You receive positive confirmation within the last reachable time period.
Stale	A node receives no positive confirmation from the neighbor in the last reachable time period.
Delay	A time period longer than the reachable time period passes since the node received the last positive confirmation, and a packet was sent within the last DELAY_FIRST_PROBE_TIME period. If no reachability confirmation is received within DELAY_FIRST_PROBE_TIME period of

State	Description
	entering the DELAY state, neighbor solicitation is sent and the state is changed to PROBE.
Probe	Reachability confirmation is sought from the device every retransmit timer period.

The following events involve Layer 2 and Layer 3 interaction when processing and affect the neighbor cache:

- flushing the Virtual Local Area Network (VLAN) media access control (MAC)
- removing a VLAN
- performing an action on all VLANs
- removing a port from a VLAN
- removing a port from a spanning tree group (STG)
- removing a multi-link trunk group from a VLAN
- removing a Multi-Link Trunking port from a VLAN
- removing a Multi-Link Trunking port from an STG
- performing an action that disables a VLAN, such as removing all ports from a VLAN
- disabling a tagged port that is a member of multiple routable VLANs

Router discovery

IPv6 nodes discover routers on the local link with router discovery. The IPv6 router discovery process uses the following messages:

- Router advertisement
- Router solicitation

Router advertisement

Configured interfaces on an IPv6 router send out router-advertisement messages. Routeradvertisements are also sent in response to router-solicitation messages from IPv6 nodes on the link.

Router solicitation

An IPv6 host without a configured unicast address sends router solicitation messages.

Path MTU discovery

IPv6 routers do not fragment packets. The source node sends a packet equal in size to the maximum transmission unit (MTU) of the link layer. The packet travels through the network to the destination. If the packet encounters a link with a smaller MTU, the router sends the source node an ICMP error message containing the MTU size of the next link.

The source IPv6 node then resends a packet equal to the size of the MTU included in the ICMP message.

The default MTU value for a regular interface is 1500.

Dynamic Host Configuration Protocol

Dynamic Host Configuration Protocol (DHCP) is defined by the RFC 2131. DHCP allows individual TCP/IP hosts on an IP network to obtain their configuration information from a DHCP server (or servers) that have no exact information about the individual hosts until they request configuration parameters. This reduces the work of system administrators, especially in larger IP networks, by eliminating the need to manually set every IP address. The most significant pieces of information distributed through DHCP are:

- the IP address
- the network mask
- the IP address of the gateway

In many networks, DHCP must coexist with VLANs, and the DHCP client can make its broadcasts only in the trusted VLANs. The DHCP client will run at startup just like the BootP client. The DHCP client restricts its discovery broadcasts to the management VLAN.

The DHCP modes supported by the Avaya Ethernet Routing Switch 5000 Series Series are:

- DHCP or Last Address mode
- DHCP When Needed.
- DHCP Always
- DHCP Disabled. Disable DHCP by setting BootP Disabled.

The host cannot act as a DHCP relay while the DHCP client is running.

46 Configuration — System October 2012

Simple Network Time Protocol

The Simple Network Time Protocol (SNTP) is a subset of the Network Time Protocol. It provides a simple mechanism for time synchronization. NTP enables clocks to be synchronized to a few milliseconds, depending on the clock source and local clock hardware.

SNTP synchronizes to the Universal Coordinated Time (UTC) with an error of less than one second. This feature adheres to the RFC 2030 (MIB is the s5agent). With this feature, the system can obtain the time from any RFC 2030-compliant NTP or SNTP server.

SNTP accuracy is typically in the order of "significant fractions of a second." This accuracy is related to the latencies between the SNTP client device and the NTP server. In a low latency network, the SNTP accuracy can be reduced to the sub-100 millisecond range and, to further increase the accuracy, a simple latency measurement algorithm can be used. The intended accuracy for this implementation is one second, which is sufficient for logs and time displays on user interfaces.

The SNTP feature allows you to set an offset from GMT for the time zone of your location. You can also set a start date and end date and offset for Daylight Savings Time.

The SNTP client implementation for this feature is unicast. The SNTP client operates typically in a unicast mode, but also can use the broadcast and multicast modes.

When SNTP is enabled (the default state is disabled), the system synchronizes with the configured NTP server at bootup (after network connectivity is established) and at userconfigurable periods thereafter (the default synchronization interval is 24 hours). The synchronization also can happen upon manual request.

The SNTP feature supports both primary and secondary NTP servers. SNTP attempts to contact the secondary NTP server only if the primary NTP server is unresponsive. When a server connection fails, SNTP retries for a maximum of three times, with five minutes between each retry.

Ping enhancement

Using ACLI you can specify additional ping parameters, including the number of ICMP packets to be sent, the packet size, the interval between packets, and the timeout. You can also set ping to continuous, or you can set a debug flag to obtain extra debug information.

For information about ACLI ping command, see ping command on page 110.

Auto-MDI X

The term auto-MDI/X refers to automatic detection of transmit and receive twisted pairs.

Auto-MDI/X detects, receive, and transmit twisted pairs automatically. When auto-MDI/X is active, any straight or crossover category 5 cable can be used to provide connection to a port. If autonegotiation is disabled, then auto-MDI/X is not active.

Auto-polarity

The term auto-polarity refers to the ability of the port to compensate for positive and negative signals being reversed on the receive cables.

The Avaya Ethernet Routing Switch 5000 Series support auto-polarity. With autonegotiation enabled, auto-polarity automatically reverses the polarity of a pair of pins from positive to negative or negative to positive. This corrects the polarity of the received data, if the port detects that the polarity of the data has been reversed due to a wiring error. If autonegotiation is disabled, auto-polarity is not active.

Autosensing and autonegotiation

The Avaya Ethernet Routing Switch 5000 Series are autosensing and autonegotiating devices:

- The term autosense refers to ability of a port to sense the speed of an attached device.
- The term autonegotiation refers to a standardized protocol (IEEE 802.3u or 802.3z or 802.3ab) that exists between two IEEE-capable devices. Autonegotiation enables the switch to select the best speed and duplex modes.

Autosensing is used when the attached device is not capable of autonegotiation or is using a form of autonegotiation that is not compatible with the IEEE 802.3z autonegotiation standard. If it is not possible to sense the duplex mode of the attached device, the Avaya Ethernet Routing Switch 5000 Series reverts to half-duplex mode.

When autonegotiation-capable devices are attached to the Avaya Ethernet Routing Switch 5000 Series, the ports negotiate down from 1000 Mb/s speed and full-duplex mode until the attached device acknowledges a supported speed and duplex mode.

Navigation:

- <u>Custom Autonegotiation Advertisements</u> on page 49
- Configuring CANA with ACLI on page 49

48 Configuration — System October 2012

- Viewing current autonegotiation advertisements on page 50
- Viewing hardware capabilities on page 51
- Setting default advertisements on page 52
- Silencing advertisements on page 53

Custom Autonegotiation Advertisements

In the Avaya Ethernet Routing Switch 5000 Series, the Custom Autonegotiation Advertisements (CANA) feature enables you to control the speed and duplex settings that each Ethernet port of the device advertises as part of the autonegotiation process.

Without CANA, a port with autonegotiation enabled advertises all speed and duplex modes that are supported by the switch and attempt to establish a link at the highest common speed and duplex setting. By using CANA, the port can be configured to advertise only certain speed and duplex settings, thereby allowing links to be established only at these settings, regardless of the highest common supported operating mode.

CANA also enables control over the IEEE802.3x flow control settings advertised by the port. as part of the autonegotiation process. Flow control advertisements can be set to Symmetric, Asymmetric, or Disabled if neither is selected.

You may not want a port to advertise all speed and duplex modes supported, in the following situations:

- If a network can support only 10 Mb/s connection, a port can be configured to advertise only 10 Mb/s capabilities. Devices using autonegotiation to connect to this port connect at 10 Mb/s, even if both devices are capable of higher speeds.
- If a port is configured to advertise only 100 Mb/s full-duplex capability, the link becomes active only if the link partner is also capable of autonegotiating a 100 Mb/s full duplex connection. This prevents mismatched speed or duplex settings if autonegotiation is disabled on the link partner.
- For testing or network troubleshooting, it can be useful to configure a link to autonegotiate at a particular speed or duplex mode.

Configuring CANA with ACLI

Use this procedure to configure CANA.

Procedure steps

Use the following command from Privileged EXEC mode: auto-negotiationadvertisements

Example

To configure port 5 to advertise the operational mode of 10 Mb/s and full duplex, enter the following command line: auto-negotiation-advertisements port 5 10-full

The following figure shows sample output for this command.

```
5510-48T(config-if)#auto-negotiation-advertisements port 5 10-full 5510-48T(config-if)#
```

Figure 6: auto-negotiation-advertisements command sample output

Viewing current autonegotiation advertisements

Use this procedure to view autonegotiation advertisements for the device.

Procedure steps

50

Use the following command from Privileged EXEC mode: show autonegotiation-advertisements [port <portlist>]

The following figure shows an example of the output for the show auto-negotiation-advertisements command.

Configuration — System October 2012

Comments? infodev@avaya.com

```
5510-48T#show auto-negotiation-advertisements
Port Autonegotiation Advertised Capabilities
1 10Full 10Half 100Full 100Half 1000Full
   10Full 10Half 100Full 100Half 1000Full
                                                               Pause
   10Full 10Half 100Full 100Half 1000Full
                                                               Pause
   10Full 10Half 100Full 100Half 1000Full
                                                               Pause
    10Full
    10Full 10Half 100Full 100Half 1000Full
                                                               Pause
    10Full 10Half 100Full 100Half 1000Full
                                                               Pause
    10Full 10Half 100Full 100Half 1000Full
                                                               Pause
    10Full 10Half 100Full 100Half 1000Full
                                                               Pause
   10Full 10Half 100Full 100Half 1000Full
10
                                                               Pause
   10Full 10Half 100Full 100Half 1000Full
11
                                                               Pause
   10Full 10Half 100Full 100Half 1000Full
                                                               Pause
   10Full 10Half 100Full 100Half 1000Full
13
                                                               Pause
14 10Full 10Half 100Full 100Half 1000Full
                                                               Pause
15 10Full 10Half 100Full 100Half 1000Full
                                                               Pause
16 10Full 10Half 100Full 100Half 1000Full
                                                               Pause
17 10Full 10Half 100Full 100Half 1000Full
                                                               Pause
18 10Full 10Half 100Full 100Half 1000Full
                                                               Pause
19 10Full 10Half 100Full 100Half 1000Full
                                                               Pause
   10Full 10Half 100Full 100Half 1000Full
                                                               Pause
----More (q=Quit, space/return=Continue)----
```

Figure 7: show auto-negotiation-advertisements command sample output

The following figure shows an example of the output for the show auto-negotiationadvertisements command.

```
5510-48T#show auto-negotiation-advertisements port 5
Port Autonegotiation Advertised Capabilities
----
5 10Full
5510-48T#
```

Figure 8: show auto-negotiation-advertisements command sample output

Note:

Port 5 has been configured to only advertise an operational mode of 10 Mb/s full duplex

Viewing hardware capabilities

Use this procedure to view the operational capabilities of the device.

Procedure steps

Use the following command from Privileged EXEC mode: show autonegotiation-capabilities [port <portlist>]

The following figure shows an example of the output for the show auto-negotiationcapabilities command.

```
5510-48T#show auto-negotiation-capabilities
Port Autonegotiation Capabilities
----
   10Full 10Half 100Full 100Half 1000Full
                                                            Pause
    10Full 10Half 100Full 100Half 1000Full
                                                            Pause
   10Full 10Half 100Full 100Half 1000Full
10
                                                            Pause
   10Full 10Half 100Full 100Half 1000Full
11
                                                            Pause
   10Full 10Half 100Full 100Half 1000Full
                                                            Pause
13 10Full 10Half 100Full 100Half 1000Full
                                                            Pause
   10Full 10Half 100Full 100Half 1000Full
                                                            Pause
15 10Full 10Half 100Full 100Half 1000Full
                                                            Pause
    10Full 10Half 100Full 100Half 1000Full
                                                            Pause
    10Full 10Half 100Full 100Half 1000Full
                                                            Pause
----More (q=Quit, space/return=Continue)----
```

Figure 9: show auto-negotiation-capabilities command sample output

The following figure shows an example of the output for the show auto-negotiationcapabilities command.

```
5510-48T#show auto-negotiation-capabilities port 5
Port Autonegotiation Capabilities
    10Full 10Half 100Full 100Half 1000Full
                                                                Pause
5510-48T#
```

Figure 10: show auto-negotiation-capabilities command sample output

Setting default advertisements

Use this procedure to set default autonegotiation advertisements for the device.

Procedure steps

Use the following command from Interface Configuration mode: default autonegotiation-advertisements [port <portlist>]

Example

To set default advertisements for port 5 of the device, enter the following command line: default auto-negotiation-advertisements port 5

Silencing advertisements

Use this procedure to set a port to not transmit any autonegotiation advertisements.

Procedure steps

Use the following command from Interface Configuration mode: no autonegotiation-advertisements [port <portlist>]

Exmale

To silence the autonegotiation advertisements for port 5 of the device, enter the following command line: no auto-negotiation-advertisements port 5

The following figure shows an example of the output for the default auto-negotiationadvertisements command.

```
5510-48T(config-if)#default auto-negotiation-advertisements port 5
5510-48T(config-if)#
```

Figure 11: default auto-negotiation-advertisements command sample output

The following figure shows an example of the output for the default auto-negotiationadvertisements command.

```
5510-48T(config-if) #no auto-negotiation-advertisements port 5
5510-48T(config-if)#
```

Figure 12: no auto-negotiation-advertisements command sample output

Rate Limiting Configuration

The Rate Limiting feature allows you to configure the threshold limits for broadcast and multicast packets ingressing on a port for a given time interval. The ERS 5000 Series drops packets received above the threshold value if the traffic ingressing on the port exceeds the threshold.

When the volume of either packet type is high, placing severe strain on the network (often referred to as a "storm"), you can set the ingress rate of those packet types to not exceed a specified percentage of the total available bandwidth.

Rate Limiting counts packets from the beginning of each second. When the number of packets reaches the value of the rate limit, all remaining packets are dropped until the end of the second. As a result, the packets are not evenly distributed over the course of a second. For this reason, rate limiting utilization counters/calculations can appear to be inaccurate.

3 Note:

Rate Limiting behaves differently when the egress (out) port speed is less than the ingress (in) port speed.

When rate limiting is enabled on an ingress port and the egress port operates at a slower speed, traffic is sent to the egress port at the ingress port's (wire) speed. Egress rate limiting is done through a token bucket, and is not averaged over each second. Once the token bucket is full, traffic is dropped, as indicated in the *Dropped on no Resources* counter. When rate limiting is enabled on an ingress port, this behavior can have an effect on unicast packets.

Clarification of behavior:

Rate limit counts packets on the ingress port until the limit is reached and then drops everything until the end of the second. On a 1 Gbps ingress port, the first 10% of the 1Gb (100Mb) is allowed in the first tenth of the second and sent to the 100Mbps egress port. However, the 100Mbps port cannot handle 100Mb in a tenth of a second, as it can only handle 10Mb in a tenth of a second, and the rest is dropped.

O Note:

If a packet with an unknown destination MAC is received (including during a FDB ageout) and rate limiting is set for either packet type of broadcast or both (broadcast and multicast), the rate limiting feature counts the unknown unicast packets in the same way as the broadcast packets. The system drops (filters) these unknown unicast packets.

Quick install

Quick Install allows users to take first configuration from a file found on a USB device or from a minimal configuration menu.

If the switch does not obtain an IP address using bootp, and, a file named IP.CFG exists on the USB device, then the switch loads the IP.CFG file as its first configuration.

See also Set IP parameters using IP.CFG file on a USB memory device on page 55.

54 Configuration — System October 2012

If the switch cannot find an IP address after the user presses CTRL + Y from long console then it shows a minimal menu. Quick Configuration encompasses multiple menus consolidating them into a single menu for the user to access and make the required initial setup modifications.

The user must enter the following information into the menu:

- IP address
- Sub-net mask
- Default gateway
- Read-only community string
- Read-write community string
- Quick start VLAN

Set IP parameters using IP.CFG file on a USB memory device

If the switch does not obtain an IP address through BootP, you can load the IP address and optionally new switch software and configuration from the USB memory device using the ip.cfg file.

☑ Note:

The file name, ip.cfg, is case-insensitive.

If a properly formatted file exists on a USB port, the switch uses that ip.cfg as the first option, rather than the last. You can specify one or more of the optional parameters in the ip.cfg file. All of the parameters are optional.

The following table describes the ip.cfg file parameters:

Table 5: IP.CFG file parameters

Parameter	Description
IP <xx.xx.xx.xx></xx.xx.xx.xx>	Specifies the IP address for the switch. Example: 192.168.22.1
Mask <xx.xx.xx.xx></xx.xx.xx.xx>	Specifies the network mask. Example: 255.255.255.0
Gateway <xx.xx.xx.xx></xx.xx.xx.xx>	Specifies the default gateway. Example: 181.30.30.254
SNMPread <string></string>	Specifies the SNMP read community string. Example: public
SNMPwrite <string></string>	Specifies the SNMP write community string. Example: private
VLAN <number></number>	Specifies the management VLAN-ID. Example: VLAN 1
USBdiag <string></string>	Specifies the filename of the diagnostic image to load from the USB. Example: ers5600/ers5600_6.0.0.10.bin

Parameter	Description
USBascii <string></string>	Specifies the filename of the ASCII config file to load from the USB. Example: customer1.cfg
USBagent <string>D NEXTIP, NEXTMask, and NEXTGateway</string>	Specifies the filename of the agent image to load from the USB and specifies IPs for next boot. Example: ers5600/ ers5600_6.2.0.0.img

O Note:

If you download an ASCII file or diag/image with an Ip.cfg file, the specific ASCII file or diag/image must be present on the usb device.

The ip.cfg file loads information from the ASCII configuration file in order of precedence. For example, if you have an ip.cfg file with the following commands:

```
USBascii ip.txt IP 181.30.30.113 Mask 255.255.255.0 Gateway 181.30.30.254
```

The stack IP becomes 181.30.30.113 no matter what IP address is in the ip.txt file.

If you have an ip.cfg file with the following commands:

IP 181.30.30.113 Mask 255.255.255.0 Gateway 181.30.30.254 USBascii
ip.txt

The stack IP will be the IP address defined in the ip.txt file.

3 Note:

56

The ip.cfg file runs only on a base or stand-alone unit. The file cannot be more than 4096 bytes or contain more than 200 lines.

The following figure shows an example of an ip.cfg file.

```
#Any lines starting with a # are comments \#IP < xx.xx.xx.xx> specifies the IP address for the switch
#Mask <xx.xx.xx.xx> specifies the network mask Mask 255.255.255.0
#Gateway <xx.xx.xx> specified the default gateway Gateway 172.16.1.1
#SNMPread <string> specified the SNMP read community string SNMPread public
#SNMPwrite <string> specified the SNMP write community string SNMPwrite private
#VLAN rumber> specified the management VLAN-ID VLAN 1
#USBdiag <string> specifies the filename of the diagnostic image to load (noreset)
USBdiag ers5600/ers5600_5.1.0.4.bin
#USBagent <string> specifies the filename of the agent image to load (noreset)
USBagent ers5600/ers5600_5.2.0.0.img
#USBascii <string> specifies the filename of the ASCII config file to load
USBascii customer1.cfg
#NEXTIP <xx.xx.xx.xx> specifies the IP address for the switch NEXTIP 172.16.1.23 #NEXTMask <xx.xx.xx.xx> specifies the network mask NEXTMask 255.255.255.0 #NEXTGateway <xx.xx.xx.xx> specified the default gateway NEXTGateway 172.16.1.1
```

Figure 13: Ip.cfg file example

If the ip.cfg file specifies an image or agent code, the switch loads the software, even if the same version is already installed on the switch. Ensuring that the appropriate software is always upgraded on the units is the correct operation of ip.cfg.

Use the factory default command to reset the switch to the factory default after you insert the USB memory device in the USB port. The USB memory device must contain the properly formatted ip.cfg file in the root directory.

System configuration fundamentals

Chapter 4: Power over Ethernet fundamentals

The information in this section provides an overview of Power over Ethernet (PoE). See the Avaya Ethernet Routing Switch 5000 Series Installation (NN47200-300) for detailed information about the installation of power supplies and details about PoE.

PoE in Avaya Ethernet Routing Switch 5000 Series switches uses the IEEE 802.3af standard.

PoE is the ability to power network devices over the Ethernet cable. Some such devices include IP Phones, Wireless LAN Access Points, security cameras, access control points, and so on.

The following 5000 Series switches provide PoE:

- Avaya Ethernet Routing Switch 5520-24T-PWR
- Avaya Ethernet Routing Switch 5520-48T-PWR
- Avaya Ethernet Routing Switch 5650-TD-PWR
- Avaya Ethernet Routing Switch 5698-TFD-PWR

The 5000 Series switches support the following PoE features:

- DTE power.
- Powered device (PD) discovery and classification.
- Capacitive detection to support legacy PD devices, including the Avaya and Cisco Legacy IP Phones.
- Port power management and monitoring for each port.
- AC and DC disconnection.
- Detection of load over or under voltage or current.
- PoE status LED for each port.
- Port prioritizing to guarantee DTE power available on high-priority ports
- Port pruning to prevent system failure

You can configure PoE with ACLI or Enterprise Device Manager. See the following sections for details:

- PoE overview on page 60
- Power source on page 61
- Stacking on page 61
- Power pairs on page 61
- Diagnosing and correcting PoE problems on page 62

- Power management on page 64
- Configuring PoE with ACLI on page 195
- Viewing PoE ports with Enterprise Device Manager on page 221

PoE overview

The 5000 Series switches are ideal to use with Avaya Business Communication Manager system, IP phones, hubs, and wireless access points. You can use these switches in conjunction with all network devices.

By using the 5000 Series switches, you can plug any IEEE 802.3af-compliant powered device into a front-panel port of a PoE-capable switch and receive power. Data can be passed simultaneously on that port.

The IEEE 802.3af draft standard regulates a maximum of 15.4 watts (W) of power for each port; that is, a power device cannot request more than 15.4 watts (W) of power. As different network devices require different levels of power, the overall available power budget of the 5000 Series switches depends on your power configuration and the particular connected network devices. If you connect an IP device that requires more than 16 W of power, you see an error on that port notifying you of an overload.

The 5000 Series switches automatically detect all IEEE 802.3af-draft-compliant powered devices attached to each front-panel port and immediately sends power to that appliance. The switch also automatically detects how much power each device requires and supplies the required DC voltage at a set current based on the load conditions and current availability. The switch supports both PoE and standard LAN devices.

The power detection function of the 5000 Series switches operate independently of the data link status. Power can be requested by a device that is already operating the link for data, or it can be requested by a device that is not yet operational. That is, the 5000 Series switches provide power to a requesting device even if the data link for that port is disabled. The switch monitors the connection and automatically disconnects power from a port when the device is removed or changed, as well as when a short occurs.

The 5000 Series switches automatically detect those devices that do not require power connections from it, such as laptop computers or other switching devices, and does not send any power to those devices. You control the supply of power to specific ports by setting the maximum allowed power to each port in 1 W increments, from 3 W to 16 W.

☑ Note:

Allow 30 seconds between unplugging and replugging an IP device to the switch to enable the IP device to discharge. If you attempt to make connection earlier, the switch may not detect the IP device.

October 2012 60 Configuration — System

Power source

The Avaya Ethernet Redundant Power Supply 15 is available as an optional external power source for the Avaya Ethernet Routing Switch 5520. Contact your Avaya representative for more information about the Avaya Ethernet Redundant Power Supply Unit 15.

The following are the available options to power the Avaya Ethernet Routing Switch 5520:

- Internal power source only
- External power source only:
 - Avaya Ethernet Redundant Power Supply 15
- Internal power source plus external power source:
 - Avaya Ethernet Redundant Power Supply 15

In a stack configuration, each unit can have its own external power source.

The 5650-TD-PWR and 5698-TFD-PWR switches use modular power supply units. The PoE capability at each 5600 Series switch port depends on the power supply modules that you install. See Avaya Ethernet Routing Switch 5000 Series Installation (NN47200-300) for information about the power supplies and PoE.

The PoE capability of each 5650-TD-PWR or 5698-TFD-PWR switch port depends on the power supply modules that you install. See the Avaya Ethernet Routing Switch 5000 Series Installation (NN47200-300) for information about the PoE capability at each port as a function of the power supply modules.

Stacking

You can stack the 5000 Series switches up to 8 units high. These stacks also can be configured for redundancy.

Power pairs

The 5000 Series switches support wiring as mentioned in the IEEE 802.3AF draft standard.

The 5000 Series switches supports power to Signal pair only.

See the Avaya Ethernet Routing Switch 5000 Series Installation (NN47200-300) for connector pinout tables and wiring specifics.

Diagnosing and correcting PoE problems

This section discusses some common problems that you can encounter while using the PoE features of the 5000 Series switches.

See the Avaya Ethernet Routing Switch 5000 Series Troubleshooting (NN47200-700) for detailed troubleshooting information.

Navigation:

- Messages on page 62
- Connecting the PSU on page 62

Messages

The following table describes the error messages displayed by a port that supports PoE.

Table 6: Error messages displayed by PoE ports

Error Message	Descriptions
Detecting	The port detects an IP device that is requesting power.
Delivering power	Port delivers the requested power to the IP device.
Disabled	The port power state is disabled.
Invalid PD	The port is detecting a device that is not authorized to request for power.
Deny low priority	Power disabled from the port because of port setting and demands on power budget.
Overload	Power disabled from the port because the port is overloaded.
Test	The port is in testing mode. This was set by using SNMP.
Error	An unspecified error condition has occurred.

Connecting the PSU

Perform this procedure in the order specified to connect the PSU to the Avaya Ethernet Routing Switch 5520.

Configuration — System October 2012 62

Procedure steps

- 1. Ensure that the DC ON/OFF switch on the back of the Avaya Ethernet Routing Switch 5520 is in the OFF position.
- 2. Plug the external power source into the DC connector receptacle on the back of the Avaya Ethernet Routing Switch 5520, by using the 2-pin power connector and 10pin control connector.
- 3. Attach the ground lug on a cable to a grounding point.
- 4. Plug the power cord from the Avaya Ethernet RPSU 15 to the wall outlet.
- 5. Plug the power cord from Avaya Ethernet Routing Switch 5520 into the wall outlet.
- 6. Turn the DC ON/OFF breaker on the back of the switch to the ON position.

Caution:

Ensure that the DC ON/OFF breaker is in the OFF position before you connect or disconnect the optional external power source.

The following figure shows 3 Avaya Ethernet RPSU 15s connected to the back of a stack of 3 Avaya Ethernet Routing Switch 5520 switches.

Note:

The grounding wire is connected with a screw, and a star washer is provided on the base of the Avaya Ethernet Routing Switch 5520.




Figure 14: External power source connected to back of the Avaya Ethernet Routing Switch 5520

Power management

The 5000 Series switch uses several device management systems, such as Command Line Interface (ACLI), and Enterprise Device Manager, as well as Optivity for network-level management services.

With ACLI or Enterprise Device Manager, you can configure the level of power to specific ports, as well as enable or disable power to each port. You can set the maximum power level for each port by increments of 1 W; in the range of 3 to 16 W. The default power level for each port is 16 W.

You can configure the power priority of each port by choosing low, high, or critical power priority settings. The switch automatically drops low-priority ports when the power requirements exceed the available power budget. If the power requirements are lower than the switch power budget, the power is returned to the dropped port.

For example, assume the following scenario:

- Ports 1 to 20 are configured as low priority
- Port 21 is configured as high priority
- Ports 1 to 20 are connected to powered devices
- Devices on ports are consuming all the available 5000 Series switch power
- A device is connected to port 21 and requests power

In this scenario, the 5000 Series switch provides power to the device on port 21 because that port is configured as high priority. However, to maintain the power budget, the switch drops one of the ports configured as a lower priority. As all the other ports (1 to 20) are configured with a low priority, the switch drops power to the highest port number. In this case, the switch drops power to port 20 and provides power to port 21. If another port drops power, the switch automatically reinstates power to port 20.

You configure the autodiscovery power process as either IEEE 802.3af compliant or IEEE 802.3af draft compliant and legacy:

- 802.3af -- detection method outlined in IEEE 802.3af draft standard
- legacy -- detection standard in use prior to IEEE 802.3af draft standard

The default value is IEEE 802.3af draft compliant. You can set this parameter for the entire switch; you cannot set the discovery mode for each port.

You can obtain power usage information from the management systems. Statistics do not accumulate. The system automatically disconnects the port from power when it detects overload on any port, and the rest of the ports remain functioning.

October 2012 64 Configuration — System

O Note:

Ensure that the switch is set for the power detection mode used by the connected powered device. Consult the device documentation for this information.

Power over Ethernet fundamentals

Chapter 5: LLDP fundamentals

The information in this section provides an overview of LLDP fundamentals.

Navigation:

- Link Layer Discover Protocol (IEEE 802.1ab) Overview on page 67
- LLDP operational modes on page 68
- Connectivity and management information on page 68
- 802.1AB MED network policies on page 72
- Avaya Automatic QoS enhancement for LLDP-MED on page 72

Link Layer Discover Protocol (IEEE 802.1ab) Overview

Release 5.0 software supports the Link Laver Discovery Protocol (LLDP) (IEEE 802.1ab). which enables stations connected to a LAN to advertise their capabilities to each other, enabling the discovery of physical topology information for network management. LLDPcompatible stations can consist of any interconnection device including PCs, IP Phones, switches, and routers. Each LLDP station stores LLDP information in a standard Management Information Base (MIB), making it possible for a network management system (NMS) or application to access the information.

Each LLDP station:

- advertises connectivity and management information about the local station to adjacent stations on the same 802 LAN (802.3 Ethernet with 5000 Series).
- receives network management information from adjacent stations on the same LAN.

LLDP also makes it possible to discover certain configuration inconsistencies or malfunctions that can result in impaired communications at higher layers. For example, it can be used to discover duplex mismatches between an IP Phone and the connected switch.

LLDP is compatible with IETF PROTO MIB (IETF RFC 2922).

The following figure shows an example of how LLDP works in a network.




Figure 15: LLDP: how it works

- 1. The Ethernet Routing Switch and LLDP-enabled router advertise chassis and port IDs and system descriptions (if enabled) to each other.
- 2. The devices store the information about each other in local MIB databases. accessible by using SNMP.
- 3. A network management system retrieves the data stored by each device and builds a network topology map.

LLDP operational modes

LLDP is a one-way protocol. An LLDP agent can transmit information about the capabilities and current status of the system associated with its MAC service access point (MSAP) identifier. The LLDP agent also can receive information about the capabilities and current status of the system associated with a remote MSAP identifier. However, LLDP agents cannot solicit information from each other.

You can set the local LLDP agent to transmit only, receive only, or to both transmit and receive LLDP information. You can configure the state for LLDP reception and transmission using SNMP or ACLI commands.

Connectivity and management information

The information fields in each LLDP frame are contained in a Link Layer Discovery Protocol Data Unit (LLDPDU) as a sequence of short, variable length information elements known as TLVs (type, length, value).

October 2012 68 Configuration — System

Each LLDPDU includes the following four mandatory TLVs:

- Chassis ID TLV
- Port ID TLV
- Time To Live TLV
- End Of LLDPDU TLV

The chassis ID and the port ID values are concatenated to form a logical MSAP identifier that the recipient uses to identify the sending LLDP agent and port.

A non-zero value in the Time to Live (TTL) field of the TTL TLV indicates to the receiving LLDP agent how long the LLDPDU information from the MSAP identifier remains valid. The receiving LLDP agent automatically discards all LLDPDU information, if the sender fails to update it in a timely manner. A zero value in TTL field of Time To Live TLV tells the receiving LLDP agent to discard the information associated with the LLDPDU MSAP identifier.

In addition to the four mandatory TLVs, Release 5.0 software supports the TLV extension set consisting of Management TLVs and organizationally-specific TLVs. Organizationally-specific TLVs are defined by either the professional organizations or the individual vendors that are involved with the particular functionality being implemented. You can specify which of these optional TLVs to include in the transmitted LLDPDUs for each port.

For more information about the supported TLV extension set, refer to the following:

- Management TLVs on page 69
- IEEE 802.1 organizationally-specific TLVs on page 70
- IEEE 802.3 organizationally-specific TLVs on page 70
- Organizationally-specific TLVs for MED devices on page 70

Management TLVs

The optional management TLVs are as follows:

- Port Description TLV
- System Name TLV
- System Description TLV
- System Capabilities TLV (indicates both the system supported capabilities and enabled capabilities, such as end station, bridge, or router)
- Management Address TLV

IEEE 802.1 organizationally-specific TLVs

The optional IEEE 802.1 organizationally-specifc TLVs are:

- Port VLAN ID TLV contains the local port PVID.
- Port And Protocol VLAN ID TLV contains the VLAN IDs of the port and protocol VLANs that contain the local port.
- VLAN Name TLV contains the VLAN names of the VLANs that contain the local port.
- Protocol Identity TLV advertises the protocol supported. The following values are used for supported protocols on the 5000 Series:
 - Stp protocol {0x00.0x26.0x42.0x42.0x03, 0x00, 0x00, 0x00}
 - Rstp protocol string {0x00,0x27,0x42,0x42,0x03, 0x00, 0x00, 0x02}
 - Mstp protocol string {0x00,0x69,0x42,0x42,0x03, 0x00, 0x00, 0x03}
 - Eap protocol string {0x88, 0x8E, 0x01}
 - Lldp protocol string {0x88, 0xCC}

IEEE 802.3 organizationally-specific TLVs

The optional IEEE 802.3 organizationally-specific TLVs are:

- MAC/PHY Configuration/Status TLV indicates the autonegotiation capability and the speed and duplex status of IEEE 802.3 MAC/PHYs.
- Power-Via-MDI TLV indicates the capabilities and current status of IEEE 802.3 PMDs that can provide power over twisted-pair copper links.
- Link Aggregation TLV indicates the current link aggregation status of IEEE 802.3 MACs.
- Maximum Frame Size TLV indicates the maximum supported 802.3 frame size.

Organizationally-specific TLVs for MED devices

The optional organizationally-specific TLVs for use by Media Endpoint Devices (MED) and MED network connectivity devices are:

- Capabilities TLV enables a network element to advertise the LLDP-MED TLVs it is capable of supporting.
- Network Policy Discovery TLV is a fixed length TLV that enables both network connectivity devices and endpoints to advertise VLAN type, VLAN identifier (VID), and Layer 2 and Layer 3 priorities associated with a specific set of applications on a port. In addition, an LLDP-MED endpoint advertises this TLV for supported application types to enable the

October 2012 70 Configuration — System

discovery of specific policy information and the diagnosis of network policy configuration mismatch issues.

- Location Identification TLV allows network connectivity devices to advertise the appropriate location identifier information for an endpoint to use in the context of locationbased applications. The Location Identification Discovery extension enables the advertisement of location identifier information to Communication Endpoint Devices (Class III), based on the configuration of the Network Connectivity Device to which it is connected. This is expected to be related to wiremap or similar network topology data, such that the configuration of the Network Connectivity Device can uniquely identify the physical location of the connected MED Endpoint, and hence the correct location identifier information for it to use.
- Extended Power-via-MDI TLV enables advanced power management between an LLDP-MED endpoint and network connectivity devices. The Extended Power-via-MDI TLV enables the advertisement of fine grained power requirement details, endpoint power priority, and power status for both endpoint and network connectivity devices.
- Inventory TLVs provide switch information. The LLDP Inventory TLVs consist of the following:
 - LLDP-MED Hardware Revision TLV allows the device to advertise its hardware revision.
 - LLDP-MED Firmware Revision TLV allows the device to advertise its firmware
 - LLDP-MED Software Revision TLV allows the device to advertise its software revision.
 - LLDP-MED Serial Number TLV allows the device to advertise its serial number.
 - LLDP-MED Manufacturer Name TLV allows the device to advertise the name of its manufacturer.
 - LLDP-MED Model Name TLV allows the device to advertise its model name

You can also use the show sys-info command to display information about the Inventory TLVs.

Trasmitting LLDPDUs

When a transmit cycle is initiated, the LLDP manager extracts the managed objects from the LLDP local system MIB and formats this information into TLVs. TLVs are inserted into the LLDPDU.

LLDPDU are regularly transmitted at a user-configurable transmit interval (tx-interval) or when any of the variables contained in the LLPDU is modified on the local system (such as system name or management address).

Tx-delay is "the minimum delay between successive LLDP frame transmissions."

TLV system MIBs

The LLDP local system MIB stores the information for constructing the various TLVs to be sent. The LLDP remote systems MIB stores the information received from remote LLDP agents.

LLDPDU and TLV error handling

LLDPDUs and TLVs that contain detectable errors are discarded. TLVs that are not recognized, but that also contain no basic format errors, are assumed to be validated and are stored for possible later retrieval by network management.

Time to live interval

The Time to live interval represents the tx-interval multiplied by the tx-hold-multiplier.

Med fast start

Med fast start provides a burst of LLDPDU when the system initializes an LLDP MED transmission.

802.1AB MED network policies

You can configure 802.1AB MED network policies to dynamically configure voice VLAN, DSCP, priority, and VLAN tagging on the switch for voice traffic received from an IP phone. When you enable LLDP and configure the MED network policies on the switch, the switch sends the network policies to the IP Phone. The IP phone processes the data in the LLDP PDU and transmits the voice traffic with the appropriate VLAN ID, VLAN tagging, DSCP and priority information.

You can configure MED network policies on a switch port that has ADAC enabled. The network policies have priority over the ADAC configuration on the port.

When you enable Auto QoS, the MED network policy is changed to DSCP 47 (0x2F) from user defined DSCP.

Avaya Automatic QoS enhancement for LLDP-MED

The Avaya Automatic QoS enhancement for LLDP-MED allows Avaya Automatic QoS to set the DSCP, sent by Network Policy TLV for voice traffic application types, to a value that it recognizes. The LLDP compliant IP phone uses the received DSCP when sending voice traffic so that the traffic is recognized by the Avaya Aunotmatic QoS and is prioritized accordingly.

This feature is automatically enabled when Avaya Automatic QoS is enabled on switch.

72 Configuration — System October 2012

Chapter 6: System configuration with ACLI

General switch administration with ACLI

This section outlines the Command Line Interface commands used in general switch administration. It contains information about the following topics:

- Stack manager on page 75
- Multiple switch configurations on page 76
- New Unit Quick Configuration on page 78
- IP blocking on page 80
- Assigning and clearing IP addresses on page 81
- Assigning and clearing IP addresses for specific units on page 86
- Displaying interfaces on page 87
- Setting port speed on page 88
- Testing cables with the Time Domain Reflectometer on page 91
- Enabling Autotopology on page 92
- Enabling flow control on page 94
- Enabling rate-limiting on page 96
- Using Simple Network Time Protocol on page 100
- Real time clock configuration on page 106
- Custom Autonegotiation Advertisements on page 108
- Connecting to Another Switch on page 110
- Domain Name Server (DNS) Configuration on page 111
- Auto Unit Replacement using the ACLI on page 114
- Avaya Energy Saver configuration using the ACLI on page 117
- Changing switch software in the ACLI on page 126
- Configuration files in ACLI on page 128
- Terminal setup on page 134
- Setting the default management interface on page 135
- Setting Telnet access on page 135

- Setting boot parameters on page 138
- Defaulting to BootP-when-needed on page 139
- shutdown command on page 140
- reload command on page 141
- ACLI Help on page 142
- Clearing the default TFTP server with ACLI on page 142
- Configuring a default TFTP server with ACLI on page 143
- Displaying the default TFTP server with ACLI on page 143
- Host keys on page 146
- Secure Transfer File Protocol configuration on page 143
- Configuring daylight savings time with ACLI on page 150
- Configuring default clock source with ACLI on page 151
- Configuring local time zone with ACLI on page 152
- Configuring Dual Agent with ACLI on page 153
- Configuring IPv6 with ACLI on page 155
- Configuring LLDP with ACLI on page 168
- Configuring PoE detection method with ACLI on page 195
- Customizing ACLI banner with ACLI on page 199
- Displaying complete GBIC information on page 200
- Displaying hardware information on page 201
- Configuring AUR with ACLI on page 201
- Agent Auto Unit Replacement (AAUR) on page 204
- Enabling Autosave on page 206
- Disabling Autosave on page 206
- Setting Stack Forced Mode on page 207
- Enabling feature license files on page 208
- Setting user access limitations on page 209
- Configuring serial console port and USB host port on page 212
- Restoring factory default on page 216

74

Stack manager

Use the following procedures to integrate switches in a stack with the stack manager:

- Configuring a pure stack with stack manager on page 75
- Configuring a hybrid stack with stack manager on page 75
- show stack oper-mode on page 75
- stack oper-mode {Pure Hybrid} on page 76

Configuring a pure stack with stack manager

Use this procedure to configure a pure stack with stack manager.

Procedure steps

Upgrade the existing stack with release 6.2 software.

Configuring a hybrid stack with stack manager

Use this procedure to configure a hybrid stack with stack manager.

Procedure steps

- 1. Upgrade the existing stack with release 6.0 software.
- 2. Cable in one Ethernet Routing Switch 5600 Series switch into this stack.
 - Once the new Ethernet Routing Switch 5600 Series switch joins the stack, it will have learned the entire configuration from the base unit and programmed its NVRAM. This switch can now be configured as base unit.
- 3. To configure the Ethernet Routing Switch 5600 Series switch as the base unit, turn the power off to the whole stack and set the base unit switch on the Ethernet Routing Switch 5500 Series switch to Off and set the base unit switch on the Ethernet Routing Switch 5600 Series switch to On.
- 4. Turn the power on to the stack. The Ethernet Routing Switch 5600 Series switch is now the base unit in the stack.

You can now add more than one Ethernet Routing Switch 5600 Series switch to the stack. You can add more Ethernet Routing Switch 5600 Series switches to the stack up to the maximum of eight units.

show stack oper-mode

An Ethernet Routing Switch 5000 Series stack is in one of two modes: Pure or Hybrid.

Use this procedure to display the stack operation mode.

Procedure steps

Use the following command from Global Configuration mode:

show stack oper-mode

stack oper-mode {Pure|Hybrid}

You can configure the operating mode on all the Ethernet Routing Switch 5600 Series switches in the stack. Ethernet Routing Switch 5500 Series switches do not have a configurable operating mode as the software operates in only one mode.

This command is available only on the Ethernet Routing Switch 5600 Series switches in the stack or on an Ethernet Routing Switch 5600 Series stand-alone switch.

Use this procedure to configure the stack as Pure or Mixed.

Procedure steps

Use the following command from Global Configuration mode:

stack oper-mode {Pure|Hybrid}

Variable definitions

The following table defines the parameters for the stack oper-mode {Pure|Hybrid} command.

Table 7: stack oper-mode command parameters

Variable	Value
Pure	Sets stack manager for an Ethernet Routing Switch 5600 Series stack or stand-alone.
Hybrid	Sets stack manager for a hybrid Ethernet Routing Switch 5600 Series and Ethernet Routing Switch 5600 Series stack.
	Note:
	You must use an Ethernet Routing Switch 5600 Series switch as the base unit in a hybrid or mixed stack.

Multiple switch configurations

The following ACLI commands are used to configure and use multiple switch configuration:

October 2012 76 Configuration — System

Navigation:

- show nvram block command on page 77
- copy config nvram block command on page 77
- copy nvram config block command on page 77

show nyram block command

Use this procedure to show the configurations currently stored on the switch.

Procedure steps

Use the following command from Global Configuration mode:

show nvram block

copy config nvram block command

Use this procedure to copy the current configuration to one of the flash memory spots.

Procedure steps

Use the following command from Global Configuration mode:

copy config nvram block <1-2> name <block_name>

Variable definitions

The following table describes the parameters for the copy config nvram block <1-2> name <block name> command.

Table 8: copy config nvram block command parameters

Variable	Value
block <1 - 2>	The flash memory location to store the configuration.
name <block_name></block_name>	The name to attach to this block. Names can be up to 40 characters in length with no spaces.

copy nvram config block command

Use this procedure to copy the configuration stored in flash memory at the specified location and make it the active configuration.

Procedure steps

Use the following command from Global Configuration mode:

copy nvram config block <1-2>

Substitute <1-2> with the configuration file to load.

This command causes the switch to reset so that the new configuration can be loaded.

New Unit Quick Configuration

In Software Release 4.2 and later, use the New Unit Quick Configuration feature to create a default configuration that can be applied to any new unit entering a stack configuration. You do not need to manually configure a new unit that is added to the existing stack. However, if required, you can set the default values for VLAN lds, port speed, duplex mode, PVID, tagging, and spanning tree groups on the new unit without the need to reset the stack during the process.

Note: All commands in this section are executed in the Global Configuration command mode except the quickconfig start-recording command which is executed in Privileged EXEC mode.

To configure and enable this feature with ACLI, refer to the following commands:

- quickconfig enable on page 78
- no quickconfig enable on page 78
- default quickconfig on page 78
- quickconfig start-recording on page 79

quickconfig enable

Use this procedure to enable the quick configuration feature on the switch.

Procedure steps

Use the following command from Global Configuration mode:

quickconfig enable

no quickconfig enable

Use this procedure to disable the quick configuration feature on the switch.

Procedure steps

Use the following command from Global Configuration mode:

no quickconfig enable

default quickconfig

Use this procedure to set the quick configuration feature to the factory default value.

78 Configuration — System October 2012

Procedure steps

Use the following command from Global Configuration mode:

```
default quickconfig
```

quickconfig start-recording

Use this procedure on the stack base unit to record the default configuration that is applied to new units in the stack.

Procedure steps

1. Use the following command from Global Configuration mode:

```
quickconfig (start-recording)[u3]
```

2. To record a VLAN configuration or port configuration enter the following commands one on each line in ACLI:

```
enable
config term
vlan port $/13-40 tag untagPvidonly
vlan create 10 name vlan_10 type port
vlan create 20 name vlan_20 type port
vlan members add 10 $/13-40
vlan members add 20 $/13-40
vlan ports $/13-40 pvid 10
interface fast $/13-34
speed 100
end
```

⚠ Caution:

The first two commands must be enable and config term, otherwise the config commands that follow will not be applied.

Use \$ as a wild card for the slot. When you add a new unit to the stack the unit number is not known so the wild card character can match any slot number. To end the recording process enter a dot on a separate line in ACLI.

IP blocking

IP blocking provides a safeguard against the use of duplication IP addresses in a stack at the Layer 3 level. When a unit leaves a stack or reboots the IP blocking feature ensures that duplicate IPs are not present.

Use the following ACLI commands to configure and manage IP blocking with ACLI:

- show ip-blocking on page 80
- show ip blocking-mode on page 80
- <u>ip blocking-mode command</u> on page 80
- clear ip-blocking on page 81
- default ip blocking-mode on page 81

show ip-blocking

Use this procedure to show the current IP blocking state.

Procedure steps

Use the following command from User EXEC mode:

show ip-blocking

show ip blocking-mode

Use this procedure to show the current IP blocking parameters.

Procedure steps

Use the following command from User EXEC mode:

show ip blocking-mode

ip blocking-mode command

Use this procedure to set the level of ip blocking to perform in the stack.

Procedure steps

Use the following command from Interface Configuration mode:

```
ip blocking-mode {full | none}
```

Variable definitions

The following table describes the parameters for the ip blocking-mode {full | none } command.

Table 9: ip blocking-mode command parameters

Variable	Value
full	Select this parameter to set IP blocking-mode to full. This never enables a duplicate IP address in a stack.
none	Select this parameter to set IP blocking-mode to none. This enables duplicate IP addresses unconditionally.

clear ip-blocking

Use this procedure to clear the current IP blocking-mode state.

Procedure steps

Use the following command from Privileged EXEC mode:

clear ip-blocking

default ip blocking-mode

Use this procedure to set the IP blocking mode to factory defaults.

Procedure steps

Use the following command from Global Configuration mode:

default ip blocking-mode

Assigning and clearing IP addresses

You can assign, clear, and view IP addresses and gateway addresses with ACLI. Use the following commands to perform various operations on IP and gateway addresses:

- ip address command on page 82
- ip address source command on page 82
- no ip address command on page 83
- ip default-gateway command on page 84

- no ip default-gateway command on page 84
- show ip command on page 85

ip address command

Use this procedure to set the IP address and subnet mask for the switch or a stack.

Procedure steps

Use the following command from Global Configuration mode:

```
ip address [stack | switch] <A.B.C.D> [netmask <A.B.C.D>]
[default-gateway <A.B.C.DX>]
```

If the stack or switch parameter is not specified, the system automatically modifies the stack IP address when in stack mode and modifies the switch IP address when in stand-alone mode.

Variable definitions

The following table describes the parameters for the ip address [stack | switch] <A.B.C.D> [netmask <A.B.C.D>][default-gateway <A.B.C.DX>] command.

Table 10: ip address command parameters

Variable	Value
stack switch	Sets the IP address and netmask of the stack or the switch.
A.B.C.D	Denotes the IP address in dotted-decimal notation; netmask is optional.
netmask	Signifies the IP subnet mask for the stack or switch.
Default Gateway A.B.C.D	Displays the IP address of the default gateway. Enter the IP address of the default IP gateway.



When the IP address or subnet mask is changed, connectivity to Telnet can be lost.

ip address source command

Use this procedure to automatically obtain an IP address, subnet mask and default gateway on the switch or stack.

Procedure steps

Use the following command from Global Configuration mode:

October 2012 82 Configuration — System

ip address source {bootp-always | bootp-last-address | bootpwhen-needed | configured-address | dhcp-always | dhcp-lastaddress | dhcp-when-needed }

When you use DHCP, the switch or stack can also obtain up to three DNS server IP addresses.

Variable definitions

The following table describes the parameters for the ip address source command.

Table 11: ip address source command parameters

Variable	Value
bootp-always	Always use the bootp server.
bootp-last- address	Use the last bootp server.
bootp-when-needed	Use bootp server when needed.
configured- address	Use the manually configured IP configuration.
dhcp-always	Always use the DHCP server.
dhcp-last-address	Use the last DHCP server.
dhcp-when-needed	Use DHCP client when needed.

no ip address command

Use this procedure to clear the IP address and subnet mask for a switch or a stack.

Procedure steps

Use the following command from Global Configuration mode:

```
no ip address {stack | switch | unit}
```

This command sets the IP address and subnet mask for a switch or a stack to all zeros (0).

Variable definitions

The following table describes the parameters for the no ip address {stack | switch | unit \ command.

Table 12: no ip address command parameters

Variable	Value
stack switch	Zeroes out the stack IP address and subnet mask or the switch IP address and subnet mask.

Variable	Value
unit	Zeroes out the IP address for the specified unit.

O Note:

When the IP address or subnet mask is changed, connectivity to Telnet can be lost. Any new Telnet connection can be disabled and is required to connect to the serial console port to configure a new IP address.

ip default-gateway command

Use this procedure to set the default IP gateway address for a switch or a stack to use.

Procedure steps

Use the following command from Global Configuration mode:

Variable definitions

The following table describes the parameters for the ip default-gateway command.

Table 13: ip default-gateway command parameters

Variable	Value
A.B.C.D	Enter the dotted-decimal IP address of the default IP gateway.

O Note:

When the IP gateway is changed, connectivity to Telnet can be lost.

no ip default-gateway command

Use this procedure to set the IP default gateway address to zero (0).

Procedure steps

Use the following command from Global Configuration mode:

■ Note:

84

When the IP gateway is changed, connectivity to Telnet can be lost.

Comments? infodev @avaya.com

show ip command

Use this procedure to display the IP configurations, BootP/DHCP mode, stack address, switch address, subnet mask, and gateway address.

Procedure steps

Use the following command from User EXEC mode:

```
show ip [bootp] [dhcp] [default-gateway] [address]
```

This command displays the parameters for what is configured, what is in use, and the last BootP/DHCP. If you do not enter any parameters, this command displays all IPrelated configuration information.

Variable definitions

The following table describes the parameters and variables for the **show** ip command.

Table 14: show ip command parameters

Variable	Value
bootp	Displays BootP/DHCP-related IP information. The possibilities for status returned are:
	BootP Always
	Disabled
	BootP or Last Address
	BootP When Needed
	DHCP Always
	DHCP or Last Address
	DHCP When Needed
dhcp client lease	Displays DHCP client lease information. The command displays information about configured lease time and lease time granted by the DHCP server.
default-gateway	Displays the IP address of the default gateway.
address	Displays the current IP address.
address source	Displays the BootP or DHCP client information. The possibilities for status returned are:
	DHCP always
	DHCP when needed
	DHCP or last address
	Disabled

Variable	Value
	BootP always
	BootP when needed
	BootP or last address

Assigning and clearing IP addresses for specific units

You can use ACLI to assign and clear IP addresses for a specific unit in a stack. For details, refer to the following:

- ip address unit command on page 86
- no ip address unit command on page 86
- default ip address unit command on page 87

ip address unit command

Use this procedure to set the IP address and subnet mask of a specific unit in the stack.

Procedure steps

Use the following command from Global Configuration mode:

Variable definitions

The following table describes the parameters the ip address unit <1-8> [A.B.C.D] command.

Table 15: ip address unit command parameters

Variable	Value
unit <1-8>	Sets the unit you are assigning an IP address.
A.B.C.D	Enter IP address in dotted-decimal notation.

Note:

When the IP address or subnet mask is changed, connectivity to Telnet and the Internet can be lost.

no ip address unit command

Use this procedure to set the IP address for the specified unit in a stack to zeros (0).

October 2012 86 Configuration — System

Procedure steps

Use the following command from Global Configuration mode:

no ip address unit <1-8>

Variable definitions

The following table describes the parameters the no ip address unit <1-8> command.

Table 16: no ip address command parameters

Variable	Value
unit <1-8>	Zeroes out the IP address for the specified unit.

Note:

When the IP address or subnet mask is changed, connectivity to Telnet and the Internet can be lost.

default ip address unit command

Use this procedure to set the IP address for the specified unit in a stack to all zeros (0).

Procedure steps

Use the following command from Global Configuration mode:

default ip address unit <1-8>

Variable definitions

The following table describes the parameters for the default ip address unit <1-8> command.

Table 17: default ip address unit command parameters

Variable	Value
unit <1-8>	Zeroes out the IP address for the specified unit.

☑ Note:

When the IP gateway is changed, connectivity to Telnet and the Internet can be lost.

Displaying interfaces

The status of all interfaces on the switch or stack can be viewed, including Multi-Link Trunk membership, link status, autonegotiation and speed.

show interfaces command

Use this procedure to display the current configuration and status of all interfaces.

Procedure steps

Use the following command from User EXEC mode:

```
show interfaces [names] [<portlist>]
```

Variable definitions

The following table describes the parameters and variables for the **show interfaces** command.

Table 18: show interfaces command parameters

Value	Variable
names <portlist></portlist>	Displays the interface names; enter specific ports if you want to see only those.

Setting port speed

To set port speed and duplexing with ACLI, refer to the following:

- speed command on page 88
- default speed command on page 89
- duplex command on page 90
- default duplex command on page 90

speed command

Use this procedure to set the speed of the port.

Procedure steps

Use the following command from Interface Configuration mode:

```
speed [port <portlist>] {10 | 100 | 1000 | auto}
```

Variable definitions

88

The following table describes the parameters and variables for the speed command.

Comments? infodev @avaya.com

Table 19: speed command parameters

Variable	Value
port <portlist></portlist>	Specifies the port numbers for which to configure the speed. Enter the port numbers you want to configure.
	Note:
	If you omit this parameter, the system uses the port number you specified in the interface command.
10 100 1000 auto	Sets speed to:
	• 1010 Mb/s
	• 100100 Mb/s
	• 10001000 Mb/s or 1 GB/s
	autoautonegotiation

■ Note:

Enabling/disabling autonegotiation for speed also enables/disables it for duplex operation.

When you set the port speed for autonegotiation, ensure that the other side of the link is also set for autonegotiation.

default speed command

Use this procedure to set the speed of the port to the factory default speed.

Procedure steps

Use the following command from Interface Configuration mode:

default speed [port <portlist>]

Variable definitions

The following table describes the parameters for the default speed [port <portlist>] command.

Table 20: Default speed command parameters

Variable	Value
port <portlist></portlist>	Specifies the port numbers to set the speed to factory default. Enter the port numbers you want to set.
	Note:
	If you omit this parameter, the system uses the port number you specified in the interface command.

duplex command

Use this procedure to specify the duplex operation for a port.

Procedure steps

Use the following command from Interface Configuration mode:

```
duplex [port <portlist>] {full | half | auto}
```

Variable definitions

The following table describes the parameters for the duplex [port <portlist>] {full | half | auto} command.

Table 21: Duplex command parameters

Variable	Value
port <portlist></portlist>	Specifies the port numbers for which to reset the duplex mode to factory default values. Enter the port number you want to configure. The default value is autonegotiation.
	S Note:
	If you omit this parameter, the system uses the ports you specified in the interface command.
full half	Sets duplex to:
auto	• fullfull-duplex mode
	halfhalf-duplex mode
	autoautonegotiation

Note:

Enabling/disabling autonegotiation for speed also enables/disables it for duplex operation.

When you set the duplex mode for autonegotiation, ensure that the other side of the link is also set for autonegotiation.

default duplex command

Use this procedure to set the duplex operation for a port to the factory default duplex value.

Procedure steps

Use the following command from Interface Configuration mode:

default duplex [port <portlist>]

Variable definitions

The following table describes the parameters for the default duplex [port <portlist>] command.

Table 22: Default duplex command parameters

Variable	Value
port <portlist></portlist>	Specifies the port numbers to reset the duplex mode to factory default values. Enter the port numbers you want to configure. The default value is autonegotiation.
	Note:
	If you omit this parameter, the system uses the ports you specified in the interface command.

Testing cables with the Time Domain Reflectometer

The Avaya Ethernet Routing Switch 5000 Series is equipped with a Time Domain Reflectometer (TDR). The TDR provides a diagnostic capability to test connected cables for defects (such as short pin and pin open). You can obtain TDR test results from ACLI or Enterprise Device Manager.

The cable diagnostic tests only apply to Ethernet copper ports; fiber ports cannot be tested.

You can initiate a test on multiple ports at the same time.

When you test a cable with the TDR, if the cable has a 10/100 MB/s link, the link is broken during the test and restored only when the test is complete. If the cable has a 10/100 MB/s link, the test results may be incomplete as the test does not test all of the pins in the connector. Use of the TDR does not affect 1 GB/s links.

See the Avaya Ethernet Routing Switch Troubleshooting Guide (NN47200-700) for more information on troubleshooting cables and for connector pin tables.

Note:

The accuracy margin of cable length diagnosis is between three to five meters. Avaya suggests the shortest cable for length information be five meters long.

With the following ACLI commands, you can initiate a TDR cable diagnostic test and obtain test reports.

- tdr test command on page 92
- show tdr command on page 92

tdr test command

Use this procedure to initiate a TDR test on a port or ports.

Procedure steps

Use the following command from Privileged EXEC mode:

tdr test <portlist>

Variable definitions

The following table describes the parameters for the tdr test <portlist> command.

Table 23: Tdr test command parameters

Variable	Value
<portlist></portlist>	Specifies the ports to be tested.

show tdr command

Use this procedure to display the results of a TDR test.

Procedure steps

Use the following command from Privileged EXEC mode:

show tdr <portlist>

Variable definitions

The following table describes the parameters for the show tdr <portlist> command.

Table 24: Show tdr command parameters

Variable	Value
<portlist></portlist>	Specifies the ports for which to display the test results.

Enabling Autotopology

The Optivity Autotopology protocol can be configured with ACLI.

For more information about Autotopology, refer to www.avaya.com. (The product family for Optivity and Autotopology is Data and Internet.)

To enable autotopology with ACLI, refer to the following:

- <u>autotopology command</u> on page 93
- no autotopology command on page 93
- default autotopology command on page 93
- show autotopology settings command on page 93
- show autotopology nmm-table command on page 94

autotopology command

Use this procedure to enable the Autotopology protocol.

Procedure steps

Use the following command from Global Configuration mode:

autotopology

no autotopology command

Use this procedure to disable the Autotopology protocol.

Procedure steps

Use the following command from Global Configuration mode:

no autotopology

default autotopology command

Use this procedure to enable the Autotopology protocol.

Procedure steps

Use the following command from Global Configuration mode:

default autotopology

☑ Note:

The default autotopology command has no parameters or values.

show autotopology settings command

Use this procedure to display the global autotopology settings.

Procedure steps

Use the following command from Privileged EXEC mode:

show autotopology settings

O Note:

The show autotopology settings command has no parameters or values.

show autotopology nmm-table command

Use this procedure to display the Autotopology network management module (NMM) table.

Procedure steps

Use the following command from Privileged EXEC mode:

show autotopology nmm-table

3 Note:

The show autotopology nmm-table command has no parameters or values.

Enabling flow control

Gigabit Ethernet, when used with the Avaya Ethernet Routing Switch 5000 Series, can control traffic on this port using the flowcontrol command.

To enable flow control with ACLI, refer to the following:

- flowcontrol command on page 94
- no flowcontrol command on page 95
- default flowcontrol command on page 96

flowcontrol command

Use this procedure to control the traffic rates during congestion.

Procedure steps

Use the following command from Interface Configuration mode:

flowcontrol [port <portlist>] {asymmetric | symmetric | auto |
disable}

☑ Note:

This command is used only on Gigabit Ethernet ports.

Variable definitions

The following table describes the parameters for the flowcontrol command.

Table 25: Flowcontrol command parameters

Variable	Value
port <portlist></portlist>	Specifies the port numbers to configure for flow control.
	Note:
	If you omit this parameter, the system uses the ports you specified in the interface command but only those ports which have speed set to 1000/full.
asymmetric	Sets the mode for flow control:
symmetric auto disable	asymmetricPAUSE frames can only flow in one direction.
disable	symmetricPAUSE frames can flow in either direction.
	autosets the port to automatically determine the flow control mode (default).
	disabledisables flow control on the port.

no flowcontrol command

Use this procedure to disable flow control.

Procedure steps

Use the following command from Interface Configuration mode:

no flowcontrol [port <portlist>]



This command is used only on Gigabit Ethernet ports.

Variable definitions

The following table describes the parameters for the no flowcontrol command.

Table 26: No flowcontrol command parameters

Variable	Value
port <portlist></portlist>	Specifies the port numbers for which to disable flow control.

Variable	Value
	Note: If you omit this parameter, the system uses the ports you specified in the interface command, but only those ports
	that have speed set to 1000/full.

default flowcontrol command

Use this procedure to set the flow control to auto, which automatically detects the flow control.

Procedure steps

Use the following command from Interface Configuration mode:

default flowcontrol [port <portlist>]

3 Note:

This command is used only on Gigabit Ethernet ports.

Variable definitions

The following table describes the parameters for the default flowcontrol command.

Table 27: Default flowcontrol command parameters

Variable	Value
port <portlist></portlist>	Specifies the port numbers to default to auto flow control.
	Note:
	If you omit this parameter, the system uses the port number you specified in the interface command.

Enabling rate-limiting

The percentage or packets per seconds of multicast traffic, or broadcast traffic, or both can be limited with ACLI. For details, refer to the following:

- show rate-limit command on page 97
- rate-limit command on page 98
- no rate-limit command on page 99
- default rate-limit command on page 99

Configuration — System October 2012

show rate-limit command

Use this procedure to display the rate-limiting settings and statistics.

Procedure steps

Use the following command from Privileged EXEC mode:

show rate-limit

Variable definitions

The following table outlines the parameters of the show rate-limit command.

Table 28: show rate-limit parameters

Variable	Value
Port	Specifies the switch port numbers that correspond to the field values in that row of the screen (for example, the field values in row 2 apply to switch port 2). Note that the values applied in the Switch or Stack row (last 2 rows) affect all standalone switch ports or all switch ports in a stack.
	Displays the packet type selected for rate-limiting or viewing.
	Both — both multicast and broadcast packet types
Packet Type	Multicast
	Broadcast
	Default value is Both.
	Displays the percentage of port bandwidth allowed for forwarding the packet types specified in the Packet Type field. When the threshold is exceeded, any additional packets (specified in the Packet Type field) are discarded. Range is None, 1% to 10%. Default value is None.
Limit	Note:
	Rate-limiting is disabled if this field is set to None. This allows you to select and view the percentage of specific packet types present in the network, without inadvertently limiting the forwarding rate.
Last 5 Minutes	Specifies the percentage of packets (of the type specified in the Packet Type field) received by the port in the last 5 minutes. This field provides a running average of network activity and is updated every 15 seconds. Note that this field indicates the receiving port's view of network activity, regardless of the rate-limiting setting.
Last Hour	Specifies the percentage of packets (of the type specified in the Packet Type field) received by the port in the last hour. This field

Variable	Value
	provides a running average of network activity and is updated every 5 minutes. Note that this field indicates the receiving port's view of network activity, regardless of the rate-limiting setting.
Last 24 Hours	Specifies the percentage of packets (of the type specified in the Packet Type field) received by the port in the last 24 hours. This field provides a running average of network activity and is updated every hour. Note that this field indicates the receiving port's view of network activity, regardless of the rate-limiting setting.

rate-limit command

Use this procedure to configure rate-limiting on the port.

Procedure steps

Use the following command from Interface Configuration mode:

rate-limit {multicast | broadcast | both } {percent
$$<0-10>$$
 | pps $<0-262143$ | $<0-10>$ }

Variable definitions

98

The following table describes the parameters for the rate-limit command.

Table 29: Rate-limit command parameters

Variable	Value
multicast	Applies rate-limiting to the type of traffic.
broadcast both	multicastapplies rate-limiting to multicast packets
	broadcastapplies rate-limiting to broadcast packets
	bothapplies rate-limiting to both multicast and broadcast packets
percent <0-10> pps <0-262143>	Specifies the mode for setting the rates of the incoming traffic.
	• percent <0-10>enter an integer from 1 to 10 to set the rate-limiting percentage.
	• pps <0-262143>enter an integer from 1 to 262143 to set the rate-limiting packets per second.
	For 10 Gb/s links, the default value for limiting both broadcast and multicast is 10 percent. When pps mode is used the limit on 10 Gb/s links cannot be configured to a value under 1000.

Configuration — System

Comments? infodev@avaya.com

Comments? infodev@avaya.com

Variable	Value
	Rate limiting using packet per seconds can only be configured using ACLI.

☑ Note:

The rate-limit parameter of the ERS 5000 can be expressed as a percentage of total traffic. (ERS 5000 supports multicast/broadcast storm control as either a percentage or packets per second.)

When measuring the broadcast rate limit as a percentage, the rate limiting feature calculation is based on packets that are a fixed (not measured) average packet size of 500 bytes, rather than octets. To obtain the actual value, use the following equation (the average packet size is 500 bytes):

(Line speed (bit/sec) / average packet size x 8) X (Rate Limit / 100) = Packets per second

no rate-limit command

Use this procedure to disable rate-limiting on the port.

Procedure steps

Use the following command from Interface Configuration mode:

Variable definitions

The following table describes the parameters for the no rate-limit command.

Table 30: No rate-limit command parameters

Variable	Value
port <portlist></portlist>	Specifies the port numbers to disable for rate-limiting. Enter the port numbers you want to disable.
	Note:
	If you omit this parameter, the system uses the port number you specified in the interface command.

default rate-limit command

Use this procedure to restore the rate-limiting value for the specified port to the default setting.

Procedure steps

Use the following command from Interface Configuration mode:

default rate-limit [port <portlist>]

Variable definitions

The following table describes the parameters for the default rate-limit command.

Table 31: Default rate-limit command parameters

Variable	Value
port <portlist></portlist>	Specifies the port numbers on which to reset rate-limiting to factory default. Enter the port numbers on which to set rate-limiting to default.
	Note:
	If you omit this parameter, the system uses the port number you specified in the interface command.

Using Simple Network Time Protocol

The Simple Network Time Protocol (SNTP) feature synchronizes the Universal Coordinated Time (UCT) to an accuracy within 1 second. This feature adheres to the IEEE RFC 2030 (MIB is the s5agent). With this feature, the system can obtain the time from any RFC 2030-compliant NTP/SNTP server.

3 Note:

If you have trouble using this feature, try various NTP servers. Some NTP servers can be overloaded or currently inoperable.

The system retries connecting with the NTP server a maximum of three times, with 5 minutes between each retry.

Using SNTP provides a real-time timestamp for the software, shown as Greenwich Mean Time (GMT).

If SNTP is enabled, the system synchronizes with the configured NTP server at boot-up and at user-configurable periods thereafter (the default synchronization interval is 24 hours). The first synchronization is not performed until network connectivity is established.

SNTP supports primary and secondary NTP servers. The system tries the secondary NTP server only if the primary NTP server is unresponsive.

To configure SNTP, refer to the following commands:

- show SNTP command on page 101
- show sys-info command on page 101
- SNTP enable command on page 101
- no SNTP enable command on page 102
- SNTP server primary address command on page 102

100 Configuration — System

- SNTP server secondary address command on page 102
- no SNTP server command on page 103
- SNTP sync-now command on page 103
- SNTP sync-interval command on page 103
- Configuring the local time zone on page 104
- Configuring daylight savings time on page 105

show SNTP command

Use this procedure to display the SNTP information, as well as the configured NTP servers.

Procedure steps

Use the following command from Privileged EXEC mode:

show SNTP

show sys-info command

Use this procedure to display the current system characteristics.

Procedure steps

Use the following command from Privileged EXEC mode:

show sys-info

Note:

You must have SNTP enabled and configured to display GMT time.

SNTP enable command

Use this procedure to enable SNTP.

Procedure steps

Use the following command from Global Configuration mode:

SNTP enable

☑ Note:

The default setting for SNTP is disabled.

no SNTP enable command

Use this procedure to disable SNTP.

Procedure steps

Use the following command from Global Configuration mode:

no SNTP enable

SNTP server primary address command

Use this procedure to specify the IP addresses of the primary NTP server.

Procedure steps

Use the following command from Global Configuration mode:

sntp server primary address [<ipv6_address> | <A.B.C.D>]

Variable definitions

The following table describes the parameters for the sntp server primary address command.

Table 32: SNTP server primary address command parameters

Variable	Value
<a.b.c.d></a.b.c.d>	Enter the IP address of the primary NTP server in dotted-decimal notation.

SNTP server secondary address command

Use this procedure to specify the IP addresses of the secondary NTP server.

Procedure steps

Use the following command from Global Configuration mode:

sntp server secondary address [<ipv6_address> | <A.B.C.D>]

Variable definitions

The following table describes the parameters for the sntp server secondary address command.

Table 33: SNTP server secondary address command parameters

Variable	Value
ipv6_address	Enter the IPv6 address of the secondary NTP server.
<a.b.c.d></a.b.c.d>	Enter the IP address of the secondary NTP server in dotted-decimal notation.

no SNTP server command

Use this procedure to clear the NTP server IP addresses. The command clears the primary and secondary server addresses.

Procedure steps

Use the following command from Global Configuration mode:

Variable definitions

The following table describes the parameters for the no sntp server command.

Table 34: no SNTP server command parameters

Variable	Value
primary	Clear primary SNTP server address.
secondary	Clear secondary SNTP server address.

SNTP sync-now command

Use this procedure to force a manual synchronization with the NTP server.

Procedure steps

Use the following command from Global Configuration mode:

SNTP sync-now

Note:

SNTP must be enabled before this command can take effect.

SNTP sync-interval command

Use this procedure to specify recurring synchronization with the secondary NTP server in hours relative to initial synchronization.

Procedure steps

Use the following command from Global Configuration mode:

sntp sync-interval <0-168>

Variable definitions

The following table describes the parameters for the sntp sync-interval command.

Table 35: SNTP sync-interval command parameters

Variable	Value
<0-168>	Enter the number of hours for periodic synchronization with the NTP server.
	Note:
	0 is boot-time only, and 168 is once a week.

Configuring the local time zone

Use this procedure to configure your switch for your local time zone.

Procedure steps

1. Use the following command from Global Configuration mode:

configure

- 2. Enable sntp server.
- 3. Set clock time zone using the clock command.

```
clock time-zone zone hours [minutes]
```

setting time zone example

clock time-zone PST -8

This command sets the time zone to UTP minus 8 hours and the time zone will be displayed as "PST."

Variable definitions

The following table describes the parameters for the clock time-zone zone hours [minutes] command.

Table 36: clock time-zone command parameters

Variable	Value
zone	Time zone acronym to be displayed when showing system time (up to 4 characters).

Variable	Value
hours	Difference from UTC in hours. This can be any value between -12 and +12.
minutes	Optional: This is the number of minutes difference from UTC. Minutes can be any value between 0 and 59.

Configuring daylight savings time

Use this procedure to configure local daylight savings time recurring change dates.

1. Use the following command from Global Configuration mode:

configure

- 2. Enable sntp server.
- 3. Set the date to change to daylight savings time.

clock summer-time zone date day month year hh:mm day month
year hh:mm [offset]

set daylight savings time example

clock summer-time BST date 28 Mar 2007 2:00 30 Aug 2007 15:00 +60

This command sets the daylight savings time to begin at 02:00 on March 28, 2007 and end on August 30th, 2007 at 15:00. The change to daylight savings moves the clock forward by 60 minutes and "BST" will be displayed as the time zone acronym. These changes to and from daylight savings time will happen automatically.

Variable definitions

The following table describes the parameters for the clock summer-time zone date day month year hh:mm day month year hh:mm [offset] command

Table 37: daylight savings command parameters

Variable	Value
date	Indicates that daylight savings time should start and end on the specified days every year.
day	Date to start daylight savings time.
month	Month to start daylight savings time.
year	Year to start daylight savings time.
hh:mm	Hour and minute to start daylight savings time.
day	Date to end daylight savings time.

Variable	Value
month	Month to end daylight savings time.
year	Year to end daylight savings time.
hh:mm	Hour and minute to end daylight savings time.
offset	Number of minutes to add during the summer time.
zone	The time zone acronym to be displayed when daylight savings time is in effect. If it is unspecified, it defaults to the time zone acronym set when the time zone was set.

Real time clock configuration

In addition to SNTP time configuration, a real-time clock (RTC) is available to provide the switch with time information. This RTC provides the switch information in the instance that SNTP time is not available.

Use the following commands to view and configure the RTC:

- clock set command on page 106
- Clock sync-rtc-with-SNTP enable command on page 107
- no clock sync-rtc-with-SNTP enable on page 107
- <u>Default clock sync-rtc-with-SNTP enable</u> on page 107
- Clock source command on page 108
- default clock source on page 108

clock set command

Use this procedure to set the RTC. The syntax of the clock set.



The clock set command is only applicable for 5530 and 56XX.

Procedure steps

Use the following command from Privileged EXEC mode:

```
clock set {<LINE> | <hh:mm:ss>}
```

Variable definitions

The following table outlines the parameters for the clock set {<LINE> | <hh:mm:ss>} command.

Table 38: clock set command parameters

Variable	Value
<line></line>	A string in the format of mmddyyyyhhmmss that defines the current local time.
<hh:mm:ss></hh:mm:ss>	Numeric entry of the current local time in the manner specified.

Clock sync-rtc-with-SNTP enable command

Use this procedure to enable the synching of the RTC with the SNTP clock when the SNTP clock synchronizes.

■ Note:

The clock sync-rtc-with-SNTP enable command is only applicable for 5530 and 56XX.

Procedure steps

Use the following command from Global Configuration mode:

clock sync-rtc-with-sntp enable

no clock sync-rtc-with-SNTP enable

Use this procedure to disable the synching of the RTC with the SNTP clock when the SNTP clock synchronizes.

Procedure steps

Use the following command from Global Configuration mode:

no clock sync-rtc-with-sntp enable

Default clock sync-rtc-with-SNTP enable

Use this procedure to set the synchronizing of the RTC with the SNTP clock to factory defaults.

Procedure steps

Use the following command from Global Configuration mode:

default clock sync-rtc-with-sntp enable

Clock source command

Use this procedure to set the default clock source for the switch.

Procedure steps

Use the following command from Global Configuration mode:

```
clock source {sntp | rtc | sysUpTime}
Substitute {sntp | rtc | sysUpTime} with the clock source selection.
```

default clock source

Use this procedure to set the clock source to factory defaults.

Procedure steps

Use the following command from Global Configuration mode:

```
default clock source
```

Custom Autonegotiation Advertisements

Custom Autonegotiation Advertisement (CANA) customizes the capabilities that are advertised. It also controls the capabilities that are advertised by the Avaya Ethernet Routing Switch 5000 Series as part of the auto-negotiation process.

The following sections describe configuring CANA with ACLI:

- Configuring CANA on page 108
- Viewing current autonegotiation advertisements on page 50
- Viewing hardware capabilities on page 109
- Setting default auto-negotiation-advertisements on page 109
- no auto-negotiation-advertisements command on page 109

Configuring CANA

Use this procedure to configure CANA.

Procedure steps

Use the following command from Global Configuration mode:

auto-negotiation-advertisements

To configure port 5 to advertise the operational mode of 10 Mb/s and full duplex enter the following command line:

auto-negotiation-advertisements port 5 10-full

Viewing current autonegotiation advertisements

Use this procedure to view the autonegotiation advertisements for the device.

Procedure steps

Use the following command from Global Configuration mode:

show auto-negotiation-advertisements [port <portlist>]

Viewing hardware capabilities

Use this procedure to view the available operational modes for the device.

Procedure steps

Use the following command from Interface Configuration mode:

show auto-negotiation-capabilities [port <portlist>]

Setting default auto-negotiation-advertisements

Use this procedure to make a port advertise all its auto-negotiation-capabilities.

Procedure steps

Use the following command from Interface Configuration mode:

default auto-negotiation-advertisements [port <portlist>]

To set default advertisements for port 5 of the device, enter the following command line:

default auto-negotiation-advertisements port 5

no auto-negotiation-advertisements command

Use this procedure to make a port silent.

Procedure steps

Use the following command from Interface Configuration mode:

no auto-negotiation-advertisements [port <portlist>]

Connecting to Another Switch

Using the Command Line Interface (CLI), it is possible to communicate with another switch while maintaining the current switch connection. This is accomplished with the familiar ping and telnet commands.

ping command

Use this procedure to determine if communication with another switch can be established.

Procedure steps

Use the following command from User EXEC mode:

```
ping <ipv6_address | dns_host_name> [datasize <64-4096>]
[{count <1-9999>} | continuous] [{timeout | -t} <1-120>]
[interval <1-60>] [debug]
```

Substitute < ipv6_address | dns_host_name > with either the IPv6 address or the DNS host name of the unit to test.

Variable definitions

The following table describes the parameters for the ping command.

Table 39: ping command parameters

Variable	Value
<pre><ipv6_address dns_host_name="" =""></ipv6_address></pre>	The IPv6 address or the DNS host name of the unit to test.
datasize <64- 4096>	Specify the size of the ICMP packet to be sent. The data size range is from 64 to 4096 bytes.
count <1-9999> continuous	Set the number of ICMP packets to be sent. The continuous mode sets the ping running until the user interrupts it by entering Ctrl+C.
timeout -t <1-120>	Set the timeout using either the <i>timeout</i> with the <i>-t</i> parameter followed by the number of seconds the switch must wait before timing out.
interval <1-60>	Specify the number of seconds between transmitted packets.
debug	Provide additional output information such as the ICMP sequence number and the trip time.

telnet command

Use this procedure to establish communications with another switch during the current ACLI session.

Procedure steps

Use the following command from User EXEC mode:

```
telnet <ipv6_address | dns_host_name>
```

Substitute < ipv6 address | dns host name > with either the IPv6 address or the DNS host name of the unit with which to communicate.

Communication can be established to only one external switch at a time using the telnet command.

Domain Name Server (DNS) Configuration

Domain name servers are used when the switch needs to resolve a domain name (such as "avaya.com") to an IP address. The following commands allow for the configuration of the switch domain name servers:

- show ip dns command on page 111
- ip domain-name command on page 112
- no ip domain-name command on page 112
- default ip domain-name command on page 112
- ip name-server command on page 113
- no ip name-server command on page 113

show ip dns command

Use this procedure to display DNS-related information.

Procedure steps

Use the following command from User EXEC mode:

show ip dns

O Note:

This information includes the default switch domain name and any configured DNS servers.

ip domain-name command

Use this procedure to set the default DNS domain name for the switch.

Procedure steps

Use the following command from Global Configuration mode:

```
ip domain-name <domain_name>
```

Substitute <domain_name> with the default domain name to be used. A domain name is determined to be valid if it contains alphanumeric characters and contains at least one period (.).

3 Note:

This default domain name is appended to all DNS queries or commands that do not already contain a DNS domain name.

no ip domain-name command

Use this procedure to clear a previously configured default DNS domain name for the switch.

Procedure steps

Use the following command from Global Configuration mode:

```
no ip domain-name
```

default ip domain-name command

Use this procedure to set the system default switch domain name.

Procedure steps

Use the following command from Global Configuration mode:

default ip domain-name

■ Note:

Because this default is an empty string, this command has the same effect as the no ip domain-name command.

ip name-server command

Use this procedure to set the domain name servers the switch uses to resolve a domain name to an IP address.

Procedure steps

Use the following command from Global Configuration mode:

```
ip name-server [<ipv6_address> | <ip_address_1> ip name-server
[<ipv6_address> | <ip_address_2>] ip name-server
[<ipv6 address> | <ip address 3>]
```

A switch can have up to three domain name servers specified for this purpose.

■ Note:

To enter all three server addresses you must enter the command three times, each with a different server address.

Variable definitions

The following table outlines the parameters for the ip name-server command.

Table 40: ip name-server command parameters

Variable	Value
ipv6_address	The IPv6 address of the domain name server used by the switch.
<ip_address_1></ip_address_1>	The IP address of the domain name server used by the switch.
<ip_address_2></ip_address_2>	Optional. The IP address of a domain name server to add to the list of servers used by the switch.
<ip_address_3></ip_address_3>	Optional. The IP address of a domain name server to add to the list of servers used by the switch.

no ip name-server command

Use this procedure to remove domain name servers from the list of servers used by the switch to resolve domain names to an IP address.

Procedure steps

Use the following command from Global Configuration mode:

no ip name-server <ip_address_1> no ip name-server [<ip address 2>] no ip name-server [<ip address 3>]

☑ Note:

To enter all three server addresses you must enter the command three times, each with a different server address.

Variable definitions

The following table outlines the parameters for the no ip name-server command.

Table 41: no ip name-server command parameters

Variable	Value
<ip_address_1></ip_address_1>	The IP address of the domain name server to remove.
<ip_address_2></ip_address_2>	Optional. The IP address of a domain name server to remove from the list of servers used by the switch.
<ip_address_3></ip_address_3>	Optional. The IP address of a domain name server to remove from the list of servers used by the switch.

Auto Unit Replacement using the ACLI

The following sections describe Auto Unit Replacement (AUR).

Prerequisites

• The units must be in a stack.

Auto Unit Replacement using the ACLI navigation

- Viewing Auto Unit Replacement using the ACLI on page 115
- Enabling Auto Unit Replacement using the ACLI on page 115
- Disabling AUR using the ACLI on page 116
- Restoring the default setting for AUR using the ACLI on page 116
- Configuring AUR operation settings using the ACLI on page 116

Viewing Auto Unit Replacement using the ACLI

View Unit Replacement (AUR) to understand the current setting and to discover if the unit is ready for replacement.

Procedure steps

Use the following command from the privileged EXEC mode:

show stack auto-unit-replacement

Job aid

The following table describes the fields for the show stack auto-unit-replacement command.

Table 42: show stack auto-unit-replacement fields

Field	Description
Auto Unit Replacement Auto-Restore	Specifies whether the Auto Unit Replacement Auto-Restore is enabled for the stack.
Auto Unit Replacement Auto-Save	Specifies whether the Auto Unit Replacement Auto-Save is enabled for the stack.
UNIT #	Specifies the number of the unit in the stack.
READY FOR REPLACEMENT	Specifies whether the unit is ready for replacement.

Enabling Auto Unit Replacement using the ACLI

Enable Unit Replacement (AUR) to permit the automatic update of a license for any stack unit, including the base unit.

Procedure steps

Use the following command from the Global Configuration mode:

stack auto-unit-replacement enable

Important:

The default mode is enable.

Disabling AUR using the ACLI

Disable AUR to stop the automatic update of a license for any stack unit, including the base unit.

Procedure steps

Use the following command from the Global Configuration mode:

no stack auto-unit-replacement enable

Restoring the default setting for AUR using the ACLI

Restore the default setting for AUR to permit the automatic update of a license for any stack unit, including the base unit.

Procedure steps

Use the following command from the Global Configuration mode:

default stack auto-unit-replacement enable

Configuring AUR operation settings using the ACLI

Configure AUR to modify the operation settings.

Procedure steps

1. Restore the configuration of a unit from the saved configuration on the base unit by using the following command in Global Configuration mode:

```
stack auto-unit-replacement config restore unit <1-8>
```

2. Force an immediate save of the new base unit (NBU) configuration to the base unit (BU) by using the following command in Global Configuration mode:

```
stack auto-unit-replacement config save unit <1-8>
```

Enable AUR auto save by using the following command in Global Configuration mode:

```
stack auto-unit-replacement config save enable
```

4. DIsable AUR auto save by using the following command in Global Configuration mode:

stack auto-unit-replacement config save disable

Variable definitions

The following table explains the parameters for the stack auto-unit-replacement config {restore unit <1-8>|save {enable|disable|unit <1-8>}} coimmand.

Table 43: stack auto-unit-replacement config parameters

Variable	Value
disable	Disables AUR auto save.
enable	Enables AUR auto-save.
restore	Restores the configuration of a unit from the saved configuration on the base unit by
save	Forces an immediate save of the NBU configuration to the BU.
unit <1-8>	Identifies the unit in the stack.

Avaya Energy Saver configuration using the ACLI

You can use Avaya Energy Saver (AES) to configure the switch to utilize energy more efficiently.

AES configuration using the ACLI navigation

- Configuring global AES using the ACLI on page 118
- Configuring port-based AES using the ACLI on page 119
- Activating or deactivating AES manually using the ACLI on page 120
- Configuring AES scheduling using the ACLI on page 121
- Disabling AES scheduling using the ACLI on page 122
- Configuring AES scheduling to default using the ACLI on page 123
- Viewing AES scheduling using the ACLI on page 123
- Viewing AES savings using the ACLI on page 124
- Viewing the global AES configuration using ACLI on page 124
- Viewing port-based AES configuration using the ACLI on page 125

Configuring global AES using the ACLI

Use the following procedure to enable or disable the energy saving feature for the switch. Avaya recommends disabling AES on uplink copper ports since activating or deactivating AES on copper ports will trigger a link down followed rapidly by a link up event. The best solution is to use fiber ports for uplinks since link status will not change when AES is activated or deactivated.

Important:

If a switch is reset while energy-saver is activated, the PoE power saving calculation may not accurately reflect the power saving, and in some cases may display zero savings. This is because the switch did not have sufficient time to record PoE usage between the reset of the switch and energy-saver being reactivated. When energy saver is next activated, the PoE power saving calculation will be correctly updated.

Important:

Some RIP routes might be cleared when AES is activated or deactivated on the uplink ports. Routes are automatically recovered when routes are relearned.

Using ip rip advertise-when-down enable option on the IP interface affected by the link change will help to keep the routes learned.

Important:

OSPF neighbors can disconnect when AES is activated or deactivated on uplink ports. Because of this link status change, some OSPF routes are cleared from the routing tables and automatically recovered when routes are relearned.

Using the ip ospf advertise-when-down enable command for the IP interface affected by the link change will help the routes remain learned.

Procedure steps

Use the following command from Global Configuration mode:

```
[no] [default] energy-saver [enable] [efficiency-mode] [poe-
power-saving]
```

Variable definitions

The following table defines optional parameters that you can enter with the [no] [default] energy-saver [enable] [efficiency-mode] [poe-power-saving] command.

October 2012 118 Configuration — System

Variable	Value
[default]	Configures AES efficiency mode, POE power saving, or global AES to default values (disabled).
efficiency-mode	Enables AES efficiency mode.
	Important:
	You must ensure that SNTP is enabled before you can enable AES efficiency mode.
	Important:
	You must disable AES globally before you can modify AES efficiency mode.
	1 Important:
	When enabled, AES efficiency mode overrides custom AES scheduling and PoE power saving mode. You will be prompted to confirm that you want to enable AES efficiency mode before proceeding.
enable	Enables AES globally.
[no]	Disables AES efficiency mode, POE power saving, or AES globally.
poe-power-saving	Enables POE power saving.
	Important: You must disable AES globally before you can modify POE power saving.

Configuring port-based AES using the ACLI

Use the following procedure to enable or disable energy saving for the accessed port, an alternate individual port, or a range of ports.

Prerequisites

• Disable AES globally.

Procedure steps

Use the following command from Interface Configuration mode:

[default] [no] energy-saver port <portlist> enable

Variable definitions

The following table defines optional parameters that you enter after the [default] [no] energy-saver port <portlist> enable command.

Variable	Value
<enable></enable>	Enables AES for the accessed port.
[no]	Disables AES for the accessed port, an alternate port, or list of ports.
port <portlist> enable</portlist>	Enables AES for a port or list of ports.

Activating or deactivating AES manually using the ACLI

Use the following procedure to have AES enabled, but not activated. Activate AES to ensure that AES is enabled and activated.

Prerequisites

- Disable AES globally.
- Log on to the in ACLI.

Procedure steps

1. Activate AES by using the following command from Pivileged EXEC mode:

energy-saver activate

2. Deactivate AES by using the following command from Pivileged EXEC mode:

energy-saver deactivate

Configuring AES scheduling using the ACLI

Use the following procedure to configure an on and off time interval for the switch to enter lower power states. The time interval can be a complete week, complete weekend, or individual days.

Prerequisites

• Disable AES globally.

Procedure steps

Configure AES scheduling by using the following command from Global Configuration mode:

energy-saver schedule {weekday|weekend|monday|tuesday | wednesday|thursday|friday|saturday|sunday} <hh:mm> {activate| deactivate}

Variable definitions

The following table defines parameters that you can enter with the energy-saver schedule {weekday|weekend|monday|tuesday|wednesday|thursday|friday|saturday|

Variable	Value
<activate></activate>	Specifies the AES on time.
<deactivate></deactivate>	Specifies the AES off time.
friday monday saturday sunday thursday tuesday wednesday	Configures AES scheduling for a specific day.
<hh:mm></hh:mm>	Specifies the scheduled AES start time (hour and minutes).
weekday	Configures AES scheduling for all weekdays.

Variable	Value
weekend	Configures AES scheduling for Saturday and Sunday.

Disabling AES scheduling using the ACLI

Use the following procedure to discontinue using an on and off time interval for the switch to enter lower power states.

Prerequisites

Disable AES globally.

Procedure steps

Configure AES scheduling by using the following command from the Global Configuration mode:

no energy-saver schedule

Variable definitions

The following table defines optional parameters that you can enter after the no energy-saver schedule command.

Variable	Value
friday monday saturday sunday thursday tuesday wednesday	Disables AES scheduling for a specific day.
weekday	Disables AES scheduling for all weekdays.
weekend	Disables AES scheduling for Saturday and Sunday.
<hh:mm></hh:mm>	Specifies the scheduled AES start time (hour and minutes).

122 Configuration — System October 2012

Configuring AES scheduling to default using the ACLI

Use the following procedure to completely disable scheduling for the switch or to disable specific energy saver schedules.

Prerequisites

Disable NES globally.

Procedure steps

Configure AES scheduling by using the following command from Global Configuration mode:

default energy-saver schedule

Variable definitions

The following table defines optional parameters that you can enter after the default energy-saver schedule command.

Variable	Value
friday monday saturday sunday thursday tuesday wednesday	Configures AES scheduling for a specific day to default (disabled).
weekday	Configures AES scheduling for all weekdays to default (disabled).
weekend	Configures AES scheduling for Saturday and Sunday to default (disabled).
<hh:mm></hh:mm>	Specifies the scheduled AES start time (hour and minutes).

Viewing AES scheduling using the ACLI

Use the following procedure to review configured energy saving schedule information.

Procedure steps

View AES savings by using the following command from User EXEC mode.

show energy-saver schedule

Job aid: show energy-saver schedule command output

The following figure displays sample output for the **show energy-saver schedule** command.




Figure 16: show energy-saver schedule command output

Viewing AES savings using the ACLI

Use the following procedure to review the switch capacity energy saving (Watts) and the PoE energy saving (Watts).

Procedure steps

View AES savings by using the following command from User EXEC mode:

show energy-saver savings

Viewing the global AES configuration using ACLI

Use the following procedure to review the AES configuration for the switch.

Prerequisites

• Log on to the User EXEC mode in ACLI.

Procedure steps

View the global AES configuration by using the following command from User EXEC mode:

show energy-saver

Job aid: show energy-saver command output

The following figure displays sample output for the show energy-saver command.

```
| S530-24TFD(config)#show energy-saver
| Avaya Energy Saver (AES): Enabled
| AES PoE Power Saving Mode: Disabled
| AES Efficiency-Mode Mode: Disabled
| Day/Time: Not set
| Current AES state: AES is Inactive
```

Figure 17: show energy-saver command output

Viewing port-based AES configuration using the ACLI

Use the following procedure to review AES configuration for all ports on the switch, an individual port, or range of ports.

Prerequisites

Log on to the User EXEC mode in ACLI.

Procedure steps

View AES savings by using the following command:

show energy-saver interface

Variable definitions

The following table defines optional parameters that you can enter after the **show energy- saver interface** command.

Variable	Value
<portlist></portlist>	Specifies a port or range of ports.

Job aid: show energy-saver interface command output

The following figure displays sample output for the **show energy-saver interface** command using the *<portalist>* variable.

Port	AES State	PoE Saving	s PoE Priority
1	Enabled	Enabled	Low
2 3	Disabled	Disabled	Low
3	Enabled	Enabled	Low
4 5	Disabled	Disabled	Low
5	Enabled	Enabled	Low
6	Disabled	Disabled	Low
7	Disabled	Disabled	Low
8	Disabled	Disabled	Low
9	Disabled		Low

Figure 18: show energy-saver interface command output

Changing switch software in the ACLI

Use this procedure to change the software version running on the switch.

Procedure steps

1. Use the following command from User EXEC mode:

```
download [address <ipv6_address> | <a.b.c.d>] {primary |
secondary} {image <image name> | image-if-newer <image name>
| diag <image name> | poe_module_image <image name>) [no-
reset] [usb]
```

2. Press Enter.

The software download process occurs automatically without user intervention. This process deletes the contents of the flash memory and replaces it with the desired software image. Do not interrupt the download process. Depending on network conditions, this process make take up to 10 minutes.

When the download process is complete, the switch automatically resets unless the noreset parameter was used. The software image initiates a self-test and returns a message when the process is complete.

The following table shows an example of this message.

Table 44: Software download message output

```
Download Image [/]
Saving Image [-]
Finishing Upgrading Image
```

During the download process the switch is not operational.

The progress of the download process can be tracked by observing the front panel LEDs. For more information about this topic, refer to LED activity during software download on page 24.

Variable definitions

The following table outlines the parameters for the **download** command.

Table 45: download command parameters

Variable	Value
address <ipv6_address> <a.b.c.d></a.b.c.d></ipv6_address>	This parameter is the IPv6 or IP address of the TFTP server to be used. The address <ip> parameter is optional and if omitted the switch defaults to the TFTP server specified by the tftp-server command unless software download is to take place using a USB Mass Storage Device.</ip>
primary secondary	This parameter determines if the image is the primary or secondary image.
image <image name=""/>	This parameter is the name of the software image to be downloaded from the TFTP server.
image-if-newer <image name=""/>	This parameter is the name of the software image to be downloaded from the TFTP server if newer than the currently running image.
diag <image name=""/>	This parameter is the name of the diagnostic image to be downloaded from the TFTP server.

Variable	Value
<pre>poe_module_image <image name=""/></pre>	This parameter is the name of the PoE module image to be downloaded from the TFTP server. This option is only available in 5000 Series switches that support Power Over Ethernet.
no-reset	This parameter forces the switch to not reset after the software download is complete.
usb	In the 5530-24TFD or 5600 series switches, this parameter specifies that the software download is performed using a USB Mass Storage Device and the front panel USB port.
The image, image-if-newer, diag, and poe_module_image parameters are mutually exclusive and only one can be executed at a time.	

Configuration files in ACLI

ACLI provides many options for working with configuration files. Through ACLI, configuration files can be displayed, stored, and retrieved.

For details, refer to the following:

- Displaying the current configuration on page 128
- Storing the current configuration on page 129
- Restoring a system configuration on page 131
- Saving the current configuration on page 132
- Automatically downloading a configuration file with ACLI on page 133

Displaying the current configuration

Use this procedure to display the current configuration of switch or a stack.

Procedure steps

- Log on to the Privileged EXEC mode in the ACLI.
- 2. Display the current configuration parameters that differ from the default configuration by using the following command:

show running-config

3. Display all the current configuration parameters t by using the following command:

128 Configuration — System October 2012

show running-config verbose

4. Display the current configuration for a specific application by using the following command:

show running-config module <value>

Important:

If the switch CPU is busy performing other tasks, the output of the aboverunningconfig command can appear to intermittently start and stop. This is a normal operation to ensure that the switch management tasks receive appropriate priority.

Variable definitions

Use the data in the following table to help you use the show running-config [verbose] [module <value>] command.

Table 46: show running-config parameters

Variable	Value
verbose	Displays all the configuration including defaults and nondefaults.
module <value></value>	Displays the configuration of an application for any of the following parameter values: [802.1ab] [aaur] [adac] [arp-inspection] [asset-id] [aur] [banner] [core] [dhcp-relay] [dhcp-snooping] [eap] [energy-saver] [interface] [ip] [ip-source-guard] [ipfix] [ipmgr] [ipv6] [l3] [l3-protocols] [lacp] [logging] [macsecurity] [mlt] [nsna] [port-mirroring] [qos] [rate-limit] [rmon] [rtc] [snmp] [ssh] [ssl] [stack] [stkmon] [stp] [vlacp] [vlan]

Storing the current configuration

Copy the running configuration to store the information. The copy running-config command copies the contents of the current configuration file to another location for storage. For all switches in the 5000 Series, the configuration file can be saved to a TFTP server. The Avaya Ethernet Routing Switch 5530-24TFD or 5600 Series switches also provide the ability to save the configuration file to a USB Mass Storage Device through the front panel USB drive.

Procedure steps

- 1. Log on to the Privileged EXEC mode in the ACLI.
- 2. Copy the running configuration to the TFTP server by using the following command:

 copy running-config tftp address {<A.B.C.D>/<WORD>} filename
- 3. Copy the running configuration to the USB by using the following command:
 copy running-config usb {[module <value>] | [verbose]} filename <WORD>

Variable definitions

The following table outlines the parameters of the copy running-config [tftp address {<A.B.C.D>|<WORD>}| usb {[module <value>]|[verbose]}} filename <WORD> command.

Table 47: copy running-config parameters

Variable	Value
address { <a.b.c.d> <word>}</word></a.b.c.d>	Specifies the address of the TFTP server to be used:
	A.B.C.D—specifies the IP address.
	WORD—specifies the IPv6 address.
filename <word></word>	Specifies the name of the file that is created when the configuration is saved to the TFTP server or USB Mass Storage Device.
module <value></value>	Displays the configuration of an application for any of the following parameter values: [802.1ab] [aaur] [adac] [arp-inspection] [asset-id] [aur] [banner] [core] [dhcp-relay] [dhcp-snooping] [eap] [energy-saver] [interface] [ip] [ip-source-guard] [ipfix] [ipmgr] [ipv6] [l3] [l3-protocols] [lacp] [logging] [macsecurity] [mlt] [nsna] [port-mirroring] [qos] [rate-limit] [rmon] [rtc] [snmp] [ssh] [ssl] [stack] [stkmon] [stp] [vlacp] [vlan]
tftp	Copies all of the running configuration file to a specified file on the TFTP server.
verbose	Copies all the configuration, including defaults and non-defaults, to the USB.

Variable	Value
	Copies all of the running configuration file to the USB.

Restoring a system configuration

ACLI provides three commands for restoring a system configuration to a switch:

- copy tftp config on page 131
- copy usb config on page 131
- copy tftp config unit on page 132

copy tftp config

Use this procedure to restore a configuration file stored on a TFTP server.

Procedure steps

Use the following command from Privileged EXEC mode:

copy tftp config address <A.B.C.D> filename <name>

Variable definitions

The following table outlines the parameters of the copy tftp config command.

Table 48: copy tftp config command parameters

Variable	Value
address <a.b.c.d></a.b.c.d>	The IP address of the TFTP server to be used.
filename <name></name>	The name of the file to be retrieved.

copy usb config

Use this procedure to restore a configuration file stored on a USB Mass Storage Device.

Procedure steps

Use the following command from Privileged EXEC mode:

copy usb config filename < name >

Note:

The only parameter for this command is the name of the file to be retrieved from the USB device.

copy tftp config unit

Use this procedure to enable the configuration of a switch in a stack to be copied to a standalone switch for the purpose of replacing units in a stack.

Procedure steps

Use the following command from Privileged EXEC mode:

copy tftp config unit address <A.B.C.D> filename <name> unit <unit number>

Variable definitions

The following table outlines the parameters of the copy tftp config unit command.

Table 49: copy tftp config unit command parameters

Variable	Value
address <a.b.c.d></a.b.c.d>	The IP address of the TFTP server to be used.
filename <name></name>	The name of the file to be used.
unit <unit number=""></unit>	The number of the stack unit to be used.

Saving the current configuration

The configuration currently in use on a switch is regularly saved to the flash memory automatically. However, you can manually initiate this process using the copy config nvram command. This command takes no parameters and you must run it in Privileged EXEC mode. If you have disabled the AutosaveToNvramEnabled function by removing the default check in the AutosaveToNvRamEnabled field, the configuration is not automatically saved to the flash memory.

write memory command

Use this procedure to copy the current configuration to NVRAM.

Procedure steps

Use the following command from Privileged EXEC mode:

Comments? infodev @avaya.com

write memory

save config command

Use this procedure to copy the current configuration to NVRAM.

Procedure steps

Use the following command from Privileged EXEC mode:

save config

Automatically downloading a configuration file with ACLI

Use this procedure to enable a script to be loaded and executed immediately as well as configure parameters to automatically download a configuration file when the switch or stack is booted.

Procedure steps

Use the following command from Privileged EXEC mode:

configure network load-on-boot {disable | use-bootp | useconfig address < A.B.C.D> filename < name>



The current switch settings relevant to this process can be viewed using the show config-network command. This command takes no parameters and must be executed in Privileged EXEC mode.

Variable definitions

The following table outlines the parameters of the configure network command.

Table 50: configure network command parameters

Variable	Value
<pre>load-on-boot {disable use- bootp use- config}</pre>	Specifies the settings for automatically loading a configuration file when the system boots:

Variable	Value
	disable - disables the automatic loading of config file
	use-bootp - specifies loading the ASCII configuration file at boot and using BootP to obtain values for the TFTP address and filename
	use-config - specifies loading the ASCII configuration file at boot and using the locally configured values for the TFTP address and filename
	≫ Note:
	If you omit this parameter, the system immediately downloads and runs the ASCII config file.
address <a.b.c.d></a.b.c.d>	The IP address of the desired TFTP server.
filename <name></name>	The name of the configuration file to use in this process

Terminal setup

Use this procedure to configure terminal settings.

These settings are transmit and receive speeds, terminal length, and terminal width.

Procedure steps

Use the following command from User EXEC mode:

terminal speed $\{2400 | 4800 | 9600 | 19200 | 38400\}$ length <0-132> width <1-132>



The **show** terminal command can be used at any time to display the current terminal settings. This command takes no parameters and is executed in the EXEC command mode.

Variable definitions

The following table outlines the parameters of the terminal command.

Table 51: terminal command parameters

Variable	Value
speed {2400 4800 9600 19200 38400}	Sets the transmit and receive baud rates for the terminal. The speed can be set at one of the five options shown; the default is 9600.
length	Sets the length of the terminal display in lines; the default is 23.
	S Note:
	If the terminal length is set to a value of 0, the pagination is disabled and the display continues to scroll without stopping.
width	Sets the width of the terminal display in characters; the default is 79.

Setting the default management interface

You can set the default management interface with ACLI to suit the preferences of the switch administrator. This selection is stored in NVRAM and propagated to all units in a stack configuration. When the system is started, the banner displays and prompts the user to enter Ctrl+Y. After these characters are entered, the system displays either a menu or the command line interface prompt, depending on previously configured defaults. When using the console port, you must log out for the new mode to display. When using Telnet, all subsequent Telnet sessions display the selection.

Use this procedure to change the default management interface.

Procedure steps

Use the following command from Privileged EXEC mode:

cmd-interface {cli | menu}

Setting Telnet access

ACLI can be accessed through a Telnet session. To access ACLI remotely, the management port must have an assigned IP address and remote access must be enabled.

Note:

Multiple users can access ACLI system simultaneously, through the serial port, Telnet, and modems. The maximum number of simultaneous users is four, plus, one each at the serial port for a total of 12 users on the stack. All users can configure simultaneously.

For details on viewing and changing the Telnet-allowed IP addresses and settings, refer to the following:

- telnet-access command on page 136
- no telnet-access command on page 137
- default telnet-access command on page 138

telnet-access command

Use this procedure to configure the Telnet connection that is used to manage the switch

Procedure steps

Use the following command from Global Configuration mode:

```
telnet-access [enable | disable] [login-timeout <1-10>] [retry
<1-100>] [inactive-timeout <0-60>] [logging {none | access |
failures | all}] [source-ip <1-50> <51-100> <A.B.C.D> <WORD>
[mask <A.B.C.D>]
```

Variable definitions

The following table outlines the parameters of the telnet-access command.

Table 52: telnet-access command parameters

Variable	Value
enable disable	Enables or disables Telnet connection.
login-timeout <1-10>	Specify in minutes the time to wait for Telnet and Console login before the connection closes. Enter an integer between 1 and 10.
retry <1-100>	Specify the number of times the user can enter an incorrect password before closing the connection. Enter an integer between 1 and 100.
inactive-timeout <0-60>	Specify in minutes the duration for an inactive session to be terminated.
<pre>logging {none access failures all}</pre>	Specify the events whose details you want to store in the event log: noneDo not save access events in the log

Variable	Value
	accessSave only successful access events in the log failureSave failed access events in the log allSave all access events in the log
<pre>[source-ip <1-50> <a.b.c.d> [mask <a.b.c.d>] [source-ip <51-100> <word></word></a.b.c.d></a.b.c.d></pre>	Specify the source IP address from which connections are allowed. Enter the IP address in dotted-decimal notation. Mask specifies the subnet mask from which connections are allowed; enter IP mask in dotted-decimal notation. Specify the source IPv6 address and prefix from which to allow connections.

no telnet-access command

Use this procedure to disable the Telnet connection.

Procedure steps

Use the following command from Global Configuration mode:

• For an IPv4 address and mask pair:

```
no telnet-access [source-ip [<1-50>]]
```

• For an IPv6 address and mask pair:

```
no telnet-access [source-ip [<51-100>]]
```

Variable definitions

The following table outlines the parameters of the no telnet-access command.

Table 53: no telnet-access command parameters

Variable	Value
source-ip [<1-50>] source- ip [<51-100>]	Disables the Telnet access. When you do not use the optional parameter, the source-ip list is cleared, meaning the first index is set to 0.0.0.0/0.0.0.0, the second to fiftieth indexes are set to 255.255.255.255.255.255.255.255.255, the fiftyfirst index is set to ::/ 0, and the fiftysecond to hundredth indexes are set to ffff:ffff:ffff:ffff:ffff:ffff:ffff:

default telnet-access command

Use this procedure to set the Telnet settings to the default values.

Procedure steps

Use the following command from Global Configuration mode:

default telnet-access

Setting boot parameters

The command outlined in this section is used for booting the switch or stack as well as setting boot parameters.

boot command

Use this procedure to perform a soft-boot of the switch or stack

Procedure steps

Use the following command from Privileged EXEC mode:

boot [default] [partial default] [unit <unitno>]

3 Note:

When you reset to factory defaults, the switch or stack retains the last reset count and reason for last reset; these two parameters do not default to factory defaults. Stack operational mode is retained only when resetting to partial-default.

Variable definitions

The following table outlines the parameters of the boot command.

Table 54: boot command parameters

Variable	Value
default	Reboot the stack or switch and use the factory default configurations
partial-default	Reboot the stack or switch and use partial factory default configurations

Variable	Value
unit <unitno></unitno>	Unit number

Defaulting to BootP-when-needed

The BootP default value is BootP-when-needed. This enables the switch to be booted and the system to automatically seek a BootP server for the IP address.

If an IP address is assigned to the device and the BootP process times out, the BootP mode remains in the default mode of BootP-when-needed.

However, if the device does not have an assigned IP address and the BootP process times out, the BootP mode automatically changes to BootP disabled. But this change to BootP disabled is not stored, and the BootP reverts to the default value of BootP-when-needed after rebooting the device.

When the system is upgraded, the switch retains the previous BootP value. When the switch is defaulted after an upgrade, the system moves to the default value of BootP-when-needed.

Configuring with the command line interface

This section covers ACLI commands needed to configure BootP parameters:

- ip bootp server command on page 139
- no ip bootp server command on page 140
- default ip bootp server command on page 140

ip bootp server command

Use this procedure to configure BootP on the current instance of the switch or server.

This command is used to change the value of BootP from the default value, which is BootP-when-needed.

Procedure steps

Use the following command from Global Configuration mode:

```
ip bootp server {always | disable | last | needed}
```

Variable definitions

The following table outlines the parameters of the ip bootp server command.

Table 55: ip bootp server command parameters

Variable	Value
always disable last I needed	Specifies when to use BootP:
	always - Always use BootP
	disable - never use BootP
	last - use BootP or the last known address
	needed - use BootP only when needed
	Note: The default value is to use BootP when needed.

no ip bootp server command

Use this procedure to disable the BootP server.

Procedure steps

Use the following command from Global Configuration mode:

no ip bootp server

default ip bootp server command

Use this procedure to use BootP when needed.

Procedure steps

Use the following command from Global Configuration mode:

default ip bootp server

shutdown command

The **shutdown** command proves a mechanism for safely shutting down a switch or stack without interfering with device processes or corrupting the software image. After this command

is issued, the configuration is saved, auto-save functionality is temporarily disabled, and configuration changes are not allowed until the switch or stack restarts. If the shutdown is cancelled, auto-save functionality returns to the state in which it was previously functioning.

Use this procedure to shut down a switch or stack.

Procedure steps

Use the following command from Privileged EXEC mode:

```
shutdown [force] [minutes-to-wait <1-60>] [cancel]
```

Variable definitions

The following table outlines the parameters of the **shutdown** command.

Table 56: shutdown command parameters

Variable	Value
force	This parameter forces the shutdown without confirmation.
minutes-to-wait <1-60>	This parameter represents the number of minutes to wait before the shutdown occurs. If no value is specified, the default value of 10 minutes is used.
cancel	This parameter cancels a scheduled shutdown any time during the time period specified by the minutes-to-wait parameter.

reload command

The reload command operates in a similar fashion to the shutdown command. However, the reload command is intended more to be used by system administrators using the command functionality to configure remote devices and reset them when the configuration is complete.

The reload command differs from the shutdown command in that the configuration is not explicitly saved after the command is issued. This means that any configuration changes must be explicitly saved before the switch or stack reloads.

The reload command does temporarily disable auto-save functionality until the reload occurs. Cancelling the reload returns auto-save functionality to any previous setting.

Use this procedure to reload a switch or stack.

Procedure steps

Use the following command from Privileged EXEC mode:

```
reload [force] [minutes-to-wait <1-60>] [cancel]
```

Variable definitions

The following table outlines the parameters of the reload command.

Table 57: reload command parameters

Variable	Value
force	This parameter forces the reload without confirmation.
minutes-to-wait <1-60>	This parameter represents the number of minutes to wait before the reload occurs. If no value is specified, the default value of 10 minutes is used.
cancel	This parameter cancels a scheduled reload any time during the time period specified by the minutes-to-wait parameter.

ACLI Help

Use this procedure to obtain help on the navigation and use of Command Line Interface (ACLI).

Procedure steps

Use the following command:

help {commands | modes}



These commands are available in any command mode.

Use help commands to obtain information about the commands available in ACLI organized by command mode. A short explanation of each command is also included.

Use help modes to obtain information about command modes available and ACLI commands used to access them.

Clearing the default TFTP server with ACLI

Use this procedure to clear the TFTP server and reset it to 0.0.0.0.

Procedure steps

The default TFTP server can be cleared from the switch and reset to 0.0.0.0 with the following two commands:

•no tftp-server

This command has no parameters and is executed from the Global Configuration command mode.

•default tftp-server

This command has no parameters and is executed from the Global Configuration command mode.

Configuring a default TFTP server with ACLI

The switch processes that make use of a TFTP server often give the switch administrator the option of specifying the IP address of a TFTP server to be used. Instead of entering this address every time it is needed, a default IP address can be stored on the switch.

Use this procedure to specify a default TFTP server.

Procedure steps

1. Use the following command from Privileged EXEC mode:

```
tftp-server [<ipv6_address> | <A.B.C.D>
```

2. To complete the command, replace either the ipv6_address or <A.B.C.D> with
the IPv6 or IP address of the default TFTP server

Displaying the default TFTP server with ACLI

Use this procedure to display the default TFTP server configured for the switch.

Procedure steps

Use the following command from Privileged EXEC mode:

show tftp-server

Secure Transfer File Protocol configuration

This section describes Secure Transfer File Protocol (SFTP) configuration using the ACLI.

Navigation

- Uploading a config file to an SFTP server on page 144
- Downloading a config file to an SFTP server on page 145
- Enabling DSA authentication on page 147
- Disabling DSA authentication on page 147
- Enabling Password authentication on page 148
- Disabling Password authentication on page 148
- Setting the Transmission Control Protocol port on page 148
- Setting timeout on page 149
- Viewing SFTP on page 149

Uploading a config file to an SFTP server

Upload a config file to a SFTP server using SFTP protocol.

Procedure steps

Use the following command from the Global Configuration mode:

```
copy config sftp address < A.B.C.D | WORD> filename < WORD>
[username <WORD> password <WORD>]
```

Important:

If you do not enter the username and password, and the default values are not available, you are prompted for these parameters if the password authentication is enable.

If the password authentication is disable and you enter the username and password, the password authentication changes from the inactive to active state.

Variable definitions

Use the data in the following table to help you upload a config file.

Table 58: copy config sftp address command parameters

Variable	Value
address <a.b.c.d word="" =""></a.b.c.d>	Specifies the address of the SFTP server:
	A.B.C.D specifies the IP address.
	WORD specifies the IPv6 address.
filename <word></word>	Specifies the config file name.
password <word></word>	Specifies the password.
username <word></word>	Specifies the username.

Downloading a config file to an SFTP server

Download a config file to a SFTP server using SFTP protocol.

Procedure steps

Use the following command from the Global Configuration mode:

copy sftp config address < A.B.C.D | WORD> filename < WORD> [username <WORD>][password <WORD>]

! Important:

If you do not enter the username and password, and the default values are not available, you are prompted for these parameters if the password authentication is enable.

If the password authentication is disable and you enter the username and password, the password authentication changes from the inactive to active state.

Variable definitions

Use the data in the following table to help you upload a config file.

Table 59: copy sftp config address command parameters

Variable	Value
address <a.b.c.d word="" =""></a.b.c.d>	Specifies the address of the SFTP server:
	A.B.C.D specifies the IP address.
	WORD specifies the IPv6 address.

Variable	Value
filename <word></word>	Specifies the config file name.
password <word></word>	Specifies the password.
username <word></word>	Specifies the username.

Host keys

This section describes how to configure host keys.

Navigation

- Generating a host key (public and private) on page 146
- Deleting the host keys (public and private) on page 146
- Uploading the public host key on page 146

Generating a host key (public and private)

Generate a host key to replace an old key in the NVRAM. The new key immediately becomes active and the DSA authentication state does not change.

Procedure steps

Use the following command from Global Configuration mode:

sshc dsa-host-key

Deleting the host keys (public and private)

Delete the DSA host keys from the NVRAM. The DSA authentication state does not change.

Procedure steps

Use the following command from Global Configuration mode:

no sshc dsa-host-key

Uploading the public host key

Upload the DSA public host key to an TFTP Server or an USB flash drive if available

Procedure steps

Use the following command from Global Configuration mode:

```
sshc upload-host-key address <A.B.C.D | WORD> filename <WORD>
OR
```

sshc upload-host-key usb filename <WORD> unit <#>

Variable definitions

Use the data in the following table to help you upload the public host key.

Table 60: sshc upload-host-key command parameters

Variable	Value
address <a.b.c.d word="" =""></a.b.c.d>	Specifies the address of the SFTP server:
	A.B.C.D specifies the IP address.
	WORD specifies the IPv6 address.
filename <word></word>	Specifies the config file name.
unit <#>	Specifies the unit number.
usb filename <word></word>	Specifies the USB key file.

Enabling DSA authentication

Enable DSA authentication to generate DSA keys if they are not available.

Procedure steps

Use the following command from Global Configuration mode:

sshc dsa-auth

Disabling DSA authentication

Disable DSA authentication to generate DSA keys if they are not available.

Procedure steps

Use the following command from Global Configuration mode:

no sshc dsa-auth

Enabling Password authentication

Use this procedure to enable Password authentication.

Procedure steps

Use the following command from Global Configuration mode:

sshc pass-auth

Disabling Password authentication

Use this procedure to disable Password authentication.

Procedure steps

Use the following command from Global Configuration mode:

no sshc pass-auth

Setting the Transmission Control Protocol port

Use this procedure to set the Transmission Control Protocol (TCP) port.

Procedure steps

Use the following command from Global Configuration mode:

sshc port TCP-port <portlist>

Variable definitions

Use the data in the following table to help you set the TCP port.

Table 61: sshc port TCP-port command parameters

Variable	Value
portlist	Specifies the TCP port. The default portis 22.

Setting timeout

Set the time expired used during a session.

Procedure steps

Use the following command from Global Configuration mode:

sshc timeout <1-120>

Variable definitions

Use the data in the following table to help you set the time expired parameter.

Table 62: sshc timeout parameters

Variable	Value
<1-120>	Specifies the time expired in the range of 1 to 120 seconds. The default is 60 seconds.

Viewing SFTP

View the current SFTP configuration.

Procedure steps

Use the following command from Global Configuration mode:

sshc show

Job aid

The following table describes the fields for the sshc show command.

Table 63: sshc show command

Field	Description
Version	Specifies the current SSH version.
SFTP Server IP	Specifies the IP or IPv6 address.
Port	Specifies the port number.
The Remote Config File Name	Specifies the Filename.
DSA Authentication	Specifies if DSA authentication is enabled.
Password Authentication	Specifies if Passwor authentication isenabled
User Name (pw auth)	Specifies the use name.
Password (pw auth)	Specifies if
DSA Host Keys	
Key Gen In Process	Specifies whether key generation is in progress.

Configuring daylight savings time with ACLI

Use the following procedure to configure the daylight savings time adjustment with ACLI:

- Use the following command from Global Configuration mode: configure
- 2. Enable sntp server.
- 3. Set the date to change to daylight savings time.

clock summer-time zone date day month year hh:mm day month
year hh:mm [offset]

Variable definitions

The following table outlines the parameters of the clock summer-time command.

Table 64: clock summer-time command parameters

Variables	Value
date	Indicates that daylight savings time should start and end on the specified days every year.

Variables	Value
day	Date to start daylight savings time.
month	Month to start daylight savings time.
year	Year to start daylight savings time.
hh:mm	Hour and minute to start daylight savings time.
day	Date to end daylight savings time.
month	Month to end daylight savings time.
year	Year to end daylight savings time.
hh:mm	Hour and minute to end daylight savings time.
offset	Number of minutes to add during the summer time.
zone	The time zone acronym to be displayed when daylight savings time is in effect. If it is unspecified, it defaults to the time zone acronym set when the time zone was set.

set daylight savings time example

This command sets the daylight savings time to begin at 02:00 on March 28, 2007 and end on August 30th, 2007 at 15:00. The change to daylight savings moves the clock forward by 60 minutes and "BST" will be displayed as the time zone acronym. These changes to and from daylight savings time will happen automatically.

clock summer-time BST date 28 Mar 2007 2:00 30 Aug 2007 15:00 +60

Configuring default clock source with ACLI

Use this procedure to set the default clock source for the switch.

Procedure steps

Use the following command from Global Configuration mode:

clock source {rtp | sntp | sysUpTime}



Substitute {rtp | sntp | sysUpTime} with the clock source selection.

Configuring local time zone with ACLI

SNTP uses Coordinated Universal Time (UTC) for all time synchronizations so it is not affected by different time zones. To have the switch report the time in your local time zone, you need to use the clock commands to set the local time zone.

You must enable SNTP before you set the time zone. If SNTP is not enabled, this command has no effect. If you enable SNTP and do not specify a time zone, UTC is shown by default.

Use this procedure to configure your switch for your local time zone.

Procedure steps

1. Use the following command from Global Configuration mode:

configure

- 2. Enable sntp server.
- 3. Set clock time zone using the clock command.

clock time-zone zone hours [minutes]

Variable definitions

The following table outlines the parameters for the clock time-zone command.

Table 65: clock time-zone command parameters

Variable	Value
zone	Time zone acronym to be displayed when showing system time (up to 4 characters).
hours	Difference from UTC in hours. This can be any value between -12 and +12.
minutes	Optional: This is the number of minutes difference from UTC. Minutes can be any value between 0 and 59.

Configuring Dual Agent with ACLI

Use the following procedures to configure the Dual Agent feature with ACLI:

- Enhanced download command on page 153
- Set the next boot Image on page 154
- Show agent images on page 155

Enhanced download command

You can update either active image or non-active image. Once the image download is done, the unit resets and restarts with the new image regardless of the value of the Next Boot image indicator. In case of image download without reset, the new image in the flash will be the Next Boot image.

Use this procedure to specify the download target image.

Procedure steps

Use the following command from Global Configuration mode:

```
download [address <ipv6_address> | <a.b.c.d>] {primary |
secondary} {image <image name> | image-if-newer <image name> |
diag <image name> I poe_module_image <image name>} [no-reset]
[usb]
```

Variable definitions

The following table outlines the parameters of the download command.

Table 66: download command parameters

Variable	Value
ipv6_address	IPv6 IP address
a.b.c.d	IP address in dot notation.
primary secondary	Choose which image to download.
image <image name=""/>	Download the specified image.
image-if-newer <image name=""/>	Only download the image if the version is newer than the installed version.

Variable	Value
diag <image name=""/>	Download the specified diagnostic image.
<pre>poe_module_image <image name=""/></pre>	Download the specified PoE module image.
no-reset	Do not reset the switch.
usb	Download the image from the USB drive.

3 Note:

Dual Agent supports the Ethernet Routing Switch 5510 NBUs through AAUR.

Set the next boot Image

You can use ACLI commands to change the next boot image of the device. Use the following procedures to change the next boot image:

- toggle-next-boot-image on page 154
- boot secondary on page 154

toggle-next-boot-image

Use this procedure to toggle the next boot image.

Procedure steps

sue the following command from Global Configuration mode:

toggle-next-boot-image



You must restart the switch or stack after this command to use the next boot image as the new primary image.

boot secondary

Use this procedure to use the secondary boot image.

Procedure steps

Use the following command from Global Configuration mode:

boot secondary

Note:

The switch or stack will restart automatically with the new image.

Show agent images

You can use ACLI commands to list the following information about the agent images stored in flash memory:

- Primary image version
- Secondary mage name
- Active image version

Use this procedure to show the agent image information for agent images stored in the flash memory.

Procedure steps

Use the following command from Global Configuration mode:

show boot image

Configuring IPv6 with ACLI

Use the following procedures to configure IPv6:

- Enabling IPv6 interface on the management VLAN on page 156
- Configuring IPv6 interface on the management VLAN on page 157
- Displaying the IPv6 interface information on page 157
- Displaying IPv6 interface addresses on page 158
- Configuring an IPv6 address for a switch or stack on page 159
- Displaying the IPv6 address for a switch or stack on page 160
- Configuring IPv6 management interface on page 160
- Disabling IPv6 globally on page 161
- Returning IPv6 to default settings on page 162
- Configuring IPv6 global properties on page 162
- Displaying the global IPv6 configuration on page 163
- Configuring an IPv6 default gateway for the switch or stack on page 164
- Displaying the IPv6 default gateway on page 164
- Configuring the IPv6 neighbor cache on page 164

- Displaying the IPv6 neighbor information on page 165
- Displaying IPv6 interface ICMP statistics on page 165
- <u>Displaying IPv6 interface statistics</u> on page 166
- Displaying IPv6 TCP statistics on page 167
- Displaying IPv6 TCP connections on page 167
- Displaying IPv6 TCP listeners on page 167
- Displaying IPv6 UDP statistics and endpoints on page 168

You can only execute ACLI commands for IPv6 interface configuration on the base unit of a stack. Use the Global Configuration mode to execute IPv6 commands.

Enabling IPv6 interface on the management VLAN

Use this procedure to enable an IPv6 interface on the management VLAN.

Procedure steps

1. Use the following command from Global Configuration mode:

```
interface vlan 1
```

- 2. Enter ipv6 interface enable.
- 3. Enter exit to return to the main menu.

Use this procedure to enable or disable ipv6 admin status and set icmp error interval:

Procedure steps

1. Use the following command from Global Configuration mode:

```
[no] ipv6 enable [icmp error-interval <0-2147483647> | icmp
unreach-msq]
```

2. Enter exit to return to the main menu.

Variable definitions

The following table outlines the parameters for ipv6 enable:

Table 67: IPv6 enable command parameteres

Variable	Value
enable	Default admin status: enabled
icmp error- interval <0-2147483647>	Specifies the ICMP error interval. Values range from 0 to 2147483647 seconds.

Variable	Value
icmp unreach-msg	Enables the IPv6 ICMP unreach message.

Configuring IPv6 interface on the management VLAN

Use this procedure to assign an IPv6 address to a VLAN.

Procedure steps

1. Use the following command from Global Configuration mode:

interface vlan 1

- 2. Enter ipv6 interface enable.
- 3. Enter exit to return to the main menu.

Displaying the IPv6 interface information

Use this procedure to display the IPv6 interface information.

Procedure steps

Use the following command from Global Configuration mode:

show ipv6 interface

Job aid

The following figure shows the results of the show ipv6 interface command.

			Interf	ace In	formation	on	
IFINDX VLAN-ID	MTU	PHYSICAL	ADMIN	OPER	RCHBLE	RETRAN	TYPE
		ADDRESS	STATE	STATE	TIME	TIME	
10001 1	1522	0:11:f9:34:88:0	enabled	up	30000	1000	ETHER
			Addres				
INTF IPV6					rmation		TATUS
				s Info	rmation		
INTF IPV6				TYPE	ORIG:	in s	
INTF IPV6 INDEX ADDRESS	0:0:0			TYPE UNICAS	ORIG:	IN S	TATUS
INTF IPV6 INDEX ADDRESS 10001 3000:0:0: 10001 fe80:0:0:	(0:0:((0:21)	2:0:99	Addres	TYPE UNICA:	ORIG.	IN S	TATUS

Figure 19: show ipv6 interface

Displaying IPv6 interface addresses

Use this procedure to view IPv6 interface addresses to learn the addresses.

Use the following command from User EXEC mode:

show ipv6 address interface [<WORD 0-45> | vlan <1-4094>]

Variable definitions

The following table outlines the parameters of the **show ipv6 address interface** command.

Table 68: show ipv6 address interface command parameters

Variable	Value
<word 0-45=""></word>	Specifies the IPv6 address length assigned to the management interface.
vlan <1-4094>	Specifies the VLAN ID for which to display IPv6 interface address information. Values range from 1 to 4094.

The following table shows the field descriptions for this command.

Table 69: show ipv6 address interface command field descriptions

Field	Value
IPV6 ADDRESS	Specifies the IPv6 destination address.
VID/BID/TID	
TYPE	Specifies Unicast, the only supported type.
ORIGIN	Specifies a read-only value indicating the origin of the address. The origin of the address is other, manual, DHCP, linklayer, or random.
STATUS	Indicates the status of the IPv6 address. The values of the status are as follows:
	• PREFERRED
	• DEPRECATED
	• INVALID
	• INACCESSIBLE
	• UNKNOWN
	• TENTATIVE
	• DUPLICATE

Configuring an IPv6 address for a switch or stack

Use this procedure to configure and IPv6 address for a switch or stack.

Procedure steps

Use the following command from Global Configuration mode:

ipv6 address { [<ipv6_address/prefix_length>] [stack <ipv6_address/prefix_length>] [switch <ipv6_address/</pre> prefix length>] [unit <1-8> < ipv6 address/prefix length>]

Variable definitions

The following table outlines the parameters of the ipv6 address command.

Table 70: IPv6 address command parameters

Variable	Value
<pre>ipv6_address/ prefix_length</pre>	Specifies the IPv6 address and prefix length.

Variable	Value
stack	IPv6 address and prefix length of stack.
switch	IPv6 address/prefix length of switch.
unit	IPv6 address/prefix length of unit number: 1 to 8

Displaying the IPv6 address for a switch or stack

Use this procedure to display the IPv6 address for a switch or stack.

Procedure steps

Use the following command from Global Configuration mode:

show ipv6 address

Use this procedure to display all ipv6 interface addresses.

Procedure steps

Use the following command from Global Configuration mode: show ipv6 address interface

Job aid

The following figure shows the results of theshow ipv6 address interface command.

	Address	s Information	on	
IPV6	VID/BI	D/TYPE	ORIGIN	STATUS
ADDRESS	TID			
3000:0:0:0:0:0:99	V-1	UNICAST	MANUAL	PREFERRED
fe80:0:0:0:211:f9ff:fe34:8800	V-1	UNICAST	OTHER	UNKNOWN

Figure 20: show ipv6 address interface

Configuring IPv6 management interface

Use this procedure to configure the IPv6 interface and create the VLAN IPv6 interface and set the parameter.

1. Use the following command from Global Configuration mode:

```
interface vlan <mgmt_vlan_id>
```

2. Enter ipv6 interface [address <ipv6_address/prefix_length>]

Variable definitions

The following table outlines the parameters of the ipv6 interface command.

Table 71: ipv6 interface command parameters

Variable	Value
address <ipv6_address prefix_length=""></ipv6_address>	Address or prefix length.
name <1-255>	Name: integer from 1 to 255
link-local <word 0-19=""></word>	Interface identifier,
mtu <1280-9600>	Default status: MTU 1280
reachable-time <0-3600000>	Time in milliseconds neighbor is considered reachable after a reachable confirmation message. Default: 30000
retransmit-timer <0-3600000>	Time in milliseconds between retransmissions of neighbor solicitation messages to a neighbor. Default: 1000

Disabling IPv6 globally

Use this procedure to disable IPv6 globally.

Procedure steps

Use the following command from Global Configuration mode:

no ipv6 interface [address <ipv6_address>][all][enable]



If you do not specify a parameter, you can use the no ipv6 interface to delete an IPv6 interface.

Variable definitions

The following table outlines the parameters for the no ipv6 interface command.

Table 72: no ipv6 interface command parameters

Variable	Value
address	Delete an IPv6 address.
all	Disable interface administrative status or delete an IPv6 address.
enable	Disable interface administrative status.

Returning IPv6 to default settings

Use this procedure to return an IPv6 interface or address to the default settings.

Procedure steps

Use the following command from Global Configuration mode:

```
default ipv6 interface [all | enable | link-local | mtu |
reachable-time | retransmit-timer]
```

Variable definitions

The following table outlines the parameters for the default ipv6 interface command.

Table 73: default ipv6 interface command parameters

Variable	Value
all	Disable interface administrative status or delete an IPv6 address.
enable	Disable interface administrative status.
link-local	Default identifier.
mtu	Default MTU.
reachable-time	Default reachable time.
retransmit-timer	Default retransmit timer.

Configuring IPv6 global properties

Use this procedure to configure the IPv6 global properties.

Procedure steps

Use the following command from Global Configuration mode:

ipv6 [enable | icmp <error-interval | unreach-msg>]

Variable definitions

The following table outlines the parameters for the ipv6 command.

Table 74: ipv6 command parameters

Variable	Value
enable	Enable the IPv6 global administrative status.
icmp	Set the IPv6 ICMP parameters.
	error-interval: Set the IPv6 ICMP error interval.
	unreach-msg: Enable the IPv6 ICMP unreach-msg

Displaying the global IPv6 configuration

Use this procedure to display the global IPv6 configuration.

Procedure steps

Use the following command from Global Configuration mode:

show ipv6 global

Job aid

The following table describes the show ipv6 global command results.

Table 75: show ipv6 global command results

Field	Default setting
forwarding	disabled
default-hop-cnt	30
number-of-interfaces	1
admin-status	enabled
icmp-error-interval	1000
icmp-redirect-msg	disabled

Field	Default setting
icmp-unreach-msg	disabled
multicast-admin-status	disabled

Configuring an IPv6 default gateway for the switch or stack

Use this procedure to configure an IPv6 default gateway for the switch or stack.

Procedure steps

1. Use the following command from Global Configuration mode:

```
ipv6 default-gateway <ipv6_gateway address>
```

2. Enter no ipv6 default-gateway to disable a default gateway.

Displaying the IPv6 default gateway

Use this procedure to display the IPv6 address for the default gateway.

Procedure steps

Use the following command from Global Configuration mode:

show ipv6 default-gateway

Configuring the IPv6 neighbor cache

Use this procedure to add or remove a static neighbor cache entry.

Procedure steps

1. Use the following command from Global Configuration mode to add a static neighbor cache:

```
ipv6 neighbor <ipv6_address> [port <port/slot>] [mac <H.H.H>]
```

2. Use the following command from Global Configuration mode to remove a static neighbor cache entry:

no ipv6 neighbor <ipv6_address> [port <port/slot>] [mac
<H.H.H>]

Displaying the IPv6 neighbor information

Use this command to display IPv6 neighbor information.

Procedure steps

Use the following command from Global Configuration mode:

```
show ipv6 neighbor [<ipv6_address>] [type {other | dynamic |
static | local}]
```

Job aid

The following figure shows the output of the show ipv6 neighbor command.

	Neighbor Info	rmation		
NET ADDRESS/	PHYS	TYPE	STATE	LAST
PHYSICAL ADDRESS	INTF			UPD
3000:0:0:0:0:0:0:0/ 00:11:f9:34:88:00	V-1	LOCAL	REACHABLE	0
3000:0:0:0:0:0:0:1/	1/5	STATIC	REACHABLE	387452
00:01:02:03:04:05				
3000:0:0:0:0:0:0:99/	V-1	LOCAL	REACHABLE	385251
00:11:f9:34:88:00				
fe80:0:0:0:211:f9ff:fe34:8800/	V-1	LOCAL	REACHABLE	385193
00:11:f9:34:88:00				

Figure 21: show ipv6 neighbor

Displaying IPv6 interface ICMP statistics

Use this procedure to display IPv6 interface ICMP statistics.

Use the following command from Global Configuration mode:

```
show ipv6 interface icmpstatistics [<1-4094>]
```

Job aid

The following figure shows a sample of the results from the **show ipv6 interface** icmpstatistics command.

```
[config) #show ipv6 interface icmpstatistics

Icmp Stats

Icmp Stats

Icmp stats for IfIndex = 10001

IcmpInMsgs: 1
IcmpInExrors: 1
IcmpInDestUnreachs : 1
IcmpInAdminProhibs : 0
IcmpInTimeExcds : 0
IcmpInParmProhlems : 0
IcmpInParmProhlems : 0
IcmpInPktTooBigs : 0
IcmpInEchos : 0
IcmpInEchoReplies : 0
```

Figure 22: show ipv6 interface icmpstatistics

Displaying IPv6 interface statistics

Use this procedure to display IPv6 TCP statistics.

Use the following command from Global Configuration mode:

show ipv6 interface statistics [<1-4094>]

Job aid

The following figure shows a sample of the results from the **show ipv6 interface** statistics command.

```
Interface Stats

Interface Stats

If stats for IfIndex = 10001

InReceives: 0
InHorExtors: 0
InTooBigExtors: 0
InNoRoutes: 0
InMoRoutes: 0
InDunknownProtos: 0
InTruncatedPkts: 0
InDiscards: 0
InDelivers: 20
<truncated>
```

Figure 23: show ipv6 interface statistics

Displaying IPv6 TCP statistics

Use this procedure to display IPv6 TCP statistics.

Procedure steps

Use the following command from Global Configuration mode:

```
show ipv6 tcp
```

Job aid

The following figure shows a sample result from the show ipv6 tcp command.

```
(config) #show ipv6 tcp
show ipv6 tcp global statistics:
ActiveOpens:
PassiveOpens:
AttemptFails:
EstabResets:
OutSegs:
RetransSegs:
OutRsts:
                24
HCOutSegs:
```

Figure 24: show ipv6 tcp

Displaying IPv6 TCP connections

Use this procedure to display IPv6 TCP connections.

Procedure steps

Use the following command from Global Configuration mode:

```
show ipv6 tcp connections [<WORD 0-128>] [<portList>] [<WORD
0-128 > ]
```

Displaying IPv6 TCP listeners

Use this procedure to display IPv6 TCP listeners.

Procedure steps

Use the following command from Global Configuration mode:

show ipv6 tcp listener

Displaying IPv6 UDP statistics and endpoints

Use this procedure to display IPv6 UDP statistics and endpoints.

Procedure steps

1. Use the following command from Global Configuration mode to show UDP statistics:

show ipv6 udp

Use the following command from Global Configuration mode to show UDP endpoints:

show ipv6 udp endpoints

Configuring LLDP with ACLI

You can enable and configure LLDP with ACLI. For more information about LLDP, see <u>Link Layer Discover Protocol (IEEE 802.1ab) Overview</u> on page 67. This section covers the following commands:

- Ildp command on page 169
- <u>Ildp port command</u> on page 170
- Ildp tx-tlv command on page 170
- Ildp tx-tlv dot1 command on page 171
- Ildp tx-tlv dot3 command on page 172
- Ildp tx-tlv med command on page 173
- IIdp location-identification coordinate-base command on page 173
- Ildp location-identification civic-address command on page 174
- Ildp location-identification ecs-elin command on page 176
- default IIdp command on page 176
- default IIdp port command on page 177
- default lldp tx-tlv command on page 177
- default lldp tx-tlv dot1 command on page 178

- default IIdp tx-tlv dot3 command on page 179
- default lldp tx-tlv med command on page 180
- no lldp port command on page 180
- no lldp tx-tlv command on page 180
- no Ildp tx-tlv dot1 command on page 181
- no lldp tx-tlv dot3 command on page 181
- no lldp tx-tlv med command on page 181
- show lldp command on page 182
- show lldp port command on page 183
- Configuring LLDP MED policies for switch ports on page 184
- Setting Ildp med-network-policies to the default values on page 185
- Disabling LLDP MED policies for switch ports on page 186
- Viewing Ildp med-network-policies on page 186
- Configuring LLDP on page 187

Ildp command

Use this procedure to set the LLDP transmission parameters.

Procedure steps

Use the following command from Global Configuration mode:

```
lldp [tx-interval <5-32768>] [tx-hold-multiplier <2-10>]
[reinit-delay <1-10>] [tx-delay <1-8192>] [notification-
interval <5-3600>] [med-fast-start <1-10>]
```

Variable definitions

The following table outlines the parameters of the 11dp command.

Table 76: Ildp command parameters

Variable	Value
tx-interval <5-32768>	sets the interval between successive transmission cycles
tx-hold- multiplier <2-10>	sets the multiplier for the tx-interval used to compute the Time To Live value for the TTL TLV

Variable	Value
reinit-delay <1-10>	sets the delay for the reinitialization attempt if the adminStatus is disabled
tx-delay <1-8192>	sets the minimum delay between successive LLDP frame transmissions
notification- interval <5-3600>	sets the interval between successive transmissions of LLDP notifications
med-fast-start <1-10>	sets the MED Fast Start repeat count value

lldp port command

Use this procedure to set the LLDP port parameters.

Procedure steps

Use the following command from Interface Configuration mode:

```
lldp port <portlist> [config notification] [status {rxOnly |
txAndRx | txOnly}]
```

Variable definitions

The following table outlines the parameters of the 11dp port command.

Table 77: Ildp port command parameters

Variable	Value
port <portlist></portlist>	specifies the ports affected by the command
config notification	enables notification when new neighbor information is stored or when existing information is removed
status {rxOnly txAndRx txOnly}	sets the LLDPU transmit and receive status on the ports rxonly: enables LLDPU receive only. txAndRx: enables LLDPU transmit and receive. txOnly: enables LLDPU transmit only.

lldp tx-tlv command

Use this procedure to set the optional Management TLVs to be included in the transmitted LLDPDUs.

Procedure steps

Use the following command from Interface Configuration mode:

```
lldp tx-tlv [port <portlist>] [local-mgmt-addr] [port-desc]
[sys-cap] [sys-desc] [sys-name]
```

Variable definitions

The following table outlines the parameters of the lldp tx-tlv command.

Table 78: IIdp tx-tlv command variables

Variables	Value
local-mgmt-addr	Specifies the local management address TLV.
port <portlist></portlist>	Specifies the ports affected by the command.
port-desc	Specifies the port description TLV.
sys-cap	Specifies the system capabilities TLV.
sys-desc	Specifies the system description TLV.
sys-name	Specifies the system name TLV.

IIdp tx-tlv dot1 command

Use this procedure to set the optional IEEE 802.1 organizationally-specifc TLVs to be included in the transmitted LLDPDUs.

Procedure steps

Use the following command from Interface Configuration mode:

```
lldp tx-tlv [port <portlist>] dot1 [port-protocol-vlan-id
<vlanlist>] [port-vlan-id] {protocol-identity [EAP] [LLDP]
[STP] [vlan-name <vlanlist>]
```

Variable definitions

The following table outlines the parameters of the lldp tx-tlv dot1 command.

Table 79: Ildp tx-tlv dot1 command parameters

Variable	Value
port <portlist></portlist>	specifies the ports affected by the command

Variable	Value
port-vlan-id	Port VLAN ID TLV
vlan-name	VLAN Name TLV
port-protocol- vlan-id	Port and Protocol VLAN ID TLV
protocol-identity [EAP] [LLDP] [STP]	Protocol Identity TLV

IIdp tx-tlv dot3 command

Use this procedure to set the optional IEEE 802.3 organizationally-specifc TLVs to be included in the transmitted LLDPDUs.

Procedure steps

Use the following command from Interface Configuration mode:

lldp tx-tlv [port <portlist>] dot3 [link-aggregation] [mac-phyconfig-status] [maximum-frame-size] [mdi-power-support]

Variable definitions

The following table outlines the parameters of the 11dp tx-tlv dot3 command.

Table 80: Ildp tx-tlv dot3 command parameters

Variable	Value
port <portlist></portlist>	specifies the ports affected by the command
mac-phy-config- status	MAC/Phy Configuration/Status TLV
mdi-power-support	Power Via MDI TLV
link-aggregation	Link Aggregation TLV
maximum-frame- size	Maximum Frame Size TLV

IIdp tx-tlv med command

Use this procedure to set the optional organizationally-specific TLVs for use by MED devices to be included in the transmitted LLDPDUs.

Procedure steps

Use the following command from Interface Configuration mode:

```
lldp tx-tlv [port <portlist>] med [extendedPSE] [inventory]
[location] [med-capabilities] [network-policy]
```

Variable definitions

The following table outlines the parameters of the 11dp tx-tlv med command.

Table 81: IIdp tx-tlv med command parameters

Variable	Value
port <portlist></portlist>	specifies the ports affected by the command
med-capabilities	MED Capabilities TLV (MED TLVs are transmitted only if MED Capabilities TLVs are transmitted)
extendedPSE	Extended PSE TLV
inventory	Inventory TLVs
location	Location Identification TLV
network-policy	Network Policy TLV

Ildp location-identification coordinate-base command

Use this procedure to set the coordinate-base parameters for LLDP location identification information.

Procedure steps

Use the following command from Interface Configuration mode:

lldp location-identification coordinate-base [altitude] [datum]
[latitude] [longitude]

Variable definitions

The following table outlines the parameters of the lldp location-identification coordinate-base command.

Table 82: IIdp location-identification coordinate-base command parameters

Variable	Value
altitude [+ -] [0-4194303.fracti on] [meters floors]	Altitude, in meters or floors.
datum [NAD83/MLLW NAD83/NAVD88	Reference datum The valid options are:
WGS84]	NAD83/MLLW: North American Datum 1983, Mean Lower Low Water
	NAD83/NAVD88: North American Datum 1983, North American Vertical Datum of 1988
	WGS84: World Geodesic System 1984, Prime Meridian Name: Greenwich
latitude [0-90.00] [NORTH SOUTH]	Latitude in degrees, and relative to the equator.
longitude [0-180.00] [EAST WEST]	Longitude in degrees, and relative to the prime meridian.

Ildp location-identification civic-address command

Use this procedure to set the LLDP civic address parameters.

Procedure steps

Use the following command from Interface Configuration mode:

ldp location-identification civic-address country-code
[additional-code] [additional-information] [apartment] [block]
[building] [city] [city-district] [county] [floor] [house-number] [house-number-suffix] [landmark] [leading-street-direction] [name] [p.o.box] [place-type] [postal-community-

name] [postal/zip-code] [room-number] [state] [street] suffix] [trailing-street-suffix]

Variable definitions

The following table outlines the parameters of the lldp location-identification civic-address command.

Table 83: Ildp location-identification civic-address command parameters

Variable	Value
additional-code	Additional code
additional- information	Additional location information
apartment	Unit (apartment, suite)
block	Neighborhood, block
building	Building (structure)
city	City, township, shi (JP)
city-district	City division, city district, ward
country-code	Country code value (2 capital letters)
county	County, parish, gun (JP), district (IN)
floor	Floor
house-number	House number
house-number- suffix	House number suffix
landmark	Landmark or vanity address
leading-street- direction	Leading street direction
name	Residence and office occupant
p.o.box	Post office box
place-type	Office
postal-community- name	Postal community name
postal/zip-code	Postal/Zip code
room-number	Room number

Variable	Value
state	National subdivisions (state, canton, region)
street	Street
street-suffix	Street suffix
trailing-street- suffix	Trailing street suffix

Ildp location-identification ecs-elin command

Use this procedure to set the LLDP emergency call service - emergency location identification number (ECS-ELIN).

Procedure steps

Use the following command from Interface Configuration mode:

lldp location-identification ecs-elin <ecs-elin>



<ecs-elin> specifies a 10 to 25 digit numerical string.

default lldp command

Use this procedure to set the LLDP transmission parameters to their default values.

Procedure steps

Use the following command from Global Configuration mode:

```
default lldp [tx-interval ] [tx-hold-multiplier ] [reinit-
delay] [tx-delay] [notification-interval] [med-fast-start]
```



If no parameters are specified, the default 11dp sets all parameters to their default parameters.

Variable definitions

The following table outlines the parameters of the default lldp command.

Table 84: default lldp command parameters

Variable	Value
tx-interval	sets the retransmit interval to the default value (30)
tx-hold- multiplier	sets the transmission multiplier to the default value (4)
reinit-delay	sets the reinitialize delay to the default value (2)
tx-delay	sets the transmission delay to the default value (2)
notification- interval	sets the notification interval to the default value (5)
med-fast-start	sets the MED Fast Start repeat count value to the default value (4)

default lldp port command

Use this procedure to set the port parameters to their default values.

Procedure steps

Use the following command from Interface Configuration mode:

default lldp port <portlist> [config notification] [status]

Variable definitions

The following table outlines the parameters of the default 11dp port command.

Table 85: default lldp port command parameters

Variable	Value
port <portlist></portlist>	specifies the ports affected by the command
config notification	sets the config notification to its default value (disabled)
status	sets the LLDPU transmit and receive status to the default value (txAndRx)

default lldp tx-tlv command

Use this procedure to set the LLDP Management TLVs to their default values.

Procedure steps

Use the following command from Interface Configuration mode:

```
default lldp tx-tlv [port <portlist>][port-desc] [sys-name]
[sys-desc] [sys-cap] [local-mgmt-addr]
```

Variable definitions

The following table outlines the parameters of the default lldp tx-tlv command.

Table 86: default lldp tx-tlv command parameters

Variable	Value
port <portlist></portlist>	specifies the ports affected by the command
port-desc	Port description TLV (default value is false: not included)
sys-name	System name TLV (default value is false: not included)
sys-desc	System description TLV (default value is false: not included)
sys-cap	System capabilities TLV (default value is false: not included)
local-mgmt-addr	Local management address TLV (default value is false: not included)

default lldp tx-tlv dot1 command

Use this procedure to set the optional IEEE 802.1 organizationally-specifc TLVs to their default values.

Procedure steps

Use the following command from Interface Configuration mode:

```
default lldp tx-tlv [port <portlist>] dot1 [port-vlan-id]
[vlan-name ] [port-protocol-vlan-id] [protocol-identity [EAP]
[LLDP] [STP] ]
```

Variable definitions

The following table outlines the parameters of the default lldp tx-tlv dot1 command.

Table 87: default lldp tx-tlv dot1 command parameters

Variable	Value
port <portlist></portlist>	specifies the ports affected by the command
port-vlan-id	Port VLAN ID TLV (default value is false: not included)
vlan-name	VLAN Name TLV (default value is none)
port-protocol- vlan-id	Port and Protocol VLAN ID TLV (default value is none)
protocol-identity [EAP] [LLDP] [STP]	Protocol Identity TLV (default value is none)

default lldp tx-tlv dot3 command

Use this procedure to set the optional IEEE 802.3 organizationally-specifc TLVs to their default values.

Procedure steps

Use the following command from Interface Configuration mode:

default lldp tx-tlv [port <portlist>] dot3 [mac-phy-configstatus] [mdi-power-support] [link-aggregation][maximum-framesize]

Variable definitions

The following table outlines the parameters of the default 11dp tx-tlv dot3 command.

Table 88: default lldp tx-tlv dot3 command parameters

Variable	Value
port <portlist></portlist>	specifies the ports affected by the command
mac-phy-config- status	MAC/Phy Configuration/Status TLV (default value is false: not included)
mdi-power-support	Power Via MDI TLV (default value is false: not included)
link-aggregation	Link Aggregation TLV (default value is false: not included)
maximum-frame- size	Maximum Frame Size TLV (default value is false: not included)

default lldp tx-tlv med command

Use this procedure to set the optional organizationally-specifc TLVs for MED devices to their default values.

Procedure steps

Use the following command from Interface Configuration mode:

```
default lldp tx-tlv [port <portlist>] med [med-capabilities]
[extendedPSE] [inventory] [location] [network-policy]
```

Variable definitions

The following table outlines the parameters of the default lldp tx-tlv med command.

Table 89: default lldp tx-tlv med command parameters

Variable	Value
port <portlist></portlist>	specifies the ports affected by the command
med-capabilities	MED Capabilities TLV (default value is false: not included)
extendedPSE	Extended PSE TLV (default value is false: not included)
inventory	Inventory TLVs (default value is false: not included)
location	Location Identification TLV (default value is false: not included)
network-policy	Network Policy TLV (default value is false: not included)

no lldp port command

Use this procedure to disable LLDP features on the port.

Procedure steps

Use the following command from Interface Configuration mode:

```
no lldp [port <portlist>] [config notification] [status]
```

no lldp tx-tlv command

Use this procedure to specify the optional Management TLVs not to include in the transmitted LLDPDUs.

Procedure steps

Use the following command from Interface Configuration mode:

```
no lldp tx-tlv [port <portlist>] [port-desc] [sys-name] [sys-
desc] [sys-cap] [local-mgmt-addr]
```

no lldp tx-tlv dot1 command

Use this procedure to specify the optional IEEE 802.1 TLVs not to include in the transmitted LLDPDUs.

Procedure steps

Use the following command from Interface Configuration mode:

```
no lldp tx-tlv [port <portlist>] dot1 [port-vlan-id] [vlan-
name] [port-protocol-vlan-id] [protocol-identity [EAP] [LLDP]
[STP] ]
```

no lldp tx-tlv dot3 command

Use this procedure to specify the optional IEEE 802.3 TLVs not to include in the transmitted LLDPDUs.

Procedure steps

Use the following command from Interface Configuration mode:

```
no lldp tx-tlv [port <portlist>] dot3 [mac-phy-config-status]
[mdi-power-support] [link-aggregation][maximum-frame-size]
```

no lldp tx-tlv med command

Use this procedure to specify the optional Management TLVs not to include in the transmitted LLDPDUs.

Procedure steps

Use the following command from Interface Configuration mode:

```
no lldp tx-tlv [port <portlist>] med [med-capabilities]
[extendedPSE] [inventory] [location] [network-policy]
```

show IIdp command

Use this procedure to display the LLDP parameters.

Procedure steps

Use the following command from User EXEC mode:

```
show lldp [local-sys-data {dot1 | dot3 | med | detail}] [mgmt-
sys-data] [rx-stats] [tx-stats] [stats] [pdu-tlv-size] [tx-tlv
{dot1 | dot3 | med }] [neighbor { dot1 [vlan-names | protocol-
id] } | [dot3] | { med [capabilities] [network-policy]
[location] [extended-power] [inventory] } | [detail] ]
[neighbor-mgmt-addr]
```

Variable definitions

The following table outlines the parameters of the **show 11dp** command.

Table 90: show IIdp command parameters

Variable	Value
	Displays the organizationally-specific TLV properties on the local switch:
	dot1: displays the 802.1 TLV properties
local-sys-data {dot1 dot3	dot3: displays the 802.3 TLV properties
med detail}	med: displays the MED TLV properties
	detail: displays all organizationally specific TLV properties
	To display the properties of the optional management TLVs, include only the local-sys-data parameter in the command.
mgmt-sys-data	Displays the local management system data.
rx-stats	Displays the LLDP receive statistics for the local system.
tx-stats	Displays the LLDP transmit statistics for the local system.
stats	Displays the LLDP table statistics for the remote system.
pdu-tlv-size	Displays the different TLV sizes and the number of TLVs in an LLDPDU.
tx-tlv {dot1 dot3 med }	Displays which TLVs are transmitted from the local switch in LLDPDUs:

Variable	Value
	dot1: displays status for 802.1 TLVs
	dot3: displays status for 802.3 TLVs
	med: displays status for MED TLVs
	To display the transmission status of the optional management TLVs, include only the tx-tlv parameter in the command.
	Displays the neighbor TLVs:
	dot1: displays 802.1 TLVs:
neighbor { dot1	- vlan-names: VLAN Name TLV
[vlan-names	- protocol-id: Protocol Identity TLV
<pre>protocol-id] } [dot3] { med</pre>	dot3: displays 802.3 TLVs
[capabilities]	med: displays MED TLVs:
[network-policy]	- capabilities: Capabilities TLV
[location] [extended-power]	- network-policy: Network Policy Discovery TLV
[inventory] } [detail]	- location: Location Identification TLV
	- extended-power: Extended Power-via-MDI TLV
	- inventory: Inventory TLVs
	detail: displays all TLVs
[neighbor-mgmt-addr]	Displays the LLDP neighbor management address.

show IIdp port command

Use this procedure to display the LLDP port parameters.

Procedure steps

Use the following command from User EXEC mode:

```
show lldp port <portlist> [rx-stats] [tx-stats] [pdu-tlv-size]
[tx-tlv {dot1 | dot3 | med}] [neighbor {dot1 [vlan-names |
protocol-id] } | [dot3] | {med [capabilities] [network-policy]
[location] [extended-power] [inventory]} | [detail] ]}
[neighbor-mgmt-addr]
```

Variable definitions

The following table outlines the parameters of the **show 11dp port** command.

Table 91: show lldp port command parameters

Variable	Value
rx-stats	Displays the LLDP receive statistics for the local port.
tx-stats	Displays the LLDP transmit statistics for the local port.
pdu-tlv-size	Displays the different TLV sizes and the number of TLVs in an LLDPDU.
	Displays which TLVs are transmitted from the local port in LLDPDUs:
	dot1: displays status for 802.1 TLVs
tx-tlv {dot1 dot3 med }	dot3: displays status for 802.3 TLVs
	med: displays status for MED TLVs
	To display the transmission status of the optional management TLVs, include only the tx-tlv parameter in the command.
	Displays the port neighbor TLVs:
	dot1: displays 802.1 TLVs:
neighbor { dot1	- vlan-names: VLAN Name TLV
[vlan-names	- protocol-id: Protocol Identity TLV
<pre>protocol-id] } [dot3] { med</pre>	dot3: displays 802.3 TLVs
[capabilities]	med: displays MED TLVs:
[network-policy]	- capabilities: Capabilities TLV
[location] [extended-power]	- network-policy: Network Policy Discovery TLV
<pre>[inventory] } [detail]</pre>	- location: Location Identification TLV
	- extended-power: Extended Power-via-MDI TLV
	- inventory: Inventory TLVs
	detail: displays all TLVs.
[neighbor-mgmt-addr]	Displays the port neighbor LLDP management address.

Configuring LLDP MED policies for switch ports

Use the following procedure to configure LLDP Media Endpoint Devices (MED) policies.

Procedure steps

Use the following command from the Interface Configuration mode:

lldp med-network-policies [port <portList>] {voice|voicesignaling [dscp <0-63>] [priority <0-7>] [tagging {tagged| untagged) [vlan-id <1-4094>]

Variable definitions

The following table outlines the parameters of the 11dp med-network-policies command.

Table 92: IIdp med-network-policies

Variable	Value
port <portlist></portlist>	Specifies the port or ports on which to configure LLDP MED policies.
voice	Specifies voice network policy.
voice-signaling	Specifies voice signalling network policy.
dscp <0-63>	Specifies the value of the Differentiated Service Code Point (DSCP) as defined in IETF RFC 2474 and RFC 2475 that is associated with the selected switch port or ports. Values range from 0–63.
priority <0-7>	Specifies the value of the 802.1p priority that applies to the selected switch port or ports. Values range from 0–7.
	Specifies the type of VLAN tagging to apply on the selected switch port or ports.
	tagged—uses a tagged VLAN
tagging {tagged untagged}	untagged—uses an untagged VLAN or does not support port-based VLANs.
	If you select untagged, the system ignores the VLAN ID and priority values, and recognizes only the DSCP value.
vlan-id <1-4094>	Specifies the VLAN identifier for the selected port or ports. Values range from 1–4094. If you select priority tagged frames, the system recognizes only the 802.1p priority level and uses a value of 0 for the VLAN ID of the ingress port.

Setting IIdp med-network-policies to the default values

Use this procedure to return IIdp med-network-policies to the default values.

Procedure steps

Use the following command from the Interface Configuration mode:

default lldp med-network-policies [port <portList>] {voice|
voice-signaling}

Variable definitions

The following table outlines the parameters of the default lldp med-network-policies command.

Table 93: default IIdp med-network-policies parameters

Variable	Value
port <portlist></portlist>	Specifies the port or ports on which to configure default LLDP MED policies.
voice	Specifies the default voice network policy.
voice-signaling	Specifies the default voice signalling network policy.

Disabling LLDP MED policies for switch ports

Use this procedure to disable LLDP MED policies for switch ports.

Procedure steps

Use the following command from the Interface Configuration mode:

no lldp med-network-policies [port <portlist>] {voice|voicesignaling}

Variable definitions

The following table outlines the parameters of the no lldp med-network-policies command.

Table 94: no IIdp med-network-policies parameters

Variable	Value
port <portlist></portlist>	Specifies the port or ports on which to disable LLDP MED policies.
voice	Specifies the voice network policy to disable.
voice-signaling	Specifies the voice signalling network policy to disable.

Viewing IIdp med-network-policies

Use this procedure to display LLDP MED policy information for switch ports.

Procedure steps

Use the following command from the Privileged EXEC mode:

show lldp med-network-policies [port <portlist>] {voice|voicesignaling }

Variable definitions

The following table outlines the parameters of the show 11dp med-network-policies command.

Table 95: show IIdp med-network-policies parameters

Variable	Value
port <portlist></portlist>	Specifies the port or ports for which to display LLDP MED policy information.
voice	Displays the voice network policy for which to display information.
voice-signaling	Specifies the voice signalling network policy to disable.

Configuring LLDP

Use this procedure to configure the LLDP as shown in LLDP configuration example on page 189.

Important:

If a switch is reset while energy-saver is activated, the PoE power saving calculation may not accurately reflect the power saving, and in some cases may display zero savings. This is because the switch did not have sufficient time to record PoE usage between the reset of the switch and energy-saver being reactivated. When energy saver is next activated, the PoE power saving calculation will be correctly updated.

Procedure steps

1. Modify the default LLDP Tx interval from (the default 30 second value) to 60 seconds.

Notice that if any modification is detected in the LLDP local-sys-data before the Tx interval expires, an LLDPDU is immediately sent on all active links in order to update the peers neighbor tables.

- 2. Enable the Port Description TLV for transmission. (contains the description of the LLPD sending port)
- 3. Enable the System Name TLV for transmission. (contains the name of the LLDP device)

- 4. Enable the System Description TLV for transmission. (contains the description of the LLDP device)
- 5. Enable the System Capabilities TLV for transmission. (contains the capabilities of the LLDP device)
- 6. Enable the Management Address TLV for transmission. (contains the management address of the LLDP device)
- 7. Enable the Port VLAN ID TLV for transmission. (contains the PVID of the LLDP sending port)
- 8. Enable the Port And Protocol VLAN ID TLV for transmission. (indicates the Port and Protocol VLANs to which the LLDP sending port belongs to).
- 9. Enable the VLAN Name TLV for transmission. (indicates the names of the VLANs to which the LLDP sending port belongs to)
- 10. Enable the Protocol Identity TLV for transmission. (indicates the supported protocols by the LLDP sending port)
- 11. Enable the MAC/PHY Configuration/Status TLV for transmission. (indicates the IEEE 802.3 duplex and bitrate capabilities and settings of the LLDP sending port)
- 12. Enable the Power Via MDI TLV for transmission. (indicates the MDI power support capabilities of the LLDP sending port)
- 13. Enable the Link Aggregation TLV for transmission. (indicates the link aggregation capability and status of the LLDP sending port)
- 14. Enable the Maximum Frame Size TLV for transmission. (indicates the maximum frame size that could be handled by the LLDP sending port)
- 15. Configure the location information for the LLDP-MED Location Identification TLV.

 There are three coordinate sets available for location advertisement.
- Enable the LLDP-MED Capabilities TLV for transmission. (indicates the supported LLDP-MED TLVs and the LLDP-MED device type of the LLDP sending device)
 - MED TLVs are transmitted only if MED-Capabilities TLV is transmitted
- 17. Enable the Network Policy TLV for transmission. (advertises the available MED applications available on the LLDP sending device and the policies required to use the applications)
- 18. Enable the Location Identification TLV for transmission. (indicates the physical location of the LLDP sending port; three coordinate sets are available to configure and send)
- 19. Enable the Extended Power-via-MDI TLV for transmission. (provides detailed informations regarding the PoE parameters of the LLDP sending device)
- 20. Enable the Inventory Hardware Revision TLV for transmission. (indicates the hardware revision of the LLDP sending device)
- 21. Enable the Inventory Firmware Revision TLV for transmission. (indicates the firmware revision of the LLDP sending device)
- 22. Enable the Inventory Software Revision TLV for transmission. (indicates the software revision of the LLDP sending device)

- 23. Enable the Inventory Serial Number TLV for transmission. (indicates the serial number of the LLDP sending device)
- 24. Enable the Inventory Manufacturer Name TLV for transmission. (indicates the manufacturer name of the LLDP sending device)
- 25. Enable the Inventory Model Name TLV for transmission. (indicates the model name of the LLDP sending device)

☑ Note:

The switch only transmits LLDP MED information if the neighbor is a MED-capable unit.

LLDP configuration example

By default, LLDP is enabled for Tx and Rx on all switch ports. The default value for the LLDP Tx interval is 30 seconds (LLDPDUs are sent at 30 seconds). With the default settings, only the mandatory TLVs are sent, but the switch can receive any LLDP Core, DOT1, DOT3 or MED TLV from its peers.

shows an example of LLDP configuration. For this example, the router is connected to the ERS 5000 Series port 1 and the IP Phone uses port 13.




Figure 25: LLDP configuration example

Detailed configuration commands

The following section describes the detailed ACLI commands required to carry out the configuration depicted in <u>Figure 25: LLDP configuration example</u> on page 189.

Navigation:

- Modifying the default LLDP Tx interval on page 190
- Checking the new LLDP global settings on page 190
- Enabling all LLDP Core TLVs for transmission on the router and IP Phone ports on page 191
- Checking the LLDP settings of the router and IP Phone ports on page 191
- Enabling all LLDP DOT1 TLVs for transmission on the router and IP Phone ports on page 192
- Checking the LLDP settings of the router and IP Phone ports on page 192
- Enabling all LLDP DOT3 TLVs for transmission on the router and IP Phone ports on page 193
- Checking the LLDP settings of the router and IP Phone ports on page 193
- Enabling all LLDP MED TLVs for transmission on the router and IP Phone ports on page 193
- Checking the new LLDP settings of the router and IP Phone ports on page 194

Modifying the default LLDP Tx interval

Use this procedure to modify the default LLDP Tx interval.

Procedure steps

Use the following command from Global Configuration mode:

lldp tx-interval 60

Checking the new LLDP global settings

Use this procedure to show LLDP global settings.

Procedure steps

Use the following command from Global Configuration mode:

show lldp

Job aid

The following job aid shows the output for the **show 11dp** command.

5520-24T-PWR(config)#show lldp

TxInterval:60 TxHoldMultiplier:4 RxInitDelay:2

TxDelay:2

NotificationInterval:5 MedFastStartRepeatCount:4

Enabling all LLDP Core TLVs for transmission on the router and IP Phone ports

Use this procedure to enable all LLDP Core TLVs for transmission on the route and IP Phone ports.

Procedure steps

Use the following command from Global Configuration mode:

```
interface fastEthernet 1,13
lldp tx-tlv port 1,13 port-desc
lldp tx-tlv port 1,13 sys-name
lldp tx-tlv port 1,13 sys-desc
lldp tx-tlv port 1,13 sys-cap
lldp tx-tlv port 1,13 local-mgmt-addr
```

Checking the LLDP settings of the router and IP Phone ports

Use this procedure to check the LLDP settings of the router and IP Phone ports.

Procedure steps

Use the following command from Interface Configuration mode:

```
show lldp port 1,13 tx-tlv
```

Job aid

The following job aid shows the output for the show 11dp port 1,13 tx-tlv command.

5520-24T-PWR(config-if)#show lldp port 1,13 tx-tlv

```
Port PortDesc SysName SysDesc SysCap MgmtAddr
1 true true true true true 13 true true true true true
```

Enabling all LLDP DOT1 TLVs for transmission on the router and IP Phone ports

Use this procedure to enable all LLDP DOT1 TLVs for transmission on the router and IP Phone ports.

Procedure steps

Use the following command from Interface Configuration mode:

```
11dp tx-tlv port 1,13 dot1 port-vlan-id
11dp tx-tlv port 1,13 dot1 port-protocol-vlan-id
11dp tx-tlv port 1,13 dot1 vlan-name
11dp tx-tlv port 1,13 dot1 protocol-identity EAP
LLDP STP
```

Checking the LLDP settings of the router and IP Phone ports

Use this procedure to check the LLDP setting of the router and IP Phone ports.

Procedure steps

Use the following command from Interface Configuration mode:

```
show lldp port 1,13 tx-tlv dot1
```

Job aid

The following job aid shows the output for the show lldp port 1,13 tx-tlv dot1 command.

5520-24T-PWR(config-if)#show lldp port 1,13 tx-tlv dot1

```
lldp port dot1 tlvs

Dot1 protocols: STP,EAP,LLDP

Port PortVlanId VlanNameList PortProtocolVlanId ProtocolIdentity

true 1 1 ALL

13 true 1 1 ALL
```

Enabling all LLDP DOT3 TLVs for transmission on the router and IP Phone ports

Use this procedure to enable all LLDP DOT3 TLVs for transmission on the router and IP Phone ports.

Procedure steps

Use the following command from Interface Configuration mode:

```
lldp tx-tlv port 1,13 dot3 mac-phy-config-status
lldp tx-tlv port 1,13 dot3 mdi-power-support
lldp tx-tlv port 1,13 dot3 link-aggregation
lldp tx-tlv port 1,13 dot3 maximum-frame-size
```

Checking the LLDP settings of the router and IP Phone ports

Use this procedure to check the LLDP settings of the router and IP Phone ports.

Procedure steps

Use the following command from Interface Configuration mode:

```
show lldp port 1,13 tx-tlv dot3
```

Job aid

The following job aid shows the output for the show 11dp port 1,13 tx-tlv dot3 command.

5520-24T-PWR(config-if)#show lldp port 1,13 tx-tlv dot3

```
lldp port dot3 tlvs
Port MacPhy MdiPower Link
Aggregation
                               MaxFrameSize ConfigStatus Support
1 true true true true 13 true true true true
```

Enabling all LLDP MED TLVs for transmission on the router and IP Phone ports

Use this procedure to enable all LLDP MED TLVs for transmission on the router and IP Phone ports.

☑ Note:

The first three commands are required to configure the location identification for the LLDP-MED Location Identification TLV.

Procedure steps

Use the following command from Interface Configuration mode:

```
11dp location-identification civic-address country-code US city
Boston
lldp location-identification coordinate-base altitude 3 floors
lldp location-identification ecs-elin 1234567890
lldp tx-tlv med port 1,13 med-capabilities
lldp tx-tlv med port 1,13 network-policy
lldp tx-tlv med port 1,13 location
lldp tx-tlv med port 1,13 extendedPSE
lldp tx-tlv med port 1,13 inventory
```

Checking the new LLDP settings of the router and IP Phone ports

Use this procedure to check the new LLDP settings of the router and IP Phone ports.

Procedure steps

Use the following command from Interface Configuration mode:

```
show lldp tx-tlv med
```

Job aid

The following job aid shows the output of the show lldp tx-tlv med command.

5530-24TFD(config-if)#show lldp tx-tlv med

```
lldp port med tlvs
Port Med Network Location Extended Inventory Capabilities
         PSE
```

Configuring PoE detection method with ACLI

Configuring PoE with ACLI

The following section details the commands necessary to configure PoE with ACLI:

- <u>Set port power enable or disable</u> on page 195
- Set port power priority on page 196
- Set power limit for channels on page 196
- Set traps control on page 197
- Show main power status on page 197
- Set power usage threshold on page 197
- Setting PoE detection method on page 198
- Show port power status on page 198
- Show port power measurement on page 198

Set port power enable or disable

Use this procedure to disable Power Over Ethernet to a port.

Procedure steps

Use the following command from Interface Configuration mode:

```
poe poe-shutdown [port <portlist>]
```

Use this procedure to enable Power Over Ethernet to a port.

Procedure steps

Use the following command from Interface Configuration mode:

```
no poe poe-shutdown [port <portlist>]
```

■ Note:

In either command, substitute <portlist> with the ports on which PoE is enabled or disabled.

Set port power priority

Use this procedure to set the port power priority.

Procedure steps

Use the following command from Interface Configuration mode:

```
poe poe-priority [port <portlist>] {critical | high | low}
```

Variable definitions

The following table outlines the parameters of the poe-priority command.

Table 96: poe-priority command parameters

Variable	Value
port <portlist></portlist>	The ports to set priority for.
{low high critical}	The PoE priority for the port.

Set power limit for channels

Use this procedure to set the power limit for channels.

Procedure steps

Use the following command from Interface Configuration mode:

```
poe poe-limit [port <portlist>] <3-16>
```

Variable definitions

The following table outlines the parameters of the poe-limit command.

Table 97: poe-limit command parameters

Variable	Value
port <portlist></portlist>	The ports to set the limit on.
<3 - 16>	The power range to limit at from 3 to 16 Watts.

Comments? infodev @avaya.com

Set traps control

Use this procedure to enable PoE-related traps for PoE-enabled ports.

Procedure steps

Use the following command from Interface Configuration mode:

```
poe poe-trap [unit <1-8>]
```

☑ Note:

Substitute <1-8> with the number of the unit on which to enable traps.

Show main power status

Use this procedure to display the power configuration.

Procedure steps

Use the following command from Privileged EXEC mode:

```
show poe-main-status [unit <1-8>]
```

■ Note:

Substitute <1-8> with the number of the unit for which to display the configuration.

Set power usage threshold

Use this procedure to set the power usage threshold in percentage on individual units.

Procedure steps

Use the following command from Global Configuration mode:

```
poe poe-power-usage-threshold [unit <1-8>] <1-99>
```

Variable definitions

The following table outlines the parameters of the poe-power-usage-threshold command.

Table 98: poe-power-usage-threshold command parameters

Variable	Value
unit <1 - 8>	The unit for which to set the power threshold.
<1 - 99>	199 percent

Setting PoE detection method

Use this procedure to enable either 802.3af or Legacy compliant PD detection methods.

Procedure steps

Use the following command from Global Configuration mode:

```
poe poe-pd-detect-type [unit <1-8>] {802dot3af |
802dot3af and legacy}
```

Show port power status

Use this procedure to display the power configuration.

Procedure steps

Use the following command from Global Configuration mode:

```
show poe-port-status [<portlist>]
```

☑ Note:

Substitute <portlist> with the ports for which to display configuration.

Show port power measurement

Use this procedure to display the configuration.

Procedure steps

Use the following command from Global Configuration mode:

```
show poe-power-measurement [<portlist>]
```

Note:

Substitute <portlist> with the ports for which to display configuration.

Customizing ACLI banner with ACLI

The following sections show the commands used to customize the ACLI banner.

Navigation:

- show banner command on page 199
- banner command on page 199
- no banner command on page 200

show banner command

Use this procedure to display the banner.

Procedure steps

Use the following command from Privileged EXEC mode:

show banner [static | custom]

Variable definitions

The following table outlines the parameters of the **show banner** command.

Table 99: show banner command parameters

Variable	Value
static custom	Displays which banner is currently set to display:
	• static
	• custom

banner command

Use this procedure to specify the banner displayed at startup.

Procedure steps

Use the following command from Privileged EXEC mode:

```
banner {static | custom} <line number> "<LINE>"
```

Variable definitions

The following table outlines the parameters of the **banner** command.

Table 100: banner command parameters

Variable	Value
static custom	Sets the display banner as:
	• static
	• custom
line number	Enter the banner line number you are setting. The range is 1 to 19.
LINE	Specifies the characters in the line number.

no banner command

Use this procedure to clear all lines of a previously stored custom banner.

Procedure steps

Use the following command from Privileged EXEC mode:

no banner



This command sets the banner type to the default setting (STATIC).

Displaying complete GBIC information

Use this procedure to display complete GBIC information.

Procedure steps

Use the following command in any command mode:

show interfaces gbic-info <port-list>

O Note:

Substitute <port-list> with the GBIC ports for which to display information. If no GBIC is detected, this command does not show any information.

Displaying hardware information

Use this procedure to display hardware information about the status of the switch.

Procedure steps

Use the following command from any command mode:

show system [verbose]

O Note:

The inclusion of the [verbose] option displays additional information about fan status, power status, and switch serial number.

Configuring AUR with ACLI

Use the following commands to configure AUR with ACLI:

- show stack auto-unit-replacement command on page 201
- stack auto-unit-replacement enable command on page 202
- no stack auto-unit-replacement enable command on page 203
- default stack auto-unit-replacement enable command on page 203
- stack auto-unit-replacement config save enable on page 203
- stack auto-unit-replacement config save disable on page 203
- stack auto-unit-replacement config restore unit on page 204
- stack auto-unit-replacement config save unit on page 204

show stack auto-unit-replacement command

Use this procedure to display the current AUR settings.

Procedure steps

Use the following command from any command mode:

show stack auto-unit-replacement

Variable definitions

Table 101: show stack auto-unit-replacement command parameters

Variable	Value
Auto Unit Replacement Auto-	Enable: During a unit replacement, the configuration will be automatically restored to the new unit.
Restore	Disable: During a unit replacement, the configuration will not be restored automatically.
Auto Unit Replacement Auto-	Enable: The current configuration of a non base unit will be automatically saved to the base unit.
Save	Disable: The current configuration of a non base unit will not be automatically saved to the base unit.
Last Configuration- Save Time-Stamp	The system-up time of the non base unit recorded when the non base unit sends configuration to the base unit.
Ready for Replacement	Yes: The current configuration of the non base unit has been saved to the base unit. This unit is currently ready for replacement.
	No: The current configuration of the non base unit is not saved to the base unit. The latest changes of the configuration of the non base unit will be lost if the unit is replaced with a new unit.

For information about configuring AUR with ACLI, see <u>Configuring AUR with ACLI</u> on page 201.

For information about configuring AUR with Enterprise Device Manager, see <u>Configuring AUR</u> on page 229.

stack auto-unit-replacement enable command

Use this procedure to enable AUR on the switch.

Procedure steps

Use the following command from Global Configuration mode:

stack auto-unit-replacement enable

no stack auto-unit-replacement enable command

Use this procedure to disable AUR on the switch.

Procedure steps

Use the following command from Global Configuration mode:

no stack auto-unit-replacement enable

default stack auto-unit-replacement enable command

Use this procedure to restore the default AUR settings.

Procedure steps

Use the following command from Global Configuration mode:

default stack auto-unit-replacement enable

stack auto-unit-replacement config save enable

Use this procedure to enable automatic configuration saves for non-base units.

Procedure steps

Use the following command from Global Configuration mode:

stack auto-unit-replacement config save enable

stack auto-unit-replacement config save disable

Use this procedure to disable automatic configuration saves for non-base units.

Procedure steps

Use the following command from Global Configuration mode:

stack auto-unit-replacement config save disable

stack auto-unit-replacement config restore unit

Use this procedure to restore the saved configuration to a non-base unit. Use the base unit console in Privileged Mode to enter this command.

Procedure steps

Use the following command from Privileged EXEC mode:

stack auto-unit-replacement config restore unit <1-8>

stack auto-unit-replacement config save unit

Use this procedure to save the configuration of the selected non-base unit to the base unit, regardless of the state of the AUR feature.

Use the following command from Privileged EXEC mode:

stack auto-unit-replacement config save unit <1-8>

Agent Auto Unit Replacement (AAUR)

Use the following commands to configure and use AAUR.

Navigation:

- stack auto-unit-replacement-image enable command on page 204
- no stack auto-unit-replacement-image-enable command on page 205
- default stack auto-unit-replacement-image enable command on page 205
- show stack auto-unit-replacement-image command on page 205

stack auto-unit-replacement-image enable command

Use this procedure to enable AAUR.

Procedure steps

Use the following command from Global Configuration mode:

stack auto-unit-replacement-image enable

■ Note:

AAUR is enabled by default; this command is only used if this functionality was previously disabled.

no stack auto-unit-replacement-image-enable command

Use this procedure to disable AAUR.

Procedure steps

Use the following command from Global Configuration mode:

no stack auto-unit-replacement-image enable

■ Note:

AAUR is enabled by default,; this command must be executed if the AAUR functionality is not desired on a switch.

default stack auto-unit-replacement-image enable command

Use this procedure to set the AAUR functionality to the factory default of enabled.

Procedure steps

Use the following command from Global Configuration mode:

default stack auto-unit-replacement-image enable

show stack auto-unit-replacement-image command

Use this procedure to view the current status of the AAUR fuctionality.

Procedure steps

Use the following command from User EXEC mode:

show stack auto-unit-replacement-image

Enabling Autosave

With autosave enabled the system checks every minute to see if there is any new configuration data. If there is, it will automatically be saved to NVRAM. While autosave is enabled, the AUR feature should perform normally.

Use the following command to enable the autosave feature.

autosave enable command

Use this procedure to enable the autosave feature.

Procedure steps

Use the following command from Global Configuration mode:

autosave enable

Disabling Autosave

With autosave disabled, the unit will not save the new configuration data to NVRAM. The user can restore via AUR all the configuration data that is configured before the feature is disabled. The user can also restore via AUR all the configuration data that is configured before ACLI command copy config nvram is executed.

When resetting a stack with autosave disabled the stack will form with the configuration from NVRAM of each unit in the stack. The original configuration of a unit should be restored if the user replaces that unit in the stack without having to use the copy config nvram command.

no autosave enable command

Use this procedure to disable the autosave feature.

Procedure steps

Use the following command from Global Configuration mode:

206 Configuration — System October 2012

no autosave enable

Setting Stack Forced Mode

This section describes the procedures and commands to configure Stack Forced Mode on a two unit stack.

Use ACLI Global Configuration command mode to configure Stack Forced Mode.

This section contains the procedures to configure stack forced-mode.

Configuring stack forced-mode

Use this procedure to configure stack forced-mode.:

Procedure steps

Use the following command from Global Configuration mode:

<no | default | show>

Variable definitions

The following table outlines the parameters for the stack forced-mode command.

Table 102: stack forced-mode command parameters

Variable	Value
<>	Enable Stack Forced Mode.
no	Disable Stack Forced Mode.
default	Return to the default setting for Stack Forced Mode.
show	Show Stack Forced Mode status for the switch. The following list shows the possible responses:
	• Forced-Stack Mode: Enabled Device is not currently running in forced Stack Mode.
	• Forced-Stack Mode: Enabled Device is currently running in forced Stack Mode.
	• Forced-Stack Mode: Disabled Device is not currently running in forced Stack Mode.

Enabling feature license files

With the following commands, you can copy the software license file to your switch and display or clear the existing license information:

- copy tftp license command on page 208
- show license command on page 209
- clear license command on page 209

copy tftp license command

Use this procedure to copy the features software license file from a TFTP server to your switch.

Procedure steps

Use the following command from Privileged EXEC mode:

copy tftp license < A.B.C.D > < WORD >

After you copy the license to the switch, you must perform a reboot to activate the license.

With the copy tftp license <A.B.C.D.> <WORD> command, you can copy the features software license file from a TFTP server to your switch.

Note:

The software license is copied to NVRAM. If you reset the switch to default, this removes the software license from the switch. In this case, you must recopy the license file to the switch and reboot to reactivate the licensed features.

Variable definitions

The following table outlines the parameters of the copy tftp license command.

Table 103: copy tftp license command parameters

Variable	Value
<a.b.c.d></a.b.c.d>	The TFTP server address.
<word></word>	The software license filename on the TFTP server.

October 2012 208 Configuration — System

show license command

Use this procedure to display the existing software licenses on your switch.

Procedure steps

Use the following command from Privileged EXEC mode:

```
show license { <1-10> | all }
```

clear license command

Use this procedure to delete the existing software licenses on your switch.

Procedure steps

Use the following command from Privileged EXEC mode:

```
clear license { <1-10> | all }
```

Setting user access limitations

The following sections show the commands for setting user access limitations.

Navigation:

- Setting the read-only and read-write passwords on page 209
- Enabling and disabling passwords on page 210
- Configuring RADIUS authentication on page 211
- Related RADIUS Commands on page 212

Setting the read-only and read-write passwords

The first step to requiring password authentication when the user logs in to the switch is to edit the password settings...

Use this procedure to se the read-only and read-write passwords.

Procedure steps

Use the following command from Privileged EXEC mode:

```
cli password {read-only | read-write} <password>
```

Variable definitions

The following table outlines the parameters of the cli password command.

Table 104: cli password command parameters

Variable	Value
{read-only read-write}	This parameter specifies if the password change is for read-only access or read-write access.
<password></password>	If password security is disabled, the length can be 1-15 chars. If password security is enabled, the range for length is 10-15 chars.

Enabling and disabling passwords

After the read-only and read-write passwords are set, they can be individually enabled or disabled for the various switch access methods. When enabled, password security prompts you for a password and the value is hidden.

Use this procedure to enable or disable passwords.

Procedure steps

Use the following command from Privileged EXEC mode:

```
cli password {telnet | serial} {none | local | radius | tacacs}
```

Variable definitions

The following table outlines the parameters of the cli password command.

Table 105: cli password command parameters

Variable	Value
{telnet serial}	This parameter specifies if the password is enabled or disabled for telnet or the console.
<pre>{none local radius tacacs}</pre>	This parameter specifies if the password is to be disabled (none), or if the password to be used is the locally stored password created in <u>Setting the read-only and read-write passwords</u> on page 209, or if RADIUS authentication or TACACS +AAA services is used.

Configuring RADIUS authentication

The Remote Authentication Dial-In User Service (RADIUS) protocol is a means to authenticate users through the use of a dedicated network resource. This network resource contains a listing of eligible user names and passwords and their associated access rights. When RADIUS is used to authenticate access to a switch, the user supplies a user name and, when prompted, a password. The password value is hidden when entered. This information is checked against the preexisting list. If the user credentials are valid they can access the switch.

If RADIUS Authentication was selected when enabling passwords through ACLI, the RADIUS server settings must be specified to complete the process.

Use this procedure to enable RADIUS athentication.

Procedure steps

Use the following command from Global Configuration mode:

radius-server host <address> [secondary-host <address>] port
<num> key <string> [password fallback]

Variable definitions

The following table outlines the parameters of the radius-server command.

Table 106: radius-server command parameters

Variable	Value
host <address></address>	This parameter is the IPv6 or IPv4 address of the RADIUS server that is used for authentication.
[secondary-host <address>]</address>	The secondary-host <address> parameter is optional. If a backup RADIUS server is to be specified, include this parameter with the IPv6 or IPv4 address of the backup server.</address>
port <num></num>	This parameter is the UDP port number the RADIUS server uses to listen for requests.
key	This parameter prompts you to supply a secret text string or password that is shared between the switch and the RADIUS server. Enter the secret string, which is a string up to 16 characters in length. The password is hidden when entered.
[password fallback]	This parameter is optional and enables the password fallback feature on the RADIUS server. This option is disabled by default.

Related RADIUS Commands

During the process of configuring RADIUS authentication, there are three other ACLI commands that can be useful to the process. These commands are:

- show radius-server —The command takes no parameters and displays the current RADIUS server configuration.
- no radius-server—This command takes no parameters and clears any previously configured RADIUS server settings.
- radius-server password fallback—This command takes no parameters and enables the password fallback RADIUS option if it was not done when the RADIUS server was configured initially.

Configuring serial console port and USB host port

You can enable or disable the serial console and USB host ports to control access to an operational switch. Disabling the USB or serial console ports can prevent unauthorized access and configuration. Both the serial console and USB host ports are enabled by default. ACLI and ACG are used to enable and disable the serial console and USB host ports. ACG support allows users to save the current settings as text files using ACLI commands.

While disabled, the USB host port does not provide power to attached USB devices. No operation which uses the USB host port will be able to complete.

While disabling a console port, the current session ends. While it is disabled and the device is rebooted, the banner is no longer displayed. After enabling the port the user will see the login banner.

If the show running config command is running while disabling the serial console port, the execution is aborted.

The following ACLI commands are used to enable and disable the serial console port and the **USB** host port:

Navigation:

- serial-console command on page 213
- no serial-console command on page 213
- default serial-console command on page 214
- show serial-console command on page 214
- usb-host-port command on page 214
- no usb-host-port command on page 215

Configuration — System October 2012

- default usb-host-port command on page 215
- show usb-host-port on page 216

serial-console command

Use this procedure to enable serial console ports to grant users console access.

Procedure steps

Use the following command from Global Configuration mode:

```
serial-console [unit <1-8>] [enable]
```

Variable definitions

The following table outlines the parameters of the serial-console command.

Table 107: serial-console command parameters

Variable	Value
[unit <1-8>]	Identifies the unit number in a stack. Values range from 1 to 8.

no serial-console command

Use this procedure to disable the serial console port to deny users console access.

Procedure steps

Use the following command from Global Configuration mode:

```
no serial-console [unit <1-8>] [enable]
```

Variable definitions

The following table outlines the parameters of the no serial-console command.

Table 108: no serial-console command parameters

Variable	Value
[unit <1-8>]	Identifies the unit number in a stack. Values range from 1 to 8.

default serial-console command

Use this procedure to reset the serial console port to its default setting of enabled.

Procedure steps

Use the following command from Global Configuration mode:

default serial-console [unit <1-8>] [enable]

Variable definitions

The following table outlines the parameters of the default serial-console command.

Table 109: default serial-console command parameters

Variable	Value
[unit <1-8>]	Identifies the unit number in a stack. Values range from 1 to 8.

show serial-console command

Use this procedure to display the operational status of the serial console ports on all switches.

Procedure steps

Use the following command from Privileged EXEC mode:

show serial-console command [unit <1-8>]

Variable definitions

The following table outlines the parameters of the show serial-console command.

Table 110: show serial-console command parameters

Variable	Value
[unit <1-8>]	Identifies the unit number in a stack. Values range from 1 to 8.

usb-host-port command

Use this procedure to enable USB ports to grant users console access.

Procedure steps

Use the following command from Global Configuration mode:

```
usb-host-port [unit <1-8>] [enable]
```

Variable definitions

The following table outlines the parameters of the usb-host-port command.

Table 111: usb-host-port command parameters

Variable	Value
[unit <1-8>]	Identifies the unit number in a stack. Values range from 1 to 8.

no usb-host-port command

Use this procedure to disable the USB host port to deny users console access.

Procedure steps

Use the following command from Global Configuration mode:

Variable definitions

The following table outlines the parameters of the no usb-host-port command.

Table 112: no usb-host-port command parameters

Variable	Value
[unit <1-8>]	Identifies the unit number in a stack. Values range from 1 to 8.

default usb-host-port command

Use this procedure to reset the USB host port to its default setting of enabled.

Procedure steps

Use the following command from Global Configuration mode:

```
default usb-host-port [unit <1-8>] [enable]
```

Variable definitions

The following table outlines the parameters of the default usb-host-port command.

Table 113: default usb-host-port command parameters

Variable	Value
[unit <1-8>]	Identifies the unit number in a stack. Values range from 1 to 8.

show usb-host-port

Use this procedure to display the operational status of the USB ports on all switches.

Procedure steps

Use the following command from Global Configuration mode:

show usb-host-port

Restoring factory default

Use this procedure to reset the switch or stack back to its default configuration.

Procedure steps

Use the following command from Global Configuration mode:

• the [-y] parameter instructs the switch not to prompt for confirmation.

Chapter 7: System configuration with Enterprise Device Manager

This section contains information about the following topics:

- Configuring Quick Start using EDM on page 218
- Configuring remote access using EDM on page 218
- Configuring the IPv4 remote access list using EDM on page 219
- Configuring the IPv6 remote access list using EDM on page 220
- Viewing PoE ports with Enterprise Device Manager on page 221
- General Switch Administration with Enterprise Device Manager on page 222
- Avaya Energy Saver configuration using Enterprise Device Manager on page 248
- Bridge configuration using Enterprise Device Manager on page 257
- File System configuration using Enterprise Device Manager on page 260
- ADAC Configuration using Enterprise Device Manager on page 271
- <u>Topology configuration using Enterprise Device Manager</u> on page 274
- System Log configuration using Enterprise Device Manager on page 276
- LLDP configuration using Enterprise Device Manager on page 279
- LLDP Port dot1 configuration using Enterprise Device Manager on page 295
- <u>LLDP Port dot3 configuration using Enterprise Device Manager</u> on page 301
- LLDP Port MED configuration using Enterprise Device Manager on page 309
- SNTP configuration using Enterprise Device Manager on page 327
- Power over Ethernet configuration with Enterprise Device Manager on page 332
- IPv6 configuration using Enterprise Device Manager on page 334
- Viewing SFP GBIC ports on page 337

Prerequisites

- Open one of the supported browsers.
- Enter the IP address of the switch to open an EDM session.

Configuring Quick Start using EDM

Perform this procedure to configure Quick Start to enter the setup mode through a single screen.

Procedure steps

- 1. From the navigation tree, double-click **Administration**.
- 2. In the Administration tree, double-click Quick Start.
- 3. In the IP/Community/Vlan work area, type a switch or stack IP address in the **In-Band Stack IP Address** dialog box.
- 4. In the In-Band Stack Subnet Mask dialog box, type a subnet mask.
- 5. In the **Default Gateway** dialog box, type an IP address.
- 6. In the **Read-Only Community String** box, type a character string.
- 7. In the **Re-enter to verify** dialog box immediately following the Read-Only Community String box, retype the character string from Step 6.
- 8. In the **Read-Write Community String** dialog box, type a character string.
- 9. In the **Re-enter to verify** dialog box immediately following the Read-Write Community String: box, retype the character string from Step 8.
- 10. In the Quick Start VLAN dialog box, type a VLAN ID ranging from 1 to 4094.
- 11. Click Apply.

Configuring remote access using EDM

Use this procedure to configure remote access for a switch.

Procedure steps

- 1. From the navigation tree, double-click **Administration**.
- 2. In the Administration tree, double-click **Remote Access** .
- 3. In the work area, click the **Setting** tab.
- 4. In the Telnet Remote Access Setting section, select a value from the **Access** list.
- In the Telnet Remote Access Setting section, select a value from the Use List list.
- 6. In the SNMP Remote Access Setting section, select a value from the Access list.
- 7. In the SNMP Remote Access Setting section, select a value from the **Use List** list.

218 Configuration — System October 2012

- 8. In the Web Page Remote Access Setting section, select a value from the Use List list.
- 9. In the SSH Remote Access Setting section, select a value from the **Access** list.
- 10. In the SSH Remote Access Setting section, select a value from the **Use List** list.
- 11. Click Apply.

Use the data in this table to configure remote access for a switch.

Table 114: Variable definitions

Variable	Value
Telnet Remote Access Setting	Specifies the remote access settings for telnet sessions.
	Access—allows or disallows telnet access to the switch
	Use List—enables (Yes) or disables (No) the use of listed remote Telnet information.
SNMP Remote Access Setting	Specifies SNMP remote access settings.
	Access—allows or disallows SNMP access to the switch
	Use List—enables (Yes) or disables (No) the use of listed remote SNMP information.
Web Page Remote Access Setting	Specifies web page remote access settings.
	Use List—enables (Yes) or disables (No) the use of listed remote web page information.
SSH Remote Access Setting	Specifies SSH remote access settings.
	Access—allows or disallows SSH access to the switch
	Use List—enables (Yes) or disables (No) the use of listed remote SSH information.

Configuring the IPv4 remote access list using EDM

Use this procedure to configure a list of IPv4 source addresses for which to permit remote access to a switch.

Procedure steps

- 1. From the navigation tree, double-click **Administration**.
- 2. In the Administration tree, double-click **Remote Access** .
- 3. In the work area, click the Allowed List(IPv4) tab.
- 4. To select a source to edit, click the source row.
- In the source rowdouble-click the cell in the Allowed Source IP Address column.
- 6. In the dialog box, type a value.
- 7. In the source rowdouble-click the cell in the **Allowed Source Mask** column.
- 8. In the dialog box, type a value.
- 9. Click Apply.

Use the data in this table to configure to configure a list of IPv4 source addresses for which to permit access to the switch.

Table 115: Variable definitions

Variable	Value
Allowed Source IP Address	Specifies the source IPv4 address to permit remote access to the switch.
Allowed Source Mask	Specifies subnet mask associated with the source IPv4 address to permit remote access to the switch.

Configuring the IPv6 remote access list using EDM

Use this procedure to configure a list of IPv6 source addresses for which to permit remote access to a switch.

Procedure steps

- 1. From the navigation tree, double-click **Administration**.
- 2. In the Administration tree, double-click **Remote Access** .
- 3. In the work area, click the **Allowed List(IPv6)** tab.
- 4. To select a source to edit, click the source row.
- 5. In the source rowdouble-click the cell in the **Allowed Source IPv6 Address** column.
- 6. In the dialog box, type a value.
- 7. In the source rowdouble-click the cell in the Allowed Prefix Length column.

220 Configuration — System October 2012

- 8. In the dialog box, type a value.
- 9. Click Apply.

Use the data in this table to configure to configure a list of IPv6 source addresses for which to permit access to the switch .

Table 116: Variable definitions

Variable	Value
Allowed Source IPv6 Address	Specifies the source IPv6 address to permit remote access to the switch.
Allowed Prefix Length	Specifies prefix length for the source IPv6 address to permit remote access to the switch. Values range from 0 to 128.

Viewing PoE ports with Enterprise Device Manager

The Front Panel view of Enterprise Device Manager provides additional information for PoE ports on the Avaya Ethernet Routing Switch 5520. This additional information is provided in the form of a colored "P" that appears inside the graphic representation of the port. This colored "P" represents the current power aspect of the PoE port.

<u>Figure 26: Avaya Ethernet Routing Switch 5520-48T-PWR</u> on page 221 displays an example of the Front Panel view of an Avaya Ethernet Routing Switch 5520-48T-PWR.



Figure 26: Avaya Ethernet Routing Switch 5520-48T-PWR

<u>Table 117: Power Aspect color codes</u> on page 221 explains what the different colors displayed by the power aspect represent.

Table 117: Power Aspect color codes

Color	Description
Green	Indicates that the port is currently delivering power.
Red	Indicates that the power and detection mechanism for the port is disabled.

Color	Description
Orange	Indicates that the power and detection mechanism for the port is enabled. The port is not currently delivering power.
White/Gray	Indicates that the power and detection mechanism for the port is unknown.

Note:

The data and power aspect coloring schemes are independent of each other. The initial status for both data and power aspect for the port can be viewed. To refresh the power status, right-click the unit, and select Refresh PoE Status from the shortcut menu.

For more information about PoE, see the following sections:

- Displaying the PoE tab for a single unit on page 223
- Viewing the PoE power settings on page 238

General Switch Administration with Enterprise Device Manager

This section contains information about the following topics:

- Displaying the Unit dialog box on page 222
- Displaying the Chassis dialog box on page 225
- Displaying the Switch/Stack dialog box on page 230
- Displaying the Ports dialog box on page 234
- Displaying the Environment dialog box on page 246

Displaying the Unit dialog box

The Power over Ethernet (PoE) parameters that apply to the whole switch can be configured and viewed using the Unit screen.

™ Note:

View and edit the PoE parameters for each Avaya Ethernet Routing Switch 5520 one by one. If more than one unit is selected, the PoE power parameters, such as the PoE tab, are not displayed.

To open the Unit dialog box:

Procedure steps

- 1. In the **Device Physical View**, select the unit.
- 2. From the navigation tree, double-click Edit.
- 3. From the Edit tree, double-click Unit.

This sections contains information about the following topics:

- Displaying the Unit tab for a single unit on page 223
- Displaying the PoE tab for a single unit on page 223

Displaying the Unit tab for a single unit

To display the Unit tab for a single unit:

Procedure steps

- 1. In the **Device Physical View**, select the unit.
- 2. From the navigation tree, double-click Edit.
- 3. From the Edit tree, double-click **Unit**.
- 4. Select the **Unit** tab.

The following table outlines the parameters for the **Unit** tab.

Table 118: Variable definitions

Variable	Value
Туре	Specifies the type number.
Descr	Specifies the type of switch.
Ver	Specifies the version number of the switch
SerNum	Specifies the serial number of the switch.
BaseNumPorts	Specifies the base number of ports.
TotalNumPorts	Specifies the total number of ports.

Displaying the PoE tab for a single unit

To set the power usage threshold, the power pairs to use, and the power detection method to use, select a single Avaya Ethernet Routing Switch 5520 unit.

☑ Note:

These parameters only can be viewed and set by selecting a single unit. If more than one unit is selected, the **PoE** tab is not displayed.

To open the PoE tab for a single unit:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Unit**.
- 3. Select the **PoE** tab.

The following table outlines the parameters of the **PoE** tab.

Table 119: Variable definitions

Variable	Value
Power	Displays the total power available to the Avaya Ethernet Routing Switch 5520.
OperStatus	Displays the power state of the Avaya Ethernet Routing Switch 5520.:
	• on
	• off
	• faulty
Consumption Power	Displays the power being used by the Avaya Ethernet Routing Switch 5520.
Usage Threshold	Enables you to set a percentage of the total power usage of the Avaya Ethernet Routing Switch 5520 switch based on which the system sends a trap.
	Note:
	You must have the traps enabled (see NotificationControlEnable) to receive a power usage trap.
Notification Control Enable	Enables you to enable or disable sending traps if the switch's power usage exceed the percentage set in the UsageThreshold field.
PowerDevice DetectType	Enables you to set the power detection method that the switch uses to detect a request for power from a device connected to all ports on the switch:
	• 802.3af
	• 802.3af and legacy
PowerPairs	Displays the RJ-45 pin pairs that the switch uses to send power to the ports on the switch.

224 Configuration — System October 2012

Displaying the Chassis dialog box

To open the Chassis dialog box:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Chassis.
- 3. From the Chassis tree, double-click Chassis.

The following sections provide a description of the tabs in the Edit Chassis screen:

- Viewing system properties on page 225
- Displaying the Asset ID tab on page 227
- Displaying the Banner tab on page 227
- Displaying the Custom Banner tab on page 228
- Viewing stack mode properties on page 229
- Configuring AUR on page 229

Viewing system properties

Use the System tab to specify, among other things, tracking information for a device and device descriptions.

To view the System tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Chassis.
- 3. From the Chassis tree, double-click Chassis.
- 4. Select the **System** tab.

The following table outlines the parameters for the **System** tab.

Table 120: Variable definitions

Variable	Value
sysDescr	A description of the device.
sysUpTime	The time since the system was last booted.
sysObjectID	The system object identification number.

Variable	Value
sysContact	Type the contact information (in this case, an e-mail address) for the system administrator.
sysName	Type the name of this device.
sysLocation	Type the physical location of this device.
AuthenticationTraps	Click to enable or disable. When you select enabled, SNMP traps are sent to trap receivers for all SNMP access authentication. When you select disabled, no traps are received. To view traps, click the Trap toolbar button.
Reboot	Action object to reboot the agent. Reset initiates a hardware reset. The agent attempts to return a response before the action occurs. If any of the combined download actions are requested, neither action occurs until the expiration of s5AgInfoScheduleBootTime, if set. • bootPrimary: Use the primary boot image. • bootSecondary: Use the secondary boot image.
AutoPvid	Click enabled or disabled. When you select enabled, Port VLAN ID (PVID) is automatically assigned.
StackInsertionUnitNumbe r	The unit number to be assigned to the next unit that joins the stack. The value cannot be set to the unit number of an existing stack member. When a new unit joins the stack, and the value of this object is used as its unit number, the value reverts to 0. If the value of this object is 0, it is not used when determining the unit number of new units.
JumboFramesEnabled	Click to enable or disable jumbo frames.
NextBootMgmtProtocol	The transport protocols to use after the next boot of the agent.
CurrentMgmtProtocol	Read only: The current transport protocols that the agent supports.
BootMode	The source from which to load the initial protocol configuration information to boot the switch the next time. The options available are
	bootpDisabled
	bootpAlways
	bootpWhenNeeded
	bootpOrLastAddress
	• dhcp

Variable	Value
	dhcpWhenNeeded
	dhcpOrLastAddress
CurrentImageVersion	Read only: The version number of the agent image that is currently used on the switch.
NextBootDefaultGateway	Read only: The IP address of the default gateway for the agent to use after the next time the switch is booted.
CurrentDefaultGateway	Read only: The IP address of the default gateway that is currently in use.
NextBootLoadProtocol	Read only: The transport protocol to be used by the agent to load the configuration information and the image at the next boot.
LastLoadProtocol	Read only: The transport protocol last used to load the image and configuration information about the switch.

Displaying the Asset ID tab

To open the Asset ID tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Chassis**.
- 3. From the Chassis tree, double-click **Chassis**.
- 4. Select the **Asset ID** tab.

The following table outlines the parameters for the **Asset ID** tab.

Table 121: Variable definitions

Variable	Value
Class	Specifies the local MED device class.
AssetID	Specifies the vendor-specific asset tracking identifier as advertised by the local device.

Displaying the Banner tab

To display the Banner tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Chassis**.
- 3. From the Chassis tree, double-click Chassis.
- 4. Select the **Banner** tab.

The following table outlines the parameters for the **Banner** tab.

Table 122: Variable definitions

Variable	Value
BannerControl	BannerControl specifies the banner to be displayed as soon as you connect to an Avaya Ethernet Routing Switch 5000 Series device. BannerControl has the following three options:
	The static option causes the predefined static banner to be used.
	The custom option causes the previously set custom banner to be used when displaying a banner.
	The disabled option prevents the display of any banners.

Displaying the Custom Banner tab

To display the Custom Banner tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Chassis.
- 3. From the Chassis tree, double-click Chassis.
- 4. Select the Custom Banner tab.

The following table outlines the parameters for the **Custom Banner** tab.

Table 123: Variable definitions

Variable	Value
Туре	Identifies the banner type. There are two types of banner - one type is used in switch or stand-alone mode while the other is used in the stack mode.
Id	Identifies the line of text within a custom banner
Line	Displays a one line of a fifteen line banner. If the line contains non-printable ASCII characters, then the line is rejected and an error message returned.

228 Configuration — System October 2012

Viewing stack mode properties

To view the Stack Mode tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Chassis.
- 3. From the Chassis tree, double-click **Chassis**.
- 4. Select the Stack Mode tab.

The following table outlines the parameters for the **Stack Mode** tab.

Table 124: Variable definitions

Variable	Value
CurrentOperationalMode	View operational mode.
NextBootOperationMode	View boot operation mode.

Configuring AUR

To configure AUR:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Chassis.
- 3. From the Chassis tree, double-click Chassis.
- 4. Select the AUR tab.
- 5. Enable Auto Unit Replacement by selecting the AutoUnitReplacementEnabled check box.
- 6. Enable Auto Unit Replacement saving by selecting the AutoUnitReplacementSaveEnabled check box.
- 7. Enter a value for forced saves in the AutoUnitReplacementForceSaves field.
- 8. Enter a value for AUR restore in the **AutoUnitReplacementRestore** field.
- 9. Click Apply.

The following table outlines the parameters for the **AUR** tab.

Table 125: Variable definitions

Variable	Value
AutoUnitReplacementEn abled	Specifies whether AUR is enabled.
AutUnitReplacementSav eEnabled	Specifies whether AUR Save is enabled.
AutUnitReplacementForc eSave	Specifies whether an immediate save of the new base unit (NBU) configuration to the base unit (BU) is forced.
AutUnitReplacementRest ore	Specifies whether the configuration of a unit from the saved configuration on the base unit is restored.

Displaying the Switch/Stack dialog box

The following section provides information about how to display switch/stack details.

- Displaying the Base Unit Info tab on page 230
- Viewing stack operating status on page 231
- Renumbering stack switch units using EDM on page 233

Displaying the Base Unit Info tab

The Base Unit Info tab provides read-only information about the operating status of the hardware and whether or not the default factory settings are being used.

To display the Base Unit Info tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Chassis.
- 3. From the Chassis tree, double-click **Switch/Stack**.
- 4. Select the Base Unit Info tab.

The following table outlines the parameters for the **Base Unit Info** tab.

Table 126: Variable definitions

Variable	Value
Туре	The switch type.
Descr	A description of the switch hardware, including number of ports and transmission speed.

Variable	Value
Ver	The switch hardware version number.
SerNum	The switch serial number.
LstChng	The value of sysUpTime at the time the interface entered its current operational state. If the current state was entered prior to the last reinitialization of the local network management subsystem, the value is zero.
AdminState	Administrative state of the switch. Select either enable or reset.
	Note:
	In a stack configuration, Reset only resets the base unit.
OperState	The operational state of the switch.
Location	Type the physical location of the switch.
RelPos	The relative position of the switch.
BaseNumPorts	The number of base ports of the switch.
TotalNumPorts	The number of ports of the switch.
IpAddress	The base unit IP address.
RunningSoftwareVer	The software version.

Viewing stack operating status

The Stack Info tab provides read-only information about the operating status of the stacked switches and whether or not the default factory settings are being used.

To open the Stack Info tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Chassis**.
- 3. From the Chassis tree, double-click **Switch/Stack**.
- 4. Select the **Stack Info** tab.

The following table outlines the parameters for the **Stack Info** tab.

Table 127: Variable definitions

Variable	Value
Descr	A description of the component or subcomponent. If not available, the value is a zero length string.

Variable	Value
Location	The geographic location of a component in a system modeled as a chassis, but possibly physically implemented with geographically separate devices connected together to exchange management information. Chassis modeled in this manner are sometimes referred to as virtual chassis. An example value is: 4th flr wiring closet in blg A. Notes: 1. This field is applicable only to components that can be found in either the Board or Unit groups. If the information is unavailable, for example, the chassis is not modeling a virtual chassis or component is not in Board or Unit group, the value is a zero length string. 2. If this field is applicable and is not assigned a value through a SNMP SET PDU when the row is created, the value defaults to the value of the object s5ChasComSerNum.
LstChng	The value of sysUpTime when it was detected that the component/sub-component was added to the chassis. If this action has not occurred since the cold/warm start of the agent, then the value is zero.
AdminState	The state of the component or subcomponent. The values that are read-only are:
	other currently in some other state
	notAvail actual value is not available
	The possible values that can be read and written are:
	enableenables operation
	resetresets component
OperState	The current operational state of the component. The possible values are:
	othersome other state
	notAvailstate not available
	removedcomponent removed
	disabledoperation disabled
	normalnormal operation
	• resetInProgreset in progress
	• testingdoing a self test
	warningoperating at warning level
	nonFatalErroperating at error level fetalErr error stopped energing
	fatalErrerror stopped operation The allowable (and meaningful) values are determined by the
	component type.

Variable	Value
Ver	The version number of the component or subcomponent. If not available, the value is a zero length string.
SerNum	The serial number of the component or subcomponent. If not available, the value is a zero length string.
BaseNumPorts	The number of base ports of the component or subcomponent.
TotalNumPorts	The number of ports of the component or subcomponent.
IpAddress	The IP address of the component or subcomponent.
RunningSoftwareVer	The software version.

Renumbering stack switch units using EDM

Use this procedure to change the unit numbers of switches in a stack.

Important:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. In the Edit tree, double-click Chassis.
- 3. In the Chassis tree, double-click **Switch/Stack**.
- 4. In the work area, click the **Stack Numbering** tab.
- 5. To select a switch unit, click a unit row.
- 6. In the unit rowdouble-click the cell in the **New Unit Number** column.
- 7. Select a value from the list.
- 8. Click Apply.

A warning message appears indicating that initiating the renumbering of switch units in a stack results in an automatic reset of the entire stack.

The following table outlines the parameters for the **Stack Numbering** tab.

Table 128: Variable definitions

Variable	Value
Current Unit Number	Indicates the current switch numbering sequence.
Descr	Provides a description of hardware included with the selected stack switch.
New Unit Number	Specifies the updated switch numbering sequence.

Variable definitions

Use the information in the following table to change the unit numbers of switches in a stack.

Displaying the Ports dialog box

Port configuration tasks are performed in Enterprise Device Manager on the Port screen.

To open the Port screen:

Procedure steps

- 1. In the **Device Physical View** double-click the port. Multiple ports can be edited by selecting ports with the Control (CTRL) key depressed. Or From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Chassis**.
- 3. From the Chassis tree, double-click Ports.

☑ Note:

The presentation of the Port screen differs when one port is selected or multiple ports are selected. This difference is mainly in presentation although some options are not be available when multiple ports are selected. These exceptions are noted in their descriptions.

The following sections describe some of the tabs on the Port screen:

- Displaying port status on page 234
- Viewing VLAN port properties on page 237
- Viewing the PoE power settings on page 238
- Displaying the LACP tab on page 239
- Viewing VLACP properties on page 241
- Configuring rate limiting for a single port on page 242
- Testing port cables on page 243

Displaying port status

The Interface tab shows the basic configuration and status of a port.

To open the Interface tab:

Procedure steps

- 1. In the **Device Physical View** double-click the port. Multiple ports can be edited by selecting ports with the Control (CTRL) key depressed. Or From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Chassis**.
- 3. From the Chassis tree, double-click Ports.
- 4. Select the Interface tab.
- 5. Click **Apply** after making any changes.

The following table outlines the parameters for the **Interface** tab.

Table 129: Variable definitions

Variable	Value
Index	A unique value assigned to each interface. The value ranges between 1 and 128 standalone. On stack, the index value of the first port of the second unit is 129. The maximum value is 512.
Name	Use this field to enter an optional name for the port.
Descr	The type of switch and number of ports.
Туре	The media type of this interface.
Mtu	The size of the largest packet, in octets, that can be sent or received on the interface.
PhysAddress	The MAC address assigned to a particular interface.
AdminStatus	The current administrative state of the interface, which can be one of the following:
	• up
	• down
	When a managed system is initialized, all interfaces start with AdminStatus in the down state. AdminStatus changes to the up state (or remains in the down state) as a result of either management action or the configuration information available to the managed system.
OperStatus	The current operational state of the interface, which can be one of the following:
	• up
	• down
	• testing
	If AdminStatus is up, then OperStatus is also up if the interface is ready to transmit and receive network traffic. If AdminStatus is down, then OperStatus is also down. It remains in the down state if and only if there is a fault that prevents it from going to

Variable	Value
	the up state. The testing state indicates that no operational packets can be passed.
LastChange	The value of sysUpTime at the time the interface entered its current operational state. If the current state was entered prior to the last reinitialization of the local network management subsystem, the value is zero.
LinkTrap	Indicates whether linkUp/linkDown traps are generated for this interface. By default, this object has the value enabled for interfaces that do not operate on top of any other interface (as defined in the ifStackTable).
AutoNegotiate	Indicates whether this port is enabled for autonegotiation or not.
AdminDuplex	Sets the administrative duplex mode of the port (half or full).
OperDuplex	Shows the current administrative duplex mode of the port (half or full).
AdminSpeed	Set the port speed.
OperSpeed	The current operating speed of the port.
AutoNegotiation Capability	Specifies the port speed and duplex capabilities that hardware can actually support on a port, and which can be advertised by the port using auto-negotiation. Bit 7 tells if a port supports pause frame capabilities (for full-duplex links) as a part of the advertisement. bit 0 - 10 half duplex advertisements bit 1 - 10 full duplex advertisements bit 2 - 100 half duplex advertisements bit 3 - 100 full duplex advertisements bit 4 - 1000 half duplex advertisements bit 5 - 1000 full duplex advertisements bit 6 - PAUSE frame support advertisements bit 7 - Asymmetric PAUSE frame support advertisements If auto-negotiation is not supported by the port hardware, then all bits reflect a value of zero.
AutoNegotiation Advertisements	Specifies the port speed and duplex abilities to be advertised during link negotiation. • 10Half: 10 half duplex advertised • 10Full: 10 full duplex advertised • 100Half: 100 half duplex advertised • 100Full: 100 full duplex advertised • 1000Half: 1000 half duplex advertised • 1000Full: 1000 full duplex advertised

Variable	Value
	PauseFrame: PAUSE frame support advertised.
	AsymPauseFrame: Asymmetric PAUSE frame support advertised.
	The abilities specified in this object are only used when autonegotiation is enabled on the port. If all bits in this object are disabled, and auto-negotiation is enabled on the port, then the physical link process on the port is disabled.
WanMode	Set the area network type for a 10 GE port.
	• none
	• wan
	• lan
Mitid	The multilink trunk to which the port is assigned (if any).
IsPortShared	Displays if the selected port is a shared port or not.
PortActive Component	Displays the active component of shared ports.

Viewing VLAN port properties

To view the VLAN tab:

Procedure steps

- 1. In the **Device Physical View** double-click the port. Multiple ports can be edited by selecting ports with the Control (CTRL) key depressed. Or From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Chassis**.
- 3. From the Chassis tree, double-click Ports.
- 4. Select the **VLAN** tab.

The following table outlines the parameters for the **VLAN** tab.

Table 130: Variable definitions

Variable	Value
VlanIds	Specifies the IDs of the VLANs.
DefaultVlandId	The VLAN ID assigned to untagged frames received on a trunk port.
PortPriority	Specifies the port priority value from the list as a value between 0 and 7.

Variable	Value
Tagging	Indicates the type of VLAN port. A trunk port can be a member of more than one VLAN. An access port can be a member of only VLAN, if no membership conflict exists. There are four types of VLAN port:
	• tagAll(trunk)
	• untagAll(access)
	• tagPvidOnly
	untagPvidOnly

For more information on the VLAN tab, see *Avaya Ethernet Routing Switch 5000 Series Configuration — VLANs, Spanning Tree, and Multi-Link Trunking* (NN47200-502).

Viewing the PoE power settings

The PoE tab enables the configuration of the PoE power settings for a port in the Avaya Ethernet Routing Switch 5520. This tab is not displayed for units other than the 5520.

To open the PoE tab:

Procedure steps

- 1. In the **Device Physical View**double-click the port. Multiple ports can be edited by selecting ports with the Control (CTRL) key depressed. Or From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Chassis.
- 3. From the Chassis tree, double-click Ports.
- 4. Select the PoE tab.

™ Note:

The **PoE** tab is for setting Power over Ethernet (PoE) parameters for each port. The **Power Supply** tab on the Chassis screen displays the status of the internal Avaya Ethernet Routing Switch power supply.

The following table outlines the parameters for the **PoE** tab.

Table 131: Variable definitions

Variable	Value
AdminEnable	Enables or disables PoE on this port.
Detection Status	Displays the operational status of the power-device detecting mode on the specified port:

Variable	Value
	disabled: detecting function disabled
	searching: detecting function is enabled and the system is searching for a valid powered device on this port
	detected: detecting function detects a valid powered device but the port is not supplying power
	deliveringPower: detection found a valid powered device and the port is delivering power
	fault: power-specific fault detected on port
	invalidPD: detecting function found an invalid powered device
	denyLowPriority: port disabled by management system to supply power to higher-priority ports
	test: detecting device in test mode
	❖ Note:
	Avaya recommends against using the test operational status.
PowerClassifications	Displays the operational status of the port PD classification.
PowerPriority	Sets the power priority for the specified port to:
	• critical
	• high
	• low
PowerLimit	Enter an integer from 3 to 16 W to set the power limit for the port.
Power Measurement	Read only:
	Voltage: in 1/10 v.
	• Current: in 1/1000 A.
	• Power: in 1/1000 W.

Displaying the LACP tab

To display the LACP tab:

Procedure steps

- 1. In the **Device Physical View** double-click the port. Multiple ports can be edited by selecting ports with the Control (CTRL) key depressed. Or From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Chassis.
- 3. From the Chassis tree, double-click Ports.
- 4. Select the **LACP** tab.

The following table outlines the parameters for the **LACP** tab.

Table 132: Variable definitions

Variable	Value
ActorSystemPriority	A 2-octet read-write value indicating the priority value associated with the Actor's System ID.
OperEnabled	The current operational state for the port. A value of true means the port is participating in LACP. A value of false means the port is not participating in LACP.
ActorAdminState	A string of 8 bits, corresponding to the administrative values of Actor_State as transmitted by the Actor in LACPDUs.
ActorOperState	A string of 8 bits, corresponding to the current operational values of Actor_State as transmitted by the Actor in LACPDUs.
AggregateOrIndividual	The current operational state of the port, either aggregate and participating in a LAG, or individual link, not participating in a LAG. Value is read-only.
ActorPortPriority	The priority value assigned to this Aggregation Port. This 16-bit value is read-write.
ActorySystemID	The identifier for the actor system, currently the MAC address of the actor system. Value is read-only.
ActorOperKey	The current operational value of the Key for the Aggregation Port. This is a 16-bit read-only value.
SelectedAggID	The identifier value of the Aggregator that this Aggregation Port has currently selected. Zero indicates that the Aggregation Port has not selected an Aggregator, either because it is in the process of detaching from an Aggregator or because no suitable Aggregator exists for it to select.
AttachedAggID	The identifier value of the Aggregator that this Aggregation Port is currently attached to. Zero indicates that the Aggregation Port is not currently attached to an Aggregator. This value is readonly.

Variable	Value
ActorPort	The port number locally assigned to the Aggregation Port. The port number is communicated in LACPDUs as the Actor_Port. This value is read-only
PartnerOperPort	The operational port number assigned by the port's protocol partner. This value is read-only.

For more information on the LACP tab, see Avaya Ethernet Routing Switch 5000 Series Configuration — VLANs, Spanning Tree, and Multi-Link Trunking (NN47200-502).

Viewing VLACP properties

To view the VLACP tab:

Procedure steps

- 1. In the **Device Physical View**double-click the port. Multiple ports can be edited by selecting ports with the Control (CTRL) key depressed. Or From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Chassis**.
- 3. From the Chassis tree, double-click Ports.
- 4. Select the VLACP tab.

The following table outlines the parameters for the **VLACP** tab.

Table 133: Variable definitions

Variable	Value
OperEnable	Indicates whether VLACP is operationally enabled (true) or disabled (false).
	Important:
	VLACP is only operational when OperEnable is true and PortState is up.
FastPeriodicTimer	Indicates the number of milliseconds between periodic transmissions using short timeouts. Valid values range from 400-20000 with a default of 500.
SlowperiodicTimer	Indicates the number of milliseconds between periodic transmissions using long timeouts. Values range from 10000-30000 with a default of 30000.
Timeout	Indicates whether the timeout control value is a short or long timeout.
TimeoutScale	Indicates the scale value used to calculate timeout from periodic time. Values range from 1–10. The default is 3.

Variable	Value
	With VLACP, a short interval exists between a port transmitting a VLACPDU and the partner port receiving the same VLACPDU. If the timeout-scale is set to 1, the port timeout value does not take into account the normal travel time of the VLACPDU. The port expects to receive a VLACPDU at the same moment the partner port sends it. Therefore, the delayed VLACPDU results in the link being blocked, and then enabled again when the packet arrives. Avaya recommends that you set the timeout scale to a value larger than 1.
EtherType	Indicates VLACP protocol identification. The value can be entered as a numerical value ranging from 33025–33279 or a hexadecimal equivalent (8101–81ff). The default is 8103. Use the prefix 0x to type a hexadecimal value in the dialog box. Only hexadecimal values display in the EtherType column of the VLACP work area.
EtherMacAddress	Indicates the MAC address of the switch or stack to which this port is sending VLACPDUs. This value cannot be configured as a multicast MAC. The default value is 00:00:00:00:00:00. VLACP uses only the multicast MAC address configured when VLACP is enabled globally. This is the Layer 2 destination address used for the VLACPDUs. The port-specific EtherMACAddress specifies the MAC address of the switch or stack to which this port is sending VLACPDUs. If you do not type a value for the EtherMACAddress, the first VLACP-enabled switch that receives the PDUs from a sending port becomes the intended recipient and processes the PDUs. If you want an intermediate switch to drop VLACP packets, configure EtherMACAddress with the desired destination MAC address. With EtherMACAddress configured, the intermediate switches do not misinterpret the VLACP packets.
PortState	Indicates whether the VLACP port state is up or down.
	Important:
	VLACP is only operational when OperEnable is true and PortState is up.

For more information on the VLACP tab, see *Avaya Ethernet Routing Switch 5000 Series Configuration — VLANs, Spanning Tree, and Multi-Link Trunking* (NN47200-502).

Configuring rate limiting for a single port

You can use the Rate Limit tab to configure the Rate Limiting for a single port.

To open the Rate Limit tab:

Procedure steps

- 1. In the **Device Physical View**double-click the port. Multiple ports can be edited by selecting ports with the Control (CTRL) key depressed. Or From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Chassis**.
- 3. From the Chassis tree, double-click Ports.
- 4. Select the **Rate Limit** tab.

The following table outlines the parameters for the **Rate Limit** tab.

Table 134: Variable definitions

Variable	Value
TrafficType	Specifies the two types of traffic that can be set with rate limiting: broadcast and multicast.
AllowedRate	Sets the rate limiting percentage. The available range is from 0% (none) to 10%.
Enable	Enables and disables rate limiting on the port for the specified traffic type. Options are true (enabled) or false (disabled).

Testing port cables

The 5000 Series switch is equipped with a Time Domain Reflectometer (TDR). The TDR provides a diagnostic capability to test connected cables for defects (such as short pin and pin open). Use the TDR tab to initiate cable diagnostic tests on attached cables.

The cable diagnostic tests only apply to Ethernet copper ports; fiber ports cannot be tested. You can initiate a test on multiple ports at the same time.

When you test a cable with the TDR, if the cable has a 10/100 MB/s link, the link is broken during the test and restored only when the test is complete. Use of the TDR does not affect 1 GB/s links.

■ Note:

The accuracy margin of cable length diagnosis is between three to five meters. Avaya suggests the shortest cable for length information be five meters long.

To initiate a TDR test:

Procedure steps

- 1. In the **Device Physical View**double-click the port. Multiple ports can be edited by selecting ports with the Control (CTRL) key depressed. Or From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Chassis**.

- 3. From the Chassis tree, double-click Ports.
- 4. Select the TDR tab.
- 5. Select the **StartTest** option. (If multiple ports are selected, select **true** from the **StartTest** field for each port that you want to test.)
- 6. Click Apply.

The following table outlines the parameters for the TDR tab.

Table 135: Variable definitions

Variable	Value
StartTest	Enables the TDR test.
TestDone	Indicates whether a TDR test is complete.
CableStatus	Status of the cable as a whole. The status of a cable is, in a sense, a summation of the status of its pairs. If all the pairs are normal, the cable is normal. If the cable consists of zero or more normal pairs and one or more open pairs, the cable is considered open. If the cable consists of shorted pairs and normal pairs, it is considered shorted. Any combination of open and shorted pairs is considered simply failed.
	• cableFail
	cableNormal
	• cableOpen
	cableShorted
	cableNotApplicable
	cableUntested
Pair1Status	The status of a single pair in the cable:
	• pairFail
	pairNormal
	pairOpen
	pairShorted
	pairNotApplicable
	pairNotTested
	pairForce
	Note: If a 10MB or 100MB link is established without autonegotiation, Pair 1 will return Forced mode. The pair length is meaningless in this case.

244 Configuration — System October 2012

Variable	Value
Pair1Length	Pair Length, in meters, measured by Time Domain Reflectometry.
Pair2Status	The status of a single pair in the cable.
Pair2Length	Pair Length, in meters, measured by Time Domain Reflectometry.
Pair3Status	The status of a single pair in the cable.
Pair3Length	Pair Length, in meters, measured by Time Domain Reflectometry.
Pair4Status	The status of a single pair in the cable.
Pair4Length	Pair Length, in meters, measured by Time Domain Reflectometry.
CableLength	Length of cable in meters based on average electrical length of 4 pairs. Measurement can be done when traffic is live or not.
Pair1Polarity	The polarity of a single pair in the cable. This capability is available only when the cable gigabit link is up, regardless of traffic activity.
Pair1Swap	The pair swap in the cable:
	• normal
	• swapped
	• invalid
	• error
	This capability is available only when the cable gigabit link is up, regardless of traffic activity.
Pair1Skew	Pair skew is measured in nanoseconds. Skew measurement only can be performed when the cable gigabit link is up, regardless of traffic activity. A value of -1 means an error occurred when trying to get the length.
Pair2Polarity	The polarity of a single pair in the cable. This capability is available only when the cable gigabit link is up, regardless of traffic activity.
Pair2Swap	The pair swap in the cable. This capability is available only when the cable gigabit link is up, regardless of traffic activity.
Pair2Skew	Pair skew is measured in nanoseconds. Skew measurement only can be performed when the cable gigabit link is up, regardless of traffic activity. A value of -1 means an error occurred when trying to get the length.

Variable	Value
Pair3Polarity	The polarity of a single pair in the cable. This capability is available only when the cable gigabit link is up, regardless of traffic activity.
Pair3Swap	The pair swap in the cable. This capability is available only when the cable gigabit link is up, regardless of traffic activity.
Pair3Skew	Pair skew is measured in nanoseconds. Skew measurement only can be performed when the cable gigabit link is up, regardless of traffic activity. A value of -1 means an error occurred when trying to get the length.
Pair4Polarity	The polarity of a single pair in the cable.
Pair4Swap	The pair swap in the cable.
Pair4Skew	Differential cable pair length in meters. Skew measurement only can be performed when the cable gigabit link is up, regardless of traffic activity. A value of -1 means an error occurred when trying to get the length.

Displaying the Environment dialog box

The following section provides information about how to display switch environment details.

- Viewing the switch power supply properties on page 246
- Displaying status of switch fans on page 247
- Viewing temperature information on page 248

Viewing the switch power supply properties

The Power Supply tab provides read-only information about the operating status of the switch power supplies.

The power supply parameters are slightly different for the Avaya Ethernet Routing Switch 5520, as it supports Power over Ethernet (PoE).

To view the Power Supply tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Chassis.
- 3. From the Chassis tree, double-click **Environment**.
- 4. Select the **PowerSupply** tab.

The following table outlines the parameters for the **PowerSupply** tab.

Table 136: Variable definitions

Variable	Value
Description	Indicates the chassis number, power supply number, and the type of power supply.
OperStat	The operational state of the power supply. Possible values include:
	other: Some other state.
	notAvail: State not available.
	removed: Component was removed.
	disabled: Operation disabled.
	normal: State is in normal operation.
	resetInProg: There is a reset in progress.
	testing: System is doing a self test.
	warning: System is operating at a warning level.
	nonFatalErr: System is operating at error level.
	fatalErr: A fatal error stopped operation.
	notConfig: A module needs to be configured. The allowable values are determined by the component type.

Displaying status of switch fans

The Fan tab provides read-only information about the operating status of the switch fans.

To display status of switch fans:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Chassis.
- 3. From the Chassis tree, double-click **Environment**.
- 4. Select the Fan tab.

The following table outlines the parameters for the **Fan** tab.

Table 137: Variable definitions

Variable	Value
OperStat	The operational state of the fan. Values include:
	other: Some other state.
	notAvail: This state is not available.

Variable	Value
	• removed: Fan was removed.
	disabled: Fan is disabled.
	normal: Fan is operating in normal operation.
	resetInProg: A reset of the fan is in progress.
	testing: Fan is doing a self test.
	warning: Fan is operating at a warning level.
	nonFatalErr: Fan is operating at error level.
	fatalErr: An error stopped the fan operation
	notConfig: Fan needs to be configured. The allowable values are determined by the component type.

Viewing temperature information

The Temperature tab provides read-only information about the temperature of the switch.

To view the Temperature tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Chassis**.
- 3. From the Chassis tree, double-click Environment.
- 4. Select the **Temperature** tab.

A report of the temperature settings of the switch appears in the Environment window.

5. Click the **Refresh** tab to update the data.

Avaya Energy Saver configuration using Enterprise Device Manager

You can use Avaya Energy Saver (AES) to configure the switch to utilize energy more efficiently.

Navigation:

- Global AES configuration on page 249
- AES schedule configuration on page 252

Configuration — System October 2012

- Port-based AES configuration on page 255
- Viewing AES information using EDM on page 257

Global AES configuration

Use the information in this section to configure AES for an single switch or a stack.

Navigation

- Enabling global AES on page 249
- Disabling global AES on page 250
- Enabling global AES PoE power save mode on page 250
- Disabling global AES PoE power save mode on page 250
- Enabling AES efficiency mode on page 251
- Disabling AES efficiency mode on page 252

Enabling global AES

Use the following procedure to enable energy saving for the switch.

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. In the Power Management tree, double-click Energy Saver.
- 3. In the work area, click the Energy Saver Globals tab.
- 4. Click the EnergySaverEnabled box.
- 5. On the toolbar, click **Apply**.
- 6. On the toolbar, you can click **Refresh** to update the work area data display.

The following table outlines the parameters of the **Energy Saver Globals** tab.

Table 138: Variable definitions

Variable	Value
EnergySaverEnabled	Enables or disables energy saving for the switch.
PoePowerSavingEnabled	Enables or disables AES PoE power save mode for the switch.

Variable	Value
EfficiencyModeEnabled	Enables or disables AES efficiency mode for the switch.
EnergySaverActive	Activates or deactivates the Avaya Energy Saver.

Disabling global AES

Use the following procedure to disable energy saving for the switch.

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. In the Power Management tree, double-click **Energy Saver**.
- 3. In the work area, click the **Energy Saver Globals** tab.
- 4. Click the EnergySaverEnabled box.
- 5. Click Apply.
- 6. On the toolbar, you can click **Refresh** to update the work area data display.

Enabling global AES PoE power save mode

Use the following procedure to enable AES PoE power save mode for the switch.

When enabled, AES PoE power save mode provides the capability to control power consumption savings for only ports that have AES enabled, and PoE priority configured to low.

Prerequisites

- Disable AES globally.
 - 1. From the navigation tree, double-click **Power Management**.
 - 2. In the Power Management tree, double-click **Energy Saver**.
 - 3. In the work area, click the **Energy Saver Globals** tab.
 - 4. Click the **PoePowerSavingEnabled** box.
 - 5. Click Apply.
 - 6. On the toolbar, you can click **Refresh** to update the work area data display.

Disabling global AES PoE power save mode

Use the following procedure to disable AES PoE power save mode for the switch.

When enabled, AES PoE power save mode provides the capability to control power consumption savings for only ports that have AES enabled, and PoE priority configured to low.

Prerequisites

Disable AES globally.

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. In the Power Management tree, double-click **Energy Saver**.
- 3. In the work area, click the Energy Saver Globals tab.
- 4. Click the **PoePowerSavingEnabled** box.
- 5. Click **Apply**.
- 6. On the toolbar, you can click **Refresh** to update the work area data display.

Enabling AES efficiency mode

Use the following procedure to enable AES efficiency mode for the switch.

When enabled, AES efficiency mode enables AES globally and for each port, enables AES PoE power save mode, and configures AES scheduling to predetermined values (on time 18:00 and off time 07:30 daily).

! Important:

AES efficiency mode overrides custom AES scheduling and PoE power saving mode. You will be prompted to confirm that you want to enable AES efficiency mode before proceeding.

Prerequisites

• Disable AES globally.

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. In the Power Management tree, double-click **Energy Saver**.
- 3. In the work area, click the Energy Saver Globals tab.
- 4. Select the **EfficiencyModeEnabled** check box.
- 5. Click Apply.
- 6. On the toolbar, you can click **Refresh** to update the work area data display.

Disabling AES efficiency mode

Use the following procedure to disable AES efficiency mode for the switch.

When enabled, AES efficiency mode enables AES globally and for each port, enables AES PoE power save mode, and configures AES scheduling to predetermined values (on time 18:00 and off time 07:30 daily).

Prerequisites

Disable AES globally.

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. In the Power Management tree, double-click **Energy Saver**.
- 3. In the work area, click the **Energy Saver Globals** tab.
- 4. Click the EfficiencyModeEnabled box.
- 5. Click Apply.
- 6. On the toolbar, you can click **Refresh** to update the work area data display.

AES schedule configuration

Use the information in this section to configure a time interval for the switch to enter lower power states.

Navigation

- Configuring the AES schedule on time on page 252
- Configuring the AES schedule off time on page 253
- Modifying an AES schedule on and off time status on page 254

Configuring the AES schedule on time

Use the following procedure to configure the start of a time interval for the switch to enter lower power states. The time interval can span a complete week, a complete weekend, multiple days, or be configured within an individual day.

252 Configuration — System October 2012

Prerequisites

Disable AES globally.

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. In the Power Management tree, double-click **Energy Saver**.
- 3. In the work area, click the **Energy Saver Schedules** tab.
- 4. Click Insert.
- 5. To choose a day for the AES schedule on time, click a button in the **ScheduleDay** section.
- 6. To choose an hour of the day for the AES schedule on time, type a value in the ScheduleHour box.
- 7. To choose a portion of an hour for the AES schedule on time, type a value in the ScheduleMinute box.
- 8. To configure the selected day, hour, and minutes as the AES schedule on time, click the activate button in the ScheduleAction section.
 - Activate is selected by default.
- 9. Click Insert.

The following table describes the fields of Insert Energy Saver Schedule window.

Table 139: Variable definitions

Variable	Value
ScheduleDay	Indicates the day on which this schedule entry takes effect.
ScheduleHour	Indicates the hour on which this schedule entry takes effect.
ScheduleMinute	Indicates the Minute on which this schedule entry takes effect.
ScheduleAction	Activates or deactivates the energy savings.

Configuring the AES schedule off time

Use the following procedure to configure the end of a time interval for the switch to enter lower power states. The time interval can span a complete week, a complete weekend, multiple days, or be configured within an individual day.

Prerequisites

• Disable AES globally.

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. In the Power Management tree, double-click **Energy Saver**.
- 3. In the work area, click the Energy Saver Schedules tab.
- 4. Click Insert.
- 5. To choose a day for the AES schedule off time, select a button in the **ScheduleDay** section.
- 6. To choose an hour of the day for the AES schedule off time, type a value in the **ScheduleHour** box.
- 7. To choose a portion of an hour for the AES schedule off time, type a value in the **ScheduleMinute** box.
- 8. To configure the selected day, hour, and minutes as the AES schedule off time, click the **deactivate** radio button in the ScheduleAction section.
 - Activate is selected by default.
- 9. Click Insert.

The following table describes the fields of Insert Energy Saver Schedule window.

Table 140: Variable definitions

Variable	Value
ScheduleDay	Indicates the day on which this schedule entry takes effect.
ScheduleHour	Indicates the hour on which this schedule entry takes effect.
ScheduleMinute	Indicates the Minute on which this schedule entry takes effect.
ScheduleAction	Activates or deactivates the energy savings.

Modifying an AES schedule on and off time status

Use the following procedure to change an existing schedule off time to on time or to change an existing schedule on time to off time.

Prerequisites

Disable AES globally.

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. In the Power Management tree, double-click **Energy Saver**.

- 3. In the work area, click the **Energy Saver Schedules** tab.
- 4. To select a schedule time to edit, click a schedule day.
- In the schedule day rowdouble-click the cell in the ScheduleAction column.
- 6. Select a value from the list—activate to configure the schedule time as the on time, or **deactivate** to configure the schedule time as the off time.
- 7. Click Apply.

Port-based AES configuration

Configure port-based AES to enable or disable energy saving for individual ports, or all ports on a switch or stack.

Navigation

- Enabling AES on individual ports on page 255
- Disabling AES on individual ports on page 256

Enabling AES on individual ports

Use the following procedure to turn on AES for individual ports on a switch or stack.

Procedure steps

- 1. From the navigation tree, double-click Power Management.
- 2. In the Power Management tree, double-click **Energy Saver**.
- 3. In the work area, click the **Ports** tab.
- 4. In the Multiple Port Configuration area, click the Switch/Stack/Ports elipsis **(...)**.
- 5. Click a port or ports, or click All.
- 6. Click Ok.

The portlist appears in the **Switch/Stack/Ports** box.

7. In the Multiple Port Configuration areadouble-click the cell under EnergySaverEnabled.

A downward arrow appears.

- Click the arrow.
 - A list appears.
- 9. Click true.

- 10. Click Apply Selection.
- 11. On the toolbar, click Apply.
- 12. Repeat steps 4 to 11 to enable AES for additional ports as required.
- 13. Click Apply.
- 14. On the toolbar, you can click **Refresh** to update the work area data display.

The following table describes the fields of the **Ports** tab.

Table 141: Variable definitions

Field	Description
Port	Indicates the port.
EnergySaverEnabled	Indicates whether the Avaya Energy Saver feature is enabled for the port.

Disabling AES on individual ports

Use the following procedure to turn off AES for individual ports on a switch or stack.

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. In the Power Management tree, double-click **Energy Saver**.
- 3. In the work area, click the **ports** tab.
- 4. In the **Multiple Port Configuration** area, click the **Switch/Stack/Ports** elipsis (...).
- 5. Click a port or ports, or click All.
- 6. Click Ok.

The portlist appears in the **Switch/Stack/Ports** box.

7. In the **Multiple Port Configuration** areadouble-click the cell under **EnergySaverEnabled**.

A downward arrow appears.

- 8. Click the arrow.
 - A list appears.
- 9. Click false.
- 10. Click Apply Selection.
- 11. On the toolbar, click **Apply**.
- 12. Repeat steps 4 to 11 to disable AES for additional ports as required.

- 13. Click Apply.
- 14. On the toolbar, you can click **Refresh** to update the work area data display.

Viewing AES information using EDM

Use the following procedure to display energy saving information for an individual switch or switches in a stack.

Procedure steps

- 1. From the navigation tree, double-click Power Management.
- 2. In the Power Management tree, double-click **Energy Saver**.
- 3. In the work area, click the **Energy Savings** tab.
- 4. On the toolbar, you can click **Refresh** update the data.

Use the data in this table to help you understand the displayed AES information.

Table 142: Variable definitions

VariableValue	Value
UnitIndex	Indicates the unit number of the switch.
UnitSavings(watts)	Indicates the total power capacity being saved on the switch.
PoeSavings(watts)	Indicates the total PoE power being saved on the switch.

Bridge configuration using Enterprise Device Manager

Bridge information displays the MAC Address Table for the switch.

To open the Bridge dialog box:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Bridge.

This section provides information about the following topics:

- Displaying bridge information on page 258
- Displaying the Transparent tab on page 258
- Displaying the Forwarding tab on page 259

Displaying bridge information

The Base tab displays basic Bridge information including the MAC address, type, and number of ports participating in the Bridge.

The MAC address used by the bridge must be referred to in a unique fashion; moreover, it must be the smallest MAC address (numerically) of all ports that belong to the bridge. However, it is only required to be unique when integrated with dot1dStpPriority. A unique Bridgeldentifier is formed that is used in the Spanning Tree Protocol.

To open the Base tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Bridge.
- 3. Select the **Base** tab.

The following table outlines the parameters for the **Base** tab.

Table 143: Variable definitions

Variable	Value
BridgeAddress	MAC address of the bridge when it is referred to in a unique fashion. This address must be the smallest MAC address of all ports that belong to the bridge. However, it is has to be unique. When concatenated with dot1dStpPriority, a unique bridge ID is formed that is then used in the Spanning Tree Protocol.
NumPorts	Number of ports controlled by the bridging entity.
Туре	Indicates the type of bridging this bridge can perform. If the bridge is actually performing a certain type of bridging, this fact is indicated by entries in the port table for the given type.

Displaying the Transparent tab

The Transparent tab is used to view information about learned forwarding entries.

To display the Transparent tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Bridge.

October 2012 Configuration — System

- 3. Select the **Transparent** tab.
- 4. Click **Apply** if the **AgingTime** field is modified.

The following table outlines the parameters for the **Transparent** tab.

Table 144: Variable definitions

Variable	Value
LearnedEntryDiscards	Number of Forwarding Database entries learned that have been discarded due to a lack of space in the Forwarding Database. If this counter is increasing, it indicates that the Forwarding Database is becoming full regularly. This condition affects the performance of the subnetwork. If the counter has a significant value and is not presently increasing, it indicates that the problem has been occurring but is not persistent.
AgingTime	Timeout period in seconds for aging out dynamically learned forwarding information.
	Note:
	The 802.1D-1990 specification recommends a default of 300 seconds.

Displaying the Forwarding tab

The Forwarding tab displays the current state of the port, as defined by application of the Spanning Tree Protocol.

To display the Forwarding tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Bridge.
- 3. Select the **Forwarding** tab.

The following table outlines the parameters for the **Forwarding** tab.

Table 145: Variable definitions

Variable	Value
Status	The values of this fields include:
	invalid: Entry is no longer valid, but has not been removed from the table.
	learned: Value of the corresponding instance of dot1dTpFdbPort was learned and is being used.
	self: Value of the corresponding instance of dot1dTpFdbAddress represents an address of the bridge.

Variable	Value
	The corresponding instance of dot1dTpFdbPort indicates that a specific port on the bridge has this address.
	 mgmt(5): Value of the corresponding instance of dot1dTpFdbAddress is also the value of an existing instance of dot1dStaticAddress.
	 other: None of the preceding. This includes instances where some other MIB object (not the corresponding instance of dot1dTpFdbPort or an entry in the dot1dStaticTable) is being used to determine if a frames addressed to the value of dot1dTpFdbAddress are being forwarded.
Address	A unicast MAC address for which the bridge has forwarding or filtering information.
Port	Either the value "0" or the port number on a frame has been seen. The source address must be equal to the value of the corresponding instance of dot1dTpFdbAddress A value of "0" indicates that the port number has not been learned, so the bridge does have the forwarding/filtering information for this address (located in the dot1dStaticTable). You must assign the port value to this object whenever it is learned even for addresses for which the corresponding value of dot1dTpFdbStatus is not learned(3).
Id	The VLAN ID.

File System configuration using Enterprise Device Manager

This section provides information about the following topics:

- Config/Image/Diag file tab on page 261
- ASCII file tab on page 264
- Configuring the license file on page 267
- File configuration on page 268
- Displaying Boot Image information on page 270
- Displaying the Help File Path tab on page 271

260 Configuration — System October 2012

Config/Image/Diag file tab

This section provides information about the following topics:

- Changing the switch software on page 261
- Storing a binary configuration file on page 263
- Retrieving a binary configuration file on page 264

Changing the switch software

The Config/Image/Diag file tab is used to change the switch software.

To open the Config/Image/Diag file tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **File System**.
- Select the Config/Image/Diag file tab.
 In the fields provided, specify the information necessary to perform the download process.
- 4. Click Apply.

The software download process occurs automatically after clicking **Apply**. This process erases the contents of flash memory and replaces it with the new software image. Do not interrupt the download process. Depending on network conditions, this process can take up to 10 minutes. When the download process is complete, the switch automatically resets and the new software image initiates a self-test. During the download process, the switch is not operational.

The following table outlines the parameters for the **Config/Image/Diag file** tab.

Table 146: Variable definitions

Variable	Value
TftpServerInetAddressTy pe	The type of TFTP server on which the new software images are stored for download.
TftpServerInetAddress	The IP address of the TFTP server on which the new software images are stored for download.
BinaryConfigFileName	The binary configuration file currently associated with the switch. This field is used when working with configuration files and is not used when downloading a software image.
BinaryConfigUnit Number	The unit number of the portion of the configuration file that has to be extracted and used for the stand-alone unit configuration. If this value is 0 it is ignored. This field is used when working

Variable	Value
	with configuration files and is not used when downloading a software image.
ImageFileName	The name of the image file currently associated with the switch. If needed, change this field to the name of the software image to be downloaded.
FwFileName (Diagnostics)	The name of the diagnostic file currently associated with the switch. If needed, change this field to the name of the diagnostic software image to be downloaded.
UsbTargetUnit	This field indicates the unit number of the USB port to be used in file upload or download operation.
Image	Specify if the image to download is the primary or secondary image.
Action	This group of option buttons represents the actions that are to be taken during this file system operation. The options applicable to a software download are:
	dnldImg - Select this option to download a new software image to the switch. This option replaces the software image on the switch regardless of whether it is newer or older than the current image.
	dnldFw - Select this option to download a new diagnostic software image to the switch. This option replaces the image regardless of whether it is newer or older than the current image.
	dnldImglfNewer - Select this option to download a new software image to the switch only if it is newer than the one currently in use.
	dnldImgFromUsb - Select this option to download a new software image to the switch using the front panel USB port. This option replaces the image regardless of whether it is newer or older than the current image. This option is only available on the Avaya Ethernet Routing Switch 5530-24TFD.
	dnldFwFromUsb - Select this option to download a new diagnostic software image to the switch from the front panel USB port. This option replaces the image regardless of whether it is newer or older than the current image. This option is only available on the Avaya Ethernet Routing Switch5530-24TFD or 5600 Series.
	dnldImgNoReset - Select this option to download a new software image to the switch. This option replaces the software image on the switch regardless of whether it is newer

Variable	Value
	or older than the current image. After the download is complete, the switch is not reset.
	dnldFwNoReset - Select this option to download a new diagnostic software image to the switch. This option replaces the image regardless of whether it is newer or older than the current image. After the download is complete, the switch is not reset.
Status	Displays the status of the last action that occurred since the switch was last booted. The values that are displayed are:
	other - No action has taken place since the last boot.
	• inProgress - The selected operation is currently in progress.
	success - The selected operation was successful.
	fail - The selected operation failed.

Storing a binary configuration file

To store the current binary configuration file to a TFTP server or USB storage device:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **File System**.
- 3. Select the Config/Image/Diag file tab.
- 4. If a default TFTP server is not already specified (or another TFTP server is to be used), enter the IP address of the TFTP server to use in the TftpServerInetAddress field. If the file is stored on a USB storage device, skip this step.
- 5. In the **BinaryConfigFilename** field enter the name to assign to the configuration file .
- 6. If the configuration file to be stored is part of a stack, enter the stack unit number in the **BinaryConfigUnitNumber** field. If it is a stand-alone unit, specify 0.
- 7. If the configuration file is saved to a USB storage device, enter the stack unit number in which the USB device is inserted in the **UsbTargetUnit** field.
- 8. In the **Action** field, select the **upldConfig** option to upload to a TFTP server or **upldConfigtoUsb** to upload it to a USB storage device.
- 9. Click Apply.

For more information, see Table 146: Variable definitions on page 261.

Retrieving a binary configuration file

To retrieve a binary configuration file from a TFTP server:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click File System.
- 3. Select the Config/Image/Diag file tab.
- 4. If a default TFTP server is not already specified (or another TFTP server is to be used), enter the IP address of the TFTP server to use in the TftpServerInetAddress field. If the file is retrieved from a USB storage device, skip this step.
- 5. Enter the name of the configuration file to retrieve in the **BinaryConfigFilename** field.
- If the configuration file to be retrieved to a member of a stack, enter the stack unit number in the BinaryConfigUnitNumber field. If it is a stand-alone unit, specify 0.
- 7. If the configuration file is retrieved from a USB storage device, enter the stack unit number in which the USB device is inserted in the **UsbTargetUnit** field.
- 8. In the **Action** field, select the **dnldConfig** option to download the file from a TFTP server or **dnldConfigFromUsb** to download it from a USB storage device.
- 9. Click Apply.

For more information, see Table 146: Variable definitions on page 261.

ASCII file tab

This section provides information about the following topics:

- Downloading an ASCII configuration file on page 264
- Storing the current ASCII configuration on page 266
- Retrieving an ASCII configuration file on page 267

Downloading an ASCII configuration file

This feature is enabled through Enterprise Device Manager by using the File System screen.

To enable the automatic downloading of a configuration file:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click File System.
- 3. Select the **AsciiConfigFile** tab.
- 4. Type the IP address of the desired TFTP server in the TftpServerInetAddress field.
- 5. Type the name of the configuration file to be used in the AsciiConfigFilename field.
- 6. From the AsciiConfigAutoDownload field, select the option button that represents how the configuration file is to be downloaded. The options are:
 - disabled Automatic downloading is disabled.
 - useBootp Use BootP to obtain the settings needed to connect to the TFTP server that contains the configuration file. Using this option overrides the value in the LoadServerAddr field.
 - useConfig Use the TFTP settings on the screen to connect to the TFTP server.

7. Click Apply.

The following table outlines the parameters for the **Ascii Config File** tab.

Table 147: Variable definitions

Variable	Value
TftpServerInet AddressType	Specifies the IP address of the TFTP server for all TFTP operations. If not used, then the value is 0.0.0.0. Further, if the value of s5AgTftpServerInetAddressType is not ipv4(1), then the value of this object must be 0.0.0.0.
TftpServerInetAddress	This object indicates the type of address stored in the related object s5AgSysTftpServerInetAddress.
AsciiConfigFilename	Specifies the name of the ascii configuration file that is downloaded/uploaded either at boot time when the s5AgSysAsciiConfigAutoDownload object is set to useConfig(3), or when the s5AgSysAsciiConfigManualDownloadobject is set to downloadNow(4) or downloadFromUsb(5). When not used, the value is a zero length string.
UsbTargetUnit	Indicates the unit number of the USB port to be used in file upload/download operations
AsciiConfigAuto Download	Indicates whether an ASCII configuration file should be downloaded at boot time. The file can be downloaded using either the configured filename and TFTP server address, or a BOOTP server can be used to determine the filename and TFTP server address.

Variable	Value
AsciiConfigAutoDld Status	Indicates the status of the last automatic ASCII configuration file download at boot time. If no automatic download at boot time has been attempted, the value returned is failed.
AsciiConfigManual Download	Indicates the last manual attempt to download an ASCII configuration file.
AsciiConfigManualDld Status	Indicates the status of the last manual attempt to download an ASCII configuration file. The value of this object when retrieved can be either passed(1), inProgress(2), or failed(3). Setting this object to downloadNow(4) initiates a manual ASCII configuration file download from a TFTP server. Setting this object to downloadFromUsb(5) initials a manual ASCII configuration file download from a USB flash dongle. If no attempt has been made to manually download a configuration file, the value returned is failed(3).
Applications	Specifies the application.
AsciiConfigManual Upload	Indicates the the last manual attempt to upload an ASCII configuration file.
AsciiConfigManual UpldStatus	Indicates the status of the last manual attempt to upload an ASCII configuration file. The value of this object when retrieved can be either passed(1), inProgress(2), or failed(3). Setting this object to uploadNow(4) initiates a manual ASCII configuration file upload to a TFTP server. Setting this object to uploadToUsb(5) initiates a manual ASCII configuration file upload to a USB flash dongle. If no attempt has been made to manually upload a configuration file, the value returned is failed(3)." ::= { s5AgentSystem 19 }

Storing the current ASCII configuration

To store the current ASCII switch configuration file to a TFTP server or USB storage device:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **File System**.
- 3. Select the Ascii Config File tab.
- 4. In the **TftpServerInetAddress** box type the IP address of the desired TFTP server.
- 5. In the **AsciiConfigFilename** box type the name of the configuration file.
- 6. To save the configuration file to a USB storage device, select 9 if the device is a standalone or 1-8 if the device is a stack.

- 7. In the AsciiConfigManualUpload field select Upload Now to transfer the file to a TFTP server or **UploadToUsb** to transfer the file to a USB mass storage device.
- 8. Click Apply.
- 9. Check the AsciiConfigManualUpload field for the file transfer status. If the status of the file upload is InProgress, wait for up to two minutes and then click Refresh to see the new status. The file upload is complete when the status displays either Passed or Failed .

For more information, see Table 147: Variable definitions on page 265.

Retrieving an ASCII configuration file

To retrieve an ASCII configuration file from a TFTP server or USB storage device:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **File System**.
- 3. Select the **Ascii Config File** tab.
- 4. In the TftpServerInetAddress box type the IP address of the desired TFTP server if you are retrieving the configuration file from a TFTP server.
- 5. If you retrieve the configuration file from a USB storage device, select 9 if the device is a stand-alone or 1-8 if the device is a stack.
- 6. Select downloadNow in the AsciiConfigManualDownload field to transfer the file from a TFTP server or downloadFromUsb to transfer the file from a USB mass storage device.
- 7. Click Apply.
- 8. Check the AsciiConfigManualDldStatus field for the file transfer status. If the status of the file upload is InProgress, wait for up to two minutes and then click Refresh to see any new status applied to the upload. The file upload is complete when the status displays either Passed or Failed .

For more information, see Table 147: Variable definitions on page 265.

Configuring the license file

To configure the license file:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **File System**.
- Select the License File tab.

- 4. In the TftpServerInetAddressType field, select the address type, IPv4 or IPv6.
- 5. In the TftpServerInetAddress field, enter the TFTP server address in the format selected in the previous step.
- 6. In the LicenseFileName field, enter the software license filename for the TFTP server.
- 7. In the UsbTargetUnit field, select the target location using an integer ranging 0-9. 0 specifies TFTP retrieval. 1-8 are used to specify USB in a stack unit. 9 is used to specify a standalone unit.
- 8. In the LicenseFileAction field, select dnldLicense.
- 9. Click Apply.
- Click Refresh. The LicenceFileStatus field displays the file copy progress. After the
 file copy completes, a warning message appears prompting you to reboot the switch
 and activate the license.
- 11. To reboot the switch, choose Edit, Chassis
- 12. Under the System tab, select the reboot option and click Apply.

The following table outlines the parameters for the **License File** tab.

Table 148: Variable definitions

Variable	Value
TftpServerInetAddressTy pe	Specifies the IP address of the TFTP server for all TFTP operations. If not used, then the value is 0.0.0.0. Further, if the value of s5AgTftpServerInetAddressType is not ipv4(1), then the value of this object must be 0.0.0.0.
TftpServerInetAddress	Specifies the type of address of the TFTP server for all TFTP operations as IPv4 or IPv6.
LicenseFileName	Specifies the name of the license file.
UsbTargetUnt	Specifies the USB target location.
	• 1–8 specifies that the USP target unit is in the stack.
	9 specifies that the USB target is a standalone unit.
	0 specifies a TFTP server.
LicenseFileAction	Specifies the license file action. Only dnld license is supported.
LicenseFileStatus	Displays the file copy process.
RemoveLicense	Removes the license from a unit.

File configuration

Enterprise Device Manager provides tools for the storage and retrieval of configuration files.

This section provides information about the following topics:

- Saving the current configuration on page 269
- Enabling autosave on page 270
- Disabling autosave on page 270

Saving the current configuration

The configuration currently in use on a switch is regularly saved to the flash memory automatically. However, you can manually initiate this process using the Save Configuration tab.

To save the current configuration:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click File System.
- 3. Select the **Config/Image/Diag file** tab.
- 4. Choose the Save Configuration tab.

The Save Configuration tab appears.

3 Note:

The shared graphic was removed in accordance with the NTDA for cloning of documents. The graphic that was removed was Edit_FileSystem_Save_Config.png

- 5. In the **Action** field, choose **copyConfigToNvram**.
- 6. Click Apply.
- 7. Click Refresh The Status field displays the file copy progress.

The following table outlines the parameters for the **Save Configuration** tab.

Table 149: Variable definitions

Variable	Value
AutosaveToNvramEnable d	Controls whether autosaving to NVRAM is enabled. Autosaving normally occurs periodically in a background task if any configuration changes have been made
Action	Specifies where the current configuration file is saved. Only copyConfigToNvram is supported.
Status	

Enabling autosave

To enable autosave:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **File System**.
- 3. Select the **Save Configuration** tab.
- 4. Select the AutoSaveToNvramEnabled check box.
- 5. Click Apply.

For more information, see <u>Table 149</u>: <u>Variable definitions</u> on page 269.

Disabling autosave

To disable autosave:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **File System**.
- 3. Select the Save Configuration tab.
- 4. Deselect the AutoSaveToNvramEnabled check box.
- 5. Click Apply.

For more information, see <u>Table 149</u>: <u>Variable definitions</u> on page 269.

Displaying Boot Image information

You can view boot image information with the Boot Image tab.

To see the version of the primary and secondary boot images on your system:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **File System**.
- 3. Select the **Boot Image** tab.
- 4. Click **Refresh** to renew the information.

The following table outlines the parameters for the **Boot Image** tab.

Table 150: Variable definitions

Variable	Value
Chassis <1 to 8> Primary Image version	Displays the version number of the primary boot image.
Chassis <1 to 8> Secondary Image version	Displays the version number of the secondary boot image. This line is blank if the switch does not have a secondary image in memory.
Chassis <1 to 8> Running Image version	Displays the version number of the boot image currently running.

Displaying the Help File Path tab

To open the Help File Path tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- From the Edit tree, double-click File System.
- 3. Select the Help File Path tab.

ADAC Configuration using Enterprise Device Manager

This section provides information about the following topics:

- Displaying the ADAC tab on page 271
- Displaying the ADAC MAC Ranges tab on page 272
- Displaying the ADAC Ports tab on page 273

Displaying the ADAC tab

To open the ADAC tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click ADAC.
- 3. Select the ADAC tab.

The following table outlines the parameters of the **ADAC** tab.

Table 151: Variable definitions

Variable	Value
OperEnable	Indicates ADAC operational state: true is enabled and false is disabled.
	Important:
	If AdminEnable is True and OperEnable is False, this indicates an error condition such as missing Uplink and Call Server ports.
OperatingMode	Selects the ADAC operation mode:
	untaggedFramesBasic—IP Phones send untagged frames, and the Voice VLAN is not created.
	untaggedFramesAdvanced—IP Phones send untagged frames, and the Voice VLAN is created.
	taggedFrames—IP Phones send tagged frames.
VoiceVlan	Sets the Voice VLAN ID.
CallServerPortList	Selects the Call Server port. A maximum of 8 Call Server ports are supported.
UplinkPortList	Selects the Uplink port. A maximum of 8 Uplink ports are supported.
MacAddrRangeControl	Selects a MAC address range table control option.
	none—default
	clearTable—clears all MAC address range table entries.
	defaultTable—replaces all MAC address range table entries to default values.

Displaying the ADAC MAC Ranges tab

To open the ADAC MAC Ranges tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click ADAC.
- 3. Select the ADAC MAC Ranges tab.

The following table outlines the parameters of the **ADAC MAC Ranges** tab.

Table 152: Variable definitions

Variable	Value
MacAddrRangeLowEndI ndex	The MAC address for the low end of the MAC address range.
MacAddrRangeHighEndl ndex	The MAC address for the high end of the MAC address range.

Displaying the ADAC Ports tab

To open the ADAC Ports tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click ADAC.
- 3. Select the ADAC Portss tab.

The following table outlines the parameters of the ADAC Ports tab.

Table 153: Variable definitions

Variable	Value
Index	Indicates the switch position in a stack and the port number. The default value for a standalone switch is 1.
AdminEnable	Indicates whether ADAC is enabled (true) or disabled (false) for the port.
OperEnable	Indicates whether the port ADAC operational state is true (enabled) or false (disabled). This is a read-only cell.
	Important:
	If OperEnable is false and AdminEnable is true, ADAC is disabled. This can occur if you reach the maximum number of devices supported on a port.
ConfigStatus	Indicates the ADAC status for the port.
	configApplied—the ADAC configuration is applied to the port.
	configNotApplied—the ADAC configuration is not applied to the port.
	•
	This is a read-only cell.

Variable	Value
TaggedFramesPvid	Indicates the unique Port VLAN identifier (PVID). Values range from 0–4094. A value of 0 indicates that Auto-Configuration cannot change the PVID for the port.
TaggedFramesTagging	Indicates the tagging value that Auto-Con figuration applies to a port that has ADAC enabled and has tagged frames selected as the operating mode.
	tagAll—tagging is enabled on all frames
	tagPvidOnly—tagging is enabled on frames with a PVID that matches the PVID of this port
	untagPvidOnly—tagging is disabled on frames with a PVID that matches the PVID of this port
	noChange—accepts frames without change
AdacPortType	Indicates how ADAC classifies the port:
	telephony—autodetection is enabled for the port
	callServer—the port is configured as a Call Server
	uplink—the port is configured as an Uplink
	other—the port is not classified as telephony, callServer, or uplink
MacDetectionEnable	Indicates whether Autodetection of Avaya IP Phones, based on MAC address is enabled (true) or disabled (false) on the interface.
	Important:
	You cannot configure MacDetectionEnable to false if no other supported detection mechanism is enabled on the port.
LldpDetectionEnable	Indicates whether Autodetection of Avaya IP Phones, based on 802.1ab is enabled (true) or disabled (false) on the interface.
	Important:
	You cannot configure LldpDetectionEnable to false if no other supported detection mechanism is enabled on the port.

Topology configuration using Enterprise Device Manager

This section describes topology diagnostic information available in Enterprise Device Manager through the following tabs:

- Viewing topology information on page 275
- <u>Viewing topology table information</u> on page 275

Viewing topology information

To view topology information:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **Topology**.
- 4. Select the **Topology** tab.

The following table outlines the parameters of the **Topology** tab.

Table 154: Variable definitions

Variable	Value
IpAddr	The IP address of the device.
Status	Whether Avaya topology is on (topOn) or off (topOff) for the device. The default value is topOn.
NmmLstChg	The value of sysUpTime the last time an entry in the network management MIB (NMM) topology table was added, deleted, or modified. If the table has not changed since the last cold or warm start of the agent, then the value is zero.
NmmMaxNum	The maximum number of entries in the NMM topology table.
NmmCurNum	The current number of entries in the NMM topology table.

Viewing topology table information

To view more topology information:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **Topology**.
- 4. Select the **Topology Table** tab.

The following table outlines the parameters of the **Topology Table** tab.

Table 155: Variable definitions

Variable	Value
Slot	The slot number in the chassis in which the topology message was received.
Port	The port on which the topology message was received.
IpAddr	The IP address of the sender of the topology message.
SegId (Slot/Port)	The segment identifier, slot, and port number from where the autotopology packets were received.
MacAddr	The MAC address of the sender of the topology message.
ChassisType	The chassis type of the device that sent the topology message.
BkplType	The backplane type of the device that sent the topology message.
LocalSeg	Indicates if the sender of the topology message is on the same Ethernet segment as the reporting agent.
CurState	The current state of the sender of the topology message. The choices are:
	topChanged: Topology information has recently changed.
	heartbeat: Topology information is unchanged.
	• new: The sending agent is in a new state.

System Log configuration using Enterprise Device Manager

This section has information on the following:

- Viewing system log settings on page 276
- Viewing remote system log properties on page 278
- Viewing system logs on page 278

Viewing system log settings

To view the System Log Settings tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **System Log**.
- 4. Select the **System Log Settings** tab.

The following table outlines the parameters of the **System Log Settings** tab.

Table 156: Variable definitions

Variable	Value
Operation	Enables (on) or disables (off) the system log.
BufferFullAction	Specifies the action for the system to take when the buffer space allocated for system log messages is exhausted.
	overwrite—previously logged messages are overwritten
	latch—halts the saving of system log messages until overwrite is selected, or buffer space is made available by other means (for example, clearing the buffer).
CurSize	Indicates the number of messages currently stored in memory.
SaveTargets	Specifies the type of system messages to save in memory.
	critical—only messages classified as critical are saved in memory
	critical/serious—only messages classified as critical and serious are saved in memory
	critical/serious/inform—only messages classified as critical, serious, and informational are saved in memory
	none—no system log messages are saved in memory
ClearMessageBuffers	Specifies the types system log messages to delete from volatile and non-volatile memory.
	volCritical—only messages classified as critical are deleted from volatile memory
	volSerious—only messages classified as serious are deleted from volatile memory
	volInformational—only messages classified as informational are deleted from volatile memory
	nonVolCritical—only messages classified as critical are deleted from non-volatile memory
	nonVolSerious—only messages classified as serious are deleted from non-volatile memory

Viewing remote system log properties

To view the Remote System Log tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **System Log**.
- 4. Select the Remote System Log tab.

The following table outlines the parameters of the **Remote System Log** tab.

Table 157: Variable definitions

Variable	Value
RemoteSyslogAddressTy pe	Specifies the type of IP address of the remote system log server.
RemoteSyslogAddress	Specifies the IP address of the remote system log server when sending system log messages.
SecondarySyslogAddres sType	Specifies the type of IP address of the secondary remote system log server.
SecondarySyslogAddres s	Specifies the IP address of the secondary remote system log server when sending system log messages.
SaveTargets	Specifies the type of system messages to send to the remote system log server.
	critical—only messages classified as critical are sent to the remote system log server
	critical/serious—only messages classified as critical and serious are sent to the remote system log server
	critical/serious/inform—only messages classified as critical, serious, and informational are sent to the remote system log server
	none—no system log messages are sent to the remote system log server

Viewing system logs

To view the System Logs tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **System Log**.
- 4. Select the **System Logs** tab.

The following table outlines the parameters of the **System Logs** tab.

Table 158: Variable definitions

Variable	Value
OrigUnitNumber	Indicates the slot or unit number of the originator of a log message.
MsgTime	Indicates the time (in one hundredths of a second) between system initialization and the appearance of a log message in the system log.
MsgIndex	Indicates a sequential number the system assigns to a log message when it enters the system log.
MsgScr	Indicates whether a log message was loaded from non-volatile memory at system initialization or was generated since system initialization.
MsgString	Indicates the log message originator and the reason the log message was generated.

LLDP configuration using Enterprise Device Manager

Use the following tabs to configure and view LLDP global and transmit properties for local and neighbor systems:

- Configuring LLDP transmit properties on page 280
- Configuring LLDP ports on page 283
- TX Stats on page 285
- RX Stats on page 286
- Viewing LLDP local system properties on page 288
- Viewing LLDP local port properties on page 290
- Viewing LLDP management properites on page 291
- Viewing LLDP remote management properties on page 292

- Viewing unknown TLVs received on page 293
- Viewing LLDP organizationally-specific properties on page 294

Configuring LLDP transmit properties

With the Globals tab, you can configure LLDP transmit properties and view remote table statistics.

To configure LLDP transmit properties:

Procedure steps

280

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Diagnostics.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click **LLDP**.
- 5. Select the Globals tab.

The following table outlines the parameters of the **LLDP Globals** tab.

Table 159: Variable definitions

Variable	Value
IldpMessageTxInterval	The interval (in seconds) at which LLDP frames are transmitted on behalf of this LLDP agent.
IldpMessageTx HoldMultiplier	The time-to-live value expressed as a multiple of the object. The actual time-to-live value used in LLDP frames, transmitted on behalf of this LLDP agent, is expressed by the following formula: TTL = min(65535, (IldpMessageTxInterval *IldpMessageTxHoldMultiplier)) For example, if the value of IldpMessageTxInterval is 30, and the value of IldpMessageTxHoldMultiplier is 4, the value 120 is encoded in the TTL field in the LLDP header.
IldpReinitDelay	The IldpReinitDelay indicates the delay (in seconds) from when the LLDP Port AdminStatus of a particular port is disabled until reinitialization begins.
IldpTxDelay	The IldpTxDelay indicates the delay (in seconds) between successive LLDP frame transmissions initiated by value or status changes in the LLDP local systems MIB. The recommended value for the IldpTxDelay is set by the following formula: 1 <= IldpTxDelay <= (0.25 * IldpMessageTxInterval)
IldpNotificationInterval	This object controls the transmission of LLDP notifications. The agent must not generate more than one IldpRemTablesChange notification-event in the indicated period, where a notification-event is the "transmission of a single notification PDU type to a

Configuration — System

Comments? infodev@avaya.com

Comments? infodev@avaya.com

Variable	Value
	list of notification destinations." If additional changes in IldpRemoteSystemsData object groups occur within the indicated throttling period, these trap-events must be suppressed by the agent. An NMS must periodically check the value of IldpStatsRemTableLastChangeTime to detect any missed IldpRemTablesChange notification-events, for example, due to throttling or transmission loss. If notification transmission is enabled for particular ports, the suggested default throttling period is 5 seconds.
RemTablesLast ChangeTime	The value of the sysUpTime object (defined in IETF RFC 3418) at the time an entry is created, modified, or deleted in tables associated with the IldpRemoteSystemsData objects, and all LLDP extension objects associated with remote systems. An NMS can use this object to reduce polling of the IldpRemoteSystemsData objects.
RemTablesInserts	The number of times the complete set of information advertised by a particular MSAP is inserted into tables contained in IldpRemoteSystemsData and IldpExtensions objects. The complete set of information received from a particular MSAP is inserted into related tables. If partial information cannot be inserted for a reason such as lack of resources, all of the complete set of information is removed. This counter is incremented only once after the complete set of information is successfully recorded in all related tables. Any failures occurring during insertion of the information set, which result in deletion of previously inserted information, do not trigger any changes in IldpStatsRemTablesInserts because the insert is not completed yet or in IldpStatsRemTablesDeletes, because the deletion is only a partial deletion. If the failure is the result of a lack of resources, the IldpStatsRemTablesDrops counter is incremented once.
RemTablesDeletes	The number of times the complete set of information advertised by a particular MSAP is deleted from tables contained in IldpRemoteSystemsData and IldpExtensions objects. This counter is incremented only once when the complete set of information is completely deleted from all related tables. Partial deletions, such as a deletion of rows associated with a particular MSAP, from some tables, but not from all tables, are not allowed, and thus, do not change the value of this counter.
RemTablesDrops	The number of times the complete set of information advertised by a particular MSAP can not be entered into tables contained in IldpRemoteSystemsData and IldpExtensions objects because of insufficient resources.
RemTablesAgeouts	The number of times the complete set of information advertised by a particular MSAP is deleted from tables contained in IldpRemoteSystemsData and IldpExtensions objects because

Variable	Value
	the information timeliness interval has expired. This counter is incremented only once when the complete set of information is completely invalidated (aged out) from all related tables. Partial aging, similar to deletion case, is not allowed, and thus, does not change the value of this counter.
FastStartRepeatCount	The number of times the fast start LLDPDU is sent during the activation of the fast start mechanism defined by LLDP-MED.

Viewing LLDP remote properties

With the Neighbor tab, you can view LLDP properties for the remote system.

To view LLDP properties for the remote system:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click **LLDP**.
- 5. Select the **Neighbor** tab.

The following table outlines the parameters of the **LLDP Neighbor** tab.

Table 160: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry. See the TimeFilter textual convention in IETF RFC 2021 for details about TimeFilter.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
ChassisIdSubtype	The type of encoding used to identify the remote system chassis:
	chassisComponent
	interfaceAlias
	portComponent
	macAddress

Variable	Value
	• networkAddress
	interfaceName
	• local.
ChassisId	Remote chassis ID.
SysCapSupported	Identifies the system capabilities supported on the remote system.
SysCapEnabled	Identifies the system capabilities that are enabled on the remote system.
SysName	Remote system name.
SysDesc	Remote system description.
PortIdSubtype	The type of encoding used to identify the remote port.
	• interfaceAlias
	• portComponent
	• macAddress
	• networkAddress
	interfaceName
	agentCircuitId
	• local
PortId	Remote port ID.
PortDesc	Remote port description.

Configuring LLDP ports

With the Port tab, you can set the optional TLVs to include in the LLPDUs transmitted by each port.

To configure LLDP ports:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click **LLDP**.
- 5. Select the **Port** tab.

The following table outlines the parameters of the **LLDP Port** tab.

Table 161: Variable definitions

Variable	Value
PortNum	Port number.
AdminStatus	The administratively desired status of the local LLDP agent:
	txOnly: the LLDP agent transmits LLDP frames on this port and does not store any information about the remote systems to which it is connected.
	rxOnly: the LLDP agent receives but does not transmit LLDP frames on this port.
	txAndRx: the LLDP agent transmits and receives LLDP frames on this port.
	disabled: the LLDP agent does not transmit or receive LLDP frames on this port. If the port receives remote systems information which is stored in other tables before AdminStatus is disabled, the information ages out.
NotificationEnable	Controls, for each port, whether notifications from the agent are enabled.
	true: indicates that notifications are enabled
	false: indicates that notifications are disabled.
TLVsTxEnable	Sets the optional Management TLVs to be included in the transmitted LLDPDUs:
	portDesc: Port Description TLV
	sysName: System Name TLV
	sysDesc: System Description TLV
	sysCap: System Capabilities TLV
	Note: The Local Management tab controls Management Address TLV transmission.
VLANTxEnable(dot1)	Specifies whether the IEEE 802.1 organizationally defined port VLAN TLV transmission is included in the transmitted LLDPDUs.
TLVsTxEnable(dot3)	Sets the optional IEEE 802.3 organizationally defined TLVs to be included in the transmitted LLDPDUs:
	macPhyConfigStatus: MAC/PHY configuration/status TLV
	powerViaMDI: Power over MDI TLV
	IinkAggregation: Link Aggregation TLV
	maxFrameSize: Maximum-frame-size TLV.

284

Variable	Value
CapSupported(med)	Identifies which MED system capabilities are supported on the local system.
TLVsTxEnable(med)	Sets the optional organizationally defined TLVs for MED devices to include in the transmitted LLDPDUs:
	capabilities: Capabilities TLVs
	networkPolicy: Network Policy TLVs
	location: Emergency Communications System Location TLVs
	extendedPSE: Extended PoE TLVs with PSE capabilities
	inventory: Hardware Revision, Firmware Revision, Software Revision, Serial Number, Manufacturer Name, Model Name, and Asset ID TLVs.
NotifyEnable(med)	A value of true enables sending the topology change traps on this port. A value of false disables sending the topology change traps on this port.

TX Stats

This section provides information about the following topics:

- Displaying the TX Stats tab on page 285
- Graphing LLDP transmit statistics on page 286

Displaying the TX Stats tab

With the TX Stats tab, you can view LLDP transmit statistics by port.

To open the TX Stats tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click LLDP.
- 5. Select the TX Stats tab.

The following table outlines the parameters of the **LLDP TX Stats** tab.

Table 162: Variable definitions

Variable	Value
PortNum	port number
FramesTotal	the number of LLDP frames transmitted by this LLDP agent on the indicated port

Graphing LLDP transmit statistics

To graph LLDP transmit statistics:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Diagnostics.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click LLDP.
- 5. Select the TX Stats tab.
- 6. Click **Graph**. The TX Stats Graph dialog box appears.
- 7. Highlight a data column to graph.
- 8. Click one of the graph buttons.

RX Stats

This section provides information about the following topics:

- Displaying the RX Stats tab on page 286
- Graphing LLDP receive statistics on page 288

Displaying the RX Stats tab

With the RX Stats tab, you can view LLDP receive statistics by port.

To open the RX Stats tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.

- 4. From the 802.1AB tree, double-click **LLDP**.
- 5. Select the **RX Stats** tab.

The following table outlines the parameters of the **LLDP RX Stats** tab.

Table 163: Variable definitions

Variable	Value
PortNum	Port number.
FramesDiscardedTotal	The number of LLDP frames received on the port and discarded for any reason. This counter provides an indication that LLDP header formatting problems exist with the local LLDP agent in the sending system, or that LLDPDU validation problems exist with the local LLDP agent in the receiving system.
FramesErrors	The number of invalid LLDP frames received on the port, while the LLDP agent is enabled.
FramesTotal	The number of valid LLDP frames received on the port, while the LLDP agent is enabled.
TLVsDiscardedTotal	The number of LLDP TLVs discarded for any reason.
TLVsUnrecognizedTotal	The number of LLDP TLVs received on a given port that are not recognized by this LLDP agent on the indicated port. An unrecognized TLV is referred to as the TLV whose type value is in the range of reserved TLV types (000 1001 - 111 1110) in Table 9.1 of IEEE 802.1AB-2004. An unrecognized TLV can be a basic management TLV from a later LLDP version.
AgeoutsTotal	This counter represents the number of age-outs that occurred on a given port. An age-out is "the number of times the complete set of information advertised by a particular MSAP is deleted from tables contained in IldpRemoteSystemsData and IldpExtensions objects because the information timeliness interval has expired." This counter is similar to IldpStatsRemTablesAgeouts, except that it is on a for each-port basis. This enables NMS to poll tables associated with the IldpRemoteSystemsData objects and all LLDP extension objects associated with remote systems on the indicated port only. This counter is set to zero during agent initialization. When the admin status for a port changes from disabled to rxOnly, txOnly or txAndRx, the counter associated with the same port is reset to 0. The agent also flushes all remote system information associated with the same port. This counter is incremented only once when the complete set of information is invalidated (aged out) from all related tables on a particular port. Partial aging is not allowed, and thus, does not change the value of this counter.

Graphing LLDP receive statistics

To graph LLDP receive statistics:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click LLDP.
- 5. Select the **RX Stats** tab.
- 6. Click **Graph**. The RX Stats Graph dialog box appears.
- 7. Highlight a data column to graph.
- 8. Click one of the graph buttons.

Viewing LLDP local system properties

With the Local System tab, you can view LLDP properties for the local system.

To view LLDP local system properties:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click **LLDP**.
- 5. Select the **Local System** tab.

The following table outlines the parameters of the **LLDP Local System** tab.

Table 164: Variable definitions

Variable	Value
ChassisIdSubtype	the type of encoding used to identify the local system chassis:
	chassisComponent
	• interfaceAlias
	• portComponent
	• macAddress
	• networkAddress

Variable	Value
	interfaceName
	• local
ChassisId	chassis ID
SysName	local system name
SysDesc	local system description
SysCapSupported	identifies the system capabilities supported on the local system
SysCapEnabled	identifies the system capabilities that are enabled on the local system
DeviceClass	local MED device class
HardwareRev	the vendor-specific hardware revision string as advertised by the local device
FirmwareRev	the vendor-specific firmware revision string as advertised by the local device
SoftwareRev	the vendor-specific software revision string as advertised by the local device
SerialNum	the vendor-specific serial number as advertised by the local device
MfgName	the vendor-specific manufacturer name as advertised by the local device
ModelName	the vendor-specific model name as advertised by the local device
AssetID	the vendor-specific asset tracking identifier as advertised by the local device
DeviceType	defines the type of Power-via-MDI (Power over Ethernet) advertised by the local device:
	pseDevice: indicates that the device is advertised as a Power Sourcing Entity (PSE).
	pdDevice: indicates that the device is advertised as a Powered Device (PD)
	none: indicates that the device does not support PoE
PSEPowerSource	defines the type of PSE Power Source advertised by the local device:
	primary: indicates that the device advertises its power source as primary
	backup: indicates that the device advertises its power source as backup

Variable	Value
PDPowerReq	specifies the value of the power required (in units of 0.1 watts) by a Powered Device (PD)
PDPowerSource	defines the type of power source advertised as in use by the local device:
	fromPSE: indicates that the device advertises its power source as received from a PSE
	local: indicates that the device advertises its power source as local
	localAndPSE: indicates that the device advertises its power source as using both local and PSE power
PDPowerPriority	defines the priority advertised as required by this PD:
	critical: indicates that the device advertises its power priority as critical, see RFC 3621
	high: indicates that the device advertises its power priority as high, see RFC 3621
	low: indicates that the device advertises its power priority as low, see RFC 3621

Viewing LLDP local port properties

With the Local Port tab, you can view LLDP port properties for the local system.

To view LLDP local port properties:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click LLDP.
- 5. Select the **Local System** tab.

The following table outlines the parameters of the **LLDP Local Port** tab.

Table 165: Variable definitions

Variable	Value
PortNum	Port number.
PortIdSubtype	The type of port identifier encoding used in the associated PortId object.

Variable	Value
	• interfaceAlias
	• portComponent
	• macAddress
	networkAddress
	interfaceName
	agentCircuitId
	• local.
PortId	The string value used to identify the port component associated with a given port in the local system.
PortDesc	The string value used to identify the 802 LAN station port description associated with the local system. If the local agent supports IETF RFC 2863, the PortDesc object has the same value as the ifDescr object.

Viewing LLDP management properites

With the Local Management tab, you can view LLDP management properties for the local system.

To view LLDP management properties:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click **LLDP**.
- 5. Select the **Local Management** tab.

The following table outlines the parameters of the **LLDP Local Management** tab.

Table 166: Variable definitions

Variable	Value
AddrSubtype	The type of management address identifier encoding used in the associated Addr object.
Addr	The string value used to identify the management address component associated with the local system. This address is used to contact the management entity.

Variable	Value
AddrLen	The total length of the management address subtype and the management address fields in LLDPDUs transmitted by the local LLDP agent. The management address length field is needed so that the receiving systems that do not implement SNMP are not required to implement an iana family numbers/address length equivalency table to decode the management address.
AddrlfSubtype	Identifies the numbering method used to define the interface number associated with the remote system. • unknown • ifIndex
	• systemPortNumber
Addrlfld	The integer value used to identify the interface number of the management address component associated with the local system.
AddrOID	The value used to identify the type of hardware component or protocol entity associated with the management address advertised by the local system agent.
AddrPortsTxEnable	Identifies the ports on which the local system management address TLVs are transmitted in the LLPDUs.

Viewing LLDP remote management properties

With the Neighbor Mgmt Address tab, you can view LLDP management properties for the remote system.

To open the Neighbor Mgmt Address tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click **LLDP**.
- 5. Select the **Neighbor Mgmt Address** tab.

The following table outlines the parameters of the **LLDP Neighbor Mgmt Address** tab.

Table 167: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
AddrSubtype	The type of encoding used in the associated Addr object.
Addr	The management address associated with the remote system.
AddrlfSubtype	Identifies the numbering method used to define the interface number associated with the remote system. • unknown • ifIndex
	systemPortNumber
Addrlfld	The integer value used to identify the interface number of the management address component associated with the remote system.
AddrOID	The value used to identify the type of hardware component or protocol entity associated with the management address advertised by the remote system agent.

Viewing unknown TLVs received

With the Unknown TLV tab, you can view details about unknown TLVs received on the local system.

To view the Unknown TLV tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click LLDP.
- 5. Select the Unknown TLV tab.

The following table outlines the parameters of the **LLDP Unknown TLV** tab.

Table 168: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
UnknownTLVType	The value extracted from the type field of the unknown TLV.
UnknownTLVInfo	The value extracted from the value field of the unknown TLV.

Viewing LLDP organizationally-specific properties

With the Organizational Defined Info tab, you can view Organizationally-specific properties for the remote system.

To view LLDP organizationally-specific properties:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Diagnostics.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click **LLDP**.
- 5. Select the Organizational Defined Info tab.

The following table outlines the parameters of the **LLDP Organizational Defined Info** tab.

Table 169: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
OrgDefInfoOUI	The Organizationally Unique Identifier (OUI), as defined in IEEE 802-2001, is a 24 bit (three octets) globally unique assigned

294 Configuration — System October 2012

Variable	Value
	number referenced by various standards, of the information received from the remote system.
OrgDefInfoSubtype	The integer value used to identify the subtype of the organizationally defined information received from the remote system. The subtype value is required to identify different instances of organizationally defined information that cannot be retrieved without a unique identifier that indicates the particular type of information contained in the information string.
OrgDefInfoIndex	This object represents an arbitrary local integer value used by this agent to identify a particular unrecognized organizationally defined information instance, unique only for the OrgDefInfoOUI and IldpRemOrgDefInfoSubtype of the same remote system. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot. It is unlikely that the IldpRemOrgDefInfoIndex will wrap between reboots.
OrdDefInfo	The string value used to identify the organizationally defined information of the remote system. The encoding for this object is the same as that defined for SnmpAdminString TC.

LLDP Port dot1 configuration using Enterprise Device Manager

You can use the LLDP Port dot1 dialog box to configure and view IEEE 802.1 LLDP information. For details, refer to the following tabs:

- Viewing LLDP VLAN ID properties on page 295
- Viewing LLDP protocol VLAN properties on page 296
- Viewing LLDP VLAN Name properties on page 297
- Viewing LLDP protocol properties on page 298
- Viewing LLDP VLAN ID properties on page 298
- Viewing LLDP Neighbor Protocol VLAN properties on page 299
- Viewing LLDP VLAN Name properties on page 300
- Viewing LLDP Neighbor Protocol properties on page 301

Viewing LLDP VLAN ID properties

With the Local VLAN Id tab, you can view LLDP VLAN ID properties for the local system.

To open the Local VLAN Id tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port dot1.
- 5. Select the Local VLAN Id tab.

The following table outlines the parameters of the **Port dot1 Local VLAN Id** tab.

Table 170: Variable definitions

Variable	Value
PortNum	Port number.
VlanId	The local port VLAN ID. A value of zero is used if the system does not know the PVID.

Viewing LLDP protocol VLAN properties

With the Local Protocol VLAN tab, you can view LLDP Protocol VLAN properties for the local system.

To view LLDP protocol VLAN properties:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click **Port dot1**.
- 5. Select the Local Protocol VLAN tab.

The following table outlines the parameters of the **Port dot1 Local Protocol VLAN** tab.

Table 171: Variable definitions

Variable	Value
PortNum	Port number.
ProtoVlanId	The ID of the port and protocol VLANs associated with the local port. A value of zero is used if the system does not know the protocol VLAN ID (PPVID).

Variable	Value
ProtoVlanSuported	Indicates whether the local port supports port and protocol VLANs.
ProtoVlanEnabled	Indicates whether the port and protocol VLANs are enabled on the local port.
ProtoVlanTxEnable	Indicates whether the corresponding local port and protocol VLAN information are transmitted from the port.

Viewing LLDP VLAN Name properties

With the Local VLAN Name tab, you can view LLDP VLAN Name properties for the local system.

To view the Local VLAN Name tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click Port dot1.
- 5. Select the Local VLAN Name tab.

The following table outlines the parameters of the **Port dot1 Local VLAN Name** tab.

Table 172: Variable definitions

Variable	Value
PortNum	Port number.
VlanId	The integer value used to identify the IEEE 802.1Q VLAN IDs with which the given port is compatible.
VlanName	The string value used to identify the VLAN name identified by the VLAN ID associated with the given port on the local system. This object contains the value of the dot1QVLANStaticName object (defined in IETF RFC 2674) identified with the given IldpXdot1LocVlanId.
VlanNameTxEnable	Indicates whether the corresponding Local System VLAN name instance is transmitted from the port.

Viewing LLDP protocol properties

With the Local Protocol tab, you can view LLDP protocol properties for the local system.

To open the Local Protocol tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click **Port dot1**.
- 5. Select the Local Protocol tab.

The following table outlines the parameters of the Port dot1 Local Protocol tab.

Table 173: Variable definitions

Variable	Value
PortNum	Port number.
ProtocolIndex	An arbitrary local integer value used by this agent to identify a particular protocol identity.
Protocolld	The octet string value used to identify the protocols associated with the given port of the local system.
ProtocolTxEnable	Indicates whether the corresponding Local System Protocol Identity instance is transmitted on the port.

Viewing LLDP VLAN ID properties

With the Neighbor VLAN Id tab, you can view LLDP VLAN ID properties for the remote system.

To view the Neighbor VLAN Id tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click **Port dot1**.
- 5. Select the **Neighbor VLAN Id** tab.

October 2012 298 Configuration — System Comments? infodev @avaya.com

The following table outlines the parameters of the Port dot1 Neighbor VLAN Id tab.

Table 174: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
VlanId	The port VLAN identifier associated with the remote system. If the remote system does not know the PVID or does not support port-based VLAN operation, the value is zero.

Viewing LLDP Neighbor Protocol VLAN properties

With the Neighbor Protocol VLAN tab, you can view LLDP Protocol VLAN properties for the remote system.

To view the Neighbor Protocol VLAN tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port dot1.
- 5. Select the Neighbor Protocol VLAN tab.

The following table outlines the parameters of the **Port dot1 Neighbor Protocol VLAN** tab.

Table 175: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.

Variable	Value
ProtoVlanId	The ID of the port and protocol VLANs associated with the remote port. A value of zero is used if the system does not know the protocol VLAN ID (PPVID).
ProtoVlanSuported	Indicates whether the remote port supports port and protocol VLANs.
ProtoVlanEnabled	Indicates whether the port and protocol VLANs are enabled on the remote port.

Viewing LLDP VLAN Name properties

With the Neighbor VLAN Name tab, you can view LLDP VLAN Name properties for the remote system.

To open the Neighbor VLAN Name tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port dot1.
- 5. Select the **Neighbor VLAN Name** tab.

The following table outlines the parameters of the **Port dot1 Neighbor VLAN Name** tab.

Table 176: PVariable definitions

Vaiable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
VlanId	The integer value used to identify the IEEE 802.1Q VLAN IDs with which the remote port is compatible.
VlanName	The VLAN name identified by the VLAN ID associated with the remote system.

Viewing LLDP Neighbor Protocol properties

With the Neighbor Protocol tab, you can view LLDP Protocol properties for the remote system.

To view the Neighbor Protocol tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click **Port dot1**.
- 5. Select the **Neighbor Protocol** tab.

The following table outlines the parameters of the **Port dot1 Neighbor Protocol** tab.

Table 177: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
ProtocolIndex	This object represents an arbitrary local integer value used by this agent to identify a particular protocol identity.
Protocolld	Identifies the protocols associated with the remote port.

LLDP Port dot3 configuration using Enterprise Device Manager

You can use the LLDP Port dot3 dialog box to configure and view IEEE 802.3 LLDP information. For details, refer to the following tabs:

- Viewing LLDP auto-negotiation properties on page 302
- Viewing LLDP PoE porperties on page 302
- Viewing LLDP link aggregation properties on page 304

- Viewing LLDP maximum frame size properties on page 304
- Viewing LLDP neighbor auto-negotiation properties on page 305
- Viewing LLDP neighbor PoE properties on page 306
- Viewing LLDP neighbor link aggregation properties on page 307
- Viewing LLDP neighbor maximum frame size properties on page 308

Viewing LLDP auto-negotiation properties

With the Local Port Auto-negotiation tab, you can view LLDP auto-negotiation properties for the local system.

To view the Local Port Auto-negotiation tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click **Port dot3**.
- 5. Select the Local Port Auto-negotiation tab.

The following table outlines the parameters of the Port dot3 Local Port Auto-negotiation tab.

Table 178: Variable definitions

Variable	Value
PortNum	Port number.
AutoNegSupported	Indicates whether the local port supports Auto-negotiation.
AutoNegEnabled	Indicates whether Auto-negotiation is enabled on the local port.
AutoNegAdvertisedCap	This object contains the value (bitmap) of the ifMauAutoNegCapAdvertisedBits object (defined in IETF RFC 3636) associated with the local port on the system.
OperMauType	A value that indicates the operational MAU type of the given port on the local system.

Viewing LLDP PoE porperties

With the Local PoE tab, you can view LLDP PoE properties for the local system.

October 2012 302 Configuration — System

To open the Local PoE tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click **Port dot3**.
- 5. Select the **Local PoE** tab.

The following table outlines the parameters of the **Port dot3 Local PoE** tab.

Table 179: Variable definitions

Value
Port number.
Identifies the port Class of the local port.
Indicates whether MDI power is supported on the local port.
Indicates whether MDI power is enabled on the local port.
Derived from the value of the pethPsePortPowerPairsControlAbility object (defined in IETF RFC 3621), this value is used to indicate whether pair selection can be controlled on the local port.
This object contains the value of the pethPsePortPowerPairs object (defined in IETF RFC 3621) for the local port: • signal • spare
This object contains the value of the pethPsePortPowerClassifications object (defined in IETF RFC 3621) for the local port: class0 class1 class2 class3 class4

Viewing LLDP link aggregation properties

With the Local Link Aggregate tab, you can view LLDP link aggregation properties for the local system.

To view the Local Link Aggregate tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click **Port dot3**.
- 5. Select the Local Link Aggregate tab.

The following table outlines the parameters of the **Port dot3 Local Link Aggregate** tab.

Table 180: Variable definitions

Variable	Value
PortNum	Port number.
LinkAggStatus	Specifies the link aggregation capabilities and the current aggregation status of the link.
LinkAggPortId	Contains the IEEE 802.3 aggregated port identifier, aAggPortID (IEEE 802.3-2002, 30.7.2.1.1), derived from the ifNumber of the ifIndex for the port component in link aggregation. If the port is not in a link aggregation state or does not support link aggregation, this value is set to zero.

Viewing LLDP maximum frame size properties

With the Local Max Frame tab, you can view LLDP maximum frame size properties for the local system.

To view the Local Max Frame tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.

- 4. From the 802.1AB tree, double-click Port dot3.
- 5. Select the Local Max Frame tab.

The following table outlines the parameters of the **Port dot3 Local Max Frame** tab.

Table 181: Variable definitions

Variable	Value
PortNum	port number
MaxFrameSize	maximum frame size for the port

Viewing LLDP neighbor auto-negotiation properties

With the Neighbor Port Auto-Negotiation tab, you can view LLDP auto-negotiation properties for the remote system.

To view the Neighbor Port Auto-Negotiation tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Diagnostics.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port dot3.
- 5. Select the **Neighbor Port Auto-negotiation** tab.

The following table outlines the parameters of the **Port dot3 Neighbor Port Autonegotiation** tab.

Table 182: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
AutoNegSupported	The truth value used to indicate whether the given port (associated with a remote system) supports Auto-negotiation.
AutoNegEnabled	Indicates whether Auto-negotiation is enabled on the remote port.

Variable	Value
AutoNegAdvertisedCap	This object contains the value (bitmap) of the ifMauAutoNegCapAdvertisedBits object (defined in IETF RFC 3636) associated with the remote port.
OperMauType	A value that indicates the operational MAU type of the given port on the remote system.

Viewing LLDP neighbor PoE properties

With the Neighbor PoE tab, you can view LLDP PoE properties for the remote system.

To view the Neighbor PoE tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click Port dot3.
- 5. Select the **Neighbor PoE** tab.

The following table outlines the parameters of the **Port dot3 Neighbor PoE** tab.

Table 183: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
PowerPortClass	Identifies the port Class of the remote port.
PowerMDISupported	Indicates whether MDI power is supported on the remote port.
PowerMDIEnabled	Indicates whether MDI power is enabled on the remote port.
PowerPairControlable	Derived from the value of the pethPsePortPowerPairsControlAbility object (defined in IETF RFC 3621), this value is used to indicate whether pair selection can be controlled on the remote port.
PowerPairs	This object contains the value of the pethPsePortPowerPairs object (defined in IETF RFC 3621) for the remote port.

Variable	Value
	• signal
	• spare
PowerClass	This object contains the value of the pethPsePortPowerClassifications object (defined in IETF RFC 3621) for the remote port.
	• class0
	• class1
	• class2
	• class3
	• class4

Viewing LLDP neighbor link aggregation properties

With the Neighbor Link Aggregate tab, you can view LLDP link aggregation properties for the remote system.

To view the Neighbor Link Aggregate tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port dot3.
- 5. Select the Neighbor Link Aggregate tab.

The following table outlines the parameters of the Port dot3 Neighbor Link Aggregate tab.

Table 184: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.

Variable	Value
LinkAggStatus	Specifies the link aggregation capabilities and the current aggregation status of the remote link.
LinkAggPortId	Contains the IEEE 802.3 aggregated port identifier, aAggPortID (IEEE 802.3-2002, 30.7.2.1.1), derived from the ifNumber of the ifIndex for the port component in link aggregation. If the port is not in a link aggregation state or does not support link aggregation, this value is set to zero.

Viewing LLDP neighbor maximum frame size properties

With the Neighbor Max Frame tab, you can view LLDP maximum frame size properties for the remote system.

To view the Neighbor Max Frame tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port dot3.
- 5. Select the Neighbor Max Frame tab.

The following table outlines the parameters of the **Port dot3 Neighbor Max Frame** tab.

Table 185: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
MaxFrameSize	Maximum Frame Size for the remote port.

LLDP Port MED configuration using Enterprise Device Manager

You can use the LLDP Port med dialog box to configure and view MED LLDP information. For details, refer to the following tabs:

- Viewing local policy properties on page 309
- Local Location on page 310
- Viewing LLDP local PoE PSE properties on page 314
- Viewing LLDP neighbor capabilities properties on page 314
- Viewing LLDP neighbor policy properties on page 315
- Viewing LLDP neighbor location properties on page 317
- Viewing LLDP neighbor PoE properties on page 318
- Viewing LLDP neighbor PoE PSE properties on page 319
- Viewing LLDP neighbor PoE PD properties on page 320
- Viewing LLDP neighbor inventory properties on page 321

Viewing local policy properties

With the Local Policy tab, you can view LLDP policy properties for the local system.

To open the Local Policy tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port MED.
- Select the Local Policy tab.
- 6. Click **Insert**. The **Insert Local Policy** dialog box appears.
- 7. Enter the parameters according to the Variable definitions table.
- 8. Click Insert.

The following table outlines the parameters of the **Port MED Local Policy** tab.

Table 186: Variable definitions

Variable	Value
PortNum	Port number.
PolicyAppType	Voice or voice-signaling application type.
PolicyVlanID	An extension of the VLAN Identifier for the port, as defined in IEEE 802.1P-1998. A value of 1 through 4094 is used to define a valid PVID. A value of 0 is used if the device is using priority tagged frames, meaning that only the 802.1p priority level is significant and the default VID of the ingress port is being used instead. A value of 4095 is reserved for implementation use.
PolicyPriority	Indicates the value of the 802.1p priority which is associated with the local port.
PolicyDscp	This object contains the value of the Differentiated Service Code Point (DSCP) as defined in IETF RFC 2474 and RFC 2475 that is associated with the given port on the local system.
PolicyTagged	A value of true indicates that the application is using a tagged VLAN. A value of false indicates that for the specific application, the device is using an untagged VLAN or does not support a port based VLAN operation. In this case, both the VLAN ID and the Layer 2 priority fields are ignored, and only the DSCP value has relevance.

Local Location

This section contains information about the following topics:

- Viewing local location properties on page 310
- Viewing coordinate-based location details on page 311
- Viewing civic address location details on page 312

Viewing local location properties

With the Local Location tab, you can view LLDP location properties for the local system.

To open the Local Location tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.

- 4. From the 802.1AB tree, double-click Port MED.
- 5. Select the **Local Location** tab.

The following table outlines the parameters of the **Port MED Local Location** tab.

Table 187: Variable definitions

Variable	Value
PortNum	Port number.
LocationSubtype	The location subtype advertised by the remote device: • unknown • coordinateBased • civicAddress • elin
LocationInfo	The location information. The parsing of this information is dependent on the value LocationSubtype.

Viewing coordinate-based location details

You can select and view or configure details for coordinate-based locations listed on the Local Location tab.

To view or configure details for coordinate-based locations:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port MED.
- 5. Select the **Local Location** tab.
- 6. Select a location with the LocationSubtype listed as coordinateBased.

The Location Detail button is activated.

- 7. Click the **Location Detail** button to view or configure the local detailed location information. The **Insert Local Location** dialog box appears.
- 8. Enter the parameters according to the Variable definitions table.
- 9. Click Ok.

The following table outlines the parameters of the **Port MED Coordinate Based Location** dialog box.

Table 188: Variable definitions

Variable	Value
Latitude	Specifies the latitude in degrees, and its relation to the equator (North or South).
Longitude	Specifies the longitude in degrees, and its relation to the prime meridian (East or West).
Altitude	Specifies the altitude, and the units of measurement used (meters or floors).
Map Datum	Specifies the reference datum. The format can be one of the following:
	WGS84: World Geodesic System 1984, Prime Meridian Name: Greenwich
	NAD83/NAVD88 North American Datum 1983/ North American Vertical Datum of 1988
	NAD83/MLLW: North American Datum 1983/ Mean Lower Low Water
	•

Viewing civic address location details

You can select and view or configure details for civic address locations listed on the Local Location tab.

Prerequisites

- Open one of the supported Web browsers.
- Access the switch.
- Click the Configuration arrowhead to open the navigation tree.

To view and configure details for civic address locations:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port MED.
- 5. Select the **Local Location** tab.
- 6. Select a location with the **LocationSubtype** listed as civicAddress

The Location Detail button is activated.

7. Click the Location Detail button.

The Civic Address Location dialog box opens.

- 8. Enter details and click OK.
- 9. Click Close.

The following table outlines the parameters of the Port MED Civic Address Location dialog

Table 189: Variable definitions

Variable	Value
Country Code	Country code (2 upper case letters)
State	National subdivisions (state, canton, region)
County	County, parish, gun (JP), district (IN)
City	City, township, shi (JP)
City District	City division, city district, ward
Block (Neighborhood, block)	Neighborhood, block
Street	Street
Leading street direction	Leading street direction
Trailing street suffix	Trailing street suffix
Street suffix	Street suffix
House number	House number
House number suffix	House number suffix
Landmark or vanity address	Landmark or vanity address
Additional Location info	Additional location information
Name (Residence and office occupant)	Residence and office occupant
Postal/Zip code	Postal/Zip code
Building (structure)	Building (structure)
Apartment (suite)	Unit number (apartment, suite)
Floor	Floor
Room number	Room number
Place type	Office
Postal community name	Postal community name

Variable	Value
Post office box P.O.Box	Post office box
Additional Code	Additional code

Viewing LLDP local PoE PSE properties

With the Local PoE PSE tab, you can view LLDP PoE PSE properties for the local system.

To view the Local PoE PSE tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port MED.
- 5. Select the Local PoE PSE tab.

The following table outlines the parameters of the **Port MED Local PoE PSE** tab.

Table 190: Variable definitions

Variable	Value
PortNum	Port number.
PSEPortPowerAvailable	This object contains the value of the power available (in units of 0.1 watts) from the PSE through this port.
PSEPortPDPriority	Indicates the PD power priority that is advertised on this PSE port:
	unknown: priority is not configured or known by the PD
	• critical: the device advertises its power priority as critical, see RFC 3621
	high: the device advertises its power priority as high, see RFC 3621
	• low: the device advertises its power priority as low, see RFC 3621

Viewing LLDP neighbor capabilities properties

With the Neighbor Capabilities tab, you can view LLDP capabilities properties for the remote system.

To view the Neighbor Capabilities tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click **Port MED**.
- 5. Select the Neighbor Capabilities tab.

The following table outlines the parameters of the **Port MED Neighbor Capabilities** tab.

Table 191: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
CapSupported	Identifies the MED system capabilities supported on the remote system.
CapCurrent	Identifies the MED system capabilities that are enabled on the remote system.
DeviceClass	Remote MED device class.

Viewing LLDP neighbor policy properties

With the Neighbor Policy tab, you can view LLDP policy properties for the remote system.

To view the Neighbor Policy tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click **Port MED**.
- 5. Select the **Neighbor Policy** tab.

The following table outlines the parameters of the **Port MED Neighbor Policy** tab.

Table 192: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
PolicyVlanID	An extension of the VLAN Identifier for the port, as defined in IEEE 802.1P-1998. A value of 1 through 4094 is used to define a valid PVID. A value of 0 is used if the device is using priority tagged frames, meaning that only the 802.1p priority level is significant and that the default VID of the ingress port is being used instead. A value of 4095 is reserved for implementation use.
PolicyPriority	Indicates the value of the 802.1p priority which is associated with the remote system connected to the port.
PolicyDscp	This object contains the value of the Differentiated Service Code Point (DSCP) as defined in IETF RFC 2474 and RFC 2475 that is associated with the remote system connected to the port.
PolicyUnknown	A value of true indicates that the network policy for the specified application type is currently unknown. In this case, the VLAN ID, the Layer 2 priority, and the DSCP value fields are ignored. A value of false indicates that this network policy is defined.
PolicyTagged	A value of true indicates that the application is using a tagged VLAN. A value of false indicates that for the specific application, the device is using an untagged VLAN or does not support a port based VLAN operation. In this case, both the VLAN ID and the Layer 2 priority fields are ignored, and only the DSCP value has relevance.

Neighbor Location

This section contains information about the following topics:

- Viewing LLDP neighbor location properties on page 317
- Viewing coordinate-based location details on page 317
- Viewing civic address location details on page 318

Viewing LLDP neighbor location properties

With the Neighbor Location tab, you can view LLDP location properties for the remote system.

To view the Neighbor Location tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click Diagnostics.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click **Port MED**.
- 5. Select the **Neighbor Location** tab.

The following table outlines the parameters of the **Port MED Neighbor Location** tab.

Table 193: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
LocationSubtype	The location subtype advertised by the remote device: • unknown • coordinateBased • civicAddress • elin
LocationInfo	The location information advertised by the remote device. The parsing of this information is dependent on the location subtype.

Viewing coordinate-based location details

From the Neighbor Location tab, you can select coordinate-based locations and view details for the remote system.

To view coordinate-based location details:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port MED.
- 5. Select the **Neighbor Location** tab.
- Select a location with the LocationSubtype listed as coordinateBased
 The Location Details button is activated.
- 7. Click the Location Details button.

The Coordinate Based Location window displays the selected location details.

8. Click Close.

Viewing civic address location details

From the Neighbor Location tab, you can select civic address locations and view details for the remote system.

To view civic address location details:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click 802.1AB.
- 4. From the 802.1AB tree, double-click Port MED.
- 5. Select the **Neighbor Location** tab.
- 6. Select a location with the **LocationSubtype** listed as civicAddress

The Location Details button is activated.

7. Click the Location Details button.

The Civic Address Location window displays the selected location details.

8. Click Close.

Viewing LLDP neighbor PoE properties

With the Neighbor PoE tab, you can view LLDP PoE properties for the remote system.

To view the Neighbor PoE tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click **Port MED**.
- 5. Select the **Neighbor PoE** tab.

The following table outlines the parameters of the **Port MED Neighbor PoE** tab.

Table 194: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
PoEDeviceType	The type of PoE device.

Viewing LLDP neighbor PoE PSE properties

With the Neighbor PoE PSE tab, you can view LLDP PoE PSE properties for the remote system.

To view the Neighbor PoE PSE tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click **Port MED**.
- 5. Select the **Neighbor PoE PSE** tab.

The following table outlines the parameters of the **Port MEDNeighbor PoE PSE** tab.

Table 195: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
PSEPowerAvailable	Specifies the power available (in units of 0.1 watts) from the PSE connected remotely to this port.
PSEPowerSource	Defines the type of PSE Power Source advertised by the remote device.
	primary: indicates that the device advertises its power source as primary.
	backup: indicates that the device advertises its power source as backup.
PSEPowerPriority	Specifies the priority advertised by the PSE connected remotely to the port:
	critical: indicates that the device advertises its power priority as critical, see RFC 3621.
	high: indicates that the device advertises its power priority as high, see RFC 3621.
	low: indicates that the device advertises its power priority as low, see RFC 3621.

Viewing LLDP neighbor PoE PD properties

With the Neighbor PoE PD tab, you can view LLDP PoE PD properties for the remote system.

To view the Neighbor PoE PD tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.

- 4. From the 802.1AB tree, double-click **Port MED**.
- 5. Select the **Neighbor PoE PD** tab.

The following table outlines the parameters of the **Port MED Neighbor PoE PD** tab.

Table 196: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
PDPowerReq	Specifies the value of the power required (in units of 0.1 watts) by a Powered Device (PD) connected remotely to the port.
PDPowerSource	Defines the type of Power Source advertised as being used by the remote device:
	fromPSE: indicates that the device advertises its power source as received from a PSE.
	local: indicates that the device advertises its power source as local.
	localAndPSE: indicates that the device advertises its power source as using both local and PSE power.
PDPowerPriority	Defines the priority advertised as being required by the PD connected remotely to the port:
	• critical: indicates that the device advertises its power priority as critical, see RFC 3621.
	high: indicates that the device advertises its power priority as high, see RFC 3621.
	low: indicates that the device advertises its power priority as low, see RFC 3621.

Viewing LLDP neighbor inventory properties

With the Neighbor Inventory tab, you can view LLDP Inventory properties for the remote system.

To view the Neighbor Inventory tab:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **Diagnostics**.
- 3. From the Diagnostics tree, double-click **802.1AB**.
- 4. From the 802.1AB tree, double-click Port MED.
- 5. Select the **Neighbor inventory** tab.

The following table outlines the parameters of the **Port MED Neighbor Inventory** tab.

Table 197: Variable definitions

Variable	Value
TimeMark	The TimeFilter for this entry.
LocalPortNum	Identifies the local port on which the remote system information is received.
Index	An arbitrary local integer value used by this agent to identify a particular MSAP. An agent is encouraged to assign monotonically increasing index values to new entries, starting with one, after each reboot.
HardwareRev	The vendor-specific hardware revision string as advertised by the remote device.
FirmwareRev	The vendor-specific firmware revision string as advertised by the remote device.
SoftwareRev	The vendor-specific software revision string as advertised by the remote device.
SerialNum	The vendor-specific serial number as advertised by the remote device.
MfgName	The vendor-specific manufacturer name as advertised by the remote device.
ModelName	The vendor-specific model name as advertised by the remote device.
AssetID	The vendor-specific asset tracking identifier as advertised by the remote device.

322 Configuration — System October 2012

LLDP MED policy management using Enterprises Device Manager

Use the information in this section to view, create, and edit LLDP MED policies for the switch.

Navigation

- Viewing LLDP MED policies on page 323
- Creating LLDP MED policies on page 324
- Editing LLDP MED policies on page 326
- Deleting LLDP MED policies on page 327

Viewing LLDP MED policies

Use this procedure to view LLDP MED policy properties for the local system.

Procedure steps

- 1. Open one of the supported browsers.
- 2. Enter the IP address of the switch to open an EDM session.
- 3. From the navigation tree, double-click Edit.
- 4. In the Edit tree, double-click Diagnostics.
- 5. In the Diagnostic tree, double-click **802.1AB**.
- 6. In the 802.1AB tree, double-click **Port MED**.
- 7. In the work area, click the **Local Policy** tab.

Use the data in the following table to help you understand the LLDP MED local policy display.

Table 198: Variable definitions

Field	Description
PortNum	Indicates the port number
PolicyAppType	Shows the policy application type.

Field	Description
PolicyVlanID	Indicates the extension of the VLAN Identifier for the port, as defined in IEEE 802.1P-1998. A value of 1 through 4094 is used to define a valid PVID. A value of 0 is used if the device is using priority tagged frames, meaning that only the 802.1p priority level is significant and the default VID of the ingress port is being used instead. A value of 4095 is reserved for implementation use.
PolicyPriority	Indicates the value of the 802.1p priority which is associated with the local port.
PolicyDscp	Contains the value of the Differentiated Service Code Point (DSCP) as defined in IETF RFC 2474 and RFC 2475 that is associated with the given port on the local system.
PolicyTagged	Indicates whether the application is using a tagged VLAN, untagged VLAN, or does not support a port based VLAN operation.

Creating LLDP MED policies

Use this procedure to create a new LLDP MED policy for the local system.

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. In the Edit tree, double-click **Diagnostics**.
- 3. In the Diagnostic tree, double-click **802.1AB**.
- 4. In the 802.1AB tree, double-click **Port MED**.
- 5. In the work area, click the **Local Policy** tab.
- 6. Click Insert.
- 7. To select a port to create a policy for, click the **PortNum** elipsis.
- 8. Click Ok.
- 9. In the **PolicyAppType** section, select one or both boxes.
- 10. To select a VLAN identifier for the selected port, click the **PolicyVlanID** elipsis.
- 11. Click Ok .
- 12. Double-click the **PolicyPriority** box.
- 13. Type a priority value.

- 14. Double-click the **PolicyDscp** box.
- 15. Type a DSCP value.
- 16. To use a tagged VLAN, click the **PolicyTagged** box.

OR

To use an untagged VLAN, clear the **PolicyTagged** box.

17. Click Insert.

Use the data in the following table to create a new LLDP MED policy for the local system.

Table 199: Variable definitions

Field	Description
PortNum	Specifies the port on which to configure LLDP MED policies.
PolicyAppType	Specifies the policy application type.
	voice—selects the voice network policy
	voiceSignaling—selects the voice signaling network policy
PolicyVlanID	Specifies the VLAN identifier for the selected port or ports. Values range from 1–4094. If you select priority tagged frames, the system recognizes only the 802.1p priority level and uses a value of 0 for the VLAN ID of the ingress port.
PolicyPriority	Specifies the value of the 802.1p priority that applies to the selected switch port or ports. Values range from 0–7.
PolicyDscp	Specifies the value of the Differentiated Service Code Point (DSCP) as defined in IETF RFC 2474 and RFC 2475 that is associated with the selected switch port or ports. Values range from 0–63.
PolicyTagged	Specifies the type of VLAN tagging to apply on the selected switch port or ports.
	when selected—uses a tagged VLAN
	when cleared—uses an untagged VLAN or does not support port-based VLANs.
	If you select untagged, the system ignores the VLAN ID and priority values, and recognizes only the DSCP value.

Editing LLDP MED policies

Use this procedure to edit a previously configured LLDP MED policy for the local system.

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. In the Edit tree, double-click **Diagnostics**.
- 3. In the Diagnostic tree, double-click 802.1AB.
- 4. In the 802.1AB tree, double-click Port MED.
- 5. To select a policy to edit, click the PortNum.
- 6. In the policy row, double-click the cell in the Policy VlanID column.
- 7. Select a VLAN from the list.
- 8. Click Ok.
- 9. In the policy row, double-click the cell in the **PolicyPriority** column.
- 10. Edit the policy priority value.
- 11. In the policy row, double-click the cell in the **PolicyDscp** column.
- 12. Edit the policy DSCP value.
- 13. In the policy row, double-click the cell in the **PolicyTagged** column.
- 14. Select a value from the list.
- 15. On the toolbar, click **Apply**.

Use the data in the following table to edit a previously configured LLDP MED policy for the local system.

Table 200: Variable definitions

Field	Description
PortNum	Indicates the port on which to configure LLDP MED policies. This is a read-only cell.
PolicyAppType	Indicates the policy application type. This is a read-only cell.
	voice— voice network policy
	voiceSignaling— voice signaling network policy
PolicyVlanID	Specifies the VLAN identifier for the selected port or ports. Values range from 1–4094. If you select priority tagged frames, the system recognizes only the 802.1p priority level and

326 Configuration — System October 2012

Field	Description
	uses a value of 0 for the VLAN ID of the ingress port.
PolicyPriority	Specifies the value of the 802.1p priority that applies to the selected switch port or ports. Values range from 0–7.
PolicyDscp	Specifies the value of the Differentiated Service Code Point (DSCP) as defined in IETF RFC 2474 and RFC 2475 that is associated with the selected switch port or ports. Values range from 0–63.
PolicyTagged	Specifies the type of VLAN tagging to apply on the selected switch port or ports.
	• true—uses a tagged VLAN
	false—uses an untagged VLAN or does not support port-based VLANs.
	If you select untagged, the system ignores the VLAN ID and priority values, and recognizes only the DSCP value.

Deleting LLDP MED policies

Use this procedure to delete a LLDP MED policy.

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. In the Edit tree, double-click **Diagnostics**.
- 3. In the Diagnostic tree, double-click 802.1AB.
- 4. In the 802.1AB tree, double-click **Port MED**.
- 5. In the work area, click the **Local Policy** tab.
- 6. To select a policy to delete, click the PortNum.
- 7. On the toolbar, click **Delete**.

SNTP configuration using Enterprise Device Manager

The SNTP/Clock screen contains the parameters for configuring Simple Network Time Protocol (SNTP).

This section provides information about the following topics:

- Displaying the Simple Network Time Protocol tab on page 328
- Setting the local time zone on page 329
- Configuring daylight savings time on page 330
- Displaying the Summer Time Recurring tab on page 331

Displaying the Simple Network Time Protocol tab

To open the Simple Network Time Protocol tab:

Procedure steps

- 1. From the navigation tree, double-click Edit.
- 2. From the Edit tree, double-click SNTP/Clock.
- 3. Select the **Simple Network Time Protocol** tab.
- 4. Enter the fields as indicated by the table.
- 5. Click Refresh.

The following table outlines the parameters of the **Simple Network Time Protocol** tab.

Table 201: Variable definitions

Variable	Value
PrimaryServerInet AddressType	The IP address type (IPv4 or IPv6) of the primary SNTP server.
PrimaryServerInet Address	The IP address of the primary SNTP server.
SecondaryServerInet AddressType	The IP address type (IPv4 or IPv6) of the secondary SNTP server.
SecondaryServerInet Address	The IP address of the secondary SNTP server.
State	Controls whether the device uses the Simple Network Time Protocol to synchronize the device clock to the Coordinated Universal Time. If the value is disabled, the device does not synchronize its clock using SNTP. If the value is unicast, the device synchronizes shortly after boot time when network access becomes available, and periodically thereafter.
SynchInterval	Controls the frequency, in hours, with which the device attempts to synchronize with the NTP servers.
ManualSynch Request	Specifies that the device must immediately attempt to synchronize with the NTP servers.

328 Configuration — System October 2012

Variable	Value
LastSynch Time	Specifies the UTC when the device last synchronized with an NTP server.
LastSyncSourceInet AddressType	Specifies the IP source address type (IPv4 or IPv6) of the NTP server with which this device last synchronized.
LastSyncSourceInet Address	Specifies the IP source address of the NTP server with which this device last synchronized.
NextSynch Time	Specifies the UTC at which the next synchronization is scheduled.
PrimaryServer SynchFailures	Specifies the number of times the switch failed to synchronize with the primary server address. However, synchronization with the secondary server address can still occur.
SecondaryServer SynchFailures	Specifies the number of times the switch failed to synchronize with the secondary server address.
CurrentTime	Specifies the UTC for the switch.

Setting the local time zone

To set the local time zone:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **SNTP/Clock**.
- 3. Select the **Time Zone** tab.
- 4. Type the time zone offset in the **TimeZone** box.
- 5. Type a time zone acronym in the **TimeZoneAcronym** box.
- 6. Click Apply.

The following table outlines the parameters of the **Time Zone** tab.

Table 202: Variable definitions

Variable	Value
TimeZone	Specifies the time zone of the switch, measured as an offset in 15-minute increments from Greenwich mean Time (GMT).
TimeZoneAcronym	Enter the acronym for your time zone: example, EST for Eastern Time Zone in North America.

Configuring daylight savings time

To set daylight saving start and end time:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click **SNTP/Clock**.
- 3. Select the **Daylight Saving Time** tab.
- 4. Type the number of minutes to shift the clock in the **Offset** box.
- 5. Type the time zone acronym for the change in the **TimeZoneAcronym** box.
- 6. Select the **StartYear**, **StartMonth**, **StartDate**, **StartHour** and type the **StartMinutes** (if applicable) to define when to switch the clock to daylight saving time.
- 7. Select the **EndYear**, **EndMonth**, **EndDate**, **EndHour** and type the **EndMinutes** (if applicable) to define when to switch the clock back to normal time. If you want to keep the same daylight saving time changeover dates, you can set the **EndYear** to a year in the future.
- 8. Click **Enabled** to enable daylight savings time.
- 9. Click Apply.

The following table outlines the parameters of the **Daylight Saving Time** tab.

Table 203: Variable definitions

Variable	Value
Offset	Specifies the time in minutes by which you want to change the time when daylight savings begins and ends.
TimeZoneAcronym	Specifies a time zone acronym.
StartYear	Specifies the year from when you want to start the daylight savings time.
StartMonth	Specifies the month of each year from when you want to start the daylight savings time.
StartDay	Specifies the day of the particular month from when you want to start the daylight savings time.
StartHour	Specifies the hour of the particular day from when you want to start the daylight savings time.
StartMinutes	Specifies the minutes of the particular hour from when you want to start the daylight savings time.
EndYear	Specifies the year when to end the daylight savings time.

Variable	Value
EndMonth	Specifies the month of each year when to end the daylight savings time.
EndDay	Specifies the day of the particular month when to end the daylight savings time.
EndHour	Specifies the hour of the particular day when to end the daylight savings time.
Enabled	Enables or disables day light saving time.

Displaying the Summer Time Recurring tab

To set summer time recurring:

Procedure steps

- 1. From the navigation tree, double-click **Edit**.
- 2. From the Edit tree, double-click SNTP/Clock.
- 3. Select the **Summer Time Recurring** tab.

The following table outlines the parameters of the **Summer Time Recurring** tab.

Table 204: Variable definitions

Variable	Value
RecurringStartMonth	Specifies the month of each year you want recurring daylight savings time to start.
ReucrringStartWeek	Specifies the week of the month you want recurring daylight savings time to start.
RecurringStartDay	Specifies the day of the particular month you want recurring daylight savings time to start.
RecurringStartHour	Specifies the hour of the particular day you want recurring daylight savings time to start.
RecurringStartMinute	Specifies the minutes of the particular hour you want recurring daylight savings time to start.
RecurringEndMonth	Specifies the month of each year you want recurring daylight savings time to end.
RecurringEndWeek	Specifies the week of the month you want recurring daylight savings time to end.
RecurringEndDay	Specifies the day of the particular month you want recurring daylight savings time to end.

Variable	Value
RecurringEndHour	Specifies the hour of the particular day you want recurring daylight savings time to end.
RecurringEndMinute	Specifies the minutes of the particular hour you want recurring daylight savings time to end.
RecurringOffset	Specifies the time in minutes by which you want to change the time when recurring daylight savings begins and ends. The offset is added to the current time when daylight saving time begins and subtracted from the current time when daylight saving time ends.

Power over Ethernet configuration with Enterprise Device Manager

You can view and configure Power over Ethernet (PoE) for a unit or a port with Enterprise Device Manager.

Navigation

- Viewing global PoE properties for a unit on page 332
- Viewing PoE properties for a port on page 333

Viewing global PoE properties for a unit

To view the Globals - PoE Units tab:

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. From the Power Management tree, double-click **PoE**.
- 3. Select the Globals PoE Units tab.

The following table outlines the parameters of the **Globals - PoE Units** tab.

Table 205: Variable definitions

Variable	Value
Unit	Specifies the unit number in the stack.

Variable	Value
Power(watts)	Specifies the power in Watts.
OperStatus	Specifies whether PoE is enabled
ConsumptionPower(watt s)	Specifies the power consumption in Watts.
UsageThreshold%	Specifies the usage threshold expressed as a percentage for comparing the measured power and initiating an alarm if the threshold is exceeded.
NotificationControlEnable	Controls, on a per-group basis, whether or not notifications from the agent are enabled. The value true(1) means that notifications are enabled; the value false(2) means that they are not.
PoweredDeviceDetectTy pe	Specifies the mechanism used to detect powered ethernet devices attached to a powered ethernet port. This object should only be instantiated for values of ifIndex that represent ports that support powered ethernet.

For more information, see Displaying the PoE tab for a single unit on page 223.

Viewing PoE properties for a port

To view the PoE Ports tab:

Procedure steps

- 1. From the navigation tree, double-click **Power Management**.
- 2. From the Power Management tree, double-click **PoE**.
- 3. Select the **PoE Ports** tab.

The following table outlines the parameters of the **PoE Ports** tab.

Table 206: Variable definitions

Variable	Value
Unit	Indicates the switch position in a stack.
Port	Indicates the switch port number.
AdminEnable	Use this function to enable or disable Power over Ethernet on this port. PoE is enabled by default.
PowerPairs	This is a read-only field that displays the status of the RJ-45 pin pairs that the switch uses to send power to the ports on the switch.

Variable	Value
DetectionStatus	Displays the operational status of the power-device detecting mode on the specified port as follows:
	disabled, detecting function disabled
	searching, detecting function is enabled and the system is searching for a valid powered device and the port is delivering power
	fault, power-specific fault detected on port
	test, detecting device in test mode
	otherFault
	Important:
	Avaya recommends against using the test operational status.
PowerClassifications	You can use classifications to tag different terminals on the Power over LAN network according to their power consumption. Devices such as IP telephones, WLAN access points, and others can be classified according to their power requirements.
PowerPriority	You can set the power priority for the specified port to:
	• critical
	• high
	• low
PowerLimit(watts)	Specifies the maximum power that the switch can supply to a port. The default value is 16W.
Voltage(volts)	Indicates the voltage, measured in Volts.
Current(amps)	Indicates the current, measured in Amps.
Power(watts)	Indicates the power, measured in Watts.

For more information, see Viewing the PoE power settings on page 238.

IPv6 configuration using Enterprise Device Manager

To open the IPv6 dialog box:

Procedure steps

- 1. From the navigation tree, double-click IPv6.
- 2. From the IPv6 tree, double-click IPv6.

This section contains information about the following topics:

- Configuring IPv6 global properties on page 335
- Displaying the ICMP Stats tab on page 336
- Displaying the ICMP Msg Stats tab on page 336

Configuring IPv6 global properties

To configure IPv6 global properties:

Procedure steps

- 1. From the navigation tree, double-click **IPv6**.
- 2. From the IPv6 tree, double-click IPv6.
- 3. Select the Globals tab.
- 4. Enter the global properties in the boxes.
- 5. Click **Apply** to save the changes.
- 6. Click **Refresh** to display updated information.

The following table outlines the parameters of the **Globals** tab.

Table 207: Variable definitions

Variable	Value
AdminEnabled	Check this box to enable the administration function.
OperEnabled	True or false
Forwarding	notForwarding or Forwarding
DefaultHopLimit	Default number of hops: 30
IcmpNetUnreach	Enables or disables the ICMP net unreach feature.
IcmpRedirectMsg	True or false
IcmpErrorInterval	Time to wait before sending an ICMP error message. A value of 0 means the system does not send an ICMP error message. Value: 0 to 2147483647 ms
IcmpErrorQuota	Default value: 1
MulticastAdminStatus	True or false

Displaying the ICMP Stats tab

To display the IPv6 interface ICMP statistics:

Procedure steps

- 1. From the navigation tree, double-click **IPv6**.
- 2. From the IPv6 tree, double-click IPv6.
- 3. Select the ICMP Stats tab.
- 4. Click Clear Counters to reset the statistics.
- 5. Set the Poll interval.

The following table outlines the parameters for the **ICMP Stats** window.

Table 208: Variable definitions

Variable	Value
InMsgs	Number of ICMP messages received.
InErrors	Number of ICMP error messages received.
OutMsgs	Number of ICMP messages sent.
OutErrors	Number of ICMP error messages sent.
Poll Interval	Sets polling interval. Value: 2 to 60 s.

Displaying the ICMP Msg Stats tab

To display the IPv6 interface ICMP message statistics:

Procedure steps

- 1. From the navigation tree, double-click IPv6.
- 2. From the IPv6 tree, double-click IPv6.
- 3. Select the ICMP Msg Stats tab.
- 4. Click **Refresh** to update the ICMP message statistics.

The following table outlines the parameters for the **ICMP Msg Stats** window.

Table 209: Variable definitions

Variable	Value
Туре	Type of packet received or sent.
InPkts	Number of packets received.


Variable	Value
OutPkts	Number of packets sent.

Viewing SFP GBIC ports

The details of an SFP GBIC port are only available if the port is active.

To view the SFP GBIC ports:

- 1. From the **Device Physical View**, click a unit.
- 2. From the navigation tree, double-click **Edit**.
- 3. In the Edit tree, double click **Chassis**.
- 4. In the Chassis tree, double-click **Ports**.



Chapter 8: Configuration reference

Factory default configuration

When a newly installed switch is initially accessed or a switch is reset to factory defaults, the switch is in a factory default configuration. This factory default configuration is the base configuration from which the switch configuration is built.

Table 210: Factory default configuration settings on page 339 outlines the factory default configuration settings present in a switch in a factory default state.

Table 210: Factory default configuration settings

Setting	Factory Default Configuration Value
Unit Select switch	non-Base
Unit	1
BootP Request Mode	BootP When Needed
In-Band Stack IP Address	0.0.0.0 (no IP address assigned)
In-Band Switch IP Address	0.0.0.0 (no IP address assigned)
In-Band Subnet Mask	0.0.0.0 (no subnet mask assigned)
Default Gateway	0.0.0.0 (no IP address assigned)
Read-Only Community String	public
Read-Write Community String	private
Trap IP Address	0.0.0.0 (no IP address assigned)
Community String	Zero-length string
Authentication Trap	Enabled
Autotopology	Enabled
sysContact	Zero-length string
sysName	Zero-length string
sysLocation	Zero-length string
Aging Time	300 seconds
Find an Address	00-00-00-00-00 (no MAC address assigned)

Setting	Factory Default Configuration Value
Select VLAN ID [1]	
MAC Address Security	Disabled
MAC Address Security SNMP- Locked	Disabled
Partition Port on Intrusion Detected:	Disabled
Partition Time	0 seconds (the value 0 indicates forever)
DA Filtering on Intrusion Detected:	Disabled
Generate SNMP Trap on Intrusion	Disabled
Clear by Ports	NONE
Learn by Ports	NONE
Current Learning Mode	Not Learning
Trunk	blank field
Security	Disabled
Port List	blank field
Find an Address	blank field
MAC Address	00-00 00-00 -00-00
Allowed Source	- (blank field)
Display/Create MAC Address	00-00-00-00-00
Create VLAN	1
Delete VLAN	blank field
VLAN Name	VLAN#
Management VLAN	Yes (VLAN #1)
VLAN Type	Port-based
Protocol ID (PID)	None
User-Defined PID	0x0000
VLAN State	Active (VLAN # 1)
Port Membership	All ports assigned as members of VLAN 1
Unit	1
Port	1
Filter Untagged Frames	No

Setting	Factory Default Configuration Value
Filter Unregistered Frames	Yes
Port Name	Unit 1, Port 1
PVID	1
Port Priority	0
Tagging	Untag All
AutoPVID	Enabled
Unit	1
Port	1
PVID	1 (read only)
Port Name	Unit 1, Port 1 (read only)
Unit	1
Status	Enabled (for all ports)
Linktrap	On
Autonegotiation	Enabled (for all ports)
Speed/Duplex	(Refer to Autonegotiation)
Trunk	1 to 32 (depending on configuration status)
Trunk Members (Unit/Port)	Blank field
STP Learning	Normal
Trunk Mode	Basic
Trunk Status	Disabled
Trunk Name	Trunk #1 to Trunk #32
Traffic Type	Rx and Tx
Port	1
Monitoring Mode	Disabled
Monitor/Unit Port	Zero-length string
Unit/Port X	Zero-length string
Unit/Port Y	Zero-length string
Address A	00-00-00-00-00 (no MAC address assigned)
Address B	00-00-00-00-00 (no MAC address assigned)
Rate Limit Packet Type	Both
Limit	None

Setting	Factory Default Configuration Value
VLAN	1
Snooping	Disabled
Proxy	Disabled
Robust Value	2
Query Time	125 seconds
Set Router Ports	Version 1
Static Router Ports	- (for all ports)
Multicast Group Membership screen	
Unit	1
Port	1
Console Port Speed	9600 Baud
Console Switch Password type	None
Console Stack Password type	None
Telnet Stack Password type	None
Telnet Switch Password type	None
Console Read-Only Switch Password	Passwords are user for non-SSH software images and userpasswd for SSH software images.
Console Read-Write Switch Password	Passwords are secure for non-SSH software images and securepasswd for SSH software images.
Console Read-Only Stack Password	Passwords are user for non-SSH software images and userpasswd for SSH software images.
Console Read-Write Stack Password	Passwords are secure for non-SSH software images and securepasswd for SSH software images.
Radius password/server	secret
New Unit Number	Current stack order
Renumber units with new setting?	No
Group	1
Bridge Priority	8000
Bridge Hello Time	2 seconds
Bridge Maximum Age Time	20 seconds
Bridge Forward Delay	15 seconds

Setting	Factory Default Configuration Value
Add VLAN Membership	1
Tagged BPDU on tagged port	• STP Group 1No
	Other STP GroupsYes
STP Group State	STP Group 1Active
	Other STP GroupsInActive
VID used for tagged BPDU	4001-4008 for STGs 1-8, respectively
STP Group	1
Participation	Normal Learning
Priority	128
Path Cost	1
STP Group	1
STP Group	1
TELNET Access/SNMP	By default, SNMP access is disabled in the SSH image and enabled in the non-SSH image. Telnet is enabled by default in both SSH and non-SSH images. Use list: Yes
Login Timeout	1 minute
Login Retries	3
Inactivity Timeout	15 minutes
Event Logging	All
Allowed Source IP Address (50 user-configurable fields)	First field: 0.0.0.0 (no IP address assigned)
	Remaining 49 fields: 255.255.255.255 (any address is allowed)
Allowed Source Mask (50 user-configurable fields)	First field: 0.0.0.0 (no IP address assigned)
	Remaining 49 fields: 255.255.255.255 (any address is allowed)
Allowed Source IPv6 Address and Allowed Prefix Length (50 user-configurable fields)	First field: ::/0 (no IPv6 address assigned)
	Remaining 49 fields: ffff:ffff:ffff:ffff:ffff:ffff:ffff:f
Image Filename	Zero-length string

Setting	Factory Default Configuration Value
TFTP Server IP Address	0.0.0.0 (no IP address assigned)
Start TFTP Load of New Image	No
Configuration Image Filename	Zero-length string
Copy Configuration Image to Server	No
Retrieve Configuration Image from Server	No
ASCII Configuration Filename	Zero-length string
Retrieve Configuration file from Server	No
Auto Configuration on Reset	Disabled
EAPOL Security Configuration	Disabled
High Speed Flow Control Configuration	
VLAN Configuration Control	Strict
Agent Auto Unit Replacement	Enabled

Index

A	configuration files		
	in ACLI		
AAUR <u>204</u>	On the state Carlot Call		
access			
address field85		<u>49</u>	
address source field85			
AdminState field230	D		
Agent Auto Unit Replacement204			
AUR <u>201</u>	DC power source	62	
configuring with ACLI201	connection		
auto-MDI X48			
autonegotiation48, 88	default duplex command		
description48			
autopolarity48			
autosense description			
Autotopology92	activities process control community in the control co		
configuring with ACLI92			
autotopology command93			
available power223			
available power	doladi. opoda dolililaria ililililaria		
	default telnet-access command		
В	default-gateway field		
	Descr field		
banner command <u>199</u>			
BaseNumPorts field230			
boot command <u>138</u>	DNS		
Bootp <u>36</u>	configuring with ACLI		
BootP85, <u>139</u>	duplex command		
modes	duplex mode		
bootp field85	Dynamic Host Configuration Protocol (DHCP)	<u>40</u>	
Bridge parameter			
Base tab <u>258</u>			
BridgeAddress field258			
NumPorts field258		6	
Type258			
Forwarding tab259		<u>02</u>	
Address field259	·		
Port field259			
Status field259			
broadcast traffic	Tactory detaillt confiditation	<u>33</u> 9	
bioaucast trailic	reature license tile		
	configuring with NNCLI	<u>208</u>	
C	flow control	<u>9</u> 4	
	flowcontrol command	<u>9</u> 4	
CANA <u>49</u> , <u>108</u>		25	
configuring with NNCLI 108			
Clock <u>151</u>			
configuring with ACLI <u>151</u>			

G	no telnet-access command	<u>137</u>	
9	NotificationControlEnable field		
gateway81	NVRAM	<u>76</u>	
GBIC information			
displaying200	0		
Gigabit Ethernet94	O		
<u></u>	OperState field	230 247	
	OperStatus field		
Н	Operotatus field	<u>223</u>	
hardware information201			
	P		
displaying <u>201</u>			
	passwords		
1	setting with NNCLI		
	ping command		
IEEE 802.3u standard	PoE <u>62</u> ,		
interfaces <u>87</u>	available power		
displaying <u>87</u>	configuring with ACLI		
IP address <u>81</u> – <u>83</u> , <u>86</u>	power being used	2 <u>223</u>	
for each unit	error codes	<u>62</u>	
ip address command82	status codes	<u>62</u>	
ip address unit command86	traps	<u>223</u>	
IP blocking <u>80</u>	ports	<u>88</u>	
configuring with ACLI80	power being used	<u>223</u>	
ip bootp server command <u>139</u>	Power field	<u>223</u>	
ip default-gateway command84	power usage traps	<u>223</u>	
IpAddress field230	PowerDetectionMethod fieldtroubleshooting	<u>223</u>	
	power detection method	<u>223</u>	
1	PowerPairs field	<u>223</u>	
L			
LLDP	Q		
Configuring with ACLI	Q.		
Location field	quick configuration	78	
LstChng field230	4		
<u>200</u>			
	R		
M	RADIUS authentication	211	
MDAs94	configuring with ACLI		
multicast traffic96	rate-limit command		
<u>90</u>	rate-limiting		
	Real Time Clock		
N	configuring with NNCLI		
	reload command		
netmask		· · · · · · · · · · · · · · · · · · ·	
no autotopology command <u>93</u>	RelPos field		
no banner command <u>200</u>	requirements		
no flowcontrol command $\underline{95}$	remote access	<u>135</u>	
no ip address command <u>83</u>			
no ip address unit command $\underline{86}$	S		
no ip bootp server command <u>140</u>			
no ip default-gateway <u>84</u>	security	<u>136</u>	
no rate-limit command99	SerNum field	230	

setting TFTP parameters with NNCLI23	IEEE 802.1 organizationally-specific7			
show banner command	IEEE 802.3 organizationally-specific7			
show interfaces command88	Management6			
show ip command85	Organizationally-specific for MED devices7			
show rate-limit command97	TotalNumPorts23			
shutdown command 140	traffic94, 94			
Simple Network Time Protocol <u>100</u>	Gigabit Ethernet94			
Simple Network Time Protocol (SNTP)47	rate-limiting96			
SNTP	Transparent tab25			
configuring with NNCLI 100	traps <u>22</u>			
software	power			
updating <u>23</u>	troubleshooting			
updating with ACLI <u>126</u>	DC power source6			
speed <u>88</u>	power pairs <u>22</u> 3			
speed command88	access <u>83,</u> <u>86</u>			
subnet mask	external power source6			
switch configuration	PoE <u>22</u>			
•	Type field			
т	U			
TDR91	updating software2			
configuring with ACLI91	UsageThreshold field223			
Telnet <u>135, 136</u>	user access limitations			
telnet command111	setting with NNCLI209			
telnet-access command	V			
terminal setup134	•			
testing cables91	Ver field230			
TLVs	VlanIds25			