

Ethernet Routing Switch 4500, 5000, Avaya Business Communications Manager 50, 450, Avaya Communication Server 1000, Avaya Communication Server 2100, Avaya CS 1000 Survivable Remote Gateway 50 Engineering

> Avaya Automatic QoS Technical Configuration Guide for the ERS 4500, 5000, Avaya BCM 50, 450, Avaya CS 1000, Avaya CS 2100 and Avaya SRG 50

Avaya Data Solutions Document Date: October_2010 Document Number: NN48500-576 Document Version: 1.1



© 2010 Avaya Inc. All Rights Reserved.

Netions

Notices

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of this documentation unless such modifications, additions, or deletions were performed by Avaya. End User agree to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation(s) provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on this product. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product, while under warranty, is available to Avaya customers and other parties through the Avaya Support Web site: http://www.avaya.com/support Please note that if you acquired the product from an authorized reseller, the warranty is provided to you by said reseller and not by Avaya.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/ ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER, AND AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Copyright

Except where expressly stated otherwise, no use should be made of the Documentation(s) and Product(s) provided by Avaya. All content in this documentation(s) and the product(s) provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third Party Components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: http://support.avaya.com/Copyright.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the documentation(s) and product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the documentation(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party. Avaya is a registered trademark of Avaya Inc. All non-Avaya trademarks are the property of their respective owners.

Downloading documents

For the most current versions of documentation, see the Avaya Support. Web site: http://www.avaya.com/support.

Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: http://www.avaya.com/support.



Abstract

The purpose of this Technical Configuration Guide (TCG) is to provide configuration examples on various Avaya voice and data products (Ethernet Routing Switch 4500, 5000, Avaya BCM 50, 450, Avaya CS1000, Avaya CS 2100 and Avaya SRG 50) that support Avaya Automatic QoS. Avaya Automatic QoS is a set of capabilities that dramatically simplifies configuration of Quality of Service (QoS) in a network to ensure proper prioritization and forwarding of different traffic types.

Revision Control

No	Date	Version	Revised by	Remarks
1	1/27/2009	1.0	EBS	First External Release



Table of Contents

Conver	ntions	
1. Ov	erview: Avaya Automatic QoS	5
1.1 1.2	Avaya Automatic QoS Edge Mode: ERS 4500 and ERS 5000 Avaya Automatic QoS Support	6 7
2. Av	aya Automatic QoS Configuration	8
2.1	ERS 4500 – Edge Switch	8
2.2	ERS 5000 – Edge Switch	9
2.3	ERS 8600 – Used as Core Switch only	
2.4	ERS 8300 – Used as Core Switch only	
2.5	Avaya BCM 50, Avaya SRG 50, and Avaya BCM 450 Configuration	
2.6	CS1000 – Node Configuration	
2.7	CS 1000 – Media Gateway Controller (MGC) Configuration	
2.8	CS 2100	
2.9	Software Baseline	
3. Cu	stomer service	17
3.1	Getting technical documentation	17
3.2	Getting product training	
3.3	Getting help from a distributor or reseller	17
3.4	Getting technical support from the Avaya Web site	



Conventions

This section describes the text, image, and command conventions used in this document.

Symbols:



Tip – Highlights a configuration or technical tip.



Note - Highlights important information to the reader.



Warning – Highlights important information about an action that may result in equipment damage, configuration or data loss.

Text:

Bold text indicates emphasis.

Italic text in a Courier New font indicates text the user must enter or select in a menu item, button or command:

ERS5520-48T# show running-config

Output examples from Avaya devices are displayed in a Lucinda Console font:

```
ERS5520-48T# show running-config
```

! Embedded ASCII Configuration Generator Script ! Model = Ethernet Routing Switch 5520-24T-PWR ! Software version = v5.0.0.011 enable configure terminal

AVAYA

1. Overview: Avaya Automatic QoS

Avaya Automatic QoS provides application traffic prioritization allowing for the ability to identify and prioritize Avaya application traffic on both an Avaya only or Avaya edge and third party core data infrastructure to provide application aware networking. Avaya application traffic is defined as IP Telephony and Multimedia applications. By identifying Avaya application traffic, Avaya Automatic QoS transparently provides appropriate traffic prioritization handling and in turn improves application performance particularly in times of network congestion. Avaya Automatic QoS is applied end-to-end from the application filters and QoS components across a variety of platforms. Simply enable/disable the appropriate Avaya Automatic QoS mode and all underlying QoS configurations to identify Avaya application traffic are automatically configured. Well known Avaya application traffic that is automatically identified via DSCP values will be given preferential treatment and will be handled by the appropriate egress queue on the Ethernet switching infrastructure.

As shown in the diagram below, dynamic prioritization is provided by enabling Avaya Automatic QoS on the ERS 4500 or ERS 5000 edge access switch and on the Avaya CS 1000, Avaya CS 2100, Avaya BCM, and/or Avaya SRG call servers. In regards to the edge switch, the ERS 4500 or ERS 5000 support dynamic prioritization for either tagged or untagged IP telephony traffic. The only other configuration required on the edge switch is setting the uplink port members attached to the core/distribution layer as trusted port members. In the core, all that is required is enabling the port members as QoS trusted.





Please note that Avaya Automatic QoS configuration on an Avaya switch or Avaya voice application is referred to as Avaya on Avaya configuration in the initial release.



1.1 Avaya Automatic QoS Edge Mode: ERS 4500 and ERS 5000

On the ERS 4500 and ERS 5000, when enabling dynamic prioritization via Avaya Automatic QoS Edge, there are two modes to choose from, mixed mode and pure mode.

In mixed mode, the ERS 4500 or ERS 5000 will recognize and remark the traffic from the attached IP phone, IP Softphone 2050 client or Avaya BCM/Avaya SRG/Avaya CS 1000/Avaya CS 2100 according to values shown in Table 1. As long as the switches used in the core/distribution layer are configured as QoS trusted, these remarked DSCP values will be given preferential treatment and will be handled by the appropriate egress queue.

NT DSCP from IP Phone	Traffic Type	Standard DSCP
0x2F (47)	VoIP Data (Premium)	0x2E (EF)
0x29 (41)	VoIP Signaling (Platinum)	0x28 (CS5)
0x23 (35)	Video (Platinum)	0x22 (AF41)
0x1B (27)	Streaming (Gold)	0x1A (AF31)

Table 1: NT DSCP Mapping Values

Please note that all other traffic types not identified will be handled as normal unidentified traffic and will be remarked as "Standard/Best Effort" with DSCP value of 0x00 and treated as untrusted traffic.

In pure mode, the ERS 4500 or ERS 5000 will recognize and not remark the traffic from the attached IP phone, Avaya 2050 IP Softphone client or Avaya BCM/Avaya SRG/Avaya CS 1000/Avaya CS 2100. Avaya DSCP values will be given preferential treatment and will be handled by the appropriate egress queue and the packet will retain these DSCP values as shown in Table 2.

Table	2: NT	DSCP	Values
-------	-------	------	--------

NT DSCP	Traffic Type
0x2F (47)	VoIP Data (Premium)
0x29 (41)	VoIP Signaling (Platinum)
0x23 (35)	Video (Platinum)
0x1B (27)	Streaming (Gold)



Please note that all other traffic types not identified will be handled as normal unidentified traffic and will be remarked as "Standard/Best Effort" with DSCP value of 0x00 and treated as untrusted traffic.

Avaya Automatic QoS support is envisioned as a multi-phase project. In phase 1 of Avaya Automatic QoS, ADAC, NSNA, Avaya Automatic QoS pure mode, or 802.1AB is not supported simultaneously. This



will be added in subsequent phases of Avaya Automatic QoS. Avaya Automatic QoS Edge (mixed and pure mode) is planned for the ERS 2500 in a future release.

1.2 Avaya Automatic QoS Support

1.2.1 Ethernet Switches – Avaya Automatic QoS Edge Support

Avaya Automatic QoS is available on the Avaya switching platforms shown below.

- ERS 4500
 - Release 5.2
 - Edge with Avaya Automatic QoS mixed or pure mode
- ERS 5000
 - Release 6.0 (not formally supported)
 - Release 6.1 (Q209 with formal support)
 - Edge with Avaya Automatic QoS mixed or pure mode
- ERS 2500
 - o POI Q409

1.2.2 Ethernet Switches – Avaya Automatic QoS Core Support

In order to support Avaya Automatic QoS pure mode (DSCP values maintained end to end over Avaya infrastructure), the core switches must be able to recognize and honor the Avaya Automatic QoS DSCP values.

Presently, only Avaya Automatic QoS Edge mixed mode is supported. When the edge switch is configured for Avaya Automatic QoS Edge mixed mode, the application traffic that is recognized by the edge switch is remarked to standard DSCP values as shown in Table 1. In the core, these DSCP values can then be recognized and honored by either Avaya or any third party core switch supporting Differentiated Services.

Avaya Automatic QoS Core support will be added to the following switches as shown below. The will allow the Core Ethernet switch to recognize and honor the DSCP value when the Edge switch is configured for Avaya Automatic QoS pure mode without the requirement of the Edge switch to remark the Avaya Automatic QoS values from the attached device.

- ERS 8300
 - POR Q209
- ERS 8600
 - o POI Q209

7



2. Avaya Automatic QoS Configuration

2.1 ERS 4500 – Edge Switch

2.1.1 Avaya Automatic QoS CLI Configuration

Avaya Automatic QoS is configured by using the following command:

• 4526GTX-PWR(config)#qos agent nt-mode ?

disable	NT application traffic processing disabled on all ports
mixed	NT application traffic processing enabled on all ports with egress
	DSCP remapping
pure	NT application traffic processing enabled on all ports without
	egress DSCP remapping

where:

Parameter	Description
disable	Disables Avaya Automatic QoS functionality for the system
mixed	Enables Avaya Automatic QoS functionality with DSCP remarking at egress enabled. Private Avaya DSCP values will be remarked to corresponding standard DSCP values as noted in table 2.
pure	Enables Avaya Automatic QoS functionality with DSCP remarking at egress disabled. Private DSCP values will be honored as noted in table 1 while all other traffic is remarked to QoS level of Standard. Please note that this mode is not supported at this time.



Please note that phase 1 of Avaya Automatic QoS does not support ADAC, NSNA, or 802.1AB simultaneously.

Only Avaya Automatic QoS mixed mode is supported

2.1.2 Core Ports

The core or uplink port members should be configured as QoS trusted ports. This can be accomplished by first adding a new QoS interface group and then adding the port members to this interface group.

- 4548GT_5-PWR(config)# qos if-group name <if-group_name> class trusted
- 4550T_5-PWR(config)# qos if-assign port <port members> name <if-group_name>
- 4548GT_5-PWR(config)# qos if-assign port <port members> name <if-group_name>



2.2 ERS 5000 - Edge Switch

2.2.1 Avaya Automatic QoS CLI Configuration

Avaya Automatic QoS is configured by using the following command:

• 5520-6#(config)# qos agent nt-mode ?

```
disableNT application traffic processing disabled on all portsmixedNT application traffic processing enabled on all ports with egressDSCP remappingpureNT application traffic processing enabled on all ports without<br/>egress DSCP remapping
```

2.2.2 Core Ports

The core or uplink port members should be configured as QoS trusted ports. This can be accomplished by first adding a new QoS interface group and then adding the port members to this interface group.

- 5520-6#(config)# qos if-group name <if-group_name> class trusted
- 5520-6#(config)# qos if-assign port <port members> name <if-group_name>
- 5520-6#(config)# qos if-assign port <port members> name <if-group_name>

2.2.3 Queue Set

By default, the ERS 5000 is configured with Queue set 2 and Large buffers. This can be verified by using the following command:

• 5520-6# show qos agent

```
QoS NVRam Commit Delay: 10 seconds
QoS Queue Set: 2
QoS Buffering: Large
QoS UBP Support Level: Disabled
```

To view the various settings for each queue set, enter the following command:

• 5520-6(config)# show qos queue-set

After choosing the queue set you wish to use, enter the following command:

• 5520-6(config)# qos agent queue-set <1-8>



Please refer to the document titled "Filters and QOS Configuration for Ethernet Routing Switch 5000 Technical Configuration Guide" document number NN48500-559 for more details.

As shown below, the default queue set of 2 should not be used for Avaya Automatic QoS. It is recommended to use at least queue set 8 which has one strict queue and seven weighted round robin queues and use regular buffers.



• 5520-6# show gos queue-set

5520)-6#sh	ow qos que	eue-set					
Set	Queue	Ge	eneral	Bandwidt	h Absolute	Bandwidth	Service	Size
ID	ID	Disc	cipline	(응)	Bandwidth	Allocation	Order	(Bytes
				(Kbps)				
1		Driority	Quouing	100			1	26214
1	1	Priority	Queuing	100	0	Relative	1	100214
2	1	Priority	Queuing	100	0	Relative	1	01022
2	1	Priority	Queuing	100	0	Relative	∠ 1	10056
ວ ວ	1	Prioricy	Queuing Dound Dobin	100	0	Relative	1	27040
2	2	Weighted	Round Robin	75	0	Relative	2	87040
3	3	weighted	Round Robin	25	0	Relative	2	00000
4	1	Priority	Queuing	100	0	Relative	1	81920
4	2	Weighted	Round Robin	65	0	Relative	2	/4240
4	3	Weighted	Round Robin	26	0	Relative	2	61440
4	4	Weighted	Round Robin	9	0	Relative	2	44544
5	1	Priority	Queuing	100	0	Relative	1	64000
5	2	Weighted	Round Robin	58	0	Relative	2	59904
5	3	Weighted	Round Robin	27	0	Relative	2	53760
5	4	Weighted	Round Robin	11	0	Relative	2	46080
5	5	Weighted	Round Robin	4	0	Relative	2	38400
6	1	Priority	Queuing	100	0	Relative	1	51200
6	2	Weighted	Round Robin	52	0	Relative	2	49152
6	3	Weighted	Round Robin	24	0	Relative	2	47104
6	4	Weighted	Round Robin	14	0	Relative	2	43008
6	5	Weighted	Round Robin	7	0	Relative	2	37376
6	6	Weighted	Round Robin	3	0	Relative	2	34304
7	1	Priority	Queuing	100	0	Relative	1	49152
7	2	Weighted	Round Robin	45	0	Relative	2	46080
7	3	Weighted	Round Robin	21	0	Relative	2	39936
7	4	Weighted	Round Robin	15	0	Relative	2	33280
7	5	Weighted	Round Robin	10	0	Relative	2	31232
7	6	Weighted	Round Robin	6	0	Relative	2	31232
7	7	Weighted	Round Robin	3	0	Relative	2	31232
8	1	Priority	Queuina	100	0	Relative	1	49152
8	2	Weighted	Round Robin	41	0	Relative	2	47104
8	3	Weighted	Round Robin	19	0	Relative	2	45056
8	4	Weighted	Round Robin	13	0	Relative	2	43008
8	5	Weighted	Round Robin	11	0	Relative	2	39936
8	6	Weighted	Round Robin	8	0	Relative	2	36864
8	7	Weighted	Round Robin	5	0	Relative	2	33792
8	, g	Weighted	Round Robin	3	0	Polativo	2	30720
0	0	werdured	NOULIG KODILI	J	U	NGTALING	4	50120



2.3 ERS 8600 – Used as Core Switch only

There is no edge configuration for Avaya Automatic QoS on the ERS 8600. Presently, when used as a core switch for Avaya Automatic QoS with either the ERS 4500 or ERS 5000 as an edge switch, only Avaya Automatic QoS mixed mode is supported on the edge switch

2.3.1 CLI Configuration – R Modules

When used as a core switch, the edge ERS 4500 or ERS 5000 uplinks ports to the ERS 8600 should be configured as DiffServ core ports with 802.1 p-bit over-ride enabled.

- ERS-8610:5# config ethernet <slot/port> enable-diffserv true
- ERS-8610:5# config ethernet <slot/port> 802.1p-override enable

2.3.2 CLI Configuration – Legacy Modules

- ERS8600-4:5# config ethernet <slot/port> enable-diffserv true
- ERS8600-4:5# config ethernet <slot/port> access-diffserv false (default setting)

2.4 ERS 8300 – Used as Core Switch only

Similar to the ERS 8600, there is no edge configuration for Avaya Automatic QoS on the ERS 8300, but it can still be used as a core switch.

2.4.1 CLI Configuration

When used as a core switch, the edge ERS 4500 or ERS 5000 uplinks ports to the ERS 8300 should be configured using ACL's to trust the DSCP values. Assuming no ACL or ACG's have been configured, using ACL 1 and ACG 1, enter the following commands:

- ERS8300-2:5# config filter acl 1 create ip acl-name "trust"
- ERS8300-2:5# config filter acl 1 ace 1 action permit trust-dscp enable "trust" precedence 1
- ERS8300-2:5# config filter acg 1 create 1 acg-name "acg_trust"

Finally, add the ACG 1 to the appropriate interfaces connected the edge ERS 4500 or ERS 5000 uplinks:

• ERS8300-2:5# config ethernet <slot/port> filter create 1





2.5 Avaya BCM 50, Avaya SRG 50, and Avaya BCM 450 Configuration

2.5.1 Enable Avaya Automatic QoS

To enable Avaya Automatic QoS on the Avaya BCM 50 or Avaya SRG 50, open the BCM Element Manager and go to *Data Services*>QoS and check the box labeled *NT_on_NT*.

File Edit Wew Network Session Tools Help						
🐐 Exit 👷 Cut 😰 Copy 💼 Paste 🔭 Web Page	Validate Device 🎽 Disconnect 🔗 Refresh 💣 Auto-refresh					
Element Navigation Panel Network Elements Network Elements Network Elements Network Elements Configuration Administrator Access Administrator Access	DSCP Marking DSCP Marking The utps service needs to be restarted via service manager after any value below is changed. NT_on_NT NT_on_NT DSCP Setting UOJP Signaling QoS value for VOIP signaling Avaya_CSS TOS byte for VOIP Signaling I64 Voice Media QoS value for voice media Avaya_EF TOS byte for video media I88 Video Media QoS value for video media I40 Fax Media QoS value for fax media I40 Fax Media I05 byte for fax media I88					
pone.	C:0 M:0 M:0 M:24 🔽 Include ACKed alarms					



2.5.2 Restart the UTPS service

After you have enabled Avaya Automatic QoS, you need to restart the *utps* service. Start by clicking on the *Administration* icon via the *Task Navigation Panel* and click on *Service Manager*. Scroll down to *utps* and click the *Restart* icon and select Yes to restart the service.

Navigation Pane etwork Elements 10.5.80.5	Task Navigation Panel Configuration Administration Alarms Alarm Settings SMMP Trap Destination	Service Manager Image: Service Manager Should a service Manager should be ser	rvice Manager Improper use can affect system operation.		
	Hardware Inventory	Service Name	Startup	Status	
	🗄 🛅 System Metrics	OneButtonText	Enabled	Running	-
	🗄 🛅 Telephony Metrics	Pdrd	Enabled	Running	
	🗈 🛅 Utilities	SoftwareUpdateProviderAgent	Enabled	Running	
	🗄 🛅 Backup and Restore	SyslogListener	Enabled	Running	
	E Cogs	UftpServer	Enabled	Running	
	E Coftware Management	WANFailoverProviderAgent	Enabled	Running	
		WANServiceMgr	Enabled	Running	
		apcupsd	Enabled	Stopped	
		btraceserver	Enabled	Running	
		core_file_monitor	Enabled	Running	
		crond	Enabled	Running	
		ctiserver	Enabled	Running	
		reps	Enabled	Running	
		httpd	Enabled	Running	
		Ims	Enabled	Running	
		nigs mik2rak	Enduled	Running	La,
		modemos	Enabled	Running	
		modeline	Enabled	Rupping	
		owcimond	Enabled	Running	
		nostares	Enabled	Running	
		nsm	Enabled	Running	
		amond	Enabled	Running	Restart Service
		securityservice	Enabled	Running	
		srg	Enabled	Running	Are you sure you want to restart this service?
		ssba	Enabled	Running	Click on Yos
		sshd	Enabled	Running	Click off Yes No
		tmwservice	Enabled	Running	
		utps	Enabled	Running	
		voicemail	Enabled	Running	

Warning – use caution when restarting the UTPS as all IP Sets registered with the BCM server are temporarily reset.

Note: These Business Element Manager screen shots are from an Avaya BCM 50 system. The process on an Avaya BCM 450 is the same, although the setting is referred to as "Avaya on Avaya".

Note: the Avaya BCM200/400 does not support NT_on_NT settings or the ability to remark DSCP values at source, although it is possible to re-mark DSCP values for traffic egressing any BCM interface using the built-in BCM Firewall configuration and manually configuring new rules.



2.6 CS1000 – Node Configuration

To enable Avaya Automatic QoS on the CS1000, open Element Manager and go to IP Network and click on Edit for the appropriate node that you wish to enable Avaya Automatic QoS. Then check the box labeled *"Enable Avaya on Avaya"* under the QoS heading as shown below.

-Home	Managing: 10.1.5.13 System × IP Network × Node Configuration × IP Telephony:	Node ID 5010 × Edit	1
- LINKS - Virtual Terminals	System # Herwork # Note Configuration # Helephony.	Nous ID Joro / Eult	
- Bookmarks	Edit		121
- System	Ear		
+ Alarms			
– Maintenance	Rayo and Transfor		
+ Core Equipment	Cancer	Click here to enable	e Avaya Automatic QoS
- Peripheral Equipment	+ IP Telephony Node	1	
- Nodes: Servers Media Cards	+VGW and IP phone codec profile		
- Maintenance and Reports	-0.05		
- Media Gateways	- 003	1	
- Zones	Enable Avaya on Avaya		
- Host and Route Tables	Diffeon/Codensint/DSCD) Control packate	41	T annual
- Network Address Translation (N)	Dinserv Codepoin(DSCF) Control packets	140	(0-63)
- QUS Thresholds - Personal Directories	Diffserv Codepoint(DSCP) Voice packets	47] (0 e2)
+ Interfaces		10] (0-03)
- Engineered Values	Enable 802.1Q support		
+ Emergency Services	002 40 Photoship (002 4c)	6	T
+ Geographic Redundancy	802.1Q Bits Value (802.1p)	b	(0-7)
+ Software	+ LAN configuration		
- Customers	+ SNTP		
- Routes and Trunks			
- D-Channels	+ VIITUAL FRUNK NETWORK HEARTN MONITOR CONTIGURATION		
– Digital Trunk Interface	+H323 GW Settings		
- Dialing and Numbering Plans	+ Firmware		
- Electronic Switched Network	+ SIP GW Settings		
- Flexible Code Restriction	+ SIP URI Map		
– Incoming Digit Translation	+ SIP CD Services		
- Tools	+ SIP CTI Services		
- Call Server Initialization	+ Microsoft Unified Messaging		
– Date and Time	a t	(A.1.)	
+ Logs and reports	+Cards	Add	
- Security	+ Signaling Servers	Add	
+ Policies			
+ Login Options	Save and Transfer Cancel		
< >			
8			Tobayash
E 1			Thernet 🦉



2.7 CS 1000 – Media Gateway Controller (MGC) Configuration

To enable Avaya Automatic QoS on the CS1000 for MGC, open Element Manager and go to IP Network>*Media Gateways* and check the box labeled *"Enable Avaya on Avaya"* under the QoS heading as shown below.

- Home - Links - Virtual Terminals - Bookmarks	Managing: 10.1.5.13 System » IP Network » <u>Media Gateways</u> » I <u>PMG 4 0 Proper</u> Configuration	t <u>y Configuration</u> » IPMG 4 0 №	Media Gateway Controller (MGC)
- System + Alarms - Maintenance + Core Equipment	IPMG 4 0 Media Gateway Controller ((MGC) Configu	ration
- Peripheral Equipment	– Media Gateway Controller		
– IP Network – Nodes: Servers, Media Cards	Hostname	MGC-10	
- Maintenance and Reports - <u>Media Gateways</u>	Management LAN (ELAN) IP address	10.1.5.14	
- Zones - Host and Route Tables	Management LAN (ELAN) gateway IP address	10.1.5.1	
 Network Address Translation (N/ - QoS Thresholds Percend Directories 	Management LAN (ELAN) subnet mask	255.255.255.0	
+ Interfaces	Voice LAN (TLAN) IP address	47.17.200.14	
+ Emergency Services + Geographic Redundancy	Voice LAN (TLAN) gateway IP address	47.17.200.1	
+ Software	Voice LAN (TLAN) subnet mask	255.255.255.224	
- Customers	+DSP Daughterboard 1	<u>Ул</u>	- A.
- Routes and Trunks	+DSP Daughterhoard 2		
- D-Channels	+VGW and IP phone codec profile	Click here to enable	e Avaya Automatic QoS
- Digital Trunk Interface	-005		
- Electronic Switched Network	Enable Avaya on Avaya	V	
- Flexible Code Restriction - Incoming Digit Translation	Diffserv Codepoint(DSCP) Control packets	41	Range: 0 to 63
- Tools + Backup and Restore	Diffserv Codepoint(DSCP) Voice packets	47	Range: 0 to 63
- Call Server Initialization	+ LAN configuration		
 Date and Time + Logs and reports 	Submit Cancel VGW Channels		
- Security + Passwords + Policies + Login Options	*Mandatory fields of current configuration		
< · · · · · · · · · · · · · · · · · · ·			
			🔮 Internet

2.8 CS 2100

To enable Avaya on Avaya QoS capabilities on the Communication Server 2100 work with your Avaya Implementation team to make sure all components of the customer's network are coordinated to support this enhancement.



2.9 Software Baseline

- ERS 4500
 - o Release 5.2
 - Edge with Avaya Automatic QoS mixed or pure mode

• ERS 5000

- o Release 6.0
- o Edge with Avaya Automatic QoS mixed or pure mode

• CS1000

- o Avaya Automatic QoS supported in Element Manager
- o Release 5.5
- Patch MPLR26485 is required
- CS 2100
 - SE10
 - Edge with Avaya Automatic QoS supported in Element Manager
- Avaya BCM 50, Avaya SRG 50, and Avaya BCM 450
 - Avaya BCM 50/Avaya SRG 50 requires minimum of Release 3.0 software with Smart Update BCM050.R300.SU.System-115 or later
 - Avaya BCM 450 requires minimum of Release 1.0 software with Smart Update BCM450.R100.SU.System-003 or later



Note: The Business Element Manager from these System Smart Updates must be downloaded and installed before being able to configure the Avaya Automatic QoS settings. Also note that Avaya BCM 450 Release 1.0 refers to this setting as "Avaya on Avaya".



3. Customer service

Visit the Avaya Web site to access the complete range of services and support that Avaya provides. Go to <u>www.avaya.com</u> or go to one of the pages listed in the following sections.

3.1 Getting technical documentation

To download and print selected technical publications and release notes directly from the Internet,go to <u>www.avaya.com/support</u>.

3.2 Getting product training

Ongoing product training is available. For more information or to register, you can access the Web site at <u>www.avaya.com/support</u>. From this Web site, you can locate the Training contacts link on the left-hand navigation pane.

3.3 Getting help from a distributor or reseller

If you purchased a service contract for your Avaya product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

3.4 Getting technical support from the Avaya Web site

The easiest and most effective way to get technical support for Avaya products is from the Avaya Technical Support Web site at <u>www.avaya.com/support</u>.