



**DEFINITY®**

**Enterprise Communication Server**

Release 10

Installation for Adjuncts and Peripherals

555-233-116

Issue 2

December 2001

## Notice

Every effort was made to ensure that the information in this book was complete and accurate at the time of printing. However, information is subject to change.

## Your Responsibility for Your System's Security

Toll fraud is the unauthorized use of your telecommunications system by an unauthorized party, for example, persons other than your company's employees, agents, subcontractors, or persons working on your company's behalf. Note that there may be a risk of toll fraud associated with your telecommunications system and, if toll fraud occurs, it can result in substantial additional charges for your telecommunications services.

You and your system manager are responsible for the security of your system, such as programming and configuring your equipment to prevent unauthorized use. The system manager is also responsible for reading all installation, instruction, and system administration documents provided with this product in order to fully understand the features that can introduce risk of toll fraud and the steps that can be taken to reduce that risk. Avaya does not warrant that this product is immune from or will prevent unauthorized use of common-carrier telecommunication services or facilities accessed through or connected to it. Avaya will not be responsible for any charges that result from such unauthorized use.

## Avaya Fraud Intervention

If you *suspect that you are being victimized* by toll fraud and you need technical support or assistance, call Technical Service Center Toll Fraud Intervention Hotline at 1 800 643-2353 or contact your local Lucent representative.

## Federal Communications Commission Statement

**Part 15: Class A Statement.** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

**Part 68: Network Registration Number.** This equipment is registered with the FCC in accordance with Part 68 of the FCC Rules. It is identified by FCC registration number AS593M-13283-MF-E.

**Part 68: Answer-Supervision Signaling.** Allowing this equipment to be operated in a manner that does not provide proper answer-supervision signaling is in violation of Part 68 Rules. This equipment returns answer-supervision signals to the public switched network when:

- Answered by the called station
- Answered by the attendant
- Routed to a recorded announcement that can be administered by the CPE user

This equipment returns answer-supervision signals on all DID calls forwarded back to the public switched telephone network. Permissible exceptions are:

- A call is unanswered
- A busy tone is received
- A reorder tone is received

## Canadian Department of Communications (DOC)

### Interference Information

This digital apparatus does not exceed the Class A limits for radio noise emissions set out in the radio interference regulations of the Canadian Department of Communications.

Le Présent Appareil Numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la class A prescrites dans le règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

### Trademarks

See About This Document.

### Ordering Information

**Call:** Avaya Publications Center  
Voice 1 800 457-1235 or 1 410 568 3680  
Fax 1 800 457-1764 or 1 410 891 0207

**Write:** Globalware Solutions  
200 Ward Hill Avenue  
Haverhill, MA 01835 USA

**Order:** Document No. 555-233-116  
Issue 2, December 2001

For additional documents, refer to the section in "About This Document" entitled "Related Resources."

You can be placed on a standing order list for this and other documents you may need. Standing order will enable you to automatically receive updated versions of individual documents or document sets, billed to account information that you provide. For more information on standing orders, or to be put on a list to receive future issues of this document, contact the Avaya Publications Center.

### European Union Declaration of Conformity

The "CE" mark affixed to the DEFINITY® equipment described in this book indicates that the equipment conforms to the following European Union (EU) Directives:

- Electromagnetic Compatibility (89/336/EEC)
- Low Voltage (73/23/EEC)
- Telecommunications Terminal Equipment (TTE) i-CTR3 BRI and i-CTR4 PRI

For more information on standards compliance, contact your local distributor.

### Comments

To comment on this document, return the comment card at the front of the document.

### Acknowledgment

This document was prepared by Product Documentation Development, Avaya Inc., Denver, CO.

# Contents

<b>Contents</b>	<b>iii</b>
<b>About This Book</b>	<b>vii</b>
■ Overview	vii
■ Conventions Used in This Book	x
■ How to Comment on This Document	xi
■ How to Order Books	xi
■ Antistatic Protection	xii
■ Remove/Install Circuit Packs	xiii
■ Security	xiii
■ Trademarks	xiii
■ Standards Compliance	xiv
■ LASER Product	xv
■ Electromagnetic Compatibility Standards	xv
■ Federal Communications Commission Statement	xvii
<b>1 909A/B Universal Coupler</b>	<b>1</b>
<b>2 Auxiliary Power Supplies</b>	<b>5</b>
■ Local, auxiliary power supply	5
■ Applications that require auxiliary power	6
■ Sources of auxiliary, local power	7
■ Required Safety Precautions	7
■ 1145B Power Supply	8
■ 1151A and 1151A2 Power Supplies	16
<b>3 2-Wire DCP Voice and Data Terminals and Extenders</b>	<b>19</b>
■ 2-Wire DCP Endpoint	19
■ DEFINITY DCP Extender, Stand Alone	22
■ DEFINITY DCP Extender, Rack Mount	23
<b>4 Data Modules and Asynchronous Data Units</b>	<b>25</b>
■ Understanding RS-232 communications	25
■ Installation Procedure	27
■ Obtain Required Equipment	27
■ Set Hardware Options	28

■	Connect Data Modules	32
■	Administer the DEFINITY ECS for Data Modules	73
■	Asynchronous Data Units (ADUs)	76
<b>5</b>	<b>External Modems</b>	<b>77</b>
■	Hardware required when configuring modems	77
■	PARADYNE COMSPHERE 3715	78
■	PARADYNE COMSPHERE 3810 Plus and 3811 Plus	79
■	Setting Up the PARADYNE COMSPHERE 3910	79
■	Setting Up the U.S. Robotics Modem for DEFINITY	87
■	Administering the DEFINITY for Modems	88
<b>6</b>	<b>Printers</b>	<b>91</b>
■	Configuring the AT&T Model 572	91
■	Connecting the Printer	95
■	Okidata Model OP16N	95
■	Connecting printers via TCP/IP	98
<b>7</b>	<b>DEFINITY LAN Gateway System</b>	<b>103</b>
■	Installing DEFINITY LAN Gateway in a Single-Carrier Cabinet	103
■	Installing DEFINITY LAN Gateway in a Multicarrier Cabinet	105
■	Connecting the Alarm Origination Cable	107
■	Connecting a PC	108
■	Installing a Printer	114
<b>8</b>	<b>Terminal Server Installation</b>	<b>115</b>
■	Overview	115
■	Installing and administering the terminal server	116
■	Administering IP node names	126
■	Administering IP services	127
<b>9</b>	<b>DS1/T1 CPE Loopback Jack</b>	<b>129</b>
■	Installing Loopback Jacks	129
■	Administering the Loopback Jack	131
■	Loopback Testing with a Smart Jack	131
■	Loopback Testing Without a Smart Jack	140

<b>10</b>	<b>ISDN Converters and Adapters</b>	<b>145</b>
	■ Converters for Single-Carrier Cabinets	145
	■ Converters for Multicarrier Cabinets	148
<b>11</b>	<b>Stratum 3 Clock</b>	<b>151</b>
	■ Set Clock Options	151
<b>12</b>	<b>Busy Tone Disconnect Equipment for Non-U.S. Installations</b>	<b>159</b>
<b>13</b>	<b>Call Detail Recording Option Settings</b>	<b>161</b>
	■ Connecting CDR Equipment to DEFINITY ECS	161
	■ Using a Printer as the CDR Output Device	162
	■ Using Other Equipment as the CDR Output Devices	163
	■ Sources of Administration Information	163
	■ Connecting a CDR device through the C-LAN	164
	■ Using the Downloadable Reliable Session-Layer Protocol Tool	165
<b>14</b>	<b>DEFINITY INADS</b>	<b>169</b>
<b>15</b>	<b>Malicious Call Trace</b>	<b>179</b>
<b>16</b>	<b>Loudspeaker Paging, Music-on-Hold, and External Alerting Equipment</b>	<b>181</b>
	■ Loudspeaker Paging	181
	■ Music-on-Hold, Dial Dictation, or Recorded Announcement Access	184
	■ External Ringing	186
	■ Queue Warning Indicator	186
<b>17</b>	<b>Paging and Announcement Equipment</b>	<b>187</b>
	■ PagePac Plus Paging System	187
	■ ESPA Radio Paging	191
<b>18</b>	<b>Multimedia Communications Products: MMCX, MMCH, ESM</b>	<b>193</b>
	■ MASI for MMCX	193
	■ Wideband Endpoints	196
	■ Multimedia Call Handling (MMCH)	199

<b>19</b>	<b>Property Management System</b>	<b>211</b>
	■ Connecting the Property Management System	211
	■ Connecting a Terminal and/or Journal Printer	213
	■ Connecting PMS and printers over TCP/IP	214
<b>A</b>	<b>Connector and Cable Pinout Charts</b>	<b>217</b>
<b>IN</b>	<b>Index</b>	<b>229</b>

## About This Book

---

This book provides procedures for installing equipment and software peripheral to the DEFINITY ECS and DEFINITY ONE, hereafter referred to as DEFINITY. Not all adjuncts and peripherals are addressed in this book. For those, we are supplying other resources for the information.

The information in this book is intended for use by

- Trained field installation and maintenance personnel
- Technical support personnel
- Network engineers and technicians
- Design center personnel
- Sales associates
- Business partners

## Overview

---

DEFINITY ECS and DEFINITY One can work with a wide range of external equipment, applications, and peripherals. Adjuncts are software products that work with the various DEFINITY switches. Peripherals are products that connect directly or remotely to DEFINITY switches. Be aware that some equipment and software work only with certain DEFINITY releases. See the Adjunct Minimum Vintage table for the most current compatibility information.

[Table i on page viii](#) provides a list of current adjuncts and peripherals and where installation information exists

**Table i. DEFINITY adjuncts and peripheral resource list**

<b>Adjunct/Peripheral</b>	<b>Resource</b>
909A/B Universal Coupler	<a href="#">Chapter 1</a>
AUDIX	<i>AUDIX Installation</i> <i>AUDIX Voice Power Installation and Maintenance Guide</i>
Auxiliary Power Supplies	<a href="#">Chapter 2</a>
Basic Call Management System (BCMS) View	<i>Basic Call Management System (BCMS) Operations</i>
Busy Tone Disconnect Equipment for Non-U.S. Installations	<a href="#">Chapter 12</a>
Call Detail Recording (CDR) Option Settings	<a href="#">Chapter 13</a>
CallVisor ASAI LAN Gateway	<i>DEFINITY ECS CallVisor ASAI DEFINITY LAN Gateway over MAPD Installation, Administration, and Maintenance</i>
CentreVu Agent	<i>CentreVu® Agent Installation and Administration</i>
CentreVu Call Management System (CMS)	<i>CentreVu® Call Management System Software Installation and Setup</i>
CentreVu Explorer	<i>CentreVu® Explorer User Guide</i>
CentreVu Supervisor	<i>CentreVu® Supervisor —Installation and Getting Started</i>
Conversant	<i>INTUITY CONVERSANT System Customer Assist Technical Operations</i>
Data Modules and ADUs	<a href="#">Chapter 4</a>
DCS Connections	<a href="#">Chapter 9</a>
DEFINITY INADS	<a href="#">Chapter 14</a>
DEFINITY LAN Gateway System	<a href="#">Chapter 7</a>
DEFINITY Wireless Personal Comm Mgr.	<i>DEFINITY ECS Interface for the DEFINITY Wireless Business System Guide</i>
DS1/T1 CPE Loopback Jack	<a href="#">Chapter 9</a>
Expansion Services Module (ESM)	<a href="#">Chapter 18</a>
External Alerting Equipment	<a href="#">Chapter 16</a>

*Continued on next page*

**Table i. DEFINITY adjuncts and peripheral resource list — *Continued***

<b>Adjunct/Peripheral</b>	<b>Resource</b>
Internet Call Center	<i>CentreVu Internet Solutions Documentation CD-ROM</i> <i>Internet Call Center Solution Guide</i>
Internet Telephony Gateway	<i>Internet Telephony Server-Enterprise Hardware Installation Quick Reference</i>
Intuity AUDIX	<i>Internet Messaging for the Intuity AUDIX Multimedia Messaging System, Installation</i>
Intuity Interchange	<i>INTUITY Interchange System Supporting Documentation</i>
ISDN Converters and Adapters	<a href="#">Chapter 10</a>
Loudspeaker Paging	<a href="#">Chapter 17</a>
Malicious Call Trace	<a href="#">Chapter 15</a>
Modems, external	<a href="#">Chapter 5</a>
Multimedia Call Exchange MMCX	<a href="#">Chapter 18</a>
Multimedia Call Handling (MMCH)	<a href="#">Chapter 18</a>
Multipoint Control Unit (MCU)/CRS	<i>MultiPoint Conferencing Unit Installation and Test</i>
Music on Hold	<a href="#">Chapter 16</a>
Paging and Announcement Equipment	<a href="#">Chapter 17</a>
Pollable Storage Unit (PSU)	<i>Pollable Storage Unit Installation</i>
Printers	<a href="#">Chapter 6</a>
Property Management System	<a href="#">Chapter 19</a>
Stratum 3 Clock	<a href="#">Chapter 11</a>
Voice and Data Terminals	<a href="#">Chapter 3</a>

## Conventions Used in This Book

---

### Typographic

---

- Information you type at the access terminal is shown in the following typeface: **list system-parameters maintenance**.
- Variables are shown in the following typeface: *number*.
- Field names and information displayed on the access terminal screen is shown in the following typeface: `login`.
- Keyboard keys are shown in the following typeface: Enter.

### Systems and circuit packs

---

- The word “system” is a general term encompassing the DEFINITY Enterprise Communications Server models: Release 10r, Release 10si, Release 10csi, and Release 10c.
- DEFINITY Enterprise Communications Server is abbreviated as DEFINITY ECS.
- Circuit pack codes (for example, TN780 or TN2182B) are shown with the minimum acceptable alphabetic suffix (like the “B” in the code TN2182B).  
Generally, an alphabetic suffix higher than that shown is also acceptable. However, not every *vintage* of either the minimum suffix or a higher suffix code is necessarily acceptable.
- The term “ASAI” is synonymous with the newer CallVisor ASAI.

### Admonishments

---

Admonishments in this book have the following meanings:



**CAUTION:**

*This sign is used to indicate possible harm to software, possible loss of data, or possible service interruptions.*



**WARNING:**

*This sign is used where there is possible harm to hardware or equipment.*



**DANGER:**

*This sign is used to indicate possible harm or injury to people.*

## Physical dimensions

---

- All physical dimensions in this book are in English units (feet [ft]) followed by metric (centimeter [cm]) in parenthesis.
- Wire gauge measurements are in AWG followed by the diameter in millimeters in parenthesis

## How to Comment on This Document

---

Avaya welcomes your feedback. Your comments are of great value and help improve our documentation.

- Please fill out the reader comment card at the front of this manual and return it.
- If the reader comment card is missing, FAX your comments to 1-303-538-1741 or to your Avaya representative, and mention this document's name and number, *DEFINITY ECS Installation for Adjuncts and Peripherals*, 555-233-116, Issue 2.
- Email your comments to **document@avaya.com**

## How to Order Books

---

In addition to this book, other description, installation and test, maintenance, and administration books are available. A complete list of DEFINITY books can be found at <http://support.avaya.com>.

This book and any other DEFINITY books can be ordered directly from the Avaya Publications Center: Voice — 1.800.457.1235 or 1.410.568.3680, Fax — 1.800.457.1764 or 1.410.891.0207. You can also write to Globalware Solutions, 200 Ward Hill Avenue, Haverhill, MA 01835 USA.

## Where To Call for Technical Support

Use the telephone numbers in [Table ii](#) for the region in which the system is being installed.

**Table ii. Technical support contact numbers**

	Telephone Number
DEFINITY Helpline (feature administration and system applications)	1-800-225-7585
Avaya Toll Fraud Intervention	1-800-643-2353
Avaya National Customer Care Center (ATM customers)	1-800-242-2121
Avaya Corporate Security	1-800-822-9009
Streamlined Implementation (for missing equipment)	1-800-772-5409
USA/Canada Technical Service Center (ATM technicians)	1-800-248-1234
NetCare® Professional Services (NPS)	1-800-237-0016
International Technical Assistance (ITAC)	1-303-804-3777
<b>Avaya Centers of Excellence</b>	
Asia/Pacific Regional Support Center	65-872-8686
Western Europe/Middle East/South Africa	44-1252-77-4800
Central/Eastern Europe	361-345-4334
Central/Latin America Caribbean	1-303-804-3778
Australia	61-2-9352-9090
North America (INADS Database Administration)	1-800-248-1111

## Antistatic Protection



**WARNING:**

*To minimize electrostatic discharge (ESD), always wear an authorized wrist ground strap when handling circuit packs or any components of a DEFINITY System. Connect the strap to an approved ground such as an unpainted metal surface on the DEFINITY ECS switch.*

## Remove/Install Circuit Packs

---

### CAUTION:

*The control circuit packs with white labels cannot be removed or installed when the power is on. The port circuit packs with gray labels (older version circuit packs had purple labels) can be removed or installed when the power is on.*

## Security

---

To ensure the greatest security possible, Avaya offers services that can reduce toll fraud liabilities. Contact your Avaya representative for more security information.

Login security is an attribute of the DEFINITY ECS software. Advise customers that their existing passwords expire 24 hours after the upgrade. Also explain that the new passwords must conform to strict requirements.

System administrators must keep network addresses confidential. A PPN or any endpoint masquerading as a PPN on the ATM network can seize that EPN and control it if that EPN is not already connected to its proper PPN.

## Trademarks

---

This document contains references to the following Avaya trademarked products:

- ACCUNET®
- AUDIX®
- Callmaster®
- CallVisor®
- CentreVu™
- CONVERSANT®
- DEFINITY®
- DEFINITY ONE™
- FORUM™
- Intuity™
- Intuity Lodging™
- Quorum™
- SYSTIMAX®
- TRANSTALK™
- VOICE POWER®

The following products are trademarked by their corresponding vendor:

- 3Comm<sup>®</sup>, U.S. Robotics<sup>®</sup>, and Sportster<sup>®</sup> are registered trademarks of the 3Comm Corporation
- Audichron<sup>®</sup> is a registered trademark of Audichron Company
- LINX<sup>™</sup> is a trademark of Illinois Tool Works, Inc.
- Windows95/98/NT is a trademark of Microsoft Corporation
- Music Mate<sup>®</sup> is a registered trademark of Harris Corporation
- PagePac<sup>®</sup> is a registered trademark of Harris Corporation, Dracon Division
- Paradyne<sup>™</sup> and COMSPHERE<sup>™</sup> are trademarks of the Paradyne Corporation
- Shockwatch<sup>®</sup> is a registered trademark of Media Recovery, Incorporated
- Styrofoam<sup>®</sup> is a registered trademark of Styrofoam Corporation
- Tiltwatch<sup>®</sup> is a registered trademark of Media Recovery, Incorporated
- Zone Mate<sup>®</sup> is a registered trademark of Harris Corporation

## **Standards Compliance**

---

The equipment in this document complies with the following standards (as applicable):

- ITU-T (Formerly CCITT)
- ECMA
- ETSI
- IPNS
- DPNSS
- National ISDN-1
- National ISDN-2
- ISO-9000
- ANSI
- FCC Part 15 and Part 68
- EN55022
- EN50081
- EN50082
- UNI 3.1
- CISPR22
- Australia AS3548 (AS/NZ3548)

- Australia AS3260
- IEC 825
- IEC 950
- UL1459
- UL 1950
- CSA C222 Number 225
- TS001
- ILMI 3.1

## LASER Product

---

The DEFINITY ECS switch may contain a Class 1 LASER device (IEC 825 1993) if single-mode fiber optic cable is connected to a remote expansion port network (EPN). The laser device operates within the following parameters:

Power output	Wavelength	Mode field diameter
-5 dBm	1310 nm	8.8 mm

### DANGER:

*Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.*

Contact your Avaya representative for more information.

## Electromagnetic Compatibility Standards

---

This product complies with and conforms to the following EMC standards (as applicable):

- Limits and Methods of Measurements of Radio Interference Characteristics of Information Technology Equipment, EN55022 (CISPR22), 1993
- EN50082-1, European Generic Immunity Standard
- FCC Part 15
- Australia AS3548

### NOTE:

The DEFINITY system conforms to Class A (industrial) equipment. Voice terminals meet Class B requirements.

- Electrostatic Discharge (ESD) IEC 1000-4-2
- Radiated radio frequency field IEC 1000-4-3
- Electrical Fast Transient IEC 1000-4-4
- Lightning effects IEC 1000-4-5
- Conducted radio frequency IEC 1000-4-6
- Mains frequency magnetic field IEC 1000-4-8
- Low frequency mains disturbance IEC 1000-4-11

## **European Union Standards**

---

Avaya Business Communications Systems declares that the DEFINITY equipment specified in this document bearing the “CE” mark conforms to the European Union Electromagnetic Compatibility Directives.

The “CE” (Conformité Européenne) mark indicates conformance to the European Union Electromagnetic Compatibility Directive (89/336/EEC) Low Voltage Directive (73/23/EEC) and Telecommunication Terminal Equipment (TTE) Directive (91/263/EEC) and with i-CTR3 Basic Rate Interface (BRI) and i-CTR4 Primary Rate Interface (PRI) as applicable.

The “CE” mark is applied to the following products:

- Global AC-powered Multicarrier Cabinet (MCC) with 25-Hz and 50-Hz ring generator
- DC-powered Multicarrier Cabinet (MCC) with 25-Hz ring generator
- AC-powered Enhanced Single-Carrier Cabinet (ESCC) with 25-Hz ring generator
- AC-powered Compact Single-Carrier Cabinet (CSCC) with 25-Hz ring generator
- AC-powered Compact Modular Cabinet (CMC) with 25-Hz and 50-Hz ring generator (for France)
- Enhanced DC Power System

## Federal Communications Commission Statement

---

### Part 68: Statement

---

Part 68: Answer-Supervision Signaling. Allowing this equipment to be operated in a manner that does not provide proper answer-supervision signaling is in violation of Part 68 rules. This equipment returns answer-supervision signals to the public switched network when:

- Answered by the called station
- Answered by the attendant
- Routed to a recorded announcement that can be administered by the CPE user

This equipment returns answer-supervision signals on all domestic DID calls forwarded back to the public switched telephone network. Permissible exceptions are:

- A call is unanswered
- A busy tone is received
- A reorder tone is received

Avaya attests that this registered equipment is capable of providing users access to interstate providers of operator services through the use of access codes. Modification of this equipment by call aggregators to block access dialing codes is a violation of the Telephone Operator Consumers Act of 1990.

This equipment complies with Part 68 of the FCC Rules. On the rear of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company.

The REN is used to determine the quantity of devices which may be connected to the telephone line. Excessive RENs on the telephone line may result in devices not ringing in response to an incoming call. In most, but not all areas, the sum of RENs should not exceed 5.0. To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company.

 **NOTE:**

REN is not required for some types of analog or digital facilities.

## Means of connection

Connection of this equipment to the telephone network is shown in the following table.

<b>Manufacturer's Port Identifier</b>	<b>FIC Code</b>	<b>SOC/REN/A.S. Code</b>	<b>Network Jacks</b>
Off/On Premises Station	OL13C	9.0F	RJ2GX, RJ21X, RJ11C
DID trunk	02RV2-T	0.0B	RJ2GX, RJ21X
CO trunk	02GS2	0.3A	RJ21X
CO trunk	02LS2	3.0A	RJ21X
Tie trunk	TL31M	9.0F	RJ2GX
1.544 digital Interface	04DU9-B,C	6.0F	RJ48C, RJ48M
1.544 digital Interface	04DU9-BN,KN	6.0F	RJ48C, RJ48M
2.048 digital Interface	04DU9-BN,KN	6.0F	RJ48C, RJ48M
120A2 channel service unit	04DU9-DN	6.0F	RJ48C

If the terminal equipment (DEFINITY® System) causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

If trouble is experienced with this equipment, for repair or warranty information, please contact the Technical Service Center at 1-800-242-2121. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

It is recommended that Avaya-certified technicians perform the repairs.

The equipment cannot be used on public coin phone service provided by the telephone company. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

This equipment, if it uses a telephone receiver, is hearing-aid compatible.

# 909A/B Universal Coupler

# 1


---

The 909A/B Universal Coupler is used with paging and music-on-hold equipment that is not approved for use with the public network.

 **NOTE:**

If the music source is registered by the FCC (in the USA) or an equivalent body, the 909A/B is not required.

[Figure 1](#) shows a typical 909A/B universal coupler. For additional installation and switch setting information, refer to *909A/909B Universal Coupler Installation Instructions*.



909\_brkt KLC 042296

- |                             |                          |
|-----------------------------|--------------------------|
| 1. 909A/B universal coupler | 4. J3 7-Pin modular jack |
| 2. J1 8-Pin modular jack    | 5. DIP switch location   |
| 3. J2 8-Pin modular jack    |                          |

**Figure 1. Typical 909A/B Universal Coupler**

The 909A is the DC version of the coupler, and cabinet power supplies -48 VDC power. The 909B is the AC-powered version and power is supplied from a separate power supply (such as the KS-22911L2).

The DIP switches on the unit set:

- Protection/Paging selection — For AUX trunk paging and malicious call trace, set to C2. Set the switch to C1 for all other applications.
- Output attenuation (-9 or -15 dBm) — Setting depends on output level of music source.
- Output impedance (8 ohms, 1.5 k $\Omega$ , and 50 k $\Omega$ ) — This switch only requires setting if the Protection/Paging switch is set to C2 and the coupler is supplying background music to a customer-supplied paging amplifier.

The pinouts for J1, J2, and J3 are provided in [Table 1](#), [Table 2](#), and [Table 3](#). Refer to these tables when connecting music or paging equipment.

**Table 1. J1 Pin Assignments (System Connections)**

Pin	Color	Designation	Description
1	White-Orange	—	Not Used
2	Orange	PG2/BZ2	Seizure control lead, connected to -48 VDC from the system or from the 909A/B when the protection paging switch is set to C2, or to -48 VDC on the 909A/B when protection/paging switch is set to C1
3	White-Green	PG1/BZ1	Seizure control lead, connected to SZ lead from the AUX trunk when the protection/paging switch is set to C2, or to -48 VDC on the 909A/B when the protection/paging switch is set to C1
4	Blue	R	Ring lead
5	White-Blue	T	Tip lead
7	Green	BSY2/BY2	Busy/busy-out lead, connected to S1 lead from the AUX trunk
7	White-Brown	BSY1/BY1	Busy/busy-out lead, connected to S lead from the AUX trunk
8	Brown	—	Not Used

**Table 2. J2 Pin Assignments (Accessory Connections)**

Pin	Color	Designation	Description
1	White-Orange	CMS1/M1	Customer-supplied music source
2	Orange	CMS2/M2	Customer-supplied music source
3	White-Green	COS1	Remote busy-out control contact closure from music source
4	Blue	CR	Customer ring lead
5	White-Blue	CT	Customer tip lead
7	Green	COS2	Remote busy-out control contact closure from music source
7	White-Brown	CBS1/C1	Seizure indication provided to music source
8	Brown	CBS2/C2	Seizure indication provided to music source


**⚠ CAUTION:**

*Damage to the 909A/B may occur if the cable is plugged into J3 **before** all cross-connects are completed.*

**Table 3. J3 Pin Assignments (Power Connections)**

Pin	Color	Designation	Description
1, 3, 4, & 7	—	—	Not used
2	Black	GRD	-48 RET or ground lead from system or from positive lead of power supply
5	Yellow	-48 VDC	-48 VDC from system or from negative lead of power supply

Figure 2 shows the physical locations of the pins for J1, J2, and J3.



1. J1 and J2 8-Pin modular jacks

2. J3 7-Pin modular jack

**Figure 2. Typical Modular Jack Pinout**

## Auxiliary Power Supplies

# 2

---

Nonessential features of the attendant console, such as the optional 27B1 selector console, and DCP terminals derive their power from an auxiliary power source. One console can connect to R10csi, and 3 consoles can connect to each cabinet stack or R10r. Each cabinet can derive auxiliary power from the system and through the auxiliary cable located in the trunk/auxiliary field. Auxiliary power for a primary attendant console should be provided through this cable so the console remains fully operational during short power outages.

### Local, auxiliary power supply

Consoles can use either local or phantom power, depending on the distance between the console and the DEFINITY ECS cabinet. Over short distances, phantom power is attractive, because no additional hardware is necessary—power is supplied via the telephone circuit itself. For longer distances, you need a local power supply. [Table 4](#) shows cabling distances for the 302 attendant console.

**Table 4. 302C1 Attendant Console Cabling Distances**

	24 AWG Wire (0.27 mm <sup>2</sup> )		27 AWG Wire (0.14 mm <sup>2</sup> )	
	feet	meters	feet	meters
<b>With selector console:</b>				
Phantom-powered	800	244	500	152
Locally powered	5000	1524	3400	1037
<b>Without selector console:</b>				
Phantom powered	1400	427	900	274
Locally powered	5000	1524	3400	1037

## **Applications that require auxiliary power**

Auxiliary power (local or bulk) is always required for the following:

- Any 8520 telephone
- 302-series attendant console
- PassageWay adapter interface
- Any 7500-series telephone whether in passive bus, or point to point (one per BRI port)
- Any 7500- or 8500-series telephone with an asynchronous data module
- Any 8510 telephone in passive bus or with an asynchronous data module (unless the 8510 will not be used to support data or video)
- Any 7400-series telephone with XM24 expansion module
- Any 7400-series telephone with adjuncts 7407, 7434 or 7444
- Any 8400-series telephone with adjuncts 8411 or 8434
- Any 4600-series IP telephone
- IP console

The 1145B power supply is required for all installations outside the United States.

## Sources of auxiliary, local power

---

An attendant console can derive auxiliary power from:

- A bulk power supply, such as the 1145B

A console's maximum distance from its 1145B auxiliary power source is 800 ft. (244 m) for a 302A1 or 350 ft. (107 m) for a 301B1 and 302C1.

- 1151A1 or 1151A2 power supply

## Required Safety Precautions

---

### DANGER:

*When operating power-supply equipment, you must follow basic safety precautions to reduce the risk of fire, electric shock and personal injury. Read and understand all instructions. Follow all warnings and instructions marked on the products. Follow all the installation instructions when mounting the product.*

### DANGER:

*Never use a power unit with a power source other than that specified on the product labels.*

*Do not try to plug the 3-wire grounding plug into a nongrounding power outlet. This plug only fits into a grounding power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, have an electrician replace the outlet. Do not defeat the safety purpose of the grounding plug.*

*Do not attach the power supply cord to building surfaces.*

*Do not overload power outlets.*

*Do not use this product near water. Do not let anything spill on or into the unit. Clean only with a dry rag.*

*Never push objects through openings in the case.*

*Do not try to disassemble the unit. Return it for repair. Opening or removing covers may expose you to dangerous voltages. Incorrect reassembly may cause electric shock when the products are subsequently used.*

*Power down the unit and refer servicing immediately if the unit is exposed to water or other liquids, if the unit is dropped or damaged, or if the unit fails to operate normally.*

 **DANGER:**

*Never let the operating temperature of the unit exceed the recommended maximum.*

*Do not block or cover the ventilation openings in the case.*

*Do not let anything rest on the unit.*

 **DANGER:**

*Do not attempt to recharge batteries. The power unit recharges the batteries itself. Any other recharging method may cause leaks of corrosive electrolyte or explosion. Discard discharged batteries as soon as possible. Discharged batteries are more likely to leak.*

*Do not store batteries in high temperature areas. Batteries stored in a cold environment should be protected from condensation during storage and warming. Batteries should be stabilized at room temperature prior to use after cold storage. Do not install batteries if the manufacturing date on the label indicates that the batteries are more than 6 months old.*

## 1145B Power Supply

---

The 1145B power supply powers ISDN/DCP, terminal equipment, adjuncts, and other customer-supplied external equipment. It supplies -48V, 200 W total and supports 32 outputs. You can install one ISDN terminal or DCP adjunct per output.

A manual switch on the distribution unit lets the user redirect reserve power to outputs 1 to 32 so that all outputs get battery reserve power.

An optional 1149 battery and 1146 distribution unit provides uninterruptible -48 VDC power.

 **DANGER:**

*When operating power-supply equipment, you must follow basic safety precautions to reduce the risk of fire, electric shock and personal injury. Read, understand, and follow all warnings and instructions. See [“Required Safety Precautions”](#) on page 2-7.*

## Circuit protection

---

A thermistor current-limits the maximum output of each output to 12 W, but the average power per output cannot exceed 7.25 W ( $200/32 = 7.25$ ). An LED indicates the status of the thermistor. When the LED is ON, there is a short on the power pair.

## Mountings

---

The back-up battery mounts on a top plate. The power supply and distribution units mount on a bottom plate. The plates are normally wall-mounted.

## Installing the Wall Mounting

---

See [Figure 3](#)

1. Locate one plate directly below the other with the raised letters right side up. Be sure that the AC power cord can reach the electrical outlet from the bottom plate. The power cord is about 7.5 ft. (2 m) long.




**NOTE:**

Up to 4 power supplies can draw current from one 110- or 230-VAC, 20- or 15-A feeder. Use only unswitched receptacles that are not shared with other equipment.

2. Secure the wall mounting plates to a 3/4-in. (2-cm) plywood mounting board using the four 1/2-in. #10 wood screws supplied with the plates.
3. Snap the 1145B power supply onto the bottom wall-mounting plate (no tools are needed).
4. Connect an insulated 17-AWG #12 (1.2-mm) ground wire (or better) between the ground lug on the power-supply frame and an approved ground.

The frame ground screw is located next to the AC receptacle, to the left of the unit.



1. Wall mounting plate
2. Optional battery (1149B shown)
3. 1146 power distribution unit
4. 1145B power unit
5. Power cable
6. Unswitched outlet (120 VAC, 20 A or 230 VAC, 15 A)
7. Battery backup switch setting

Figure 3. 1145B/1146 Mounting Arrangement

5. Write the Unit Number and connectivity information on the front label, next to the LEDs.

## Installing the 1146 Power Distribution Unit

1. Insert and securely tighten the two supplied #8-32 x 1/2-in. shoulder screws (they have an unthreaded section at the top) into the top holes designated for 1146 Power Distribution Unit on the bottom plate. Mount the unit on these two shoulder screws, using the key holes on the back of the unit.
2. Secure the unit by inserting the #8-32 x 1 in. screw through the bottom of the unit (just above the wire clips) into the plate and tighten.
3. Set the battery back-up switch option to the 1-32 (down) position to provide battery back-up to all outputs.
4. Connect the power distribution unit to the power supply with the power cable. Refer to the power supply's right-side label to locate the output power connection.

## Installing and Wiring the Battery

Two types of back-up batteries can be used:

**Table 5. Back-Up Batteries**

Battery	Rating
1148B	2.5 amp-hours
1149B	5 amp-hours

To install the battery, proceed as follows.

1. Loosely insert two #10-32 x 1/2-in. shoulder screws in the battery-mounting holes at the top of the wall mounting plate.
2. Place the keyhole slots in the battery bracket on these two screws. Make sure the label on the battery is visible.  
 The battery cord exits from the right side of the bracket.
3. Tighten the screws securely.
4. Plug the battery cord into the right rear receptacle on the power supply. The right-side label indicates the rear receptacle.

## Installing the Expanded Power Distribution Unit

You can install a second power-distribution unit for additional 8400- and 8500-series terminals.

### CAUTION:

*Total power cannot exceed 200 W. Consult the chart below for permissible terminal installations.*

**Table 6. Permissible terminal installations (total power < 200 W)**

Terminal mix	Maximum numbers	Notes
7500-series + 8500-series ISDN	24 + 24	
7400-series + 8400-series DCP	24 + 24	
8400-series DCP	74	
7400-series DCP	74	Average power per terminal must be less than 3.126 W

Each expanded power distribution unit kit supplies the following items:

- One power distribution unit
- One T-cable
- Two #8-32 x 1/2-in. shoulder screws
- One #8-32 x 1 in. screw
- One spacer bracket

Refer to [Figure 4](#) while installing the power distribution unit:

1. Fasten the spacer bracket to the mounting plate with the #8-32 x 1/2-in. shoulder screws.


The spacer bracket is not shown in the figure. It is behind the top power distribution unit.

2. Slide the keyhole slots in the power distribution unit over the shoulder screws.
3. Insert the #8-32 x 1 in. screw through the distribution unit, through the spacer bracket, and into the plate. Tighten the screw.

The mounting hole is located just above the wire clip.

4. Set the battery back-up switch to the 1-32 (down) position.
5. Power-down the 1145B as described on the label on the side of the unit.

6. Remove the output power cable between the 1145B and the 1147B units. The cable will not be reused.
7. Connect the P1 connector end of the T-cable to the bottom power distribution unit.
8. Connect the P2 connector to the top distribution unit.
9. Connect the P3 connector to the 1145B.
10. Power-up the 1145B as described on the label on the side of the unit.



0004\_1 PDH 062596

- |  |  |
|--|--|
| 1. Wall-mounting plate                   | 4. Standard 1146 power distribution unit |
| 2. Optional 1146 power distribution unit | 5. 1145B power unit                      |
| 3. T cable (H600-347-G7)                 |  |

Figure 4. Expanded Power Distribution Unit

## Powering Up and Testing AC and DC Power

When you power up the unit or interrupt power to a unit, the unit runs an AC or DC self test. LEDs on the front panel indicate the status of the power supply. The following table lists the LEDs.

**Table 7. Power-supply LEDs**

LED Color	Meaning
GREEN	Power supply is providing power
YELLOW	Battery is charging (after at most 20 hours, when the battery has reached full charge, the YELLOW LED should go out)
RED	Power supply is on battery reserve

1. Connect the AC power cord to the power supply, and route the cord to an appropriate AC outlet using the clips provided on the unit.



**NOTE:**

A maximum of four power supplies can be powered from one dedicated 110 VAC, 20-A feeder. Use only unswitched receptacles.


2. Start the AC test by plugging the cord into the outlet.  
This powers up the power supply.
3. Check AC operation of the 1145B power supply by monitoring the LEDs:  
**PASS:** GREEN and YELLOW are both lit.  
**FAIL:** either GREEN or YELLOW LED is not lit.
4. If the AC test failed, test the AC outlet, power cord, and connections.
5. If the AC test failed, but power is available and the AC power cord and connections are good, replace the power unit.
6. Once the AC test passes, activate the DC battery-backup supply by disconnecting the AC plug.
7. Check DC (battery back-up) operation by monitoring the LEDs.  
**PASS:** RED and GREEN are both lit.  
**FAIL:** either RED or GREEN is not lit.
8. If the DC test fails, check the connections.
9. If the DC test fails but the connections are good, replace the batteries and retest.
10. If the DC test fails after you replace the batteries, replace the power supply.
11. Once the DC test passes, reconnect AC power to the power supply.

## Wire the 1146 Power Distribution Unit

Wire endpoints to the 1146 while power from the 1145B is on.

1. Install cross-connect jumpers (the label shows polarity) to Pins 7 and 8 of the appropriate information outlet. Route the wires through the clip provided on the unit. If a red LED is on, see *"Repairing Short Circuits and Resetting Red LEDs"* on page 2-16. Figure 5 shows the connections.

A red LED lights if the associated circuit is connected to shorted wiring or a shorted terminal.



- |                                    |  |
|------------------------------------|--|
| 1. Power supply kit                | 8. Main distribution frame                 |
| 2. 2.5, 5.0, or 8.0 A hour battery | 9. Modular cord                            |
| 3. 1146 power distribution unit    | 10. AC input                               |
| 4. 1145B power supply              | 11. Ground wire                            |
| 5. Circuits 1-17                   | 12. ISDN/ display system protocol terminal |
| 6. Circuits 17-32                  | 13. Circuits 1-32                          |
| 7. Port circuit                    | 14. Pins 7 and 8 (display terminal power)  |

Figure 5. Typical wiring to a terminal

2. Mark lead destinations, unit number, and connectivity information on the label next to each connector.

## Replacing the Batteries

To maintain back-up protection and battery reliability:

1. Replace batteries every four years.

## Storing the Batteries in Inactive Units

To prevent leakage when the power unit is not in use for several months or more:

1. Remove the batteries and store them separately.

## Repairing Short Circuits and Resetting Red LEDs

A red LED next to any of the 32 power output connectors indicates a short circuit in the building wiring or the terminal equipment. To reset the LED:

1. Disconnect the terminal equipment from the wall jack.
2. If the LED goes off, the terminal equipment is faulty. Replace it.
3. If the LED is still lit, find and repair the short circuit in the building wiring.
4. Reconnect the terminal equipment to the wall jack, and re-test.

## 1151A and 1151A2 Power Supplies

The 1151A is a standard (no battery backup) power supply unit. The 1151A2 is a battery backup version of the 1151A. Either power supply can support one telephone with or without an adjunct.

The 1151A and 1151A2 power supplies can supply local power to ISDN-T 7400-, 7500-, 8400-, and 8500-series voice terminals connected to a system, and to the DCP 7444 voice terminal or 302C attendant console that need auxiliary power for its display. The unit can supply power to adjunct equipment such as S201A and CS201A speakerphones, or a 500A headset adapter attached to any currently manufactured analog, DCP, or ISDN-T voice terminal equipped with an adjunct jack.

The power supply has the following specifications:

- A single output of -48 VDC, 0.4 A
- Either a 120 VAC 60-Hz power source (105 to 129 VAC) or a 220/230/240 VAC 50-Hz power source (198 to 274 VAC)
- Automatic input voltage selection
- Output capacity of 19.2 W
- Maximum loop range of 250 ft. (77 m)
- Use of 2 modular jacks. PHONE jack pins 7 and 8 (- and +, respectively) provide power.

The PHONE and LINE jacks are 8-pin female nonkeyed 757-type jacks that can accept D4, D7, and D8 modular plug cables. [Figure 6](#) shows a 1151A power supply. The 1151A2 looks similar.

**⚠ DANGER:**


*When operating power-supply equipment, you must follow basic safety precautions to reduce the risk of fire, electric shock and personal injury. Read, understand, and follow all warnings and instructions. See [“Required Safety Precautions”](#) on page 2-7.*

**⚠ CAUTION:**

*Do not locate the unit within 7 in. (15.25 cm) of the floor.*

**⚠ CAUTION:**

*Use the power supply **only** with telecommunications equipment, indoors, and in a controlled environment.*



pwr\_sup1 C.JL 051496

---

**Figure 6. Typical 1151A Power Supply (Front)**

## **Desk Mounting**

---

1. Place the power supply on a flat surface such as a desk.

## **Wall Mounting**

---

1. For wall-mounting, use the keyhole slots on the bottom of the chassis.

## **Standards compliance**

---

The 1151A and 1151A2 power supplies comply with the UL Standard UL 1459, second edition.

**Table 8. Standards compliance**

<b>Complies</b>	UL 1459
Certified	CSA 22.2
Approved	EN7950
Approved	CE

---

## 2-Wire DCP Voice and Data Terminals and Extenders

# 3

---

This chapter provides information on 2-wire voice and data terminals and DEFINITY digital communication protocol (DCP) extenders.

### 2-Wire DCP Endpoint

---

Wire the tip and ring connections of 2-wire DCP endpoints to a TN2224B digital line 2-wire circuit pack (or equivalent) similar to the 2-wire analog endpoints for a TN747B analog line circuit pack.



**NOTE:**

The TN2224B supports 2-wire DCP sets only (not 4-wire).

### 2-wire Voice Terminals

---



**CAUTION:**

*Except for auxiliary power, if necessary, these should be the **only** connections to the modular wall jack. Do not bridge or parallel these telephones.*

Table 9 provides the pin-out configuration for 2-wire voice terminals.

**Table 9. Pin-out for 2-wire Voice Terminals**

Pin Number	Function	Pin Number	Function
1	4-wire output from terminal	5	2-wire ring
2	4-wire output from terminal	7	4-wire input from system
3	4-wire input from system	7	Auxiliary power -48 VDC
4	2-wire tip	8	Auxiliary power GRD


## 2-Wire Voice and Data Terminals

Table 10 provides the pin-out configuration for 2-wire voice and data terminals.

**Table 10. Pin-out for 2-wire Voice Terminals**

Pin Number	Function	Pin Number	Function
1	4-wire output from terminal	5	2-wire ring
2	4-wire output from terminal	7	4-wire input from system
3	4-wire input from system	7	Auxiliary power -48 VDC
4	2-wire tip	8	Auxiliary power GRD

Figure 7 shows a workstation connecting to a data adapter. The line side of the adapter connects to the TN2181 digital line 2-wire circuit pack via the main distribution frame (MDF) (to the system cabinet).



- |                                   |  |
|-----------------------------------|--|
| 1. 103A or modular wall jack      | 5. 4-wire modular cord                 |
| 2. 2-wire endpoint                | 6. 25-pair cable                       |
| 3. Data terminal (serial data)    | 7. To TN2181 digital line circuit pack |
| 4. Data adapter (such as Italtel) |  |


Figure 7. Typical Connections to a 2-Wire DCP Workstation

Wire the circuit pack to the MDF with a 25-pair cable:

1. Wire to the data adapter per local standards.
2. Wire the data terminal and telephone as instructed in the document accompanying the data adapter.

## DEFINITY DCP Extender, Stand Alone

The figure below shows a typical connection from a digital line 2-wire DCP circuit pack through two DCP extender devices. See [Appendix A, "Connector and Cable Pinout Charts"](#) for cabling information and pin assignments.




- |   |   |
|---|---|
| 1. System cabinet                           | 7. 103A or modular wall jack                    |
| 2. TN2181 or TN2224B circuit pack           | 8. Modular line cord                            |
| 3. 25-pair cable                            | 9. DCP telephone (Such as 8410D, 8405, or 8434) |
| 4. DEFINITY DCP extender                    | 10. Remote work location                        |
| 5. Main distribution frame (MDF)            |   |
| 6. Public switched telephone network (PSTN) |   |

Figure 8. Typical DEFINITY DCP Extender Connections

## DEFINITY DCP Extender, Rack Mount

Figure 9 shows a typical rack mount (multi-mount) DCP extender. Connections from either a digital line 17-port 2-wire DCP circuit pack or a digital line 24-port 2-wire DCP circuit pack, are made through two DCP extender devices. The stand alone extender installs at the work location. To install the stand-alone unit, refer to the installation instructions in “DEFINITY DCP Extender, Stand Alone” earlier in this chapter. Refer to [Appendix A, Table 35, “DCP Extender 25-Pair Cable Pinout”](#). The *DEFINITY Extender Switch Module System Administrator’s Guide* contains additional information.



- |                                       |  |
|---------------------------------------|--|
| 1. Front of rack mount assembly       | 4. Rear of rack mount assembly                                     |
| 2. First circuit pack in slot 1 (“A”) | 5. 25-pair connector to the MDF and the digital line circuit packs |
| 3. Slot 12 (“L”)                      | 6. Power connector   |

Figure 9. Typical DEFINITY DCP Extender Connections

**3** 2-Wire DCP Voice and Data Terminals and Extenders  
*DEFINITY DCP Extender, Rack Mount*

24

## Data Modules and Asynchronous Data Units

# 4

Data modules connect peripheral equipment to the DEFINITY ECS or DEFINITY ONE and convert between the RS-232 communications protocol used by peripherals and the DEFINITY Digital Communications Protocol (DCP). Possible peripherals include AUDIX adjunct equipment and terminals, serial printers, customer-supplied terminals and host computers, call detail-recording (CDR) devices, and pooled modems. The following data modules are described in this chapter, and [Figure 10](#) shows typical data-module connections.

- 7400A/B/C/D
- 8400B
- ExpressRoute 1000
- Asynchronous data units (ADUs).



**NOTE:**

**ISDN data modules**, such as the 7500B, are not covered in this book. Refer to *Integrated Services Digital Network (ISDN) 7500B Data Module User's Manual*, for detailed procedures++. ISDN data modules connects DTE and DCE equipment to the ISDN network using an RS-232 or V.35 interface and an RS-377 automatic calling unit.

## Understanding RS-232 communications

---

To install a data module, you have to set up the device to work with RS-232 devices.


The RS-232 communications protocol defines a communications link as a Data Communications Equipment (DCE) device and a Data Terminal Equipment (DTE) device connected by an RS-232 cable. The send and receive pins on DCE equipment (pins 2 and 3) are reversed on DTE equipment, so that the DCE transmit pin connects to the receive pin of the DTE and vice versa.

Generally, the term DCE is applied to devices that mediate between customer equipment and the carrier or network. Such devices include modems, data modules, and data units. DTE describes devices that provide a user interface for data communications, such as dumb terminals and PCs. When configured as DTE, data modules are used for asynchronous modem pooling. When configured as DCE, data modules are analogous to modems in that they link a device such as a terminal or PC (DTE) to DEFINITY.

To install a data module correctly, you identify the connected equipment as DCE or DTE and do one of the following:

- Configure the modem for a DTE or DCE connection
- Install a null-modem converter

Detailed instructions are provided in the sections for each modem type (below).



cydfnst RPY 070397

- |  |  |
|--|--|
| 1. 103A connector or modular wall jack | 9. Auxiliary power supply for telephone  |
| 2. 400B2 adapter                       | 10. D7AP cord                            |
| 3. Rear of data module (7400B Shown)   | 11. D8W cord                             |
| 4. Host computer                       | 12. Line to display telephone (D8W cord) |
| 5. Data module power supply            | 13. Data cable (EIA/RS-232)              |
| 6. Electrical outlet                   | 14. Data-module power cable              |
| 7. Display telephone                   | 15. To MDF and system cabinet            |
| 8. S101A speakerphone                  | 16. Printer                              |

Figure 10. Typical Connections to a data module

## Installation Procedure

---

To install a typical data module, you perform the following tasks:

1. [Obtain Required Equipment](#)
2. [Set Hardware Options](#) (must be completed before you administer or physically connect the data module)
3. [Connect Data Modules](#)
4. [Administer the DEFINITY ECS for Data Modules](#) (can be completed either before or after you physically connect the data module)

## Obtain Required Equipment

---

To physically connect a data module to the system, you need the following parts.

- 105C/D Isolating Data Interface (if connecting to a DC cabinet)
- EIA-232-D (RS-232-C) cable with a male connector (for the data module) and the correct connector for the peripheral equipment

The cable connects the PC to the data module

- Null-modem converter (optional)
- V.35 cable with correct connectors (not required by all systems)
- D8W telephone cord

The cord connects the data module's LINE jack to the DEFINITY wall jack.

- DCP telephone and D8W cord (optional)

The D8W cord connects the telephone to the data module's PHONE jack.

- Suitable auxiliary power supply if the optional telephone is installed (D7AP power cord and 400B2 adapter in the US, international power supply, such as the MSP-1, elsewhere).

You must have access to the administration console of the DEFINITY, either through a terminal and keyboard or through a PC.

A breakout box for RS-232 interfaces may prove helpful in some cases. The RS-232 breakout box helps you to identify the pin configuration of the RS-232 interface on the equipment you are trying to connect.

## Set Hardware Options

---

Depending on the data module, you may have to set various configuration options using hardware switches, software commands, or both. *You must set the hardware options before you administer or physically install the data module.*

### Setting 7400A Data-Module Hardware Options

---


Most configuration options are controlled by commands entered on the front panel of the 7400A. But you have to make hardware changes when you want to set up the 7400A data-module for use in a modem pool or as a piece of data communications equipment. In a modem-pool, the data module operates as data-terminal equipment (DTE). In most other applications, it functions as data communications equipment (DCE). You have to set the correct operating mode for the data module before you can access the menus for the remaining configuration tasks.

To change the operating mode of the 7400A from DCE to DTE (or vice versa), you change the position of a small circuit board (the Electronic Industries Association connector board) inside the case. See [Figure 11](#) and proceed as follows.

#### **WARNING:**

*Electrostatic discharge can severely damage sensitive electronic circuits. Before handling any electronic hardware, be sure to wear a grounding wrist strap or other static-dissipating device. Do not touch exposed circuitry or semiconductor chips.*

1. Unplug the data module from the power receptacle.
2. Remove the access panel on the top of the case by grasping the rear lip of the panel and pulling sharply upward.
3. While facing the front of the data module, locate the small EIA connector circuit board. It sticks up vertically, and a large, silver arrow on the main circuit board points to it.



7400atop KLC 053096

1. 7400A data module      2. EIA connector board (shown in DTE mode)

**Figure 11. Data Module Mode Selector**

4. Note the three letters engraved in the upper lefthand corner of the EIA connector board. Data modules ship from the factory with board inserted with "DCE" in the upper left corner.
5. Use the DCE position to connect to DTE equipment. Use the DTE position to connect to DCE equipment. To change the mode, remove the board by grasping it and pulling it gently upward. Flip the board around, left to right, and reinsert it in the socket so that the correct operating mode, DCE or DTE, appears in the upper lefthand corner.
6. Snap the top cover onto the unit.

### Setting 7400B Data-Module Hardware Options

You configure the 7400B data module using DIP switches on the circuit card inside the case. [Figure 12](#) shows the front and rear of a 7400B data module.




Figure 12. 7400B Data Module

To configure the 7400B data module, proceed as follows.

**⚠ WARNING:**


*Electrostatic discharge can severely damage sensitive electronic circuits. Before handling any electronic hardware, be sure to wear a grounding wrist strap or other static-dissipating device. Do not touch exposed circuitry or semiconductor chips.*

1. If you are not attaching a telephone to the data module, activating data metering, or enabling busyout on the local loop, you can use the factory default settings. The 7400B data module is already configured for your use. Stop now.
2. Otherwise, remove the access panel on the top of the case by grasping the rear lip of the panel and pulling sharply upward.
3. Locate the DIP switch block, a bank of tiny switches on the circuit board, in the center of the opening.


DIP switches 1, 5, and 8 control the attached telephone (if any), data metering, and loopback on local loop.

- Set the switches for the combination of options that you need to enable, using the chart below as a guide.


No telephone attached, data metering OFF, busyout on local loop OFF  
 (factory default settings)




Telephone attached, data metering OFF, busyout on local loop OFF




No telephone attached, data metering ON, busyout on local loop OFF




No telephone attached, data metering OFF, busyout on local loop ON




No telephone attached, data metering ON, busyout on local loop ON




Telephone attached, data metering ON, busyout on local loop OFF



Telephone attached, data metering OFF, busyout on local loop ON



Telephone attached, data metering ON, busyout on local loop ON



5. Replace the cover on the data module.

## Connect Data Modules

To connect a single data module, follow the procedure in following section. To connect multiple data modules, see [Connecting Multiple Data Modules to the System](#).

## Connecting a Single Data Module

---

### CAUTION:

*You must install a 105D or 105C isolating data interface adapter when connecting data modules to equipment in DC-powered cabinets.*

Connect the data module to your house wiring or DEFINITY as follows.

1. Attach a D8W cable to the **LINE** port of the data module.
2. If you are going to attach a telephone to the data module
  - a. Attach a 400B2 adapter to the other end of the D8W cable.
  - b. Plug the adapter into a modular wall jack or 103A connector.
  - c. Plug a D7AP cord into the 400B2 adapter.
  - d. Plug the other end of the D7AP cord into the auxiliary power supply for the telephone.

You must have a separate power supply for the telephone and for the data module.

- e. Attach a D8W cable to the **PHONE** port of the data module.
3. If you are not attaching a telephone, attach the D8W cable from the Line port of the data module to a modular wall jack or 103A connector.
4. Attach the data-module power supply to the power connector on the back of the data module, and plug the power supply into an AC electrical outlet.
5. Connect an RS-232 cable to the **PORT 1** connector on the back of the data module.
6. If the equipment includes a V.35 interface, plug a V.35 cable into the **V.35** connector on the data module.
7. If the data module is a 7400B DCE-only device and if the other end of the cable is connected to another DCE device, insert a null-modem adapter between the data module and the RS-232 cable.
8. Connect the other end of the RS-232 cable to a serial (COM) port connection on the data device (host computer, serial printer, modem, etc.).
9. Go to the configuration procedure for the data module you are using:


- [Installation Procedure](#)
- [Configuring the 7400B Data Module](#)
- [Configuring the 7400C HSL \(High-Speed Link\) Data Module](#)
- [Configuring the 7400D Data Module](#)
- [Configuring the 8400B Plus Data Module](#)
- [Configuring the ExpressRoute 1000 Data Module](#)

## Connecting Multiple Data Modules to the System

### ⚠ CAUTION:

*You must install a 105D or 105C isolating data interface adapter when connecting data modules to equipment in DC-powered cabinets.*

You install multiple data modules in a data mounting on the DEFINITY. A Z77A data mounting can take up to 8 data modules. See [Figure 13](#).



z77a KLC 053096

- |                              |                               |
|------------------------------|-------------------------------|
| 1. Z77A data mounting        | 4. Retaining bar plunger      |
| 2. Data module (7400A shown) | 5. Twist-lock cable retainers |
| 3. Retaining bar             |                               |

Figure 13. Z77A Data Mounting

Proceed as follows.

1. Set data-module hardware options before installing the hardware in the mounting.
2. Release the horizontal retaining bar at the front of the data mounting by pulling out the plungers at the left and right sides of the bar.
3. Pull the retaining bar out and down.

4. Connect the a 25-pin RS-232 cable to the 25-pin connector on the rear of the data module.
5. Route the cable through the data mounting and through the twist-lock cable retainer on the top of the data mounting.
6. Attach the other end of the RS-232 cable to DTE or DCE.
7. Insert the data module vertically into the data mounting. Be sure the display is to the top of the data mounting.
8. Repeat steps 2 through 5 for each data module.
9. Return the horizontal retaining bar to its original position to secure the data modules inside the data mounting.
10. Go to the configuration procedure for the data module you are using:
  - [Configuring the 7400A Data Module](#)
  - [Configuring the 7400B Data Module](#)
  - [Configuring the 7400C HSL \(High- Speed Link\) Data Module](#)
  - [Configuring the 7400D Data Module](#)
  - [Configuring the 8400B Plus Data Module](#)

## Configuring the 7400A Data Module

The 7400A is a full-duplex, asynchronous data module for use with Digital Communications Protocol (DCP). It is designed for applications that do not require integration of voice and data. It supports asynchronous connections at speeds up to 19.2 Kbps via an EIA-232-D interface. [Figure 14](#) represents the front and back of the 7400A data module.





Figure 14. 7400A asynchronous data module

### Using the 7400A menu system

On the 7400A, you select communications settings using the controls on the front panel of the device. An LCD displays the configuration menus. You use the **NEXT/NO** and **BACK** buttons to navigate through the menus and the **ENTER/YES** button to select values.

### Powering up the 7400A

When you power up the 7400A, the **POWER TEST** and **DATA** LEDs light up, and the 7400A data module displays the HOME screen on the LCD. The figure below represents a typical home screen. Dashes indicate a lead that is connected, ovals indicate a lead that is not.



### Adjusting the control-panel display on the 7400A

1. Adjust the contrast of the display so that you can see it comfortably. Press the **ENTER/YES** button. This steps you through the available contrast settings.



Push the button indicated by the arrow (→)

### 7400A data module, EIA RS-232 interface circuits

The data module communicates with other equipment via a configurable, 25-pin RS-232 serial interface. DCE and DTE operation use different sets of pins and assign different functions to some of the same pins. To avoid confusion later on, please take a moment to review the differences. See the table below (the pins most discussed in subsequent sections have been emphasized).

Pin	Name	Function	DCE	DTE
1	—	Not used	—	—
2	BA (TD)	Transmitted Data	Input	Output
3	BB (RD)	Received Data	Output	Input
4	CA (RTS)	Request to Send	Input	Output
5	CB (CTS)	Clear to Send	Output	Input
6	CC (DSR)	Data Communication Equipment Ready	Output	Input
7	AB (SG)	Signal Ground	Common	Common
8	CF (RLSD)	Received Line Signal Detector	Output	Input

*Continued on next page*

Pin	Name	Function	DCE	DTE
9	—	Reserved for Testing	+12 volts	—
10	—	Reserved for Testing	-12 volts	—
11	—	Not used	—	—
12	CI	Data Signal Rate Select (DCE Source)	Output	Input
<b>13</b>	<b>CI2</b>	<b>Data Signal Rate Select 2 (DCE Source)</b>	—	<b>Input</b>
14	—	Not used	—	—
15	DB*	Transmitter Signal Element Timing (DCE Source)	Output	Input
16	—	Not used	—	—
17	DD*	Receiver Signal Element Timing (DCE Source)	Output	Input
18	LL	Local Loopback	Input	Output
19	CH2	Data Signal Rate Select 2 (DTE Source)	—	Output
20	CD (DTR)	Data Terminal Equipment Ready	Input	Output
21	RL	Remove Loopback	Input	Output
22	CE (RI)	Ring Indicator	Output	Input
23	CH	Data Signal Rate Select (DTE Source)	Input	Output
24	DA*	Transmit Signal Element Timing (DTE Source)	Input	Output
25	TM	Test Mode	Output	Input

---

\* Circuits are not used for asynchronous operation. Outputs are clamped OFF and inputs are ignored.

### Configuring the 7400A for data communications equipment (DCE) applications

If you are not going to use the 7400A data module in a modem pool, proceed as follows.

### Setting interface options on 7400A DCE

1. To access the menus, press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

2. When the **SET OPTIONS?** prompt appears on the LCD. Press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

3. The **VIEW OPTIONS?** prompt appears. Press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

You will return to the options menus in a minute. But first you must select a command interface for the data module.

4. The **SET INTERFACE?** prompt appears. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

A series of **INT = InterfaceType?** prompts appears.

5. For each prompt, if you want to select the interface, press the **ENTER/YES** button or, if you want a different interface, press the **NEXT/NO** button.
  - a. Enable the answer-only interface if the data module must operate without any kind of external control:

INT=ANS ONLY?	DATA	NEXT/NO	BACK	ENTER/YES
	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Select an option (NEXT/NO or ENTER/YES)

- b. Enable the AT-command interface if users need to control the data module remotely, using a dial-up connection and Hayes-compatible modem commands:

INT = AT COM?	DATA	NEXT/NO	BACK	ENTER/YES
	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Select an option (NEXT/NO or ENTER/YES)

- c. Enable the keyboard-dial interface if users need to control the data module interactively, from a terminal:

INT = KYBD DIAL?	DATA	NEXT/NO	BACK	ENTER/YES
	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Select an option (NEXT/NO or ENTER/YES)

After you select an interface, the data module runs a self-test and returns to the HOME screen.

<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;"></td> <td style="text-align: center;">D D D R C</td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">T S R C T T T R</td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;">R R I D S S D D</td> <td></td> </tr> <tr> <td style="padding: 5px;">POWER TEST</td> <td style="padding: 5px; border: 1px solid black; text-align: center;">0 0 — 0 0 0 — —</td> <td style="padding: 5px;">DATA</td> </tr> <tr> <td style="text-align: center;">*</td> <td style="text-align: center;">7400A Data Module</td> <td style="text-align: center;">*</td> </tr> </table>		D D D R C			T S R C T T T R			R R I D S S D D		POWER TEST	0 0 — 0 0 0 — —	DATA	*	7400A Data Module	*	<table style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="4" style="text-align: center; padding-bottom: 5px;">HOME</td> </tr> <tr> <td style="padding: 5px;">NEXT/NO</td> <td style="padding: 5px;">BACK</td> <td colspan="2" style="padding: 5px;">ENTER/YES</td> </tr> <tr> <td style="text-align: center;"><input type="radio"/></td> <td style="text-align: center;"><input type="radio"/></td> <td colspan="2" style="text-align: center;"><input type="radio"/></td> </tr> </table>	HOME				NEXT/NO	BACK	ENTER/YES		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
	D D D R C																											
	T S R C T T T R																											
	R R I D S S D D																											
POWER TEST	0 0 — 0 0 0 — —	DATA																										
*	7400A Data Module	*																										
HOME																												
NEXT/NO	BACK	ENTER/YES																										
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>																										

## Setting speed options on 7400A DCE

1. Press the **NEXT/NO** button to continue with the setup procedure.



Push the button indicated by the arrow (→)

2. The **SET OPTIONS?** prompt appears on the LCD. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

A series of **SET number SPEED?** prompts appears.

3. Press the **NEXT/NO** button until you see the **SET 9600 SPEED?** prompt. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

Most DEFINITY connections operate at the 9600 speed.

4. The **9600 = ON?** prompt appears. Press the **ENTER/YES** button.




Push the button indicated by the arrow (→)

5. The **CONTINUE?** prompt appears. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

- The **SET 19200 SPEED?** prompt appears. Press the **NEXT/NO** button.




- If you selected the AT-command interface in the section "[Setting interface options on 7400A DCE](#)" (above), you are finished configuring the 7400A data module.


### Setting the automatic-answer feature on 7400A DCE

You can set up the 7400A data module to automatically answer calls or you can have it ignore calls until an operator answers manually. Set up the data module for automatic answering unless specifically directed to otherwise.


- When the **SET ANSWER?** prompt appears, press the **ENTER/YES** button.



- When the **ANS = AUTO?** prompt appears, if you want to enable automatic answering, press the **ENTER/YES** button. Otherwise, press the **NEXT/NO** button.



- If you pressed **NEXT/NO** in the preceding step, the **ANS → MANUAL?** prompt appears. If you want to disable automatic answering, press the **ENTER/YES** button. Otherwise, press the **NEXT/NO** button.



- The **CONTINUE?** prompt appears. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

### Setting the break-disconnect option on 7400A DCE

This setting specifies the length of the BREAK signal, a string of 10 or more spaces that tells the host that the user needs to interrupt operations. There are three options: TRIPLE, LONG (the default), and NONE. Accept the default values, unless otherwise instructed.

- When the **SET BREAK DISC?** prompt appears, press the **NEXT/NO** button to keep the default.



Push the button indicated by the arrow (→)

### Configuring the RS-232 interface on 7400A DCE

You can set each pin of the RS-232 cable to meet the needs of specific applications or connected equipment. However, in most cases, you can use the defaults.

To set the EIA leads, proceed as follows:

- When the **SET LeadName LEAD?** prompt appears, press the **NEXT/NO** button to keep the default or the **ENTER/YES** button to make a change.



Push the button indicated by the arrow (→)

2. If you pressed the **ENTER/YES** button at the **SET LeadName LEAD?** prompt, the **LeadName -> ON?** prompt appears. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

3. Repeat until all leads have been set.

### Setting parity on 7400A DCE

Next you need to identify the type of parity coding that the data module should expect. Parity is an error-detection scheme that is based on the value of a parity bit in each unit of information. Four coding schemes are used: **ODD**, **EVEN**, **MARK**, and **SPACE**. In odd-parity coding, the parity bit is set to 0 if the number of 1s in the information is odd, 1 if it is even. In even-parity coding, the parity bit is set to 0 if the number of 1s in the information is even, 1 if it is odd. Mark-parity coding always sets the parity bit to 1. Space-parity coding always sets the parity bit to 0.

1. Accept the default value, unless otherwise instructed. When the **SET PARITY?** prompt appears, press the **NEXT/NO** button to keep the default, **SPACE**.



Push the button indicated by the arrow (→)

### Enabling remote loopback testing on 7400A DCE

You can set the remote loopback option to **GRANT** or **DENY**.

1. Accept the default value, unless otherwise instructed. When the **SET REMOTE LOOP?** prompt appears, press the **NEXT/NO** button to keep the default, **GRANT**.



Push the button indicated by the arrow (→)

### Configuring the ring indicator on 7400A DCE

The ring-indicator (pin 22) setting can have either of two values: **CYCLE** or **ON** (the default).

1. Accept the default values, unless otherwise instructed. When the **SET RI LEAD?** prompt appears, press the **NEXT/NO** button to keep the default, **ON**.



Push the button indicated by the arrow (→)

### Enabling remote loopback on 7400A DCE

The remote-loopback setting (pin 21) can have either of two values: **ON** or **OFF** (the default).

1. Accept the default values, unless otherwise instructed. When the **SET RL LEAD?** prompt appears, press the **NEXT/NO** button to keep the default, **ON**.



Push the button indicated by the arrow (→)

### Setting the signals-disconnect (SIGLS DISC) option on 7400A DCE

The settings can have either of two values: **ON** (the default) or **OFF**.

Accept the default values, unless otherwise instructed.

1. When the **SET SIGLS DISC?** prompt appears, press the **NEXT/NO** button to keep the default, **ON**.



Push the button indicated by the arrow (→)

### Enabling test mode on 7400A DCE

The test-mode (pin 25) setting can have either of two values: **ON** or **OFF** (the default).

1. Accept the default values, unless otherwise instructed. When the **SET TM LEAD?** prompt appears, press the **NEXT/NO** button to keep the default, **ON**.



Push the button indicated by the arrow (→)

### Exiting menus and saving changes on 7400A DCE

1. When the **DONE?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

2. When the **SAVE CHANGES?** prompt appears, press the **ENTER/YES** button.




Push the button indicated by the arrow (→)

Your changes are saved.



Push the button indicated by the arrow (→)

You return HOME.



### Checking DEFINITY administration on 7400A DCE

Check that the DEFINITY is administered to support the 7400A data module in the DCE application as follows:

1. If necessary, return to the HOME display on the 7400A by pressing the **NEXT/NO** and **BACK** buttons at the same time.
2. From the HOME display, press **NEXT/NO** until **ANS/ORIG CALL?** is displayed, then press the **ENTER/YES** button.
3. If you see the message **WAITING ... DISCONNECTED**, the switch has not been administered correctly.
4. If you see the message **DIAL TONE** followed by **DISCONNECT CALL?**, the DEFINITY is correctly administered for the 7400A data module. Press the **ENTER/YES** button to return to the menu.

The 7400A replies **WAITING ... DISCONNECTED** and returns to the **ANS/ORIG CALL?** menu.

5. Return to the HOME display by pressing the **NEXT/NO** and **BACK** buttons at the same time.


### Configuring the 7400A for modem pooling (DTE) applications

From the HOME screen, proceed as follows.

#### Setting speed options on 7400A DTE

1. To access the menus, press the **NEXT/NO** button.

- When the **SET OPTIONS?** prompt appears on the LCD, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

A series of **SET number SPEED?** prompts appears.

- Press the **NEXT/NO** button until you see the **SET 9600 SPEED?** prompt. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

Most DEFINITY connections operate at the 9600 speed.

- The **9600 = OFF?** prompt appears. Press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

- The **9600 → ON?** prompt appears. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

6. The **CONTINUE?** prompt appears. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

7. The **SET 19200 SPEED?** prompt appears. Press the **NEXT/NO** button to keep the default.



Push the button indicated by the arrow (→)

8. The **SET AT CONTROL?** prompt appears. Press the **ENTER/YES** button to enable Hayes-compatible modem commands. Press the **NEXT/NO** button to accept the default (OFF).



Select an option (NEXT/NO or ENTER/YES)

Use the AT CONTROL setting to let users control the data module remotely, using a dial-up connection.

9. If you enabled AT commands, the **AT = OFF?** prompt appears. Press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

- If you enabled AT commands, the **AT → ON?** prompt appears. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

- If you enabled AT commands, the **CONTINUE?** prompt appears. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

### Configuring the RS-232 interface on 7400A DTE

You can set each pin of the RS-232 cable to meet the needs of specific applications, though in most cases, the defaults should work. For a list of pins and leads, see [Table 11](#) below.

The Data Signal-Rate Select EIA leads—**CI**, **CI2**, **CH**, and **CH2**—of the RS-232 cable indicate the receive/transmit speeds that the data module can use. To set the EIA signal-rate leads, proceed as follows:

- From the HOME display, press **NEXT/NO** until **SET OPTIONS?** appears. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

- When the **SET 300 SPEED?** prompt appears, press **NEXT/NO** until **SET CI LEAD?** appears. Then, using the table and instructions below as a guide, start setting the leads.



Push the button indicated by the arrow (→)

**Table 11. DTE-mode RS-232 signal-rate lead settings for the 7400A**

	CI	CH	CI2	CH2
If you selected AT control in an earlier step, set	OFF	OFF	OFF	OFF
You want only 1 data speed.	OFF	OFF	OFF	OFF
You want 2 data speeds.	ON	ON	OFF	OFF
You want only 3 or 4 data speeds.	ON	ON	ON	ON

3. When the **SET CI LEAD?** prompt appears, press the **NEXT/NO** button to keep the default (OFF) or the **ENTER/YES** button to make a change.



Choose a button indicated by the question mark (?)

4. If you pressed **ENTER/YES** in the preceding step and the **CI LEAD = ON?** prompt appears, press the **ENTER/YES** button again to confirm your selection.



Push the button indicated by the arrow (→)

5. When the **SET CI2 LEAD?** prompt appears, press the **NEXT/NO** button to keep the default (OFF) or the **ENTER/YES** button to make a change.



Choose a button indicated by the question mark (?)

6. If you pressed **ENTER/YES** in the preceding step and the **CI2 LEAD = ON?** prompt appears press the **ENTER/YES** button again to confirm your selection.



Push the button indicated by the arrow (→)

7. When the **SET CH LEAD?** prompt appears, press the **NEXT/NO** button to keep the default (OFF) or the **ENTER/YES** button to make a change.



Choose a button indicated by the question mark (?)

8. If you pressed **ENTER/YES** in the preceding step and the **CH LEAD = ON?** prompt appears, press the **ENTER/YES** button again to confirm your selection.



Push the button indicated by the arrow (→)

9. If the **SET CH2 LEAD?** prompt appears, press the **NEXT/NO** button to keep the default (OFF) or the **ENTER/YES** button to make a change.



Choose a button indicated by the question mark (?)

- The maintenance-option EIA leads configure loopback testing for the data module. You do not need to set any specific options. So, when the **SET LL LEAD?** prompt appears, press the **NEXT/NO** and **BACK** buttons together to return HOME.



Push the button indicated by the arrow (→)

- When the **SAVE CHANGES?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

The **CHANGES SAVED** message flashes on screen, and you return to the HOME screen. The data module is now configured.

### Restoring factory defaults on 7400A DTE

If necessary, you can always revert to the factory default settings. From the HOME screen, proceed as follows.

- To access the menus, press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

- When the **SET OPTIONS?** prompt appears on the LCD, press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

- When the **VIEW OPTIONS?** prompt appears on the LCD, press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

- When the **TEST - RESET?** prompt appears on the LCD, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

- When the **DATA LOOPBACK?** prompt appears on the LCD, press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

- When the **SELF-TEST?** prompt appears on the LCD, press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

- When the **LOCAL LOOPBACK?** prompt appears on the LCD, press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

8. When the **LOCAL LOOP/ST?** prompt appears on the LCD, press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

9. When the **REMOTE LOOPBACK?** prompt appears on the LCD, press the **NEXT/NO** button.




Push the button indicated by the arrow (→)

10. When the **RESET OPTIONS?** prompt appears on the LCD, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

The factory options are restored, and you return to the HOME screen.



## Configuring the 7400B Data Module

The factory default settings for the 7400B data module are generally satisfactory. But if you need to change them, you use a terminal device and the AT command language commonly used by Hayes-compatible modems (7400B data modules have no control buttons). While a full explanation of the Hayes command set is beyond the scope of this book, the following sections sketch the basic processes involved in changing the factory settings.

### Installing required configuration equipment for the 7400B

Before you can enter AT configuration commands, you must first connect a terminal or a PC with a keyboard, monitor, and terminal-emulation software to the data module. Proceed as follows.

1. Connect one end of an RS-232 cable to an RS-232, serial-communications port (often called a COM port) on the terminal or PC.
2. Connect the other end of the RS-232 cable to Port 1 of the data module
3. If you are using a PC, start your terminal emulation software.

### Selecting command mode on the 7400B

When it is transmitting and receiving data, the 7400B data module is online, in data mode. To configure the 7400B, you have to switch it to command mode. Proceed as follows.

1. From the terminal keyboard, enter the escape sequence: **+++**  
The data module enters command mode and displays the **OK** result code.

### Displaying the current configuration on the 7400B

1. Enter **at&v**

### Enabling automatic answering on the 7400B

1. Enter **ats0=nnn**  
where **nnn** is a decimal number in the range **1-255**.

### Enabling remote operation on the 7400B

The exact configuration of any particular 7400B data module depends on what it is being used for. Consult a list of Hayes-compatible AT commands to see what is possible. The following is an example of a typical, custom configuration.

The 7400B Data Module can be used at a remote site as a dedicated service device to answer incoming data calls, send data to a remote end device, and then hang up. For example, you might wish to provide access to a printer from a remote site. The following is a typical command line you might use for setting up this operation (spaces are used here for readability, but are not required):

1. **at &c1 &d2 q1 s0=1 &w0 &y0**

where:

- **at** puts the modem in command mode
- **&C1** sets the Data Carrier Detect (DCD) circuit of the data module to operate according to the EIA standard
- **&D2** sets the data module to go on hook when an on-to-off transition is detected on the Data Terminal Ready (DTR) input, disconnecting the call
- **Q1** turns off the result codes that would be the normal responses of the data module to commands that it receives.
- **S0=1** turns on the automatic answer feature and causes the data module to answer an incoming data call on the first ring
- **&W0** causes the current configuration to be stored in profile **0**
- **&Y0** selects the configuration stored in profile **0** to become the current configuration each time the data module is powered on

### Configuring the 7400B for remote administration

1. At the command prompt of your terminal-emulation software or terminal, enter **at&c1&d2&s1s0=1&w0&w1&y0**

where:

- **at** puts the modem in command mode
- **&c1** tells the modem to respond to DCD
- **&d2** tells the modem to respond to DTR
- **&s1** tells the modem to respond to DSR
- **s0=1** tells the modem to auto answer on the first ring
- **&w0** tells the modem to save changes in profile **0**
- **&w1** tells the modem to save changes in profile **1**
- **&y0** tells the modem to use profile0 after a power failure

### Restoring factory defaults for the 7400B

1. Enter **at&F**

### Exiting command mode on the 7400B

After configuring the 7400B, exit command mode, and put the data module back online.

1. Enter **O** (capital O).

### Configuring the 7400C HSL (High-Speed Link) Data Module

Figure 15 shows the front and rear of a 7400C synchronous data module.




Figure 15. 7400C Data Module (High Speed Link)

### Setting the data speed for the 7400C

Proceed as follows.

1. From the HOME screen, press the **NEXT/NO** button until **SET DATA OPTS?** appears. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

2. When **SET SPEED?** appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

The current transmission speed appears: **SPEED = 56KBPS?** (the default) or **SPEED = 64KBPS?**

3. To keep the existing speed, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

4. To change the existing speed, press **NEXT/NO**.



Push the button indicated by the arrow (→)

When the **SPEED ->NewSpeed?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

5. The **CONTINUE?** prompt appears. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

6. If you want to set any other options, skip to the following section.

7. Otherwise, if you want to quit now, press **NEXT/NO** until **DONE?** appears. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

8. When **SAVE CHANGES?** appears, press the **ENTER/YES** button again.



Push the button indicated by the arrow (→)

**CHANGES SAVED** appears, and the data module returns to the HOME screen.

### Setting other data options for the 7400C

You can usually use the default settings for all other options. However, two exceptions are discussed below.

#### Selecting data inversion for 64-kbps, HDLC transmissions on restricted facilities

Data inversion is available when you are transmitting at 64 kbps over restricted facilities using HDLC-based protocols. Proceed as follows.

1. If you need compatibility with an ACCUNET MPDM, set **DATA INVERSION** to **ON** using the menus and controls as described above, in [“Setting the data speed for the 7400C”](#).
2. Otherwise, set **DATA INVERSION** to **OFF**.
3. Exit and save changes, as described above, in [“Setting the data speed for the 7400C”](#).

### Configuring the 7400C for a dedicated private line

The factory default settings assume that the data module connects to a switched, dial-up line. Private lines are permanent, unswitched connections, so they have to be specially configured. Proceed as follows.

1. Set the dialing method to **MANUAL**, using the menus and controls as described above, in [“Setting the data speed for the 7400C”](#).
2. Set the answering mode (**ANS**) to **AUTO**.
3. Set the **DTR** lead to **IGNORE**.

4. Set the **DSR lead** to **ON**.
5. Set **PERMANENT CONNECTION** to **YES**.
6. Exit and save changes, as described above, in [“Setting the data speed for the 7400C”](#).

## Configuring the 7400D Data Module

The 7400D data module is a converted 7400A used for synchronous data transmission ([Figure 16](#)). It is a direct replacement for the MPDM. You configure the 7400D just as you would a 7400A, except that there is no SET INTERFACE option (the 7400D is an answer-only device that cannot originate calls). It supports DCE mode only. DTE modem-pooling is not supported. The PHONE and PORT2 connectors are not used.

The following table lists recommended settings for a typical installation. For the configuration procedure, see the subsequent sections.

### Recommended settings for typical configurations

The table below summarizes the recommended configuration values for the 7400D data module. The procedures for setting these values follow.

Options	CMS settings	DCS settings
<b>300</b>	<b>OFF</b>	<b>OFF</b>
<b>1200</b>	<b>OFF</b>	<b>OFF</b>
<b>2400</b>	<b>OFF</b>	<b>OFF</b>
<b>4800</b>	<b>OFF</b>	<b>OFF</b>
<b>9600</b>	<b>ON (OFF for R8r)</b>	<b>ON</b>
<b>19200</b>	<b>OFF (ON for R8r)</b>	<b>OFF</b>
<b>ANSWER</b>	<b>AUTO</b>	<b>AUTO</b>
<b>CI</b>	<b>OFF</b>	<b>ON</b>
<b>CH LEAD</b>	<b>OFF</b>	<b>OFF</b>
<b>CTS LEAD</b>	<b>NORMAL</b>	<b>NORMAL</b>
<b>DCD LEAD</b>	<b>NORMAL</b>	<b>ON</b>
<b>DSR LEAD</b>	<b>NORMAL</b>	<b>ON</b>
<b>DTR DETECT</b>	<b>50 MSEC</b>	<b>50 MSEC</b>
<b>DTR LEAD</b>	<b>FOLLOW</b>	<b>IGNORE</b>

*Continued on next page*

Options	CMS settings	DCS settings
RI LEAD	ON	ON
SIGLS DISC	ON	ON
TM LEAD	OFF	OFF





Figure 16. 7400D Data Module

### Accessing the menus of the 7400D

You configure the 7400D from a set of menus.

1. To access the menus, press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

- When the **SET OPTIONS?** prompt appears on the LCD. Press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

- The **VIEW OPTIONS?** prompt appears. Press the **NEXT/NO** button.



Push the button indicated by the arrow (→)

### Setting speed options for the 7400D

The data speed depends on the exact application, but most require 9600 bps or, less commonly, 19200.

- Press the **NEXT/NO** button to continue with the setup procedure.



Push the button indicated by the arrow (→)

- The **SET OPTIONS?** prompt appears on the LCD. Press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

A series of **SET number SPEED?** prompts appears.

3. Press the **NEXT/NO** button until you see the **SET yourSpeed SPEED?** prompt. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

4. Press the **NEXT/NO** button until you see the **yourSpeed=ON?** prompt. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

5. If the **CONTINUE?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

### Setting the automatic-answer feature on the 7400D

You can set up the 7400A data module to automatically answer calls or you can have it ignore calls until an operator answers manually. Set up the data module for automatic answering unless specifically directed to otherwise.

1. When the **SET ANSWER?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

- When the **ANS = AUTO?** prompt appears, press the **ENTER/YES** button for most applications.



Push the button indicated by the arrow (→)

### Configuring the RS-232 interface of the 7400D

From the front panel, you can set each pin of the RS-232 cable to meet the needs of specific applications, though in most cases, the settings below should work.

- When the **SET CI LEAD?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

- Press the **NEXT/NO** button until you see the **CI = correctSetting?** or **CI -> correctSetting?** prompt. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

- When the **CONTINUE?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

- When the **SET CH LEAD?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

5. Press the **NEXT/NO** button until you see the **CH = correctSetting?** or **CH - > correctSetting?** prompt. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

6. When the **CONTINUE?** prompt appears, press the **ENTER/YES** button.
7. When the **SET CTS LEAD?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

8. Press the **NEXT/NO** button until you see the **CTS = correctValue?** or **CTS -> correctValue?** prompt. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

9. When the **CONTINUE?** prompt appears, press the **ENTER/YES** button.
10. When the **SET DCD LEAD?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

11. Press the **NEXT/NO** button until you see the **DCD = correctValue?** or **DCD -> correctValue?** prompt. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

12. When the **CONTINUE?** prompt appears, press the **ENTER/YES** button.  
13. When the **SET DSR LEAD?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

14. Press the **NEXT/NO** button until you see the **DSR = correctValue?** or **DSR -> correctValue?** prompt. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

15. When the **CONTINUE?** prompt appears, press the **ENTER/YES** button.  
16. When the **SET DTR DETECT?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

17. Press the **NEXT/NO** button until you see the **DTR = correctValue MSEC?** or **DTR -> correctValue MSEC?** prompt. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

18. When the **CONTINUE?** prompt appears, press the **ENTER/YES** button.
19. When you see the **SET DTR LEAD?** prompt, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

20. Press the **NEXT/NO** button until the **DTR = correctValue?** or **DTR -> correctValue?** prompt appears. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

21. When the **CONTINUE?** prompt appears, press the **ENTER/YES** button.
22. When the **SET LL LEAD?** prompt appears, press the **NEXT/NO** button to skip this setting.



Push the button indicated by the arrow (→)

23. When the **SET LL DETECT?** prompt appears, press the **NEXT/NO** button to skip this setting.



Push the button indicated by the arrow (→)

24. When the **SET RI LEAD?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

25. Press the **NEXT/NO** button until the **RI = correctValue?** or **RI > correctValue?** prompt appears. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

26. When the **CONTINUE?** prompt appears, press the **ENTER/YES** button.  
 27. When the **SET RL LEAD?** prompt appears, press the **NEXT/NO** button to skip this setting.



Push the button indicated by the arrow (→)

28. When the **SET SIGLS DISC?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

29. Press the **NEXT/NO** button until the **SIGLS DISC = correctValue?** or **SIGLS DISC -> correctValue?** prompt appears. Then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

30. When the **CONTINUE?** prompt appears, press the **ENTER/YES** button.  
 31. When the **SET TM LEAD?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

32. Press the **NEXT/NO** button until the **TM = OFF?** or **TM -> OFF?** prompt appears, then press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

33. When the **DONE?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

34. When the **SAVE CHANGES?** prompt appears, press the **ENTER/YES** button.



Push the button indicated by the arrow (→)

The **CHANGES SAVED** message flashes on screen, and you return to the HOME screen. The data module is now configured.

## Configuring the 8400B Plus Data Module

Figure 17 shows the rear of a 8400B plus asynchronous data module. The unit provides integrated voice and data communications over standard, 2-wire, twisted-pair circuits within 2000 ft. of a DEFINITY. The unit can emulate a Hayes-compatible interface for standard personal computer (PC) communication. The options for the 8400B Plus are set from the rear panel interface. Refer to *DEFINITY Communications System User's Guide* for procedures.




Figure 17. 8400B Plus Data Module

### Installing required configuration equipment for the 8400B

Before you can enter configuration commands, you must first connect a terminal or a PC with a keyboard, monitor, and terminal-emulation software to the data module. Proceed as follows.

1. Connect one end of an RS-232 cable to an RS-232, serial-communications port (often called a COM port) on the terminal or PC.
2. Connect the other end of the RS-232 cable to Port 1 of the data module
3. If you are using a PC, start your terminal emulation software.

### Selecting 8400B options

On the 8400B data module, all configuration options are enabled by default. You configure the 8400B by disabling options with a code that you enter in a memory register (S24) in the data module. Consult the table below, and perform the steps that follow.

Table 12. Codes for disabling default settings of the 8400B data module

Default setting	Disabling code
With Telephone	1
US Companding	2
Telephone Provides Dialing	4

*Continued on next page*

Table 12. Codes for disabling default settings of the 8400B data module

Default setting	Disabling code
Disable Data Metering Feature	16
Immediate Speakerphone Activation	32
Automatic Speakerphone Activation	64
Disable Busyout During Local Loopback Test	128

Proceed as follows.

1. Calculate an option-selection value using [Figure 12, "Codes for disabling default settings of the 8400B data module"](#). Add up the disabling codes for all options that you wish to disable.

For example, if you turned off **With Telephone, US Companding, Disable Data Metering Feature**, the selection code would be:

$$1 + 2 + 16 = 19$$


2. Check the current data-module setting by entering **ATS24?**.
3. If the current value does not match the selection value you calculated, enter **ATS24=nnn**, where *nnn* is the selection value you calculated.

## Configuring the ExpressRoute 1000 Data Module

You can substitute an ExpressRoute 1000 data module for the 8400B data module. Both DCP and ISDN-BRI connections are possible. [Figure 18](#) shows typical connections.

### CAUTION:

*In DC-powered cabinet installations, a 105C Isolator adapter is required when connecting equipment to a data module.*



1. To BRI circuit pack or DCP digital line circuit pack
2. Main distribution frame (MDF)
3. ExpressRoute 1000 data module
4. PC administration terminal
5. Modular line cord
6. M25B (25-Pin RS-232) cable

Figure 18. Typical ExpressRoute 1000 Data Module Connections

## Administer the DEFINITY ECS for Data Modules

You have to administer each data module that you attach to the system.

### ⇒ NOTE:

Only the basic procedure is covered here. For the full range of options, see the *DEFINITY Enterprise Communications Server Release 8 Administrator's Guide*.

1. Locate an available port. At the DEFINITY ECS administration console, enter

**list config port**

```
list configuration port-network Page 1
SYSTEM CONFIGURATION
Board
Number Board Type Code Vintage Assigned Ports
u=unassigned t=tti p=psa
01A01 POOLED MODEM TN758 000002 u u u u
01A02 DATA LINE TN726B 000002 u u u u u u u u
01A03 AUXILIARY TRUNK TN763D 000005 01 02 u u
01A04 ANNOUNCEMENT TN750C 000006 01 02 03 04 05 06 07 08
09 10 11 12 13 14 15 16
u
01A05 DIGITAL LINE TN2181 000007 01 02 u u u u u u
u u u u u u u u
01A07 CO TRUNK TN2138 000001 u u u u u u u u
01A08 DIGITAL LINE TN754B 000002 01 02 03 04 05 06 07 08
01A09 CONTROL-LAN TN799 000001 01 02 u u u u u u
press CANCEL to quit -- press NEXT PAGE to continue
```

Screen 1. Typical system-configuration listing

2. Locate an unassigned port on a suitable circuit pack, and make a note of the corresponding port number.

The port number is the **Board Number**, **UUCSS** (where **UU** is the 2-digit cabinet number, **C** is the single-character carrier identifier, and **SS** is the 2-digit slot number) followed by the next 2-digit number, **PP**, in the sequence in the **Assigned Ports** fields at the right side of the form: **UUCSSPP**.

For example, in the listing above, the next available port address for the TN2181 digital line circuit pack would be **01A0503**.

3. From the DEFINITY administration console, open a new data-module form by typing

**add data-module next**

The system automatically assigns the next available extension number to the data module.

```
add data-module next                                     Page 1 of 1
                                     DATA MODULE
Data Extension: 2002                                     Name: _____ BCC: 2
Type: pdm                                               COS: 1             Remote Loop-Around Test? n
Port: █                                               COR: 1            Secondary data module? n
ITC: restricted                                         TN: 1             Connected To: dte

ABBREVIATED DIALING
List1: _____

SPECIAL DIALING OPTION: _____

ASSIGNED MEMBER ( Station with a data extension button for this data module )

    Ext      Name
1:
```


## Screen 2. Typical data-module form

4. In the **Port** field, enter the seven-digit port address that you wrote down in step 2, above.
5. If you installed a telephone on the data module, enter the extension number and station name for this telephone in the **ASSIGNED MEMBER** part of the form.
6. Press the F3 key to close the form and save the changes.

## Asynchronous Data Units (ADUs)

ADUs are used with Data Line circuit packs to connect peripherals, such as printers, data terminals, fax equipment, and call-detail recording equipment to the DEFINITY. Figure 19 shows a typical Z3A2 ADU assembly (without a cable).

- Add a female-to-male EIA-232 cable (shown) to make a Z3A1 ADU assembly.
- Add a female-to-female EIA-232 cable (not shown) to make a Z3A4 ADU assembly.



- |  |   |
|--|---|
| 1. Z3A2 ADU  | 4. Telephone jack (to analog telephone) |
| 2. 25-pin male D-connector (EIA-232-D) to DTE  | 5. Originate/disconnect jack            |
| 3. Wall jack connector (to data line circuit pack or analog line circuit pack or equivalent) | 6. Female connector on EIA-232-D cable  |
|  | 7. Male connector on EIA-232-D cable    |

Figure 19. Z3A2 Asynchronous Data Unit (ADU)

Refer to the tables in Appendix A, "Connector and Cable Pinout Charts", for the pinouts of the TN726B data line circuit pack and TN2183 analog line circuit pack (or equivalents) in the cabinet.

## External Modems

# 5

---

The following section assumes that you are using one of the recommended modems. However, any locally obtained, type-approved external modem should work. Contact your Avaya representative for more information.

Recommended modems include:

- Paradyne Comsphere 3715
- Paradyne Comsphere 3810 Plus and 3811 Plus
- Paradyne Comsphere 3910
- U.S. Robotics (various models)

## Hardware required when configuring modems

---

To configure many modems, you use the Hayes-compatible AT command set. Before you can enter AT configuration commands, you must first connect a terminal or a PC with a keyboard, monitor, and terminal-emulation software to the modem. Proceed as follows.

1. Connect one end of an RS-232 cable to an RS-232, serial-communications port (often called a COM port) on the terminal or PC.
2. Connect the other end of the RS-232 cable to the modem.
3. If you are using a PC, start your terminal emulation software.

## PARADYNE COMSPHERE 3715

---

You configure COMSPHERE 3715 modems using the Hayes-compatible AT commands common to many modems. For instructions on how to physically connect the modem and enter the commands listed in the instructions below, see the documentation that came with the modem.

### Configuring the 3715 for CMS

---

The instructions below set up the modem for use in a DEFINITY ECS Call Management System (other configurations may work as well).

1. From the command line prompt of your terminal emulation software or terminal, enter **at&f**.

This loads factory default configuration options into active memory. If all is well, the modem replies **OK**.

2. Enter **at%b9600**.

This sets the data speed to 9600 kbps. If all is well, the modem replies **OK**.

3. Enter **atq1&r0&S1\d1&w0**.

This disables result codes, sets the RTS (Request To Send), DSR (Data Set Ready), CTS (Clear To Send) signals action to standard RS-232 operation, and saves the changes to profile **0**. If all is well, the modem replies **OK**.

### Configuring the 3715 for modem pooling

---

The instructions below set up the modem for use in a DEFINITY modem pool (other configurations may work as well).

1. From the command line prompt of your terminal emulation software or terminal, enter **at &f**.

This loads factory default configuration options into active memory. If all is well, the modem replies **OK**.

2. Enter **at m0 x7 y0 &s1 /d1**.

If all is well, the modem replies **OK**.

3. Enter **at e0 v0 c2=128 s7=60 f10=100 &w0 &y0**.

If all is well, the modem replies **OK**.

## PARADYNE COMSPHERE 3810 Plus and 3811 Plus

---

1. Install the modem as described in the vendor's documentation.
2. Attach a PC with terminal emulation software, as described in the vendor's documentation.
3. From the terminal, enter the following AT command string:

**AT&F&D2&S4\D3S2=128x7V2S7=60S85=1**

4. Then enter the following command string:


**ATY0S10=100S78=2M0E0\N1&W**

The modem is now configured.

## Setting Up the PARADYNE COMSPHERE 3910

---

You configure COMSPHERE 3910 modems using a front button panel or Hayes-compatible AT commands. For instructions on how to physically connect the modem and general configuration instructions, see the documentation that came with the modem. This document describes configuring the 3910 for particular, DEFINITY adjuncts.



---

Figure 20. COMSPHERE 3910 modem, front panel

## Configuring the COMSPHERE 3910 for CMS

---

The COMSPHERE 3910 modem may be used as the Call Management System (CMS) Remote Console Modem or as a device that provides serial connectivity to CMS through the Network Terminal Server (NTS). The instructions below set up the modem for use in DEFINITY CMS (other configurations may work as well).

### Understanding the modem controls and displays

You control the modem by using the buttons on the front panel of the modem to change menus and select menu items displayed on a small LCD screen. The buttons do the following:

 **NOTE:**

The arrow and function buttons described in this section are located on the front panel of the modem, not on a PC keyboard or terminal.

- **Single Up Arrow** moves up one level in the menu tree.
- **Double Up Arrow** moves to the top level of the menu tree.
- **Left Arrow** moves to the previous choice at the current level of the menu tree.
- **Right Arrow** moves to next choice at the current level of the menu tree.
- **F1** selects the choice displayed above **F1**.
- **F2** selects the choice displayed above **F2**.
- **F3** selects the choice displayed above **F3**.

For our purposes, the on-screen prompt *strap group* indicates a collection of related configuration settings.

Modem menus can be confusing because you only get to see one or two headings or items at a time. The modem also has a limited set of command words, so many of them have to be used more than once, and commands seem to be repeating themselves. This can be confusing. To avoid missing a step, check the values on the display after you enter a command, and make sure the result agrees with that listed in the corresponding step in the instructions.

## Creating an editable configuration set

It is generally easiest to configure the modem by starting from the default, factory configuration. You then change only those settings that are different for a DEFINITY installation.

### Copying factory default settings

Make a copy of the default, factory configuration using the following procedure.

1. On the front panel of the COMSPHERE 3910, press the **F2** button to select **Configure**.

The **Ld EditArea frm >** prompt appears.

2. Press the right-arrow button four times.

The **Factory** menu item appears.

3. Press the **F1** button to select **Factory**.

The **Ld Fact Preset: >** prompt appears.

4. Press the right-arrow button.

5. Press **F2** to select **Async\_Dial**.

6. Press **F3** to select **Save**.

The **Sav EditArea to >** prompt appears.

7. Press **F1** to save configuration changes to the **Active(Saved)** storage area.

Since you are changing the active area to a new set of options—**Factory/Async\_Dial**—the modem automatically runs a power-on self-test. The **Idle:19.2** and **Status Configure** messages appear.

8. To return to the top-level menu at any time, press the double up-arrow button.

### Loading the copied default settings

Load the default settings so that you can edit them for use with CMS. Proceed as follows.

1. On the front panel of the COMSPHERE 3910, press **F2** to select **Configure**.

The **Ld EditArea frm >** prompt appears.

2. Press the right-arrow button once.

The **Active(Saved)** prompt appears.

3. Press **F1** to select **Choose Function**.

4. Press **F1** to select **Edit**.

The **Edit StrapGroup >** prompt appears.

## Configuring the DTE interface

Set the data speed and enable standard, RS-232 communications settings. Proceed as follows.

### Configuring basic, RS-232 handshaking

Start by selecting values for the basic parameters of serial data communications, mode, speed/rate, framing, and error correction (parity). The modem uses these parameters when it negotiates a connection with another RS-232 device, a process called *handshaking*.

1. From the **Edit StrapGroup >** prompt, press **F1** to select **DTE\_Interface**.  
The **Async/Sync Mode** menu heading appears.
2. Press **F1** to select **Nxt**.  
The **Async DTE Rate** menu heading appears.
3. Press the right-arrow button five times.  
The **9600** menu item appears.
4. Press **F2** to select **9600**.
5. Press **F1** to select **Nxt**.  
The **Asyn #Data Bits (8)** menu heading appears.
6. Press **F1** to select **Nxt**.  
The **Asyn Parity Bit (None)** menu heading appears.
7. Press **F1** to select **Nxt**.  
The **Asyn #Stop Bits (1)** menu heading appears.
8. Press **F1** to select **Nxt**.  
The **DTR Action** menu heading appears.

### Configuring the RS-232 Ready signals, DTR and DSR

Next, configure the Data Terminal Ready and Data Set Ready leads of the RS-232 interface.

1. From the **DTR Action** menu heading, press the right-arrow button once.  
The **Stndrd\_RS232** menu item appears.
2. Press **F2** to select **Stndrd\_RS232**.
3. Press **F1** to select **Nxt**.  
The **DSR Control** menu heading appears.
4. Press the right-arrow button once.  
The **Stndrd\_RS232** menu item appears.

5. Press **F2** to select **Stndrd\_RS232**.
6. Press **F1** to select **Nxt**.

The **RTS Action** menu heading appears.

### Configuring RS-232 Send signals, RTS and CTS

Next you set the parameters that the modem uses to offer and accept data, Request To Send (RTS) and Clear To Send (CTS).

1. From the **RTS Action** menu heading, press the right-arrow button once.

The **Stndrd\_RS232** menu item appears.

2. Press **F2** to select **Stndrd\_RS232**.
3. Press **F1** to select **Nxt**.

The **CTS Control** menu heading appears.

4. Press the right-arrow button once.

The **Stndrd\_RS232** menu item appears.

5. Press **F2** to select **Stndrd\_RS232**.
6. Press **F1** to select **Nxt**.

The **RTS/CTS Delay (0 msec)** menu heading appears.

### Configuring various control features

Now set the Line Signal Detect (LSD, also known as DCD or Data Carrier Detect) control and rate controls.

1. Press **F1** to select **Nxt**.

The **LSD Control (Stndrd\_RS232)** menu heading appears.

2. Press **F1** to select **Nxt**.

The **CT111\_Rate Cntl (Disable)** menu heading appears.

3. Press **F1** to select **Nxt**.

The **DTE\_Rate=VF (Disable)** menu heading appears.

4. Press **F1** to select **Nxt**.

The **Extend Main Ch. (Disable)** menu heading appears.

### Finishing configuration of the DTE interface

1. Press **F1** select **End**.

The **Edit StrapGroup >** prompt appears.

## Configuring the DTE Dialer

Now define the command interface that the modem should use when dialing. The RS-232 interface uses control characters to pass communications commands and control the transmission. These are user-configurable. We need to disable the result-code options while retaining the default values for the other control characters. Proceed as follows.

### Opening the DTE Dialer menus

1. From the **Edit StrapGroup >** prompt, press the right-arrow button once.  
The **DTE Dialer** menu heading appears.
2. Press **F1** to select **DTE\_Dialer**.  
The **DTE Dialer Type (AT)** menu heading appears.

### Skipping to the result-code options

To reach the options we need to set, we have to skip over a number of other options without making changes. Proceed as follows.

1. From the **DTE Dialer Type (AT)** menu heading, press **F1** to select **Nxt**.  
The **AT Escape Char** menu heading appears.
2. Press **F1** to select **Nxt**.  
The **Escape GuardTim** menu heading appears.
3. Press **F1** to select **Nxt**.  
The **BreakForceEscap** menu heading appears.
4. Press **F1** to select **Nxt**.  
The **CommandCharEcho** menu heading appears.
5. Press **F1** to select **Nxt**.  
The **CarriageRtn Char** menu heading appears.
6. Press **F1** to select **Nxt**.  
The **Backspace Char** menu heading appears.
7. Press **F1** to select **Nxt**.  
The **Linefeed Char** menu heading appears.
8. Press **F1** to select **Nxt**.  
The **ResultCodes (Enable)** menu heading appears.

## Disabling result codes

We have reached the options that we need to change. Proceed as follows.

1. From the **ResultCodes (Enable)** menu heading, press the right-arrow button once.

The **Disable** menu item appears.

2. Press **F2** to select **Disable**.

3. Press **F1** to select **Nxt**.

The **ExtendResltCode (Enable)** menu heading appears.

4. Press the right-arrow button once.

The **Disable** menu item appears.

5. Press **F2** to select **Disable**.

## Exiting the DTE Dialer menu

Skip over the remaining menu headings. Proceed as follows.

1. Press **F1** to select **Nxt**.

The **ResultCode Form** menu heading appears.

2. Press **F1** to select **Nxt**.

The **AT Cmnd Mode** menu heading appears.

3. Press **F1** to select **End**.

The **Edit StrapGroup >** menu heading appears.

## Configuring the Data Line

Set the line speed and accept the default values for the other settings. Proceed as follows.

### Opening the dial line menu

1. From the **Edit StrapGroup >** menu heading, press the right-arrow button twice.

The **Dial\_Line** menu item appears.

2. Press **F1** to select the **Dial\_Line** menu heading.

The **Dial Line Rate** menu heading appears.

### Setting the line rate

1. From the **Dial Line Rate** menu heading, press the right-arrow button four times.

The **9600(V32b)** menu item appears.

2. Press **F2** to select **9600(V32b)**.

## Exiting the dial line menu

Skip over the remaining menu headings. Proceed as follows.

1. Press **F1** to select **Nxt**.  
The **V32bis Automode (Enable)** menu heading appears.
2. Press **F1** to select **Nxt**.  
The **V32bis Autorate (Enable)** menu heading appears.
3. Press **F1** to select **Nxt**.  
The **Dial Tx Level (Permissv (-9))** menu heading appears.
4. Press **F1** to select **Nxt**.  
The **V22b Guard Tone (Disable)** menu heading appears.
5. Press **F1** to select **Nxt**.  
The **V32bis Train (Long)** menu heading appears.
6. Press **F1** to select **End**.  
The **Edit StrapGroup >** prompt appears.

## Saving the new configuration

You must save the configuration changes you have made before you can use them.

1. From the **Edit StrapGroup >** prompt, press the single up-arrow button once.  
The **Choose Function, Edit, and Save** menu headings appear.
2. Press **F3** to select **Save**.  
The **Save EditArea to >** prompt appears.
3. Press **F1** to select **Active(Saved)**.  
The **Command Complete** message appears.
4. Press the single up-arrow button again.  
The **Save EditArea to >** prompt appears.
5. Press the right-arrow button once to select **Customer 1**.
6. Press **F1** to save changes to the **Customer 1** storage area.  
The **Command Complete** message appears.
7. Press the double up-arrow button once.  
The **Idle:9600** and **Status Configure** messages appear. When you power off the modem, it should return to this state.

## Checking the status of the COMSPHERE 3910 modem

To check the status of the COMSPHERE 3910 modem at any time, proceed as follows.

1. From the topmost menu, select the **Status** menu item.

## Setting Up the U.S. Robotics Modem for DEFINITY

The U.S. Robotics modem external modem is recommended for DEFINITY systems. For instructions on how to physically connect it and for general configuration instructions, see the documentation that came with the modem. This document describes configuring the modem for particular DEFINITY adjuncts.

All configuration is done via hardware switches. Proceed as follows.

1. Set the DIP switches on the modem to match the settings listed in the table below (for switch locations, consult the documentation that came with the modem).

**Table 13. U.S. Robotics External Modem Switch Settings**

Switch	Setting	Function
1	OFF (Up)	DTR (Data Terminal Ready) override
2	OFF (Up)	Result codes
3	ON (Down)	Result codes
4	OFF (Up)	Keyboard command echo
5	ON (Down)	Auto answer
6	OFF (Up)	CD (Carrier Detect) override
7	OFF (Up)	Power-on and ATZ reset software defaults
8	ON (Down)	AT command recognition

## Administering the DEFINITY for Modems

---

You have to administer each modem that you attach to the system.



### NOTE:

Only the basic procedure is covered here. For the full range of options, see the *DEFINITY ECS Release 10 Administrator's Guide*.

### Accessing the Administration Form

1. Open the modem-administration form. At the management terminal, enter **change system-parameters maintenance**.
2. Scroll to page 3 of the form.

### Identifying the modem

1. On the modem-administration form, set the **Modem Connection:** field to **external** (it should be set to **none** if no modem is installed).  
  
This field generates alarms if it is not administered correctly. It cannot be set to **none** if **Alarm Origination** is activated.
2. Set the **Modem Name:** field to a unique, 20-character, alphanumeric identifier.

### Setting data-transmission parameters

1. On the modem-administration form, set the **Data Bits:** field to **8** (the default).
2. Set the **Parity:** field to **none** (the default).
3. Set the **RTS/CTS Enabled:** field to **&H1** (unless you have an Intel modem, in which case set it to **\Q3**).  
  
This enables flow-control.
4. Set the **Asynchronous Data Mode:** field to **&M0**, the default (unless you have an Intel modem, in which case set it to **\J1**).
5. Set the **DTE Auto-Data Speed:** field to **S90=1** (unless you have an Intel modem, in which case set it to **&M0&Q0**).

This lets the modem automatically adjust the data speed to match the requirements of the remote equipment.

## 5 External Modems

### Administering the DEFINITY for Modems

89

6. Set the **Disable Data Compression:** field to **%C0** (unless you have an Intel modem, in which case set it to **H0%C0**, or a U.S. Robotics 839, in which case the option is not available).

This disables V.42bis and MNP Class-5 data compression.

7. Set the **Enable Error Control:** field to **IN5** (unless you have an Intel modem, in which case set it to **IN3**).

This enables LAPM and MNP error control.

### Setting dialing parameters

1. Set the **Auto-Answer Ring Number:** field to **S0=10**.

This specifies the number of rings that the modem waits before answering an incoming call.

2. Set the **Dial Type:** field to **T** for tone dialing (the default) or **P** for pulse dialing.

3. Set the **Adjustable Make/Break Ratio:** field to **&P0** for the United States and Canada, **&P1** for the United Kingdom and Hong Kong.

Controls the make/break ratios of pulses and DTMF dialing. The United States and Canada use 39% make and 61% break. The United Kingdom and Hong Kong use 33% make and 67% break

4. Set the **Dial Command:** field to **D**.

Specifies standard dialing command.

### Setting additional, modem-specific parameters

1. Put any remaining AT configuration commands required by your modem in the **Misc. Init. Param:** field.

### Exiting the form and saving the changes

1. When you are finished, press ENTER.

<b>5</b>	External Modems	
	<i>Administering the DEFINITY for Modems</i>	90

# Printers

# 6

This chapter provides information on configuring the various printers supported by Avaya.

## Configuring the AT&T Model 572

An AT&T Model 572 printer functions as a CDR device, system printer, or journal printer. The options are set with function keys rather than DIP switches. [Figure 21](#) shows the arrangement of the function keys on the printer control panel.




Figure 21. Control Panel for 572 Printer

## Entering Setup Mode

---

1. Load paper.
2. Turn the **Power On** button OFF.
3. Simultaneously press and hold the **Print Quality** and **On Line** buttons.
4. Without releasing the **Print Quality** and **On Line** buttons, press the **Power On** button.
5. Release all three buttons.

The printer is now in set-up mode. It prints its current settings.

## Selecting the Correct Configuration for Your Application

---

1. If the printer is used with a PC, as a CDR reporting device, or as a journal printer, set the options as shown below.

Function	Function Name	Menu	Menu Status
01	FORM LENGTH	09	11
02	LPI	01	6
03	CPI	01	10
04	LQ or NLQ	01	LQ
05	BUZZER	01	ON
06	FONT	02	FONTCART
07	RESOLUTION	01	144
11	BUFFER	02	N-LINE
13	PW ON MODE	01	ON-LINE
14	DIRECTION	01	B1-DIR.1
15	BUFF FULL	02	LF + CR
16	P.E.	01	ACTIVE
17	AUTO CARRIAGE RETURN (CR)	01	CR + LF
18	ZERO	01	0
22	AUTO LINE FEED	01	CR ONLY
31	1" SKIP	01	OFF
32	CHAR.SET (GO, GL)	02	USA

---

*Continued on next page*

Function	Function Name	Menu	Menu Status
33	CHAR.SET (G1, GR)	01	UK
34	CHAR SET (G2)	03	GE
35	CHAR SET (G3)	07	LINE DRAWING
81	OFF-LINE STATE	01	ALL RECEIVE
82	DSR	02	OFF
83	REQUEST TO SEND (RTS) TIMING	01	RTS
84	CD	02	OFF
85	CLEAR TO SEND (CTS)	02	OFF
91	OVER RUN	02	256
92	DATA BIT	02	8
93	PROTOCOL	03	XON/XOFF
94	STOP BIT	01	1
95	PARITY	01	NONE
96	PBS (matches connected device)	01	9600

- If the printer is used as the system printer, set the options as shown in [Table 14](#).

**Table 14. 572 Printer Used as System Printer**

572 Printer Option Settings			
Function	Function Name	Menu	Menu Status
01	FORM LENGTH	09	11
02	LPI	01	6
03	CPI	01	10
04	LQ or NLQ	01	LQ
05	BUZZER	01	ON
06	FONT	02	FONTCART

*Continued on next page*

Table 14. 572 Printer Used as System Printer — *Continued*

572 Printer Option Settings			
Function	Function Name	Menu	Menu Status
07	RESOLUTION	01	144
11	BUFFER	02	N-LINE
13	PW ON MODE	01	ON-LINE
14	DIRECTION	01	B1-DIR.1
15	BUFF FULL	02	LF + CR
16	P.E.	01	ACTIVE
17	AUTO CARRIAGE RETURN (CR)	01	CR + LF
18	ZERO	01	0
22	AUTO LINE FEED	01	CR ONLY
31	1" SKIP	01	OFF
32	CHAR.SET (GO, GL)	02	USA
33	CHAR.SET (G1, GR)	01	UK
34	CHAR SET (G2)	03	GE
35	CHAR SET (G3)	07	LINE DRAWING
81	OFF-LINE STATE	01	ALL RECEIVE
82	DSR	02	OFF
83	REQUEST TO SEND (RTS) TIMING	01	RTS
84	CD	02	OFF
85	CLEAR TO SEND (CTS)	02	OFF
91	OVER RUN	02	256
92	DATA BIT	02	8
93	PROTOCOL	03	XON/XOFF
94	STOP BIT	01	1
95	PARITY	01	NONE
96	PBS	04	1200

## Using the Control Panel

---

1. Use **Line Feed** or **Form Feed** to step through the options for the function.
2. To activate the menu for the function, press **On Line**.
3. To step through the options for the function, press **Line Feed** and **Form Feed**.
4. When you reach the option you are looking for, press **Print Quality** to select.

The printer prints the new setting. Repeat for each option to be set.

5. When finished, press **Print Quality**. The printer changes to normal mode.

## Connecting the Printer

---

Connect the printer using one of the following methods:

- An Asynchronous Data Unit (ADU) or data module (see [Chapter 4, "Data Modules and Asynchronous Data Units"](#))
- A direct, RS-232 connection from the serial port on the printer (often labeled COM) to the serial port on the DEFINITY ECS (labeled DCE).

## Okidata Model OP16N

---

The following sections describe the set-up of the printer and associated interfaces used during testing.

### Setting Up the OP16N

---

1. Set up the printer, install toner, and load paper as described in the vendor documentation, with one exception: fill the paper tray until the paper indicator gauge reads PAPER FULL.

Do not try to load the full 500 sheets of 20-lb paper indicated in the documentation. The true capacity is usually about 475 sheets. When more is loaded, the printer jams.


### Connecting OP16N to CMS

---

#### Connecting the OP16N via a parallel port

If the new printer is being connected to CMS through the parallel interface, the connectivity has not changed.

See [Figure 22](#), “Connecting the OP16N printer to a Sun CMS using the parallel interface”, for an overview of possible OP16N parallel connections.



**Figure 22. Connecting the OP16N printer to a Sun CMS using the parallel interface**

### Connecting the OP16N via serial port

The OP16N comes with a parallel interface only. To connect it to a serial port, you have to use a converter. Proceed as follows.

1. Attach an OKIDATA Serial Interface Converter (part number 50115001) to the parallel port on the back of the printer.
2. Connect the printer to a serial port on the CMS.

The following connections are possible, depending on the CMS equipment you have installed:

- A serial port on an 8-, 16-, or 64-port NTS (Network Terminal Server) installed on a Sun server
- A serial port on an 8- or 16-port Aurora Ports Card installed on a Sun server other than the E3000
- A serial port on an Equinox Megaplex brick installed on an AT&T Intel-based CMS platform
- A serial port on an IPC-1600 fanout module installed on an AT&T Intel-based CMS platform

See [Figure 23](#), “Connecting the OP16N printer to a Sun CMS using the serial converter”, for an overview of possible OP16N serial connections.




Figure 23. Connecting the OP16N printer to a Sun CMS using the serial converter




Figure 24. Connecting the OP16N printer to a Megaplex brick or IPC-1600 fanout

## Administering the OP16N

---

On Intel CMS systems, in **face**, the **Printer Type** for the OP16n is **HPLASERJET**.  
On Sun CMS systems, the **lpadmin type** for the OP16N is **hplaserjet**.

## Connecting printers via TCP/IP

---

Printers can be connected to the switch using asynchronous TCP/IP links. This section provides information on connecting adjuncts to the C-LAN and providing the initial administration.

### Task list

---

Whether you use an end-to-end TCP/IP configuration, a terminal server or a PC running RSP, you must complete the following tasks:

- [“Administering IP node names” on page 8-126](#)
- [“Administering IP services” on page 8-127](#)
- [“Administering adjunct parameters” on page 6-98](#)
- If you are using a terminal server, also complete [“Installing and administering the terminal server” on page 8-116](#)
- If you are using a PC with the Downloadable RSP Tool, complete [“Using the Downloadable Reliable Session-Layer Protocol Tool” on page 6-99](#)

## Administering adjunct parameters

---

You must administer adjunct parameters to let the system know that the adjunct is connected via TCP/IP.

### PMS journal and PMS log printers

1. Type **change system-parameters hospitality** and press RETURN.  
The Hospitality screen appears.
2. On this screen, you can administer the PMS Log Endpoint (PMS\_LOG) or PMS Journal Endpoint (PMS\_JOURNAL) for whichever of these is connected via TCP/IP.
3. In the PMS Log Endpoint field, type **CDR1**. If you use a secondary output device, and that device is also connected via TCP/IP, type **CDR2** in the Secondary Output Endpoint field.
4. Press ENTER to save your changes.

## System Printer

1. Type **change system-parameters features** and press RETURN.  
The Feature-Related System Parameters screen appears.
2. Move to Page 4.
3. In the System Printer Endpoint field, type **SYS\_PRNT**.
4. Press ENTER to save your changes.

## Testing the switch-to-adjunct link

You can use the test, status, busyout and release commands for to find and correct problems with system printer, PMS log printer, or PMS journal printer. For more information about these commands, see the Maintenance manual for your switch.

If a link does not come up immediately, try using the busyout (journal-link pms-log and wakeup-log, and sp-link) and release (journal-link pms-log and wakeup-log, and sp-link) commands.



### NOTE:

Status sp-link can show a system printer link as down, when it is actually properly connected. If no data is being transmitted, the switch may not see this link as active.

## Using the Downloadable Reliable Session-Layer Protocol Tool

---

The intent of the Reliable Session-Layer Protocol (RSP) is to guarantee delivery of data records from the switch to an output device that connects to the switch over an asynchronous TCP/IP link. The Downloadable RSP tool allows you to implement this protocol on a PC that collects data records in a file. The protocol assures that the data records arrive safely at the PC. You can then send the output file to a printer.

## Setting up an RSP configuration

To set up an RSP configuration:

- Administer the PC as a client application on the switch.
- Download, install, and administer the RSP for the PC

## Setting up the switch

To set up the server application on the switch:

- [“Administering IP node names” on page 8-126](#)

Give the PC a node name. The IP address is the IP address of the PC that is running the RSP tool.

- [“Administering IP services” on page 8-127](#)

The service type = SYS\_PRNT, the Remote Node = the node name assigned to the PC. Remote port is the port assigned as the listen port on the PC. You can figure out what this is by starting the RSP Server application, clicking on Start, and checking in the output window to see what port the server is listening on.

## Setting up the PC

To set up the client application on the PC:

- Download RSP
- Install RSP
- Administer RSP

### Downloading RSP

The RSP is available from the Avaya support web site as a self-extracting executable. To download the RSP:

1. Browse to the Avaya Customer Support web site:  
<http://support.avaya.com/sd.jhtml>
2. Select the RSP tool from the web site.
3. When queried, save the setup.exe file to a temporary folder on your computer. It is approximately 1.4-MB.

### Installing RSP

To install the RSP:

1. Double-click the setup.exe file.  
The Install Shield Wizard steps you through the installation.
2. When prompted to select Client or Server, select both programs.
3. Continue with the installation. Use the default destination folder and program folder.

4. You can view the readme file now or later. The following files are installed on the PC in the folder \\Program Files\Avaya\DEFINITY Data Transport Tool:

- client.exe (the client tool)
- server.exe (the server tool)
- user guide.doc (same as the readme file)
- spl\_design\_doc.doc (the RSP design document)
- splserver.ini
- ddt\_log.txt (installation log file)
- spl.dll

### Administering RSP

See the instructions in the user guide.doc file to administer the Reliable Session-layer Protocol on a PC.

<b>6</b>	<b>Printers</b>	
	<i>Connecting printers via TCP/IP</i>	102

## DEFINITY LAN Gateway System



---

The DEFINITY LAN Gateway lets DEFINITY exchange messages with LAN communications software. The DEFINITY LAN Gateway system is used in display set mode only, not in control link. Use it with the R10r, R10si, or R10csi. Refer to the *DEFINITY Communications System Generic 3 Installation, Administration and Maintenance of CallVisor ASAI over the DEFINITY LAN Gateway* for complete installation procedures.

Use the **add subscribers** command during administration, to prevent a **no port available** error. When administration is complete, enter **reset system reboot** to clear all alarms.

### Installing DEFINITY LAN Gateway in a Single-Carrier Cabinet

The DEFINITY LAN Gateway system installs in five adjacent slots, preferably the five rightmost slots in a Single-Carrier Cabinet. See [Figure 25](#).

#### **CAUTION:**

*Do not power up the DEFINITY LAN Gateway System until instructed to do so. Refer to the *DEFINITY Communications System Generic 3 Installation, Administration and Maintenance of CallVisor ASAI over the DEFINITY LAN Gateway*.*


It is not necessary to power down a system before installing a DEFINITY LAN Gateway.

**CAUTION:**

When the assembly is inserted, it will automatically power up (including the disk), run diagnostics, and boot. Therefore, to avoid a disk crash, never remove the assembly and never power down the DEFINITY System without first shutting down the unit and allowing the disk to completely spin down.

**NOTE:**

The system treats a DEFINITY LAN Gateway like a digital line circuit pack connecting 8 or 17 ports. These emulated stations (serving as ports) are assigned as members of a hunt group that reside in a coverage path. This coverage path is used by every station that covers an LAN Gateway system.



- 1. System cabinet
- 2. Five adjacent slots in cabinet
- 3. Multi-function circuit pack
- 4. Alarm circuit pack
- 5. DEFINITY LAN gateway

Figure 25. Typical DEFINITY LAN Gateway Installation

## Installing DEFINITY LAN Gateway in a Multicarrier Cabinet

---

It is not necessary to power down a system before installing a DEFINITY LAN Gateway

 **CAUTION:**

*Never locate a DEFINITY LAN Gateway in port carrier C of a multicarrier cabinet. Never locate a DEFINITY LAN Gateway either in port slots 01 to 03 of an expansion control cabinet or in slots 01 to 04 of a port cabinet.*

 **CAUTION:**


*When the DEFINITY LAN Gateway assembly is inserted, it will automatically power up (including the disk), run diagnostics, and boot. Therefore, to avoid a disk crash, never remove the assembly and never power down the DEFINITY System without first shutting down the unit and allowing the disk to completely spin down.*

1. If necessary, to provide five adjacent port slots in a desirable location, relocate and retranslate port circuit packs. See [Figure 26](#).

The system treats a DEFINITY LAN Gateway like a TN754B/C Digital Line circuit pack connecting 8 or 17 ports. These emulated stations (serving as ports) are assigned as members of a hunt group that reside in a coverage path. This coverage path is used by every station that covers an LAN Gateway system.

 **CAUTION:**

*Do not power up the DEFINITY LAN Gateway System until the installation and cabling is completed.*




1. System cabinet
2. Five adjacent slots in carrier
3. Multi-function circuit pack
4. Alarm circuit pack
5. DEFINITY LAN gateway

Figure 26. Typical DEFINITY LAN Gateway Installation

## Connecting the Alarm Origination Cable

The alarm cable connects to the MDF and cross-connects to the customer-supplied alarm equipment. See [Figure 27](#) and [Table 15](#).



- |   |  |
|---|--|
| 1. Customer-supplied alarm equipment              | 7. Alarm Y-cable                                     |
| 2. Cross-connections to alarm equipment           | 8. System cabinet                                    |
| 3. Main distribution frame (MDF)                  | 9. Multi-function circuit pack (part of LAN gateway) |
| 4. B25A 25-pair cable                             | 10. Alarm circuit pack (part of LAN gateway)         |
| 5. Female <b>ALARM</b> Connector on alarm Y-cable |  |
| 6. Unused RS-232 connector on alarm Y-cable       |  |

Figure 27. Connecting the Alarm Origination Cable

1. Connect the alarm Y-cable to the first connector associated with the alarm circuit pack on the LAN gateway system on the rear of the system cabinet.
2. Attach the male Amphenol connector on a B25A cable to the female Amphenol connector labeled **ALARM** on the alarm Y-cable.
3. Connect the opposite end of the B25A cable to the MDF.

**⇒ NOTE:**

Do not connect the RS-232 connector on the alarm Y-cable. The standard alarm origination circuit uses an on-board modem that is internally wired to the connector on the alarm Y-cable.

4. Perform the cross-connects for the alarm origination connection as described on the service order. Also see [Table 15](#).

**Table 15. Alarm Origination Pinouts (ALB Y-cable)**

Pin Number	Definition
27	Tip (white/blue)
1	Ring (blue/white)
44	Minor RTN (return) (yellow/brown)
19	Minor (brown/yellow)
47	Major RTN (return) (violet/orange)
22	Major (orange/violet)

## Connecting a PC

You need a PC to administer the DEFINITY LAN Gateway system. You must have a local administration PC and a local maintenance PC as well.

There are four ways to connect a local administration terminal:


- Direct connection
- Modem connection
- Asynchronous Data Unit (ADU)
- One 7400A data module and one 7400B data module (recommended) or two 7400A data modules

Local maintenance PCs are always connected directly.

### Directly Connecting a Terminal


[Figure 28](#) shows typical connections for a local maintenance PC.

[Figure 29](#) shows typical connections for a local administration PC.



- |  |   |
|--|---|
| 1. Administration PC                       | 6. Multifunction Y-cable (MFB)                      |
| 2. RS-232 cable                            | 7. System cabinet                                   |
| 3. 117A isolator (DC powered systems only) | 8. Alarm circuit pack (part of LAN gateway)         |
| 4. Port A connector on MFB Y-cable         | 9. Multifunction circuit pack (part of LAN gateway) |
| 5. Port B connector on MFB Y-cable         |   |

Figure 28. Typical Local Maintenance PC Connections



- |  |  |
|--|--|
| 1. Administration PC                       | 6. 25-pair connector on multi-function Y-cable (MFB) |
| 2. RS-232 cable                            | 7. System cabinet                                    |
| 3. 117A Isolator (DC-powered systems only) | 8. Alarm circuit pack (part of LAN gateway)          |
| 4. Port B connector on MFB Y-cable         | 9. Multifunction circuit pack (part of LAN gateway)  |
| 5. Unused RS-232 connector on MFB Y-cable  |  |

Figure 29. Typical Local Administration PC Connections

## Testing a direct connection

1. Plug the power cord on the terminal into a wall outlet.
2. Power on the terminal.
3. If you are installing a printer, set the printer options as described in the printer manual. Then set the corresponding options on the terminal to match.

If the terminal is installed correctly and if the DEFINITY LAN Gateway is in the **ADX, OAM, OS** or **AINIT** state, the screen displays the **login** prompt.


4. If you are not installing a printer, set the terminal options according to the instructions in the terminal documentation.

If the terminal is installed correctly and if the DEFINITY LAN Gateway is in the **ADX, OAM, OS** or **AINIT** state, the screen displays the **login** prompt.

5. If the terminal does not display the **login** prompt, write down the state displayed, then see the troubleshooting procedures for terminal connections in CallVisor ASAI/DEFINITY LAN Gateway documentation.

## Connecting an administration PC via modems

Connect as shown in [Figure 30](#).



- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. Printer (optional)</li> <li>2. Administration PC</li> <li>3. RS-232 cable</li> <li>4. Modem</li> <li>5. 103A or modular wall jack</li> <li>6. Main distribution frame (MDF)</li> <li>7. Public switched telephone network</li> <li>8. 117A Isolator (DC-powered Port-A connector on MFB Y-cable systems only)</li> </ol> | <ol style="list-style-type: none"> <li>9. Port B connector on MFB Y-cable</li> <li>10. Port A connector on MFB Y-cable</li> <li>11. Multifunction Y-cable (MFB)</li> <li>12. System cabinet</li> <li>13. Alarm circuit pack (part of LAN gateway)</li> <li>14. Multifunction circuit pack (part of LAN gateway)</li> </ol> |
|--|--|

Figure 30. Typical Administration Terminal Connections via Modems

1. Attach the connector on one end of a modular cord to the modem. Attach the other connector to the modular wall jack (information outlet).
2. Connect the second modem to the wall jack at the remote terminal site.
3. If you are installing a printer, connect the printer to the terminal, and set the printer options as described in the printer manual. Then set the corresponding options on the terminal to match.
4. If you are not installing a printer, set the terminal options according to the instructions in the terminal documentation.
5. At the terminal, enter **AT**.
6. If the modem is installed correctly, it responds with **OK** (on the terminal screen).
7. Enter **ATDT** and the telephone number of the modem connected to **Port B** (listed on the Installing the Terminals worksheet).


If the terminal is installed correctly and if the DEFINITY LAN Gateway is in the **ADX**, **OAM**, **OS** or **AINIT** state, the screen displays the **login** prompt.

8. If the terminal does not display the **login** prompt, write down the state displayed, then see the troubleshooting procedures for terminal connections in CallVisor ASAI/DEFINITY LAN Gateway documentation.

### Connecting an administration PC via Asynchronous Data Units

---

Connect as shown in [Figure 31](#).



- |   |  |
|---|--|
| 1. Administration PC                      | 9. 400B2 adapter                                     |
| 2. 25-Pin EIA-232-D connector on Z3A1 ADU | 10. Z3A2 ADU   |
| 3. D8AM crossover cord                    | 11. Port A connector on MFB Y-cable                  |
| 4. 103A or modular wall jack              | 12. Port B connector on MFB-Y-cable                  |
| 5. Main distribution frame (MDF)          | 13. Multifunction Y-cable (MFB)                      |
| 6. D8W cord                               | 14. System cabinet                                   |
| 7. Power supply                           | 15. Multifunction circuit pack (part of LAN gateway) |
| 8. D7AP cord                              |  |

Figure 31. Typical Administration PC Connections through ADUs

If the terminal is installed correctly and if the DEFINITY LAN Gateway is in the **ADX**, **OAM**, **OS** or **AINIT** state, the screen displays the **login** prompt.


9. If the terminal does not display the **login** prompt, write down the state displayed, then see the troubleshooting procedures for terminal connections in CallVisor ASAI/DEFINITY LAN Gateway documentation.

### Connect the Administration PC via Data Modules

Two data modules can be used in this configuration. The DEFINITY LAN gateway side of the configuration requires the 7400A. A second 7400A can be used and is connected the same as a 7400B. Set the options as described in [Chapter 4, "Data Modules and Asynchronous Data Units"](#).

1. Make sure the EIA connector board (located inside the data module) is set to DCE (factory default). If not, unplug the card and turn it around to the DCE setting (see "Mode Selection" on page 5-84 for details).
2. Connect as shown in [Figure 32](#).
3. If you are installing a printer, set the printer options as described in the printer manual. Then set the corresponding options on the terminal to match.

4. If you are not installing a printer, set the terminal options according to the instructions in the terminal documentation.
5. At the terminal, enter **AT**. If the 7400B data module is connected correctly, it responds with OK (written on the terminal screen).
6. Enter **ATDT** and the telephone number of the 7400A data module connected to the DEFINITY LAN gateway (refer to the "Installing the Terminals" worksheet for this number).
7. Check the DIP switches inside the front panel. If a telephone is not connected with the data module, set the first DIP switch (1) to the ON position. If a telephone is connected, set all DIP switches OFF.



cydr003 RPY 091197

- |                                  |  |
|----------------------------------|--|
| 1. Administration PC             | 9. Null modem cable                                  |
| 2. RS-232 cable                  | 10. Port B connector on MFB Y-cable                  |
| 3. Data module power supply      | 11. Port A connector on MFB Y-cable                  |
| 4. 7400B data module             | 12. Multifunction Y-cable (MFB)                      |
| 5. D8W cord                      | 13. System cabinet                                   |
| 6. 103A or modular wall jack     | 14. Alarm circuit pack (part of LAN gateway)         |
| 7. Main distribution frame (MDF) | 15. Multifunction circuit pack (part of LAN gateway) |
| 8. 7400A data module             | 16. Multifunction circuit pack (part of LAN gateway) |

Figure 32. Typical Administration PC Connections Using Data Modules

8. After a connect interval, if the PC and 7400 data modules are installed correctly (and the DEFINITY LAN Gateway is in either *ADX*, *OAM*, *OS* or *AINIT* state), the screen displays the `login` prompt.
9. If the PC does not display the `login` prompt, write down the state displayed, then see the troubleshooting procedures for terminal connections in *DEFINITY Communications System Generic 3 Installation, Administration and Maintenance of CallVisor ASAI over the DEFINITY LAN Gateway*.

## Installing a Printer

---

The following instructions are typical for most installations. But follow the instructions supplied with the printer.

1. Unpack and set up the printer according to the instructions supplied with the printer.
2. Be sure that the printer has paper, the ribbon is properly installed, and the cover is closed.
3. Connect one end of the printer cable to either the serial or parallel port on the PC (depending on the PC and printer). Secure the connector with the screws provided.
4. Connect the opposite end of the printer cable to the matching port (serial or parallel) on the printer.
5. Set the options on the printer. Refer to the documentation shipped with the printer.

# Terminal Server Installation

# 8

This chapter provides information on connecting adjunct equipment to the C-LAN board in DEFINITY ECS using a terminal server.

## Overview

Any device that does not support a direct TCP/IP connection, but that does support an RS232 interface, can connect to the C-LAN board through a terminal server. Property Management Systems, printers, and some CDR devices use RS232 connections.

You can connect up to four adjuncts through one terminal server.




Figure 33. Switch-to-adjunct LAN connectivity via terminal server

## Installing and administering the terminal server

Make sure you have all the equipment on site before the installation. You must have the hardware listed in [Table 16](#).

**Table 16. Required equipment**

Comcode	Description	Number	Supplier
700015084	IOLAN+ 104 communications server	1	Avaya
NA	RJ45-to-DB25 connector for IOLAN+ (supplied with 700015084)	4	Avaya
NA	DB25-to-DB9 connector for PC COM port	1	Avaya
NA	RS232 Null modem (if needed for PC or printer connectivity)	1 or more	Avaya
405369042	Male/female adapter (if necessary)	1 or more	Avaya
846943306 or 104154414	6-inch RJ45 crossover cord, or	1	Avaya
NA	10/100Base-T auto-sensing LAN hub or router	1	Customer
102631413	259A adapter, or	1	Avaya
NA	CAT5 cross connect hardware and connecting blocks		Customer
NA	RJ45 UTP Category 5 modular cords	1–2	Customer
NA	451A in-line RJ45 adapters, as needed to connect modular cords together		

You also need a computer (laptop) with the HyperTerminal software program for the initial administration of the IOLAN+ and to set up the ports.

The general process is to

- Connect the IOLAN+ to the adjunct and the LAN
- Administer the ports on the IOLAN+ using a PC or laptop at the local site
- Test the connectivity back through the DEFINITY switch

### Distance limits

The distance limit from the switch to the LAN hub is 328 feet (100 meters). The distance limit from the LAN hub to the terminal server is 328 feet (100 meters). If installed, the limit from the terminal server to the adjunct is 50 feet (15 meters).

### Cabling diagram

Figure 34 shows the connection between the terminal server port and a call accounting system.





Figure 34. Stand-Alone Call Accounting System Link Using a Terminal Server

### Making the connections

Connect the adjunct to the IOLAN+, using the RJ45-to-DB25 cable and the null modem. You can use a male/female adapter. See Figure 35.



### Figure Notes

- |  |  |
|--|--|
| 1. C-LAN circuit pack in DEFINITY switch             | 5. Null modem                                |
| 2. Local area network (LAN)                          | 6. PC or laptop (for initial administration) |
| 3. IOLAN+ 104 terminal server                        | 7. DB25-to-RJ45 cable                        |
| 4. Adjunct (system management terminal, for example) | 8. DB25-to-DB9 cable                         |

Figure 35. Connecting an adjunct to the IOLAN+

## 8 Terminal Server Installation

*Installing and administering the terminal server*

118

Follow these typical steps:



**NOTE:**

Depending on the adjunct's connections, you may not need all of these pieces.

1. Connect the null modem adapter to COM1 port on the adjunct.
2. Connect the other end of the null modem adapter to the DB25 to RJ45 cable.
3. Connect the RJ45 end to any port on the IOLAN+.

### Administering the IOLAN+

To administer the IOLAN+ the first time, you must connect a PC or laptop to the RS232 Port 1 on the IOLAN+ terminal server. Follow these typical steps:



**NOTE:**

Depending on the computer's COM port, you may not need all of these pieces.

1. Connect the DB9 end of the DB9-to-DB25 cable to the COM port on the PC or laptop.
2. Connect the DB25 end to the null modem adapter.
3. Connect the other end of the null modem adapter to the DB25 to RJ45 cable.
4. Connect the RJ45 end to Port 1 of the IOLAN+.

Before beginning the initial administration, make sure you have the following information:

- New IP address and subnet mask for IOLAN+
- Host name for IOLAN+
- IP address of C-LAN Ethernet interface
- Port number of C-LAN Ethernet interface where adjunct connects.

### Setting up HyperTerminal on the computer

Use the HyperTerminal software program that comes with Windows 95/98/NT/2000 to administer the IOLAN+.

1. Open HyperTerminal.
2. Click on **File > Properties > Connect** tab. In the Connect using: field, select **COM *n***, where *n* is the communication port your computer is using.
3. Click on CONFIGURE and set the bits per second field to **9600** and the Flow control field to **Hardware**.

8 Terminal Server Installation

Installing and administering the terminal server

119

4. Click OK, OK.
5. Press ENTER to get the login prompt.

### Navigating the IOLAN+ terminal server

Refer to the IOLAN+ user guide for details. In general,

- Use the arrow keys to move to a menu item
- Use the TAB key to move from field to field horizontally.
- Use the ENTER key to choose an item.

### Administering the IOLAN+ the first time

1. At the login prompt type **any text** and press ENTER.
2. At the second prompt type **set term ansi** and press ENTER to view the Connections menu.

```

Name: port 2                      CONNECTIONS MENU                      Terminal: 2

      Connection      Host
      1               *** FREE ** === Commands ===
      2               *** FREE ** | Telnet      ^T|
      3               *** FREE ** | Rlogin      ^R|
      4               *** FREE ** | Port        ^P|
                               | Admin mode   ^A|
                               | CLI          |
                               | Lock          |
                               | Logout      ^D|
                               =====

-----

IOLAN PLUS v4.02.00 a CDi                      iolan
    
```

3. Under Connection select Port 1 (the port to which the adjunct is connected) and press ENTER to access the Commands menu.
4. Select **Admin mode > Password** and press ENTER.

8 Terminal Server Installation

Installing and administering the terminal server

120

```

Name: port 2                      ADMINISTRATION MENU                      Terminal: 2

gateway      Examine/modify gateway table.
host         Examine/modify host table.
line         Terminal configuration organised by line.
password     Specify password to allow modification of menu items.
port         Terminal configuration organised by port.
quit         Return to connections menu.
server       Examine/modify Server parameters.
stats        Examine Server statistics.

Password     [          ]

-----

IOLAN PLUS v4.02.00 a CDi                      iolan-st
    
```

5. Type **iolan**, the default password, and press ENTER.

The Administration Menu changes, offering more options.

6. Select **server** and press ENTER to view the Server Configuration menu.

```

** Administrator **                SERVER CONFIGURATION                Terminal: 2

Name          [iolan      ]          Debug mode    [0      ]
IP address    [123.45.67.89 ]
Subnet mask   [222.222.0.0   ]
Ethernet address [00:80:d4:03:11:cd]          Ethernet interface [AUTO  ]
Language      [English  ]
Identification [          ]
Lock          [Disabled]
Password limit [5      ]
CR to initiate [No   ]
SNAP encoding [Disabled]
Boot host     [          ]          Boot diagnostics [Enabled ]
Boot file     [          ]
Init file     [          ]
MOTD file    [          ]
Domain name   [          ]
Name server   [          ]          NS Port      [53   ]
WINS server   [          ]

-----

Name used for prompts and message on bottom right of screen.

IOLAN PLUS v4.02.00 a CDi                      iolan
    
```

## 8 Terminal Server Installation

*Installing and administering the terminal server*

121

7. Fill in the following fields with information appropriate to your network. Leave the default settings for the other fields.
  - Name:
  - IP address: (for IOLAN+)
  - Subnet mask:
8. Press ENTER and select **Save & Exit** to effect the changes.

**Rebooting the IOLAN+**

You must reboot the server any time you change an IP address or Local Port value.

1. Press ENTER to view the Administration Menu.

```
** Administrator **                ADMINISTRATION MENU                Terminal: 2

access      Remote System Access (PPP).
change      Change login and/or admin password.
gateway     Examine/modify gateway table.
host        Examine/modify host table.
kill        Kill TCP connections on serial line.
line        Terminal configuration organised by line.
port        Terminal configuration organised by port.
quit        Return to connections menu.
reboot     Reboot Server.
server      Examine/modify Server parameters.
stats       Examine Server statistics.
trap        Examine/modify SNMP Trap parameters.

Port                [ 2 ]

-----

IOLAN PLUS v4.02.00 a CDi                iolan
```

**⇒ NOTE:**

The following steps re-initialize the IOLAN+ so it knows it's connected to the LAN through its IP address.

2. Select **reboot** and press ENTER.
3. Press the space bar to restart the IOLAN+.

## Administering the gateway

### ⇒ NOTE:

If the C-LAN circuit pack and IOLAN+ are in the same subnet, skip this step.

1. Select **Admin mode > Password** and press ENTER.
2. Type **iolan** and press ENTER.
3. Select **gateway** to access the Gateway menu
4. Fill in the following fields for Entry 1:
  - Destination: *C-LAN IP address*
  - Gateway: *Gateway address*
  - Netmask: *Subnet mask*

### ⇒ NOTE:

The following steps re-initialize the IOLAN+ so it knows it's connected to the LAN through your gateway.

5. Select **reboot** and press ENTER.
6. Press the space bar to restart the IOLAN+.

## Administering an IOLAN+ port

Use this procedure when connecting an adjunct or serial COM port on a PC directly (locally) to the IOLAN+ (see [Figure 35](#)).

1. Select **Admin mode > Password** and press ENTER.
2. Type **iolan** and press ENTER.
3. Select **port** and press ENTER.
4. Type **port number**, where **port number** is the port that the adjunct connects to, and press ENTER to view the Port Setup Menu.

## 8 Terminal Server Installation

Installing and administering the terminal server

123

```
** Administrator **
Hardware
Speed      [19200 ]
Parity     [None]
Bit        [8]
Stop       [1]
Break      [Disabled]
Monitor DSR [Yes ]
Monitor DCD [No ]

PORT SETUP MENU
Flow ctrl  [Hardware]
Input Flow [Enabled ]
Output Flow [Enabled ]

Keys
Hot  [^]
Quit [^@]
Del  [^@]
Echo [^@]

Terminal: 2
Intr  [^C]
Kill  [^U]
Sess  [^@]

IP Addresses
Src  [ ]
Dst  [ ]
Mask [ ]

User
Name [port 2 ]
Terminal type [undef ]
TERM [ ]
Video pages [0]
CLI/Menu [CLI]
Reset Term [No ]

Options
Keepalive [No ]
Rlogin/Telnet [Telnet]
Debug options [No ]
Map CR to CR LF [No ]
Hex data [No ]
Secure [No ]
MOTD [No ]

Access
Access [Local ]
Authentication [None ]
Mode [Telnet ]
Connection [initiated]
Host [ ]
Remote Port [9001 ]
Local Port [10002]
```

5. Fill in the following fields. Leave the default settings for the other fields.

- Speed: 19200
- Monitor DSR: Yes
- Monitor DCD: No
- Name: *port number or other descriptive name*
- Terminal type: undef
- CLI/Menu: CLI
- Reset Term: No
- Flow ctrl: Both

 NOTE:

*This is very important! If the link goes down between the terminal server and the adjunct, the terminal server buffers the data and notifies the switch. Once the terminal server buffer fills up, the switch buffers the data. The switch raises an alarm once the switch buffer is full.*

- IP addresses: *leave blank*
- Mask: *leave blank*
- Access: Local
- Authentication: None
- Mode: Telnet
- Connection: Initiated

## 8 Terminal Server Installation

*Installing and administering the terminal server*

124

- Host: *C-LAN IP Address*
  - Remote Port: *C-LAN Ethernet port where IP adjunct service is offered*
  - Local Port: *must match the value of Remote Port on the DEFINITY IP Services screen*
6. Press ENTER and select **Save & Exit** to effect the changes.
  7. Press ENTER again to view the Administration Menu.
  8. Select **kill** to disable the port connection.
  9. Repeat the steps for each additional port you want to administer.
  10. When administration is complete, from the Connections Menu, select **logout** (or press **Ctrl D**).
  11. Close HyperTerminal.

At this point, you have established a connection path from the adjunct through the IOLAN+ to the C-LAN circuit pack.

## Testing

1. On the system management terminal, press ENTER to get the login prompt to the DEFINITY switch.

### NOTE:

If you get garbled text, check the baud rate setting on the Port Setup Menu. You can adjust it up or down.

2. If no login prompt appears, log back into the IOLAN+ through HyperTerminal.
3. Select **Admin mode > stats** and press ENTER twice.
4. Select **users** and press ENTER.
5. Look at the port that the adjunct is connected to and see if there is any traffic. If not, check all your connections and administration fields.

**8 Terminal Server Installation***Installing and administering the terminal server*

125

```
** Administrator **          SERVER STATISTICS          Terminal: 2
1. port1                    Talking to host 172.22.22.67.5111<DSR+CTS+DCD >DTR+RTS
2. port 2                   SERVER STATISTICS          <DSR+DCD >DTR+RTS
3. port 3                   waiting for DSR or DCD     >DTR+RTS
4. port 4 modem             waiting for DSR or DCD     >DTR+RTS
REM <unknown>               logged out
LOG                           logger not enabled
```

---

```
Press <RETURN> to see list of options.
IOLAN PLUS v4.02.00 a CDi
```

iolan-st

After you have successfully administered and validated the connection between the adjunct and the C-LAN circuit pack through the IOLAN+, you can disconnect the laptop or other PC from the IOLAN+. No further IOLAN+ administration is required.

**Potential failure scenarios and repair actions**

If a link goes down between the terminal server and the switch, you must reboot the terminal server for the link come back up. If you are performing a software upgrade or if a system reset occurs, you must reboot the terminal server to restore the link. See [“Rebooting the IOLAN+” on page 8-121](#) for instructions.

## Administering IP node names

You must administer the IP addresses of the C-LAN board, any adjunct that connects directly to the LAN, the terminal server (if appropriate), and the PC running the Reliable Session-Layer Protocol (if appropriate). You use the Node Names screen to do this.

1. Type **change node-names ip** and press RETURN.
2. Enter the name and the IP address of the C-LAN board, as well as any adjunct, terminal server or PC you need to administer.

change node-names ip

Page 1 of 1

### NODE NAMES

Name	IP Address	Name	IP Address
1. switch_____	123.456.7 .89	17. _____	____.____.____.____
2. callacctg_____	123.456.9 .00	18. _____	____.____.____.____
3. termserver_____	123.456.11 .00	19. _____	____.____.____.____
4. pmslogpc_____	123.456.78 .00	20. _____	____.____.____.____
5. _____	____.____.____.____	21. _____	____.____.____.____
6. _____	____.____.____.____	22. _____	____.____.____.____
7. _____	____.____.____.____	23. _____	____.____.____.____
8. _____	____.____.____.____	24. _____	____.____.____.____
9. _____	____.____.____.____	25. _____	____.____.____.____
10. _____	____.____.____.____	26. _____	____.____.____.____
11. _____	____.____.____.____	27. _____	____.____.____.____
12. _____	____.____.____.____	28. _____	____.____.____.____
13. _____	____.____.____.____	29. _____	____.____.____.____
14. _____	____.____.____.____	30. _____	____.____.____.____
15. _____	____.____.____.____	31. _____	____.____.____.____
16. _____	____.____.____.____	32. _____	____.____.____.____

3. Print a copy of this screen, or write down the node names you entered. You need this information for the next administration task.
4. Press ENTER to save your changes.

## Administering IP services

For each adjunct that you connect using TCP/IP, you need to administer IP services to establish the IP address/TCP port pairing. The IP address is associated with the node name that you just administered. In this example, we are administering the primary CDR connection as end-to-end TCP/IP, and the PMS connection through a terminal server.

1. Type **change ip-services** and press RETURN to assign the CDR endpoint.
2. In the Service Type field, enter **CDR1** for the call accounting link, and **PMS** for the property management system.

```
change ip-services
```

```
Page 1 of 3
```

```

                IP SERVICES
Service  Enabled  Local      Local  Remote  Remote
Type    Node      Node      Port   Node    Port
CDR1    switch    switch    0      callac  5101
PMS     switch    switch    0      termser 5103
```

3. In the Local Node field, enter the node name for the switch. In this example, **switch** is the local node.
4. The Local Port field defaults to 0 for all client applications. You cannot make an entry in this field.
5. In the Remote Node field, enter the node name for the adjunct, as administered on the Node Names screen. For the call accounting application, type **callacctg**. Since the PMS application routes through the terminal server, **termserver** is the remote node for this service type.
6. In the Remote Port field, enter the TCP listen port assigned to the adjunct. The recommended value for CDR1 is 5101, and the recommended value for PMS is 5103.

### NOTE:

This number must match the port administered on the end device. If you are using the Downloadable Reliable Session-Layer Protocol tool, this must match the port administered in the Server application. If you are using a terminal server, this number must match the Local Port number on the Port Setup menu. Consult the documentation for your Call Accounting system to determine the appropriate port for the CDR device.

7. Move to Page 3. Type **y** in the Reliable Protocol field for the CDR Service Type.

change ip-services

Page 3 of 3

SESSION LAYER TIMERS

Service Type	Reliable Protocol	Packet Resp Timer	Session Connect Message Cntr	SPDU Cntr	Connectivity Timer
CDR1	y	3	1	1	1

8. Press ENTER to save your changes.

## DS1/T1 CPE Loopback Jack

# 9

---

This chapter provides information on how to install and use a DS1 loopback jack to test the DS1 span between the DEFINITY and the network interface point. *The loopback jack is required when DC power is at the interface to the ICSU.*

**⇒ NOTE:**

Do not remove the loopback jack after installation. It should always be available for remote tests of the DS1 span.

The loopback jack isolates the ICSU from the DC power and properly loops the DC span power.

**⇒ NOTE:**

The loopback jack operates with DS1 circuit packs and R7 or later software. The loopback jack operates with the 120 integrated channel service unit (ICSU) only. It does not support 3100-series channel service units or other external CSUs or older ICSUs.

## Installing Loopback Jacks

---

You can install a loopback jack with or without a smart jack.

### With a Smart Jack

---

Install the loopback jack at the interface to the smart jack, if possible. This position provides maximum coverage of CPE wiring when remote loopback tests are run.

If the smart jack is not accessible, install the loopback jack at the extended demarcation point.

If there is no extended demarcation point, install the loopback jack directly at the network interface point as shown in [Figure 36](#).

If there is an extended demarcation point and the smart jack is not accessible, install the loopback jack as shown in [Figure 37](#).

If there is an extended demarcation point, but the smart jack is accessible, install the loopback jack as shown in [Figure 38](#).

1. To install the loopback jack, simply disconnect the RJ-48 (8-wide) connector (typically an H600-383 cable) at the appropriate interface point and connect the loopback jack in series with the DS1 span. See [Figure 36](#) through [Figure 40](#).
2. Plug the H600-383 cable from the ICSU into the female connector on the loopback jack.
3. Plug the male connector on the loopback jack cable into the network interface point.

**NOTE:**

Do not remove the loopback jack after installation. This is not a test tool and should always be available to remotely test a DS1 span.

## Without a Smart Jack

---

Install the loopback jack at the point where the cabling from the ICSU plugs into the *dumb* block. If there is more than one *dumb* block, choose the one that is closest to the Interface Termination feed or the fiber MUX to provide maximum coverage for loopback jack tests. Refer to [Figure 39](#) and [Figure 40](#).

1. To install the loopback jack, simply disconnect the RJ-48 (8-wide) connector (typically an H600-383 cable) at the appropriate interface point and connect the loopback jack in series with the DS1 span. See [Figure 36](#) through [Figure 40](#).
2. Plug the H600-383 cable from the ICSU into the female connector on the loopback jack.
3. Plug the male connector on the loopback jack cable into the network interface point.

**NOTE:**

Do not remove the loopback jack after installation. This is not a test tool and should always be available to remotely test a DS1 span.

## Administering the Loopback Jack

1. At the management terminal, enter **change DS1 location**.  
**Location** is the DS1 interface circuit pack corresponding to the loopback jack.
2. Be sure the **near-end CSU** type is set to **integrated**.
3. On page 2 of the form, change the **supply CPE loopback jack power field** to **y**.  
Setting this field to **y** informs the technician that a loopback jack is present on the facility and allows the technician to determine that the facility is available for remote testing.
4. Enter **save translation** to save the new information.

## Loopback Testing with a Smart Jack

The loopback jack and smart jack isolate faults by dividing the DS1 span into 3 sections (see [Figure 36](#), [Figure 37](#), and [Figure 38](#)):

- From the 120A2 (or later) ICSU to the loopback jack
- From the loopback jack to the smart jack (network interface point)
- From the smart jack to the CO

The first 2 sections are your responsibility. The last is the responsibility of the DS1 service provider.

## Testing the DS1 Span from the ICSU to the Loopback Jack

The DS1 span test has 2 parts.

- Checking for circuit connectivity  
The first part of the test powers-up the loopback jack and sends a signal from the DS1 circuit pack, through the wiring, to the loopback jack. The test allows about 10 seconds for the signal to loop around the loopback jack and return to the DS1 circuit pack. Then it sends the results to the management terminal and proceeds to the second part of the test.
- The second part of the test sends the standard, 3-in-24 DS1 stress-testing pattern from the DS1 board, through the loopback jack, and back to a bit error detector and counter on the DS1 board. A bit-error rate counter displays the results on the management terminal until you terminates the test.

Always perform both parts of the test. Proceed as follows.

## Checking the integrity of local equipment

Before you go any further, make sure that the problem is actually on the DS1 span by testing the equipment that connects to the span at the near end.

1. Test the DS1 circuit pack, and perform any needed maintenance or repairs.
2. Test the ICSU, and perform any needed maintenance or repairs.

## Busying out the DS1 circuit pack

Now take the DS1 circuit out of service.

1. Once you are sure that the DS1 circuit pack and ICSU are functioning correctly, go to the management terminal, and busy out the DS1 circuit pack by entering

**busyout board UUCSS**

where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.

## Administering the DS1 for the test

1. At the management terminal, open the DS1 administration form. Enter  
**change DS1 UUCSS**  
where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.
2. Make sure that the **near-end csu type** field is set to **integrated**.
3. Change to page 2 of the DS1 administration form, and confirm that the value of the **TX LBO** field is **0dB**.
4. If the value of the **TX LBO** field is not **0dB**, record the current value. Then set the **TX LBO** field to **0dB** for testing.
5. Press ENTER to make the changes, CANCEL to quit without changes.

## Testing the integrity of the loopback circuit

Now perform the first part of the actual loopback test.

1. At the management terminal, enter  
**test DS1-loop UUCSS cpe-loopback-jack**

where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.

The loopback jack powers up. Active, DS1 facility alarms (if any) clear. After about 20 seconds, the first set of results appears on the terminal.

2. If **FAIL** appears on the terminal display, there may be a fault in the wiring between the ICSU and the loopback jack or the loopback jack may itself be faulty. Isolate the problem by replacing the loopback jack and repeating step 1.
3. If **FAIL** still appears after the loopback jack has been replaced, suspect a wiring problem. Replace the cable between the ICSU and the loopback jack. Then repeat step 1.
4. When **PASS** appears on the terminal, proceed with the second part of the test, checking the integrity of transmitted data.

## Testing the integrity of data sent over the loop

Now perform the second part of the test, checking for data errors.



### NOTE:

The loss of signal (LOS) alarm (demand test #138) is not processed during this test while the 3-in-24 pattern is active.

## Clearing the results of previous tests

1. Zero out the bit-error counter. At the management terminal, enter  
**clear meas DS1 loop UUCSS**  
where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.
2. Zero out the performance measurement counter. At the management terminal, enter  
**clear meas DS1 log UUCSS**  
where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.
3. Zero out the ESF error count. At the management terminal, enter  
**clear meas DS1 esf UUCSS**  
where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.

## Running the data test

1. Display the bit error count. At the management terminal, enter  
**list meas DS1 sum UUCSS**  
where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.
2. Step through the table below to troubleshoot.

Condition	Solution
The value of the <b>Test: cpe-loopback-jack</b> field is <b>Pattern 3-in-24</b>	The loopback jack test is active.
The value of the <b>Synchronized</b> field is <b>N</b>	Retry the test 5 times.
The value of the <b>Synchronized</b> field remains <b>N</b> after 5 tries.	Excessive bit errors are likely. Check for intermittent connections or broken wires in an SPE receive or transmit pair, and repair as necessary. Then repeat step 1.
The value of the <b>Bit-error count</b> field is <b>non-zero</b>	Repeat step 1 several times.
The value of the <b>Synchronized</b> is <b>Y</b>	The DS1 circuit pack has synchronized to the looped 3-in-24 pattern and is counting bit errors in the pattern.
The value of the <b>Bit-error count</b> field pegs at <b>75535</b> or increments by 100s or 1000s each time you repeat step 1.	Suspect loose or corroded connections, severe crosstalk, or impedance imbalances between the two conductors of the receive or transmit pair. Wiring may need replacement.
The value of the <b>Bit-error count</b> field is <b>0</b>	There are no obvious wiring problems. Verify this by repeating step 1 a 1- to 10-minute intervals until you are certain.  If the test reports no errors for 1 minute, the error rate is less than 1 in 10 <sup>8</sup> . If the test reports no errors for 10 minutes, the error rate is less than 1 in 10 <sup>9</sup> .

- Once you are fairly certain that the test is reporting no errors (after at least 1 error-free minute), confirm that the 3-in-24 pattern error detector is operating. Enter

**test DS1-loop UUCSS inject-single-bit-error.**

where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.

- Display the bit error count again. At the management terminal, enter

**list meas DS1 sum UUCSS**

where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.

9 DS1/T1 CPE Loopback Jack  
 Loopback Testing with a Smart Jack

Condition	Solution
The value of the <b>Bit-error count</b> field is greater than <b>1</b>	Replace the ICSU, and retest.
The value of the <b>Bit-error count</b> field is still greater than <b>1</b> after you replace the ICSU.	Replace the DS1 circuit pack, and retest.
The value of the <b>Bit-error count</b> field is <b>1</b>	The test passed.

5. End the test. Enter  
**test DS1-loop location end cpe-loopback-jack-test**
6. Wait about 30 seconds for the DS1 to reframe on the incoming signal and clear DS1 facility alarms.

Condition	Solution
Loopback termination fails with an error code of 1313.	The span is still looped somewhere, possibly at the loopback jack, at the ICSU, or somewhere in the network.
The red LED on the loopback jack is on.	Replace the ICSU, and re-run the test.
Loopback termination still fails.	Replace the DS1 circuit pack, and repeat the test
The DS1 cannot frame on the incoming span's signal after the loopback jack power down.	There is something wrong with the receive signal into the loopback jack from the dumb block or the smart jack.
The span failed the service provider's loopback test.	The problem is in the service provider's network.
The service provider successfully loop tested the span, up to the smart jack.	The wiring between the loopback jack and the smart jack is suspect. Test, and make repairs, as needed.
You cannot locate and repair the problem in the time available and must terminate the test.	The test will not terminate normally in the absence of a good framing signal. You have to reset the circuit pack. Enter <b>reset board UUCSS</b>  where <b>UU</b> is the cabinet number, <b>C</b> is the carrier number, and <b>SS</b> is the slot number of the DS1 board.
The test terminated normally.	Proceed with " <a href="#">Restoring DS1 administration</a> ", below.

## Restoring DS1 administration

1. At the management terminal, open the DS1 administration form. Enter **change DS1 UUCSS**  
where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.
2. Change to page 2 of the DS1 administration form.
3. Change the value of the **TX LBO** field to the original value that you wrote down when you were "[Administering the DS1 for the test](#)" on page 9-132.
4. Press ENTER to make the changes, CANCEL to quit without changes.

## Releasing the DS1 circuit pack

1. Release the DS1 circuit pack. From the management terminal, enter **release board UUCSS**  
where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.
2. Leave the loopback jack in place.

## Testing the DS1 Span from the Smart Jack to the Network Interface Termination or Fiber Multiplexer (MUX)

---

1. Have the service provider run a smart-jack loopback test against the network interface wiring that links the smart jack to the CO (Section 3 in [Figure 36](#)).
2. If the tests fails, there is a problem on the network side. Have the service provider correct it.

## Testing the DS1 Span from the Loopback Jack to the Smart Jack

---

Test the short length of customer premises wiring between the loopback jack and the smart jack (Section 2 in the following 3 figures) using a loopback that overlaps this section of the span.


- Have the DS1 service provider at the CO end run a local ICSU line loopback test.
- Have the DS1 service provider at the CO end run a local DS1 payload loopback test.

- Run a far-end ICSU line loopback, using the procedure below.

⇒ NOTE:

This test cannot isolate the problem if there are problems in the wiring between the far-end CO and the far-end ICSU. You must coordinate this test with the DS1 service provider.


1. From the management terminal, enter  
**test DS1-loop UUCSS far-csu-loopback-test-begin**  
 where **UU** is the cabinet number, **C** is the carrier number, and **SS** is the slot number of the DS1 board.
2. Examine the bit-error counts, as in [“Testing the integrity of data sent over the loop” on page 9-133.](#)
3. Terminate the test. Enter  
**test DS1-loop location end-loopback/span-test.**
3. If the tests fails and the there were no problems [“Testing the DS1 Span from the ICSU to the Loopback Jack”](#) or [“Testing the DS1 Span from the Smart Jack to the Network Interface Termination or Fiber Multiplexer \(MUX\)”](#), there is a problem between the loopback jack to the smart jack. Work with the service provider to isolate the fault.



prdfcs7 KLC 012797

- |  |   |
|--|---|
| 1. Span section 1                                      | 6. Loopback jack                                    |
| 2. Span section 2                                      | 7. Network interface smart jack                     |
| 3. Span section 3                                      | 8. Interface termination or fiber multiplexer (MUX) |
| 4. 120A2 (or later) ICSU                               | 9. Central office                                   |
| 5. RJ-48 to network interface (up to 1000 ft. [305 m]) |   |


Figure 36. Network Interface at Smart Jack



prdfcs4 KLC 012797

- |  |   |
|--|---|
| 1. Span section 1                                      | 6. Loopback jack                                    |
| 2. Span section 2                                      | 7. Dumb block (extended demarcation)                |
| 3. Span section 3                                      | 8. Network interface smart jack                     |
| 4. 120A2 (or later) ICSU                               | 9. Interface termination or fiber multiplexer (MUX) |
| 5. RJ-48 to network interface (up to 1000 ft. [305 m]) | 10. Central office                                  |

Figure 37. Network Interface at Extended Demarcation Point (Smart Jack Inaccessible)




pdfcs5 KLC 012797

- |  |   |
|--|---|
| 1. Span section 1                                      | 6. Loopback jack                                    |
| 2. Span section 2                                      | 7. Dumb block (extended demarcation)                |
| 3. Span section 3                                      | 8. Network interface smart jack                     |
| 4. 120A2 (or later) ICSU                               | 9. Interface termination or fiber multiplexer (MUX) |
| 5. RJ-48 to network interface (up to 1000 ft. [305 m]) | 10. Central office                                  |
|  | 11. Dumb block to smart jack RJ-48                  |

Figure 38. Network Interface at Extended Demarcation Point (Smart Jack Accessible)

## Loopback Testing Without a Smart Jack

When the loopback jack is added to a span that does not contain a smart jack, the span is divided into 2 sections: from the ICSU to the loopback jack and from the loopback jack to the central office (CO). Section 2 includes the short cable from the loopback jack to the dumb block demarcation point (part of the loopback jack). This cable is the only part of Section 2 that is part of customer premises wiring. It is not covered in the loopback jack's loopback path. See [Figure 39](#) and [Figure 40](#).




pdfcs8 KLC 012497

1. Span section 1
2. Span section 2
3. 120A2 (or later) ICSU
4. RJ-48 to network interface (up to 1000 ft. [305 m])

5. Loopback jack
6. Dumb block (demarcation point)
7. Interface termination or fiber multiplexer (MUX)
8. Central office

Figure 39. Network Interface at "Dumb" Block



prdfcs6 KLC 012497

- |  |                                   |
|--|-----------------------------------|
| 1. Span section 1                                      | 6. Dumb block (demarcation point) |
| 2. Span section 2                                      | 7. Repeater                       |
| 3. 120A2 (or later) ICSU                               | 8. Fiber multiplexer (MUX)        |
| 4. RJ-48 to network interface (up to 1000 ft. [305 m]) | 9. Central office                 |
| 5. Loopback jack                                       |                                   |

**Figure 40. Network Interface at “Dumb” Block with Repeater Line to Fiber MUX**

You are responsible for finding and correcting problems in the customer wiring (section 1 and the loopback cable portion of section 2). The DS1 service provider is responsible for finding and correcting problems in the majority of section 2.

Proceed as follows.

1. Test customer premises wiring from the ICSU to the loopback jack, as described in the “DS1 Span Test” section.
2. Test the loopback jack-to-*dumb* block and *dumb* block-to-CO wiring (section 2 in [Figure 39](#)). This can be done using a loopback that “overlaps” the section of the span. Any of the following loopbacks can do this:
  - The local ICSU’s line loopback, which the DS1 service provider at the CO end typically activates, tests, and then deactivates.
  - The local DS1 interface’s payload loopback, which the DS1 service provider at the CO end activates and tests.

- The far-end ICSU's line loopback. Activate this test at the management terminal by entering **test DS1-loop location far-csu-loopback-test-begin**. Terminate this test by entering **test DS1-loop location end-loopback/span-test**. Bit error counts are examined as described in the "DS1 Span Test" section. This test only isolates problems to Section 2 wiring if there are no problems in the wiring between the far-end CO and the far-end ICSU. Coordinate this test with the DS1 service provider.

Failure of any of the above tests (a, b, or c) indicate a problem in Section 2. This could mean bad loopback jack -to-"dumb" block cabling, but is more likely to indicate a problem somewhere between the "dumb" block and the CO. This is the responsibility of the DS1 service provider.

If the DS1 Span Test confirms that there are no problems in Section 1, the technician should proceed as follows to avoid unnecessary dispatch.

1. Identify and contact the DS1 service provider.
2. Inform the DS1 provider that loopback tests of the CPE wiring to the "dumb" block (section 1) showed no problems.
3. If the far-end ICSU line loopback test failed, inform the DS1 provider.
4. Request that the DS1 provider perform a loopback test of their portion of the Section 2 wiring by sending someone out to loop Section 2 back to the CO at the "dumb" block.

If this test fails, the problem is in the service provider's wiring.

If the test passes, the problem is in the cable between the loopback jack and the "dumb" block. Replace the loopback jack.

## Configurations Using Fiber Multiplexers

Use the loopback jack when customer premises DS1 wiring connects to an on-site fiber multiplexer (MUX) and allows wiring to the network interface point on the MUX to be remotely tested. This requires that ICSUs be used on DS1 wiring to the MUX.

Fiber MUXs can take the place of Interface termination feeds as shown in [Figure 36](#), [Figure 37](#), [Figure 38](#), and [Figure 39](#). Test these spans using the same procedures as metallic spans. Note the following points:

1. Fiber MUXs may have loopback capabilities that can the service provider can activate from the CO end. These may loop the signal back to the CO or back to the DS1 board. If the MUX provides the equivalent of a line loopback on the “problem” DS1 facility, activate it after a successful loopback jack test, and use it to isolate problems to the wiring between the loopback jack and the MUX.
2. Be aware that there are installations that use repeatered metallic lines between the MUX and the “dumb” block. These lines require DC power for the repeaters and this DC power is present at the “dumb” block interface to the CPE equipment. *A loopback jack is required in this configuration to properly isolate and terminate the DC power.*

To check for the presence of DC, make the following 4 measurements at the network interface jack:

1. From transmit tip (T, Pin 5) to receive tip (T1, Pin 2)
2. From transmit ring (R, Pin 4) to receive ring (R1, Pin 4)
3. From transmit tip (T, Pin 5) to transmit ring (R, Pin 4)
4. From receive tip (T1, Pin 2) to receive ring (R1, Pin 4)

All measurements should read 0 (zero) volts DC. For pin numbers and pin designations, refer to *Integrated Channel Service Unit (ICSU) Installation and Operation*.

## Operating Characteristics

If a TN464F or TN767E and a 120A2 were installed in a system running pre-DEFINITY ECS, V3 software and the software is later upgraded to DEFINITY ECS, V3 Release 3 or later, remove and re-install the DS1 circuit pack so that the ICSU administration fields will appear on the DS1 administration screen.

**9** DS1/T1 CPE Loopback Jack  
*Loopback Testing Without a Smart Jack*

144

## ISDN Converters and Adapters

# 10

---

This chapter provides information on converters and adapters sometimes necessary when connecting to coaxial facilities in either a multicarrier cabinet or a single carrier cabinet. Connections include


- Integrated Services Data Network Primary Rate Interface (ISDN-PRI) to Direct Access Secondary Storage (DASS)
- PRI to Digital Private Network Signaling System (DPNSS)
- PRI to ISDN Basic Rate Interface (ISDN-BRI)

Converter circuit packs as known as common channel signaling converter (CCSC), types 1 and 2.

## Converters for Single-Carrier Cabinets

### PRI-to-DASS and PRI-to-DPNSS Converters

Figure 41 shows typical connections from the CCSC-1 PRI-to-DASS converter or the CCSC-2 PRI-to-DPNSS converters to the coaxial facility.




1. To TN464F DS1 circuit pack and either a CSCC-1 PRI-to-DASS converter or a CSCC-2 PRI-to-DPNSS converter circuit pack
2. Administration PC
3. RS-232 cable to front of PRI converter circuit pack
4. 888B coaxial converter
5. Coaxial connection to 2-Mbps facility
6. Coaxial cable from PRI converter circuit pack to coaxial converter

Figure 41. Typical DASS or DPNSS converter Cabling

1. Plug the DEFINITY administration PC into the RS-232 connector on the front of the PRI converter circuit pack.
2. Connect the coaxial Y-cable from the TN464F to the PRI converter circuit pack.
3. Connect the opposite end of the Y-cable to the 888B coaxial converter.

## PRI-to-BRI Converter

Figure 42 shows typical connections from the PRI-to-BRI converter to the coaxial facility.



- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. To TN464F DS1 circuit pack and PRI-to-BRI converter circuit pack</li> <li>2. DEFINITY administration PC</li> <li>3. RS-232 cable to front of converter circuit pack</li> <li>4. 888B coaxial converter</li> <li>5. Coaxial connection to 2-Mbps facility</li> </ol> | <ol style="list-style-type: none"> <li>6. Coaxial cable from PRI converter circuit pack to coaxial converter</li> <li>7. TN464F circuit pack</li> <li>8. PRI-to-BRI converter circuit pack</li> <li>9. Jumper coaxial cable</li> <li>10. Inset showing connections on rear of carrier</li> </ol> |
|---|--|

Figure 42. Typical PRI to BRI Converter Cabling



**NOTE:**


The inset shows details of the cable connections between the circuit packs. Connect the DEFINITY administration PC to the RS-232 connector on the front of the PRI converter circuit pack.

## Converters for Multicarrier Cabinets

### PRI to DASS and PRI to DPNSS Converters

1. Connect the DEFINITY administration PC to the RS-232 connector on the front of the PRI converter circuit pack.

Figure 43 shows typical connections from the CCSC-1 PRI-to-DASS converter or the CCSC-2 PRI-to-DPNSS converters to the coaxial facility.




1. To TN464F DS1 circuit pack and either a CSCC-1 PRI-to-DASS converter or a CSCC-2 PRI-to-DPNSS converter circuit pack
2. DEFINITY administration PC
3. RS-232 cable to front of PRI converter circuit pack
4. 888B coaxial converter
5. Coaxial connection to 2-Mbps facility
6. Coaxial cable from PRI converter circuit pack to coaxial converter

Figure 43. Typical DASS or DPNSS Converter Cabling

## PRI-to-BRI Converter

Figure 44 shows typical connections from the PRI-to-BRI converter to the coaxial facility. The DEFINITY administration PC is connected to the RS-232 connector on the front of the PRI converter circuit pack.



- |  |  |
|--|--|
| <ol style="list-style-type: none"> <li>1. TN464F DS1 circuit pack and PR-to-BRI converter circuit pack</li> <li>2. DEFINITY administration PC</li> <li>3. RS-232 cable to front of converter circuit pack</li> <li>4. 888B 75-ohm coaxial converter</li> <li>5. Coaxial connection to 2-Mbps facility</li> </ol> | <ol style="list-style-type: none"> <li>6. Coaxial cable from PRI converter circuit pack to coaxial converter</li> <li>7. TN464F circuit pack</li> <li>8. PRI-to-BRI converter circuit pack</li> <li>9. Jumper coaxial cable</li> <li>10. Inset showing connections on rear of carrier</li> </ol> |
|--|--|

Figure 44. Typical PRI to BRI Converter Cabling

**NOTE:**

The inset shows details of the cable connections between the circuit packs.

**10** ISDN Converters and Adapters  
*Converters for Multicarrier Cabinets*

150

# Stratum 3 Clock

# 11

The Stratum 3 clock is an optional feature for digital frame timing that couples the clock output to local clocks. This chapter provide information on setting the option switches on the clock. For installation information refer to the appropriate installation or upgrade book for your system.

## Set Clock Options

There are four sets of option switches on the clock. Proceed as follows.

1. Set the options on the clock input board (CI) per [Table 17](#).

**Table 17. CI Option Switch Settings**

Switch	Function	Position
1	T1 select	OFF = enable (default) ON = disable
2	CC select	OFF = enable ON = disable (default)
3	Framing select	OFF = ESF ON = D4 (default)
4	BX.25	OFF = enable ON = disable (default)

- Set the options on the Stratum 3 Clock board (ST3) per [Table 18](#).

**Table 18. ST3 Clock Board Option Switch Settings**

Switch	Status/Results
SW1 Minor alarm control	OFF = minor alarm never output ON = minor alarm is output if holdover occurs
SW2 Major Alarm Control	OFF = major alarm is output and fail lamp lights if 5 VDC power is lost and 4 kHz output is lost ON = major alarm is output and fail lamp lights if 5 VDC power is lost and 4 kHz output is lost and holdover occurs



**NOTE:**

Only SW 1 and SW2 are used. SW1 controls the output of alarm signals from the Stratum 3 Clock board.

- Set the options on the Composite Clock Timing Output Board (TOCA) per [Table 19](#).
- Set the Stratum 2/Stratum 3 switch to the STRATUM 3 position.

**Table 19. Composite Clock Timing Output Board (TOCA)**

Switch		Range in feet (meters)							
500	1000	1.0 (0.3)	500 (152)	1000 (305)	1500 (457)	2000 (710)	2500 (772)	3000 (914)	
OFF	OFF								
ON	OFF								
OFF	ON								
ON	ON								



**NOTE:**


Set switches 1 and 2 according to the distance from the Stratum 3 clock to the DEFINITY System. Set switch 3 to ON. Set switch 4 to OFF.

## Cabling the Stratum 3 Clock

---

Figure 45 shows typical connections to a Stratum 3 Clock cabinet. Connections are made through the yellow field cross-connect. A custom Y-cable (H600-274) connects the CSU to the DS1 circuit pack and taps off the input for the Stratum 3 Clock. A resistor built into the cable provides the necessary isolation between the system and the clock. The Y-cable plugs directly into the CSU and connects to standard cables for interface to the system and the yellow field on the MDF.

The H600-307 cable connects the system end of the Y-cable to a DS1 circuit pack (shown as TN464F or TN767E). The B25A cable connects the clock end of the Y-cable to the yellow field on the MDF.



cydfst3 KLC C

- |                               |  |
|-------------------------------|--|
| 1. PPN cabinet                | 8. Secondary CSU                         |
| 2. "A" position               | 9. Primary CSU                           |
| 3. "B" position               | 10. Stratum 3 Clock                      |
| 4. H600-307 cable             | 11. MDC                                  |
| 5. H600-274, G2 cable         | 12. TN464F DS1/E1 interface circuit pack |
| 6. 1300 ft. (397 m)           | 13. TN767E DS1 circuit pack              |
| 7. B25A male to female cables | 14. TN780 tone-clock circuit pack        |

Figure 45. Typical Connections to Stratum 3 Clock

The H600-307 cable connects the system end of the Y-cable to a DS1 circuit pack (shown as TN464 or TN767E). The B25A cable connects the clock end of the Y-cable to the yellow field cross-connect.

## Stratum 3 Clock Wiring Installation Procedure

1. Connect the B25A cables from the TN780 connector panel slot on the system cabinet and the Stratum 3 Clock to the cross-connect module in the yellow field.
2. Connect the CSU plug end of the H-600-274 Y-cable to the primary CSU. Route an H600-307 cable from the DS1 connector panel slot on the system cabinet to the connector on the "SYSTEM" end of the Y-cable.
3. Route a B25A cable from the "CLOCK" end of the Y-cable to the cross-connect module in the yellow field.
4. Repeat steps 2 and 3 for the secondary CSU. The maximum allowable cabling distance between the Stratum 3 clock and the CSU is shown in the table below.

**Table 20. Maximum Cabling Distance for Different CSUs**

Channel Service Unit (CSU)	Maximum Cabling Distance
551A	85 feet (27 m)
551V	85 feet (27 m)
551V EFS/R	755 feet (199.7 m)
EFS T1	755 feet (199.7 m)

5. For standard reliability systems, refer to Y-cable to cross-connect the TN780 and "CLOCK" end connections to the Stratum 3 clock connections on the cross-connect module.
6. For high or critical reliability systems, refer to table below to cross-connect the TN780 and "CLOCK" end connections to the Stratum 3 clock connections on the cross-connect module.

**Table 21. Y-Cable Clock-End Cross-Connects for Reliability**

From Stratum 3 Clock		To Y-cable clock end (primary)		To Y-cable clock end (secondary)	
Lead Name	Lead Color/ Terminal	Lead Name	Lead Color/ Terminal	Lead Name	Lead Color/ Terminal
RREF1	W-BL/1		V-O/43		
TREF1	BL-W/2		O-V/44		
RREF2	W-O/3				V-O/43
TREF2	O-W/4				O-V/44

**Table 22. TN780-Carrier Cross-Connects for Standard Reliability**

From Stratum 3 Clock		To TN780 carrier A		To TN780 carrier B	
Lead Name	Lead Color/ Terminal	Lead Name	Lead Color/ Terminal	Lead Name	Lead Color/ Terminal
BCLKRTN	R-O/13	ALRM5B	V-G/45		
BCLKLST	O-R/14	ALRM5A	G-V/47		
BPWRRTN	R-BR/17	ALRM4B	BK-BL/21		
BPWRLST	BR-R/18	ALRM4A	BL-BK/22		
REF2RTN	W-BR/7	ALRM3B	R-BR/17		
REF2LST	BR-W/8	ALRM3A	BR-R/18		
SCLKRTN	R-BL/11	ALRM2B	R-BL/11		
SCLKLST	BL-R/12	ALRM2A	BL-R/12		
SPWRRTN	R-G/15	ALRM1B	Y-BL/31		
SPWRLST	G-R/17	ALRM1A	BL-Y/32		
BCLKRTN	R-O/13	ALRM5B	V-G/45		
REF1RTN	W-G/5	ALRM0B	W-BR/7		
REF1LST	G-W/7	ALRM0A	BR-W/8		
CCA01R	R-S/19	EXTSYN0T	V-BL/41		
CCA01T	S-R/20	EXTSYN0R	BL-V/42		
CCB01R	BK-BL/21	EXTSYN1T	Y-G/35		
CCB01T	BL-BK/22	EXTSYN1R	G-Y/37		

**Table 23. Y-Cable Clock-End Cross-Connects for High or Critical Reliability**

From Stratum 3 Clock		To Y-cable clock end (primary)		To Y-cable clock end (secondary)	
Lead Name	Lead Color/ Terminal	Lead Name	Lead Color/ Terminal	Lead Name	Lead Color/ Terminal
RREF1	W-BL/1		V-O/43		
TREF1	BL-W/2		O-V/44		
RREF2	W-O/3				V-O/43
TREF2	O-W/4				O-V/44

**Table 24. Circuit-Pack Cross-Connects for High or Critical Reliability**

From Stratum 3 Clock		To TN780 carrier A		To TN780 carrier B	
Lead Name	Lead Color/ Terminal	Lead Name	Lead Color/ Terminal	Lead Name	Lead Color/ Terminal
BCLKRTN	R-O/13	ALRM5B	V-G/45	ALRM5B	V-G/45
BCLKLST	O-R/14	ALRM5A	G-V/47	ALRM5A	G-V/47
BPWRRTN	R-BR/17	ALRM4B	BK-BL/21	ALRM4B	BK-BL/21
BPWRLST	BR-R/18	ALRM4A	BL-BK/22	ALRM4A	BL-BK /22
REF2RTN	W-BR/7	ALRM3B	R-BR/17	ALRM3B	R-BR/17
REF2LST	BR-W/8	ALRM3A	BR-R/18	ALRM3A	BR-R/18
SCLKRTN	R-BL/11	ALRM2B	R-BL/11	ALRM2B	R-BL/11
SCLKLST	BL-R/12	ALRM2A	BL-R/12	ALRM2A	BL-R/12
SPWRRTN	R-G/15	ALRM1B	Y-BL/31	ALRM1B	Y-BL/31
SPWRLST	G-R/17	ALRM1A	BL-Y/32	ALRM1A	BL-Y/32
REF1RTN	W-G/5	ALRM0B	W-BR/7	ALRM0B	W-BR/7
REF1LST	G-W/7	ALRM0A	BR-W/8	ALRM0A	BR-W/8
CCA01R	R-S/19	EXTSYN0T	V-BL/41		
CCA01T	S-R/20	EXTSYN0R	BL-V/42		

*Continued on next page*

**Table 24. Circuit-Pack Cross-Connects for High or Critical Reliability — Continued**

From Stratum 3 Clock		To TN780 carrier A		To TN780 carrier B	
Lead Name	Lead Color/ Terminal	Lead Name	Lead Color/ Terminal	Lead Name	Lead Color/ Terminal
CCB01R	BK-BL/21	EXTSYN1T	Y-G/35		
CCB01T	BL-BK/22	EXTSYN1R	G-Y/37		
CCA02R	BK-O/23			EXTSYN0T	V-BL/41
CCA02T	O-BK/24			EXTSYN0R	BL-V/42
CCB02R	BK-G/25			EXTSYN1T	Y-G/35
CCB02T	G-BK/26			EXTSYN1R	G-Y/37

7. Bridge the jumper wires to cross-connect from the TN780 in A and B carriers to the Stratum 3 Clock.
8. Dress the cables down sides of the cabinet and run through the cable Slack Manager, if provided.
9. Administer the switch for the clock.

# Busy Tone Disconnect Equipment for Non-U.S. Installations


# 12



**NOTE:**

Beginning with DEFINITY ECS R10, Busy Tone Disconnect is available as a software feature.

The customer-provided busy-tone disconnect adjunct detects disconnects of incoming calls on loop-start, 2-wire, analog trunks. In some countries outside the United States, the PSTN sends tones in the voice band instead of line disconnect signals. [Figure 46](#) shows typical connections.



- |                                      |   |
|--------------------------------------|---|
| 1. Public switched telephone network | 4. Tip and ring wires   |
| 2. Main distribution frame           | 5. To loop-start, central-office, trunk circuit pack such as a TN747B |
| 3. Busy tone disconnect device       |   |

**Figure 46. Typical Cabling for Busy Tone Disconnect**



## Call Detail Recording Option Settings

# 13

---

This chapter provides information on connecting Call Detail Recording (CDR) equipment to a DEFINITY.

### Connecting CDR Equipment to DEFINITY ECS

---

The interface between the DEFINITY and CDR equipment may be a

- Data module (see [Chapter 4, “Data Modules and Asynchronous Data Units”](#), for recommended settings)
- Modem (see [Chapter 5, “External Modems”](#), and the modem vendor’s documentation for recommended settings)
- TN726 data line circuit pack and an asynchronous data unit
- TCP/IP connection to the C-LAN board, either directly connected or through a terminal server

CDR equipment can connect directly to the DCE connector (EIA Port) on the rear of the control carrier in all systems except G3csi. Data modules or modems are not required. In G3csi, CDR equipment connects to the DCE (J2) connector on the processor interface cable.

## 13 Call Detail Recording Option Settings

*Using a Printer as the CDR Output Device*

162

## Using a Printer as the CDR Output Device

---

You can use a printer as an output-receiving device for CDR. The recommended option settings for the Model 572 printer are shown in [Table 25](#).

**Table 25. 572 Printer Used with Management Terminal, CDR, or Journal Printer**

Function	Function Name	Menu	Menu Status
01	FORM LENGTH	09	11
02	LPI	01	6
03	CPI	01	10
04	LQ or NLQ	01	LQ
05	BUZZER	01	ON
06	FONT	02	FONTCART
07	RESOLUTION	01	144
11	BUFFER	02	N-LINE
13	PW ON MODE	01	ON-LINE
14	DIRECTION	01	B1-DIR.1
15	BUFF FULL	02	LF + CR
16	P.E.	01	ACTIVE
17	AUTO CARRIAGE RETURN (CR)	01	CR + LF
18	ZERO	01	0
22	AUTO LINE FEED	01	CR ONLY
31	1" SKIP	01	OFF
32	CHAR.SET (GO, GL)	02	USA
33	CHAR.SET (G1, GR)	01	UK
34	CHAR SET (G2)	03	GE
35	CHAR SET (G3)	07	LINE DRAWING
81	OFF-LINE STATE	01	ALL RECEIVE
82	DSR	02	OFF

*Continued on next page*

**Table 25. 572 Printer Used with Management Terminal, CDR, or Journal Printer — Continued**

Function	Function Name	Menu	Menu Status
83	REQUEST TO SEND (RTS) TIMING	01	RTS
84	CD	02	OFF
85	CLEAR TO SEND (CTS)	02	OFF
91	OVER RUN	02	256
92	DATA BIT	02	8
93	PROTOCOL	03	XON/XOFF
94	STOP BIT	01	1
95	PARITY	01	NONE
96	PBS	01	9600

## **Using Other Equipment as the CDR Output Devices**

A CDR, a 94A local storage unit (LSU), or customer premises equipment (CPE) can be used as the output receiving device.

## **Sources of Administration Information**

Administration procedures for CDR equipment are provided in *DEFINITY Enterprise Communications Server Administrator's Guide*.



**13** Call Detail Recording Option Settings*Using the Downloadable Reliable Session-Layer Protocol Tool*

165

2. In the Primary Output Endpoint field, type **CDR1**. If you use a secondary output device, and that device is also connected via TCP/IP, type **CDR2** in the Secondary Output Endpoint field.
3. Press ENTER to save your changes.

**Testing the switch-to-adjunct link**

You can use the test, status, busyout and release commands for to find and correct problems with CDR links. For more information about these commands, see the Maintenance manual for your switch.

```
status cdr-link
                CDR LINK STATUS
                Primary                Secondary
Link State: up                extension not administered
Maintenance Busy? no
```

**Figure 47. Example status screen for CDR link**

You should also work with the vendor to test the link from the call accounting end. If you are installing the INTUITY Lodging Call Accounting, work with the Homisco technician to test the link.

If a link does not come up immediately, try using the busyout cdr-link and release cdr-link commands.

**Using the Downloadable Reliable Session-Layer Protocol Tool**

The intent of the Reliable Session-Layer Protocol (RSP) is to guarantee delivery of data records from the switch to an output device that connects to the switch over an asynchronous TCP/IP link. The Downloadable RSP tool allows you to implement this protocol on a PC that collects data records in a file. The protocol assures that the data records arrive safely at the PC. You can then send the output file to a printer.

**Setting up an RSP configuration**

To set up an RSP configuration:

- Administer the PC as a client application on the switch.
- Download, install, and administer the RSP for the PC

## Setting up the switch

To set up the server application on the switch, complete the following tasks:

- [“Administering IP node names” on page 8-126](#)

Give the PC a node name. The IP address is the IP address of the PC that is running the RSP tool.

- [“Administering IP services” on page 8-127](#)

The service type = SYS\_PRNT, the Remote Node = the node name assigned to the PC. Remote port is the port assigned as the listen port on the PC. You can determine the listen port by starting the RSP Server application, clicking on Start, and checking in the output window to see what port the server is listening on.

## Setting up the PC

To set up the client application on the PC:

- Download RSP
- Install RSP
- Administer RSP

### Downloading RSP

The RSP is available from the Avaya support web site as a self-extracting executable. To download the RSP:

1. Browse to the Avaya Customer Support web site:  
<http://support.avaya.com/sd.jhtml>
2. Select the RSP tool from the web site.
3. When queried, save the setup.exe file to a temporary folder on your computer. It is approximately 1.4-MB.

### Installing RSP

To install the RSP:

1. Double-click the setup.exe file.  
The Install Shield Wizard steps you through the installation.
2. When prompted to select Client or Server, select both programs.
3. Continue with the installation. Use the default destination folder and program folder.

4. You can view the readme file now or later. The following files are installed on the PC in the folder \\Program Files\Avaya\DEFINITY Data Transport Tool:

- client.exe (the client tool)
- server.exe (the server tool)
- user guide.doc (same as the readme file)
- spl\_design\_doc.doc (the RSP design document)
- splserver.ini
- ddt\_log.txt (installation log file)
- spl.dll

### **Administering RSP**

See the instructions in the user guide.doc file to administer the Reliable Session-layer Protocol on a PC.

**13** Call Detail Recording Option Settings  
*Using the Downloadable Reliable Session-Layer Protocol Tool*

168

## DEFINITY INADS

# 14

---

The DEFINITY ECS Initialization and Administration System (INADS) provides analog loopback connections and PARTNER<sup>®</sup> connections for remote alarming and maintenance when direct connection to the public network is not possible.



**NOTE:**


These instructions are for DEFINITY ECS systems using the TN1648/B system access/maintenance (SYSAM) circuit pack. ISDN is required.

### Analog Loopback

Analog loopback connects the INADS port to an analog station port. It switches the call through the AUX connector on the processor carrier of the DEFINITY ECS, across an analog line circuit pack, and out to the public network. Direct Inward Dialing (DID) is optional.

### **Installing INADS Analog Loopback on a Standard-Reliability System**

1. Connect the INADS tip and ring port from the AUX connector to an analog station port via the MDF. See [Figure 48](#). Use wire pair 50 and 25.
2. If you are using power-fail transfer, connect the 808A2 transfer panel between the *INADS connection to the station* and the *INADS connection to the loop-start trunk*.



- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. Release 8r PPN cabinet</li> <li>2. AUX connector on processor carrier<br/>(use wire pair 50 and 25, tip and ring)</li> <li>3. Port carrier (with analog line circuit pack)</li> </ol> | <ol style="list-style-type: none"> <li>4. B25A 25-pair cable to AUX</li> <li>5. Main distribution frame (MDF)</li> <li>6. B25A 25-pair cable to circuit pack</li> <li>7. PSTN or DEFINITY extension</li> </ol> |
|---|--|

Figure 48. Analog Loopback Connections G3r

### Installing INADS Analog Loopback on a High-Reliability System

Be sure to place the TN1648B SYSAM circuit packs in different cabinets or processor carriers. Also be sure to place the analog line circuit packs in the same cabinets or carriers as the TN1648 circuit packs.

1. Connect each INADS tip/ring port to an analog station port via the MDF. See [Figure 48](#).
2. Connect each tip/ring port to a separate analog line circuit pack.

## Administering DEFINITY ECS for INADS

---



### NOTE:

Add 2 pauses in front of the dial string when using cut-through trunks. Pauses are not required if using ARS.

1. Type **change system-parameters maintenance** and press Enter.
2. For high reliability systems, in the `see interchange:` field, type **daily** and press Enter. This is done in case 1 of the connections between the 2 TN1648B circuit packs is down. This assures that within 24 hours the working connection is available to report alarms.
3. Type **add station number** or **next** and press Enter.
4. In the `Type:` field, enter **500** (rotary analog telephone).
5. In the `Port:` field, enter the port number for this line.
6. For high reliability systems, repeat the above steps for the second analog line. Administer the 2 stations as part of a TEG (terminating extension group).
  - a. Type **add term-ext-group number** or **next** and press Enter.
  - b. In the `Group Extension:` field, enter the TEG extension number.
  - c. In the `Coverage Path:` field, enter the coverage path number.
  - d. Enter the Group Member Assignment station numbers. Press Enter when finished.

## Partner Installation

---

The PARTNER system connects the DEFINITY ECS INADS port to an outgoing central office (CO) line and is programmed to seize the outside line when INADS seizes an inside PARTNER station line.

Listed below are the 2 types of PARTNER platforms:

- PARTNER Atlas platforms with U.S. firmware and a wide input power supply (WIPS) that allows a universal power supply. The Spain platform conforms to the United States/Atlas platform
- European platforms that focus on eastern Europe and the United Kingdom


The installation procedure describes the 2 types of PARTNER platforms with or without power fail transfer.

## INADS Connection (with Power Fail Transfer)

### ⚠ CAUTION:

*Check local regulations regarding this connection method.*

In this configuration, the INADS line and the emergency telephone extension are bridged together. [Figure 49](#) shows the U.S./Atlas platform. [Figure 50](#) shows the European platform.



- |   |  |
|---|--|
| <ol style="list-style-type: none"> <li>1. PARTNER System</li> <li>2. MLS12D telephone for programming</li> <li>3. Internal connection during power failure, from CO line port 1 to station port 10</li> <li>4. 258A adapter (bridged connection)</li> <li>5. Standard RJ-45 telephone cord</li> <li>6. 103A or modular wall jack</li> </ol> | <ol style="list-style-type: none"> <li>7. Dial tone from CO or DEFINITY extension</li> <li>8. Main distribution frame</li> <li>9. PSTN or DEFINITY extension</li> <li>10. B25A 25-pair cable to AUX</li> <li>11. AUX connector (use wire pair 50 and 25, tip and ring)</li> <li>12. DEFINITY Release 8r PPN cabinet</li> </ol> |
|---|--|

Figure 49. INADS Connection (US/Atlas Platform)



## High Reliability

Be sure that the TN1648B SYSAM circuit packs are located in different DEFINITY cabinets or processor carriers.


1. Bridge the 2 INADS tip/ring ports. A 258A adapter may be used.
2. Connect the bridged INADS tip/ring port to a PARTNER station port.

## INADS Connection (without Power Fail Transfer)

### ⚠ CAUTION:

*Check local regulations regarding this connection method.*

In this configuration, the INADS line and the emergency telephone extension are bridged together. If this connection method is not allowed, do not connect the INADS port to station 10.



cydf206b RPY 021998

- |  |  |
|--|--|
| 1. PARTNER system                                | 6. Main distribution frame                           |
| 2. MLS12D telephone for programming              | 7. PSTN  |
| 3. Standard RJ-45 telephone cord                 | 8. B25A 25-pair cable                                |
| 4. 103A or modular wall jack                     | 9. AUX connector (use wire pair 50,25, tip and ring) |
| 5. Dial tone from the CO or a DEFINITY extension | 10. DEFINITY Release 8r PPN cabinet                  |

Figure 51. INADS Connection (all platforms)

## Standard Reliability

Normal connection:

1. Connect a system telephone to station 10 on the PARTNER system.
2. Connect a standard RJ-11 telephone line cord from the PARTNER CO line to the CO line protector.
3. Connect the INADS tip and ring port from the AUX connector to the tip/ring pair of CO line port 1 on the PARTNER via the MDF. See [Figure 51](#). Use wire pair 50 and 25 on the MDF.

U.S./Atlas/Spain platform connection:

1. Select station 11-15 as the INADS port connection.

European platform connection:

1. Bridge the outside pair of CO line port 1 to the INADS port. A 258A adapter may be used.

## High Reliability

Be sure that the TN1648B SYSAM circuit packs are located in different cabinets or processor carriers.

1. Bridge the 2 INADS tip/ring ports. A 258A adapter may be used. See [Figure 51](#).
2. Connect the bridged INADS tip/ring port to a station port.

## PARTNER Administration

### Set Standard Telephone Station (European Platforms Only)



**NOTE:**

Do not exit from the programming mode until instructed to do so.

1. Connect the PARTNER programming telephone (MLS12) to station 10.
2. Press Feature, followed by 0 0.
3. Press the left intercom (System Program) button twice.
4. Enter the password. The default password is **7777**. The green LED next to the left intercom button must be steady on.
5. Enter **# 3 0 8**.
6. Enter **1 0** (if station 10 is connected to the INADS port) or the station number connected to the INADS port.

7. Enter **2** to set the station port to analog rotary. Enter **1** if an analog DTMF telephone or PARTNER system telephone is connected.
8. Enter **#** to return to the start of the programming mode.

### Set PARTNER CO Line Port (All Platforms)

1. Enter **# 2 0 1**.
2. Press **1** for tone or **2** for pulse mode.
3. Enter **#** to return to the start of the programming mode.

### Set Automatic Line Selection — Outgoing Trunk (All Platforms)

1. Press the right intercom (Central Tel Program) button.
2. Enter **1 5** (if INADS is connected to station 15) or enter the station number connected to the INADS port.
3. Enter **\*\***.
4. Press the line 1 button (above left intercom). If the 2 lines are connected to the PARTNER for added reliability or security, press Next Procedure.
5. Enter **\*\***.
6. Enter **#** to return to the start of the programming mode.

### Set Incoming Line Ringing (All Platforms)

1. Press the right intercom (Central Tel Program) button.
2. Enter **1 5** (if INADS is connected to station 15) or enter the station number connected to the INADS port.
3. Press the line 1 button (above left intercom) until the LED changes to a steady green. This allows incoming calls to ring on line 1.
4. If AUDIX is installed, press the line 2 button until the LED changes to a steady green. This allows incoming calls to ring on line 2.
5. Enter **#** to return to the start of the programming mode.
6. Press Feature, followed by 0 0 to exit the programming mode.

## DEFINITY ECS Administration

By default, the INADS port automatically seizes an outgoing trunk on the PARTNER system. Therefore, a “9” is not required in the switch dial string.

## Installation Test (All Installations)

These tests confirm that the hardware and administration are correct.

1. Place an outgoing call from the INADS port. Check for normal talk path.
2. Place an incoming call to the INADS port. Check for normal talk path.
3. Place an outgoing data from the INADS port to verify connection.

A failure in the link between the remote service center and the TN1648Bs INADS port can be detected automatically.

1. Type **change system-parameters maintenance** and press Enter.
2. Set the `Test Remote Access Port:` field to **y** and press Enter.







**NOTE:**

909A couplers ships with one DW4B-DE cable and two DW8B-SE cables. The 909B ships with one KS-22911L2 power supply, one DW4B-DE cable, and two DW8B-SE cables.

1. Determine the port assignment of the recorder from the malicious call tracing form.
2. Install the 909A/B universal coupler on a vertical surface.
3. Connect the SZ, SZ1, S, and S1 leads from the 909A/B to an auxiliary trunk circuit pack.
  - a. Tip and ring connect from the voice recorder to the auxiliary trunk circuit pack (J1 on the 909A/B).
  - b. CBS1/C1 and CBS2/C2 connect from the voice recorder to J2 on the 909A/B.
4. On the 909A/B universal coupler:
  - a. Connect seizure control voltage of from -9 to -70 Volts to the PG2/BZ2 connection (pin 2 of J1). Switching voltage to the PG2/BZ2 connection can be from the 909A/B -48 VDC supply.
  - b. Connect SZ1 to the ground lead of the DC power source used for PG2/BZ2.
  - c. Set S1 to the "C2" position. Set S2 position 7 to "OPEN".
  - d. Connect an approved -48 VDC power source to the **-48** and **GRD** terminals (pins 5 and 2, respectively, of J3 on the 909A/B).
5. Administer the switch for the call trace device.

## Loudspeaker Paging, Music-on-Hold, and External Alerting Equipment

# 16

---

This chapter provides information on connecting the equipment necessary to use the following features:

- Loudspeaker paging
- Music on hold
- Dial dictation
- Recorded announcement access
- External ringing
- Queue warning indicator

### Loudspeaker Paging

The loudspeaker paging feature provides a connection from a TN763B/C/D auxiliary trunk circuit pack (or equivalent) to a customer-supplied paging amplifier. The music-on-hold feature provides a connection from a TN2183 analog line circuit pack (or equivalent) or auxiliary trunk circuit pack to a customer-supplied music source.

#### Loudspeaker Paging without Paging Adapter


Figure 53 shows the connections for the loudspeaker paging feature. These connections are used when the loudspeaker interface equipment is not located in the equipment room. If the equipment is located in the equipment room, the information outlet is not required. The connections shown are for one zone.

The figure also shows connections from the music source to the loudspeaker system through a paging amplifier as well as through a 909A/B coupler. A wiring block must be locally engineered.

**NOTE:**

If the loudspeaker paging system provides a talk-back microphone at the speakers, the microphone must be FCC approved (or equivalent) or a 909A/B universal coupler is required.

Refer to the tables at the end of this chapter for pinouts of the auxiliary trunk circuit pack.



- |   |  |
|---|--|
| 1. 25-pair cable to TN763B/C/D auxiliary trunk circuit pack (SZ1 connects to GRD on key 10) | 6. Music source for background music over loudspeakers |
| 2. Loudspeaker system   | 7. 103A or modular wall jack                           |
| 3. 909A/B universal coupler (if required)   | 8. To SZ1 on TN763B/C/D connector                      |
| 4. Part of main distribution frame  | 9. Tip and ring wires                                  |
| 5. Paging amplifier   | 10. -48 VDC power supply for 909B                      |

0031\_0 RBP 062696

Figure 53. Connections for Loudspeaker Paging

**Loudspeaker Paging Access (Without Universal Coupler)**

1. Determine port assignment of paging zone(s) from loudspeaker paging form.
2. At the main distribution frame, locate the connecting block and terminals assigned to the selected port.
3. On the locally engineered wiring block, place a strap between terminals S and SZ. Place a strap between terminals S1 and SZ1.
4. Install patch cord/jumper wires at the main distribution frame.

5. Connect a 2-pair line cord (modular plug at one end) from the information outlet to the paging amplifier (to the loudspeaker system).
6. Install loudspeaker equipment per the manufacturer's instructions.
7. Administer the switch for the new equipment.

## Loudspeaker Paging with Universal Coupler

An information outlet provides access to loudspeaker paging. The system side of the main distribution frame connects to a 909A/B universal coupler. Make provisions for the DC power that the 909A/B universal coupler requires, such as a 1151A, 1151A2, or other approved -48VDC power supply.

Six leads (T, R, SZ, SZ1, S, and S1) connect the adapter to an auxiliary trunk circuit pack located in a port carrier.

1. Determine port assignment of paging zone(s) from loudspeaker Paging form.
2. Identify carrier slot and label both ends of an A25D (male to male) cable.
3. Connect a cable from the 909A/B to the system side of the main distribution frame. A wiring block must be locally engineered.
4. [Chapter 1, "909A/B Universal Coupler"](#) provides details of the connections between the 909A/B universal coupler and the wiring blocks.



### **CAUTION:**

*Damage to the 909A/B may occur if the cable is plugged into J3 **before** all cross-connects are completed.*


5. On the 909A/B universal coupler:
  - Connect seizure control voltage of from -9 to -70 volts to the PG2/BZ2 connection (pin 2 of J1). Switching voltage to the PG2/BZ2 connection can be from the 909's -48-volt supply.
  - Connect a -48 VDC power source to the -48 and GRD terminals on the 909A/B.
6. Install patch cord/jumper wires at the main distribution frame.
7. Connect a 2-pair line cord (modular plug at one end) from the information outlet to the loudspeaker system.
8. Install loudspeaker equipment per the manufacturer's instructions.
9. Connect an approved -48 VDC power source to the **-48** and **GRD** terminals (pins 5 and 2, respectively, of J3).
10. Administer the switch for the new equipment.

## Music-on-Hold, Dial Dictation, or Recorded Announcement Access

Figure 54 shows the connections for music-on-hold, dial dictation, or recorded announcement features when the music source is Federal Communications Commission (FCC) registered (or equivalent). Figure 55 on page 16-185 shows the connections when the music source is not FCC-registered (or equivalent).

### NOTE:

Use the following connection instructions when the music source is not located in the equipment room. If the music source is located in the equipment room, do not route the connections through the information outlet.



1. Music source
2. 4-pair modular cord
3. 103A or modular wall jack
4. 122A music adapter (if required) primarily France
5. Tip (green) and ring (red)
6. Part of main distribution frame
7. A25D 25 pair cable (male-to-male) to auxiliary trunk circuit pack

Figure 54. Typical Registered Equipment Connections (Auxiliary Access)

1. If the music source is registered, the system side of the MDF connects directly to the system.
2. If the music source is not registered, the system side of the MDF connects to a 909A/B universal coupler.

### Registered Music Source

Refer to Figure 54 to install a registered music source.

1. Determine feature port assignment from Feature-Related System Parameters Form.
2. Install music source per the manufacturer's instructions.
3. Install patch cord/jumper wires at the main distribution frame.
4. Administer the switch for the new equipment.





## Paging and Announcement Equipment

# 17

---


This chapter provides information on connecting the following pieces of equipment:

- PagePac Plus Paging System
- SPA Radio Paging

### PagePac Plus Paging System

#### PagePac D20


The PagePac D20 is a 20-watt amplicenter and controller that can operate alone or with a zone expansion unit to provide multiple paging zones. It requires a 909A/B universal coupler if it operates alone, and a wiring block must be locally engineered.



- |   |                                    |
|---|------------------------------------|
| 1. PagePac D20 amplicenter and controller   | 6. 103A or modular wall jack       |
| 2. 25-pair cable to TN763/B/C/D auxiliary trunk circuit pack (T, R, S, S1, SZ, SZ1) | 7. 4-pair modular cord             |
| 3. Universal coupler  | 8. To SZ1 on TN763/B/C/D connector |
| 4. Part of main distribution frame  | 9. Tip and ring wires              |
| 5. Power supply for universal coupler   | 10. CBS1/C1 and CBS2/C2            |

Figure 57. Connections for PagePac 20 Without Zone-Mate

Figure 58 shows a PagePac D20 amplicenter and controller with a zone expansion unit incorporated into the PagePac D20. The PagePac D20 amplicenter and controller does not require 909A/B when a zone expansion is installed.




cnrflyzm LJK 091696

- |   |   |
|---|---|
| 1. PagePac D20 controller (with zone expansion unit)  | 8. Ring (red)                             |
| 2. B25A 25-pair cable to auxiliary trunk circuit pack | 9. S wire                                 |
| 3. 103A or modular wall jack                          | 10. S1 wire                               |
| 4. Part of main distribution frame                    | 11. SZ and SZ1 (not used on station side) |
| 5. Station side (yellow field)                        | 12. 110P7A patch cord or jumpers          |
| 6. System side  | 13. SZ wire                               |
| 7. Tip (green)  | 14. SZ1 wire                              |
|   | 15. 4-pair modular cord                   |

Figure 58. Connections for PagePac 20 With Zone-Mate

## PagePac 20/100/300

The 20/100/300 PagePac paging system can be wall-mounted. The unit provides three output wattages: 20, 100 and 300. See [Figure 59](#). If the PagePac 20/100/300 amplicenter is used alone, it requires a 909A/B universal coupler, and a wiring block must be locally engineered.




- |   |                                |
|---|--------------------------------|
| 1. PagePac 20/100/300 system  | 6. To SZ1 on TN763/D connector |
| 2. 25-pair cable to auxiliary trunk circuit pack (T, R, S, S1, Sz, SZ1) | 7. CBS1/C1 and CBS2/C2         |
| 3. 909A/B universal coupler   | 8. Tip and ring wires          |
| 4. Part of main distribution frame                                      | 9. Page in connections         |
| 5. Power supply for universal coupler                                   | 10. Music/page connection      |
|   | 11. Signal ground connection   |

Figure 59. Connections for PagePac 20/100/300 System

## ESPA Radio Paging

Figure 60 shows typical connections to European Standard Paging Access (ESPA) equipment. Connect the LINE jack on the PassageWay interface to a digital line 4-wire DCP circuit pack via the MDF.



cydf004 RPY 123097

1. DCP telephone
2. 4-pair modular cord
3. PassageWay interface
4. 4-pair modular cord
5. 103A or modular wall jack
6. To digital line circuit pack RS-232 connector
7. ESPA radio paging equipment
8. Paging loudspeakers

Figure 60. Typical ESPA Radio Paging Connections

**17** Paging and Announcement Equipment  
*ESPA Radio Paging*

192

# Multimedia Communications Products: MMCX, MMCH, ESM

# 18

This chapter provides information on connecting the following equipment to DEFINITY:

- MASI for MMCX
- Wideband endpoints
- Multimedia call handling (MMCH)

## MASI for MMCX

---

The multimedia application server interface (MASI) enables the DEFINITY ECS to provide calling features to the MultiMedia Communications eXchange (MMCX). The MMCX server connects to the DEFINITY ECS through a D8W cable. See [Table 26](#) for pin assignments and [Figure 61](#) for pin locations.

**Table 26. D8W cable Modular Pin Assignments**

Pin	Signal	Pin	Signal
1	Receive ring	5	Transmit Tip
2	Receive tip	7	No connection
3	No connection	7	No connection
4	Transmit ring	8	No connection




Figure 61. Modular Jack Pin Assignment

You can connect the MMCX server to the DEFINITY ECS by either of two methods: directly or via the main distribution frame.

### Direction Connection

The figure below illustrates the direct method, which connects a DEFINITY ECS DS1 interface circuit pack to a customer-supplied digital line PC board in the MMCX, via a D8W cable.





Figure 62. MMCX Connected Directly to DEFINITY ECS

## Main Distribution Frame Connection

Figure 63 illustrates the main distribution frame method which connects a DEFINITY ECS DS1 interface circuit pack, with a 25-pair cable to the MDF, to the customer-supplied digital line PC board in the MMCX, via through a D8W cable.



- |                               |                              |
|-------------------------------|------------------------------|
| 1. DEFINITY ECS               | 5. Public telephone network  |
| 2. DS1 interface circuit pack | 6. 103A or modular wall jack |
| 3. 25-pair cable              | 7. D8W 4-pair modular cord   |
| 4. Main distribution frame    | 8. MMCX server               |


Figure 63. MMCX Connected to DEFINITY ECS via the MDF

## Wideband Endpoints

Wideband endpoints include video equipment or bridges/routers for LANs. Use the running list that accompanies the system to make cable connections.

### Nonsignaling Configuration

A nonsignaling connection to a wideband endpoint may connect to a channel service unit (CSU). If *not* using a CSU, the distance between the system and the endpoint is limited to a few hundred feet. See [Figure 64](#). The maximum distance depends on the type of cable and type of endpoint.



cydf049 RPY 123097


- |  |   |
|--|---|
| 1. Wideband endpoint (wire per manufacturer) | 6. DS1/E1 circuit pack                                |
| 2. Modular cord                              | 7. Main distribution frame (MDF)                      |
| 3. 103A or modular wall jack                 | 8. Distance limit depends on cable and endpoint type. |
| 4. Channel service unit (CSU)                | 9. A25D 25-pair cable (male-to-male)                  |
| 5. H600-307 cable to DTE connector on CSU    |   |

Figure 64. Typical Nonsignaling Wideband Configuration

If using a CSU, the distance between connections may be up to 1300 ft (397.2 m). The maximum distance to the endpoint depends on the type of cable and the specifications of the endpoint.

## Signaling Configuration

A signaling connection from the system to a wideband endpoint passes through a bandwidth controller. The distance between the system and the bandwidth controller depends on the type of cable and controller. Figure 65 shows connections with and without a CSU.



cydf047 PDH 091396


- |  |  |
|--|--|
| <p>1. Wideband endpoint (wire per manufacturer)</p> <p>2. To DS1/E1 circuit pack</p> <p>3. Optional channel service unit (CSU)</p> <p>4. 103A or modular wall jack</p> <p>5. Part of main distribution frame</p> | <p>6. Bandwidth controller</p> <p>7. H600-307 cable to DTE connector on CSU</p> <p>8. Distance limit depends on cable type and bandwidth controller type</p> <p>9. A25D 25-pair cable (male-to-male)</p> |
|--|--|

Figure 65. Typical Signaling Wideband Configuration

The bandwidth controller connects directly to the wideband endpoint. The controller typically installs near the endpoint where they directly connect (usually within a few feet of each other).

- For non-CSU installations, cross the transmit and receive lines so a transmit signal from the DS1/E1 circuit pack connects to the receive connection on the bandwidth controller and a transmit signal from the bandwidth controller connects to the receive connection on the DS1/E1 circuit pack.
- For CSU installations, cross the transmit and receive lines between the CSU and the bandwidth controller.

Figure 66 shows a remote port module. In this configuration, there can be considerable distance between the bandwidth controller and the wideband endpoint. The maximum distance between elements depends on the quality of the cables and on the specifications of the wideband equipment.



- |  |  |
|--|--|
| 1. To TN464F DS1/E1 circuit pack         | 4. Bandwidth controller                      |
| 2. Part of main distribution frame (MDF) | 5. Remote port module                        |
| 3. H600-307 cable                        | 6. Wideband endpoint (wire per manufacturer) |

Figure 66. Typical Signaling Wideband Configuration with Remote Port Module


1. For non-CSU installations, cross the transmit and receive lines so a transmit signal from the TN464F connects to the receive connection on the bandwidth controller and a transmit signal from the bandwidth controller connects to the receive connection on the TN464F.
2. For CSU installations, cross the transmit and receive lines between the CSU and the bandwidth controller.

## Multimedia Call Handling (MMCH)

MMCH provides a single point to point conference call using voice, video, and data from one endpoint to another. The customer must have endpoints and a personal computer with H.320 desktop video installed.

### Connect the Endpoints

Use the following procedure and [Figure 67](#) to connect the endpoints:



- |   |  |
|---|--|
| 1. DCP telephone, 2 or 4 wire to match type of circuit pack | 7. 25-pair cable to digital line circuit pack                    |
| 2. Personal computer  | 8. 25-pair cable to BRI circuit pack or NT1, 4-to-2 wire adapter |
| 3. BRI adapter  | 9. DEFINITY ECS  |
| 4. D8W cord   | 10. Multimedia-interface circuit pack                            |
| 5. 103A or modular wall jack                                | 11. Voice conditioner circuit pack                               |
| 6. Main distribution frame                                  |  |

Figure 67. Typical Multimedia Call Handling Connections

1. Each PC MMCH endpoint must contain a BRI adapter.
2. Connect a DCP telephone to a digital line circuit pack. The DCP telephone must be used in conjunction with the PC. Refer to the tables at the end of this chapter for the pinout of the digital line circuit pack.
3. Connect the PC BRI adapter to any BRI port on the DEFINITY System. Refer to the tables at the end of this chapter for the pinout of an ISDN BRI circuit pack.

## Administer the System

1. Call INADS and notify the representative that the Multimedia Call Handling (MMCH)? field on page 2 of the customer-options form must be changed to **y**.
2. Logoff the terminal and then log back on the terminal to see your changes

## Administer the Endpoints

1. Log in and enter **add data-next** <or a valid extension number>.
2. The data module form appears. On page 1 of the form, enter the Data Extension: **xxxx**, Type: **7500**, the Name: user's name (such as ProShare), and enter **y** in Multimedia? field.
3. On page 2 of the form, enter **n** in the XID? field, and enter **n** in the MIM Support? field and press Enter.

## Administer One Number Complex

1. Identify the voice telephone (DCP set) to associate with the data endpoint. The station record for this voice station must be changed.
2. Type **change station station number** and press Enter.
3. On screen 1, type the data extension number in the MM Complex Data Ext: field.
4. On screen 2, type **y** in the H.320 Conversion? field and press Enter.
5. Type **y** in the Multimedia Early Answer field and press Enter.

## Setup and Test the MMCH Installation

This section provides general setup and testing procedures for the PictureTel, ProShare, Vistium, and Zydacron multimedia endpoints. Use the documentation that accompanies the endpoint equipment for more details.

## Configuring the PictureTel PCS50 (Live 50) and PCS100

**Table 27. Minimum System Requirements**

<b>Version:</b>	Live 50 version 1.7 or higher
<b>Minimum Processor Speed:</b>	487/33 MHz, DX2/77
<b>Disk Space:</b>	20 MB
<b>Memory:</b>	8 MB RAM, 17 MB recommended
<b>ISA Expansion Slots (17-bit):</b>	2 slots
<b>Monitor:</b>	VGA, SVGA
<b>Operating System:</b>	Windows™ 3.1x or Windows™ 95

These endpoints do not need any special configuration settings. The standard PictureTel configuration for a DEFINITY ECS is as follows.

1. Load the LiveShare Plus software first.
2. Enter the user name and company name. Use default values for subsequent prompts.
3. Enter a site name.
4. Select Restart Windows and FINISH.
5. Load the Live 50 VAFC drivers.
6. Load the Picture Tel Live 50 software.
7. Open the *PictureTel Live* program group from the Windows™ Program Manager screen.
8. Double click on the **PictureTel Live Configure** icon.
9. At the **Welcome** screen, click on **continue**.
10. Go to the **registration confirmation** screen and click on **continue**.
11. Enter the **Network Interface Settings**. Be sure that "ISDN" has an "x" in the box. Click on **continue**.
12. At the **ISDN Parameters** screen, set the signaling protocol to **USA Canada: 5ESS Custom Point-to-Point**. Click on **continue**.
13. At the **Hardware Settings** screen, set the following: Interrupt (IRQ) to 11, Base I/O Port=280, and Base Memory=D000. Under the Video Input section, select the NTSC circle. Click on **continue**.
14. At the Audio Device screen, enter the necessary information.
15. At the **Node Name** screen, enter a name for the PC using the application software package.

16. At the **Modify config.sys** screen, click the **SAVE** button.
17. The remainder of the software loads automatically.
18. When the load is finished, reboot the PC.
19. Open the *PictureTel Live* program group from the Windows™ Program Manager screen.
20. Double click on the **PictureTel Live** icon. The program takes about 1 minute to open.

## How to Place a PictureTel Video Call

1. Turn on the video camera. Be sure the green LED is on.

### NOTE:

A problem may be encountered when trying to open the PictureTel application software. If the application seems to freeze during initialization (no response for several minutes) then there may be a conflict with the interrupt (IRQ) port setting. Check the PictureTel configuration to make sure that the IRQ port is set to 11. If initialization is still a problem, contact a PictureTel representative.

2. Open the PictureTel application program.
3. Two windows should appear: one local video and one remote video.
4. Go to the remote video window (the one without the local video image inside it).
5. Click on the **blue phone** icon at the top left of the window.
6. A **DIAL PAD** window opens. Use the keyboard, or mouse and dial pad, to enter the *DATA* extension of another multimedia endpoint. If you are dialing another PictureTel, you can place a 1B (one 74 Kb channel) call by only filling in the first telephone extension box on the **DIAL PAD** window. To make a 2B (two 74 Kb channels) call, you must put the same called party extension in the second telephone extension box on the **DIAL PAD** window.
7. To initiate a call, click on the **VIDEO CALL** button on the top right of the **DIAL PAD** window.
8. The dial pad disappears and you see a status window that shows “ringing.”
9. When the connection is made, the status window disappears and you can see the connection status on the bottom bar of the remote video window.

## Troubleshooting the PictureTel

**Symptom:** A conference call between a PictureTel and a ProShare has problems with the video connection or with video switching.

**Solution:** Be sure the PictureTel is version 1.7 or higher and the ProShare is version 2.0 or higher.

## ProShare Configuration

Table 28. Minimum System Requirements

<b>Version:</b>	2.0 or higher
<b>Minimum Processor Speed:</b>	487/33 MHz, DX2/77
<b>Disk Space:</b>	7 MB
<b>Memory:</b>	12 MB RAM, 17 MB recommended
<b>ISA Expansion Slots (17-bit):</b>	2 slots
<b>Monitor:</b>	740x480, 257-color, VGA, SVGA
<b>Operating System:</b>	Windows™ 3.1x or Windows™ 95

The ProShare system must be set up so that it does not look for a Service Profile Identifier (SPID) when connecting to the DEFINITY ECS. This is important because you administer the ProShare as a single 7500 data set and the telephone extension associated with that data set applies to both BRI channels.

1. Load the ProShare software onto the PC using the default values.
2. Enter the company name and serial number of the software.
3. Select the default directory location and install all files.
4. Answer NO to modem Setup.
5. Scroll through the list of countries and select the country in which the PC is installed.
6. At the **Protocol and Switch Mfg** window, click on **Custom**. Click on **AT&T** and click on **Accept**.
7. At the next window, choose **PBX** for Exchange Switch, and choose **G3r** (for Release 8r) or **G3i** (for Release 8si) (as appropriate) as the PBX type. Click on **Accept**.
8. Select yes or no for Phone Call Support.
9. A window with **#Phone Numbers** and **#SPIDS** appears. Set **#Phone Numbers** to **1** and set **#SPIDS** to **0**.
10. Click on the **Aliases** button and enter the last 5 digits of the data extension number and an external alias.
11. Leave the telephone number at default and click on **Accept**.
12. Select **restart windows**.

## How to Place a ProShare Video Call

1. Boot the ProShare computer.
2. Open the camera lens. Be sure the green LED is on.
3. Open **ProShare Personal Conferencing** program group from the Windows™ Program Manager screen.
4. Double click on the **ProShare Conferencing** icon.
5. If this is a first time install, click on OK for the camera test. This test can take several minutes to complete.
6. After the tutorial runs (if desired) and the product is registered, the ProShare application opens with 2 video windows.
7. Click on the Call button. A telephone dial pad appears. Use the dial pad to enter the telephone number of the desired extension to place a test call to. The ProShare only makes 2 B calls. The telephone number entered is used to place both calls. To place a 2B (two 74 kB channels) call to 2 different telephone extensions, separate them with a colon ":". To place a 57 kB call instead of a 74 kB call, enter a pound "#" sign to the end of the called party extension.
8. To initiate the call, click on the **DIAL** button on the handset window. The dialing status displays where the extension was entered. When the connection is made, remote video appears.

## Troubleshooting the ProShare

**Symptom:** Any attempt to place a data call to the complex's voice station is denied by the ProShare.

**Solution:** When configuring the ProShare, you entered the voice extension of the complex. You need to enter the data extension (Step G, below). To do this:

- a. Go to the ProShare directory and run the Diagnostics and Utilities program.
- b. Double click on the **Hardware and ISDN Configuration** utility.
- c. Choose **ISDN Line Configuration**.
- d. Set **Protocol = custom** and **Manufacturer = AT&T (5ESS)**. Click on the **Accept** button.
- e. Set **Switch = PBX**, **PBX Type = G3r** or **G3i** (for G3si). Click on the **Accept** button.
- f. Set **Phone Call Support = No** and click on the **Accept** button.
- g. Set **#Phone Numbers = 1**, **#SPIDs = 0**, and **Phone Number** to the data endpoint extension. Click on the **Accept** button.

**Symptom:** Cannot accept a multimedia telephone call from off-premises to the single number.

**Solution:** Under "Aliasing," enter the data extension number. To do this:

- a. Go to the ProShare directory and run the Diagnostics and Utilities program.
- b. Double click on the **Hardware and ISDN Configuration** utility.
- c. Choose **ISDN Line Configuration**.
- d. Set **Protocol = custom** and **Manufacturer = AT&T (5ESS)**. Click on the **Accept** button.
- e. Set **Switch = PBX**, **PBX Type = G3r** or **G3i** (for G3si). Click on the **Accept** button.
- f. Set **Phone Call Support = No** and click on the **Accept** button.
- g. Set **#Phone Numbers = 1**, **#SPIDs = 0**, and **Phone Number** to the data endpoint extension.
- h. Click on the **Aliasing** button.
- i. In the **Alias** box, enter the data extension number, choose **External**, click the **Add** button, click the **OK** button, and click the **Accept** button.

**Symptom:** Get a short break in audio path during first few seconds of a call. This is most noticeable when covering to AUDIX/Voice mail.

**Solution:** ProShare mutes the audio path when it does a "capabilities exchange" in H.320. This problem is being addressed in later versions of the ProShare software. Contact your Avaya representative for more information.

## Vistium Configuration

Table 29. Minimum System Requirements

<b>Version:</b>	1.03.10 or higher
<b>Minimum Processor Speed:</b>	487/33 MHz, DX2/77
<b>Disk Space:</b>	10 MB
<b>Memory:</b>	8 MB RAM, 17 MB recommended
<b>ISA Expansion Slots (17-bit):</b>	1 slot
<b>Monitor:</b>	VGA, SVGA
<b>Operating System:</b>	Windows™ 3.1x or Windows™ 95

## Zydacron Configuration

Table 30. Minimum System Requirements

<b>Version:</b>	Z250 v. 1.0 or ZydApp2 v. 1.3
<b>Minimum Processor Speed:</b>	487/33 MHz, DX2/77
<b>Disk Space:</b>	5 MB
<b>Memory:</b>	4 MB RAM, 8 MB recommended
<b>ISA Expansion Slots (17-bit):</b>	1 slot
<b>Monitor:</b>	VGA, SVGA
<b>Operating System:</b>	Windows™ 3.1x or Windows™ 95

These endpoints do not need any special configuration settings. The standard configuration for a DEFINITY ECS is as follows. Use the documentation that accompanies the Zydacron equipment for more details.

1. Open Windows and load the software application.
2. Select Full Installation.
3. Click on OK for the default location of the application directory (c:\ZYDAPP2).
4. Select Yes to reset the video drivers (if desired).
5. View or close the READZA2.txt file as desired.
6. When the Collaboration Software dialog box opens, select Yes if another vendor's video conferencing application is being loaded. Select No if only Zydacron software is being loaded.
7. The software continues to load automatically. When finished, the application icons appear in the program group.

## How to Place a Zydacron Video Call

1. Turn on the video camera. Be sure the green LED is on.
2. Double click on the **Zydacron** icon to start the program. The program may take about 30 seconds to open.
3. Two local video windows should appear.
4. Click the Dial icon from the Main toolbar.
5. Use the keypad or the computer keyboard to enter the telephone number of the test endpoint or telephone.
6. To initiate the call, click on the **CALL** button. The Incoming Call screen appears on the test endpoint (or the test telephone rings).

7. Select ANSWER on the test endpoint or pick up the test telephone handset.
8. Remote video appears on the local screen and a talk path is opened on the headset. For a test telephone, a talk path is opened.

## Troubleshooting the Zydacron

**Symptom:** After each PC reboot, the first time you bring up the Zydacron application and receive a telephone call, if you do not answer the data call, the answer screen stays frozen in the window.

**Solution:** Restart the Zydacron application. Press the Ctrl, Alt, and Del keys at the same time. This brings up a window that allows you to select a task. Select the **Zydacron** application and click on the **end task** button.

**Symptom:** Cannot make an outgoing call. Get a Message Interrupt.

**Solution:** The interrupt (IRQ) setting is incorrect. Contact your Zydacron representative for the recommended IRQ settings.

## Place Conversion Test Call

---



**NOTE:**


The H.320 Conversion?: field must be set to **y** on page 2 of the Station Form.

Place a conversion test call to an endpoint with a known video capability (for example: call your voice station from your PC).

## Expansion Services Module

---

The Expansion Services Module (ESM) provides T.120 data sharing capability on a MMCH multipoint H.320 video conference. Each person in the conference must have endpoints and a personal computer with the H.320 video application installed. The DEFINITY ECS must have the expansion service module installed.



1. Port B Y-cable connector to a TN787 multimedia interface (MMI) circuit pack
2. Port A Y-cable connector to a TN2207 PRI circuit pack
3. 25-pair Y-cable
4. 357A adapter
5. D8W cord connected to 357A adapter S/B port 8
6. Expansion service module (ESM)
7. Port B on compatible primary rate interface (PRI) card

Figure 68. Typical Multimedia Call handling ESM Connections

## ESM Installation

Use the following procedure and [Figure 68](#) to connect to the ESM equipment:

1. Install the TN2207 primary rate interface (PRI) circuit pack and the TN787F/G/H/J/K multimedia interface (MMI) circuit pack in the DEFINITY System port carrier.
2. Record the circuit pack locations.
3. Connect the ESM Y-cable as shown.

## Administer the DEFINITY ECS

1. Enter **list configuration all**, and a list of the installed carriers, circuit packs, and ports appears.
2. Record the location (board number) of the new circuit packs and verify that all other required circuit packs (refer to [“ESM Installation”](#)) are present.
3. Enter **add DS1 xxxxx**, (where xxxxx is the location of the TN2207 PRI circuit pack recorded in step 2), and the DS1 circuit pack administration form appears.
4. Set the **Name:** field to **ESM DS1**
5. Set the **Bit Rate:** field to **2.048**
6. Set the **Line Coding:** field to **hdb3**
7. Set the **Signaling Mode:** field to **isdn-pri**

8. Set the `Connect :` field to **pbx**
9. Set the `Interface :` field to **network**
10. Set the `Country Protocol :` field to **1**
11. Set the `Protocol Version :` field to **a**
12. Set the `CRC? :` field to **y**
13. The `Idle Code` default is 11111111.
14. The `DCP/Analog Bearer Capability` default is 3.1 kHz.
15. Set the `MMI Cabling Board :` field to **xxxxx** (where xxxxx is the location of the TN787F/H/J/K MMI circuit pack recorded in step 2). This must be the slot for port B of the Y-cable.
16. The `MMI Interface :` field **ESM** appears.
17. Enter **add signaling-group next** and the signaling-group form appears.
18. Change `Associated Signaling :` field to **y**.
19. Change `Primary D-Channel Port :` field to **xxxx17** (where xxxx is the address of the TN2207 PRI circuit pack, for example: 1B0517).
20. The `Max Number of NCA TSC :` default is 0.
21. The `Max Number of GA TSC :` default is 0.
22. `Trunk Group for NCA TSC :` \_\_\_\_ (leave blank)
23. `Trunk Group for Channel Selection :` \_\_\_\_ (leave blank)
24. Logoff the terminal and then log back on the terminal to view your changes.

## Place Test Call

Place multimedia data-conference call to an endpoint with known video capability to test the esm function.

## Troubleshooting

---

To determine ESM link status enter the following commands from the system administration terminal:

1. **Status esm**
2. **Status signaling-group**
3. **List MMI**



### NOTE:

When you move ESM circuit packs, you **MUST** remove the DS1 and signaling group translations. You cannot use the **change circuit pack** command.

Refer to [“Setup and Test the MMCH Installation”](#) on page 18-200 for further information.

## Property Management System

# 19


---

This chapter provides information on connecting the property management system and a terminal, journal printer, or both.

### **Connecting the Property Management System**

---

A data module and an asynchronous data unit form the interface between the DEFINITY and the property management system (PMS). See [Figure 69](#) and [Chapter 4, "Data Modules and Asynchronous Data Units"](#), for connection and configuration information.



0002\_1 RBP 062596

- |                                       |                                      |
|---------------------------------------|--------------------------------------|
| 1. Z3A1 or Z3A2 ADU                   | 10. TXR                              |
| 2. 4-pair line cord                   | 11. PXT                              |
| 3. 103A or modular wall jack          | 12. PXR                              |
| 4. Analog telephone                   | 13. Tip                              |
| 5. Satellite site or adapter location | 14. Ring                             |
| 6. Station side blue or white field   | 15. To analog line circuit pack      |
| 7. System side                        | 16. To data line circuit pack        |
| 8. Data module                        | 17. 25-pin RS-232-D connector (male) |
| 9. TXT                                | 18. Main distribution frame          |

Figure 69. Connections to Asynchronous Data Unit

## Connecting a Terminal and/or Journal Printer

---

You can connect customer data terminals, host computers, and/or an optional journal printer in either of two ways.

### Using Data Modules

---

1. Configure printer or terminal in accordance with the recommendations in the vendor's documentation.
2. Configure the data module for the printer or terminal, using the instructions in [Chapter 4, "Data Modules and Asynchronous Data Units"](#).
3. Identify the port associated with the data unit or data module using the Data Module Form (see ["Administer the DEFINITY ECS for Data Modules" on page 4-73](#)).
4. Establish a physical connection from the data port on the circuit pack, through the MDF, to the wall jack where the data unit is installed.
5. Connect the data modules to the equipment.

### Using an Asynchronous Data Unit (ADU) and a Data Line Circuit Pack

---

You connect an asynchronous data terminal through an ADU to a data line circuit pack. Normally, the connected data terminal powers the data unit. The data unit can also be remotely or locally powered using a 2012D transformer with a 248B adapter. Data units connected to receive-only printers require external power.

1. Configure printer or terminal in accordance with the recommendations in the vendor's documentation.
2. Identify the port associated with the data unit or data module using the Data Module Form (see ["Administer the DEFINITY ECS for Data Modules" on page 4-73](#)).
3. Establish a physical connection from the data port on the circuit pack, through the MDF, to the wall jack where the data unit is installed.
4. Connect the information outlet to the ADU.
5. Connect the RS-232 plug on the ADU or data module to the data terminal.
6. Connect the printer to the ADU via a modem or data module, using the instructions in [Chapter 4, "Data Modules and Asynchronous Data Units"](#), and [Chapter 5, "External Modems"](#).

## Connecting PMS and printers over TCP/IP

---

Property management systems (PMS) and printers can be connected to the switch using asynchronous TCP/IP links. This section provides information on connecting these adjuncts to the C-LAN and performing the initial administration.

### Task list

---

Whether you use an end-to-end TCP/IP configuration, a terminal server or a PC running RSP, you must complete the following tasks:

- [“Administering IP node names” on page 8-126](#)
- [“Administering IP services” on page 8-127](#)
- [“Administering adjunct parameters” on page 19-214](#)
- If you are using a terminal server, also complete [“Installing and administering the terminal server” on page 8-116](#)
- If you are using a PC with the Downloadable RSP Tool, complete [“Using the Downloadable Reliable Session-Layer Protocol Tool” on page 19-215](#)

### Administering adjunct parameters

---

You must administer adjunct parameters to let the system know that the adjunct is connected via TCP/IP.

#### PMS, PMS journal and PMS log printers

1. Type **change system-parameters hospitality** and press RETURN.  
The Hospitality screen appears.
2. On this screen, you can administer the PMS Log Endpoint (PMS\_LOG), the PMS Journal Endpoint (PMS\_JOURNAL), the PMS Endpoint (PMS), for whichever of these is connected via TCP/IP.
3. In the PMS Log Endpoint field, type **CDR1**. If you use a secondary output device, and that device is also connected via TCP/IP, type **CDR2** in the Secondary Output Endpoint field.
4. Press ENTER to save your changes.

#### System Printer

1. Type **change system-parameters features** and press RETURN.  
The Feature-Related System Parameters screen appears.
2. Move to Page 4.

3. In the System Printer Endpoint field, type **SYS\_PRNT**.
4. Press ENTER to save your changes.

## Testing the switch-to-adjunct link

You can use the test, status, busyout and release commands for to find and correct problems with system printer, PMS log, PMS journal and PMS links. For more information about these commands, see the Maintenance manual for your switch.

If a link does not come up immediately, try using the busyout (pms-link, journal-link pms-log and wakeup-log) and release (pms-link, journal-link pms-log and wakeup-log) commands.

## Using the Downloadable Reliable Session-Layer Protocol Tool

---

The intent of the Reliable Session-Layer Protocol (RSP) is to guarantee delivery of data records from the switch to an output device that connects to the switch over an asynchronous TCP/IP link. The Downloadable RSP tool allows you to implement this protocol on a PC that collects data records in a file. The protocol assures that the data records arrive safely at the PC. You can then send the output file to a printer.

## Setting up an RSP configuration

To set up an RSP configuration:

- Administer the PC as a client application on the switch.
- Download, install, and administer the RSP for the PC

## Setting up the switch

To set up the server application on the switch:

- [“Administering IP node names” on page 8-126](#)

Give the PC a node name. The IP address is the IP address of the PC that is running the RSP tool.

- [“Administering IP services” on page 8-127](#)

The service type = SYS\_PRNT, the Remote Node = the node name assigned to the PC. Remote port is the port assigned as the listen port on the PC. You can figure out what this is by starting the RSP Server application, clicking on Start, and checking in the output window to see what port the server is listening on.

## Setting up the PC

To set up the client application on the PC:

- Download RSP
- Install RSP
- Administer RSP

### Downloading RSP

The RSP is available from the Avaya support web site as a self-extracting executable. To download the RSP:

1. Browse to the Avaya Customer Support web site:  
<http://support.avaya.com/sd.jhtml>
2. Select the RSP tool from the web site.
3. When queried, save the setup.exe file to a temporary folder on your computer. It is approximately 1.4-MB.

### Installing RSP

To install the RSP:

1. Double-click the setup.exe file.  
The Install Shield Wizard steps you through the installation.
2. When prompted to select Client or Server, select both programs.
3. Continue with the installation. Use the default destination folder and program folder.
4. You can view the readme file now or later. The following files are installed on the PC in the folder \\Program Files\\Avaya\\DEFINITY Data Transport Tool:
  - client.exe (the client tool)
  - server.exe (the server tool)
  - user guide.doc (same as the readme file)
  - spl\_design\_doc.doc (the RSP design document)
  - splserver.ini
  - ddt\_log.txt (installation log file)
  - spl.dll

### Administering RSP

See the instructions in the user guide.doc file to administer the Reliable Session-layer Protocol on a PC.

## Connector and Cable Pinout Charts




Table 31. Lead and Color Designations

Cross-Connect Pin	Color	Amphenol Pin	Backplane Pin
1	W-BL	27	102
2	BL-W	01	002
3	W-O	27	103
4	O-W	02	003
5	W-G	28	104
7	G-W	03	004
7	W-BR	29	105
8	BR-W	04	005
9	W-SL	30	107
10	SL-W	05	007
11	R-BL	31	107
12	BL-R	07	007
13	R-O	32	108
14	O-R	07	008
15	R-G	33	109
17	G-R	08	009

*Continued on next page*

Table 31. Lead and Color Designations — *Continued*

Cross-Connect Pin	Color	Amphenol Pin	Backplane Pin
17	R-BR	34	110
18	BR-R	09	010
19	R-SL	35	111
20	SL-R	10	011
21	BK-BL	37	112
22	BL-BK	11	012
23	BK-O	37	113
24	O-BK	12	013
25	BK-G	38	302
27	G-BK	13	202
27	BK-BR	39	303
28	BR-BK	14	203
29	BK-SL	40	304
30	SL-BK	15	204
31	Y-BL	41	305
32	BL-Y	17	205
33	Y-O	42	307
34	O-Y	17	207
35	Y-G	43	307
37	G-Y	18	207
37	Y-BR	44	308
38	BR-Y	19	208
39	Y-SL	45	309
40	SL-Y	20	209
41	V-BL	47	310
42	BL-V	21	210
43	V-O	47	311
44	O-V	22	211

*Continued on next page*

Table 31. Lead and Color Designations — *Continued*

Cross-Connect Pin	Color	Amphenol Pin	Backplane Pin
45	V-G	48	312
47	G-V	23	212
47	V-BR	49	313
48	BR-V	24	213
49	V-SL	50	300
50	SL-V	25	200

Table 32. DS1 Interface cable H600-348

50-Pin			15-Pin		
Pin	Color	Designation	Pin	Color	Designation
			<b>Plug 04</b>		
38	W-BL	LI (High)	11	W-BL	LI (High)
13	BL-W	LI	03	BL-W	LI
39	W-O	LO	09	W-O	LO
14	O-W	LO (High)	01	O-W	LO (High)
			<b>Plug 03</b>		
41	W-G	LI (High)	11	W-G	LI (High)
17	G-W	LI	03	G-W	LI
42	W-BR	LO	09	W-BR	LO
17	BR-W	LO (High)	01	BR-W	LO (High)
			<b>Plug 02</b>		
44	W-SL	LI (High)	11	W-SL	LI (High)
19	SL-W	LI	03	SL-W	LI
45	R-BL	LO	09	R-BL	LO
20	BL-R	LO (High)	01	BL-R	LO (High)

*Continued on next page*

Table 32. DS1 Interface cable H600-348 — *Continued*

50-Pin			15-Pin		
Pin	Color	Designation	Pin	Color	Designation
			<b>Plug 01</b>		
47	R-O	LI (High)	11	R-O	LI (High)
22	O-R	LI	03	O-R	LI
48	R-G	LO	09	R-G	LO
23	G-R	LO (High)	01	G-R	LO (High)

Table 33. DS1 Interface Cable H600-307

50-Pin			15-Pin		
Pin	Color	Designation	Pin	Color	Designation
02	W-BL				
03	BL-W				
47	W-G	LI (High)	11	W-G	LI (High)
22	G-W	LI	03	G-W	LI
48	W-BR	LO	09	W-BR	LO
23	BR-W	LO (High)	01	BR	LO (High)
49	W-SL	LOOP2	07	W-SL	LOOP2
24	SL-W	LOOP1	05	SL-W	LOOP1

All other pins empty.

Table 34. TN2185B ISDN-BRI — 4-Wire S Interface Pinout

Port	Signal	Cross-Connect Pin	Color	Ampheno l Pin	Backplane Pin
1	TXT.1	1	W-BL	27	102
	TXR.1	2	BL-W	01	002
	PXT.1	3	W-O	27	103
	PXR.1	4	O-W	02	003
2	TXT.2	5	W-G	28	104
	TXR.2	7	G-W	03	004
	PXT.2	7	W-BR	29	105
	PXR.2	8	BR-W	04	005
3	TXT.3	9	W-SL	30	107
	TXR.3	10	SL-W	05	007
	PXT.3	11	R-BL	31	107
	PXR.3	12	BL-R	07	007
4	TXT.4	13	R-O	32	108
	TXR.4	14	O-R	07	008
	PXT.4	15	R-G	33	109
	PXR.4	17	G-R	08	009
5	TXT.5	17	R-BR	34	110
	TXR.5	18	BR-R	09	010
	PXT.5	19	R-SL	35	111
	PXR.5	20	SL-R	10	011
7	TXT.7	21	BK-BL	37	112
	TXR.7	22	BL-BK	11	012
	PXT.7	23	BK-O	37	113
	PXR.7	24	O-BK	12	013
7	TXT.7	25	BK-G	38	302
	TXR.7	27	G-BK	13	202
	PXT.7	27	BK-BR	39	303

Continued on next page

Table 34. TN2185B ISDN-BRI — 4-Wire S Interface Pinout — *Continued*

Port	Signal	Cross-Connect Pin	Color	Amphenol Pin	Backplane Pin
	PXR.7	28	BR-BK	14	203
8	TXT.8	29	BK-SL	40	304
	TXR.8	30	SL-BK	15	204
	PXT.8	31	Y-BL	41	305
	PXR.8	32	BL-Y	17	205

Table 35. DCP Extender 25-Pair Cable Pinout

Cross-Connect Pin	Wire Color	Amphenol Pin	Backplane Pin
1	W-BL	27	102
2	BL-W	01	002
3	W-O	27	103
4	O-W	02	003
5	W-G	28	104
7	G-W	03	004
7	W-BR	29	105
8	BR-W	04	005
9	W-SL	30	107
10	SL-W	05	007
11	R-BL	31	107
12	BL-R	07	007
13	R-O	32	108
14	O-R	07	008
15	R-G	33	109
17	G-R	08	009
17	R-BR	34	110
18	BR-R	09	010

*Continued on next page*

Table 35. DCP Extender 25-Pair Cable Pinout — *Continued*

Cross-Connect Pin	Wire Color	Amphenol Pin	Backplane Pin
19	R-SL	35	111
20	SL-R	10	011
21	BK-BL	37	112
22	BL-BK	11	012
23	BK-O	37	113
24	O-BK	12	013
25	BK-G	38	302
27	G-BK	13	202
27	BK-BR	39	303
28	BR-BK	14	203
29	BK-SL	40	304
30	SL-BK	15	204
31	Y-BL	41	305
32	BL-Y	17	205
33	Y-O	42	307
34	O-Y	17	207
35	Y-G	43	307
37	G-Y	18	207
37	Y-BR	44	308
38	BR-Y	19	208
39	Y-SL	45	309
40	SL-Y	20	209
41	V-BL	47	310
42	BL-V	21	210
43	V-O	47	311
44	O-V	22	211
45	V-G	48	312
47	G-V	23	212
47	V-BR	49	313

*Continued on next page*

Table 35. DCP Extender 25-Pair Cable Pinout — *Continued*

Cross-Connect Pin	Wire Color	Amphenol Pin	Backplane Pin
48	BR-V	24	213
49	V-SL	50	300
50	SL-V	25	200

**Table 36. Cross-connect pinouts**

Cross-Connect Pin	TN746B TN747B TN753/B TN769	TN754B/C TN727	TN760D/E	TN792	TN763B/C/D	TN735	TN794 TN464C/D/E	TN747B TN2183	TN2224B
1	T.1		T.1	T.1	T.1	T.1	C_5V	T.1	T.1
2	R.1		R.1	R.1	R.1	R.1		R.1	R.1
3		TXT.1	T1.1	TXT.1	SZ.1	BT.1	C_ENAB	T.2	T.2
4		TXR.1	R1.1	TXR.1	SZ1.1	BR.1		R.2	R.2
5		PXT.1	E.1	PXT.1	S.1	LT.1	C_SYNC*	T.3	T.3
7		PXR.1	M.1	PXR.1	S1.1	LR.1		R.3	R.3
7	T.2		T.2	T.2	T.2	T.2	C2D-DATA	T.4	T.4
8	R.2		R.2	R.2	R.2	R.2	RDATA*	R.4	R.4
9		TXT.2	T1.2	TXT.2	SZ.2	BT.2	TDATA*		T.5
10		TXR.2	R1.2	TXR.2	SZ1.2	BR.2	TRSYNC*		R.5
11		PXT.2	E.2	PXT.2	S.2	LT.2	GRD		T.7
12		PXR.2	M.2	PXR.2	S1.2	LR.2	SCLK*		R.7
13	T.3		T.3	T.3	T.3	T.3			T.7
14	R.3		R.3	R.3	R.3	R.3			R.7
15		TXT.3	T1.3	TXT.3	SZ.3	BT.3			T.8
17		TXR.3	R1.3	TXR.3	SZ1.3	BR.3	PAHER*		R.8
17		PXT.3	E.3	PXT.3	S.3	LT.3		T.5	T.9
18		PXR.3	M.3	PXR.3	S1.3	LR.3	C_48V	R.5	R.9

*Continued on next page*

**Table 36. Cross-connect pinouts — Continued**

Cross-Connect Pin	TN746B TN747B TN753/B TN769	TN754B/C TN727	TN760D/E	TN792	TN763B/C/D	TN735	TN794 TN464C/D/E	TN747B TN2183	TN2224B
19	T.4		T.4	T.4	T.4	T.4		T.7	T.10
20	R.4		R.4	R.4	R.4	R.4		R.7	R.10
21		TXT.4	T1.4	TXT.4	SZ.4	BT.4	C_P2SCLK	T.7	T.11
22		TXR.4	R1.4	TXR.4	SZ1.4	BR.4	LI (RX)	R.7	R.11
23		PXT.4	E.4	PXT.4	S.4	LT.4	LO* (TX)	T.8	T.12
24		PXR.4	M.4	PX4.4	S1.4	LR.4	LBACK1	R.8	R.12
25	T.5		T.5	T.5	T.5	T.5	GND	T.9	T.13
27	R.5		R.5	R.5	R.5	R.5	C_5V	R.9	R.13
27		TXT.5	T1.5	TXT.5	SZ.5	BT.5		T.10	T.14
28		TXR.5	R1.5	TXR.5	SZ1.5	BR.5		R.10	R.14
29		PXT.5	E.5	PXT.5	S.5	LT.5		T.11	T.15
30		PXR.5	M.5	PXR.5	S1.5	LR.5	C_RST	R.11	R.15
31	T.7		T.7	T.7	T.7	T.7		T.12	T.17
32	R.7		R.7	R.7	R.7	R.7		R.12	R.17
33		TXT.7	T1.7	TXT.7	SZ.7	BT.7	RDATA		T.17
34		TXR.7	R1.7	TXR.7	SZ1.7	BR.7	TDATA		R.17
35		PXT.7	E.7	PXT.7	S.7	LT.7	TRSYNC		T.18
37		PXR.7	M.7	PXR.7	S1.7	LR.7	GRD		R.18

*Continued on next page*

**Table 36. Cross-connect pinouts — Continued**

Cross-Connect Pin	TN746B TN747B TN753/B TN769	TN754B/C TN727	TN760D/E	TN792	TN763B/C/D	TN735	TN794 TN464C/D/E	TN747B TN2183	TN2224B
37	T.7		T.7	T.7	T.7	T.7	SCLK		T.19
38	R.7		R.7	R.7	R.7	R.7			R.19
39		TXT.7	T1.7	TXT.7	SZ.7	BT.7			T.20
40		TXR.7	R1.7	TXR.7	SZ1.7	BR.7			R.20
41		PXT.7	E.7	PXT.7	S.7	LT.7	GRD	T.13	T.21
42		PXR.7	M.7	PXR.7	S1.7	LR.7		R.13	R.21
43	T.8		T.8	T.8	T.8	T.8	C_PRES*	T.14	T.22
44	R.8		R.8	R.8	R.8	R.8		R.14	R.22
45		TXT.8	T1.8	TXT.8	SZ.8	BT.8		T.15	T.23
47		TXR.8	R1.8	TXR.8	SZ1.8	BR.8	DC2_DATA	R.15	R.23
47		PXT.8	E.8	PXT.8	S.8	LT.8	LI* (RX)	T.17	T.24
48		PXR.8	M.8	PXR.8	S1.8	LR.8	LO (TX)	R.17	R.24
49	GRD	GRD	GRD	GRD	GRD	GRD	LBACK2	GRD	GRD
50	GRD	GRD	GRD	GRD	GRD	GRD	GND	GRD	GRD



# Index

---

## Numerics

- 1145B power supply, [8](#)
  - 1146B power distribution unit, [11](#), [15](#)
  - 1148B battery, [11](#)
  - 1149B battery, [11](#)
  - 1151A and 1151A2 loop range, [16](#)
  - 1151A Power Supply, [16](#), [18](#)
  - 1151A2 Power Supply, [16](#), [18](#)
  - 120A ICSU, [131](#)
  - 2.5 amp-hour battery, [11](#)
  - 5 amp-hour battery, [11](#)
  - 572 printer, [91](#)
  - 888B converter, [146](#)
  - 909A
    - DC version, [2](#)
  - 909A/B Universal Coupler, [190](#)
  - 909B
    - AC version, [2](#)
- 

## A

- Asynchronous Links, [98](#), [214](#)
- 

## B

- back-up battery, [9](#)
  - battery back-up, [11](#)
  - battery back-up switch, [12](#)
  - Busy Tone Disconnect, [159](#)
- 

## C

- calling queue, [186](#)
- CDR, [161](#)
  - option settings, [161](#)
  - printer, [91](#)
- circuit packs
  - TN2181 Digital Line 2-Wire, [20](#)
  - TN2181 Digital Line 2-Wire DCP, [23](#)
  - TN2183 Analog Line, [186](#)
  - TN2224 Digital Line, [225](#)
  - TN2224 Digital Line 24-port 2-Wire DCP, [23](#)
  - TNCCSC-1 PRI to DASS Converter, [145](#),  
[148](#)
  - TNCCSC-2 PRI to DPNSS converter, [145](#),  
[148](#)
  - TNPRI/BRI Converter, [147](#), [149](#)

- coaxial converter, 888B, [146](#)
  - connecting
    - music-on-hold, FCC-registered, [186](#)
  - connections
    - music-on-hold, non-FCC-registered, [186](#)
  - connectors
    - data communications equipment, [161](#)
- 

## D

- data communications equipment connector, [161](#)
  - DS1 loopback, [129](#)
  - DS1 span, [129](#), [130](#)
  - DS1 span, T1, [129](#)
- 

## E

- EIA port, [161](#)
  - Electronic Industries Association, see EIA, [161](#)
  - Endpoints, [199](#)
  - ESPA radio paging, [191](#)
  - European Standard Paging Access, [191](#)
  - expanded power distribution unit, [12](#)
  - expanded power distribution unit spacer
    - bracket, [12](#)
  - ExpressRoute 1000 data module, [72](#)
  - external ringing, [186](#)
- 

## I

- IOLAN, [115](#)
  - IP Services, [127](#)
- 

## K

- KS-22911 power supply, [2](#)
  - KS-22911L2 power supply, [180](#)
  - KS-23395, to connect music-on-hold, [186](#)
- 

## L

- LAN Gateway, [103](#)
- loop range, 1151A and 1151A2, [16](#)
- loopback jack, [129](#)

---

## M

- MASI
  - Multimedia Application Server Interface, [193](#)
- MMCH
  - multimedia call handling, [199](#)
- MMCX
  - Multimedia Communications Exchange, [193](#)
  - multimedia call handling, [199](#)
- multimedia endpoint
  - PictureTel, [201](#)
  - ProShare, [203](#)
  - Vistium, [205](#)
  - Zydacron, [206](#)
- multimedia endpoints, [199](#)
- multi-mount DCP extender, [23](#)
- music-on-hold equipment
  - connecting non-FCC-registered, [186](#)

---

## N

- network interface, [131](#)
- Node Names, [126](#)

---

## P

- PictureTel endpoint, [201](#)
- PictureTel testcall, [202](#)
- PictureTel troubleshooting, [202](#)
- power supply
  - 1145B -48V, [8](#)
  - 1146B -48V, [8](#)
  - 1151A -48V, [18](#)
  - 1151A2 -48V, [18](#)
- printer
  - 572 option settings, [91](#)
- Printers, [98](#), [214](#)
- ProShare endpoint, [203](#)
- ProShare testcall, [204](#)
- ProShare troubleshooting, [204](#)

---

## Q

- queue calling, [186](#)
- queue warning indicator, [186](#)

---

## R

- rack mount DCP extender, [23](#)
- Reliable Session-layer Protocol, [165](#)

---

## S

- security issues, [xiii](#)
- switch settings
  - 572 printer, [91](#)
  - CDR, [161](#)
- Switch-to-Call Accounting Link
  - Testing, [99](#), [165](#), [215](#)
- system printer, [91](#)

---

## T

- T1 DS1 span, [129](#)
- T-cable, [12](#)
- TCP/IP connections, [98](#), [161](#), [214](#)
- Terminal Server, [115](#)
- testcall, PictureTel, [202](#)
- testcall, ProShare, [204](#)
- testcall, Zydacron, [206](#)
- Testing
  - Switch-to-Call Accounting Link, [99](#), [165](#), [215](#)
- TN2183 Analog Line circuit pack, [186](#)
- TN2224 Digital Line, [225](#)
- TNCCSC-1 PRI to DASS Converter, [145](#), [148](#)
- TNCCSC-2 PRI to DPNSS Converter, [145](#), [148](#)
- TNPRI/BRI converter, [147](#), [149](#)
- Translations
  - CDR Parameters, [98](#), [164](#), [214](#)
- troubleshooting PictureTel, [202](#)
- troubleshooting ProShare, [204](#)
- troubleshooting Zydacron, [207](#)
- type-approved external modem, [77](#)

---

## V

- Vistium endpoint, [205](#)

---

## W

Wideband endpoints  
  non-signaling, [196](#)  
  remote port module, [198](#)  
  signaling, [197](#)

---

## Z

Zydacron endpoint, [206](#)  
Zydacron testcall, [206](#)  
Zydacron troubleshooting, [207](#)



## We'd like your opinion.

Avaya welcomes your feedback on this document. Your comments can be of great value in helping us improve our documentation.

### DEFINITY® ECS Installation for Adjuncts and Peripherals, 555-233-116, Issue 2, December 2001

1. Please rate the effectiveness of this document in the following areas:

	Excellent	Good	Fair	Poor
Ease of Finding Information				
Clarity				
Completeness				
Accuracy				
Organization				
Appearance				
Examples				
Illustrations				
Overall Satisfaction				

2. Please check the ways you feel we could improve this document:

- |  |   |
|--|---|
| <input type="checkbox"/> Improve the overview/introduction | <input type="checkbox"/> Make it more concise                       |
| <input type="checkbox"/> Improve the table of contents     | <input type="checkbox"/> Add more step-by-step procedures/tutorials |
| <input type="checkbox"/> Improve the organization          | <input type="checkbox"/> Add more troubleshooting information       |
| <input type="checkbox"/> Add more figures                  | <input type="checkbox"/> Make it less technical                     |
| <input type="checkbox"/> Add more examples                 | <input type="checkbox"/> Add more/better quick reference aids       |
| <input type="checkbox"/> Add more detail                   | <input type="checkbox"/> Improve the index                          |

Please add details about your concern. \_\_\_\_\_

\_\_\_\_\_

3. What did you like most about this document? \_\_\_\_\_

\_\_\_\_\_

4. Feel free to write any comments below or on an attached sheet. \_\_\_\_\_

\_\_\_\_\_

If we may contact you concerning your comments, please complete the following:

Name: \_\_\_\_\_ Telephone Number: ( ) \_\_\_\_\_

Company/Organization \_\_\_\_\_ Date: \_\_\_\_\_

Address: \_\_\_\_\_

When you have completed this form, please fax to (303) 538-1741. Thank you.

