



Nortel Ethernet Routing Switch 8300

# Command Reference — NNCLI

Document status: Standard  
Document version: 03.01  
Document date: 27 August 2007

Copyright © 2007, Nortel Networks  
All Rights Reserved.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

The software described in this document is furnished under a license agreement and may be used only in accordance with the terms of that license. The software license agreement is included in this document.

## **Trademarks**

Nortel, Nortel Networks, the Nortel Networks logo, the Globemark, are trademarks of Nortel Networks.

Adobe and Acrobat Reader are trademarks of Adobe Systems Incorporated.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation.

The asterisk after a name denotes a trademarked item.

## **Restricted rights legend**

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

## **Statement of conditions**

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks reserves the right to make changes to the products described in this document without notice.

Nortel Networks does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product may be Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

## **Nortel Networks software license agreement**

This Software License Agreement ("License Agreement") is between you, the end-user ("Customer") and Nortel Networks Corporation and its subsidiaries and affiliates ("Nortel Networks"). PLEASE READ THE FOLLOWING CAREFULLY. YOU MUST ACCEPT THESE LICENSE TERMS IN ORDER TO DOWNLOAD AND/OR USE THE

SOFTWARE. USE OF THE SOFTWARE CONSTITUTES YOUR ACCEPTANCE OF THIS LICENSE AGREEMENT. If you do not accept these terms and conditions, return the Software, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

"Software" is owned or licensed by Nortel Networks, its parent or one of its subsidiaries or affiliates, and is copyrighted and licensed, not sold. Software consists of machine-readable instructions, its components, data, audio-visual content (such as images, text, recordings or pictures) and related licensed materials including all whole or partial copies. Nortel Networks grants you a license to use the Software only in the country where you acquired the Software. You obtain no rights other than those granted to you under this License Agreement. You are responsible for the selection of the Software and for the installation of, use of, and results obtained from the Software.

**1. Licensed Use of Software.** Nortel Networks grants Customer a nonexclusive license to use a copy of the Software on only one machine at any one time or to the extent of the activation or authorized usage level, whichever is applicable. To the extent Software is furnished for use with designated hardware or Customer furnished equipment ("CFE"), Customer is granted a nonexclusive license to use Software only on such hardware or CFE, as applicable. Software contains trade secrets and Customer agrees to treat Software as confidential information using the same care and discretion Customer uses with its own similar information that it does not wish to disclose, publish or disseminate. Customer will ensure that anyone who uses the Software does so only in compliance with the terms of this Agreement. Customer shall not a) use, copy, modify, transfer or distribute the Software except as expressly authorized; b) reverse assemble, reverse compile, reverse engineer or otherwise translate the Software; c) create derivative works or modifications unless expressly authorized; or d) sublicense, rent or lease the Software. Licensors of intellectual property to Nortel Networks are beneficiaries of this provision. Upon termination or breach of the license by Customer or in the event designated hardware or CFE is no longer in use, Customer will promptly return the Software to Nortel Networks or certify its destruction. Nortel Networks may audit by remote polling or other reasonable means to determine Customer's Software activation or usage levels. If suppliers of third party software included in Software require Nortel Networks to include additional or different terms, Customer agrees to abide by such terms provided by Nortel Networks with respect to such third party software.

**2. Warranty.** Except as may be otherwise expressly agreed to in writing between Nortel Networks and Customer, Software is provided "AS IS" without any warranties (conditions) of any kind. NORTEL NETWORKS DISCLAIMS ALL WARRANTIES (CONDITIONS) FOR THE SOFTWARE, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTY OF NON-INFRINGEMENT. Nortel Networks is not obligated to provide support of any kind for the Software. Some jurisdictions do not allow exclusion of implied warranties, and, in such event, the above exclusions may not apply.

**3. Limitation of Remedies.** IN NO EVENT SHALL NORTEL NETWORKS OR ITS AGENTS OR SUPPLIERS BE LIABLE FOR ANY OF THE FOLLOWING: a) DAMAGES BASED ON ANY THIRD PARTY CLAIM; b) LOSS OF, OR DAMAGE TO, CUSTOMER'S RECORDS, FILES OR DATA; OR c) DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), WHETHER IN CONTRACT, TORT OR OTHERWISE (INCLUDING NEGLIGENCE) ARISING OUT OF YOUR USE OF THE SOFTWARE, EVEN IF NORTEL NETWORKS, ITS AGENTS OR SUPPLIERS HAVE BEEN ADVISED OF THEIR POSSIBILITY. The foregoing limitations of remedies also apply to any developer and/or supplier of the Software. Such developer and/or supplier is an intended beneficiary of this Section. Some jurisdictions do not allow these limitations or exclusions and, in such event, they may not apply.

#### **4. General**

1. If Customer is the United States Government, the following paragraph shall apply: All Nortel Networks Software available under this License Agreement is commercial computer software and commercial computer software documentation and, in the event Software is licensed for or on behalf of the United States Government, the respective rights to the software and software documentation are governed by Nortel Networks standard commercial license in accordance with U.S. Federal Regulations at 48 C.F.R. Sections 12.212 (for non-DoD entities) and 48 C.F.R. 227.7202 (for DoD entities).
2. Customer may terminate the license at any time. Nortel Networks may terminate the license if Customer fails to comply with the terms and conditions of this license. In either event, upon termination, Customer must either return the Software to Nortel Networks or certify its destruction.
3. Customer is responsible for payment of any taxes, including personal property taxes, resulting from Customer's use of the Software. Customer agrees to comply with all applicable laws including all applicable export and import laws and regulations.
4. Neither party may bring an action, regardless of form, more than two years after the cause of the action arose.

5. The terms and conditions of this License Agreement form the complete and exclusive agreement between Customer and Nortel Networks.
6. This License Agreement is governed by the laws of the country in which Customer acquires the Software. If the Software is acquired in the United States, then this License Agreement is governed by the laws of the state of New York.

---

# Contents

---

<b>New in this release</b>	<b>35</b>
Features	35
Layer 2 IGMP snoop querier	35
Multicast Stream Limitation	36
Network Load Balancing Support	36
Protocol Independent Multicast-Sparse Mode	37
Simple Loop Protection Protocol	37
Static source groups	38
Other changes	38
IP Protocol commands	38
Multicast services commands	39
<b>Preface</b>	<b>41</b>
Before you begin	41
About the NNCLI	41
Text conventions	44
How to get help	46
Getting help from the Nortel web site	46
Getting help over the phone from a Nortel Solutions Center	46
Getting help from a specialist using an Express Routing Code	47
Getting help through a Nortel distributor or reseller	47
<b>Utility management commands</b>	<b>49</b>
attribute	50
boot	51
cd	51
chkdisk	51
clear	52
copy	53
cp	53
date	54
delete	54
dir	54
disable	55
edit	55

---

enable 55  
end 56  
exit 56  
format 56  
format-flash 56  
grep 57  
help 57  
history 57  
install 58  
logout 58  
mkdir 58  
monitor 58  
monitor-stats 59  
more 60  
mv 60  
pcmcia-stop 60  
peer 61  
ping 61  
pwd 62  
reload 62  
rename 63  
rlogin 63  
rlogin-sessions 63  
rsh 64  
save 64  
show running-config 65  
source 65  
sys-action 65  
telnet 66  
telnet-access 66  
test 67  
test 67  
trace 67  
trace auto-enable 68  
traceroute 70  
write memory 71

---

**Bootconfig commands**

**73**

boot choice license-file 76

Syntax 76

Parameters 76

bootconfig bootp 76

bootconfig choice config-file 77

bootconfig choice image-file 78

---

bootconfig cli more 78  
no bootconfig cli more 79  
bootconfig cli prompt 79  
bootconfig cli rlogin-sessions 79  
bootconfig cli screenlines 79  
bootconfig cli telnet-sessions 80  
bootconfig cli timeout 80  
bootconfig delay 80  
bootconfig flags 81  
no bootconfig flags 83  
bootconfig flags autoboot 85  
no bootconfig flags autoboot 85  
bootconfig flags block-snmp 85  
no bootconfig flags block-snmp 86  
bootconfig flags daylight-saving-time 86  
no bootconfig flags daylight-saving-time 86  
bootconfig flags debug-config 86  
no bootconfig flags debug-config 86  
bootconfig flags debugmode 87  
no bootconfig flags debugmode 87  
bootconfig flags factorydefaults 87  
no bootconfig flags factorydefaults 87  
bootconfig flags ftpd 88  
no bootconfig flags ftpd 88  
bootconfig flags info 88  
bootconfig flags logging 88  
no bootconfig flags logging 89  
bootconfig flags nncli 89  
no bootconfig flags nncli 89  
bootconfig flags reboot 89  
no bootconfig flags reboot 90  
bootconfig flags rlogind 90  
no bootconfig flags rlogind 90  
bootconfig flags savetostandby 90  
no bootconfig flags savetostandby 90  
bootconfig flags telnetd 91  
no bootconfig flags telnetd 91  
bootconfig flags tftpd 91  
no bootconfig flags tftpd 91  
bootconfig flags trace-logging 91  
no bootconfig flags trace-logging 92  
bootconfig flags verify-config 92  
no bootconfig flags verify-config 92

bootconfig flags watchdog 92  
no bootconfig flags watchdog 93  
bootconfig host ftp-debug 93  
no bootconfig host ftp-debug 93  
bootconfig host password 93  
bootconfig host tftp-debug 94  
no bootconfig host tftp-debug 94  
bootconfig host tftp-hash 94  
no bootconfig host tftp-hash 94  
bootconfig host tftp-rexmit 95  
bootconfig host tftp-timeout 95  
bootconfig host user 95  
bootconfig master 96  
bootconfig net autonegotiate 96  
no bootconfig net autonegotiate 96  
bootconfig net bootp 97  
no bootconfig net bootp 97  
bootconfig net fullduplex 97  
no bootconfig net fullduplex 98  
bootconfig net ip 98  
bootconfig net restart 99  
boot net route 100  
bootconfig net speed 100  
bootconfig net tftp 101  
bootconfig sio 102  
bootconfig sio 8databits 103  
no bootconfig sio 8databits 103  
bootconfig sio baud 103  
bootconfig sio disable 104  
bootconfig sio enable 104  
bootconfig sio info 104  
bootconfig sio mode 104  
bootconfig sio mtu 105  
bootconfig sio my-ip 105  
bootconfig sio peer-ip 106  
bootconfig sio pppfile 106  
bootconfig sio restart 107  
bootconfig sio slip-compression 107  
no bootconfig sio slip-compression 107  
bootconfig sio slip-rx-compression 108  
no bootconfig sio slip-rx-compression 108  
show bootconfig 108  
show bootconfig choice 109

show bootconfig cli 109  
show bootconfig config 109  
show bootconfig flags 110  
show bootconfig host 110  
show bootconfig info 110  
show bootconfig master 110  
show bootconfig net 110  
show bootconfig sio 111  
show bootconfig tz 111

---

**System management commands 113**

auto-recover-delay 114  
    Syntax 114  
    Command mode 115  
default auto-recover-delay 115  
    Syntax 115  
    Command mode 115  
no auto-recover-delay 115  
    Syntax 115  
    Command mode 115  
autotopology 115  
no autotopology 115  
banner 115  
no banner 116  
clock set 116  
clock-sync-time 117  
enable 117  
link-flap-detect 117  
    Syntax 117  
    Parameters 118  
    Command mode 118  
no link-flap-detect auto-port-down 118  
    Syntax 118  
    Command mode 118  
no link-flap-detect send-trap 118  
    Syntax 118  
    command mode 118  
load-module 118  
logging 119  
loginprompt 120  
no loginprompt 121  
mgmt-virtual-ip 121  
no mgmt-virtual-ip 121  
monitor-stats 122

---

more 122  
no more 122  
msg-control 123  
no msg-control 123  
mtu 123  
passwordprompt 123  
no passwordprompt 124  
portlock 124  
prompt 124  
rlogin-sessions 124  
screenlines 125  
show autotopology 125  
show basic config 125  
    Syntax 125  
    Command mode 125  
show interfaces GigabitEthernet interface 125  
    Syntax 125  
    Command mode 126  
show link-flap-detect 126  
show logging config 126  
show logging file 126  
show log filter 127  
show running-config 127  
show slot 127  
show sys hash-calc mltindex ip dest-mac dest-ip src-mac src-ip src-port mlt 128  
    Syntax 128  
    Parameters 128  
    Command mode 128  
show sys hash-calc mltindex non-ip dest-mac src-mac src-port mlt 128  
    Syntax 128  
    Parameters 129  
    Command mode 129  
show sys hash-calc mltindex ip-mcast source group vlan-id src-port mlt 129  
    Syntax 129  
    Parameters 129  
    Command mode 130  
show sys hash-calc mltindex non-ip-mcast dest-mac vlan-id src-port mlt 130  
    Syntax 130  
    Parameters 130  
    Command mode 131  
show sys-info 131  
show sys perf 131  
show sys sw 132

---

shutdown 132  
no shutdown 132  
sys-action cpuswitchover 132  
sys-action resetconsole 133  
sys-action resetcounters 133  
udpsrc-by-vip 133  
no udpsrc-by-vip 133

---

## **SNMP commands** 135

snmp-server authentication-trap 135  
no snmp-server authentication-trap 136  
snmp-server bootstrap 136  
snmp-server community 136  
snmp-server community name 137  
snmp-server community security 138  
no snmp-server community 138  
snmp-server contact 138  
snmp-server group 139  
no snmp-server group 140  
snmp-server host 140  
no snmp-server host 141  
show snmp-server 141  
snmp-server location 141  
snmp-server member 141  
no snmp-server member 142  
snmp-server name 142  
snmp-server user 143  
no snmp-server user 144  
snmp-server view 144  
no snmp-server view 145

---

## **Ethernet port commands** 147

action 148  
auto-negotiate 148  
no auto-negotiate 149  
auto-recover-port 149  
    Syntax 149  
    Parameters 149  
    Command mode 149  
default auto-recover-port 149  
    Syntax 149  
    Parameters 150  
    Command mode 150  
no auto-recover-port 150  
    Syntax 150

---

Parameters	150
Command mode	150
bcast-mcast-rate-limit	150
cp-limit	151
no cp-limit	151
default-vlan-id	152
duplex	152
eapol	153
no eapol	155
encapsulation	156
no encapsulation	156
linktrap	156
no linktrap	157
lock	157
no lock	157
name	158
shutdown	158
no shutdown	158
spanning-tree stp	159
no spanning-tree stp	160
tx-queue	160
no tx-queue	161
unknown-mac-discard	162
no unknown-mac-discard	163
test loopback	163
test stop	164
untagged-frames-discard	164
no untagged-frames-discard	164
custom autonegotiation advertisements	165

---

## **Security commands**

---

access-policy disable	169
access-policy enable	169
access-policy info	169
access-policy policy	169
access-policy policy	171
access-policy policy create	172
access-policy policy info	174
eapol default-guest-vlan	174
eapol guest-vlan	175
eapol allow-non-eap mac-max	175
Command mode	175
eapol non-eap-mac add	175
no eapol guest-vlan	175

---

eapol guest-vlan-id 175  
eapol multihost 175  
eapol guest-vlan 176  
eapol multihost mac-max 176  
eapol allow-non-eap 176  
no access-policy policy 176  
no eapol allow-non-eap 176  
no eapol guest-vlan 177  
no eapol multihost 177  
no nsna 177  
    Syntax 177  
    Command mode 177  
no nsna enable 177  
    Syntax 177  
    Command mode 177  
no nsna nsnas 177  
    Syntax 177  
    Command mode 178  
no nsna phone-signature 178  
    Syntax 178  
no nsna vlan 178  
    Syntax 178  
    Command mode 178  
no radius 178  
no radius-server 178  
no snmp-server group 179  
no snmp-server host 179  
no snmp-server user 180  
no snmp-server v1v2 community 180  
no snmp-server view 180  
no syslog host 181  
nsna 181  
    Syntax 181  
    Parameters 181  
    Command mode 182  
nsna enable 182  
    Syntax 182  
    Command mode 182  
nsna nsnas 182  
    Syntax 182  
    Parameters 182  
    Command mode 182  
nsna phone-signature 183

Syntax 183  
Command mode 183  
nsna uplink vlans 183  
Syntax 183  
Command mode 183  
nsna vlan color 183  
Syntax 183  
Parameters 183  
Command mode 184  
radius 184  
radius clear-stat 187  
radius info 187  
radius-server info 187  
show access-policy 187  
show nsna 188  
Syntax 188  
Command mode 188  
show nsna client 188  
Syntax 188  
show nsna nsnas 188  
Syntax 188  
Command mode 188  
show nsna interface 189  
Syntax 189  
Command mode 189  
show nsna phone-signature 189  
Syntax 189  
Command mode 189  
show nsna vlan 189  
Syntax 189  
show radius 189  
show radius-server 190  
show syslog 190  
show syslog host 190  
snmp-server authentication-trap 190  
snmp-server contact 191  
snmp-server group 191  
snmp-server group info 192  
snmp-server group match 192  
snmp-server group view 193  
snmp-server host 194  
snmp-server host 195  
snmp-server info 195

---

snmp-server location 195  
snmp-server member 196  
snmp-server member info 196  
snmp-server member name 197  
no snmp-server member 197  
snmp-server name 198  
snmp-server user 198  
snmp-server user auth 199  
snmp-server user info 200  
snmp-server user priv 200  
snmp-server view 201  
snmp-server view info 202  
snmp-server view mask 202  
snmp-server view type 203  
syslog host 204  
syslog host 205  
syslog host create 206  
syslog host severity 207  
show eapol 208  
show eapol 208  
    Command mode 208

---

<b>IP protocol commands</b>	<b>209</b>
accept adv-rtr 213	
Syntax 213	
Parameters 213	
Command mode 214	
area 214	
Syntax 214	
Parameters 214	
Command mode 215	
as-boundary-router enable 215	
Syntax 215	
Command mode 216	
auto-vlink enable 216	
Syntax 216	
Command mode 216	
default-metric 216	
default default-metric 217	
default timer basic 217	
host-route 218	
Syntax 218	
Parameters 218	
Command mode 218	

---

interface loopback 218  
    Command mode 219  
ip address 219  
no ip address 219  
ip alternative-route 219  
no ip alternative-route 220  
ip arp 220  
no ip arp 221  
ip arp proxy 221  
no ip arp proxy 221  
ip arp response 221  
no ip arp response 221  
ip default-ttl 222  
ip dhcp-relay broadcast 222  
    Command mode 222  
ip dhcp-relay 222  
    Command mode 222  
ip dhcp-relay max-hop 222  
    Command mode 222  
ip dhcp-relay min-sec 223  
    Command mode 223  
ip dhcp-relay mode 223  
    Command mode 223  
    223  
ip forward-protocol udp 223  
no ip forward-protocol udp 223  
ip forward-protocol udp portfwdlist 224  
no ip forward-protocol udp portfwdlist 224  
no ip forward-protocol udp porffwdlist 225  
ip forward-protocol udp 225  
no ip forward-protocol udp 226  
ip icmp-unreach-msg 226  
no ip icmp-unreach-msg 227  
ip irdp enable 227  
no ip irdp enable 227  
ip irdp 227  
    Enabling router discovery 227  
    Configuring router discovery on VLANs 227  
    Syntax 228  
no ip irdp 228  
    Syntax 228  
    Command mode 228  
default ip irdp 228

Syntax 228  
Command mode 229  
no ip irdp multicast 229  
Syntax 229  
Command mode 229  
ip irdp vlan multicast 229  
Syntax 229  
Command mode 229  
no ip irdp vlan multicast 229  
Syntax 229  
Command mode 229  
ip more-specific-non-local-route enable 229  
no ip more-specific-non-local-route enable 230  
ip ospf 230  
Syntax 230  
Parameters 230  
Command mode 231  
ip ospf spf-run 232  
Syntax 232  
Command mode 232  
ip prefix-list 232  
no ip prefix-list 233  
ip routing 233  
no ip routing 233  
ip rip 234  
ip route 238  
no ip route 239  
ip route preference protocol 239  
lldp 240  
Syntax 240  
Parameter 240  
Command mode 241  
default lldp 241  
Syntax 241  
Command mode 241  
lldp port status 241  
Syntax 241  
Command mode 241  
no lldp port 241  
Syntax 241  
Command mode 242  
default lldp port 242  
Syntax 242

---

Command mode 242  
    lldp tx-tlv 242  
        Syntax 242  
        Command mode 242  
    lldp port status 242  
        Syntax 242  
        Command mode 242  
    no lldp status 242  
        Syntax 242  
        Command mode 242  
    default lldp port 243  
        Syntax 243  
        Command mode 243  
    lldp tx-tlv 243  
        Syntax 243  
        Parameters 243  
        Command mode 243  
    no lldp tx-tlv 243  
        Syntax 243  
        Command mode 243  
    default lldp tx-tlv 244  
        Syntax 244  
        Command mode 244  
    lldp tx-tlv dot1 244  
        Syntax 244  
        Parameters 244  
        Command mode 244  
    no lldp tx-tlv dot1 244  
        Syntax 244  
        Command mode 244  
    default lldp tx-tlv dot1 245  
        Syntax 245  
        Command mode 245  
    lldp tx-tlv dot3 245  
        Syntax 245  
        Parameters 245  
        Command mode 245  
    no lldp tx-tlv dot3 245  
        Syntax 245  
        Command mode 246  
    default lldp tx-tlv dot3 246  
        Syntax 246  
        Command mode 246

---

lldp tx-tlv med 246  
    Syntax 246  
    Parameters 246  
    Command mode 246  
no lldp tx-tlv med 246  
    Syntax 247  
    Command mode 247  
default lldp tx-tlv med 247  
    Syntax 247  
    Command mode 247  
lldp location-identification civic-address 247  
    Syntax 247  
    Command mode 247  
    Parameters 247  
manualtrigger ip rip interface vlan 248  
network 248  
no network 249  
network 249  
    Syntax 249  
    Command mode 249  
network area 249  
    Syntax 250  
    Command mode 250  
redistribute enable 250  
    Syntax 250  
    Command mode 250  
redistribute source 250  
    Syntax 250  
    Command mode 251  
route-map 251  
route-map 252  
no route-map 254  
router ospf 254  
    Syntax 254  
    Command mode 254  
router ospf enable 254  
    Syntax 254  
    Command mode 254  
no router ospf enable 254  
    Syntax 254  
    Command mode 254  
router rip 255  
router rip enable 255

no router rip enable 255  
router-id 255  
    Syntax 255  
    Command mode 256  
slpp 256  
    Syntax 256  
    Parameters 256  
    Command mode 256  
Default slpp 256  
    Syntax 256  
    Parameters 256  
    Command mode 257  
no slpp 257  
    Syntax 257  
    Parameters 257  
    Command mode 257  
slpp port 257  
    Syntax 257  
    Parameters 258  
    Command mode 258  
default slpp port 258  
    Syntax 258  
    Parameters 258  
    Command mode 258  
no slpp port 258  
    Syntax 259  
    Parameters 259  
    Command mode 259  
show interface loopback 259  
show ip arp 259  
show ip dhcp-relay fwd-path 260  
    Command mode 260  
show ip dhcp-relay counters 260  
    Command mode 260  
show ip forward-protocol udp 260  
show ip forward-protocol udp portfwlist 260  
show ip forward-protocol udp interface 261  
show ip global 261  
show ip interface 261  
    Syntax 261  
    Command mode 261  
show ip irdp 261  
    Syntax 261

Command mode 262  
    show ip irdp interface 262  
        Syntax 262  
        Command mode 262  
        show ip irdp interface vlan 262  
            Syntax 262  
            Command mode 262  
        show ip ospf 262  
            Syntax 262  
            Command mode 262  
        show ip ospf accept 262  
            Syntax 262  
            Command mode 262  
        show ip ospf area 262  
            Syntax 263  
            Parameters 263  
            Command mode 263  
        show ip ospf ase 263  
            Syntax 263  
            Parameters 263  
            Command mode 263  
        show ip ospf authentication interface 263  
            Syntax 264  
            Parameters 264  
            Command mode 264  
        show ip ospf default-metric 264  
            Syntax 264  
            Command mode 264  
        show ip ospf host-route 264  
            Syntax 264  
            Command mode 264  
        show ip ospf ifstats 264  
            Syntax 264  
            Command mode 265  
        show ip ospf int-auth 265  
            Syntax 265  
            Command mode 265  
        show ip ospf int-timers 265  
            Syntax 265  
            Command mode 265  
        show ip ospf interface 265  
            Syntax 265  
            Parameters 265

Command mode 265  
    show ip ospf lsdb 266  
        Syntax 266  
        Parameters 266  
        Command mode 266  
    show ip ospf neighbours interface 266  
        Syntax 266  
        Parameters 266  
        Command mode 267  
    show ip ospf redistribute 267  
        Syntax 267  
        Command mode 267  
    show ip ospf stats 267  
        Syntax 267  
        Command mode 267  
    show ip ospf timer interface 267  
        Syntax 267  
        Parameters 267  
        Command mode 268  
    show ip prefix-list 268  
    show ip rip 268  
    show ip rip interface 268  
    show ip route 269  
    show ip routing 269  
    show route-map 269  
    show ip route 270  
    show ip route preference 270  
    show ip static-route 270  
    show ip tcp 271  
    show lldp 271  
        Syntax 271  
        Parameters 271  
        Command mode 272  
    show lldp neighbor 273  
        Syntax 273  
        Parameters 273  
        Command mode 273  
    show lldp neighbor-mgmt-addr 273  
        Syntax 273  
        Parameters 273  
        Command mode 274  
    show slpp 274  
        Syntax 274

---

Command mode 274  
    show ports stats dhcp-relay 274  
        Syntax 274  
        Command mode 274  
    show vlan nlb-mode 274  
        Syntax 274  
        Command mode 274  
    timer basic 274  
    timers basic holddown 276  
        Syntax 276  
        Command mode 276  
    trap enable 276  
        Syntax 277  
        Command mode 277  
    vlan nlb-mode 277  
        Syntax 277  
        Command mode 277  
    no vlan nlb-mode 277  
        Syntax 277  
        Command mode 277

---

**Layer 2 and 3 operations commands** 279

Layer 2 Operations Commands 281  
    bcast-mcast-rate-limit enable 281  
        Syntax 281  
        Parameters 282  
        Command mode 282  
    ist 282  
        Syntax 282  
        Parameter 282  
        Command mode 282  
    no ist 282  
        Syntax 282  
        Command mode 282  
    ist enable 282  
        Syntax 282  
        Command mode 283  
    no ist enable 283  
        Syntax 283  
        Command mode 283  
    no mlt encapsulation dot1q 283  
        Syntax 283  
        Parameters 283  
        Command mode 283

---

no mlt name 283  
    Syntax 283  
    Parameters 283  
    Command mode 283  
interface mlt 284  
    Syntax 284  
    Parameters 284  
    Command mode 284  
smlt 284  
    Syntax 284  
    Parameters 284  
    Command mode 284  
no smlt 284  
    Syntax 284  
    Command mode 284  
smlt 284  
    Syntax 284  
    Parameters 285  
    Command mode 285  
no smlt 285  
    Syntax 285  
    Command mode 285  
mlt members 285  
mlt add-vlan 285  
mlt name 286  
no mlt members 286  
mlt remove-vlan 287  
mlt create 287  
mlt encapsulation 288  
no mlt encapsulation 288  
no mlt 288  
show mlt 289  
show mlt error 289  
show mlt error collision 289  
show smlt 290  
    Syntax 290  
    Parameters 290  
show ist 290  
    Syntax 290  
    Command mode 290  
show ist stat 290  
    Syntax 290  
    Command mode 290

---

show mlt stats 290  
show spanning-tree 291  
show spanning-tree config 291  
show interface vlan 291  
show vlan advance 292  
    Syntax 292  
    Command mode 292  
show ip arp interface 292  
show vlan autolearn-mac 292  
show vlan vid basic 292  
show vlan vid fdb-entry 293  
show vlan vid fdb-filter 293  
show vlan vid fdb-static 293  
show interfaces vlan ip 294  
show vlan manual-edit-mac 294  
show vlan members 294  
show vlan static-mcastmac 294  
spanning-tree stp 295  
spanning-tree stp add-ports 296  
spanning-tree stp create 297  
spanning-tree stp remove-ports 297  
no spanning-tree 298  
telnet-access 298  
vlan action 299  
vlan add-mlt 299  
vlan members 300  
vlan name 301  
vlan qos-level 301  
no vlan 301  
vlan create type port 302  
vlan create type protocol-ApItkEther2Snap 302  
vlan create type protocol-decEther2 303  
vlan create type protocol-decOtherEther2 304  
vlan create type protocol-ipEther2 305  
vlan create type protocol-ipv6Ether2 305  
vlan create type protocol-ipx802.2 306  
vlan create type protocol-ipx802.3 307  
vlan create type protocol-ipxEther2 308  
vlan create type protocol-ipxSnap 308  
vlan create type protocol-Netbios 309  
vlan create type protocol-RarpEther2 310  
vlan create type protocol-sna802.2 310  
vlan create type protocol-snaEther2 311

---

vlan create type protocol-Userdef	312
vlan create type protocol-vinesEther2	312
vlan create type protocol-xnsEther2	313
vlan fdb-entry aging-time	314
vlan fdb-entry flush	314
vlan fdb-entry qos-level	315
vlan fdb-entry sync	315
vlan fdb-filter add	315
no vlan fdb-filter	316
vlan fdb-static add	317
no vlan fdb-static	317
vlan static-mcastmac add	318
vlan static-mcastmac add-mlt	318
vlan static-mcastmac remove-mlt	319
vlan static-mcastmac add-ports	319
vlan static-mcastmac remove	320
vlan static-mcastmac remove-mlt	320
vlan static-mcastmac remove-ports	321
no vlan static-mcastmac	321
Layer 3 Operations Commands	322
interface vlan	322
ip address	322
no ip address	322
ip arp proxy	323
no ip arp proxy	323
ip arp response	323
no ip arp response	323
<b>Route filters commands</b>	<b>325</b>
filter acl ip	325
filter acl non-ip	326
filter acl action	327
no filter acl	330
filter acl ethernet	331
filter acl ip-hdr	332
filter acl port	335
filter acl protocol	336
filter acl debug	337
filter acg	338
filter acg modify	339
no filter acg	339
filter act ethernet	339
filter act ip-hdr	342
no filter act	345

---

show filter acg 346  
show filter acl action 346  
show filter acl ethernet 346  
show filter acl ip 346  
show filter acl port 347  
show filter acl statistics 347  
show filter act ethernet 347  
show filter act ip 348

---

**Test and diagnostic commands** 349

clear port-stats 351  
clear telnet 351  
monitor mlt error collision 351  
monitor mlt error main 351  
monitor mlt stats interface main 352  
monitor mlt stats interface utilization 352  
monitor ports error collision 352  
monitor ports error extended 353  
monitor ports error main 354  
monitor ports stats interface extended 354  
monitor ports stats interface main 355  
monitor ports stats interface utilization 355  
monitor ports stats rmon 356  
monitor ports stats stp 357  
port-mirroring 357  
no port-mirroring 359  
rmon alarm 359  
no rmon alarm 360  
rmon event 360  
no rmon event 361  
rmon history 361  
no rmon history 362  
rmon memsize 362  
rmon stats 363  
no rmon stats 363  
rmon trap-option 364  
rmon util-method 364  
show port-mirroring 365  
show interface fast-ethernet or gigabit-Ethernet 365  
show interface statistics 366  
show rmon 367  
show spanning-tree config 368  
show spanning-tree port 368  
show sys-info 368

---

show test 369  
show trace file 369  
show trace level 370  
test 370  
trace auto-enable 371  
trace auto-enable add-module 372  
trace auto-enable auto-trace 373  
trace auto-enable remove-module 373  
trace clear 374  
trace filter 374  
trace grep 374  
trace level 375  
trace off 375  
trace route-policy 375  
trace screen 376  
traceroute 376  
vct test 377

---

**Multicast services commands** 379

debug ip pim 381  
    Syntax 381  
interface vlan 382  
ip igmp immediate-leave-mode 382  
    Syntax 382  
    Command mode 383  
default ip igmp immediate-leave-mode 383  
    Syntax 383  
    Command mode 383  
ip igmp 383  
    Syntax 383  
    Parameters 383  
    Command mode 386  
no ip igmp 386  
    Syntax 386  
    Parameters 386  
    Command mode 387  
default ip igmp 387  
    Syntax 387  
    Parameters 387  
    Command mode 389  
ip igmp generate-log 389  
    Syntax 389  
    Command mode 389  
no ip igmp generate-log 390

---

Syntax 390  
Command mode 390  
default ip igmp generate-log 390  
Syntax 390  
ip igmp generate-trap 390  
Syntax 390  
no ip igmp generate-trap 390  
Syntax 390  
Command mode 390  
default ip igmp generate-trap 390  
Syntax 390  
Command mode 390  
ip igmp mrdisc 391  
Syntax 391  
Parameters 391  
Command mode 391  
no ip igmp mrdisc 391  
Syntax 392  
Command mode 392  
default ip igmp mrdisc 392  
Syntax 392  
Command mode 392  
ip igmp snoop querier 392  
Syntax 392  
Command mode 392  
no ip igmp snoop querier 392  
Syntax 392  
Command mode 392  
ip igmp snoop querier-addr 392  
Syntax 392  
Command mode 392  
no ip igmp snoop querier-addr 393  
Syntax 393  
ip igmp stream-limit 393  
Syntax 393  
Parameters 393  
Command mode 393  
no ip igmp stream-limit 393  
Syntax 393  
Command mode 393  
ip igmp stream-limit-group enable max-streams 394  
Syntax 394  
Command mode 394

---

no ip igmp stream-limit-group 394  
    Syntax 394  
    Command mode 394  
default ip igmp stream-limit-group 394  
    Syntax 394  
ip igmp stream-limit-max-streams 394  
    Syntax 394  
    Command mode 395  
default ip igmp stream-limit-max-streams 395  
    Syntax 395  
    Command mode 395  
ip mroute static-source-group 395  
    Syntax 395  
    Command mode 395  
no ip mroute static-source-group 395  
    Syntax 395  
ip pim 396  
    Configuring PIM-SM globally 396  
    Configuring PIM-SM on a VLAN 398  
ip pim enable 399  
    Enabling PIM-SM globally 399  
    Enabling PIM-SM on a VLAN 400  
no ip pim 400  
    Disabling PIM-SM globally 400  
    Disabling PIM-SM on a VLAN 400  
ip pim interface virtual neighbor 400  
    Syntax 400  
    Command mode 400  
no ip pim interface virtual neighbor 401  
    Syntax 401  
ip pim rp-candidate group rp 401  
    Syntax 401  
    Command mode 401  
no ip pim rp-candidate group rp 401  
    Syntax 401  
    Command mode 401  
ip pim static-rp 401  
    Syntax 402  
no ip pim static-rp 402  
    Syntax 402  
    Command mode 402  
ip pim static-rp 402  
    Syntax 402

Command mode 402  
    no ip pim static-rp 403  
        Syntax 403  
        Command mode 403  
    show debug ip pim 403  
        Syntax 403  
        Command mode 403  
    show interfaces vlan igmp 403  
    show ip igmp 403  
    show ip igmp access 404  
        Command mode 404  
    show ip igmp cache 404  
    show ip igmp group 405  
    show ip igmp group 405  
        Syntax 405  
        Parameters 405  
        Command mode 405  
    show ip igmp interface 406  
        Syntax 406  
        Parameters 406  
        Command mode 406  
    show ip igmp mrdisc 406  
        Syntax 406  
    show ip igmp router-alert 406  
    show ip igmp sender 406  
        Syntax 407  
        Parameters 407  
        Command mode 407  
    show ip igmp snooping 407  
        Syntax 407  
        Command mode 407  
    show ip igmp snoop-trace 407  
        Syntax 407  
        Command mode 408  
    show ip igmp static 408  
    show ip igmp stream-limit 408  
        Syntax 408  
        Command mode 408  
    show ip igmp sys 408  
        Syntax 408  
        Command mode 408  
    show ip mroute static-source-group 408  
        Syntax 408

---

409  
Command mode 409  
show ip pim 409  
Syntax 409  
Command mode 409  
show ip pim active-rp 409  
Syntax 409  
Command mode 409  
show ip pim bsr 409  
Syntax 409  
Command mode 409  
show ip pim interface 409  
Syntax 409  
Command mode 409  
show ip pim interface vlan 410  
Syntax 410  
Command mode 410  
show ip pim mroute 410  
Syntax 410  
show ip pim static-rp 410  
Syntax 410  
Command mode 410  
show ip pim neighbor 410  
Syntax 410  
Command mode 410  
show ip pim rp-candidate 410  
Syntax 410  
Command mode 410  
show ip pim virtual-neighbor 411  
Syntax 411  
Command mode 411

---

<b>Quality of Service commands</b>	<b>413</b>
interface FastEthernet/GigabitEthernet 414	
qos 414	
qos 8021p-override 416	
no qos 8021p-override 416	
qos shaper 416	
qos shaper rate 416	
qos shaper burst size 416	
no qos shaper 417	
qos trust-dscp enable 417	
no qos trust-dscp enable 417	
qos update-dynamic-mac-qos-level 417	

---

no qos update-dynamic-mac-qos-level 417  
 qos map 418  
 qos policy create 420  
 no qos policy 421  
 qos policy action 421  
 no qos policy action 422  
 qos policy modify 423  
 qos egress-counter-set 423  
 no qos egress-counter-set 424  
 show qos egress-stats 424  
 show qos egress-counter-set 425  
 qos map-qos-level-override 425  
 show qos policy 425  
 show qos policy-stats 425  
 show qos map 8021p-to-class-map 426  
 show qos map 8021p-to-drop-precedence-map 426  
 show qos map class-to-8021p-map 426  
 show qos map class-to-8021p-policed-map 426  
 show qos map dscp-to-cos-policed-map 427

---

**Web server commands** 429

web-server 429  
 web-server password 430  
 no web-server 430  
 show web-server 430

---

**POE commands** 433

interface FastEthernet/GigabitEthernet 434  
 interface FastEthernet 434  
 poe detect-control 434  
 poe detection-control 435  
 poe fw-upgrade slot 435  
 poe limit 436  
 poe limit 436  
 poe notification slot 436  
 no poe notification 436  
 poe port admin 437  
 poe priority 437  
 poe priority 437  
 poe priority 437  
 poe shutdown 438  
 no poe shutdown 438  
 poe shutdown 438  
 no poe shutdown 438  
 no poe shutdown 439

---

poe type 439  
    poe type port 439  
poe usage-threshold 440  
show poe main-status 440  
show poe port-status 440  
show poe sys-status 440  
show poe port-stats 441  
show poe power-measurement 441

---

**VCT commands** **443**

show vct 443  
    Command mode 443  
vct test 443  
    Command mode 444

---

## New in this release

---

The following sections detail what is new in *Nortel Ethernet Routing Switch 8300 Command Reference — NNCLI* (NN462000-306)

- "Features" (page 35)
- "Other changes" (page 38)

### Features

The new features in release 4.0 have the following commands:

#### Layer 2 IGMP snoop querier

- ip igmp snoop-querier
- no ip igmp snoop-querier
- ip igmp snoop-querier-addr
- no ip igmp snoop-querier
- show ip igmp snooping

### **Multicast Stream Limitation**

- ip igmp stream-limit
- no ip igmp stream-limit
- ip igmp stream-limit-group enable max-streams
- no ip igmp stream-limit
- ip igmp stream-limit-group enable max-streams
- no ip igmp stream-limit-group
- default ip igmp stream-limit-group
- ip igmp stream-limit-max-streams
- default ip igmp stream-limit-max-streams
- show interfaces vlan igmp
- show ip igmp stream-limit
- show ip igmp stream-limit

### **Network Load Balancing Support**

- vlan nlb-mode
- no vlan nlb-mode
- show vlan nlb-mode

## Protocol Independent Multicast-Sparse Mode

- debug ip pim
- ip pim
- ip pim enable
- no ip pim
- ip pim interface virtual neighbor
- no ip pim interface virtual neighbor
- ip pim rp-candidate group rp
- no ip pim rp-candidate group rp
- ip pim static-rp
- no ip pim static-rp
- show debug ip pim
- show ip pim
- show ip pim active-rp
- show ip pim bsr
- show ip pim interface
- show ip pim interface vlan
- show ip pim mroute
- show ip pim static-rp

## Simple Loop Protection Protocol

- slpp
- Default slpp
- no slpp
- slpp port
- default slpp port
- no slpp port
- show slpp

### **Static source groups**

- `ip mroute static-source-group`
- `no ip mroute static-source-group`
- `show ip mroute static-source-group`

### **Other changes**

The following are new or revised commands in release 4.0 that are not associated with the new features:

### **IP Protocol commands**

- `ip irdp`
- `no ip irdp`
- `default ip irdp`
- `no ip irdp multicast`
- `ip irdp vlan multicast`
- `no ip irdp vlan multicast`
- `show ip irdp`

## Multicast services commands

In Software Release 4.0, many of the IP IGMP commands that were listed separately in previous releases, are now listed as parameters that are included in the `ip igmp`, `no ip igmp`, and `default ip igmp` commands.

- `ip igmp`
- `no ip igmp`
- `default ip igmp`
- `ip igmp generate-log`
- `no ip igmp generate-log`
- `default ip igmp generate-log`
- `ip igmp generate-trap`
- `no ip igmp generate-trap`
- 
- `ip igmp mrdisc`
- `no ip igmp mrdisc`
- `default ip igmp mrdisc`
- `show ip igmp group count`
- `show ip igmp snooping`
- `show ip igmp sys`



---

# Preface

---

The Nortel\* Ethernet Routing Switch 8300 is a flexible and multifunctional Layer 2/Layer 3 switch that supports diverse network architectures and protocols. The Ethernet Routing Switch 8300 provides security and control features such as Extensible Authentication Protocol over LAN (EAPoL), Simple Network Management Protocol, Version 3 (SNMP3), and Secure Shell (SSH). The Ethernet Routing Switch 8300 provides quality of service (QoS) for a high number of attached devices and supports future network requirements for QoS for critical applications, such as Voice over IP (VoIP).

This guide describes the individual NNCLI commands available for the Ethernet Routing Switch 8300 Software Release 4.0. The guide lists each command, together with the complete syntax and a functional description, from the Nortel Networks\* Command Line Interface (NNCLI).

## Before you begin

This guide is intended for network administrators who have the following background:

- basic knowledge of networks, Ethernet bridging, and IP routing
- familiarity with networking concepts and terminology
- experience with windowing systems or GUIs
- basic knowledge of network topologies

## About the NNCLI

This section describes the Nortel Networks Command Line Interface (NNCLI) command modes you use to configure the Ethernet Routing Switch 8300 and the commands you use to access the NNCLI. You can access the NNCLI using the following methods:

- Telnet session
- rlogin
- local console port

## NNCLI command modes

The NNCLI has four major command modes, listed in order of increasing privileges:

- User EXEC
- Privileged EXEC
- Global configuration
- Interface configuration

Each mode provides a specific set of commands. The command set of a higher-privilege mode is a superset of a lower-privilege mode. That is, all lower-privilege mode commands are accessible when using a higher-privilege mode.

The command modes are as follows:

- User EXEC mode

This is the initial mode of access. By default, the User Access Verification Password for this mode is empty, and password checking is disabled. The system administrator can change the password (and password checking enabled) in Global configuration mode. Once the password is changed, it is activated immediately.

- Privileged EXEC mode

This mode is accessed from the User EXEC mode. When accessing this mode, you are prompted to provide a login name and password. The login name and password combination determines your access level in the Privileged EXEC mode and other higher modes.

- Global configuration mode

This mode allows you to make changes to the running configuration. If the configuration is saved, these settings survive reboots of the switch.

- Interface configuration mode

This mode allows you to modify either a logical interface, such as a VLAN, or a physical interface, such as a port/slot.

From either the Global configuration mode or the Interface configuration mode, save all the configuration parameters (both global and interface) to a file. The default name for the configuration parameters file is config.cfg. You can also use alternative filenames.

"[NNCLI command modes](#)" (page 43) lists the NNCLI command modes, the prompts for each mode, the abbreviated name for each mode, and how to enter and exit each mode.

### NNCLI command modes

Command mode	Prompt	Mode name	Command/mode to enter or exit mode
User EXEC	Passport-8300:5>	exec	Default mode when NNCLI is started  <code>logout</code> to exit
Privileged EXEC	Passport-8300:5#	privExec	<code>enable</code> to enter from User EXEC mode  <code>disable</code> to exit to User EXEC mode
Global configuration	Passport-8300:5(config)#	config	<code>configure</code> to enter from Privileged EXEC mode  <code>exit</code> to exit to Privileged EXEC mode
Interface configuration	Passport-8300:5(config-if)#	config-if	<code>interface</code> to enter from Global configuration mode  <code>exit</code> to exit to Global configuration mode
<b>Note:</b> Prompts are expressed in this table using the format Passport-8300:5; however, prompts returned from your switch typically reflect the specific chassis you use. For example, if you use the 8310 chassis, the prompts use the format Passport-8310:5. Prompts can be customized, also, using the NNCLI command <code>snmp-server name &lt;prompt&gt;</code> . Refer to <i>Getting Started (316799-C)</i> for more information.			

### Accessing the NNCLI

When you first power up the Ethernet Routing Switch 8300, the default interface is the Ethernet Routing Switch 8300 CLI. To switch from the CLI to the NNCLI, you must change the NNCLI boot flag to `true` and save the boot configuration file using the following commands:

```
Passport-8310:5# config boot flags nncli true
Passport-8310:5# save boot
```

You must reboot the switch for this change to take effect. After you reboot the switch, access the NNCLI using Telnet, rlogin, or the local console port. You can log in to the switch using your password and the default privilege password `nortel`.

Use the following commands to:

- log in to the software using the default user name and password
- access Global configuration mode

```
Login: xxxxx
Password: xxxxx
Passport-8310:5> enable
Password: nortel
Passport-8310:5# configure terminal
Passport-8310:5 (config) #
```

## Returning to the CLI

**Note:** The config.cfg file for the CLI and the config.cfg file for the NNCLI are not compatible. If you decide to change the CLI mode to NNCLI, or the reverse, you must use the config.cfg file for the selected mode.

To switch from the NNCLI to the CLI, enter the following commands:

```
Passport-8310:5 (config) # no boot flags nncli
Passport-8310:5 (config) # exit
Passport-8310:5 (config) # save boot
```

You must reboot the switch for this change to take effect.

## Text conventions

This guide uses the following text conventions:

**angle brackets (< >)** Indicate that you choose the text to enter based on the description inside the brackets. Do not type the brackets when entering the command.

Example: If the command syntax is  
**ping <ip\_address>**, you enter  
**ping 192.32.10.12**

**bold body text** Indicates objects such as window names, dialog box names, and icons, as well as user interface objects such as buttons, tabs, and menu items.

**bold Courier text** Indicates command names, options, and text that you must enter.

Example: Use the **dinfo** command.

Example: Enter **show ip {alerts|routes}**.

---

braces ({} )	Indicate required elements in syntax descriptions where there is more than one option. You must choose only one of the options. Do not type the braces when entering the command.
	Example: If the command syntax is <code>show ip {alerts routes}</code> , you must enter either <code>show ip alerts</code> or <code>show ip routes</code> , but not both.
brackets ([ ])	Indicate optional elements in syntax descriptions. Do not type the brackets when entering the command.
	Example: If the command syntax is <code>show ip interfaces [-alerts]</code> , you can enter either <code>show ip interfaces</code> or <code>show ip interfaces -alerts</code> .
ellipsis points (. . .)	Indicate that you repeat the last element of the command as needed.
	Example: If the command syntax is <code>ethernet/2/1 [ &lt;parameter&gt; &lt;value&gt; ] . . .</code> ,
	you enter <code>ethernet/2/1</code> and as many parameter-value pairs as needed.
<i>italic text</i>	Indicates variables in command syntax descriptions. Also indicates new terms and book titles. Where a variable is two or more words, the words are connected by an underscore.
	Example: If the command syntax is <code>show at &lt;valid_route&gt;</code> , <code>valid_route</code> is one variable and you substitute one value for it.
plain Courier text	Indicates command syntax and system output, for example, prompts and system messages.
	Example: Set Trap Monitor Filters

separator ( > )	Shows menu paths.
vertical line (   )	Example: <b>Protocols &gt; IP</b> identifies the <b>IP</b> command on the <b>Protocols</b> menu. Separates choices for command keywords and arguments. Enter only one of the choices. Do not type the vertical line when entering the command.
	Example: If the command syntax is <code>show ip {alerts routes}</code> , you enter either <code>show ip alerts</code> or <code>show ip routes</code> , but not both.

## How to get help

This section explains how to get help for Nortel products and services.

### Getting help from the Nortel web site

The best way to get technical support for Nortel products is from the Nortel Technical Support web site:

[www.nortel.com/support](http://www.nortel.com/support)

This site provides quick access to software, documentation, bulletins, and tools to address issues with Nortel products. From this site, you can:

- download software, documentation, and product bulletins
- search the Technical Support Web site and the Nortel Knowledge Base for answers to technical issues
- sign up for automatic notification of new software and documentation for Nortel equipment
- open and manage technical support cases

### Getting help over the phone from a Nortel Solutions Center

If you do not find the information you require on the Nortel Technical Support web site, and you have a Nortel support contract, you can also get help over the phone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7835).

Outside North America, go to the following web site to obtain the phone number for your region:

[www.nortel.com/callus](http://www.nortel.com/callus)

---

**Getting help from a specialist using an Express Routing Code**

To access some Nortel Technical Solutions Centers, you can use an Express Routing Code (ERC) to quickly route your call to a specialist in your Nortel product or service. To locate the ERC for your product or service, go to:

[www.nortel.com/erc](http://www.nortel.com/erc)

**Getting help through a Nortel distributor or reseller**

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller.



# Utility management commands

This chapter describes the NNCLI utility management commands and their parameters.

<b>Utility Management Commands</b>
<a href="#">"attribute" (page 50)</a>
<a href="#">"boot" (page 51)</a>
<a href="#">"cd" (page 51)</a>
<a href="#">"chkdisk" (page 51)</a>
<a href="#">"clear" (page 52)</a>
<a href="#">"copy" (page 53)</a>
<a href="#">"cp" (page 53)</a>
<a href="#">"date" (page 54)</a>
<a href="#">"delete" (page 54)</a>
<a href="#">"dir" (page 54)</a>
<a href="#">"disable" (page 55)</a>
<a href="#">"edit" (page 55)</a>
<a href="#">"enable" (page 55)</a>
<a href="#">"end" (page 56)</a>
<a href="#">"exit" (page 56)</a>
<a href="#">"format" (page 56)</a>
<a href="#">"format-flash" (page 56)</a>
<a href="#">"grep" (page 57)</a>
<a href="#">"help" (page 57)</a>
<a href="#">"history" (page 57)</a>
<a href="#">"install" (page 58)</a>
<a href="#">"logout" (page 58)</a>
<a href="#">"mkdir" (page 58)</a>
<a href="#">"monitor" (page 58)</a>

Utility Management Commands
<a href="#">"monitor-stats" (page 59)</a>
<a href="#">"more" (page 60)</a>
<a href="#">"mv" (page 60)</a>
<a href="#">"pcmcia-stop" (page 60)</a>
<a href="#">"peer" (page 61)</a>
<a href="#">"ping" (page 61)</a>
<a href="#">"pwd" (page 62)</a>
<a href="#">"reload" (page 62)</a>
<a href="#">"rename" (page 63)</a>
<a href="#">"rlogin" (page 63)</a>
<a href="#">"rlogin-sessions" (page 63)</a>
<a href="#">"rsh" (page 64)</a>
<a href="#">"save" (page 64)</a>
<a href="#">"show running-config" (page 65)</a>
<a href="#">"source" (page 65)</a>
<a href="#">"sys-action" (page 65)</a>
<a href="#">"telnet" (page 66)</a>
<a href="#">"telnet-access" (page 66)</a>
<a href="#">"test" (page 67)</a>
<a href="#">"trace" (page 67)</a>
<a href="#">"trace auto-enable" (page 68)</a>
<a href="#">"traceroute" (page 70)</a>
<a href="#">"write memory" (page 71)</a>

## attribute

Use this command to modify the MS-DOS file attributes.

### Syntax

```
attribute <file> <attributes>
```

where:

- **file** specifies the MS-DOS file name.
- **attributes** specifies the file attributes as {+|-|A|S|H|R}. The range of values is 1 to 1536 characters.

### Command mode

Privileged EXEC mode

## boot

Use this command to boot the switch with an image and a configuration file. The command options let you specify the boot source (flash, PCMCIA card, or TFTP server) and file name. If you do not specify a device and file, the NNCLI uses the software and configuration files on the primary boot device that is defined by the Boot Monitor **choice** command.

**Note:** For the changes made to the Boot Monitor CLI to take effect, you must use the **save** command to save the changed configuration file and then reboot the switch.

### Syntax

```
boot [ <file> ] [config <value> ] [-y]
```

where:

- **file** is the software image device and file name in the format [[a.b.c.d:](#)]<file> | /pcmcia/<file> | /flash/<file>. The file name, including the directory structure, can be up to 1536 characters.
- **config value** is the software configuration device and file name in the format [[a.b.c.d:](#)]<file> | /pcmcia/ <file> | /flash/ <file>. The file name, including the directory structure, can be up to 1024 characters.
- **-y** suppresses the confirmation message before the switch reboots. If you omit this parameter, the system prompts you to confirm the action before the switch reboots.

### Command mode

Privileged EXEC mode

For more information about this command, see *Getting Started (316799-C)*.

## cd

Use this command to change the current file system directory path.

### Syntax

```
cd <dir>
```

where

**dir** specifies a directory path name up to 1536 characters.

### Command mode

Privileged EXEC mode

## chkdisk

This command runs a check of the file system for inconsistencies.

**Syntax**

```
chkdsk <device> [repair]
```

where:

- **device** is the device name, for example /flash | /pcmcia, up to 1536 characters.
- **repair** repairs the errors found.

**Command mode**

Privileged EXEC mode

**clear**

Use this command to clear statistics from counters, flush entries from a table, or end a Telnet session.

**Syntax**

```
clear
```

**Parameters**

This command includes the following options:

<b>clear</b>	
<b>followed by:</b>	
<b>filter statistics &lt;1-512&gt;</b>	Clears filter statistics from the switch counters, where <b>1-512</b> is the filter ID.
<b>ip arp vlan &lt;vid&gt;</b>	Clears ARP VLAN entries from the ARP table, where <b>vid</b> is the VLAN ID. The valid values are 0 to 255.
<b>ip route vlan &lt;vid&gt;</b>	Clears route entries associated with the specified VLAN, where <b>vid</b> is the VLAN ID. The valid values are 0 to 255.
<b>qos policy-stats &lt;1-128&gt;</b>	Clear QoS statistics from the switch counters, where <b>1-128</b> is the policy ID.
<b>port-stats [&lt;ports&gt;]</b>	Clears port statistics from the switch counters, where <b>ports</b> specifies the ports for which you are entering the command in the form: portlist {slot/port[-slot/port][,...]}.
<b>telnet &lt;session id&gt;</b>	Ends the specified Telnet session, where <b>session id</b> is a number between 0 and 7.

**Command mode**

Privileged EXEC mode

## copy

Use this command to copy a file from one device to another. You can also use a wildcard pattern with this command.

### Syntax

```
copy <srcfile> <destfile>
```

where:

- **srcfile** specifies the source device and file name of the file to be copied in one of the following formats:
  - [a.b.c.d:] <file>
  - /pcmcia/ <file>
  - /flash/ <file>
 The range of values is 1 to 1536 characters.
- **destfile** specifies the destination device and file name of the file that receives the copied file. The range of values is 1 to 99 characters.

### Command mode

Privileged EXEC mode

## cp

Use this command to copy a file from one device to another. This command can be used with a wildcard pattern.

### Syntax

```
cp <srcfile> <destfile>
```

where:

- **srcfile** specifies the source device and file name of the file to be copied in one of the following formats:
  - [a.b.c.d:] <file>
  - /pcmcia/ <file>
  - /flash/ <file>
 The range of values is 1 to 1536 characters.
- **destfile** specifies the destination device and file name of the file that receives the copied file. The range of values is 1 to 99 characters.

### Command mode

Privileged EXEC mode

For more information about this command, see *Getting Started (316799-C)*.

## date

Use this command to display the current date settings for the switch.

### Syntax

```
date
```

### Command mode

User EXEC mode  
Privileged EXEC mode

For more information about this command, see *Getting Started (316799-C)*.

## delete

Use this command to remove a file or directory. A wildcard pattern can be used with this command.

**Note:** This command can also be entered as `del`. There is no change in syntax or functionality when using the abbreviated command.

### Syntax

```
delete <file> [-y]
```

where:

- `file` specifies the device and file name in one of the following formats:
  - `/pcmcia/ <file>`
  - `/flash/ <file>`The range of values is 1 to 1536 characters.
- `-y` specifies bypassing the confirmation prompt.

### Command mode

Privileged EXEC mode

For more information about this command, see *Getting Started (316799-C)*.

## dir

Use this command to list the files in a directory in MS-DOS format. When you execute the `directory` command with no specified device, it displays the contents of all flash devices. When you specify flash or PCMCIA, the `directory` command displays only the contents of that device.

### Syntax

```
directory [ <dir> ] [-l]
```

where:

- **dir** specifies either flash or PCMCIA, in the form **/flash** or **/pcmcia**.
- **-l** displays file details if you specify a path name.

### **Command mode**

Privileged EXEC mode

## **disable**

Use this command to exit the Privileged EXEC command mode and return to the User EXEC command mode.

### **Syntax**

**disable**

### **Command mode**

Privileged EXEC mode

## **edit**

Use this command to modify the contents of a script file.

### **Syntax**

**edit <file>**

where

**file** specifies the file name **/flash** | **/pcmcia** with a value range of 1 to 99.

### **Command mode**

Privileged EXEC mode

## **enable**

Use this command to change from the User EXEC command mode to the Privileged EXEC command mode. If access to the Privileged EXEC command mode is password protected, you must supply a password when executing this command.

### **Syntax**

**enable**

### **Command mode**

User EXEC mode

### **Next command mode**

Privileged EXEC mode

For more information about this command, see *Getting Started (316799-C)*.

## **end**

Use this command to exit Global configuration mode and return to Privileged EXEC mode. The command is equivalent to pressing Ctrl+Z on the keyboard.

### **Syntax**

`end`

### **Command mode**

Global configuration mode

## **exit**

Use this command from within User EXEC mode or Privileged EXEC mode to end a terminal session and log out of the switch. Use this command from within Interface configuration mode to return to Global configuration mode and from Global configuration mode to return to Privileged EXEC mode.

### **Syntax**

`exit`

### **Command mode**

User EXEC mode  
Privileged EXEC  
Global configuration  
Interface configuration

For more information about this command, see *Getting Started (316799-C)*.

## **format**

This command formats the specified device (flash, or PCMCIA card).

### **Syntax**

`format <device>`

where

`device` specifies the device name (`/flash` or `/pcmcia`) that you want to format. The valid range is 1 to 1536.

### **Command mode**

Privileged EXEC mode

## **format-flash**

Use this command to format the switch's on-board flash device with an FTL and MS-DOS file system.

**Syntax**

```
format-flash
```

**Command mode**

Privileged EXEC mode

**grep**

Use this command to display all lines in a file that have one or more matching strings within the file.

**Syntax**

```
grep <string> <file>
```

where:

- **string** specifies the character string to be matched. The range of values is 0 to 1536 characters.
- **file** specifies the file name in one of the following formats:
  - /pcmcia/ <file>
  - /flash/ <file>

The file name, including the directory structure, can be up to 1536 characters

**Command mode**

Privileged EXEC mode

**help**

Use this command to display a description of the interactive help system.

**Syntax**

```
help
```

**Command mode**

User EXEC  
 Privileged EXEC mode  
 Global configuration mode  
 Interface configuration mode

**history**

Use this command to list the commands that you have entered during the current session.

**Syntax**

```
history
```

**Command mode**

Privileged EXEC mode

**install**

**Syntax**

```
install
```

**Command mode**

Privileged EXEC mode

**logout**

Use this command to log out of the current NNCLI, Telnet, or rLogin session from any mode, and return to the main console menu.

**Syntax**

```
logout
```

**Command mode**

User EXEC mode  
Privileged EXEC mode  
Global configuration mode  
Interface configuration mode

**mkdir**

Use this command to create a directory.

**Syntax**

```
mkdir <dir>
```

where

**dir** specifies the directory name with a value range of 1 to 99 characters.

**Command mode**

Privileged EXEC mode

**monitor**

Use these **monitor** commands to monitor MLT or port statistics.

**Syntax**

<pre>monitor mlt error collision [&lt;mlt_id&gt;]</pre>
<pre>monitor mlt error main [&lt;mlt_id&gt;]</pre>
<pre>monitor mlt stats interface main [&lt;mlt_id&gt;]</pre>
<pre>monitor mlt stats interface utilization [&lt;mlt_id&gt;]</pre>

monitor ports error collision [from <slot/port>]
monitor ports error extended [from <slot/port>]
monitor ports error main [from <slot/port>]
monitor ports stats interface extended [from <slot/port>]
monitor ports stats interface main [from <slot/port>]
monitor ports stats interface utilization [from <slot/port>]
monitor ports stats rmon [from <slot/port>]
monitor ports stats stp [from <slot/port>]

### Command mode

Privileged EXEC mode

## monitor-stats

Use this command to configure the duration and interval of the **monitor** commands.

### Syntax

```
monitor-stats
```

### Parameters

This command includes the following options:

<b>monitor-stats</b>	
<b>followed by:</b>	
<b>duration &lt;integer&gt;</b>	<p>Sets the length of the monitor period. To clear the display, type Ctrl/L.</p> <ul style="list-style-type: none"> <li>• <b>integer</b> is an integer value with a range of 1 to 1800 seconds. The default is 300 seconds.</li> </ul>
<b>interval &lt;integer&gt;</b>	<p>Sets the frequency of the update interval. To clear the display, type Ctrl/L.</p> <ul style="list-style-type: none"> <li>• <b>integer</b> is an integer value with a range of 1 to 600 seconds. The default is 5 seconds.</li> </ul>

### Command mode

Global configuration mode

## more

Use this command to display the contents of a file one page at a time.

### Syntax

```
more <file> [type]
```

where:

- **file** Specifies the device and file name in one of the following formats:
  - [a.b.c.d:] <file>
  - /pcmcia/ <file>
  - /flash/ <file>
- The range of values is 1 to 1536 characters.
- **type** specifies the file type, either ASCII or Binary. This is an optional parameter.

### Command mode

Privileged EXEC mode

## mv

Use this command to move or rename a file or directory. This command can be used with a wildcard pattern. You cannot use the **mv** command to move a file between two devices. Use the **cp** or the **copy** command instead.

### Syntax

```
mv <old_filename> <new_filename>
```

where:

- **old\_filename** specifies the old device and file name in one of the following formats:
  - /pcmcia/ <file>
  - /flash/ <file>
- The range of values is 1 to 1536 characters.
- **new\_filename** specifies the new file name. The range of values is 1 to 99 characters.

### Command mode

Privileged EXEC mode

## pcmcia-stop

This command enables you to terminate access to the PCMCIA card.

**Syntax**

```
pcmcia-stop
```

**Command mode**

Privileged EXEC mode

**peer**

Use this command to access the standby CPU with telnet or rlogin. This command can make changes to the standby CPU without reconnecting to the console port on that module.

**Syntax**

```
peer <operation>
```

where

**operation** specifies the type of session access. The options are **telnet** or **rlogin**.

**Note:** You must set an rlogin access policy on the standby CPU before you can use the rlogin peer command to access the standby from the master CPU. To set an access policy on the standby CPU, connect a terminal to the Console port on the standby CPU.

**Command mode**

Privileged EXEC mode

**ping**

Use this command to test the network connection to another network device. The **ping** command sends an Internet Control Message Protocol (ICMP) packet or echo message from the switch to the target device. If the device receives the packet, it sends a ping reply. When the switch receives the reply, it displays a message indicating that the specified IP address is alive. If no reply is received, a message indicates that the address is not responding.

**Syntax**

```
ping <ipaddr>
```

where

**ipaddr** is the IP address of the other network device.

**Parameters**

This command includes the following options:

<b>ping &lt;ipaddr&gt;</b>	
<b>followed by:</b>	
[datasize <value> ]	Specifies the size of the ping data. The range of <b>value</b> is 16 to 4076 bytes.
[count <value> ]	Specifies the number of times to ping. The range of <b>value</b> is 1 to 9999, with a default of 1.
[-s]	Specifies a continuous ping (with an interval of -I).
[-I <value> ]	Specifies the interval between transmissions in seconds. The range of <b>value</b> is 1 to 60.
[-t <value> ]	Specifies the no-answer timeout value in seconds. The range of <b>value</b> is 1 to 120.
[-d]	Sets ping debug mode. In debug mode, the ping reply includes additional information about the device pinged.

**Command mode**

Privileged EXEC mode

**pwd**

Use this command to print the current working directory path in the file system.

**Syntax****pwd****Command mode**

Privileged EXEC mode

**reload**

Use this command to reset the switch. When you reset the switch, the most recently saved configuration file is used to reload the system parameters.

**Syntax****reload [-y]**

where **-y** skips the information prompt. If you omit this option, the system prompts you to confirm the action before the switch performs the reload.

**Command mode**

Privileged EXEC mode

## rename

Use this command to move or rename a file or directory. This command can be used with a wildcard pattern.

### Syntax

```
rename <old> <new>
```

where:

- **old** specifies the old device and file name in one of the following formats:

- /pcmcia/ <file>
- /flash/ <file>

The range of values is 1 to 1536 characters.

- **new** specifies the new device and file name.

The range of values is 1 to 99 characters

### Command mode

Privileged EXEC mode

## rlogin

Use this command from Privileged EXEC mode to allow the login of a remote device.

### Syntax

```
rlogin <ipaddr>
```

where

**ipaddr** specifies the IP address of the remote device in the format a.b.c.d.

### Command mode

Privileged EXEC mode

## rlogin-sessions

Use this command from Global configuration mode to specify the number of rlogin sessions.

### Syntax

```
rlogin-sessions <sessions>
```

where

**sessions** specifies the number of rlogin sessions. The valid values are 0 to 8.

**Command mode**

Global configuration mode

**rsh**

Use this command to execute a shell command on a remote device.

**Syntax**

```
rsh <ipaddr> -l <value> <cmd>
```

where:

- **ipaddr** specifies the IP address of the remote device in the format a.b.c.d.
- **value** specifies the user login name. The range of values is a string of 0 to 1536 characters.
- **cmd** specifies the command to execute on the remote host. The range of values is a string of 0 to 1536 characters.

**Command mode**

Privileged EXEC mode

**save**

Use this command to save the running configuration to a selected file.

**Syntax**

```
save <savetype> [<file> <value>] [<standby> <value>] [<backup> <value>]
```

where:

- **savetype** specifies the type of file to save; options are **config**, **bootconfig**, **log**, and **trace**.
- **file <value>** specifies the file name in one of the following formats:
  - [a.b.c.d:] <file>
  - /pcmcia/ <file>
  - /flash/ <file>

The file name, including the directory structure, can be up to 99 characters.

- **standby <value>** saves the specified file name to the standby CPU.
- **backup <value>** saves the specified file name and identifies the file as a backup file.

**Command mode**

Privileged EXEC mode

**show running-config**

Use this command to display the running system information.

**Syntax**`show running-config`**Command mode**

Privileged EXEC mode

**source**

Use this command to merge a configuration script file into the running configuration without having to reboot the switch.

**Syntax**`source <file>`

where:

- `file` specifies the device and file name of the new configuration file in one of the following formats:
  - `[a.b.c.d:] <file>`
  - `/pcmcia/ <file>`
  - `/flash/ <file>`

The range of values is 1 to 1536 characters.

**Parameters**

This command includes the following options:

<code>source &lt;file&gt;</code>	
<b>followed by:</b>	
<code>[debug]</code>	Provides a debug script output.
<code>[stop]</code>	Stops the script when it finds an error in the file.
<code>[syntax]</code>	Verifies the script's syntax.

**Command mode**

Privileged EXEC mode

**sys-action**

This command resets system functions.

**Syntax****sys-action****Parameters**

This command includes the following options:

<b>sys-action</b>	
<b>followed by:</b>	
<b>cpuswitchover</b>	Resets the switch to change over to the backup CPU.
<b>resetconsole</b>	Reinitializes the hardware Universal Asynchronous Receiver/Transmitter (UART) drivers. Use this command only if the console connection is hung.
<b>resetcounters</b>	Resets all the statistics counters in the switch to zero.

**Command mode**

Privileged EXEC mode

**telnet**

Use this command from Privileged EXEC mode to set up a Telnet session to a remote device, for example, to the standby CPU.

**Syntax****telnet [ <ipaddr> ]**

where

**ipaddr** is an optional parameter that specifies the IP address {a.b.c.d} of the remote device.**Command mode**

Privileged EXEC mode

**telnet-access**

Use this command from Global configuration mode to set the number of seconds to wait for a Telnet login before closing the connection or to change the allowable number of inbound Telnet sessions.

**Syntax****telnet-access {login-timeout <seconds> | sessions <sessions> }**

where:

- **seconds** is the number of seconds to wait for a Telnet login before closing the connection. The valid range is 30 to 65535 seconds.

- **sessions** is the number of inbound Telnet sessions that you can have. The valid range is 0 to 8 sessions.

### **Command mode**

Global configuration mode

## **test**

Use this command to perform a loopback test or to stop a currently running loopback test.

### **Syntax**

```
test {loopback <slot/port> | stop}
```

where

**slot/port** specifies the ports for which you are entering the command in the form portlist {slot/port[-slot/port][, ...]}.

### **Command mode**

Privileged EXEC mode

## **test**

Use this command to set all interfaces or the specified interface(s) in testing mode.

### **Syntax**

```
test [port <slot/port> ]
```

where

**slot/port** specifies the ports for which you are entering the command in the form portlist {slot/port[-slot/port][, ...]}.

### **Command mode**

Interface configuration mode

## **trace**

Use this command to display the status of the switch at any given time.

### **Syntax**

```
trace
```

### **Parameters**

This command includes the following options:

<b>trace</b>	
<b>followed by:</b>	
<b>clear</b>	Clears the trace file.
<b>filter</b>	Filters trace messages.
<b>grep</b>	Performs a comparison of trace messages.
<b>level &lt;modid&gt; [ &lt;level&gt; ]</b>	<p>Displays the trace level on a software module for the specified module ID when the optional <b>level</b> parameter is omitted. The optional <b>level</b> parameter specifies trace levels.</p> <ul style="list-style-type: none"> <li>• 0 = Disabled</li> <li>• 1 = Very terse</li> <li>• 2 = Terse</li> <li>• 3 = Verbose</li> <li>• 4 = Very verbose</li> </ul>
<b>modid-list</b>	Displays the module ID numbers which can be traced.
<b>off</b>	Disables tracing on a module.
<b>route-policy</b>	Traces a route policy.
<b>screen [ &lt;setting&gt; ]</b>	Enables or disables displaying the trace file. The <b>setting</b> value is either <b>on</b> or <b>off</b> .
<b>slot</b>	Specifies the line card slot number, from 1 to 10.

### Command mode

Privileged EXEC mode

### trace auto-enable

Use this command to configure the switch to automatically enable a trace in the event CPU utilization reaches a pre-defined value.

#### Syntax

```
trace auto-enable
```

#### Parameters

This command includes the following parameters:

<b>trace auto-enable</b>	
<b>followed by:</b>	
<b>add-module &lt;modid&gt; &lt;level&gt;</b>	<p>Adds a module to be traced by the trace auto-enable feature.</p> <ul style="list-style-type: none"> <li>• <b>modid</b> identifies the module that you want to add. For example, 3 = Port Manager, 20 = Topology Discovery. The valid range is 0 to 66. For a list of valid module IDs, enter <b>trace level ?</b>.</li> <li>• <b>level</b> identifies the level of detail you want in the trace. For example, 0 = Disabled, 1 = Very Terse. The valid range is 0 to 7.</li> </ul>
<b>auto-trace &lt;enable disable&gt;</b>	Enables or disables auto-trace. The default value is disable.
<b>high-percentage &lt;percent&gt;</b>	<p>Specifies the CPU utilization percentage above which auto trace must be enabled.</p> <ul style="list-style-type: none"> <li>• <b>percent</b> is a value from 60 to 100. The default is 90.</li> </ul>
<b>high-track-duration &lt;seconds&gt;</b>	<p>Specifies the time in seconds to monitor CPU utilization before triggering a trace.</p> <ul style="list-style-type: none"> <li>• <b>seconds</b> is a value from 3 to 10. The default is 5.</li> </ul>
<b>low-percentage &lt;percent&gt;</b>	<p>Specifies the CPU utilization percentage below which auto-trace should be disabled.</p> <ul style="list-style-type: none"> <li>• <b>percent</b> is a value from 50 to 90. The default is 75.</li> </ul>

<b>trace auto-enable</b>	
<b>followed by:</b>	
<b>low-track-duration &lt;seconds&gt;</b>	<p>Specifies the time, in seconds, to monitor CPU utilization before disabling the trace.</p> <ul style="list-style-type: none"> <li>• <b>seconds</b> is a value from 3 to 10. The default is 5.</li> </ul>
<b>remove-module &lt;modid&gt;</b>	<p>Removes a module from automatic tracing.</p> <ul style="list-style-type: none"> <li>• <b>modid</b> identifies the module for which you want to disable auto-trace. For example, 3 = Port Manager, 20 = Topology Discovery. The valid range is 0 to 66. For a list of valid module IDs, enter <b>trace level ?</b>.</li> </ul>

**Note:** The enabling or disabling of auto-trace is not saved to the configuration file. When the Ethernet Routing Switch 8300 reboots, auto-trace functionality is disabled.

### Command mode

Privileged EXEC mode

## traceroute

Use this command to trace the route to a remote host. *traceroute* is a valuable tool for troubleshooting because it shows all the routes that are used or indicates that the remote network cannot be reached.

### Syntax

```
traceroute <ipaddr> [ <datasize> ] [-m <value>] [-p <value>]
[ -q <value> ] [-w <value>] [-v]
```

where:

- **ipaddr** is the IP address {a.b.c.d} of the remote host.
- **datasize** is the size of the probe packet (1 to 1464).
- **-m <value>** is maximum time-to-live (TTL) value (1 to 255).
- **-p <value>** is the base UDP port number (0 to 65535).
- **-q <value>** is the number of probes per TTL (1 to 255).
- **-w <value>** is the wait time per probe (1 to 255).
- **-v** is the verbose mode (showing all).

**Command mode**

Privileged EXEC mode

**write memory**

Use this command to save the running configuration to memory

**Syntax**

```
write memory
```

**Command mode**

Privileged EXEC mode



# Bootconfig commands

This chapter describes NNCLI boot configuration commands and their parameters.

<b>Bootconfig Command</b>
<a href="#">"boot choice license-file" (page 76)</a>
<a href="#">"bootconfig choice config-file" (page 77)</a>
<a href="#">"bootconfig choice image-file" (page 78)</a>
<a href="#">"bootconfig cli more" (page 78)</a>
<a href="#">"no bootconfig cli more" (page 79)</a>
<a href="#">"bootconfig cli prompt" (page 79)</a>
<a href="#">"bootconfig cli rlogin-sessions" (page 79)</a>
<a href="#">"bootconfig cli screenlines" (page 79)</a>
<a href="#">"bootconfig cli telnet-sessions" (page 80)</a>
<a href="#">"bootconfig cli timeout" (page 80)</a>
<a href="#">"bootconfig delay" (page 80)</a>
<a href="#">"bootconfig flags" (page 81)</a>
<a href="#">"no bootconfig flags" (page 83)</a>
<a href="#">"bootconfig flags autoboot" (page 85)</a>
<a href="#">"no bootconfig flags autoboot" (page 85)</a>
<a href="#">"bootconfig flags block-snmp" (page 85)</a>
<a href="#">"no bootconfig flags block-snmp" (page 86)</a>
<a href="#">"bootconfig flags daylight-saving-time" (page 86)</a>
<a href="#">"no bootconfig flags daylight-saving-time" (page 86)</a>
<a href="#">"bootconfig flags debug-config" (page 86)</a>
<a href="#">"no bootconfig flags debug-config" (page 86)</a>
<a href="#">"bootconfig flags debugmode" (page 87)</a>
<a href="#">"no bootconfig flags debugmode" (page 87)</a>
<a href="#">"bootconfig flags factorydefaults" (page 87)</a>

<b>Bootconfig Command</b>
"no bootconfig flags factorydefaults" (page 87)
"bootconfig flags ftpd" (page 88)
"no bootconfig flags ftpd" (page 88)
"bootconfig flags info" (page 88)
"bootconfig flags logging" (page 88)
"no bootconfig flags logging" (page 89)
"bootconfig flags nncli" (page 89)
"no bootconfig flags nncli" (page 89)
"bootconfig flags reboot" (page 89)
"no bootconfig flags reboot" (page 90)
"bootconfig flags rlogind" (page 90)
"no bootconfig flags rlogind" (page 90)
"bootconfig flags savetostandby" (page 90)
"no bootconfig flags savetostandby" (page 90)
"bootconfig flags telnetd" (page 91)
"bootconfig flags telnetd" (page 91)
"no bootconfig flags telnetd" (page 91)
"bootconfig flags tftpd" (page 91)
"no bootconfig flags tftpd" (page 91)
"bootconfig flags trace-logging" (page 91)
"no bootconfig flags trace-logging" (page 92)
"bootconfig flags verify-config" (page 92)
"no bootconfig flags verify-config" (page 92)
"bootconfig flags watchdog" (page 92)
"no bootconfig flags watchdog" (page 93)
"bootconfig host ftp-debug" (page 93)
"no bootconfig host ftp-debug" (page 93)
"bootconfig host password" (page 93)
"bootconfig host password" (page 93)
"bootconfig host tftp-debug" (page 94)
"no bootconfig host tftp-debug" (page 94)
"bootconfig host tftp-hash" (page 94)
"no bootconfig host tftp-hash" (page 94)
"bootconfig host tftp-rexmit" (page 95)
"bootconfig host tftp-timeout" (page 95)

<b>Bootconfig Command</b>
"bootconfig host user" (page 95)
"bootconfig master" (page 96)
"bootconfig master" (page 96)
"bootconfig net autonegotiate" (page 96)
"bootconfig net autonegotiate" (page 96)
"no bootconfig net autonegotiate" (page 96)
"bootconfig net bootp" (page 97)
"no bootconfig net bootp" (page 97)
"bootconfig net fullduplex" (page 97)
"no bootconfig net fullduplex" (page 98)
"bootconfig net ip" (page 98)
"bootconfig net restart" (page 99)
"boot net route" (page 100)
"bootconfig net speed" (page 100)
"bootconfig net tftp" (page 101)
"bootconfig sio" (page 102)
"bootconfig sio baud" (page 103)
"bootconfig sio 8databits" (page 103)
"no bootconfig sio 8databits" (page 103)
"bootconfig sio disable" (page 104)
"bootconfig sio enable" (page 104)
"bootconfig sio info" (page 104)
"bootconfig sio mode" (page 104)
"bootconfig sio mtu" (page 105)
"bootconfig sio my-ip" (page 105)
"bootconfig sio peer-ip" (page 106)
"bootconfig sio pppfile" (page 106)
"bootconfig sio restart" (page 107)
"bootconfig sio slip-compression" (page 107)
"no bootconfig sio slip-compression" (page 107)
"bootconfig sio slip-rx-compression" (page 108)
"no bootconfig sio slip-rx-compression" (page 108)
"show bootconfig" (page 108)
"show bootconfig choice" (page 109)
"show bootconfig cli" (page 109)

<b>Bootconfig Command</b>
<a href="#">"show bootconfig config" (page 109)</a>
<a href="#">"show bootconfig flags" (page 110)</a>
<a href="#">"show bootconfig host" (page 110)</a>
<a href="#">"show bootconfig info" (page 110)</a>
<a href="#">"show bootconfig master" (page 110)</a>
<a href="#">"show bootconfig net" (page 110)</a>
<a href="#">"show bootconfig sio" (page 111)</a>
<a href="#">"show bootconfig tz" (page 111)</a>

## boot choice license-file

This command loads the license file to the chassis.

### Syntax

boot choice <boot choice> license-file <file>

### Parameters

This command includes the following parameters:

<b>boot followed by:</b>	
<b>choice&lt;boot choice&gt;</b>	Specifies the order in which the specified boot path is accessed when the switch is rebooted: primary, secondary, or tertiary.
<b>license-file &lt;file&gt;</b>	The source can be Flash memory, a PCMCIA card, or a remote TFTP server. <ul style="list-style-type: none"> <li>• /flash/&lt;file_name&gt;</li> <li>• /pcmcia/&lt;file_name&gt;</li> <li>• &lt;a.b.c.d.&gt;:&lt;file_name&gt;</li> </ul>

### Command mode

Global configuration mode

## bootconfig bootp

Use this command to set or clear the bootp CLI configuration commands.

### Syntax

bootconfig bootp

### Parameters

This command includes the following options:

<b>bootconfig bootp</b>	
-------------------------	--

**followed by:**

<b>image-name &lt;name&gt; [ &lt;slot&gt; ]</b>	Set or clear the bootp CLI configuration commands.
---	--

- **name** is the bootfile to set or clear. If the name is set as default, then the configuration will be cleared.
- **slot** is slot number to use for the bootfile. Acceptable values range from 1 to 10.

## Command mode

Global configuration mode

## bootconfig choice config-file

Use this command to select runtime and boot configuration file choices or change the order in which the boot sources (flash and PCMCIA card) are accessed.

### Syntax

```
bootconfig choice <boot-choice> config-file <file>
```

### Parameters

This command includes the following options:

<b>bootconfig choice</b>	
<b>followed by:</b>	
<b>&lt;boot-choice&gt;</b>	Specifies the order in which the selected boot device is accessed when you reboot the switch.  The options are: <b>primary</b> , <b>secondary</b> , and <b>tertiary</b> . The default order is to access the PCMCIA card first, and then the onboard flash.
<b>config-file &lt;file&gt;</b>	Specifies the boot configuration device and file name. The range of values is up to 256 characters including the path.

## Command mode

Global configuration mode

## bootconfig choice image-file

Use this command to select runtime and boot image file choices or change the order in which the boot sources (flash and PCMCIA card) are accessed.

### Syntax

```
bootconfig choice <boot-choice> image-file <file>
[config-file <file> ]
```

### Parameters

This command includes the following options:

<b>bootconfig choice</b>	
<b>followed by:</b>	
<boot-choice>	Specifies the order in which the selected boot device is accessed when you reboot the switch.  The options are: <b>primary</b> , <b>secondary</b> , and <b>tertiary</b> . The default order is to access the PCMCIA card first, and then the onboard flash.
image-file <file>	Specifies the boot image device and file name.  The range of values is up to 256 characters including the path.
[config-file <file> ]	Specifies the boot configuration device and file name. The range of values is up to 256 characters including the path.

### Command mode

Global configuration mode

## bootconfig cli more

Use this command to set the output display for the Command Line Interface (CLI) to one line at a time.

### Syntax

```
bootconfig cli more
```

### Command mode

Global configuration mode

## **no bootconfig cli more**

Use this command to set the output display for the Boot Monitor Command Line Interface (CLI) to continuous scrolling.

### **Syntax**

```
no bootconfig cli more
```

### **Command mode**

Global configuration mode

## **bootconfig cli prompt**

Use this command to change the Boot Monitor prompt for the Command Line Interface (CLI) to the defined string.

### **Syntax**

```
bootconfig cli prompt <value>
```

where

**<value>** specifies the prompt text. The range of values is an ASCII string of 1 to 32 characters.

**Note:** Enclose the string in quotation marks if it has spaces between characters.

### **Command mode**

Global configuration mode

## **bootconfig cli rlogin-sessions**

Use this command to specify the allowable number of inbound remote login sessions to the Boot Monitor Command Line Interface (CLI).

### **Syntax**

```
bootconfig cli rlogin-sessions <value>
```

where

**<value>** specifies the allowable number of remote login sessions. The range of values is 0 to 8. The default is 8.

### **Command mode**

Global configuration mode

## **bootconfig cli screenlines**

Use this command to specify the number of lines in the output display for the Boot Monitor Command Line Interface (CLI).

### Syntax

```
bootconfig cli screenlines <value>
```

where

<value> specifies the number of lines in the output display. The range of values is 1 to 64. The default is 23.

### Command mode

Global configuration mode

## bootconfig cli telnet-sessions

Use this command to specify the allowable number of inbound telnet sessions to the Boot Monitor Command Line Interface (CLI).

### Syntax

```
bootconfig cli telnet-sessions <value>
```

where

<value> specifies the allowable number of telnet sessions. The range of values is 0 to 8. The default is 8.

### Command mode

Global configuration mode

## bootconfig cli timeout

Use this command to specify the idle timeout period before automatic logout for Command Line Interface (CLI) sessions.

### Syntax

```
bootconfig cli timeout <seconds>
```

where

<seconds> specifies the timeout period in seconds. The range of values is 0 to 65536.

### Command mode

Global configuration mode

## bootconfig delay

Use this command to set the number of seconds a standby CPU should wait (delay) before trying to become the master CPU for booting the switch. This command applies only during a cold start and does not apply to a failover start.

## Syntax

```
bootconfig delay <seconds>
```

where

<seconds> specifies the number of seconds of delay. The default range is 0-255 seconds.

## Command mode

Global configuration mode

# bootconfig flags

Use this command to set system flags. You enable or disable access services by setting flags. Changes to certain flags (factorydefaults, ftpd, tftpd, wdt) take effect only after you save changes to the boot configuration file and reset the switch.

## Syntax

```
bootconfig flags
```

## Parameters

This command includes the following options:

<b>bootconfig flags</b>	
<b>followed by:</b>	
<b>autoboot</b>	Sets the switch to automatically run the run-time image after being reset. Setting to no autoboot is useful for some debugging tasks. The default is <b>autoboot</b> .
<b>block-snmp</b>	Blocks access to the SNMP protocol. The default is no blocking.
<b>daylight-saving-time</b>	Enables Daylight Saving Time on the switch. The default is disabled.
<b>debug-config</b>	Enables run-time debugging of the configuration file. The default is no run-time debugging.
<b>debugmode</b>	Stops switch in debug mode following a fatal error. Debug mode provides information equivalent to the <b>trace</b> commands. A list of options is displayed that allows you to select a software module to debug. The default is no <b>debugmode</b> .

<b>bootconfig flags</b>	
<b>followed by:</b>	
<b>factorydefaults</b>	Sets the runtime switch configuration to factory default settings. The default is to reset.
<b>ftpd</b>	Enables FTP server on the switch. To enable FTP, make sure the <b>no bootconfig flags tftp</b> command is set. The default is no FTP.
<b>jumboframe</b>	Enables jumbo frames. The default is no jumbo frames.
<b>logging</b>	Enables system logging to a file on the PCMCIA card. The default is system logging.
<b>nncli</b>	Enables NNCLI services on a switch.  <b>Note:</b> Ethernet Routing Switch Command Line Interface (CLI) services are provided when NNCLI is disabled.
<b>reboot</b>	Enables the automatic reboot on a fatal error. The default is to reboot. This command is equivalent to the <b>debugmode</b> command.
<b>rlogind</b>	Enables the rlogin/rsh server. The default is disabled.
<b>savetostandby</b>	Saves the config/bootconfig setup to a standby CPU, if one is available. The default is disabled.
<b>sshd</b>	Enables the secure shell (SSH) daemon. The default is disabled.
<b>telnetd</b>	Enables the Telnet server. The default is disabled.
<b>tftp</b>	Enables the TFTP server. The default is disabled.
<b>trace-logging</b>	Enables system tracing to a file on the PCMCIA card. The default is disabled.

<b>bootconfig flags</b>	
<b>followed by:</b>	
<b>verify-config</b>	Enables syntax checking of the configuration file and prevents execution of the file if an error is found. The factory default configuration file is loaded instead. The default is enabled.
<b>wdt</b>	Enables the hardware watchdog timer, which monitors a hardware circuit. The watchdog timer reboots the switch based on software errors. The default is enabled.

## Command mode

Global configuration mode

## no bootconfig flags

Use this command to set system flags. You enable or disable access services by setting flags. Changes to certain flags (factorydefaults, ftpd, tftpd, wdt) take effect only after you save changes to the boot configuration file and reset the switch.

### Syntax

```
no bootconfig flags
```

### Parameters

This command includes the following options:

<b>no bootconfig flags</b>	
<b>followed by:</b>	
<b>autoboot</b>	Sets the switch to automatically stop at the monitor prompt after being reset. Setting to no autoboot is useful for some debugging tasks. The default is <b>autoboot</b> .
<b>block-snmp</b>	Unblocks access to the SNMP protocol. To use this command, disable SSH secure mode first.
<b>daylight-saving-time</b>	Disables Daylight Saving Time on the switch.

<b>no bootconfig flags</b>	
<b>followed by:</b>	
<b>debugmode</b>	Automatically reboots the switch following a fatal error. The default is <b>no debugmode</b> .
<b>debug-config</b>	Disables run-time debugging of the configuration file.
<b>factorydefaults</b>	Disables reset of the switch configuration to factory default settings.
<b>ftpd</b>	Disables FTP server on the switch.
<b>jumboframe</b>	Enables jumbo frames. The default is no jumbo frames.
<b>logging</b>	Disables system logging to a file on the PCMCIA card.
<b>nncli</b>	Disables NNCLI services on a switch.  <b>Note:</b> Ethernet Routing Switch Command Line Interface (CLI) services are provided when NNCLI is disabled.
<b>reboot</b>	Disables automatic reboot on fatal errors.
<b>rlogind</b>	Disables the rlogin/rsh server.
<b>sshd</b>	Enables the SSH daemon. The default is disabled.
<b>savetostandby</b>	Disables saving the config/bootconfig setup to a standby CPU, even if one is available.
<b>telnetd</b>	Disables the Telnet server.
<b>tftp</b>	Disables the TFTP server.

<code>no bootconfig flags</code>	
<b>followed by:</b>	
<code>trace-logging</code>	Disables system tracing to a file on the PCMCIA card.
<code>verify-config</code>	Disables syntax checking of the configuration file. Execution of the file occurs even if an error is found.
<code>wdt</code>	Disables the hardware watchdog timer, which monitors a hardware circuit. The watchdog timer reboots the switch based on software errors.

### **Command mode**

Global configuration mode

## **bootconfig flags autoboot**

Use this command to set the switch to automatically run the run-time image after being reset. Setting to `no autoboot` is useful for some debugging tasks. The default is `autoboot`.

### **Syntax**

```
bootconfig flags autoboot
```

### **Command mode**

Global configuration mode

## **no bootconfig flags autoboot**

Use this command to set the switch to automatically stop at the monitor prompt after being reset. Setting to `no autoboot` is useful for some debugging tasks. The default is `autoboot`.

### **Syntax**

```
no bootconfig flags autoboot
```

### **Command mode**

Global configuration mode

## **bootconfig flags block-snmp**

Use this command to block switch access to the SNMP protocol. The default is no blocking.

### **Syntax**

```
bootconfig flags block-snmp
```

**Command mode**

Global configuration mode

**no bootconfig flags block-snmp**

Use this command to allow switch access to the SNMP protocol. To use this command, disable Secure Shell (SSH) secure mode first. The default is no blocking.

**Syntax**

```
no bootconfig flags block-snmp
```

**Command mode**

Global configuration mode

**bootconfig flags daylight-saving-time**

Use this command to enable Daylight Savings Time on the switch. The default is disabled.

**Syntax**

```
bootconfig flags daylight-saving-time
```

**Command mode**

Global configuration mode

**no bootconfig flags daylight-saving-time**

Use this command to disable Daylight Savings Time on the switch. The default is disabled

**Syntax**

```
no bootconfig flags daylight-saving-time
```

**Command mode**

Global configuration mode

**bootconfig flags debug-config**

Use this command to enable run-time debugging of the configuration file. The default is no run-time debugging.

**Syntax**

```
bootconfig flags debug-config
```

**Command mode**

Global configuration mode

**no bootconfig flags debug-config**

Use this command to disable run-time debugging of the configuration file. The default is no run-time debugging.

---

**Syntax**

```
no bootconfig flags debug-config
```

**Command mode**

Global configuration mode

**bootconfig flags debugmode**

Use this command to stop the switch in debug mode following a fatal error. Debug mode provides information equivalent to the `trace` commands. A list of options is displayed that allows you to select a software module to debug. The default is no debug mode.

**Syntax**

```
bootconfig flags debugmode
```

**Command mode**

Global configuration mode

**no bootconfig flags debugmode**

Use this command to automatically reboot the switch following a fatal error. The default is no debug mode.

**Syntax**

```
no bootconfig flags debugmode
```

**Command mode**

Global configuration mode

**bootconfig flags factorydefaults**

Use this command to reset the runtime switch configuration to factory default settings. Changes to the factorydefaults flag take effect only after you save changes to the boot configuration file and reset the switch. The default is to reset.

**Syntax**

```
bootconfig flags factorydefaults
```

**Command mode**

Global configuration mode

**no bootconfig flags factorydefaults**

Use this command to disable reset of the switch boot configuration to factory default settings. Changes to the factorydefaults flag take effect only after you save changes to the boot configuration file and reset the switch. The default is to reset.

**Syntax**

```
no bootconfig flags factorydefaults
```

**Command mode**

Global configuration mode

**bootconfig flags ftpd**

Use this command to enable the FTP (File Transfer Protocol) server on the switch. To enable FTP, ensure that the `no bootconfig flags tftpd` command is set. Changes to the FTP flag take effect only after you save changes to the boot configuration file and reset the switch. The default is no FTP.

**Syntax**

```
bootconfig flags ftpd
```

**Command mode**

Global configuration mode

**no bootconfig flags ftpd**

Use this command to disable the FTP (File Transfer Protocol) server on the switch. Changes to the FTP flag take effect only after you save changes to the boot configuration file and reset the switch. The default is no FTP.

**Syntax**

```
no bootconfig flags ftpd
```

**Command mode**

Global configuration mode

**bootconfig flags info**

Use this command to display information about the current boot configuration flag settings.

```
bootconfig flags info
```

**Command mode**

Global configuration mode

**bootconfig flags logging**

Use this command to enable system logging to a file on the PCMCIA card. The default is system logging.

**Syntax**

```
bootconfig flags logging
```

**Command mode**

Global configuration mode

**no bootconfig flags logging**

Use this command to disable system logging to a file on the PCMCIA card.  
The default is system logging.

**Syntax**

```
no bootconfig flags logging
```

**Command mode**

Global configuration mode

**bootconfig flags nncli**

Use this command to enable NNCLI services on the switch.

**Note:** Ethernet Routing Switch Command Line Interface (CLI) services are provided when NNCLI is disabled.

**Syntax**

```
bootconfig flags nncli
```

**Command mode**

Global configuration mode

**no bootconfig flags nncli**

Use this command to disable NNCLI services on the switch.

**Note:** Ethernet Routing Switch Command Line Interface (CLI) services are provided when NNCLI is disabled.

**Syntax**

```
no bootconfig flags nncli
```

**Command mode**

Global configuration mode

**bootconfig flags reboot**

Use this command to enable the automatic reboot on a fatal error. The default is to reboot.

**Syntax**

```
bootconfig flags reboot
```

**Command mode**

Global configuration mode

**no bootconfig flags reboot**

Use this command to disable the automatic reboot on a fatal error. The default is to reboot.

**Syntax**

```
no bootconfig flags reboot
```

**Command mode**

Global configuration mode

**bootconfig flags rlogind**

Use this command to enable the rlogin/rsh server. The default is disabled.

**Syntax**

```
bootconfig flags rlogind
```

**Command mode**

Global configuration mode

**no bootconfig flags rlogind**

Use this command to disable the rlogin/rsh server. The default is disabled.

**Syntax**

```
no bootconfig flags rlogind
```

**Command mode**

Global configuration mode

**bootconfig flags savetostandby**

Use this command to save the config/bootconfig setup to a standby CPU, if one is available. The default is disabled.

**Syntax**

```
bootconfig flags savetostandby
```

**Command mode**

Global configuration mode

**no bootconfig flags savetostandby**

Use this command to disable saving the config/bootconfig setup to a standby CPU, even if one is available. The default is disabled.

**Syntax**

```
no bootconfig flags savetostandby
```

**Command mode**

Global configuration mode

**bootconfig flags telnetd**

Use this command to enable the Telnet server. The default is disabled.

**Syntax**

```
bootconfig flags telnetd
```

**Command mode**

Global configuration mode

**no bootconfig flags telnetd**

Use this command to disable the Telnet server. The default is disabled.

**Syntax**

```
no bootconfig flags telnetd
```

**Command mode**

Global configuration mode

**bootconfig flags tftp**

Use this command to enable the TFTP (Trivial File Transfer Protocol) server. To enable TFTP, ensure that the **no bootconfig flags ftpd** command is set. Changes to the TFTP flag take effect only after you save changes to the boot configuration file and reset the switch. The default is no TFTP.

**Syntax**

```
bootconfig flags tftp
```

**Command mode****no bootconfig flags tftp**

Use this command to disable the TFTP (Trivial File Transfer Protocol) server. Changes to the TFTP flag take effect only after you save changes to the boot configuration file and reset the switch. The default is no TFTP.

**Syntax**

```
no bootconfig flags tftp
```

**Command mode**

Global configuration mode

**bootconfig flags trace-logging**

Use this command to enable system tracing to a file on the PCMCIA card. The default is disabled.

**Syntax**

```
bootconfig flags trace-logging
```

**Command mode**

Global configuration mode

**no bootconfig flags trace-logging**

Use this command to disable system tracing to a file on the PCMCIA card.  
The default is disabled.

**Syntax**

```
no bootconfig flags trace-logging
```

**Command mode**

Global configuration mode

**bootconfig flags verify-config**

Use this command to enable syntax checking of the configuration file  
and prevent execution of the file, if an error is found. The factory default  
configuration file is loaded instead. The default is disabled.

**Syntax**

```
bootconfig flags verify-config
```

**Command mode**

Global configuration mode

**no bootconfig flags verify-config**

Use this command to disable syntax checking of the configuration file.  
Execution of the file occurs, even if an error is found. The default is disabled.

**Syntax**

```
no bootconfig flags verify-config
```

**Command mode**

Global configuration mode

**bootconfig flags wdt**

Use this command to enable the watchdog timer, which monitors a hardware  
circuit. The watchdog timer reboots the switch based on software errors.  
Changes to the wdt flag take effect only after you save changes to the boot  
configuration file and reset the switch. The default is enabled.

**Syntax**

```
bootconfig flags wdt
```

**Command mode**

Global configuration mode

## **no bootconfig flags wdt**

Use this command to disable the watchdog timer, which monitors a hardware circuit. The watchdog timer reboots the switch based on software errors. Changes to the wdt flag take effect only after you save changes to the boot configuration file and reset the switch. The default is enabled.

### **Syntax**

```
no bootconfig flags wdt
```

### **Command mode**

Global configuration mode

## **bootconfig host ftp-debug**

Use this command to enable the debug mode for FTP/FTPd (File Transfer Protocol) transfers with the remote host login. If you enable debug mode, debug messages are displayed on the management console screen. The default is disabled.

### **Syntax**

```
bootconfig host ftp-debug
```

### **Command mode**

Global configuration mode

## **no bootconfig host ftp-debug**

Use this command to disable the debug mode for FTP/FTPd (File Transfer Protocol) transfers with the remote host login. If you disable the debug mode, debug messages are not displayed on the management console screen. The default is disabled.

### **Syntax**

```
no bootconfig host ftp-debug
```

### **Command mode**

Global configuration mode

## **bootconfig host password**

Use this command to set the password for FTP (File Transfer Protocol) transfers with the remote host. When this password is set, a login with the password is required to perform FTP transfers with the remote host.

**Note:** This password must match the password for the FTP server, or FTP operation fails.

### **Syntax**

```
bootconfig host password <value>
```

where

**value** specifies the password. The range of values is a string of up to 16 characters.

**Command mode**

Global configuration mode

**bootconfig host tftp-debug**

Use this command to enable the debug mode for TFTP (Trivial File Transfer Protocol) transfers with the remote host. If you enable the debug mode, debug messages are displayed on the management console screen. The default is disabled.

**Syntax**

```
bootconfig host tftp-debug
```

**Command mode**

Global configuration mode

**no bootconfig host tftp-debug**

Use this command to disable the debug mode for TFTP (Trivial File Transfer Protocol) transfers with the remote host. If you disable the debug mode, debug messages are not displayed on the management console screen. The default is disabled.

**Syntax**

```
no bootconfig host tftp-debug
```

**Command mode**

Global configuration mode

**bootconfig host tftp-hash**

Use this command to enable TFTP (Trivial File Transfer Protocol) hash bucket display for the remote host. The default is disabled.

**Syntax**

```
bootconfig host tftp-hash
```

**Command mode**

Global configuration mode

**no bootconfig host tftp-hash**

Use this command to disable TFTP (Trivial File Transfer Protocol) hash bucket display for the remote host. The default is disabled.

**Syntax**

```
no bootconfig host tftp-hash
```

**Command mode**

Global configuration mode

**bootconfig host tftp-rexmit**

Use this command to set the TFTP (Trivial File Transfer Protocol) retransmission timeout for remote host.

**Syntax**

```
bootconfig host tftp-rexmit <seconds>
```

where

**seconds** specifies the retransmission timeout in seconds. The range of values is 1 to 2147483647.

**Command mode**

Global configuration mode

**bootconfig host tftp-timeout**

Use this command to set the TFTP (Trivial File Transfer Protocol) timeout for the remote host.

**Syntax**

```
bootconfig host tftp-timeout <seconds>
```

where

**seconds** specifies the timeout in seconds. The range of values is 1 to 2147483647.

**Command mode**

Global configuration mode

**bootconfig host user**

Use this command to set the remote host user login name.

**Syntax**

```
bootconfig host <value>
```

where

**value** specifies the remote user login name. The range of values is a string of up to 16 characters.

**Command mode**

Global configuration mode

**bootconfig master**

Use this command to specify which CPU becomes master when the switch is turned on. The master CPU performs a loopback test to test the switch fabric.

**Syntax**

```
bootconfig master <cpu-slot>
```

where

<cpu-slot><cpu-slot> specifies the module position for the master CPU. The options are slot 5 or slot 6. The default is slot 5.

**Command mode**

Global configuration mode

**bootconfig net autonegotiate**

Use this command to enable autonegotiation for the specified CPU network port. The three network port types are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port. The defaults are:

- **mgmt** - enabled
- **cpu2cpu** - disabled

**Syntax**

```
bootconfig net <cpu-net-port> autonegotiate
```

where

<cpu-net-port> specifies the CPU network port.  
The options are **mgmt**, **cpu2cpu**.

**Command mode**

Global configuration mode

**no bootconfig net autonegotiate**

Use this command to disable autonegotiation for the specified CPU network port. The three network port types are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port. The defaults are:

- **mgmt** - enabled
- **cpu2cpu** - disabled

**Syntax**

```
no bootconfig net <cpu-net-port> autonegotiate
```

where

<cpu-net-port> specifies the CPU network port.  
The options are: **mgmt**, **cpu2cpu**.

### **Command mode**

Global configuration mode

## **bootconfig net bootp**

Use this command to enable the Bootstrap Protocol (Bootp) for the specified CPU network port. The three network port types are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port. The default is enabled for all specified port types.

### **Syntax**

```
bootconfig net <cpu-net-port> bootp
```

where

<cpu-net-port> specifies the CPU network port.  
The options are **mgmt**, **cpu2cpu**.

### **Command mode**

Global configuration mode

## **no bootconfig net bootp**

Use this command to disable the Bootstrap Protocol (Bootp) for the specified CPU network port. The three network port types are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port. The default is enabled for all specified port types.

### **Syntax**

```
no bootconfig net <cpu-net-port> bootp
```

where

<cpu-net-port> specifies the CPU network port.  
The options are: **mgmt**, **cpu2cpu**.

### **Command mode**

Global configuration mode

## **bootconfig net fullduplex**

Use this command to enable the full-duplex mode for the specified CPU network port. The three network port types are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port. The defaults are:

- **mgmt** - disabled
- **cpu2cpu** - enabled

**Note:** Use the `bootconfig net mgmt ip <ipaddr> <mask>` command to assign an IP address to the switch.

### Syntax

```
bootconfig net <cpu-net-port> fullduplex
```

where

`<cpu-net-port>` specifies the CPU network port.  
The options are `mgmt`, `cpu2cpu`.

### Command mode

Global configuration mode

## no bootconfig net fullduplex

Use this command to disable the full-duplex mode for the specified CPU network port. The three network port types are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port. The defaults are:

- `mgmt` - disabled
- `cpu2cpu` - enabled

### Syntax

```
no bootconfig net <cpu-net-port> fullduplex
```

where

`<cpu-net-port>` specifies the CPU network ports.  
The options are: `mgmt`, `cpu2cpu`.

### Command mode

Global configuration mode

## bootconfig net ip

Use this command to assign an IP address and network mask to the specified CPU network port device. The three network port types are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port.

**Note:** Use the `bootconfig net mgmt ip <ipaddr> <mask>` command to assign an IP address to the switch.

### Syntax

```
bootconfig net <cpu-net-port> ip <ipaddr> <mask>  
<cpu-slot value>
```

---

## Parameters

This command includes the following options:

<b>bootconfig net &lt;cpu-net-port&gt; ip</b> <b>followed by:</b>	
<cpu-net-port>	Specifies the CPU network port. The options are: <b>mgmt</b> , <b>cpu2cpu</b> .
<ipaddr> <mask>	Assigns an IP address or mask for the specified port. The options are: <ul style="list-style-type: none"><li>• <b>a.b.c.d/x</b></li><li>• <b>a.b.c.d/x.x.x.x</b></li><li>• <b>default</b> (The default is 0.0.0.0.)</li></ul>
<cpu-slot value>	Specifies the slot position of the 8393SF module. The options are slot 5 or slot 6.  If you do not specify a slot number for the IP address, the IP address is assigned to the currently active management module.

## Command mode

Global configuration mode

## bootconfig net restart

Use this command to restart the specified CPU network port. The three network port types are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port.

**Note:** Use the **bootconfig net mgmt ip <ipaddr> <mask>** command to assign an IP address to the switch.

## Syntax

```
bootconfig net <cpu-net-port> restart
```

where

<cpu-net-port> specifies the CPU network port.  
The options are **mgmt**, **cpu2cpu**.

## Command mode

Global configuration mode

## boot net route

Use this command to set a route for the specified CPU network port. The three network port types are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port.

**Note:** Use the `bootconfig net mgmt ip <ipaddr> <mask>` command to assign an IP address to the switch.

### Syntax

```
boot net <cpu-net-port> route [add|del|net] <netaddr>
<gateway>
```

### Parameters

This command includes the following options:

<code>bootconfig net &lt;cpu-net-port&gt; route</code>	
<b>followed by:</b>	
<cpu-net-port>	Specifies the CPU network port. The options are: <code>mgmt</code> , <code>cpu2cpu</code> .
[add del net]	<p>Performs the selected action on the specified port:</p> <ul style="list-style-type: none"> <li>• Adds the specified route for the selected port.</li> <li>• Deletes the specified route for the selected port.</li> <li>• Changes the specified route for the selected port to a network route.</li> </ul>
<netaddr>	Specifies the IP address of the destination network for the selected port.
<gateway>	Specifies the IP address of the gateway for the selected port.

### Command mode

Global configuration mode

## bootconfig net speed

Use this command to set the connection speed for the specified CPU network port. The three network ports are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port.

**Note:** Use the `bootconfig net mgmt ip <ipaddr> <mask>` command to assign an IP address to the switch.

## Syntax

```
bootconfig net <cpu-net-port> speed
```

## Parameters

This command includes the following options:

<code>bootconfig net &lt;cpu-net-port&gt; speed</code>	
<b>followed by:</b>	
<code>&lt;cpu-net-port&gt;</code>	Specifies the CPU network port. The options are: <code>mgmt</code> , <code>cpu2cpu</code> .
<code>&lt;10   100&gt;</code>	<p>Sets the connection speed to 10 Mb/s or 100 Mb/s. The defaults are:</p> <ul style="list-style-type: none"> <li>• <code>mgmt</code> - 10 Mb/s</li> <li>• <code>cpu2cpu</code> - 100 Mb/s</li> </ul>

## Command mode

Global configuration mode

## bootconfig net tftp

Use this command to specify a TFTP (Trivial File Transfer Protocol) server for the CPU network port. The three network ports are the management port, the CPU port, and the PCMCIA card, if it is acting as a network port.

**Note:** Use the `bootconfig net mgmt ip <ipaddr> <mask>` command to assign an IP address to the switch.

## Syntax

```
bootconfig net <cpu-net-port> tftp <ipaddr>
```

## Parameters

This command includes the following options:

<code>bootconfig net &lt;cpu-net-port&gt; tftp</code>
---

**followed by:**

<code>&lt;cpu-net-port&gt;</code>	Specifies the CPU network port. The options are: <code>mgmt</code> , <code>cpu2cpu</code> .
-----------------------------------	---

<code>&lt;ipaddr&gt;</code>	Specifies the IP address of the TFTP server in the format a.b.c.d.
-----------------------------	--

### Command mode

Global configuration mode

## bootconfig sio

Use this command to configure the CPU serial input/output (sio) port devices.

### Syntax

<code>bootconfig sio [8databits &lt;true false&gt;] [baud &lt;rate&gt; ]</code>
---

`[restart]`

### Parameters

This command includes the following options:

<code>bootconfig sio &lt;cpu-sio-port&gt;</code>
--

**followed by:**

<code>[8databits &lt;true false&gt;]</code>	Specifies the data bits per byte that the software interprets. The options are:
---	---

- `true` (8 data bits per byte)
- `false` (7 data bits per byte)

The default is `false`.

<code>[baud &lt;rate&gt; ]</code>	Specifies the baud rate for the selected port. The default is 9600.
-----------------------------------	---

<code>[restart]</code>	Shuts down and reinitializes the specified CPU serial port.
------------------------	---

**Command mode**

Global configuration mode

**bootconfig sio 8databits**

Use this command to specify that the software interprets eight data bits per byte for the selected CPU serial input/output (sio) port devices. The default is seven data bits per byte.

**Syntax**

```
bootconfig sio 8databits
```

**Command mode**

Global configuration mode

**no bootconfig sio 8databits**

Use this command to specify seven data bits per byte for the software to interpret for the CPU serial input/output (sio) port.

**Syntax**

```
no bootconfig sio 8databits
```

**Command mode**

Global configuration mode

**bootconfig sio baud**

Use this command to specify the baud rate for the selected CPU serial input/output (sio) port.

**Syntax**

```
bootconfig sio baud <rate>
```

**Parameters**

This command includes the following options:

<b>bootconfig sio &lt;cpu-sio-port&gt; baud</b>	
<b>followed by:</b>	
<b>&lt;rate&gt;</b>	Specifies the baud rate for the port. The default is 9600.

**Command mode**

Global configuration mode

## **bootconfig sio disable**

Use this command to disable the selected CPU serial input/output (sio) port.

### **Syntax**

```
bootconfig sio disable
```

### **Command mode**

Global configuration mode

## **bootconfig sio enable**

Use this command to enable the selected CPU serial input/output (sio) port.

### **Syntax**

```
bootconfig sio enable
```

### **Command mode**

Global configuration mode

## **bootconfig sio info**

Use this command to display configuration information about the specified CPU serial input/output (sio) port.

### **Syntax**

```
bootconfig sio info
```

### **Command mode**

Global configuration mode

## **bootconfig sio mode**

Use this command to specify the communication mode the selected CPU serial input/output (sio) port device.

### **Syntax**

```
bootconfig sio mode <ascii|slip|ppp>
```

### **Parameters**

This command includes the following options:

<b>bootconfig sio &lt;cpu-sio-port&gt; mode</b>
---

**followed by:**

<b>&lt;ascii slip ppp&gt;</b>	Specifies the communication mode for the serial port. The default is <b>ascii</b> .  To configure the Console port, set the mode to <b>ascii</b> .  If you are configuring the Modem port, you can set the port to use the same SLIP or PPP communication mode as the modem.
-------------------------------	--

### Command mode

Global configuration mode

## bootconfig sio mtu

Use this command to specify the size of the maximum transmission unit (mtu) for a point-to-point link with the selected CPU serial input/output (sio) port device.

### Syntax

**bootconfig sio mtu <bytes>**

### Parameters

This command includes the following options:

<b>bootconfig sio &lt;cpu-sio-port&gt; mtu</b>
--

**followed by:**

<b>&lt;bytes&gt;</b>	Specifies the mtu size in bytes. The range of values is 0 to 2048. The default is 0.
----------------------	--

### Command mode

Global configuration mode

## bootconfig sio my-ip

Use this command to specify the near-end IP address on a point-to-point link with the selected CPU serial input/output (sio) port device.

**Syntax**

```
bootconfig sio my-ip <ipaddr>
```

**Parameters**

This command includes the following options:

<pre>bootconfig sio &lt;cpu-sio-port&gt; my-ip</pre>
--

**followed by:**

<ipaddr>	Specifies the near-end IP address on a point-to-point link. The default is 0.0.0.0.
----------	---

**Command mode**

Global configuration mode

**bootconfig sio peer-ip**

Use this command to specify the peer IP address on a point-to-point link with the selected CPU serial input/output (sio) port device.

**Syntax**

```
bootconfig sio peer-ip <ipaddr>
```

**Parameters**

This command includes the following options:

<pre>bootconfig sio &lt;cpu-sio-port&gt; peer-ip</pre>
--

**followed by:**

<ipaddr>	Specifies the peer IP address on a point-to-point link. The default is 0.0.0.0.
----------	---

**Command mode**

Global configuration mode

**bootconfig sio pppfile**

Use this command to specify which file to use for PPP initialization parameters for the selected CPU serial input/output (sio) port.

**Syntax**

```
bootconfig sio pppfile <file>
```

---

**Parameters**

This command includes the following options:

<b>bootconfig sio &lt;cpu-sio-port&gt; pppfile</b>
--

<b>followed by:</b>
---------------------

<b>&lt;file&gt;</b>	Specifies which file to use for PPP initialization parameters. The options are:
---------------------	---

- **a.b.c.d: <file>**
- **/pcmcia/ <file>**
- **/flash/ <file>**

**Command mode**

Global configuration mode

**bootconfig sio restart**

Use this command to shut down and reinitialize the selected CPU serial input/output (sio) port.

**Syntax**

```
bootconfig sio restart
```

**Command mode**

Global configuration mode

**bootconfig sio slip-compression**

Use this command to enable TCP/IP header compression for the selected CPU serial input/output (sio) port. The default is disabled.

**Syntax**

```
bootconfig sio slip-compression
```

**Command mode**

Global configuration mode

**no bootconfig sio slip-compression**

Use this command to disable TCP/IP header compression for the selected CPU serial input/output (sio) port. The default is disabled.

**Syntax**

```
no bootconfig sio slip-compression
```

**Command mode**

Global configuration mode

**bootconfig sio slip-rx-compression**

Use this command to enable TCP/IP header compression on the receive packet for the selected CPU serial input/output (sio) port. The default is disabled.

**Syntax**

```
bootconfig sio slip-rx-compression
```

**Command mode**

Global configuration mode

**no bootconfig sio slip-rx-compression**

Use this command to disable TCP/IP header compression on the receive packet for the selected CPU serial input/output (sio) port. The default is disabled.

**Syntax**

```
no bootconfig sio slip-rx-compression
```

**Command mode**

Global configuration mode

**show bootconfig**

Use this command to display the current configuration of the Boot Monitor and the Boot Monitor CLI.

**Syntax**

```
show bootconfig
```

**Parameters**

This command includes the following options:

<b>show bootconfig</b>	
<b>followed by:</b>	
<b>bootp</b>	
<b>choice</b>	Displays the current boot configuration choices.
<b>cli</b>	Displays the current Boot Monitor CLI configuration.

<b>show bootconfig</b>	
<b>followed by:</b>	
<b>config</b>	Displays the current Boot Monitor configuration.
<b>flags</b>	Displays the current flag settings for the switch.
<b>host</b>	Displays the current host configuration.
<b>info</b>	Displays information about the switch boot image.
<b>master</b>	Displays the slot where the Master CPU resides and the settings for the <b>delay</b> and <b>multicast</b> commands.
<b>net</b>	Displays the current configuration of the CPU network ports.
<b>sio</b>	Displays the current configuration of the CPU serial ports.
<b>tz</b>	Displays the switch's current time zone settings.

**Command mode**

Privileged EXEC mode

**show bootconfig choice**

Use this command to display the current boot configuration choices.

**Syntax**`show bootconfig choice`**Command mode**

Privileged EXEC mode

**show bootconfig cli**

Use this command to display the current configuration of the Boot Monitor CLI.

**Syntax**`show bootconfig cli`**Command mode**

Privileged EXEC mode

**show bootconfig config**

Use this command to display the current configuration of the Boot Monitor.

**Syntax**

```
show bootconfig config
```

**Command mode**

Privileged EXEC mode

**show bootconfig flags**

Use this command to display the current flag settings for the switch.

**Syntax**

```
show bootconfig flags
```

**Command mode**

Privileged EXEC mode

**show bootconfig host**

Use this command to display the current configuration of the host.

**Syntax**

```
show bootconfig host
```

**Command mode**

Privileged EXEC mode

**show bootconfig info**

Use this command to display information about the switch boot image.

**Syntax**

```
show bootconfig info
```

**Command mode**

Privileged EXEC mode

**show bootconfig master**

Use this command to display the slot where the Master CPU resides and to display the settings for the **bootconfig delay** and **bootconfig multicast** commands.

**Syntax**

```
show bootconfig master
```

**Command mode**

Privileged EXEC mode

**show bootconfig net**

Use this command to display the current configuration of the CPU network ports.

---

**Syntax**

```
show bootconfig net
```

**Command mode**

Privileged EXEC mode

**show bootconfig sio**

Use this command to display the current configuration of the CPU serial ports.

**Syntax**

```
show bootconfig sio
```

**Command mode**

Privileged EXEC mode

**show bootconfig tz**

Use this command to display the switch's current time zone settings.

**Syntax**

```
show bootconfig tz
```

**Command mode**

Privileged EXEC mode



# System management commands

This chapter describes the NNCLI system management commands and their parameters.

System Management Command
<a href="#">"auto-recover-delay" (page 114)</a>
<a href="#">"default auto-recover-delay" (page 115)</a>
<a href="#">"no auto-recover-delay" (page 115)</a>
<a href="#">"autotopology" (page 115)</a>
<a href="#">"no autotopology" (page 115)</a>
<a href="#">"banner" (page 115)</a>
<a href="#">"no banner" (page 116)</a>
<a href="#">"clock set" (page 116)</a>
<a href="#">"clock-sync-time" (page 117)</a>
<a href="#">"enable" (page 117)</a>
<a href="#">"load-module" (page 118)</a>
<a href="#">"logging" (page 119)</a>
<a href="#">"loginprompt" (page 120)</a>
<a href="#">"no loginprompt" (page 121)</a>
<a href="#">"mgmt-virtual-ip" (page 121)</a>
<a href="#">"no mgmt-virtual-ip" (page 121)</a>
<a href="#">"monitor-stats" (page 122)</a>
<a href="#">"more" (page 122)</a>
<a href="#">"no more" (page 122)</a>
<a href="#">"msg-control" (page 123)</a>
<a href="#">"no msg-control" (page 123)</a>
<a href="#">"mtu" (page 123)</a>
<a href="#">"passwordprompt" (page 123)</a>
<a href="#">"no passwordprompt" (page 124)</a>

System Management Command
"portlock" (page 124)
"prompt" (page 124)
"rlogin-sessions" (page 124)
"screenlines" (page 125)
"show autotopology" (page 125)
"show basic config" (page 125)
"show link-flap-detect" (page 126)
"show logging config" (page 126)
"show logging file" (page 126)
"show log filter" (page 127)
"show slot" (page 127)
"show sys hash-calc mltindex ip dest-mac dest-ip src-mac src-ip src-port mlt" (page 128)
"show sys hash-calc mltindex non-ip dest-mac src-mac src-port mlt" (page 128)
"show sys hash-calc mltindex ip-mcast source group vlan-id src-port mlt" (page 129)
"show sys hash-calc mltindex ip-mcast source group vlan-id src-port mlt" (page 129)
"show sys-info" (page 131)
"show sys perf" (page 131)
"show sys sw" (page 132)
"shutdown" (page 132)
"no shutdown" (page 132)
"sys-action cpuswitchover" (page 132)
"sys-action resetconsole" (page 133)
"sys-action resetcounters" (page 133)
"udpsrc-by-vip" (page 133)
"no udpsrc-by-vip" (page 133)

## auto-recover-delay

Use this command to configure the auto recovery delay timer for ports.

### Syntax

```
auto-recover-delay<5-3600>
```

where

<5-3600> is the auto recovery delay time in seconds. The default is 30.

### **Command mode**

Global configuration mode

## **default auto-recover-delay**

Use this command to set the auto recovery delay timer to default values.

### **Syntax**

```
default auto-recover-delay
```

### **Command mode**

Global configuration mode

## **no auto-recover-delay**

Use this command set the auto recovery delay timer to default values.

### **Syntax**

```
no auto-recovery-delay
```

### **Command mode**

Global configuration mode

## **autotopology**

Use this command to turn the topology feature on. The topology feature generates topology packets used by network management software. When this feature is off, the topology table is not generated. The default is on.

### **Syntax**

```
autotopology
```

### **Command mode**

Global configuration mode

## **no autotopology**

Use this command to turn the topology feature off. The topology feature generates topology packets used by network management software. When this feature is off, the topology table is not generated. The default is on.

### **Syntax**

```
no autotopology
```

### **Command mode**

Global configuration mode

## **banner**

Use this command to add lines of text to the NNCLI login banner.

**Syntax**

```
banner <string>
```

where

**string** specifies the lines of text. The range of values is an ASCII string of 1 to 1024 characters.

**Note:** Enclose the string in quotation marks if it has spaces between characters.

**Parameters**

This command includes the following options:

<b>banner</b>	
<b>followed by:</b>	
custom	Enables the use of the custom banner as defined by <b>banner &lt;banner&gt;</b> .
motd [displaymotd   <motd>]	Enables the display of a Message of the Day (MoTD) following the user login. The MoTD is from 1- 1536 characters.
static	Enables the default Nortel banner.
<banner>	Enables the user of a custom banner defined by the user. The length is from 0- 80 characters.

**Command mode**

Global configuration mode

**no banner**

Use this command to disable the display of a banner following the user login.

**Syntax**

```
no banner <motd> [displaymotd]
```

where

**<motd>** specifies a message from 1- 1536 characters.

**clock set**

Use this command to set the calendar time in the form of hour, minute, second, month, day, and year. You set the time zone using the **bootconfig tz** command at the Global configuration level.

**Syntax**

```
clock set <MMddyyyyhhmmss>
```

---

where

**<MMddyyyyhhmmss>** sets the calendar time in the format month, day, year, hour, minutes, seconds.

Note that you must be logged in as rwa to use this command.

### Command mode

Global configuration mode

## clock-sync-time

Use this command to configure the time interval between synchronizing the real-time and system clocks.

### Syntax

```
clock-sync-time <minutes>
```

where

**minutes** specifies the time interval between synchronizations. The range of values is 15 to 3600 minutes.

### Command mode

Global configuration mode

## enable

Use this command to change the current command mode from Privileged EXEC to Global Config, or, if you execute this command in Global Config mode, to change the password for the enable command.

### Syntax

```
enable
```

In Global configuration mode, the syntax is:

```
enable <password>
```

where

**password** string length is from 1-32 characters.

### Command mode

Global configuration mode

## link-flap-detect

Use this command to configure the control of link state changes.

### Syntax

```
link-flap-detect
```

**Parameters**

This command includes the following parameters:

<b>link-flap-detect</b> <b>followed by:</b>	
<b>auto-port-down</b>	Enables automatic disabling of the port if the link-flap threshold is exceeded. The default is enable.
<b>frequency &lt;frequency&gt;</b>	Sets the number of changes that are allowed during the time specified by the interval command. The frequency range is 1–9999. The default is 10.
<b>interval &lt;interval&gt;</b>	Sets the link-flap-detect interval in seconds. The interval range is 2–600. The default is 60.
<b>send-trap</b>	Enables trap sending to force the port out of service. The default is enable.

**Command mode**

Global configuration mode

**no link-flap-detect auto-port-down**

Use this command to disable the automatic disabling of port.

**Syntax**

```
no link-flap-detect auto-port-down
```

**Command mode**

Global configuration mode

**no link-flap-detect send-trap**

Use this command to disable sending traps.

**Syntax**

```
no link-flap-detect send-trap
```

**command mode**

Global configuration mode

**load-module**

Use this command to dynamically load modules.

## Syntax

```
load-module {<AES> | <3DES> | <DES>}
```

## Parameters

This command includes the following options:

<b>load-module</b>	
<b>followed by:</b>	
<AES> filename	Sets the module ID to AES.
<3DES> filename	Sets the module ID to 3 DES.
<DES> filename	Sets the module ID to DES

## Command mode

Global configuration mode

## logging

Use this command to configure and display the log files for the switch. When you save the `bootconfig flags logging` command in the configuration file, the log entries are written to the `/pcmcia/syslog.txt` file. If the logging flag is not set to true, the entries are stored in memory.

## Syntax

```
logging [clear] [filter <string>] [level <level>]
[logToPCMCIA] [screen <true/false>] [transferFile
<hostID> [<add-ip>|<filename>|<remove-IP>]] [write]
```

## Parameters

This command includes the following options:

<b>logging</b>	
<b>followed by:</b>	
[ <b>clear</b> ]	Erases log file entries.
[ <b>filter &lt;string&gt;</b> ]	Specifies a string to match in the log file.

<b>logging</b>	
<b>followed by:</b>	
<b>[level &lt;level&gt; ]</b>	Shows and sets the logging level. level is one of the following values:  0 = Information; all messages are recorded.  1 = Warning; only warning and more serious messages are recorded.  2 = Error; only error and more serious messages are recorded.  3 = Manufacturing; this parameter is not available for customer use.  4 = Fatal; only fatal messages are recorded.
<b>logToPCMCIA</b>	Starts logging to PCMCIA media.
<b>screen &lt;true false&gt;</b>	Enables (true) or disables (false) screen logging.
<b>[transferFile &lt;hostID&gt; [ &lt;add-IP&gt; &lt;filename&gt;  &lt;remove-IP&gt; ] ]</b>	Sets the remote host you wish to log, where:  <ul style="list-style-type: none"> <li>• <b>add-IP</b> and <b>remove-IP</b> specify the IP address.</li> <li>• <b>filename</b> is a string from 1- 256.</li> </ul>
<b>[write]</b>	Writes an entry to the log file.

### Command mode

Global configuration mode

## loginprompt

Use this command to change the CLI login prompt.

### Syntax

**loginprompt <string>**

where

**<string>** specifies the text for the new CLI login prompt. The range of values is an ASCII string of 1 to 1536 characters.

**Note:** Enclose the string in quotation marks if it has spaces between characters.

### Command mode

Privileged EXEC mode

## no loginprompt

Use this command to disable the default login banner.

### Syntax

```
no loginprompt
```

### Command mode

Privileged EXEC mode

## mgmt-virtual-ip

Use this command to create a virtual management address for the Ethernet Routing Switch 8300. Although each CPU can have its own unique physical IP address, they share a common virtual address. This is helpful when the master CPU fails and the standby CPU comes up. If the virtual IP address is defined, the switch still responds to this address, even when using the backup CPU.

### Syntax

```
mgmt-virtual-ip <ipaddr> <mask>
```

where

<ipaddr> <mask> specifies the IP address and mask that you assign to the virtual management port.

**Note:** Ensure that the virtual IP address is on the same IP subnet as the CPU physical IP address(es).

### Command mode

Global configuration mode

## no mgmt-virtual-ip

Use this command to remove/delete the virtual management IP address.

### Syntax

```
no mgmt-virtual-ip <ipaddr> <mask>
```

where

<ipaddr> <mask> specifies the IP address and mask assigned to the virtual management port.

**Command mode**

Global configuration mode

**monitor-stats**

Use this command to configure and manage the monitor duration (refresh rate).

**Syntax**

```
monitor-stats [duration <integer>] [interval <integer>]
```

**Parameters**

This command includes the following options:

<code>monitor-stats</code>	
<b>followed by:</b>	
<code>[duration &lt;integer&gt;]</code>	Changes the monitoring time duration (refresh rate) for the <code>monitor</code> commands.  <code>duration &lt;integer&gt;</code> specifies the time duration in seconds. The range of values is 1 to 1800. The default is 300.
<code>[interval &lt;integer&gt;]</code>	Changes the monitoring time interval between screen updates set by the <code>monitor</code> commands.  <code>interval &lt;integer&gt;</code> specifies the time duration in seconds. The range of values is 1 to 600. The default is 5.

**Command mode**

Global configuration mode

**more**

Use this command to set the display output to scroll one page at a time.

**Syntax**

```
more
```

**Command mode**

Privileged EXEC mode

**no more**

Use this command to set the display output to continuous scrolling.

---

**Syntax**`no more`**Command mode**

Privileged EXEC mode

**msg-control**

Use this command to enable system message control and suppress duplicate error messages.

**Syntax**`msg-control`**Command mode**

Global configuration mode

**no msg-control**

Use this command to disable the system message control.

**Syntax**`no msg-control`**Command mode**

Global configuration mode

**mtu**

This command is not valid in the Ethernet Routing Switch 8300 since Jumbo Frames are not supported in Release 2.2.

**passwordprompt**

Use this command to change the NNCLI password prompt.

**Syntax**`passwordprompt <string>`

where

`<string>` specifies the text for the CLI password prompt. The range of values is an ASCII string of 1 to 1536 characters.

**Note:** Enclose the string in quotation marks if it has spaces between characters.

**Command mode**

Privileged EXEC mode

**no passwordprompt**

Use this command to disable changing the NNCLI password prompt.

**Syntax**

```
no passwordprompt
```

**Command mode**

Privileged EXEC mode

**portlock**

Use this command to globally turn port locking on or off. To specify the ports to be locked, use the `ethernet <ports> lock` command.

This command enables port locking globally so you can enable or disable per-port locking. Locking a port or ports prevents other users from changing port parameters or modifying port action. Locked ports cannot be modified in any way until the port is first unlocked.

**Syntax**

```
portlock <on|off>
```

**Command mode**

Global configuration mode

**prompt**

Use this command to set the root-level prompt.

**Syntax**

```
prompt <prompt>
```

where

`<prompt>` specifies the text for the root-level prompt. The range of values is an ASCII string of 1 to 255 characters. The default prompt is `Passport-8310`.

**Command mode**

Privileged EXEC mode

**rlogin-sessions**

Use this command to set the allowable number of inbound rlogin/rsh sessions.

**Syntax**

```
rlogin-sessions <nsessions>
```

where

**<nsessions>** specifies the number of sessions. The range of values is 0 to 8. The default is 8.

### Command mode

Global configuration mode

## screenlines

Use this command to set the number of lines in the output display of the terminal screen.

### Syntax

```
screenlines <nlines>
```

where

**<nlines>** specifies the number of lines.  
The range of values is 8 to 64.

### Command mode

Privileged EXEC mode

## show autopology

Use this command to display the topology table. The topology table shows the information that is sent to Optivity network management software for creating network displays.

### Syntax

```
show autopology nmm-table
```

### Command mode

Privileged EXEC mode

## show basic config

Use this command to display information for the auto-recover-delay.

### Syntax

```
show basic config
```

### Command mode

Privileged EXEC mode

## show interfaces GigabitEthernet interface

This command displays the MTU values for all ports on the chassis.

### Syntax

```
show interfaces GigabitEthernet interface [portlist]
```

**Command mode**

User Exec mode

**show link-flap-detect**

Use this command to display the link-flap-detect settings.

**Syntax**

```
show link-flap-detect
```

**Command mode**

Privileged EXEC mode

**show logging config**

Use this command to display the level of information being entered in the log. The levels range from information (INFO), where all messages are entered, to FATAL, where only fatal errors are recorded. The manufacturing (MFG) level is for manufacturing purposes only and not available for customer use.

**Syntax**

```
show logging config
```

**Command mode**

Privileged EXEC mode

**show logging file**

Use this command to display the selected log file.

**Syntax**

```
show logging file [category] [CPU] [name-of-file]
[save-to-file] [severity] [tail]
```

**Parameters**

This command includes the following options:

<b>show logging file</b>	
<b>followed by:</b>	
[category <string> ]	Specifies the category of log file information to display for the <b>show logging</b> command. The range of characters is 0 to 100.
[CPU <integer> ]	Specifies the CPU number for which to display log file information. The range of values is 0 to 25.
[name-of-file <string> ]	Specifies the file for which to display log information. The range of characters is 1 to 99.

<code>show logging file</code>	
<b>followed by:</b>	
<code>[save-to-file &lt;string&gt;]</code>	Specifies the file to save log file information to. The range of characters is 1 to 99.
<code>[severity &lt;string&gt;]</code>	Specifies the severity level for which to display log information. The range of characters is 0 to 25.
<code>[tail]</code>	Specifies displaying the log file in reverse order, with the most recent information first.

**Command mode**

Privileged EXEC mode

**show log filter**

Use this command to display the log filter configuration.

**Syntax**`show log filter`**Command mode**

Privileged EXEC mode

**show running-config**

Use this command to display information about the current switch configuration.

**Syntax**`show running-config`**Command mode**

Privileged EXEC mode

**show slot**

Use this command to display the administrative status of the module.

**Syntax**`show slot <slot-number>`

where

`<slot-number>` specifies the slot number in the chassis. The range of values is 1 to 10.**Note:** Slots are numbered from top to bottom in Ethernet Routing Switch 8300 switches.

**Command mode**

Privileged EXEC mode

**show sys hash-calc mltindex ip dest-mac dest-ip src-mac src-ip src-port mlt**

Use this command to calculate unicast IP traffic distribution.

**Syntax**

```
show sys hash-calc mltindex ip dest-mac
<value>dest-ip <value>src-mac<value>src-ip<value>src-
port,value>mlt<value>
```

**Parameters**

This command includes the following parameters

<code>show sys hash-calc mltindex ip</code>
---

<b>followed by:</b>
---------------------

<code>dest-mac &lt; value&gt;</code>	Specifies the destination MAC address in hexadecimal {0x00:0x00:0x00:0x00:0x00:0x00}.
<code>dest-ip&lt; value&gt;</code>	Specifies the destination IP address {a.b.c.d}
<code>src-mac&lt;value&gt;</code>	Specifies the source MAC address in hexadecimal {0x00:0x00:0x00:0x00:0x00:0x00}.
<code>src-ip&lt;value&gt;</code>	Specifies the source IP address {a.b.c.d}.
<code>src-port &lt;value&gt;</code>	Specifies the ingress port in the format {slot/port}.
<code>mlt&lt;value&gt;</code>	Specifies the MLT ID. Value is an integer in the range of 1 to 31.

**Command mode**

Global configuration mode

**show sys hash-calc mltindex non-ip dest-mac src-mac src-port mlt**

Use this command to calculate unicast non-IP distribution.

**Syntax**

```
show sys hash-calc mltindex non-ip dest_mac
<value>src-mac<value>src-port,value>mlt<value>
```

## Parameters

This command includes the following parameters.

<b>show sys hash-calc mltindex non-ip</b>
---

**followed by:**

<b>dest-mac &lt; value&gt;</b>	Specifies the destination MAC address in hexadecimal {0x00:0x00:0x00:0x00:0x00:0x00}.
<b>src-mac&lt;value&gt;</b>	Specifies the source MAC address in hexadecimal {0x00:0x00:0x00:0x00:0x00:0x00}.
<b>src-port &lt;value&gt;</b>	Specifies the ingress port in the format {slot/port}.
<b>mlt&lt;value&gt;</b>	Specifies the MLT ID. Value is an integer in the range of 1 to 31.

## Command mode

Global configuration mode

## show sys hash-calc mltindex ip-mcast source group vlan-id src-port mlt

Use this command to calculate multicast traffic distribution.

## Syntax

```
show sys hash-calc mltindex ip-mcast source
<value>group<value>vlan-id<value>src-
port,value>mlt<value>
```

## Parameters

This command includes the following parameters:

<b>show sys hash-calc mltindex ip-mcast</b>
---

**followed by:**

<b>source &lt; value&gt;</b>	Specifies the multicast source address {a.b.c.d}.
<b>group&lt;value&gt;</b>	Specifies the multicast source address {a.b.c.d}.

```
show sys hash-calc mltindex ip-mcast
```

**followed by:**

<b>vlan-id&lt;value&gt;</b>	Specifies the VLAN ID. Value is an integer from 1 to 4000. The egress VLAN ID is used for IP-Mcast hash.
<b>src-port &lt;value&gt;</b>	Specifies the ingress port in the format {slot/port}.
<b>mlt&lt;value&gt;</b>	Specifies the MLT ID. Value is an integer in the range of 1 to 31.

### Command mode

Global configuration mode

**show sys hash-calc mltindex non-ip-mcast dest-mac vlan-id src-port mlt**

Use this command to calculate non-IP multicast traffic distribution.

### Syntax

```
show sys hash-calc mltindex non-ip-mcast dest-
mac<value>vlan-id<value>src-port,value>mlt<value>
```

### Parameters

This command includes the following parameters:

```
show sys hash-calc mltindex non-ip-mcast
```

**followed by:**

<b>dest-mac&lt; value&gt;</b>	Specifies the destination mac address in hexadecimal {0x00:0x00:0x00:0x00:0x00:0x00}.
<b>vlan-id&lt;value&gt;</b>	Specifies the VLAN ID. Value is an integer from 1 to 4000. The egress VLAN ID is used for IP-Mcast hash.
<b>src-port &lt;value&gt;</b>	Specifies the ingress port in the format {slot/port}.
<b>mlt&lt;value&gt;</b>	Specifies the MLT ID. Value is an integer in the range of 1 to 31.

**Command mode**

Global configuration mode

**show sys-info**

Use this command to display the system status and technical information about the configuration of switch hardware components.

This command displays general information about the system (such as location), chassis (type, serial number, and base MAC address), temperature, power supplies, fans, cards, system errors, port locks, and topology status.

**Syntax**

```
show sys-info [card] [asic] [mda]
```

**Parameters**

This command includes the following options:

<pre>show sys-info</pre> <b>followed by:</b>	
[ <b>card</b> ]	Displays information about all the installed modules.
[ <b>asic</b> ]	Displays information about the ASICS installed on each module.
[ <b>mda</b> ]	Displays information about installed MDAs.

**Command mode**

Privileged EXEC mode

**show sys perf**

Use this command to display system performance information, such as CPU and switch fabric utilization and NVRAM size and use. The information is updated once per second, so it is no more than one second from real time.

**Syntax**

```
show sys perf
```

**Command mode**

Privileged EXEC mode

**show sys sw**

Use this command to display the version of software running on the switch, the last update of that software, and the Boot Config Table. The Boot Config Table lists the current system settings and flags.

**Syntax**

```
show sys sw
```

**Command mode**

Privileged EXEC mode

**shutdown**

Use this command to configure shutdown policies for a module.

**Syntax**

```
shutdown <slots>
```

where

<slots> specifies the applicable slot number in the chassis. The range of values is 1 to 10.

**Note:** Slots are numbered from top to bottom in Ethernet Routing Switch 8300 switches.

**Command mode**

Global configuration mode

**no shutdown**

Use this command to enable the administrative status of the module.

**Syntax**

```
no shutdown <slots>
```

**Command mode**

Global configuration mode

**sys-action cpuswitchover**

Use this command to reset the switch to changeover to the backup CPU.

**Syntax**

```
sys-action cpuswitchover
```

**Command mode**

Privileged EXEC mode

## **sys-action resetconsole**

Use this command to reinitializes the hardware UART drivers. Use this command only if the console or modem connection is hung.

### **Syntax**

```
sys-action resetconsole
```

### **Command mode**

Privileged EXEC mode

## **sys-action resetcounters**

Use this command to reset all the statistics counters in the switch to zero.

### **Syntax**

```
sys-action resetcounters
```

### **Command mode**

Privileged EXEC mode

## **udpsrc-by-vip**

Use this command to enable the flag that directs the IP header to have the same source address as the management virtual IP address for self-generated User Datagram Protocol (UDP) packets.

### **Syntax**

```
udpsrc-by-vip
```

### **Command mode**

Global configuration mode

## **no udpsrc-by-vip**

Use this command to disable the flag that directs the IP header to have the same source address as the management virtual IP address for self-generated User Datagram Protocol (UDP) packets.

### **Syntax**

```
no udpsrc-by-vip
```

### **Command mode**

Global configuration mode



# SNMP commands

This chapter describes NNCLI SNMP commands and their parameters.

SNMP Command
<a href="#">"snmp-server authentication-trap" (page 135)</a>
<a href="#">"no snmp-server authentication-trap" (page 136)</a>
<a href="#">"snmp-server bootstrap" (page 136)</a>
<a href="#">"snmp-server community" (page 136)</a>
<a href="#">"snmp-server community name" (page 137)</a>
<a href="#">"snmp-server community security" (page 138)</a>
<a href="#">"no snmp-server community" (page 138)</a>
<a href="#">"snmp-server contact" (page 138)</a>
<a href="#">"snmp-server group" (page 139)</a>
<a href="#">"no snmp-server group" (page 140)</a>
<a href="#">"snmp-server host" (page 140)</a>
<a href="#">"no snmp-server host" (page 141)</a>
<a href="#">"show snmp-server" (page 141)</a>
<a href="#">"snmp-server location" (page 141)</a>
<a href="#">"snmp-server member" (page 141)</a>
<a href="#">"no snmp-server member" (page 142)</a>
<a href="#">"snmp-server name" (page 142)</a>
<a href="#">"snmp-server user" (page 143)</a>
<a href="#">"no snmp-server user" (page 144)</a>
<a href="#">"snmp-server view" (page 144)</a>
<a href="#">"no snmp-server view" (page 145)</a>

## snmp-server authentication-trap

Use this command to specify that you want to send authentication failure traps of SNMP transmission.

**Syntax**

```
snmp-server authentication-trap
```

**Command mode**

Global configuration mode

**no snmp-server authentication-trap**

Use this command to specify that you do not want to send authentication failure traps of SNMP transmission.

**Syntax**

```
no snmp-server authentication-trap
```

**Command mode**

Global configuration mode

**snmp-server bootstrap**

Use this command to provide a configuration for switch access.

**Syntax**

```
snmp-server bootstrap
```

**Parameters**

This command includes the following options:

<b>snmp-server bootstrap</b>	
<b>followed by:</b>	
<b>min-secure</b>	Provides the minimum security configuration for switch access.
<b>semi-secure</b>	Provides restricted view access to the switch.
<b>very-secure</b>	Does not provide any configuration to users; users must configure the switch by themselves.

**Command mode**

Global configuration mode

**snmp-server community**

Use this command to create and configure an SNMPv1/v2 community on the switch. SNMP community strings are required for access to the switch using Device Manager or other SNMP-based management software.

## Syntax

```
snmp-server community
```

## Parameters

This command includes the following options:

<b>snmp-server community</b>	
<b>followed by:</b>	
<b>&lt;comm_idx&gt;</b>	A unique SNMP community index value. The range is 1-32 characters.
<b>&lt;name&gt;</b>	The community string input for the community table that represents a configuration. The range is 1-255 characters.
<b>&lt;security&gt;</b>	Maps the community string to the security name in VACM Group Member Table. The range is 1-32.

## Command mode

Global configuration mode

## snmp-server community name

Use this command to change the name of an SNMP community by changing the name of an entry in the SNMP community table.

## Syntax

```
snmp-server community name <comm_idx> <new-name>
```

## Parameters

This command includes the following options:

<b>snmp-server community name</b>	
<b>followed by:</b>	
<b>&lt;comm_idx&gt;</b>	Specifies a unique SNMP community index value. The range is 1-32 characters.
<b>&lt;new-name&gt;</b>	Specifies the new name for the entry in the community table.

## Command mode

Global configuration mode

## snmp-server community security

Use this command to change the security name of an SNMP community by changing the security name of an entry in the SNMP community table.

### Syntax

```
snmp-server community security <comm_idx> <security>
```

### Parameters

This command includes the following options:

<b>snmp-server community security</b>	
<b>followed by:</b>	
<b>&lt;comm_idx&gt;</b>	Specifies a unique SNMP community index value. The range is 1-32 characters.
<b>&lt;security&gt;</b>	Maps the community string to the security name in VACM Group Member Table.

### Command mode

Global configuration mode

## no snmp-server community

Use this command to delete an SNMP community on the switch by deleting an entry in the SNMP community table.

### Syntax

```
no snmp-server community <comm_idx>
```

where

**<comm\_idx>** specifies a unique SNMP community index value. The range of values is 1 to 32 characters.

### Command mode

Global configuration mode

## snmp-server contact

Use this command to set the SNMP contact information for the switch.

### Syntax

```
snmp-server contact <contact>
```

where

**<contact>** specifies the contact information text. The range of values is an ASCII string from 0 to 255 characters (for example a phone extension or email address). Strings with spaces must be enclosed in quotes (e.g., "John Smith").

### Command mode

Global configuration mode

## snmp-server group

Use this command to create new access for a group in the VACM table.

### Syntax

```
snmp-server group <group name> <prefix> <model> <level>
```

where:

- **group name** specifies the group access name. The range is 1 to 32 characters.
- **prefix** is not supported in the current release of the Ethernet Routing Switch 8300; however, because it is part of the index for the table, it must be configured. When you configure prefix, enter " " to indicate an empty string. The range is 0 to 32 characters.
- **model** is the valid options are usm, snmpv1, and snmpv2c.
- **level** is the minimum level of security required to gain the access rights allowed by this conceptual row. The valid options are authPriv, authNoPriv, or noAuthNoPriv.

### Parameters

This command includes the following option:

<pre>snmp-server group</pre> <p><b>followed by:</b></p>	
<pre>view &lt;group name&gt;       &lt;prefix&gt; &lt;model&gt;       &lt;level&gt; [read &lt;value&gt;]               [write &lt;value&gt;]</pre>	<p>Assigns a MIB view for the specified group.</p> <ul style="list-style-type: none"> <li>• <b>read value</b> indicates that you want the group to have read access to the specified value (that is, MIB view).</li> <li>• <b>write value</b> indicates that you want the group to have write access to the specified value (that is, MIB view).</li> </ul>

**Command mode**

Global configuration mode

**no snmp-server group**

Use this command to delete group access from the v3 VACM table.

**Syntax**

```
no snmp-server group <group name> <prefix> <model>
<level>
```

where:

- **group name** specifies the group access name. The range is 1 to 32 characters.
- **prefix** is not supported in the current release of the Ethernet Routing Switch 8300; however, because it is part of the index for the table, it must be configured. When you configure prefix, enter " " to indicate an empty string. The range is 0 to 32 characters.
- **model** is the valid options are usm, snmpv1, and snmpv2c.
- **level** is the minimum level of security required to gain the access rights allowed by this conceptual row. The valid options are authPriv, authNoPriv, or noAuthNoPriv.

**Command mode**

Global configuration mode

**snmp-server host**

Use this command to set an SNMP trap receiver.

**Syntax**

```
snmp-server host <ipaddr> <v1|v2c> <commstr>
```

**Parameters**

This command includes the following options:

snmp-server host	
<b>followed by:</b>	
<ipaddr>	Specifies the IP address of the trap receiver.
<v1 v2c>	Specifies SNMP version 1 or SNMP version 2.
<commstr>	Specifies the input community string from 1 to 20 characters.

**Command mode**

Global configuration mode

**no snmp-server host**

Use this command to delete the SNMP trap receiver.

**Syntax**

```
no snmp-server host <ipaddr>
```

where

<ipaddr> specifies the IP address of the trap receiver.

**Command mode**

Global configuration mode

**show snmp-server**

Use this command to display the current SNMP settings.

**Syntax**

```
show snmp-server
```

**Command mode**

Privileged EXEC mode

Global configuration mode

Interface configuration mode

**snmp-server location**

Use this command to set the location information for the switch.

**Syntax**

```
snmp-server location <location>
```

where

<location> specifies the location information. The range of a values is an ASCII string from 0 to 255 characters (for example, Finance).

**Command mode**

Global configuration mode

**snmp-server member**

Use this command to create a new group member on the Ethernet Routing Switch 8300.

**Syntax**

```
snmp-server member <user name> <model> [<group name>]
```

where:

- **user name** specifies the name of the user group. The range is 1 to 32 characters.
- **model** specifies the message processing model to use when generating an SNMP message. The valid options are usm, snmpv1, and snmpv2c.
- **group name** assigns the user to the group for data access. The range is 1 to 32 characters.

## Parameters

This command uses the following option:

<b>snmp-server member</b>	
<b>followed by:</b>	
<b>name &lt;user name&gt;</b> <b>&lt;model&gt; &lt;group name&gt;</b>	Changes the group name for the v3 VACM table.

## Command mode

Global configuration mode

## no snmp-server member

Use this command to delete a user group from the v3 VACM table.

## Syntax

```
no snmp-server member <user name> <model>
```

where:

- **user name** specifies the name of the user group. The range is 1 to 32 characters.
- **model** specifies the message processing model to use when generating an SNMP message. The valid options are usm, snmpv1, and snmpv2c.

## Command mode

Global configuration mode

## snmp-server name

Use this command to set the root-level prompt name for the switch.

## Syntax

```
snmp-server name <prompt>
```

where

---

**<prompt>** specifies the text of the root-level prompt name for the SNMP server. The range of values is an ASCII string from 0 to 255 characters (for example, LabSC7 or Closet4).

### Command mode

Global configuration mode

## snmp-server user

Use this command to create a new user in the USM table on the Ethernet Routing Switch 8300:

```
snmp-server user <UserName> [<auth protocol>] [auth
<password>] [priv <password>]
```

where:

- **UserName** specifies the SNMPv3 user name. The name is used as an index to the table. The range is 1 to 32 characters.
- **auth protocol** specifies an authentication protocol. If no value is entered, the entry has no authentication capability. The protocol choices are MD5 and SHA.
- **auth <password>** specifies an authentication password. If no value is entered, the entry has no authentication capability. The range is 1 to 32 characters.
- **priv <password>** assigns a privacy password. If no value is entered, the entry has no privacy capability. The range is 1 to 32 characters. You must set authentication before you can set the privacy option.

### Parameters

This command uses the following options:

<b>snmp-server user</b>	
<b>followed by:</b>	
<b>auth &lt;user name&gt;</b> <b>old-password &lt;value&gt;</b> <b>new-password &lt;value&gt;</b>	Changes the authentication password for an existing user.
<b>priv &lt;user name&gt;</b> <b>old-password &lt;value&gt;</b> <b>new-password &lt;value&gt;</b>	Changes privacy password for an existing user.

### Command mode

Global configuration mode

**no snmp-server user**

Use this command to delete a user from the v3 VACM table.

**Syntax**

```
no snmp-server user <user name>
```

where

**user name** specifies the user's security name that is an index to the table. The range of values is 1 to 32 characters.

**Command mode**

Global configuration mode

**snmp-server view**

Use this command to create a new entry for the MIB View table on the Ethernet Routing Switch 8300:

**Syntax**

```
snmp-server view <View Name> <subtree oid> [mask <value> ]  
[type <value> ]
```

where:

- **View Name** represents an SNMP access view. The range is 1 to 32 characters.
- **subtree oid** is the prefix that defines the set of MIB objects accessible by this SNMP entity. The range is 1 to 32 characters.
- **mask <value>** specifies that a bit mask be used with vacmViewTreeFamilySubtree to determine whether an OID falls under a view subtree.
- **type <include|exclude>** determines whether access to a mib object is granted or denied.

**Parameters**

This command includes the following options:

<b>snmp-server view</b>	
<b>followed by:</b>	
<b>mask &lt;View Name&gt;</b> <b>&lt;subtree oid&gt;</b> <b>&lt;new-mask&gt;</b>	Changes the view mask for an entry in the MIB-view table.
<b>type &lt;View Name&gt;</b> <b>&lt;subtree oid&gt;</b> <b>&lt;new-type&gt;</b>	Changes the type for an entry in the MIB-view table.

## Command mode

Global configuration mode

## no snmp-server view

Use this command to delete an entry for the MIB view table.

### Syntax

```
no snmp-server view <view name> <subtree oid>
```

where:

- **view name** specifies the group name of the user. The range of values is 1 to 32 characters.
- **subtree oid** specifies the object identifier prefix that defines the set of MIB objects accessible by this SNMP entity. The range of values is 1 to 32 characters.

## Command mode

Global configuration mode



## Ethernet port commands

This chapter describes NNCLI Ethernet port commands and their parameters.

<b>Ethernet port command</b>
<a href="#">"action" (page 148)</a>
<a href="#">"auto-negotiate" (page 148)</a>
<a href="#">"no auto-negotiate" (page 149)</a>
<a href="#">"bcast-mcast-rate-limit" (page 150)</a>
<a href="#">"auto-recover-port" (page 149)</a>
<a href="#">"default auto-recover-port" (page 149)</a>
<a href="#">"no auto-recover-port" (page 150)</a>
<a href="#">"cp-limit" (page 151)</a>
<a href="#">"no cp-limit" (page 151)</a>
<a href="#">"default-vlan-id" (page 152)</a>
<a href="#">"duplex" (page 152)</a>
<a href="#">"eapol" (page 153)</a>
<a href="#">"no eapol" (page 155)</a>
<a href="#">"encapsulation" (page 156)</a>
<a href="#">"no encapsulation" (page 156)</a>
<a href="#">"linktrap" (page 156)</a>
<a href="#">"no linktrap" (page 157)</a>
<a href="#">"lock" (page 157)</a>
<a href="#">"no lock" (page 157)</a>
<a href="#">"name" (page 158)</a>
<a href="#">"shutdown" (page 158)</a>
<a href="#">"no shutdown" (page 158)</a>
<a href="#">"spanning-tree stp" (page 159)</a>
<a href="#">"no spanning-tree stp" (page 160)</a>

<b>Ethernet port command</b>
<a href="#">"tx-queue" (page 160)</a>
<a href="#">"no tx-queue" (page 161)</a>
<a href="#">"unknown-mac-discard" (page 162)</a>
<a href="#">"no unknown-mac-discard" (page 163)</a>
<a href="#">"test loopback" (page 163)</a>
<a href="#">"untagged-frames-discard" (page 164)</a>
<a href="#">"no untagged-frames-discard" (page 164)</a>

**action**

Use this command to perform port-specific actions such as flush table entries.

**Syntax**

```
action <port | none | flushMacFdb | flushALL|
      clearLoopDetectAlarm>
```

**Parameters**

This command includes the following parameters:

<b>action</b>	
<b>followed by:</b>	
<b>port</b>	Specifies the port.
<b>none</b>	Specifies none.
<b>flushMacFdb</b>	Flushes MAC forwarding table for port.
<b>flushALL</b>	Flushes all tables.
<b>clearLoopDetectAlarm</b>	Clears loop detect alarm.

**Command mode**

Interface configuration mode

**auto-negotiate**

Use this command to enable autonegotiation (adjusting between 10 Mb/s and 100 Mb/s and half- or full-duplex) on selected ports.

**Syntax**

```
auto-negotiate [port <port list>]
```

where

`port list` specifies the applicable ports in port list form: {`slot/port` [-`slot/port`] [, ...]}

### Command mode

Interface configuration mode

## no auto-negotiate

Use this command to disable autonegotiation on selected ports.

### Syntax

```
no auto-negotiate [port <port list>]
```

where

`port list` specifies the applicable ports in port list form: {`slot/port` [-`slot/port`] [, ...]}

### Command mode

Interface configuration mode

## auto-recover-port

Use this command to enable auto recovery on ports.

### Syntax

```
auto-recover-port [port <portlist>] [enable]
```

### Parameters

This command includes the following options:

<code>auto-recover-port</code>	
<b>followed by:</b>	
[ <code>port &lt;portlist&gt;</code> ]	Specifies the applicable ports in port list form: { <code>slot/port</code> [- <code>slot/port</code> ] [, ...]}.
[ <code>enable</code> ]	Enables auto recovery. The default is disabled.

### Command mode

Interface configuration mode

## default auto-recover-port

Use this command to set auto recovery on ports to default values.

### Syntax

```
default auto-recover-port [port <portlist>] [enable]
```

**Parameters**

This command includes the following options:

<b>default auto-recover-port</b>	
<b>followed by:</b>	
<b>[port &lt;portlist&gt; ]</b>	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.
<b>[enable]</b>	Disables auto recovery. The default is disabled.

**Command mode**

Interface configuration mode

**no auto-recover-port**

Use this command to remove auto recovery on ports.

**Syntax**

```
no auto-recover-port [port <portlist>] [enable]
```

**Parameters**

This command includes the following options:

<b>no auto-recover-port</b>	
<b>followed by:</b>	
<b>[port &lt;portlist&gt; ]</b>	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.
<b>[enable]</b>	Disables auto recovery. The default is disabled.

**Command mode**

Interface configuration mode

**bcast-mcast-rate-limit**

Use this command to enable broadcast and multicast rate limit on the ports.

**Syntax**

```
bcast-mcast-rate-limit <value> [port <port list>]
```

**Parameters**

This command includes the following parameters:

<b>bcast-mcast-rate-limit</b>	
<b>followed by:</b>	
<b>&lt;value&gt;</b>	Value is the broadcast-rate-limit with a range of 1 to 100.
<b>[port &lt;port list&gt; ]</b>	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.

## Command mode

Interface configuration mode

## cp-limit

Use this command to enable Control Packet rate Limit (CP-Limit).

### Syntax

```
cp-limit [port <port list> ]
```

where

**port list** specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}

## Command mode

Interface configuration mode

## no cp-limit

Use this command to disable Control Packet rate Limit (CP-Limit).

### Syntax

```
no cp-limit [port <portlist> ]
```

where

**port list** specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}

**Note:** After a CP-Limit is disabled on a port, it can only be re-enabled by disabling and re-enabling the port with command:

```
shutdown [port <ports>]
```

## Command mode

Interface configuration mode

## default-vlan-id

Use this command to define the default Virtual LAN (VLAN) identification on selected ports.

**Note:** The default switch configuration includes a port-based VLAN that includes all the ports in the system. This VLAN has a VID of 1 and is referred to as the Default VLAN. This VLAN is special in the sense that it cannot be deleted from the system, and that it is statically bound to the Default STG.

You should not confuse that Default VLAN with this default-vlan-id parameter. The purpose of this parameter is to place an incoming data packet into a user-defined (default) VLAN if the packet is expected to be carrying a VLAN ID and this value cannot be determined by the switch.

### Syntax

```
default-vlan-id [port <ports>] <vid>
```

### Parameters

This command includes the following options:

<b>default-vlan-id</b>	
<b>followed by:</b>	
[port <ports>]	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.
<vid>	Specifies the VLAN ID The range of values is 1 to 2000

### Command mode

Interface configuration mode

## duplex

Use this command to set the operating mode of the selected port to half-duplex or full-duplex when autonegotiation is disabled.

### Syntax

```
duplex [port <ports>] <half|full>
```

### Parameters

This command includes the following options:

<b>duplex</b>	
<b>followed by:</b>	
<b>[port &lt;ports&gt; ]</b>	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.
<b>half</b>	Sets the operating mode of the specified port to half-duplex when autonegotiation is disabled. The default is <b>half</b> -duplex.
<b>full</b>	Sets the operating mode of the specified port to full-duplex when autonegotiation is disabled. The default is <b>half</b> -duplex.

## Command mode

Interface configuration mode

## eapol

Use this command to configure EAPoL on a specific port.

### Syntax

```
eapol [guest-vlan<vid> [port <portlist> ] [init]
[max-request <1...10>]
[quiet-interval <1...65535> [re-authenticate]
[re-authentication <enable|disable>]
[re-authentication-period <1...2147483647>]
[server-timeout <1...65535>]
[supplicant-timeout <1...65535>]
[traffic-control <in|in-out>] [transmit-interval
<1...65535>]
```

### Parameters

This command includes the following options:

<b>eapol</b>	
<b>followed by:</b>	
<b>guest-vlan &lt;vid&gt;</b>	Specifies the ID of the guest VLAN.
<b>init</b>	Reinitializes EAPoL authentication on this port.
<b>max-request &lt;1...10&gt;</b>	Sets the maximum number of times to retry sending packets to the Supplicant.  The default is 2.

<b>eapol</b>	
<b>followed by:</b>	
<b>port &lt;portlist&gt;</b>	<p>Enter the port or ports you want to configure for EAPoL, and use the convention {slot/port[-slot/port][,...]}.</p> <p><b>Note:</b> If you omit this parameter, the system uses the port number specified when you entered the <b>interface</b> command.</p>
<b>quiet-interval &lt;1...65535&gt;</b>	<p>Sets the time interval (in seconds) between authentication failure and the start of a new authentication.</p> <p>The default is 60.</p>
<b>re-authenticate</b>	<p>Re-authenticates the Supplicant connected to this port immediately.</p> <p><b>Note:</b> Before you can reauthenticate the Supplicant connected to this port, you must first enable reauthentication <b>re-authentication &lt;enable disable&gt;</b></p>
<b>re-authentication &lt;enable disable&gt;</b>	<p>When enabled, re-authenticates an existing Supplicant at the time interval specified in <b>re-authentication-period &lt;1...2147483647&gt;</b></p> <p>The default is disable.</p>
<b>re-authentication-period &lt;1...2147483647&gt;</b>	<p>Sets the time interval (in seconds) between successive re-authentications <b>re-authentication &lt;enable disable&gt;</b>.</p> <p>The default is 3600 (1 hour).</p>
<b>server-timeout &lt;1...65535&gt;</b>	<p>Sets the time (in seconds) to wait for a response from the RADIUS server.</p> <p>The default is 30.</p>

<b>eapol</b>	
<b>followed by:</b>	
<b>status</b> <code>&lt;auto unauthorized authorized&gt;</code>	Sets the authentication status for this port. The default is <b>authorized</b> . <ul style="list-style-type: none"> <li>• <i>auto</i> - port authorization depends on the results of the EAPoL authentication by the RADIUS server.</li> <li>• <i>unauthorized</i> - port is always unauthorized.</li> <li>• <i>authorized</i> - port is always authorized.</li> </ul>
<b>supplicant-timeout</b> <code>&lt;1...65535&gt;</code>	Sets the time (in seconds) to wait for a response from a Supplicant for all EAP packets except EAP Request/Identity packets.  The default is 30.
<b>traffic-control</b> <code>&lt;in in-out&gt;</code>	Sets the desired level of traffic control for a port. <ul style="list-style-type: none"> <li>• <i>in</i> - Blocks incoming traffic when EAP authentication fails.</li> <li>• <i>in-out</i> - Blocks incoming and outgoing traffic when EAP authentication fails.</li> </ul>
<b>transmit-interval</b> <code>&lt;1...65535&gt;</code>	Sets the time (in seconds) to wait for a response from a Supplicant for EAP Request/Identity packets.  The default is 30.

### Command mode

Interface configuration mode

## no eapol

Use this command to disable eapol globally on the switch.

### Syntax

```
no eapol [port <port list>]
```

where

`port list` specifies the applicable ports in port list form: {`slot/port` [`-slot/port`] [, ...]}

**Command mode**

Interface configuration mode

## encapsulation

Use this command to enable encapsulation on selected ports.

**Syntax**

```
encapsulation [port <port list>]
```

where

`port list` specifies the applicable ports in port list form: {`slot/port` [`-slot/port`] [, ...]}

**Command mode**

Interface configuration mode

## no encapsulation

Use this command to disable encapsulation on selected ports.

**Syntax**

```
no encapsulation [port <port list>]
```

where

`port list` specifies the applicable ports in port list form: {`slot/port` [`-slot/port`] [, ...]}

**Command mode**

Interface configuration mode

## linktrap

Use this command to enable the link up/down trap of a specific port.

**Syntax**

```
linktrap [port <port list>]
```

where

`port list` specifies the applicable ports in port list form: {`slot/port` [`-slot/port`] [, ...]}

**Command mode**

Interface configuration mode

## no linktrap

Use this command to disable the link up/down trap of a specific port.

### Syntax

```
linktrap [port <port list>]
```

where

`port list` specifies the applicable ports in port list form: {`slot/port [-slot/port] [, ...]`}

### Command mode

Interface configuration mode

## lock

Use this command to lock the selected port or ports for exclusive use if the portlock feature is globally enabled by the `portlock <on|off>` command.

### Syntax

```
lock [port <port list>]
```

where

`[port <port list>]` is an optional parameter that specifies the applicable ports in port list form: {`slot/port [-slot/port] [, ...]`}.

### Command mode

Interface configuration mode

## no lock

Use this command to unlock the selected port or ports from exclusive use if the portlock feature is globally enabled by the `portlock <on|off>` command.

### Syntax

```
no lock [port <port list>]
```

where

`[port <port list>]` is an optional parameter that specifies the applicable ports in port list form: {`slot/port [-slot/port] [, ...]`}.

### Command mode

Interface configuration mode

**name**

Use this command to assign a name to the selected ports.

**Syntax**

```
name [port <ports>] <name>
```

**Parameters**

This command includes the following parameters:

<b>name</b>	
<b>followed by:</b>	
[port <ports>]	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.
<name>	Specifies the name of the port. The range of values is a string of 0 to 20 characters.

**Command mode**

Interface configuration mode

**shutdown**

Use this command to disable the interface on selected ports.

**Syntax**

```
shutdown [port <ports>]
```

where

[port <port list>] is an optional parameter that specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.

**Command mode**

Interface configuration mode

For more information about configuring port interfaces, see *Configuring IP Routing and Multicast Operations using the NNCLI and CLI (316800-B)* and *Configuring VLANs, Spanning Tree, and Static Link Aggregation using the NNCLI (316805-C)*

**no shutdown**

Use this command to enable the interface on selected ports.

**Syntax**

```
no shutdown [port <ports>]
```

where

**[port <port list> ]** is an optional parameter that specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.

### Command mode

Interface configuration mode

## spanning-tree stp

Configures the ports in a specified Spanning Tree Group (STG). This command can also display current settings for the port spanning tree group.

### Syntax

```
spanning-tree [port <ports>] stp <sid>
```

### Parameters

This command includes the following parameters:

<b>spanning-tree [port &lt;ports&gt;] stp</b>	
<b>followed by:</b>	
<b>&lt;sid&gt;</b>	Specify a spanning tree group ID from 1 to 64.
<b>change-detection</b>	Enable or Disable the topology change detection for the specified spanning tree.
<b>cost</b>  <b>&lt;value&gt;</b>	Sets the contribution of this port to the path cost. The IEEE 802.1D standard recommends that the default value of this parameter be in inverse proportion to the speed of the attached LAN. <ul style="list-style-type: none"> <li>• <b>value:</b> Specify a value from 1 to 65535.</li> </ul>
<b>faststart</b>	When enabled on a port with no other bridges, Spanning Tree FastStart brings the port up more quickly following switch initialization or a spanning tree change. The port goes through the normal listening and learning states before the forwarding state, but the hold times for these states is the bridge hello timer (2 seconds by default) instead of the bridge forward delay timer (15 seconds by default).

<b>spanning-tree [port &lt;ports&gt;] stp</b>	
<b>followed by:</b>	
<b>priority</b>	Sets this port's priority.
<value>	<ul style="list-style-type: none"> <li><b>value:</b> Specify a value from 0 to 65535.</li> </ul>
[port <portlist>]	<b>portlist:</b> Defines the list of ports for this STG. Use the format: {slot/port[-slot/port] [, ...]}.

**Note:** Ports must have tagging enabled in order to belong to multiple spanning tree groups.

### Command mode

Interface configuration mode

## no spanning-tree stp

Disables the ports in a specified Spanning Tree Group (STG).

### Syntax

```
no spanning-tree [port <ports>] stp <sid>
```

### Command mode

Interface configuration mode

## tx-queue

Use this command to configure transmit queue parameters for the specified ethernet port or ports.

### Syntax

```
tx-queue [port <ports>] <queue-id>
```

where:

- **ports** specify the ports in the portlist form {slot/port[-slot/port] [, ...]}.
- **queue-id** is the queue ID, which represents a priority with a value range of 0 (lowest) to 7 (highest).

### Parameters

This command includes the following options:

<b>tx-queue [port &lt;ports&gt;] &lt;queue-id&gt;</b>	
<b>followed by:</b>	
<b>tx &lt;enable disable&gt;</b>	Enables or disables the transmit queue feature.
<b>size &lt;size&gt;</b>	Specifies the number of traffic descriptors. One descriptor can hold one packet.  <b>size</b> range is 16 to 384.
<b>scheduler &lt;strict-priority DWRR1 DWRR0&gt;</b>	Specifies one of the following scheduling group names: <ul style="list-style-type: none"> <li>• strictPriority has the highest priority.</li> <li>• dwrr1 is a Deficit Weighted Round-Robin servicing technique with a medium level of priority.</li> <li>• dwrr0 is a Deficit Weighted Round-Robin servicing technique with the lowest priority.</li> </ul>
<b>weight &lt;weight&gt;</b>	Specifies the relative portion of bandwidth assigned to this queue compared to other queues. The relative weight uses a Deficit Weighted Round-Robin (DWRR) servicing technique.  <b>weight</b> range is 1 to 256.
<b>shaper &lt;enable disable&gt;</b>	Enables or disables the shaper feature.
<b>rate &lt;in mbps&gt;</b>	Maximum shaper rate in mbps.  <b>in mbps</b> has a value range of 1 to 10000.
<b>burst-size &lt;in kilobps&gt;</b>	Shaper burst size in kilo bytes.  <b>in kilobps</b> has a value range of 4 to 16000.

## Command mode

Interface fastethernet mode

## no tx-queue

Disables transmit queue parameters for the specified ethernet port or ports.

## Syntax

```
no tx-queue [port <ports>] <queue-id>
```

where:

- **ports** specify the ports in the portlist form {slot/port [- slot/port] [, ...]}.
- **queue-id** is the queue ID, which represents a priority with a value range of 0 (lowest) to 7 (highest).

## Command mode

Interface configuration mode

## unknown-mac-discard

Use this command to configure the unknown-mac-discard option on selected ports.

## Syntax

```
unknown-mac-discard [port <ports>] [activation] [add-allow-mac <0x00:0x00:0x00:0x00:0x00:0x00>] [autolearn] [autolearn-mode <one-shot|continuous>] [lock-autolearn-mac] [violation-downport] [violation-logging] [violation-sendAuthentificationTrap]
```

## Parameters

This command includes the following options:

<code>unknown-mac-discard [port &lt;ports&gt;]</code>	
<b>followed by:</b>	
<b>activation</b>	Sets unknown MAC discard.
<b>add-allow-mac</b> <code>&lt;0x00:0x00:0x00:0x00:0x00:0x00&gt;</code>	Sets the add allow mac address of this port.
<b>autolearn</b>	Sets autolearn on this port.
<b>autolearn-mode</b> <code>&lt;one-shot continuous&gt;</code>	Sets the autolearn mode.
<b>lock-autolearn-mac</b> <code>&lt;enable disable&gt;</code>	Sets the lock autolearn MAC address of this port.
<b>port</b> <code>&lt;ports&gt;</code>	Specifies the port numbers which are to be changed
<b>violation-downport</b>	Sets violation down port action of this port.
<b>violation-logging</b>	Sets violation logging action of this port.
<b>violation-sendAuthentificationTrap</b>	Sets violation send authentication action of this port.

**Command mode**

Interface configuration mode

**no unknown-mac-discard**

Use this command to disable the unknown-mac-discard option on selected ports.

**Syntax**

```
no unknown-mac-discard [port <ports>] [activation]
[autolearn] [autolearn-mode <one-shot|continuous>]
[lock-autolearn-mac] [max-mac-count <max MAC count>]
[remove-allow-mac <mac>] [violation-downport] [violation-logging] [violation-sendAuthenticationTrap]
```

**Parameters**

This command includes the following options:

<b>no unknown-mac-discard [port &lt;ports&gt;]</b>	
<b>followed by:</b>	
<b>activation</b>	Sets unknown MAC discard.
<b>autolearn</b>	Sets autolearn on this port.
<b>autolearn-mode &lt;one-shot continuous&gt;</b>	Sets the autolearn mode.
<b>lock-autolearn-mac &lt;enable disable&gt;</b>	Sets the lock autolearn MAC address of this port.
<b>max-mac-count &lt;max MAC count&gt;</b>	Sets the maximum number of MAC addresses allowed on this port.
<b>remove-allow-mac &lt;mac&gt;</b>	Removes allow MAC address from this port.
<b>violation-downport</b>	Sets violation down port action of this port.
<b>violation-logging</b>	Sets violation logging action of this port.
<b>violation- sendAuthenticationTrap</b>	Sets violation send authentication action of this port.

**Command mode**

Interface configuration mode

**test loopback**

Enables loopback test on specified ports.

**Syntax**

```
test loopback <ports>
```

where

**ports** specify the ports in the portlist form {*slot/port[-slot/port][, ...]*}.

**Command mode**

Interface configuration mode

**test stop**

Disables loopback test on specified ports.

**Syntax**

```
test stop <ports>
```

where

**ports** specify the ports in the portlist form {*slot/port[-slot/port][, ...]*}.

**Command mode**

Interface configuration mode

**untagged-frames-discard**

Use this command to enable the discard untagged frames option on selected ports.

**Syntax**

```
untagged-frames-discard [port <ports>] <enable|disable>
```

**Parameters**

This command includes the following parameter:

<b>untagged-frames-discard</b>	
<b>followed by:</b>	
[ <b>port &lt;ports&gt;</b> ]	Specifies the applicable ports in port list form: { <i>slot/port [-slot/port][, ...]</i> }.

**Command mode**

Interface configuration mode

**no untagged-frames-discard**

Use this command to disable the discard untagged frames option on selected ports.

---

## Syntax

```
no untagged-frames-discard [port <ports>] <enable|dis-
able>
```

## Parameters

This command includes the following parameter:

<b>no untagged-frames-discard</b>	
<b>followed by:</b>	
[port <ports>]	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.

## Command mode

Interface configuration mode

## custom autonegotiation advertisements

Configuration: new command available at the interface level

- For <10/100> interface fast auto-negotiation-advertisements <slot/port>
- For <10/100/1000> interface fast auto-negotiation-advertisements <slot/port>

Show command:

- For <10/100> show interface fast 2/1
- For <10/100/1000> show interface giga 3/1



# Security commands

This chapter describes NNCLI security commands and their parameters.

Security Commands
<a href="#">"access-policy disable"</a> (page 169)
<a href="#">"access-policy enable"</a> (page 169)
<a href="#">"access-policy info"</a> (page 169)
<a href="#">"access-policy policy"</a> (page 169)
<a href="#">"access-policy policy"</a> (page 171)
<a href="#">"access-policy policy create"</a> (page 172)
<a href="#">"access-policy policy info"</a> (page 174)
<a href="#">"no access-policy policy"</a> (page 176)
<a href="#">"no nsna"</a> (page 177)
<a href="#">"no nsna enable"</a> (page 177)
<a href="#">"no nsna nsnas"</a> (page 177)
<a href="#">"no nsna phone-signature"</a> (page 178)
<a href="#">"no nsna vlan"</a> (page 178)
<a href="#">"nsna"</a> (page 181)
<a href="#">"nsna enable"</a> (page 182)
<a href="#">"nsna nsnas"</a> (page 182)
<a href="#">"nsna phone-signature"</a> (page 183)
<a href="#">"nsna vlan color"</a> (page 183)
<a href="#">"radius-server info"</a> (page 187)
<a href="#">"no radius-server"</a> (page 178)
<a href="#">"radius"</a> (page 184)
<a href="#">"radius clear-stat"</a> (page 187)
<a href="#">"radius info"</a> (page 187)
<a href="#">"radius-server info"</a> (page 187)
<a href="#">"show access-policy"</a> (page 187)

<b>Security Commands</b>
<a href="#">"show nsna"</a> (page 188)
<a href="#">"show nsna client"</a> (page 188)
<a href="#">"show nsna nsnas"</a> (page 188)
<a href="#">"show nsna interface"</a> (page 189)
<a href="#">"show nsna phone-signature"</a> (page 189)
<a href="#">"show nsna vlan"</a> (page 189)
<a href="#">"show radius"</a> (page 189)
<a href="#">"show radius-server"</a> (page 190)
<a href="#">"show syslog"</a> (page 190)
<a href="#">"show syslog host"</a> (page 190)
<a href="#">"snmp-server authentication-trap"</a> (page 190)
<a href="#">"snmp-server contact"</a> (page 191)
<a href="#">"snmp-server group"</a> (page 191)
<a href="#">"snmp-server group info"</a> (page 192)
<a href="#">"snmp-server group match"</a> (page 192)
<a href="#">"snmp-server group view"</a> (page 193)
<a href="#">"no snmp-server group"</a> (page 179)
<a href="#">"snmp-server host"</a> (page 194)
<a href="#">"snmp-server host"</a> (page 195)
<a href="#">"no snmp-server group"</a> (page 179)
<a href="#">"snmp-server info"</a> (page 195)
<a href="#">"snmp-server location"</a> (page 195)
<a href="#">"snmp-server member"</a> (page 196)
<a href="#">"snmp-server member info"</a> (page 196)
<a href="#">"snmp-server member name"</a> (page 197)
<a href="#">"no snmp-server member"</a> (page 197)
<a href="#">"snmp-server name"</a> (page 198)
<a href="#">"snmp-server user"</a> (page 198)
<a href="#">"snmp-server user auth"</a> (page 199)
<a href="#">"snmp-server user info"</a> (page 200)
<a href="#">"snmp-server user priv"</a> (page 200)
<a href="#">"no snmp-server view"</a> (page 180)
<a href="#">"no snmp-server view"</a> (page 180)
<a href="#">"snmp-server view info"</a> (page 202)
<a href="#">"snmp-server view mask"</a> (page 202)

Security Commands
<a href="#">"snmp-server view type" (page 203)</a>
<a href="#">"syslog host" (page 204)</a>
<a href="#">"syslog host" (page 204)</a>
<a href="#">"syslog host" (page 205)</a>
<a href="#">"syslog host create" (page 206)</a>
<a href="#">"syslog host severity" (page 207)</a>
<a href="#">"no syslog host" (page 181)</a>

## access-policy disable

Use this command to globally disable the IP access policy feature on the switch so that no policies on the switch are applied. The default is disabled.

### Syntax

```
access-policy disable
```

### Command mode

Global configuration mode

## access-policy enable

Use this command to globally enable the IP access policy feature on the switch. The default is disabled.

### Syntax

```
access-policy enable
```

### Command mode

Global configuration mode

## access-policy info

Use this command to display the global access policy settings.

### Syntax

```
access-policy info
```

### Command mode

Global configuration mode

## access-policy policy

Use this command to modify an IP access policy with a specific access policy ID. Sets access level policies.

### Syntax

```
access-policy policy <vid>
```

```
[name <name> ]
[<enable|disable>]
[mode <allow|deny>]
[precedence <value> ]
[network <ip/mask> ]
[host <ip> ]
[username <name> ]
[accesslevel <string> ]
```

where

<vid> specifies the access policy ID number assigned when the policy was created. The range of values is 1 to 65535

## Parameters

This command includes the following options:

<b>access-policy policy &lt;vid&gt;</b>	
<b>followed by:</b>	
[accesslevel <string> ]	Specifies an access level for a policy. The options are: {ro   rw   rwa} or {read-only read-write read-write-all}.
create	Creates a new access policy. See " <a href="#">"access-policy policy create" (page 172)</a> for the full parameters under this command.
ftp <http/rlogin/ssh>	Enables FTP
http <rlogin/ssh>	Enables HTTP.
[host <ip> ]	Specifies the access policy for the trusted host address. Applies only for remote login and remote shell execution.
[name <name> ]	Specifies a name for the access policy. The range of values is a string of 0 to 15 characters.
[<enable disable>]	Enables or disables the specified access policy.
[mode <allow deny>]	Specifies the access policy mode. The options are: allow or deny.
[precedence <value> ]	Specifies the access policy precedence. Precedence determines which policy to use if multiple policies apply.  <value> specifies the precedence level. The range of values is 1 to 128, with the lowest number having the highest precedence.

<b>access-policy policy &lt;vid&gt;</b> <b>followed by:</b>	
[network <ip/mask> ]	<p>Specifies stations affected by the access policy using the network IP address and subnet mask.</p> <ul style="list-style-type: none"> <li>• <b>ip</b> specifies the IP address {a.b.c.d} of the host used to authenticate the user. The login must be the specified user at the specified host for access.</li> </ul> <p>If you specify an IP address and subnet mask, that location is either allowed or denied access, depending on the <b>mode</b> setting. The options are:  <b>{a.b.c.d/x   a.b.c.d/x.x.x.x   default}</b>.</p> <ul style="list-style-type: none"> <li>• <b>default</b> specifies that everyone on the network is either allowed or denied access, as defined by the <b>mode</b> setting.</li> </ul>
rlogin <ssh>	Enables rlogin.
snmp-group <name 1-32>	Adds an SNMP-v3 group under this access policy.
snmp-v3	Enables SNMP-V3.
ssh	Enables SSH.
telnet <ftp/http/rlogin/ssh/tftp>	Enables Telnet.
tftp <ftp/http/rlogin/ssh>	Enables TFTP.
[username <name> ]	Specifies the trusted host user name for the trusted host with the specified policy. Applies only to rlogin access

## Command mode

Global configuration mode

## access-policy policy

Use this command to specify access level policies for different methods of access.

## Syntax

```
access-policy policy <vid>
  [ftp <enable|disable>]
  [http <enable|disable>]
  [rlogin <enable|disable>]
  [snmp <enable|disable>]
  [telnet <enable|disable>]
  [tftp <enable|disable>]
```

## Parameters

This command includes the following options:

<b>access-policy policy &lt;vid&gt;</b>	
<b>followed by:</b>	
<vid>	Specifies the access policy ID number assigned when the policy was created. The range of values is 1 to 65535
[ftp <enable disable>]	Enables or disables access to ftp network communication protocols for the specified policy.
[http <enable disable>]	Enables or disables access to http network communication protocols for the specified policy.
[rlogin <enable disable>]	Enables or disables access to rlogin network communication protocols for the specified policy.
[snmp-group WORD <1-32>]	Adds an SNMP-V3 group under the specific access policy. <ul style="list-style-type: none"> <li>WORD &lt;1-32&gt; is the name the SNMP-V3 group.</li> </ul>
[snmpv3 <enable disable>]	Enables or disables SNMP-V3.
[ssh <enable disable>]	Enables or disables SSH.
[telnet <enable disable>]	Enables or disables access to telnet network communication protocols for the specified policy.
[tftp <enable disable>]	Enables or disables access to tftp network communication protocols for the specified policy.

## Command mode

Global configuration mode

## access-policy policy create

Use this command to create an IP access policy with a specified access policy ID. This command sets accesslevel policies.

## Syntax

```
access-policy policy <vid> create
  [name <name> ]
  [<enable|disable>]
  [mode <allow|deny>]
  [precedence <value> ]
  [network <ip/mask> ]
  [host <ip> ]
  [username <name> ]
  [accesslevel <string> ]
```

## Parameters

This command includes the following options:

<b>access-policy policy &lt;vid&gt; create</b>	
<b>followed by:</b>	
<vid>	Specifies the access policy ID number assigned when the policy was created. The range of values is 1 to 65535
[name <name> ]	Specifies a name for the access policy. The range of values is a string of 0 to 15 characters.
[<enable disable>]	Enables or disables the specified access policy.
[mode <allow deny>]	Specifies the access policy mode. The options are: <b>allow</b> or <b>deny</b> .
[precedence <value> ]	<p>Specifies the access policy precedence. Precedence determines which policy to use if multiple policies apply.</p> <p>&lt;value&gt; specifies the precedence level. The range of values is 1 to 128, with the lowest number having the highest precedence.</p>
[network <ip/mask> ]	<p>Specifies stations affected by the access policy using the network IP address and subnet mask.</p> <ul style="list-style-type: none"> <li>• <b>ip</b> specifies the IP address {a.b.c.d} of the host used to authenticate the user. The login must be the specified user at the specified host for access.</li> </ul> <p>If you specify an IP address and subnet mask, that location is either allowed or denied access, depending on the <b>mode</b> setting.</p>

<b>access-policy policy &lt;vid&gt; create</b>	
<b>followed by:</b>	
	<p>The options are:  {a.b.c.d/x  a.b.c.d/x.x.x.x  default}.</p> <ul style="list-style-type: none"> <li>• <b>default</b> specifies that everyone on the network is either allowed or denied access, as defined by the <b>mode</b> setting.</li> </ul>
[host <ip> ]	Specifies the access policy for the trusted host address. Applies only for remote login and remote shell execution.
[username <name> ]	Specifies the trusted host user name for the trusted host with the specified policy. Applies only to rlogin access
[accesslevel <string> ]	Specifies an access level for a policy. The options are: {ro   rw   rwa} or {read-only  read-write   read-write-all}.

**Command mode**

Global configuration mode

**access-policy policy info**

Use this command to create an IP access policy with a specified access policy ID. Sets accesslevel policies.

**Syntax**

```
access-policy policy <vid> info
```

where

<vid> specifies the access policy ID number assigned when the policy was created. The range of values is 1 to 65535.

**Command mode**

Global configuration mode

**eapol default-guest-vlan**

This command enables the EAPOL default guest VLAN.

**Syntax**

```
eapol default-guest-vlan <vid>
```

**Command mode**

Global configuration mode.

**eapol guest-vlan**

This command enables the EAPOL guest VLAN.

**Syntax**

```
eapol guest-vlan
```

**Command mode**

Global configuration mode.

**eapol allow-non-eap mac-max**

This command sets the maximum number of non-EAP clients.

**Syntax**

```
eapol allow-non-eap mac-max {<1-8>}
```

**Command mode**

Global configuration mode.

**eapol non-eap-mac add**

This command adds a non-EAP MAC Address to the allow list.

**Syntax**

```
eapol non-eap-mac add {<mac-add>}
```

**no eapol guest-vlan**

This command disables guest-vlan.

**Syntax**

```
no eapol guest-vlan
```

**Command mode**

This command is in the Interface configuration mode.

**eapol guest-vlan-id**

This command sets the guest-vlan at port level

**Syntax**

```
n
```

**Command mode**

This command is in the Interface configuration mode.

**eapol multihost**

This command enables EAPOL multihost.

**Syntax**

```
eapol multihost
```

**eapol guest-vlan**

This command enables guest-vlan

**Syntax**

```
eapol guest-vlan
```

**Command mode**

This command is in the Interface Config mode.

**eapol multihost mac-max**

This command sets the maximum number of EAP clients. The default is 1.

**Syntax**

```
eapol multihost mac-max {<1-8>}
```

**eapol allow-non-eap**

This command allows non-EAP clients.

**Syntax**

```
eapol allow-non-eap
```

**no access-policy policy**

Use this command to delete access policies for a specific policy ID.

**Syntax**

```
no access-policy policy <pid>
```

where

<pid> specifies the access policy ID number assigned when the policy was created. The range of values is 1 to 65535.

**Command mode**

Global configuration mode

For more information about access policies, see *Configuring and Managing Security using the NNCLI and CLI* (316804-C).

**no eapol allow-non-eap**

This command disallows non-EAP clients.

**Syntax**

```
no eapol allow-non-eap
```

**no eapol guest-vlan**

This command disables the EAPOL guest VLAN.

**Syntax**

```
no eapol guest-vlan
```

**Command mode**

This command is in the Global Config mode.

**no eapol multihost**

This command disables EAPOL multihost.

**Syntax**

```
no eapol multihost
```

**no eapol non-eap-mac**

This command removes a non-EAP MAC Address from the allow list.

**Syntax**

```
np eapol non-eap-mac {<mac-add>}
```

**no nsna**

Use this command to remove an NSNA port.

**Syntax**

```
no nsna
```

**Command mode**

Ethernet Interface configuration mode

**no nsna enable**

Use this command to disable NSNA.

**Syntax**

```
no nsna enable
```

**Command mode**

Global configuration mode

**no nsna nsnas**

Use this command to remove the NSNAS 4050 subnet.

**Syntax**

```
no nsna nsnas <ipaddr/mask>
```

where

<ipaddr/mask> is the NSNAS 4050 IP address and network mask (a.b.c.d/<0-32>).

**Command mode**

Global configuration mode

**no nsna phone-signature**

Use this command to remove NSNA phone signatures.

**Syntax**

```
no nsna phone-signature <LINE>
```

where

<LINE> is the phone signature string (for example: Nortel-i2007-A).

**no nsna vlan**

Use this command to remove an NSNA VLAN.

**Syntax**

```
no nsna vlan <vid>
```

where

<vid> is the VLAN ID in the range 1-4000.

**Command mode**

Global configuration mode

**no radius**

Use this command to remove CLI commands from accounting requests for Remote Access Dial-in User Services (RADIUS).

**Syntax**

```
no radius acct-include-cli-commands
```

**Command mode**

Global configuration mode

**no radius-server**

Use this command to disable the IP address for Remote Access Dial-in User Services (RADIUS) on the server.

**Syntax**

```
no radius-server <ipaddr>
```

where

<ipaddr> specifies the IP address for RADIUS on the server.

---

**Command mode**

Global configuration mode

For more information about RADIUS operations, see *Configuring and Managing Security using the NNCLI and CLI* (316804-C).

**no snmp-server group**

Use this command to delete view-based access for a Signaling Network Management Protocol (SNMP) group.

**Syntax**

```
no snmp-server group
<group name>
<prefix>
<model>
<level>
```

**Parameters**

This command includes the following options:

<b>no snmp-server group</b>	
<b>followed by:</b>	
<group name>	Creates the new group access with this group name. The range of values is 1 to 32 characters.
<prefix>	Assigns a context prefix. The range of values is 1 to 32 characters.
<model>	Assigns the authentication checking to communicate to the switch. The options are: <b>usm</b> , <b>snmpv1</b> , and <b>snmpv2c</b> .
<level>	Specifies the minimum level of security required to gain access rights allowed by this conceptual row.

**Command mode**

Global configuration mode

**no snmp-server host**

Use this command to delete the Signaling Network Management Protocol (SNMP) trap receiver.

**Syntax**

```
no snmp-server host <ipaddr>
```

where

<ipaddr> specifies the IP address of the trap receiver.

#### Command mode

Global configuration mode

### no snmp-server user

Use this command to delete a Signaling Network Management Protocol (SNMP) user in the User Security Model (USM) table and v3 VACM table on the switch.

#### Syntax

```
no snmp-server user <user name>
```

where

<user name> specifies the user's security name that is an index to the table. The range of values is 1 to 32 characters.

#### Command mode

Global configuration mode

### no snmp-server v1v2 community

Use this command to set the switch to check the v1v2 community string against the login access level.

#### Syntax

```
no snmp-server v1v2 community
```

#### Command mode

Global configuration mode

### no snmp-server view

Use this command to delete the Management Information Base (MIB) view for the Signaling Network Management Protocol (SNMP) on the switch.

#### Syntax

```
no snmp-server view <view name> <subtree oid>
```

#### Parameters

This command includes the following options:

<code>no snmp-server user view</code>	
<b>followed by:</b>	
<code>&lt;view name&gt;</code>	Specifies the group name of the user. The range of values is 1 to 32 characters.
<code>&lt;subtree oid&gt;</code>	Specifies the object identifier prefix that defines the set of MIB objects accessible by this SNMP entity. The range of values is 1 to 32 characters.

**Command mode**

Global configuration mode

**no syslog host**

Use this command to delete a syslog host.

**Syntax**`no syslog host <id>`

where

`<id>` specifies the syslog host ID. The range of values is 1 to 10.**Command mode**

Global configuration mode

**nsna**

Use this command to configure NSNA on ports.

**Syntax**`nsna`**Parameters**

This command uses the following parameters:

<code>nsna</code>	
<b>followed by:</b>	
<code>disable</code>	Enables/disables the Nortel SNA state of the port.
<code>dynamic [voip-vlans &lt;value&gt;]</code>	Sets the Nortel SNAS 4050 dynamic port configuration, where <code>&lt;value&gt;</code> is the VoIP VLAN IDs ( <code>vlan-id[-vlan-id][,...]</code> ).

<b>nsna</b>	
<b>followed by:</b>	
<b>info</b>	Shows the current Nortel SNA settings for the port.
<b>uplink uplink-vlans</b>	Defines the Nortel SNAS 4050 uplink VLAN list, where <value> is the Nortel SNA VLAN IDs (vlan-id[-vlan-id][,...]).

**Command mode**

Interface fastethernet or gigabitethernet mode

**nsna enable**

Use this command to enable NSNA.

**Syntax****nsna enable**

**Note:** You must enable SSH before you enable Nortel SNA globally. The command to enable Nortel SNA fails if you do not enable SSH.

**Command mode**

Global configuration mode

**nsna nsnas**

Use this command to configure the Nortel SNA 4050 subnet.

**Syntax****nsna nsnas <ipaddr/mask>**

where

<ipaddr/mask> is the Nortel SNAS 4050 pVIP address and network mask (a.b.c.d/<0-32> | a.b.c.d/x.x.x.x | default).

**Parameters**

This command includes the following parameters:

<b>nsna nsnas &lt;ipaddr/mask&gt;</b>	
<b>followed by:</b>	
<b>port &lt;value&gt;</b>	Defines the TCP port number for the Switch to Nortel SNAS 4050 Communication Protocol (SSCP) server. Values are in the range 1024–65535. The default setting is 5000.

**Command mode**

Global configuration mode

## nsna phone-signature

Use this command to specify IP phone signatures for the NSNA solution.

### Syntax

```
nsna phone-signature <LINE>
```

where

<LINE> is the phone signature string (for example: Nortel-i2007-A).

### Command mode

Global configuration mode

## nsna uplink vlans

Use this command to add the uplink port to the NSNA VLANs. You must have the uplink filter configured before you add the uplink port to the VLANs.

### Syntax

```
nsna uplink vlans <vidlist>
```

where

<vidlist> is the NSNA uplink VLAN IDs, entered using the convention {vlan-id[-vlan-id][,...]}.

### Command mode

Interface fastethernet or gigabitethernet mode

## nsna vlan color

Use this command to configure the NSNA VLANs.

### Syntax

```
nsna vlan <vid> color <red|yellow|green|voip>
```

where

<vid> is the VLAN ID in the range 2–4000.

<red|yellow|green|voip> is the color of the VLAN.

### Parameters

This command includes the following parameters:

<pre>nsna vlan &lt;vid&gt; color &lt;red yellow green voip&gt;</pre> <p><b>followed by:</b></p>	
<pre>filter &lt;filter-id&gt;</pre>	<p>Sets the NSNA filter ID. Values are in the range 1–1024.</p> <p><b>Note:</b> This parameter is not allowed for configuration of a VoIP VLAN. VoIP filters are part of the Red/Yellow filters.</p>
<pre>yellow-submask &lt;ipaddr/mask&gt;</pre>	<p>Sets the Yellow VLAN subnet IP and mask (a.b.c.d/&lt;0-32&gt;)</p> <p><b>Note:</b> This parameter is only allowed for configuration of the Yellow VLAN. The Yellow subnet is the Remediation server IP address/subnet.</p>

### Command mode

Global configuration mode

## radius

Use this command to configure Remote Access Dial-in User Services (RADIUS) on the switch. This command can also display global RADIUS settings.

### Syntax

```
radius
[<enable|disable>
[attribute-value <value> ]
[maxserver <INT> ]
[acct-enable|acct-disable]
[acct-attribute-value <value> ]
```

### Parameters

This command includes the following options:

<pre>radius</pre> <p><b>followed by:</b></p>	
<pre>[&lt;enable disable&gt;]</pre>	Enables or disables the RADIUS authentication feature.

<b>radius</b>	
<b>followed by:</b>	
<b>[attribute-value &lt;value&gt; ]</b>	Specific to RADIUS authentication. Specifies the vendor-specific attribute value of the Access-Priority attribute to match the type value set in the dictionary file on the RADIUS server. Nortel recommends the default setting of 192 for Ethernet Routing Switch 8300 Series switches. The range of values is 192 to 240.
<b>[maxserver &lt;INT&gt; ]</b>	Specific to RADIUS authentication. Specifies the maximum number of servers allowed for the switch. The range of values is 1 to 10.
<b>[acct-enable   acct-disable]</b>	Enables or disables RADIUS accounting globally. RADIUS accounting cannot be enabled unless a valid server is configured. The default is <b>acct-disable</b> .
<b>[acct-attribute-value &lt;value&gt; ]</b>	Specific to RADIUS accounting. Sets the vendor-specific attribute value of the CLI-command attribute to match the type value set in the dictionary file on the RADIUS server.  <value> must be different from the access-priority attribute value configured for authentication. The range of values is 192 to 240. The default value is 193.

**radius**

<b>radius</b>	
<b>followed by:</b>	
<b>[access-priority-attribute &lt;value&gt;]</b>	Specifies the value for Access-Priority attributes. The range of values is 192 to 240 and the default is 192.
<b>acct</b>	Enables radius accounting.

<b>radius</b>	
<b>followed by:</b>	
<b>[acct-attribute-value &lt;value&gt; ]</b>	Specific to RADIUS accounting. Sets the vendor-specific attribute value of the CLI-command attribute to match the type value set in the dictionary file on the RADIUS server.  <value> must be different from the access-priority attribute value configured for authentication. The range of values is 192 to 240. The default value is 193.
<b>[acct-include-cli-commands]</b>	Includes CLI commands in RADIUS accounting updates.
<b>[authentication]</b>	Enables RADIUS authentication for CLI login.
<b>&lt;cr&gt;</b>	Enables RADIUS.
<b>[clear-stat]</b>	Clears RADIUS statistics.
<b>[cli-commands-attribute&lt;value&gt;]</b>	Specifies the integer value for the CLI-Commands attribute. The range of values is 192 to 240 and the default is 195.
<b>[cli-profile]</b>	Enables RADIUS CLI profiling. The default is disabled.
<b>[command-access-attribute&lt;value&gt;]</b>	Specifies the integer value for the Command-Access attribute. The range is 192 to 240 and the default is 194.
<b>[maxserver &lt;INT&gt; ]</b>	Specific to RADIUS authentication. Specifies the maximum number of servers allowed for the switch. The range of values is 1 to 10 and the default is 10.
<b>[acct-enable  acct-disable]</b>	Enables or disables RADIUS accounting globally. RADIUS accounting cannot be enabled unless a valid server is configured. The default is <b>acct-disable</b> .
<b>[acct-attribute-value &lt;value&gt; ]</b>	Specific to RADIUS accounting. Sets the vendor-specific attribute value of the CLI-command attribute to match the type value set in the dictionary file on the RADIUS server.

<b>radius</b>	
<b>followed by:</b>	
	<value> must be different from the access-priority attribute value configured for authentication. The range of values is 192 to 240. The default value is 193.

**Command mode**

Global configuration mode

**radius clear-stat**

Use this command to clear statistics from the server for the Remote Access Dial-in User Services (RADIUS) on the switch.

**Syntax**

```
radius clear-stat
```

**Command mode**

Global configuration mode

**radius info**

Use this command to display global settings for the Remote Access Dial-in User Services (RADIUS) on the switch.

**Syntax**

```
radius info
```

**Command mode**

Global configuration mode

**radius-server info**

Use this command to display a list of all servers configured for Remote Access Dial-in User Services (RADIUS) on the switch.

**Syntax**

```
radius-server info
```

**Command mode**

Global configuration mode

**show access-policy**

Use this command to display the global access policy settings. If you specify a policy name, the settings for the policy are displayed.

**Syntax**

```
show access-policy [ <polname> ]
```

where

[ <polname> ] is an optional parameter that specifies the name of the access policy. The range is 0 to 15 characters.

**Command mode**

Privileged EXEC mode

**show nsna**

Use this command to view information on the state of NSNA on the switch.

**Syntax**

```
show nsna
```

**Command mode**

Privileged EXEC mode

**show nsna client**

Use this command to view information on NSNA clients that are currently connected to the switch.

**Syntax**

```
show nsna client [interface <interface-type>] | [<interface-id> | [mac-address <H.H.H>]
```

where

<interface-type> is the port type (for example, FastEthernet)  
<interface-id> is the slot/port number entered as {slot/port[-slot/port][,...]}  
<H.H.H> is the MAC address of the host.

**show nsna nsnas**

Use this command to view information related to the Nortel SNAS 4050 subnet.

**Syntax**

```
show nsna nsnas <ipaddr/mask>
```

where

<ipaddr/mask> is the Nortel SNAS 4050 IP address and network mask (a.b.c.d/<0-32>).

**Command mode**

Privileged EXEC mode

## show nsna interface

Use this command to view information related to the NSNA ports.

### Syntax

```
show nsna interface [<interface-type>] [<interface-id>]
```

where

<interface-type> is the port type (for example, FastEthernet)  
 <interface-id> is the slot/port number entered as {slot/port[-slot/  
 port][,...]}

### Command mode

Privileged EXEC mode:

## show nsna phone-signature

Use this command to view/configure NSNA phone signatures.

### Syntax

```
show nsna phone-signature <LINE>
```

where

<LINE> is the phone signature string (for example: Nortel-i2007-A). The <LINE> parameter can contain an asterisk (\*) at the end of the string to indicate that all signatures that start with the specified string are displayed. For example, if you enter Nort\* as the LINE parameter, output displays any signatures that start with the string Nort.

### Command mode

Privileged EXEC mode

## show nsna vlan

Use this command to view information related to the NSNA VLANs.

### Syntax

```
show nsna vlan <vid>
```

where

<vid> is the VLAN ID in the range 1-4000.

## show radius

Use this command to display the global status of Remote Access Dial-in User Services (RADIUS) information.

### Syntax

```
show radius
```

### Command mode

Privileged EXEC mode

**show radius-server**

Use this command to display current Remote Access Dial-in User Services (RADIUS) server configurations and statistics.

**Syntax**

```
show radius-server
```

**Command mode**

Privileged EXEC mode

**show syslog**

Use this command to display system log information for the entire system.

**Syntax**

```
show syslog
```

**Command mode**

Privileged EXEC mode

**show syslog host**

Use this command to display system log information for a specified host.

**Syntax**

```
show syslog host <id>
```

where

<id> specifies the host ID number.

**Command mode**

Privileged EXEC mode

**snmp-server authentication-trap**

Use this command to specify whether or not to send authentication failure traps of the Signaling Network Management Protocol (SNMP) transmission.

**Syntax**

```
snmp-server authentication-trap <enable|disable>
```

**Parameters**

This command includes the following options:

<b>snmp-server authentication-trap</b>
--

**followed by:**

<b>enable</b>	Enables sending authentication failure traps of the SNMP transmission.
<b>disable</b>	Disables sending authentication failure traps of the SNMP transmission.

## Command mode

Global configuration mode

## snmp-server contact

Use this command to set the contact information for the Signaling Network Management Protocol (SNMP) server.

### Syntax

```
snmp-server contact <contact>
```

where

<contact> specifies the contact information.

The range of values is an ASCII string from 1 to 1024 characters (for example, a phone extension or e-mail address).

## Command mode

Global configuration mode

## snmp-server group

Use this command to configure view-based access for a Signaling Network Management Protocol (SNMP) group.

### Syntax

```
snmp-server group
<group name>
<prefix>
<model>
<level> [match <value> ]
```

### Parameters

This command includes the following options:

<b>snmp-server group</b>	
<b>followed by:</b>	
<b>&lt;group name&gt;</b>	Creates the new group access with this group name. The range of values is 1 to 32 characters.
<b>&lt;prefix&gt;</b>	Assigns a context prefix. The range of values is 1 to 32 characters.
<b>&lt;model&gt;</b>	Assigns the authentication checking to communicate to the switch. The options are <b>usm</b> , <b>snmpv1</b> , and <b>snmpv2c</b> .
<b>&lt;level&gt;</b>	Assigns the minimum level of security required to gain access rights allowed by this conceptual row.
<b>[match &lt;value&gt; ]</b>	<p>Specifies the context match. The options are <b>exact</b> and <b>prefix</b>.</p> <ul style="list-style-type: none"> <li>• <b>exact</b> specifies that all rows in which the context name exactly matches the context prefix are selected.</li> <li>• <b>prefix</b> specifies that all rows in which the starting octet of the context name exactly matches the context prefix are selected.</li> </ul>

**Command mode**

Global configuration mode

**snmp-server group info**

Use this command to display current level parameter settings and next level directories for a Signaling Network Management Protocol (SNMP) group.

**Syntax**

```
snmp-server group info
```

**Command mode**

Global configuration mode

**snmp-server group match**

Use this command to change the group access context match in the v3 VACM table for a Signaling Network Management Protocol (SNMP) group.

## Syntax

```
snmp-server group match
<group name>
<prefix>
<model>
<level> [match <value> ]
```

## Parameters

This command includes the following options:

<b>snmp-server group match</b>	
<b>followed by:</b>	
<group name>	Creates the new group access with this group name. The range of values is 1 to 32 characters.
<prefix>	Assigns a context prefix. The range of values is 1 to 32 characters.
<model>	Assigns the authentication checking to communicate to the switch. The options are: <b>usm</b> , <b>snmpv1</b> , and <b>snmpv2c</b> .
<level>	Assigns the minimum level of security required to gain access rights allowed by this conceptual row.
[match <value> ]	<p>Specifies the context match. The options are <b>exact</b> and <b>prefix</b>.</p> <ul style="list-style-type: none"> <li>• <b>exact</b> specifies that all rows in which the context name exactly matches the context prefix are selected.</li> <li>• <b>prefix</b> specifies that all rows in which the starting octet of the context name exactly matches the context prefix are selected.</li> </ul>

## Command mode

Global configuration mode

## snmp-server group view

Use this command to change the group access view name match in the v3 VACM table for a Signaling Network Management Protocol (SNMP) group.

## Syntax

```
snmp-server group view
<group name>
<prefix>
<model>
<level>
[read <value> ]
[write <value> ]
```

## Parameters

This command includes the following options:

<b>snmp-server group view</b>	
<b>followed by:</b>	
<group name>	Creates the new group access with this group name. The range of values is 1 to 32 characters.
<prefix>	Assigns a context prefix. The range of values is 1 to 32 characters.
<model>	Assigns the authentication checking to communicate to the switch. The options are: <b>usm</b> , <b>snmpv1</b> , and <b>snmpv2c</b> .
<level>	Specifies the minimum level of security required to gain access rights allowed by this conceptual row.
[read <value> ]	
[write <value> ]	

## Command mode

Global configuration mode

## snmp-server host

Use this command to create a server host for Signaling Network Management Protocol (SNMP) transmission.

## Syntax

```
snmp-server host
```

## Command mode

Global configuration mode

## snmp-server host

Use this command to set a trap receiver for the Signaling Network Management Protocol (SNMP) transmission.

### Syntax

```
snmp-server host
<ipaddr>
<v1|v2c>
<commstr>
```

### Parameters

This command includes the following options:

<code>snmp-server host</code>	
<b>followed by:</b>	
<code>&lt;ipaddr&gt;</code>	Specifies the IP address of the trap receiver.
<code>&lt;v1 v2c&gt;</code>	Specifies the SNMP version. The options are: <code>v1</code> (version 1) or <code>v2c</code> (version 2).
<code>&lt;commstr&gt;</code>	Specifies the input community string of 1 to 1024 characters.

### Command mode

Global configuration mode

## snmp-server info

Use this command to display the current Signaling Network Management Protocol (SNMP) parameter settings.

### Syntax

```
snmp-server info
```

### Command mode

Global configuration mode

## snmp-server location

Use this command to set the location information for the Signaling Network Management Protocol (SNMP) server.

### Syntax

```
snmp-server location <location>
```

where

---

Nortel Ethernet Routing Switch 8300  
Command Reference — NNCLI  
NN46200-306 03.01 Standard  
4.0 27 August 2007

**<location>** specifies the SNMP location information. The range of values is an ASCII string from 1 to 1024 characters (for example, Finance).

### Command mode

Global configuration mode

## snmp-server member

Use this command to create a new Signaling Network Management Protocol (SNMP) group member with this user name.

### Syntax

```
snmp-server member
<user name>
<model>
[ <group name> ]
```

This command includes the following options:

<b>snmp-server member</b>	
<b>followed by:</b>	
<user name>	Assigns a user name to the SNMP member. The range of values is 1 to 32 characters.
<model>	Specifies the message processing model to use when generating an SNMP message. The options are: <b>usm</b> , <b>snmpv1</b> , and <b>snmpv2c</b> .
[ <group name> ]	Assigns the SNMP member to a SNMP group for data access. The range of values is 1 to 32 characters.

### Command mode

Global configuration mode

## snmp-server member info

Use this command to display current level parameter settings and next level directories for Signaling Network Management Protocol (SNMP) group members.

### Syntax

```
snmp-server member info
```

**Command mode**

Global configuration mode

**snmp-server member name**

Use this command to change a Signaling Network Management Protocol (SNMP) group member name for the v3 VACM table.

**Syntax**

```
snmp-server member name
<user name>
<model>
<group name>
```

**Parameters**

This command includes the following options:

<b>snmp-server member name</b>	
<b>followed by:</b>	
<user name>	Assigns a user name to the SNMP member. The range of values is 1 to 32 characters.
<model>	Specifies the message processing model to use when generating an SNMP message. The options are: <b>usm</b> , <b>snmpv1</b> , and <b>snmpv2c</b> .
<group name>	Assigns the SNMP member to a SNMP group for data access. The range of values is 1 to 32 characters.

**Command mode**

Global configuration mode

**no snmp-server member**

Use this command to delete a Signaling Network Management Protocol (SNMP) group member from the v3 VACM table.

**Syntax**

```
no snmp-server member
```

**Parameters**

This command includes the following options:

<code>no snmp-server member</code>	
<b>followed by:</b>	
<code>&lt;user name&gt;</code>	Specifies the user name of the SNMP member. The range of values is 1 to 32 characters.
<code>&lt;model&gt;</code>	Specifies the message processing model to use when generating an SNMP message. The options are: <code>usm</code> , <code>snmpv1</code> , and <code>snmpv2c</code> .

**Command mode**

Global configuration mode

**snmp-server name**

Use this command to set the box or root level prompt name for the Signaling Network Management Protocol (SNMP) server.

**Syntax**

```
snmp-server name <prompt>
```

where

`<prompt>` specifies the root level prompt name for the SNMP server.  
The range of values is an ASCII string from 1 to 1024 characters  
(for example, LabSC7 or Closet4).

**Command mode**

Global configuration mode

**snmp-server user**

Use this command to create a new Signaling Network Management Protocol (SNMP) user in the User Security Model (USM) table on the switch.

**Syntax**

```
snmp-server user
<user name>
[ <auth protocol> ]
[ auth <password> ]
[ priv <password> ]
```

**Parameters**

This command includes the following options:

<b>snmp-server user</b>	
<b>followed by:</b>	
<b>&lt;user name&gt;</b>	Specifies a security name for the new SNMP user entry. The security name is an index to the table. The range is 1 to 32 characters.
<b>[ &lt;auth protocol&gt; ]</b>	Specifies an authentication protocol. If no value is entered, the entry has no authentication capability. The protocol choices are: <b>MD5</b> and <b>SHA</b> .
<b>[auth &lt;password&gt; ]</b>	Specifies an authentication password. If no value is entered, the entry has no authentication capability. The range of values is 1 to 32 characters.
<b>[priv &lt;password&gt; ]</b>	Specifies a privacy password. If no value is entered, the entry has no privacy capability. The range is 1 to 32 characters.
<p><b>Note:</b> You must set authentication before you can set the privacy option.</p>	

## Command mode

Global configuration mode

## snmp-server user auth

Use this command to change the authentication password for a Signaling Network Management Protocol (SNMP) user on the switch.

### Syntax

```
snmp-server user auth
<user name>
old-pass <value>
new-pass <value>
```

### Parameters

This command includes the following options:

<b>snmp-server user auth</b>	
<b>followed by:</b>	
<b>&lt;user name&gt;</b>	Specifies the security name of the user whose authentication password is being changed. The security name is an index to the table. The range is 1 to 32 characters.
<b>new-pass &lt;value&gt;</b>	Specifies the new password.
<b>old-pass &lt;value&gt;</b>	Specifies the old password.

**Command mode**

Global configuration mode

**snmp-server user info**

Use this command to display current level parameter settings and next level directories for a Signaling Network Management Protocol (SNMP) user.

**Syntax**

```
snmp-server user info
```

**Command mode**

Global configuration mode

**snmp-server user priv**

Use this command to change the privacy password for a Signaling Network Management Protocol (SNMP) user on the switch.

**Syntax**

```
snmp-server user priv
<user name>
old-pass <value>
new-pass <value>
```

**Parameters**

This command includes the following options:

<b>snmp-server user priv</b>
------------------------------

**followed by:**

<b>&lt;user name&gt;</b>	Specifies the security name of the user whose privacy password is being changed. The security name is an index to the table. The range of values is 1 to 32 characters.
<b>new-pass &lt;value&gt;</b>	Specifies the new password.
<b>old-pass &lt;value&gt;</b>	Specifies the old password.

## Command mode

Global configuration mode

## snmp-server view

Use this command to configure the Management Information Base (MIB) view for the Signaling Network Management Protocol (SNMP) on the switch.

### Syntax

```
snmp-server view
<view name>
<subtree oid> [mask <value> ]
[type <value> ]
```

### Parameters

This command includes the following options:

<b>snmp-server view</b>
-------------------------

**followed by:**

<b>&lt;view name&gt;</b>	Specifies the group name of the user whose privacy password is being changed. The security name is an index to the table. The range of values is 1 to 32 characters.
<b>&lt;subtree oid&gt;</b>	Specifies the object identifier prefix that defines the set of MIB objects accessible by this SNMP entity. The range of values is 1 to 32 characters.

<b>snmp-server view</b>	
<b>followed by:</b>	
<b>[mask &lt;value&gt; ]</b>	Specifies that a bit mask be used with vacmViewTreeFamilySubtree to determine whether an OID falls under a view subtree.
<b>[type &lt;value&gt; ]</b>	Specifies whether access to a MIB object is granted or denied. The options are: <ul style="list-style-type: none"> <li>• <b>included</b> (granted)</li> <li>• <b>excluded</b> (denied)</li> </ul>

**Command mode**

Global configuration mode

**snmp-server view info**

Use this command to display the current level parameter settings and next level directories for the Management Information Base (MIB) view of the Signaling Network Management Protocol (SNMP) on the switch.

**Syntax**

```
snmp-server view info
```

**Command mode**

Global configuration mode

**snmp-server view mask**

Use this command to change the view mask for an entry in the Management Information Base (MIB) View table for the Signaling Network Management Protocol (SNMP) on the switch.

**Syntax**

```
snmp-server view mask
<view name>
<subtree oid>
<new-mask>
```

**Parameters**

<This command includes the following options:

<b>snmp-server view mask</b>	
<b>followed by:</b>	
<b>&lt;view name&gt;</b>	Specifies the group name of the user whose privacy password is being changed. The security name is an index to the table. The range of values is 1 to 32 characters.
<b>&lt;subtree oid&gt;</b>	Specifies the object identifier prefix that defines the set of MIB objects accessible by this SNMP entity. The range of values is 1 to 32 characters.
<b>&lt;new-mask&gt;</b>	Specifies the new bit mask used with vacmViewTreeFamilySubtree to determine whether an OID falls under a view subtree.

### Command mode

Global configuration mode

## snmp-server view type

Use this command to change the type for an entry in the Management Information Base (MIB) View table for the Signaling Network Management Protocol (SNMP) on the switch.

### Syntax

```
snmp-server view type
<view name>
<subtree oid>
<new-type>
```

### Parameters

This command includes the following options:

<b>snmp-server view type</b>	
<b>followed by:</b>	
<b>&lt;view name&gt;</b>	Specifies the group name of the user whose privacy password is being changed. The security name is an index to the table. The range of values is 1 to 32 characters.

<b>snmp-server view type</b>	
------------------------------	--

**followed by:**

<b>&lt;subtree oid&gt;</b>	Specifies the object identifier prefix that defines the set of MIB objects accessible by this SNMP entity. The range of values is 1 to 32 characters.
<b>&lt;new-type&gt;</b>	Specifies the new view type used.

### Command mode

Global configuration mode

## syslog host

Use this command to configure a host location for the system log information (syslog) host.

### Syntax

```
syslog host <id>
[address <ipaddr> ]
[udp-port <port> ]
[facility <facility> ]
[<enable|disable>]
```

### Parameters

This command includes the following options:

<b>syslog host &lt;id&gt;</b>	
-------------------------------	--

**followed by:**

<b>&lt;id&gt;</b>	Specifies the syslog host ID. The range of values is 1 to 10.
<b>[address &lt;ipaddr&gt; ]</b>	Specifies the IP address of the UNIX system syslog host.
<b>[udp-port &lt;port&gt; ]</b>	Specifies the UNIX system syslog host port number on which to send syslog messages to the syslog host. The range of values is 514 to 530.
<b>[facility &lt;facility&gt; ]</b>	Specifies the UNIX system syslog host facility. The range of values is LOCAL0 to LOCAL7.
<b>[&lt;enable disable&gt; ]</b>	Enables or disables sending syslog messages on the switch.

## Command mode

Global configuration mode

## syslog host

Use this command to specify the severity of syslog messages that require the messages to be sent to specified modules.

### Syntax

```
syslog host <id>
[mapinfo <level> ]
[mapwarning <level> ]
[maperror <level> ]
[mapfatal <level> ]
```

### Parameters

This command includes the following options:

<b>syslog host &lt;id&gt;</b>	
<b>followed by:</b>	
<id>	Specifies the syslog host ID. The range of values is 1 to 10.
[mapinfo <level> ]	Specifies the severity level of syslog messages that require the messages to be sent to specified modules. The options are:  {emergency alert critical error warning notice info debug}.
[mapwarning <level> ]	Specifies the severity level of syslog messages that require the messages to be sent to specified modules. The options are:  {emergency alert critical error warning notice info debug}.

<b>syslog host &lt;id&gt;</b>	
<b>followed by:</b>	
[maperror <level> ]	Specifies the severity level of syslog messages that require the messages to be sent to specified modules. The options are:  {emergency alert critical error warning notice info debug}.
[mapfatal <level> ]	Specifies the severity level of syslog messages that require the messages to be sent to specified modules. The options are:  {emergency alert critical error warning notice info debug}.

### Command mode

Global configuration mode

## syslog host create

Use this command to create a system log information (syslog) host and configure a host location.

### Syntax

```
syslog host <id> create
[<enable|disable>]
[address <ipaddr> ]
[facility <facility> ]
[udp-port <port> ]
```

### Parameters

This command includes the following options:

<b>syslog host &lt;id&gt; create</b>	
<b>followed by:</b>	
<id>	Specifies the syslog host ID. The range of values is 1 to 10.
[<enable disable>]	Enables or disables the syslog host.
[address <ipaddr> ]	Specifies the IP address of the UNIX system syslog host.

<code>syslog host &lt;id&gt; create</code>	
<b>followed by:</b>	
<code>[facility &lt;facility&gt; ]</code>	Specifies the UNIX system syslog host facility. The range of values is LOCAL0 to LOCAL7.
<code>[udp-port &lt;port&gt; ]</code>	Specifies the UNIX system syslog host port number on which to send syslog messages to the syslog host. The range of values is 514 to 530.

## Command mode

Global configuration mode

## syslog host severity

Use this command to specify the severity level of system log information (syslog) messages sent for the specified modules.

### Syntax

```
syslog host <id> severity
<info|warning|error|fatal>
[<info|warning|error|fatal>]
[<info|warning|error|fatal>]
[<info|warning|error|fatal>]
```

### Parameters

This command includes the following options:

<code>syslog host &lt;id&gt; severity</code>	
<b>followed by:</b>	
<code>&lt;id&gt;</code>	Specifies the syslog host ID. The range of values is 1 to 10.
<code>&lt;info warning  error fatal&gt;</code>	Specifies the severity levels of syslog messages sent for the specified modules. The options are:  <code>{info warning error fatal}.</code>
<code>[&lt;info warning  error fatal&gt;]</code>	Specifies the severity levels of syslog messages sent for the specified modules. The options are:  <code>{info warning error fatal}.</code>

<pre>syslog host &lt;id&gt; severity</pre> <p><b>followed by:</b></p>	
<pre>[&lt;info warning  error fatal&gt;]</pre>	<p>Specifies the severity levels of syslog messages sent for the specified modules. The options are:</p> <p>{info warning error fatal}.</p>
<pre>&lt;info warning  error fatal&gt;]</pre>	<p>Specifies the severity levels of syslog messages sent for the specified modules. The options are:</p> <p>{info warning error fatal}.</p>

**Command mode**

Global configuration mode

**show eapol**

This command displays the global settings updated to provide guest vlan and eap-mac-max information.

**Syntax**

```
show eapo
```

**Command mode**

Privileged Exec mode

**show eapol**

This command displays the guest VLAN and multihost configurations.

**Syntax**

```
show eapol
```

**Command mode**

Privileged Exec mode

---

# IP protocol commands

---

This chapter describes NNCLI IP protocol commands and their parameters.

IP Protocol Commands
"accept adv-rtr" (page 213)
"area" (page 214)
"as-boundary-router enable" (page 215)
"auto-vlink enable" (page 216)
"default-metric" (page 216)
"default default-metric" (page 217)
"default timer basic" (page 217)
"host-route" (page 218)
"interface loopback " (page 218)
"ip alternative-route" (page 219)
"no ip alternative-route" (page 220)
"ip address " (page 219)
"no ip address" (page 219)
"ip arp" (page 220)
"no ip arp" (page 221)
"ip arp proxy" (page 221)
" no ip arp proxy" (page 221)
" ip arp response" (page 221)
" no ip arp response" (page 221)
"ip default-ttl" (page 222)
" ip dhcp-relay broadcast" (page 222)
" ip dhcp-relay" (page 222)
" ip dhcp-relay max-hop" (page 222)
"ip dhcp-relay min-sec" (page 223)
"ip forward-protocol udp" (page 223)

<b>IP Protocol Commands</b>
"no ip forward-protocol udp" (page 223)
"ip forward-protocol udp portfwdlist" (page 224)
"no ip forward-protocol udp portfwdlist" (page 224)
"no ip forward-protocol udp porffwdlist" (page 225)
"ip forward-protocol udp" (page 225)
"no ip forward-protocol udp" (page 226)
"ip icmp-unreach-msg" (page 226)
"no ip icmp-unreach-msg" (page 227)
"ip irdp enable" (page 227)
"no ip irdp enable" (page 227)
"ip irdp" (page 227)
"no ip irdp" (page 228)
"default ip irdp" (page 228)
"no ip irdp multicast" (page 229)
"ip irdp vlan multicast" (page 229)
"no ip irdp vlan multicast" (page 229)
"ip more-specific-non-local-route enable" (page 229)
"no ip more-specific-non-local-route enable" (page 230)
"ip ospf" (page 230)
"ip ospf spf-run" (page 232)
"ip prefix-list" (page 232)
"no ip prefix-list" (page 233)
"ip routing" (page 233)
"no ip routing" (page 233)
"ip rip" (page 234)
"ip route" (page 238)
"no ip route" (page 239)
"ip route preference protocol" (page 239)
"lldp" (page 240)
"default lldp" (page 241)
"lldp port status" (page 241)
"no lldp port" (page 241)
"default lldp port" (page 242)
"lldp tx-tlv" (page 242)
"lldp port status" (page 242)

IP Protocol Commands
"no lldp status" (page 242)
"default lldp port" (page 243)
"lldp tx-tlv" (page 243)
"no lldp tx-tlv" (page 243)
"default lldp tx-tlv" (page 244)
"lldp tx-tlv dot1" (page 244)
"no lldp tx-tlv dot1" (page 244)
"default lldp tx-tlv dot1" (page 245)
"lldp tx-tlv dot3" (page 245)
"default lldp tx-tlv dot3" (page 245)
"lldp tx-tlv dot3" (page 245)
"no lldp tx-tlv dot3" (page 245)
"default lldp tx-tlv dot3" (page 246)
"lldp tx-tlv med" (page 246)
"no lldp tx-tlv med" (page 246)
"default lldp tx-tlv med" (page 247)
"lldp location-identification civic-address " (page 247)
"manualtrigger ip rip interface vlan" (page 248)
"network" (page 248)
"no network" (page 249)
"network" (page 249)
"network area" (page 249)
"redistribute enable" (page 250)
"redistribute source" (page 250)
"route-map " (page 251)
"route-map " (page 252)
"no route-map " (page 254)
"router ospf " (page 254)
"router ospf enable" (page 254)
"no router ospf enable" (page 254)
"router rip" (page 255)
"router rip enable" (page 255)
"no router rip enable" (page 255)
"router-id" (page 255)
"show interface loopback" (page 259)

IP Protocol Commands
"show ip arp" (page 259)
"show ip dhcp-relay fwd-path" (page 260)
"show ip dhcp-relay counters" (page 260)
"show ip forward-protocol udp" (page 260)
"show ip forward-protocol udp portfwdlist" (page 260)
"show ip forward-protocol udp interface" (page 261)
"show ip global" (page 261)
"show ip irdp" (page 261)
"show ip irdp interface" (page 262)
"show ip irdp interface vlan" (page 262)
"show ip interface" (page 261)
"Showing OSPF general configuration information" (page 262)
"Showing OSPF router acceptance parameter information" (page 262)
"Showing OSPF area information" (page 262)
"Showing OSPF external lsas information" (page 263)
"Showing OSPF interface authentication information" (page 263)
"Showing OSPF default-metric information" (page 264)
"Showing OSPF host-route information" (page 264)
"Showing OSPF interface statistics information" (page 264)
"Showing OSPF authentication information" (page 265)
"Showing OSPF timers information" (page 265)
"Showing OSPF interface information" (page 265)
"Showing OSPF lsdb information" (page 266)
"Showing OSPF neighbours information" (page 266)
"Showing OSPF redistribute information" (page 267)
"Showing OSPF statistics information" (page 267)
"Showing OSPF interface timers information" (page 267)
"show ip prefix-list" (page 268)
"show ip rip" (page 268)
"show ip rip interface" (page 268)
"show ip rip interface" (page 268)
"show ip route" (page 269)
"show ip route preference" (page 270)

IP Protocol Commands
"show route-map" (page 269)
"show ip route preference" (page 270)
"show ip route" (page 270)
"show ip static-route" (page 270)
"show ip tcp" (page 271)
"show lldp" (page 271)
"show lldp neighbor" (page 273)
"show ports stats dhcp-relay" (page 274)
"show slpp" (page 274)
"show vlan nlb-mode" (page 274)
"slpp" (page 256)
"no slpp" (page 257)
"slpp port" (page 257)
"no slpp port" (page 258)
"timer basic" (page 274)
"timers basic holddown" (page 276)
"trap enable" (page 276)
"vlan nlb-mode" (page 277)
"no vlan nlb-mode" (page 277)

## accept adv-rtr

This command configures OSPF acceptance:

### Syntax

```
accept adv-rtr <ipaddr>
```

Where:

- <ipaddr> is router ID.

### Parameters

This command includes the following parameters:

<b>accept adv-rtr</b>	
<b>followed by:</b>	
	Accept ospf router.
<ipaddr> enable	Enable OSPF accept on particular router. <ipaddr> is router ID.

<b>accept adv-rtr</b> followed by:	
<ipaddr> metric-type [type1 type2 any]	Set OSPF accept on particular router with particular metric type. <ipaddr> is router ID. [type1 type2 any] is metric type.
<ipaddr> route-policy WORD<0-64>	Set OSPF accept on particular router with particular routing policy. <ipaddr> is router ID. WORD<0-64> is policy name.

To set OSPF acceptance to a default condition, precede the command with the word **default**.

Example:

```
default accept adv-rtr <ipaddr>
```

To cancel or delete OSPF acceptance, precede the command with the word **no**.

Example:

```
no accept adv-rtr <ipaddr>
```

### Command mode

Router Configuration mode.

## area

This command creates and configures an OSPF area:

### Syntax

```
area <ipaddr>
```

Where:

- <ipaddr> is area ID.

### Parameters

This command includes the following options:

<b>area</b> followed by:	
<ipaddr> import [external noexternal nssa]	Set particular area as stub or nssa or normal area. <ipaddr> is area ID. [external noexternal nssa] is area type.

area followed by:	
1.1.1.1 import-summaries enable	Enable import-summaries on particular area.
1.1.1.1 stub-metric <0-16777215>	Set stub-metric on particular area. <0-16777215> is stub metric value.
range <ipaddr> <ipaddr/x   ipaddr/x.x.x.x   default> [summary-link nssa-extlink] [advertise-metric <0-65535> advertise-mode [summarize suppress no-summarize]]	Creates an OSPF area range with the specified IP address and advertising mode. <ipaddr> is area ID. <ipaddr/x   ipaddr/x.x.x.x   default> is ip range. [summary-link nssa-extlink] is lsa type. <0-65535> is metric value. [summarize suppress no-summarize] is advertise.
virtual-interface <ipaddr> <ipaddr>	Creates a virtual interface area identifier. <ipaddr> is area ID. <ipaddr> is router ID.
virtual-interface message-digest-key <ipaddr> <ipaddr> <1-255> md5-key WORD<1-16>	Adds an md5 key to the virtual interface. At most, two md5 keys can be configured to an interface. Multiple md5 key configurations are used for md5 transitions without bringing down an interface. <ipaddr> is area ID. <ipaddr> is virtual-interface ID. <1-255> is key ID. WORD<1-16> is md5 key.

To set an OSPF area configuration to a default condition, precede the command with the word **default**.

Example:

```
default area <ipaddr>
```

To cancel or delete an OSPF area configuration, precede the command with the word **no**.

Example:

```
no area <ipaddr>
```

### Command mode

Router Configuration mode.

## as-boundary-router enable

This command enables OSPF Autonomous System boundary router:

### Syntax

```
as-boundary-router enable
```

To set OSPF Autonomous System boundary router to a default condition, use the following command:

```
default as-boundary-router enable
```

To cancel or delete OSPF Autonomous System boundary router, use the following command:

```
no as-boundary-router enable
```

### Command mode

Router Configuration mode.

## auto-vlink enable

This command enables OSPF auto-vlink:

### Syntax

```
auto-vlink enable
```

To set OSPF auto-vlink to a default condition, use the following command:

```
default auto-vlink enable
```

To cancel or delete OSPF auto-vlink, use the following command:

```
no auto-vlink enable
```

### Command mode

Router Configuration mode.

## default-metric

This command allows you to set the value of the default metric to apply to routes imported into the RIP domain.

### Syntax

```
default-metric <metric>
```

where

**metric** is an integer value with a range of 0 to 15. The default is 8.

This is the metric used for routes not learned through RIP if a route policy does not specify a metric for a particular protocol, such as OSPF.

**Note:** You cannot assign a value of 0 to the default import metric. Entering the command **default-metric 0** deconfigures this parameter and restores the default value of 8.

### Command mode

Router Configuration mode

---

## default default-metric

The default import metric is the metric used for routes not learned through RIP if a route policy does not specify a metric for a particular protocol, such as OSPF. This command allows you to return the default import metric to its default value of 8.

### Syntax

```
default default-metric
```

or

```
default-metric 0
```

### Command mode

Router Configuration mode

## default timer basic

This command allows you to return global timer parameters to their default values, use the following command:

### Syntax

```
default timer basic
```

### Parameter

This command includes the following parameters:

<code>default timer basic</code>	
<b>followed by:</b>	
<b>holddown</b>	Resets the RIP holddown timer to its default value of 120 seconds on all the interfaces. The value of the holddown timer is the length of time (in seconds) that RIP will continue to advertise a network after determining that it is unreachable.
<b>timeout</b>	Resets the RIP timeout timer to its default value on all the interfaces. The default value is set indirectly by the global update time parameter. By default, the timeout timer is set at 6 times the update timer, in accordance with the RFC specification. With a default global update parameter setting of 30 seconds, the default timeout interval is 180 seconds.
<b>update</b>	Resets the RIP update timer to its default value of 30 seconds. The value of the update timer is the time interval (in seconds) between regular RIP updates.

### Command mode

Router Configuration mode

## host-route

This command configures OSPF host-route parameters:

### Syntax

```
host-route <ipaddr>
```

Where:

- <ipaddr> is IP address.

### Parameters

This command includes the following parameters:

<b>host-route</b>	followed by:
area <ipaddr>	<ipaddr> is the area id.
<ipaddr> metric <0-65535>	Creates an OSPF host route for the IP address and sets the metric (cost) for the host route. <ipaddr> is ip address <0-65535> is metric value

To set an OSPF host-route parameters to a default condition, use the following command:

```
default host-route <ipaddr>
```

To cancel or delete an OSPF host-route parameters, use the following command:

```
no host-route <ipaddr>
```

### Command mode

Router Configuration mode.

## interface loopback

The commands to configure CLIP are in the loopback interface configuration mode. This command allows you to access the loopback interface configuration mode.

### Syntax

```
interface loopback <id>
```

where

<id> is an integer you assign to identify the CLIP interface. The range is 1 to 32.

**Note:** You can configure a maximum of 32 CLIP interfaces on each device.

**Command mode**

Loopback interface configuration mode

**ip address**

This command allows you to create a CLIP interface in loopback interface configuration mode.

**Syntax**

```
ip address [id <id>]
```

where

<id> is an integer you assign to identify the CLIP interface. The range is 1 to 32.

**Parameter**

This command includes the following parameters:

ip address	
<b>followed by:</b>	
<ipaddr>	The IP address of the CLIP interface.
<net mask>	The subnet mask of the CLIP interface.

**Command mode**

Interface configuration mode

**no ip address**

This command allows you to delete a CLIP interface.

**Syntax**

```
no ip address
```

**Command mode**

Interface configuration mode

**ip alternative-route**

Use this command to enable alternative routing in the Ethernet Routing Switch 8300. The alternative route feature allows fast convergence to an alternative route in those cases when the primary route is unavailable. By default, alternative routing is enabled in the Ethernet Routing Switch 8300, thus allowing re-routing to an alternative link.

**Syntax**

```
ip alternative-route
```

**Command mode**

Global configuration mode

**no ip alternative-route**

Use this command to disable alternative routing in the Ethernet Routing Switch 8300.

**Syntax**

```
no ip alternative-route
```

**Command mode**

Global configuration mode

**ip arp**

Use this command to add a static entry to the Address Resolution Protocol (ARP) table on the Ethernet Routing Switch 8300.

**Syntax**

```
ip arp
multicast-mac-flooding <enable | disable>
timeout <value>
<ipaddr> <macaddr> <slot/port> <vid>
```

**Parameters**

This command includes the following parameters:

<b>ip arp</b>	
<b>followed by:</b>	
multicast-mac-flooding <enable   disable>	Enables or disables multicast MAC flooding.
timeout <value>	Sets the ARP entries lifetime aging period. Valid values here range from 1-32767 minutes.
<ipaddr> <macaddr> <slot/port> <vid>	Adds a static ARP entry to the specified IP address, MAC address, slot/port, or VLAN ID.  <b>Note:</b> An IP address must be assigned to a VLAN before a static ARP entry can be associated with it.

**Command mode**

Interface configuration mode

**no ip arp**

Use this command to delete an ARP entry at the port level.

**Syntax**

```
no ip arp <ipaddr>
```

where

<ipaddr> specifies the IP address in dotted decimal notation {a.b.c.d.}.

**Command mode**

Interface configuration mode

**ip arp proxy**

Use this command to enable proxy ARP on a VLAN.

**Syntax**

```
ip arp proxy
```

**Command mode**

Interface VLAN mode

**no ip arp proxy**

Use this command to disable proxy ARP on a VLAN.

**Syntax**

```
no ip arp proxy
```

**Command mode**

Interface VLAN mode

**ip arp response**

Use this command to enable ARP response.

**Syntax**

```
ip arp response
```

**Command mode**

Interface VLAN mode

**no ip arp response**

Use this command to disable ARP response

**Syntax**

```
no ip arp response
```

**Command mode**

Interface VLAN mode

**ip default-ttl**

Use this command to set the default time-to-live (ttl) value for a routed packet.

**Syntax**

```
ip default-ttl <seconds>
```

where

<seconds> specifies the maximum number of seconds between 1 and 255 before a packet is discarded. The default value of 255 is inserted in the ttl field whenever one is not supplied.

**Command mode**

Global configuration mode

**ip dhcp-relay broadcast**

Use this command to enable dhcp-relay broadcasting.

**Syntax**

```
ip dhcp-relay broadcast <enable|disable>
```

**Command mode**

Interface VLAN mode

**ip dhcp-relay**

Use this command to enable dhcp-relay.

**Syntax**

```
ip dhcp-relay <enable|disable>
```

**Command mode**

Interface VLAN mode

**ip dhcp-relay max-hop**

Use this command to specify the value for the dhcp-relay max-hop.

**Syntax**

```
ip dhcp-relay max-hop <max-hop>
```

**Command mode**

Interface VLAN mode

**ip dhcp-relay min-sec**

Use this command to specify the minutes and seconds of dhcp-relay.

**Syntax**

```
ip dhcp-relay min-sec <min-sec>
```

**Command mode**

Interface VLAN mode

**ip dhcp-relay mode**

Use this command to specify the dhcp-relay mode.

**Syntax**

```
config interface vlan ip dhcp-relay mode
<bootp|dhcp|bootp_dhcp>
```

**Command mode**

Interface VLAN mode

**ip forward-protocol udp**

A UDP forwarding protocol specifies which port to watch for incoming UDP broadcasts, as well as the protocol name for that port.

Use this command to create a UDP forwarding protocol.

**Syntax**

```
ip forward-protocol udp <updport> <protoname>
```

where:

- **updport** is an integer value with a range of 1 to 65535.
- **protoname** is a string length {1..15}.

**Command mode**

Global configuration mode

**no ip forward-protocol udp**

This command allows you to delete a UDP protocol, use the following command in **Global Config** mode:

**Syntax**

```
no ip forward-protocol udp <updport>
```

where

**updport** specifies the port protocol to delete.

**Command mode**

Global configuration mode

**ip forward-protocol udp portfwlist**

A UDP forwarding policy is a list of one or more UDP protocols that are assigned a forwarding IP address. Each forwarding policy also has a unique name and number. You can repeat this command to add additional UDP protocols to an existing policy, to add another forwarding IP address for an existing UDP protocol, or to update the policy name.

Use this command to create a UDP forwarding policy.

**Syntax**

```
ip forward-protocol udp portfwlist <listid> <updport>
<ipaddr> [ <name> ]
```

where:

- **listid** is an integer value from 1 to 1000. This provides a unique identifier for the UDP forwarding policy.
- **updport** is an integer value with a range of 1 to 65535. This port must have a defined UDP protocol.
- **ipaddr** is the forwarding destination. You can enter either a specific server IP address, or an IP limited broadcast in dotted-decimal notation {a.b.c.d}.
- **name** is a string length {1..15} used to describe the forwarding policy. If no value is entered when creating a new UDP forwarding policy, the system generates a name automatically.

**Command mode**

Global configuration mode

**no ip forward-protocol udp portfwlist**

Use this command to delete an entire UDP forwarding policy.

**Syntax**

```
no ip forward-protocol udp portfwlist <listid>
```

where

**listid** specifies the UDP forwarding policy ID to delete.

**Command mode**

Global configuration mode

## no ip forward-protocol udp porffwdlist

This command allows you to remove a UDP protocol from an existing UDP forwarding policy.

### Syntax

```
no ip forward-protocol udp portfwdlist <listid>
<updport> <ipaddr>
```

where:

- **listid** specifies the UDP forwarding policy ID to delete.
- **updport** specifies the port protocol to remove.
- **ipaddr** is the forwarding destination for this port protocol. You can enter either a specific server IP address, or an IP limited broadcast in dotted-decimal notation {a.b.c.d}.

### Command mode

Global configuration mode

## ip forward-protocol udp

Use this command to apply a UDP forwarding policy, to set the broadcast mask, and to set maximum TTL value for this interface.

### Syntax

```
ip forward-protocol udp [vlan <vlan> ]
```

where

**vlan** is an optional integer with a range of 1 to 4000, specifying a particular VLAN on this interface to apply the specified settings.

This command includes the following parameters:

<pre>ip forward-protocol udp [vlan]</pre> <p><b>followed by:</b></p>	
<b>portfwdlist &lt;listid&gt;</b>	Apply the specified UDP forwarding policy to this interface, and (optionally) set the broadcast mask for this interface and the maximum TTL value. <ul style="list-style-type: none"> <li>• <b>listid</b> is an integer with a range of 1 to 1000.</li> </ul>

<b>ip forward-protocol udp [vlan]</b>	
<b>followed by:</b>	
<b>broadcastmask &lt;mask&gt;</b>	Set the broadcast mask for this interface, and (optionally) set the maximum TTL value. <ul style="list-style-type: none"> <li>• <b>mask</b> is the subnet mask in A.B.C.D format.</li> </ul>
<b>maxttl &lt;maxttl&gt;</b>	Set the maximum TTL value for this interface. <ul style="list-style-type: none"> <li>• <b>maxttl</b> is an integer value with a range of 1 to 16. The default value is 4.</li> </ul>

**Command mode**

Interface configuration mode

**no ip forward-protocol udp**

Use this command to remove UDP forwarding policies from an interface.

**Syntax**

```
no ip forward-protocol udp [vlan <vlan>] [portfwdlist
<listid>] [broadcastmask <mask>]
```

where:

- **vlan** specifies a particular VLAN to remove the UDP forwarding policy from.
- **listid** specifies the UDP forwarding policy ID to remove.
- **mask** specifies the subnet mask to remove.

If no optional parameters are included with this command, then all UDP forwarding policies are removed from the interface being configured.

**Command mode**

Interface configuration mode

**ip icmp-unreach-msg**

Use this command to enable the Internet Control Message Protocol (ICMP) unreachable message. When enabled, this command allows the generation of ICMP net unreachable messages if the destination network is not reachable from this switch. These messages assist in determining if the routing switch is reachable over the network.

**Syntax**

```
ip icmp-unreach-msg
```

**Command mode**

Global configuration mode

**no ip icmp-unreach-msg**

Use this command to disable the ICMP unreachable message.

**Syntax**

```
no ip icmp-unreach-msg
```

**Command mode**

Global configuration mode

**ip irdp enable**

By default, router discovery is disabled. Use this command to enable router discovery.

**Syntax**

```
ip irdp enable
```

**Command mode**

Global configuration mode

**no ip irdp enable**

Use this command to disable router discovery.

**Syntax**

```
no ip irdp enable
```

**Command mode**

Global configuration mode

**ip irdp****Enabling router discovery**

By default, router discovery is disabled. Use this command to enable router discovery.

**Syntax**

```
ip irdp
```

**Command mode**

Global configuration mode

**Configuring router discovery on VLANs**

Use this command to configure router discovery on VLANs.

**Syntax**

```
ip irdp
```

**Parameters**

This command includes the following parameters:

<b>ip irdp</b>	
<b>followed by:</b>	
<b>address &lt;A.B.C.D&gt;</b>	Specifies the route discovery advertisement address.
<b>holdtime &lt;value&gt;</b>	Specifies the holdtime for router advertisements.
<b>maxadvertinterval &lt;value&gt;</b>	Specifies the Maximum Advertisement interval for router advertisements.
<b>minadvertinterval &lt;value&gt;</b>	Specifies the Minimum Advertisement interval for router advertisements.
<b>multicast</b>	Enables router discovery by setting the advertise flag to true.
<b>preference &lt;value&gt;</b>	Specifies the preference level for router advertisement.

**Command mode**

Interface VLAN mode

**no ip irdp**

Use this command to disable router discovery.

**Syntax**

```
no ip irdp
```

**Command mode**

Global configuration mode

**default ip irdp**

Use this command to set the router discovery to default values.

**Syntax**

```
default ip irdp
```

**Command mode**

Global configuration mode

**no ip irdp multicast**

Use this command to disable router discovery on VLANs.

**Syntax**

```
no ip irdp multicast
```

**Command mode**

Interface VLAN mode

**ip irdp vlan multicast**

Use this command to enable router discovery on a selected VLAN.

**Syntax**

```
ip irdp vlan <vid> multicast
```

where

<vid> is the ID of the selected VLAN.

**Command mode**

Interface VLAN mode

**no ip irdp vlan multicast**

Use this command to disable router discovery on a specific VLAN.

**Syntax**

```
no ip irdp vlan <vid> multicast
```

where

<vid> is the ID of the selected VLAN.

**Command mode**

Interface VLAN mode

**ip more-specific-non-local-route enable**

This command enables static routes to networks that are not directly connected. When enabled, this command allows a more specific non-local route to go into the routing table. The default is disabled.

**Syntax**

```
ip more-specific-non-local-route enable
```

**Command mode**

Global configuration mode

## no ip more-specific-non-local-route enable

This command allows you to disable that feature that permits a more specific non-local route to go into the routing table.

### Syntax

```
no ip more-specific-non-local-route enable
```

### Command mode

Global configuration mode

## ip ospf

This command configures OSPF on an interface:

### Syntax

```
ip ospf
```

### Parameters

This command includes the following options:

<b>ip ospf</b> followed by:	
<b>advertise-when-down enable</b>	The network on this interface is advertised as up, even if no ports in the VLAN are active
<b>area&lt;ipaddr&gt;</b>	Set the vlan interface in a particular area. <ipaddr> is area ID.
<b>authentication-key WORD&lt;0-8&gt;</b>	Set the authentication key for the VLAN. WORD<0-8> is simple authentication key.
<b>authentication-type [message-digest none simple]</b>	Set the OSPF authentication type for the VLAN. [message-digest none simple] is authentication type.
<b>authentication-key WORD&lt;0-2147483647&gt;</b>	Set the OSPF dead interval for the VLAN. The dead interval is the number of seconds the switch's OSPF neighbors should wait before assuming that this OSPF router is down. PT_LONG<0-2147483647> is dead-interval value
<b>enable</b>	Enables OSPF on the VLAN.
<b>hello-interval &lt;1-65535&gt;</b>	Set the OSPF hello interval for the VLAN. The hello interval is the number of seconds between hello packets sent on this VLAN. <1-65535> is hello-interval value
<b>interface-type [broadcast passive]</b>	Set the interface type, default is broadcast. A passive interface will not form neighborship with other routers. [broadcast passive] is interface type.

<b>ip ospf</b> followed by:	
<b>message-digest-key &lt;1-255&gt;md5-key WORD&lt;0-16&gt;</b>	Set the authentication message-digest-key for the VLAN. <1-255> is message-digest-key ID WORD<0-16> is md5 key
<b>metric &lt;1-65535&gt;</b>	Set the OSPF metric for the VLAN. The switch advertises the metric in router link advertisements. <1-65535> is metric value
<b>primary-md5-key &lt;1-255&gt;</b>	Set primary message-digest-key. <1-255> is message-digest-key ID
<b>priority &lt;0-255&gt;</b>	Set the OSPF priority for the VLAN during the election process for the designated router. The VLAN with the highest priority number is the best candidate for the designated router. If the priority is 0, the VLAN cannot become either the designated router or a backup. The priority is used only during election of the designated router and backup designated router. <0-255> is priority value
<b>retransmit-interval &lt;0-3600&gt;</b>	Set the retransmit interval for the virtual interface. The retransmit interval is the number of seconds between link-state advertisement retransmissions. <0-3600> is retransmit interval value
<b>transit-delay &lt;0-3600&gt;</b>	Sets the transmit delay for the virtual interface. The transmit delay is the estimated number of seconds it takes to transmit a link-state update over the interface. <0-3600> is transit delay value
<b>vlan&lt;1-4094&gt;</b>	Set ospf configuration on paticular vlan. <1-4094> is the vlan ID.

To configure OSPF parameters on an interface to a default condition, use the following command:

```
default ip ospf
```

To cancel or delete OSPF configuration parameters on an interface, use the following command:

```
no ip ospf
```

### Command mode

Interface configuration mode

## ip ospf spf-run

This command forces an OSPF SPF run:

### Syntax

```
ip ospf spf-run
```

### Command mode

User Exec mode

## ip prefix-list

The prefix list is a list of networks used by route policies to define an action. You can create one or more IP prefix lists and apply that list to any IP route policy.

When you configure the ge (mask length from) field to be less than the le (mask length to) field, it can also be used as a range.

This command allows you to configure a prefix list.

### Syntax

```
ip prefix-list <prefix-list name>
```

where

**prefix-list name** is a string length {1..64} that indicates the name of the prefix list

### Parameter

This command includes the following parameters:

<b>ip prefix-list &lt;prefix-list name&gt; followed by:</b> <b>&lt;ipaddr/mask&gt; [ge &lt;value&gt;] [le &lt;value&gt;]</b>	<p>Adds a prefix entry to the prefix list. Creates the prefix list if it does not already exist.</p> <ul style="list-style-type: none"> <li>• <b>ipaddr/mask</b> {a.b.c.d/x a.b.c.d/x.x.x.x default} is the IP address and network mask.</li> <li>• <b>ge &lt;value&gt;</b> is the lower bound of the mask length, where <b>value</b> is an integer value with a range of 0 to 32. The default is the mask length.</li> <li>• <b>le &lt;value&gt;</b> is the higher bound of the mask length, where <b>value</b> is an integer value with a range of 0 to 32. The default is the mask length.</li> </ul>
---	--

<pre>ip prefix-list &lt;prefix-list name&gt; <b>followed by:</b></pre>	
	<p><b>Note:</b> Lower bound and higher bound mask lengths together can define a range of networks</p>
<b>name &lt;name&gt;</b>	<p>Renames the prefix list specified in the command.</p> <ul style="list-style-type: none"> <li>• <b>name</b> is a string length {1..64}.</li> </ul>

**Command mode**

Global configuration mode

**no ip prefix-list**

This command allows you to delete a prefix list.

**Syntax**

```
no ip prefix-list <prefix-list name>
```

**Command mode**

Global configuration mode

**ip routing**

Use this command to enable IP routing on the Ethernet Routing Switch 8300. By default, IP routing is enabled.

**Syntax**

```
ip routing
```

**Command mode**

Global configuration mode

**no ip routing**

Use this command to disable IP routing on the Ethernet Routing Switch 8300.

**Syntax**

```
no ip routing
```

**Command mode**

Global configuration mode

**ip rip**

Use this command to configure RIP on a specified VLAN interface.

**Syntax**

```
ip rip
```

**Parameter**

This command includes the following parameters:

<b>ip rip</b> <b>followed by:</b>	
<b>advertise-when-down</b> <b>&lt;enable disable&gt;</b>	<p>If enabled, the network on this interface will be advertised as up, even if the VLAN is down. The default is disabled.</p> <p>When you configure a VLAN without any link and enable advertise-when-down, it will not advertise your route until the VLAN is active. Then the route is advertised even when the link is down. To disable advertising based on link status, disable this parameter.</p>
<b>auto-summary</b> <b>&lt;enable disable&gt;</b>	<p>Enables or disables automatic route aggregation on the interface. When enabled, the router switch automatically aggregates routes to their natural mask when they are advertised on an interface in a network of a different class. The default is disabled.</p> <p>Routes with different metrics can be aggregated. RIP uses the out metric associated with the first route found in the routing table that is to be aggregated.</p>
<b>cost &lt;cost&gt;</b>	<p>Sets the RIP cost for this interface.</p> <ul style="list-style-type: none"> <li>• <b>cost</b> is an integer value with a range of 1 to 15. The default value is 1.</li> </ul>
<b>default-listen</b> <b>&lt;enable disable&gt;</b>	Configures whether or not the interface will listen for RIP updates for the default route learned through RIP. The default is disabled.
<b>default-supply</b> <b>&lt;enable disable&gt;</b>	Configures whether or not the interface will send RIP advertisements for the default route, if one exists in the routing table. The default is disabled.

<b>ip rip</b> <b>followed by:</b>	
<b>domain &lt;domain&gt;</b>	<p>Specifies the value inserted into the Routing Domain field of all RIP packets sent on this interface.</p> <ul style="list-style-type: none"> <li>• <b>domain</b> is an integer value with a range of 0 to 65535. The default is 0.</li> </ul>
<b>holddown &lt;seconds&gt;</b>	<p>Sets the RIP holddown timer for the interface. The value of the holddown timer is the length of time (in seconds) that RIP will continue to advertise a network after determining that it is unreachable.</p> <ul style="list-style-type: none"> <li>• <b>seconds</b> is an integer value with a range of 0 to 360.</li> </ul> <p>The default value is set by the global holddown parameter, which has a default of 120 seconds. The interface timer setting overrides the global parameter. However, if you subsequently reset the global parameter, the global setting then overrides the interface timer setting.</p>
<b>in-policy &lt;policy name&gt;</b>	<p>Sets the RIP policy for inbound filtering on the interface. The in-policy determines which routes will be learned on the interface.</p> <ul style="list-style-type: none"> <li>• <b>policy name</b> is a string length {0..64}.</li> </ul> <p>To delete the policy, enter an empty string.</p>
<b>listen &lt;enable disable&gt;</b>	Configures whether or not the interface will listen for RIP routes. The default is enabled.

<pre>ip rip</pre> <p><b>followed by:</b></p>	
<pre>out-policy &lt;policy name&gt;</pre>	<p>Sets the RIP policy for outbound filtering on the interface. The out-policy determines which routes will be advertised from the routing table on the interface.</p> <ul style="list-style-type: none"> <li>• <b>policy name</b> is a string length {0..64}.</li> </ul> <p>To delete the policy, enter an empty string.</p>
<pre>poison &lt;enable disable&gt;</pre>	<p>Sets whether or not RIP routes on the interface learned from a neighbor are advertised back to the neighbor.</p> <ul style="list-style-type: none"> <li>• If disabled, split horizon is invoked, and IP routes learned from an immediate neighbor are not advertised back to the neighbor.</li> <li>• If enabled, the RIP updates sent to a neighbor from which a route is learned are "poisoned" with a metric of 16. Therefore, the receiver neighbor ignores this route because the metric 16 indicates infinite hops in the network.</li> </ul> <p>The default is disabled.</p>
<pre>receive version &lt;version&gt;</pre>	<p>Indicates which version of RIP updates the router will accept for this interface. The options for <b>version</b> are:</p> <ul style="list-style-type: none"> <li>• <b>rip1</b> — RIP version 1 (complies with RFC 1058).</li> <li>• <b>rip2</b> — RIP version 2 (complies with RFC 2453).</li> <li>• <b>rip1orrip2</b> — both versions of RIP.</li> </ul> <p>The default is <b>rip1orrip2</b>.</p>

<b>ip rip</b>	
<b>followed by:</b>	
<b>send version &lt;version&gt;</b>	<p>Indicates which version of RIP updates the router sends on this interface. The options for <b>version</b> are:</p> <ul style="list-style-type: none"> <li>• <b>notsend</b> — no updates are sent.</li> <li>• <b>rip1</b> — RIP version 1 (complies with RFC 1058; updates are broadcast).</li> <li>• <b>rip1comp</b> — compatible with RIP version 1 (RIP version 2 updates are broadcast using RFC 1058 route subsumption rules).</li> <li>• <b>rip2</b> — RIP version 2 (complies with RFC 2453; updates are multicast).</li> </ul> <p>The default is <b>rip1comp</b>.</p>
<b>supply &lt;enable disable&gt;</b>	Enables or disables the interface to supply RIP updates.
<b>timeout &lt;seconds&gt;</b>	<p>Sets the RIP timeout interval for the interface.</p> <ul style="list-style-type: none"> <li>• <b>seconds</b> is an integer value with a range of 15 to 259200.</li> </ul> <p>The default value is set indirectly by the global update time parameter. By default, the timeout timer is set at 6 times the update timer, in accordance with the RFC specification. With a default global update timer setting of 30 seconds, the default timeout interval is 180 seconds.</p> <p>Configure the timeout parameter on the interface only if you want to break the relationship with the update timer. For example, if you have set the global update parameter to a very short interval in order to minimize the problem of fast convergence, the associated default timeout may be too short. In this case, configure the timeout interval manually.</p>

<b>ip rip</b>	
<b>followed by:</b>	
	The interface timer setting overrides the global parameter. However, if you subsequently reset the global parameter, the global setting then overrides the interface timer setting.  The timeout interval must be greater than the global update time parameter.
<b>triggered &lt;enable disable&gt;</b>	Enables or disables automatic triggered updates for RIP on this interface. The default is disabled.

### Command mode

Interface configuration mode

## ip route

Use this command to create a new static route. You create static routes in order to route traffic from the Ethernet Routing Switch 8300 to other devices in the network, like an Ethernet Routing Switch 8600.

### Syntax

```
ip route [route] [mask] [next-hop] [cost] preference
<value> <enable | disable>
<weight>
```

### Parameters

This command includes the following parameters:

<b>ip route &lt;ipaddr/mask&gt;</b>	
<b>followed by:</b>	
[route] [mask] [next-hop] [cost]	<p>Adds a static or default route to the switch.</p> <p><i>route/mask</i> is the IP address and mask for the route's destination.</p> <p><i>next-hop &lt;value&gt;</i> is the IP address of the next hop router; the next router at which packets must arrive on this route.</p> <p><i>cost &lt;value&gt;</i> is the metric of the route. Valid values here are from 1-65535.</p>

<b>ip route &lt;ipaddr/mask&gt;</b> <b>followed by:</b>	
<b>preference &lt;value&gt;</b>	<i>preference &lt;value&gt;</i> specifies the route preference value assigned to the routes. Valid values range from 1-255, with a default of 1.
<b>&lt;enable disable&gt;</b>	Enables or disables the route.
<b>&lt;weight&gt;</b>	Specifies the route weight. Valid values range from 1-255.

**Command mode**

Global configuration mode

**no ip route**

Use this command to delete a static route.

**Syntax**`no ip route [route] [mask] [next-hop <value>]`**Parameters**

This command includes the following parameters:

<b>no ip route</b>	
<b>followed by:</b>	
[route] [mask] [next-hop]	<p>Deletes a static or default route to the switch.</p> <p>route/mask is the IP address and mask for the route's destination.</p> <p>next-hop &lt;value&gt; is the IP address of the next hop router; the next router at which packets must arrive on this route.</p>

**Command mode**

Global configuration mode

**ip route preference protocol**

Use this command to configure route preferences by protocol.

**Syntax**`ip route preference protocol {static|rip} <value>`

where **value** is an integer value with a range of 0 to 255, indicating the preference. The value of 0 is reserved for local routes. If two protocols have the same configured value, the default value is used to break the tie. The default preference values are:

- local routes = 0
- static routes = 5
- RIP routes = 100

This command includes the following options

<code>ip route preference protocol {static rip}&lt;value&gt;</code>	
<code>ospf-intra</code>	Specifies the protocol type OSPF-intra.
<code>ospf-inter</code>	Specifies the protocol type OSPF-inter.
<code>ospf-extern1</code>	Specifies the protocol type OSPF-extern1.
<code>ospf-extern2</code>	Specifies the protocol type OSPF-extern2.

### Command mode

Global configuration mode

## lldp

Use this command to set the LLDP transmission parameters.

### Syntax

```
lldp [tx-interval <5-32768>] [tx-hold-multiplier <2-10>]
[reinit-delay <1-10>] [tx-delay <1-8192>] [med-fast-start
<1-10>]
```

### Parameter

This command includes the following parameters:

lldp	
followed by	
<code>tx-interval &lt;5-32768&gt;</code>	sets the global interval between successive transmission cycles (default value is 30)
<code>tx-hold-multiplier &lt;2-10&gt;</code>	sets the multiplier for the tx-interval used to compute the Time To Live value for the TTL TLV (default value is 4)
<code>reinit-delay &lt;1-10&gt;</code>	sets the delay for the reinitialization attempt if the adminStatus is disabled (default value is 2)

<b>lldp</b>	
<b>followed by</b>	
<b>tx-delay</b> <i>&lt;1-8192&gt;</i>	sets the minimum delay between successive LLDP frame transmissions (default value is 2)
<b>med-fast-start</b> <i>&lt;1-10&gt;</i>	sets the MED Fast Start repeat count value (default value is 3)

### Command mode

Global configuration mode

## default lldp

Use this command to set the LLDP transmission parameters to their default values. If no parameters are specified, the default lldp sets all parameters to their default parameters.

### Syntax

```
default lldp [tx-interval] [tx-hold-multiplier]
[reinit-delay] [tx-delay] [med-fast-start]
```

### Command mode

Global configuration mode

## lldp port status

Use this command to set the LLDPDU transmit and receive status on the ports.

rxonly: enables LLDPDU receive only.

txAndRx: enables LLDPDU transmit and receive.

txOnly: enables LLDPDU transmit only. (default value is txAndRx)

### Syntax

```
lldp port <portlist> status {rxOnly | txAndRx | txOnly}
```

### Command mode

Interface configuration mode

## no lldp port

Use this command to disable LLDP features on the port,

### Syntax

```
no lldp port <portlist> [status]
```

**Command mode**

Interface configuration mode

**default lldp port**

This command sets the LLDP port parameters to their default values.

**Syntax**

```
default lldp port <portlist> [status]
```

**Command mode**

Interface configuration mode

**lldp tx-tlv**

This command sets the optional Management TLVs to be included in the transmitted LLDPDUs.

**Syntax**

```
lldp [port <portlist>] tx-tlv [port-desc] [sys-name]
[sys-desc] [sys-cap] [local-mgmt-addr]
```

**Command mode**

Interface configuration mode

**lldp port status**

This command sets the LLDPDU transmit and receive status on the ports.

rxonly: enables LLDPDU receive only.

txAndRx: enables LLDPDU transmit and receive.

txOnly: enables LLDPDU transmit only. (default value is txAndRx)

**Syntax**

```
lldp port <portlist> status {rxOnly | txAndRx | txOnly}
```

**Command mode**

Interface configuration mode

**no lldp status**

This command disables the LLDP features on the port.

**Syntax**

```
no lldp [status]
```

**Command mode**

Interface configuration mode

## default lldp port

This command sets the LLDP port parameters to their default values.

### Syntax

```
default lldp port <portlist> [status]
```

### Command mode

Interface configuration mode

## lldp tx-tlv

This command set the optional Management TLVs to be included in the transmitted LLDPDUs.

### Syntax

```
lldp [port <portlist> tx-tlv [port-desc] [sys-name]
[sys-desc] [sys-cap] [local-mgmt-addr]
```

### Parameters

This command includes the following parameters:

lldp [port <portlist> tx-tlv followed by	
<b>port-desc</b>	port description TLV (default value is false: not included)
<b>sys-name</b>	system name TLV (default value is false: not included)
<b>sys-desc</b>	system description TLV (default value is false: not included)
<b>sys-cap</b>	system capabilities TLV (default value is false: not included)
<b>local-mgmt-addr</b>	local management address TLV (default value is false: not included)

### Command mode

Interface configuration mode

## no lldp tx-tlv

This command specifies the optional Management TLVs not to include in the transmitted LLDPDUs

### Syntax

```
no lldp [port <portlist> tx-tlv [port-desc] [sys-name]
[sys-desc] [sys-cap] [local-mgmt-addr]
```

### Command mode

Interface configuration mode

## **default lldp tx-tlv**

This command sets the LLDP Management TLVs to their default values,

### **Syntax**

```
default lldp [port <portlist> tx-tlv [port-desc] [sys-name]
[sys-desc] [sys-cap] [local-mgmt-addr]
```

### **Command mode**

Interface configuration mode

## **lldp tx-tlv dot1**

This command sets the optional IEEE 802.1 organizationally-specific TLVs to be included in the transmitted LLDPDUs

### **Syntax**

```
lldp [port <portlist> tx-tlv dot1 [port-vlan-id] [vlan-name]
[port-protocol-vlan-id] [protocol-identity {EAP | LLDP | STP}
]
```

### **Parameters**

This command includes the following parameters:

<b>lldp [port &lt;portlist&gt; tx-tlv dot1]</b>	
<b>followed by</b>	
<b>port-vlan-id</b>	Port VLAN ID TLV (default value is false: not included)
<b>vlan-name</b>	VLAN Name TLV (default value is none)
<b>port-protocol-vlan-id</b>	Port and Protocol VLAN ID TLV (default value is none)
<b>protocol-identity {EAP   LLDP   STP}</b>	Protocol Identity TLV (default value is none)

### **Command mode**

Interface configuration mode

## **no lldp tx-tlv dot1**

This command specifies the optional IEEE 802.1 TLVs to exclude in the transmitted LLDPDUs.

### **Syntax**

```
no lldp [port <portlist>] tx-tlv dot1 [port-vlan-id]
[vlan-name] [port-protocol-vlan-id] [protocol-identity { EAP
| LLDP | STP } ]
```

### **Command mode**

Interface configuration mode

## default lldp tx-tlv dot1

This command resets the optional IEEE 802.1 organizationally-specific TLVs to their default values.

### Syntax

```
default lldp [port <portlist>] tx-tlv dot1 [port-vlan-id]
[vlan-name] [port-protocol-vlan-id] [protocol-identity {EAP
| LLDP | STP} ]
```

### Command mode

Interface configuration mode

## lldp tx-tlv dot3

This command specifies the optional IEEE 802.3 organizationally-specific TLVs to be included in the transmitted LLDPDUs.

### Syntax

```
lldp [port <portlist>] tx-tlv dot3 [mac-phy-config-status]
[mdi-power-support] [link-aggregation] [maximum-frame-size]
```

### Parameters

This command includes the following parameters:

<b>lldp [port &lt;portlist&gt;] tx-tlv dot3</b>	
<b>followed by</b>	
<b>mac-phy-config-status</b>	MAC/Phy Configuration/Status TLV (default value is false: not included)
<b>mdi-power-support</b>	Power Via MDI TLV (default value is false: not included)
<b>link-aggregation</b>	Link Aggregation TLV (default value is false: not included)
<b>maximum-frame-size</b>	Maximum Frame Size TLV (default value is false: not included)

### Command mode

Interface configuration mode

## no lldp tx-tlv dot3

This command specifies the optional IEEE 802.3 TLVs not to include in the transmitted LLDPDUs.

### Syntax

```
no lldp [port <portlist>] tx-tlv dot3 [mac-phy-
config-status] [mdi-power-support] [link-aggregation]
[maximum-frame-size]
```

**Command mode**

Interface configuration mode

**default lldp tx-tlv dot3**

This command sets the optional IEEE 802.3 organizationally-specific TLVs to their default values.

**Syntax**

```
default lldp [port <portlist>] tx-tlv dot3 [mac-phy-
config-status] [mdi-power-support] [link-aggregation]
[maximum-frame-size]
```

**Command mode**

Interface configuration mode

**lldp tx-tlv med**

This command specifies the optional organizationally-specific TLVs for use by MED devices to be included in the transmitted LLDPDUs.

**Syntax**

```
lldp [port <portlist>] tx-tlv med [capabilities]
[network-policy] [location] [extendedPSE]
```

**Parameters**

This command includes the following parameters:

lldp [port <portlist>] tx-tlv med	
followed by	
<b>capabilities</b>	Enables MED capabilities TLV (default value is false: not included).
<b>extendedPSE</b>	Enables extended PSE TLV (default value is false: not included).
<b>location</b>	Enables location Identification TLV (default value is false: not included).
<b>network-policy</b>	Enables Network Policy TLV (default value is false: not included).

**Command mode**

Interface configuration mode

**no lldp tx-tlv med**

This command specifies the optional Management TLVs not to include in the transmitted LLDPDUs.

**Syntax**

```
no lldp [port <portlist>] tx-tlv med [capabilities]
[extendedPSE] [location] [network-policy]
```

**Command mode**

Interface configuration mode

**default lldp tx-tlv med**

This command sets the optional organizationally-specific TLVs for MED devices to their default values.

**Syntax**

```
default lldp [port <portlist>] tx-tlv med [capabilities]
[extendedPSE] [location] [network-policy]
```

**Command mode**

Interface configuration mode

**lldp location-identification civic-address**

This command specifies LLDP civic address parameters. Note: The maximum total size for the civic-address TLV is 256 bytes. If this TLV is any larger, the 8300 Series switch does not transmit it.

**Syntax**

```
lldp location-identification civic-address [country-code]
[additional-code] [additional-information] [apartment]
[block] [building] [city] [city-district] [county]
[floor] [house-number] [house-number-suffix] [landmark]
[leading-street-direction] [name] [p.o.box] [place-type]
[postal-community-name] [postal/zip-code] [room-number]
[state] [street] [street-suffix] [trailing-street-suffix]
```

**Command mode**

Interface configuration mode

**Parameters**

This command includes the following parameters:

<b>lldp location-identification civic-address</b>	
<b>followed by</b>	
<b>country-code</b>	Country code value
<b>additional-code</b>	Additional code
<b>additional-information</b>	Additional location information
<b>apartment</b>	Unit (apartment, suite)
<b>block</b>	Neighborhood, block

<b>lldp location-identification civic-address followed by</b>	
<b>building</b>	Building (structure)
<b>city</b>	City, township, shi (JP)
<b>city-district</b>	City division, city district, ward
<b>county</b>	County, parish, gun (JP), district (IN)
<b>floor</b>	Floor
<b>house-number</b>	House number
<b>house-number-suffix</b>	House number suffix
<b>landmark</b>	Landmark or vanity address
<b>leading-street-direction</b>	Leading street direction
<b>name</b>	Residence and office occupant
<b>pobox</b>	Post office box
<b>place-type</b>	Office
<b>postal-community-name</b>	Postal community name
<b>zip-code</b>	Zip code
<b>room-number</b>	Room number
<b>state</b>	National subdivisions (state, canton, region)
<b>street</b>	Street
<b>street-suffix</b>	Street suffix
<b>trailing-street-suffix</b>	Trailing street suffix

## manualtrigger ip rip interface vlan

Use this command to execute a manually triggered RIP update on a specified VLAN interface.

### Syntax

```
manualtrigger ip rip interface vlan <vid>
```

where

**vid** is the VLAN ID.

### Command mode

User EXEC mode

## network

In addition to being enabled globally on the switch, RIP must be enabled separately on each participating interface.

This command enables RIP on an interface.

### Syntax

```
network <ipaddr>
```

where

**ipaddr** indicates the IP address of the interface.

### Command mode

Router Configuration mode

## no network

Use this command to disable RIP on an interface.

### Syntax

```
no network <ipaddr>
```

where

**ipaddr** indicates the IP address of the interface.

### Command mode

Router Configuration mode

## network

This command enables OSPF on an interface:

### Syntax

```
network <ipaddr>
```

where:

- <ipaddr> is the interface network ip address.

To set OSPF on an interface to a default condition, use the following command:

```
default network <ipaddr>
```

To cancel or delete OSPF on an interface, use the following command:

```
no network <ipaddr>
```

### Command mode

Router Config mode.

## network area

This command sets an OSPF interface on a particular OSPF area:

**Syntax**

```
network <ipaddr> area <ipaddr>
```

where:

- <ipaddr> is interface network ip address.
- <ipaddr> is the area ID.

To set an OSPF interface on a particular OSPF area to a default condition, use the following command:

```
default network <ipaddr> area <ipaddr>
```

To cancel or delete an OSPF interface on a particular OSPF area, use the following command:

```
no network <ipaddr> area <ipaddr>
```

**Command mode**

Router Configuration mode.

**redistribute enable**

This command enables OSPF redistribution:

**Syntax**

```
redistribute enable
```

To set OSPF redistribution to a default condition, use the following command:

```
default redistribute enable
```

To cancel or delete OSPF redistribution, use the following command:

```
no redistribute enable
```

**Command mode**

Router Configuration mode.

**redistribute source**

This command creates OSPF redistribution from particular source, metric and type:

**Syntax**

```
redistribute source [direct|rip|static] [enable|metric
<0-65535> | metric-type [type1|type2|any] | route-policy
WORD<0-64> | subnets [allow|suppress]]
```

where:

- [direct|rip|static] is source type

- <0-65535> is metric value
- [type1|type2|any] is metric type
- WORD<0-64> is policy name
- [allow|supress] is subnet redistribute type

To set OSPF redistribution from particular source, metric and type to a default condition, use the following command:

```
default redistribute source [direct|rip|static]
[enable|metric <0-65535>| metric-type
[type1|type2|any] |route-policy WORD<0-64>| subnets
[allow|supress]]
```

To cancel or delete OSPF redistribution from particular source, metric and type,use the following command:

```
no redistribute source [direct|rip|static] [enable|metric
<0-65535>| metric-type [type1|type2|any] |route-policy
WORD<0-64>| subnets [allow|supress]]
```

### **Command mode**

Router Configuration mode.

## **route-map**

This command allows you to create a route policy and specify the action to be taken when a route policy is selected for a specific route.

### **Syntax**

```
route-map <policy name>
```

where

**policy name** is a string length {0..64}indicating the name you assigned to the policy

The **route-map <policy name>** command includes the following parameters.

<b>route-map &lt;policy name&gt;</b> <b>followed by:</b>	
<seq number>	Specifies the sequence number. The range is 1 to 65535.
permit [<seq number>]	Allows the route.
deny [<seq number>]	Denies the route.

## Command mode

Global configuration mode

### route-map

This command allows you to enable and configure a route policy.

#### Syntax

```
route-map <policy name> <seq number>
```

where:

- **policy name** is a string length {0..64} indicating the name assigned to the policy
- **seq number** indicates the sequence number. The range is 1 to 65535.

**Note:** You must enable a route policy before you can configure its match and set parameters.

#### Parameter

This command includes the following parameters.

<pre>route-map &lt;policy name&gt; &lt;seq number&gt;</pre>	
<b>followed by:</b>	
<b>enable</b>	Enables the route policy with the policy name and sequence number specified in the command.
<b>match [interface &lt;prefix-list&gt; ] [metric &lt;metric&gt;] [network &lt;prefix-list&gt;] [next-hop &lt;prefix-list&gt;] [protocol &lt;protocol name&gt;] [route-source &lt;prefix-list&gt;]</b>	<p>If configured, the switch matches the specified criterion:</p> <ul style="list-style-type: none"> <li>• <b>interface &lt;prefix-list&gt;</b> — matches the IP address of the received interface against the contents of the specified prefix list, where <b>prefix-list</b> is a string length {0..1027}. Applicable to RIP only.</li> <li>• <b>metric &lt;metric&gt;</b> — matches the metric of the incoming advertisement or existing route against the specified value, where <b>metric</b> is an integer value with a range of 0 to 65535. If 0, then this field is ignored. The default is 0.</li> <li>• <b>network &lt;prefix-list&gt;</b> — matches the destination network against the contents of the specified prefix list, where <b>prefix-list</b> is a string length {0..1027}.</li> </ul>

<b>route-map &lt;policy name&gt; &lt;seq number&gt;</b>	
---	--

**followed by:**

	<ul style="list-style-type: none"> <li>• <b>next-hop &lt;prefix-list&gt;</b> — matches the next hop IP address of the route against the contents of the specified prefix list, where <b>prefix-list</b> is a string length {0..1027}.</li> <li>• <b>protocol &lt;protocol name&gt;</b> — matches the protocol through which the route is learned, where <b>protocol name</b> {any xxx} is a string length {0..40} and <b>xxx</b> is local rip static or any combination separated by   (vertical line). Used for RIP announce policies only.</li> <li>• <b>route-source &lt;prefix-list&gt;</b> — matches the source IP address for RIP routes against the contents of the specified prefix list, where <b>prefix-list</b> is a string length {0..1027}. This field is ignored for all other route types.</li> </ul>
<b>name &lt;policy name&gt;</b>	<p>Renames a policy once it has been created. This command changes the name field for all sequence numbers under the given policy.</p> <ul style="list-style-type: none"> <li>• <b>policy name</b> is a string length {0..64}.</li> </ul>
<b>set [injectlist &lt;prefix-list&gt; ] [ip-preference &lt;pref-value&gt; ] [mask &lt;ipaddr&gt; ]</b>	<p>If configured, the switch sets the specified parameter:</p> <ul style="list-style-type: none"> <li>• <b>injectlist &lt;prefix-list&gt;</b> — replaces the destination network of the route that matches this policy with the contents of the specified prefix list, where <b>prefix-list</b> is a string length {0..1027}.</li> <li>• <b>ip-preference &lt;pref-value&gt;</b> — specifies the route preference value to be assigned to the route that matches this policy, where <b>pref-value</b> is an integer value with a range of 0 to 255. If 0, the global preference value is used. The default is 0. Used for accept policies only.</li> <li>• <b>mask &lt;ipaddr&gt;</b> — sets the mask of the route that matches this policy, where <b>ipaddr</b> is a valid contiguous IP mask. Used for RIP accept policies only.</li> </ul>

## Command mode

Global configuration mode

**no route-map**

This command allows to delete a route policy.

**Syntax**

```
no route-map <policy name> <seq number>
```

where:

- **policy name** is a string length {0..64} indicating the name assigned to the policy
- **seq number** indicates the sequence number. The range is 1 to 65535.

**Command mode**

Global configuration mode

**router ospf**

This command allows you to enter Router Config mode for OSPF. Once in Router Config mode, you can configure OSPF global parameters:

**Syntax**

```
router ospf
```

**Command mode**

Global configuration mode

**router ospf enable**

This command enables OSPF globally on the switch

**Syntax**

```
router ospf enable
```

To disable OSPF globally on the switch, use the following command:

```
no router ospf enable
```

**Command mode**

Global configuration mode

**no router ospf enable**

This command disables OSPF globally on the switch

**Syntax**

```
no router ospf enable
```

**Command mode**

Global configuration mode

**router rip**

This command allows you to enter Router Config mode for RIP. Once in Router Config mode, you can configure the RIP global timer and default metric parameters:

**Syntax**

```
router rip
```

**Command mode**

Global configuration mode

**router rip enable**

This command enables RIP globally on the switch.

**Syntax**

```
router rip enable
```

**Command mode**

Global configuration mode

**no router rip enable**

This command disables RIP globally on the switch.

**Syntax**

```
no router rip enable
```

**Command mode**

Global configuration mode

**router-id**

This command sets the OSPF router ID:

**Syntax**

```
router-id <ipaddr>
```

where:

- <ipaddr> is the router ID.

To set OSPF router ID to a default condition, use the following command:

```
default router-id <ipaddr>
```

To cancel or delete OSPF router ID, use the following command:

```
no router-id <ipaddr>
```

**Command mode**

Router Configuration mode

**slpp**

This command is used to configure Simple Loop Protection Protocol (SLPP).

**Syntax**`slpp`**Parameters**

This command includes the following parameters:

Parameter	Description
<code>operation</code>	Enables the SLPP operation.
<code>ethertype &lt;1-65535   0x1-0xffff&gt;</code>	Specifies the SLPP PDU ether type. Enter a value from 1 to 65535 in hexadecimal (0x8104) or decimal (33028) format. The default is 0x8104.
<code>tx-interval &lt;500-5000&gt;</code>	Sets the SLPP packet transmit interval. The range is 500 to 5000 ms, and the default is 500 ms.
<code>vid &lt;1-4000&gt;</code>	Adds VLANs to a SLPP transmission list. Enter a vlan id from 1-4000.

**Command mode**

Global configuration mode

**Default slpp**

Use this command to set the SLPP parameters to default.

**Syntax**`default slpp`**Parameters**

Parameter	Description
<code>operation</code>	Sets the SLPP operation to default: disable.

Parameter	Description
<b>ethertype</b>	Sets the SLPP PDU ether type to default: 0x8104.
<b>tx-interval</b>	Sets the SLPP packet transmit interval to default: 500 ms.

**Command mode**

Global configuration mode

**no slpp**

Use this command to disable SLPP parameters.

**Syntax**`no slpp`**Parameters**

This command includes the following parameters:

Parameter	Description
<b>&lt;cr&gt;</b>	Indicates a carriage return.
<b>operation</b>	Disables the SLPP operation.
<b>vid &lt;1-4000&gt;</b>	Deletes VLANs from a SLPP transmission list. Enter a VLAN ID from 1-4000.

**Command mode**

Global configuration mode

**slpp port**

Use this command to configure SLPP on a port.

**Syntax**`slpp port [port <portlist>] [packet-rx ] [packet-rx-threshold]`

where

`<portlist>` is the slot/port.

## Parameters

This command includes the following parameters:

Parameter	Description
<b>packet-rx</b>	Enables SLPP packet reception on the listed ports.
<b>packet-rx-threshold</b>	Specifies the SLPP reception threshold on the ports. Enter a value from 1-500.

## Command mode

Interface fastethernet or gigabitethernet mode

## default slpp port

Use this command to set the SLPP parameters on a port to default.

### Syntax

```
default slpp [port<portlist>] [packet-rx ] [packet-rx-
threshold]
```

where

**portlist** is the slot/port.

### Parameters

This command includes the following parameters:

Parameter	Description
<b>packet-rx</b>	Sets the SLPP operation on the listed port or ports to default:disable
<b>packet-rx-threshold</b>	Sets the SLPP PDU reception threshold on the ports to default: 1.

## Command mode

Interface fastethernet or gigabitethernet mode

## no slpp port

Use this command to cancel the configuration of SLPP parameters.

**Syntax**

```
no slpp [port <portlist>] [packet-rx]
```

where

<portlist> is the slot/port.

**Parameters**

This command includes the following parameter:

Parameter	Description
packet-rx	Disables SLPP packet reception on the listed ports

**Command mode**

Interface fastethernet or gigabitethernet mode

**show interface loopback**

This command allows you to view the CLIP interfaces, enter the following command in any mode:

**Syntax**

```
show interface loopback
```

**show ip arp**

Use this command to display the Address Resolution Protocol (ARP) table.

**Syntax**

```
show ip arp [ip <ipaddr>] [-s <value>]
```

**Parameters**

This command includes the following options:

<pre>show ip arp</pre> <b>followed by:</b>	
[<ipaddress>]	Specifies the selected net IP address for the table.
[-s <value>] [-s<value>]	Specifies the selected subnet in the format: {a.b.c.d/x   a.b.c.d/x.x.x.x   default}

**Command mode**

Interface configuration mode

**show ip dhcp-relay fwd-path**

This command display the dhcp-relay forward path

**Syntax**

```
show ip dhcp-relay fwd-path
```

**Command mode**

Privileged EXEC mode

**show ip dhcp-relay counters**

This command displays the ip dhcp-relay counters.

**Syntax**

```
show ip dhcp-relay counters
```

**Command mode**

Privileged EXEC mode

**show ip forward-protocol udp**

This command allows you to view the existing UDP forwarding protocol.

**Syntax**

```
show ip forward-protocol udp
```

**Command mode**

User EXEC mode

**show ip forward-protocol udp portfwlist**

This command allows you to display a list of all UDP forwarding policies.

**Syntax**

```
show ip forward-protocol udp portfwlist [<listid>]
```

where

**listid** is the specific UDP forwarding policy number. Allowable values range from 1 to 1000. If a **listid** is specified, then the system only shows protocols and forwarding addresses for that UDP forwarding policy. If no **listid** is specified, then the system shows all UDP forwarding policies.

**Command mode**

User EXEC mode

## show ip forward-protocol udp interface

This command allows you to display all UDP forwarding policies applied to this interface, together with settings and general usage statistics for each forwarding policy:

### Syntax

```
show ip forward-protocol udp interface
```

### Parameter

This command includes the following parameters:

<b>ip forward-protocol udp interface</b>	
<b>followed by:</b>	
[vlan <vlan> ]	<p>Display the UDP forwarding policy applied to an existing VLAN. If no VLAN ID number is provided, applied policies to all interfaces are shown.</p> <ul style="list-style-type: none"> <li>• <b>vlan</b> is a specific vlan ID number. Allowable values range from 1 to 4000.</li> </ul>

## show ip global

Use this command to display the global IP configuration settings.

### Syntax

```
show ip global
```

### Command mode

Interface configuration mode

## show ip interface

Use this command to display the IP interfaces on the switch.

### Syntax

```
show ip interface
```

### Command mode

User EXEC mode

## show ip irdp

Use this command to view the router discovery status.

### Syntax

```
show ip irdp
```

**Command mode**

User EXEC mode

**show ip irdp interface**

Use this command to view the router discovery status on ports.

**Syntax**

```
show ip irdp interface {fastethernet|gigabitethernet}
```

**Command mode**

User EXEC mode

**show ip irdp interface vlan**

Use this command to view the router discovery status on VLANs.

**Syntax**

```
show ip irdp interface vlan [<vid>]
```

where

[<vid>] is the ID of the selected VLAM. It is an integer in the range of 1 to 4000.

**Command mode**

User EXEC mode

**show ip ospf**

This command displays information about the OSPF general configuration:

**Syntax**

```
show ip ospf
```

**Command mode**

User EXEC mode

**show ip ospf accept**

This command displays information about the OSPF router acceptance parameter configuration:

**Syntax**

```
show ip ospf accept
```

**Command mode**

User EXEC mode

**show ip ospf area**

This command displays information about the OSPF area configuration:

---

**Syntax**

```
show ip ospf area
```

**Parameters**

This command includes the following parameters:

<b>show ip ospf area</b> followed by:	
<cr>	Display ospf area information. <cr> is carriage return.
<ipaddr>	Display ospf area information with area ID. <ipaddr> is area ID.
<b>area-range</b>	Display ospf area range information
<b>area-range &lt;ipaddr&gt;</b>	Display ospf area range information with area ID. <ipaddr> is area ID.

**Command mode**

User EXEC mode

**show ip ospf ase**

This command displays information about the OSPF external lsas configuration:

**Syntax**

```
show ip ospf ase
```

**Parameters**

This command includes the following parameters:

<b>show ip ospf ase</b> followed by:	
<cr>	Display ospf external lsas information. <cr> is carriage return.
<b>metric-type&lt;1-2&gt;</b>	Display ospf external lsas metric-type information. <1-2> is metric type 1 or type 2.

**Command mode**

User EXEC mode

**show ip ospf authentication interface**

This command displays information about the OSPF interface authentication configuration:

**Syntax**

```
show ip ospf authentication interface
```

**Parameters**

This command includes the following parameters:

<b>show ip ospf authentication interface</b>	
<b>followed by</b>	
<b>&lt;cr&gt;</b>	Display ospf authentication on interface. <cr> is carriage return.
<b>vlan</b>	Display ospf authentication on vlan interface.
<b>vlan &lt;1-4094&gt;</b>	Display ospf authentication on particular vlan interface. <1-4094> is the vlan ID.

**Command mode**

User EXEC mode

**show ip ospf default-metric**

This command displays information about the OSPF default-metric configuration:

**Syntax**

```
show ip ospf default-metric
```

**Command mode**

User EXEC mode

**show ip ospf host-route**

This command displays information about the OSPF host-route configuration:

**Syntax**

```
show ip ospf host-route
```

**Command mode**

User EXEC mode

**show ip ospf ifstats**

This command displays information about the OSPF interface statistics:

**Syntax**

```
show ip ospf ifstats [detail|mismatch|<ipaddr>]
```

where:

- *detail* is shown more detail information

- *mismatch* is shown mismatch information
- <ipaddr> is interface ip address

**Command mode**

User EXEC mode

**show ip ospf int-auth**

This command displays information about the OSPF authentication configuration:

**Syntax**

```
show ip ospf int-auth
```

**Command mode**

User EXEC mode

**show ip ospf int-timers**

This command displays information about the OSPF timers configuration:

**Syntax**

```
show ip ospf int-timers
```

**Command mode**

User EXEC mode

**show ip ospf interface**

This command displays information about the OSPF interface configuration:

**Syntax**

```
show ip ospf interface
```

**Parameters**

This command includes the following parameters:

<b>show ip ospf interface</b> followed by	
<cr>	Display ospf interface information. <cr> is carriage return.
vlan	Display ospf vlan interface information.
vlan <1-4094>	Display ospf information on particular vlan interface. <1-4094> is the vlan ID.

**Command mode**

User EXEC mode

## show ip ospf lsdb

This command displays information about the OSPF lsdb configuration:

### Syntax

```
show ip ospf lsdb
```

### Parameters

This command includes the following parameters:

<b>show ip ospf lsdb</b> followed by	
<cr>	Display ospf lsdb info information. <cr> is carriage return.
adv-rtr <ipaddr>	Display ospf lsdb information on particular advertisement router. <ipaddr> is router ID.
adv-rtr <ipaddr> detail	Display ospf detail lsdb information on particular advertisement router. <ipaddr> is router ID.
area <ipaddr>	Display ospf lsdb information on particular area. <ipaddr> is area ID.
detail	Display ospf detail lsdb information.
lsa-type lsa-type <0-7>	Display particular type of ospf lsdb information. <0-7> is for typ1 to type 7.
lsid <ipaddr>	Display ospf lsdb infomation with a particular lsid. <ipaddr> is lsid ID.

### Command mode

User EXEC mode

## show ip ospf neighbours interface

This command displays information about OSPF neighbours:

### Syntax

```
show ip ospf neighbours interface
```

### Parameters

This command includes the following parameters:

<b>show ip ospf interface</b> followed by	
<cr>	Display all ospf neighbours. <cr> is carriage return.

<b>show ip ospf interface followed by</b>	
<b>vlan</b>	Display all ospf neighbours on a vlan interface.
<b>vlan &lt;1-4094&gt;</b>	Display all ospf neighbours on a particular vlan interface. <1-4094> is the vlan ID.

**Command mode**

User EXEC mode

**show ip ospf redistribute**

This command displays information about the OSPF redistribute configuration:

**Syntax**

```
show ip ospf redistribute
```

**Command mode**

User EXEC mode

**show ip ospf stats**

This command displays information about the OSPF statistics:

**Syntax**

```
show ip ospf stats
```

**Command mode**

User EXEC mode

**show ip ospf timer interface**

This command displays information about OSPF interface timers:

**Syntax**

```
show ip ospf timer interface
```

**Parameters**

This command includes the following parameters:

<b>show ip ospf timer interface followed by</b>	
<b>&lt;cr&gt;</b>	Display ospf timers information on an interface. <cr> is carriage return.

<b>show ip ospf timer interface</b> followed by	
vlan	Display ospf timers information on a vlan interface.
vlan <1-4094>	Display ospf timers information on a particular vlan interface. <1-4094> is the vlan ID.

**Command mode**

User EXEC mode

**show ip prefix-list**

This command allows you to view prefix list information:

**Syntax**`show ip prefix-list`**Command mode**

User EXEC mode

**show ip rip**

Use this command to display information about the RIP global configuration on the switch.

**Syntax**`show ip rip`**Command mode**

Global or Interface configuration mode

**show ip rip interface**

Use this command to display information about a specific RIP interface or all RIP interfaces on the switch.

**Syntax**`show ip rip interface [vlan <vid> ]`

where

`vid` is the interface VLAN ID.**Command mode**

Global or Interface configuration mode

## show ip route

Use this command to display the existing IP route table for the switch or for a specific net or subnet.

### Syntax

```
show ip route [<ipaddr>] [-s <value>] [alternative]
```

### Parameters

This command includes the following options:

<code>show ip route</code>	
<b>followed by:</b>	
<code>[-s &lt;value&gt;]</code>	Specifies a subnet in the format: {a.b.c.d x.x.x.x}.
<code>[alternative]</code>	Displays alternative routes.
<code>&lt;iipaddr&gt;</code>	Specifies the selected net IP address: (1.2. = 1.2.0.0) {a.b.c.d}.

### Command mode

Interface configuration mode

## show ip routing

Use this command to display the status of IP routing on the switch.

### Syntax

```
show ip routing
```

### Command mode

Interface configuration mode

## show route-map

This command allows you to view a route policy, enter the following command in **User EXEC** mode:

### Syntax

```
show route-map [<policy name> <seq number>][detail]
```

where:

- **policy name** is a string length {0..64} indicating the name assigned to the policy
- **seq number** indicates the sequence number. The range is 1 to 65535.

### Command mode

User EXEC mode

## show ip route

This command allows you to view the route table,

### Syntax

```
show ip route [<ip address>] [-s <value>] [alternative]
```

where:

- **<ip address>** is the specific net (1.2. = 1.2.0.0) {a.b.c.d}.
- **-s <value>** is the specific subnet {a.b.c.d/x|a.b.c.d/x.x.x.x|default}.
- **alternative** specifies the alternative-route you wish to display.

### Command mode

User EXEC mode

## show ip route preference

This command allows you to view route preferences.

### Syntax

```
show ip route preference
```

### Command mode

User EXEC mode

## show ip static-route

Use this command to display the existing IP static routes for the switch or for a specific net or subnet.

### Syntax

```
show ip static-route  
[<ip address>]  
[-s <value>]
```

### Parameters

This command includes the following options:

<code>show ip static-route</code>	
-----------------------------------	--

**followed by:**

[ip <ipaddr>]	Specifies the selected net IP address: (1.2. = 1.2.0.0) {a.b.c.d}.
[-s <value>]	Specifies the selected subnet in the format: {a.b.c.d/x   a.b.c.d/x.x.x.x   default}.

### Command mode

Interface configuration mode

## show ip tcp

Use this command to view the current TCP switch connections.

### Syntax

```
show ip tcp
<info-connections>
<statistics-global>
<properties-global>
```

### Parameters

This command includes the following options:

<code>show ip tcp</code>	
--------------------------	--

**followed by:**

<info-connections>	Displays TCP connection table information.
<statistics-global>	Displays TCP global statistics.
<properties-global>	Displays TCP global statistics.

### Command mode

Interface configuration mode

## show lldp

This command displays the LLDP parameters for the local system.

### Syntax

```
show lldp
```

### Parameters

This command includes the following parameters:

<b>show lldp</b>	
<b>followed by:</b>	
<b>interface [FastEthernet   GigabitEthernet] &lt;portlist&gt;</b>	Displays LLDP port parameters.
<b>local-sys-data {dot1   dot3   med   detail}</b>	<p>Displays the organizationally-specific TLV properties on the local switch:</p> <ul style="list-style-type: none"> <li>• dot1: displays the 802.1 TLV properties</li> <li>• dot3: displays the 802.3 TLV properties</li> <li>• med: displays the MED TLV properties</li> <li>• detail: displays all organizationally specific TLV properties</li> </ul> <p>To display the properties of the optional management TLVs, include only the local-sys-data parameter in the command.</p>
<b>mgmt-sys</b>	Displays the local management system data.
<b>pdu-tlv-size</b>	Displays the different TLV sizes and the number of TLVs in an LLDPDU.
<b>[rx-stats] [FastEthernet   GigabitEthernet] &lt;portlist&gt;</b>	Displays the LLDP receive statistics for ports on the local system.
<b>stats</b>	Displays the LLDP table statistics for the remote system.
<b>[tx-stats] [FastEthernet   GigabitEthernet] &lt;portlist&gt;</b>	Displays the LLDP transmit statistics for ports on the local system.
<b>tx-tlv {dot1   dot3   med   [FastEthernet   GigabitEthernet] &lt;portlist&gt; }</b>	<p>Displays which TLVs are transmitted from the local switch in LLDPDUs:</p> <ul style="list-style-type: none"> <li>• dot1: displays status for 802.1 TLVs</li> <li>• dot3: displays status for 802.3 TLVs</li> <li>• med: displays status for MED TLVs</li> <li>• [FastEthernet   GigabitEthernet] [portlist]</li> <li>• displays the status for management TLVs for specific ports.</li> </ul> <p>To display the transmission status of the optional management TLVs for all ports, include only the tx-tlv parameter in the command.</p>

**Command mode**

User EXEC mode

## show lldp neighbor

This command displays the LLDP parameters for the neighbor system.

### Syntax

```
show lldp neighbor
```

### Parameters

This command includes the following parameters:

<b>show lldp followed by:</b>	
[neighbor [FastEthernet   GigabitEthernet] <portlist>]	Displays the learned LLDP neighbors by port.
neighbor { dot1 [vnlan-names   protocol-id]   [dot3]   { med [capabilities] [network-policy] [location] [extended-power] }   { [FastEthernet   GigabitEthernet] <portlist> }	<p>Displays the neighbor TLVs:</p> <ul style="list-style-type: none"> <li>• dot1: displays 802.1 TLVs: <ul style="list-style-type: none"> <li>— vnlan-names: VLAN Name TLV</li> <li>— protocol-id: Protocol Identity TLV</li> </ul> </li> <li>• dot3: displays 802.3 TLVs</li> <li>• med: displays MED TLVs: <ul style="list-style-type: none"> <li>— capabilities: Capabilities TLV</li> <li>— network-policy: Network Policy Discovery TLV</li> <li>— location: Location Identification TLV</li> <li>— extended-power: Extended Power-via-MDI TL</li> </ul> </li> <li>• [FastEthernet   GigabitEthernet] &lt;portlist&gt; : displays neighbor TLVs for the specified port</li> </ul>

### Command mode

User EXEC mode

## show lldp neighbor-mgmt-addr

Use this command to display the LLDP neighbor management address.

### Syntax

```
show lldp neighbor-mgmt-addr
```

### Parameters

This command includes the following parameters:

<b>show lldp neighbor-mgmt-addr</b> <b>followed by:</b>	
<cr>	Indicates a carriage return.
[FastEthernet   GigabitEthernet]	Specifies the learned LLDP neighbors by type of port.
<portlist>	Displays the learned LLDP neighbors by port.

**Command mode**

Privileged EXEC mode

**show slpp**

Use this command to display SLPP information.

**Syntax**`show slpp`**Command mode**

Privileged EXEC mode

**show ports stats dhcp-relay**

Use this command to display port statistics for dhcp-relay.

**Syntax**`show ports stats dhcp-relay broadcast [ <ports> ]`**Command mode**

Privileged EXEC mode

**show vlan nlb-mode**

Use this command to display the NLBS mode.

**Syntax**`show vlan nlb-mode`**Command mode**

Privileged EXEC mode

**timer basic**

Use this command to set the global update, holddown, and timeout timers.

**Syntax**`timer basic`**Parameter**

This command includes the following options:

<b>timer basic</b>	
<b>followed by:</b>	
<b>holddown &lt;seconds&gt;</b>	<p>Sets the RIP holddown timer. The value of the holddown timer is the length of time (in seconds) that RIP will continue to advertise a network after determining that it is unreachable.</p> <ul style="list-style-type: none"> <li>• <b>seconds</b> is an integer value with a range of 0 to 360. The default is 120 seconds.</li> </ul> <p>The global <b>holddown</b> parameter sets the value of the holddown timer for the VLAN interfaces, but you can override the value for a specific interface.</p>
<b>timeout &lt;seconds&gt;</b>	<p>Sets the RIP timeout interval.</p> <ul style="list-style-type: none"> <li>• <b>seconds</b> is an integer value with a range of 15 to 259200.</li> </ul> <p>The default value is set indirectly by the global update time parameter. By default, the timeout timer is set at 6 times the update timer, in accordance with the RFC specification. With a default global update parameter setting of 30 seconds, the default timeout interval is 180 seconds. The default global timeout setting changes when the global update time parameter is changed.</p> <p>Configure the timeout parameter only if you want to break the relationship with the update timer. For example, if you have set the global update parameter to a very short interval in order to minimize the problem of fast convergence, the associated default timeout may be too short. In this case, configure the timeout interval manually.</p>

<b>timer basic</b>	
<b>followed by:</b>	
	<p>The global <b>timeout</b> parameter sets the value of the timeout timer for the VLAN interfaces, but you can override the value for a specific interface .</p>
<b>update &lt;seconds&gt;</b>	<p>Sets the RIP update timer. The value of the update timer is the time interval (in seconds) between regular RIP updates.</p> <ul style="list-style-type: none"> <li>• <b>seconds</b> is an integer value with a range of 1 to 2147483647. The default is 30 seconds.</li> </ul> <p>The global <b>updatetime</b> parameter sets the update timer for the VLAN interfaces.</p> <p>The <b>updatetime</b> value must be less than the timeout interval.</p>

**Command mode**

Router Configuration mode

**timers basic holddown**

This command sets the OSPF holddown timer value:

**Syntax****timers basic holddown <0-60>**

where:

- <0-60> is holddown timer value in seconds.

To set OSPF holddown timer value to a default value, use the following command in Router Config mode:

**default timers basic holddown****Command mode**

Router Configuration mode.

**trap enable**

This command enables OSPF traps:

**Syntax**

```
trap enable
```

To set OSPF trap to a default condition, use the following command in Router Config mode:

```
default trap enable
```

To disable OSPF traps, use the following command in Router Config mode:

```
no trap enable
```

**Command mode**

Router Configuration mode

**vlan nlb-mode**

Use this command to configure network load balancing (NLBS) on a specific VLAN.

**Syntax**

```
vlan nlb-mode <vid> <igmp-mcast|multicast|unicast>
```

where

<vid> is the VLAN ID from 1 to 4000.

<disable|igmp-mcast|multicast|unicast> specifies the mode of the NLBS feature. NLBS must be in the disable mode, which is the default mode, before you can choose one of the other three modes.

**Command mode**

Global configuration mode

**no vlan nlb-mode**

Use this command to configure NLSB in disable mode.

**Syntax**

```
no vlan nlb-mode <vid>
```

where

<vid> is the VLAN ID from 1 to 4000.

**Command mode**

Global configuration mode



## Layer 2 and 3 operations commands

This chapter describes NNCLI layer 2 and layer 3 operations commands and their parameters.

<b>Layer 2 Operations Commands</b>
<a href="#">"bcast-mcast-rate-limit enable" (page 281)</a>
<a href="#">"ist" (page 282)</a>
<a href="#">"no ist " (page 282)</a>
<a href="#">"ist enable" (page 282)</a>
<a href="#">"no ist enable" (page 283)</a>
<a href="#">"no mlt encapsulation dot1q" (page 283)</a>
<a href="#">"no mlt name" (page 283)</a>
<a href="#">"interface mlt" (page 284)</a>
<a href="#">"smlt" (page 284)</a>
<a href="#">"no smlt" (page 284)</a>
<a href="#">"smlt" (page 284)</a>
<a href="#">"no smlt" (page 285)</a>
<a href="#">"mlt members" (page 285)</a>
<a href="#">"mlt add-vlan" (page 285)</a>
<a href="#">"mlt name" (page 286)</a>
<a href="#">"no mlt members" (page 286)</a>
<a href="#">"mlt remove-vlan" (page 287)</a>
<a href="#">"mlt create" (page 287)</a>
<a href="#">"mlt encapsulation" (page 288)</a>
<a href="#">"no mlt encapsulation" (page 288)</a>
<a href="#">"no mlt" (page 288)</a>
<a href="#">"show mlt" (page 289)</a>
<a href="#">"show mlt error" (page 289)</a>
<a href="#">"show mlt error collision" (page 289)</a>

Layer 2 Operations Commands
"show mlt stats" (page 290)
"show spanning-tree" (page 291)
"show spanning-tree config" (page 291)
"show interface vlan" (page 291)
"show vlan autolearn-mac" (page 292)
"show vlan vid basic" (page 292)
"show vlan vid fdb-filter" (page 293)
"show vlan vid fdb-static" (page 293)
"show interfaces vlan ip" (page 294)
"show vlan manual-edit-mac" (page 294)
"show vlan members" (page 294)
"show vlan static-mcastmac" (page 294)
"spanning-tree stp" (page 295)
"spanning-tree stp add-ports" (page 296)
"spanning-tree stp create" (page 297)
"telnet-access" (page 298)
"spanning-tree stp remove-ports" (page 297)
"no spanning-tree" (page 298)
"vlan action" (page 299)
"vlan add-mlt" (page 299)
"vlan members" (page 300)
"vlan qos-level" (page 301)
"no vlan" (page 301)
"vlan create type port" (page 302)
"vlan create type protocol-ApltkEther2Snap" (page 302)
"vlan create type protocol-decEther2" (page 303)
"vlan create type protocol-decOtherEther2" (page 304)
"vlan create type protocol-ipEther2" (page 305)
"vlan create type protocol-ipv6Ether2" (page 305)
"vlan create type protocol-ipx802.2" (page 306)
"vlan create type protocol-ipx802.3" (page 307)
"vlan create type protocol-ipxEther2" (page 308)
"vlan create type protocol-ipxSnap" (page 308)
"vlan create type protocol-Netbios" (page 309)
"vlan create type protocol-RarpEther2" (page 310)

<b>Layer 2 Operations Commands</b>
"vlan create type protocol-sna802.2" (page 310)
"vlan create type protocol-snaEther2" (page 311)
"vlan create type protocol-Userdef" (page 312)
"vlan create type protocol-vinesEther2" (page 312)
"vlan create type protocol-xnsEther2" (page 313)
"vlan fdb-entry aging-time" (page 314)
"vlan fdb-entry flush" (page 314)
"vlan fdb-entry qos-level" (page 315)
"vlan fdb-entry sync" (page 315)
"vlan fdb-filter add" (page 315)
"no vlan fdb-filter" (page 316)
"vlan fdb-static add" (page 317)
"no vlan fdb-static" (page 317)
"vlan static-mcastmac add" (page 318)
"vlan static-mcastmac add-mlt" (page 318)
"vlan static-mcastmac remove-mlt" (page 319)
"vlan static-mcastmac remove" (page 320)
"vlan static-mcastmac remove-ports" (page 321)
"no vlan static-mcastmac" (page 321)

"interface vlan" (page 322)
"ip address" (page 322)
"no ip address" (page 322)
"ip arp proxy" (page 323)
"no ip arp proxy" (page 323)

## Layer 2 Operations Commands

### bcast-mcast-rate-limit enable

This command enables rate limiting on a port.

#### Syntax

```
bcast-mcast-rate-limit {port <portlist>}<percent value>
enable
```

where

**port <portlist>** is the list of ports, on which you enable rate limiting.

### Parameters

This command includes the following parameters:

Parameter	Description
<b>&lt;percent value&gt;</b>	Specifies the rate limit to use, expressed as a percentage. The value can be from 1-100.

### Command mode

Interface configuration mode

## ist

This command configures an IST MLT from an existing MLT.

### Syntax

```
ist [ip <A,B,C,D>] [vlan <1-4000>]
```

### Parameter

This command includes the following parameters:

Parameter	Description
<b>ip &lt;A,B,C,D&gt;</b>	Specifies the peer IP address for the IST.
<b>vlan &lt;1-4000&gt;</b>	Specifies a VLAN ID for the IST.

### Command mode

MLT Interface Configuration mode

## no ist

This command clears the IST configuration.

### Syntax

```
no ist [ip]
```

where

[ip] specifies the peer IP address for the IST.

### Command mode

MLT Interface Configuration mode

## ist enable

This command enables the IST MLT.

### Syntax

```
ist enable
```

**Command mode**

MLT Interface Configuration mode

**no ist enable**

This command disables the IST.

**Syntax**`no ist enable`**Command mode**

MLT Interface Configuration mode

**no mlt encapsulation dot1q**

This command removes encapsulation from a link aggregation group.

**Syntax**`no mlt <mid> encapsulation dot1q`**Parameters**

This command includes the following parameters:

Parameter	Description
<code>&lt;mid&gt;</code>	Specify a link aggregation group number from 1 to 31.

**Command mode**

Global configuration mode

**no mlt name**

This command removes a link aggregation group name.

**Syntax**`no mlt <mid> name`**Parameters**

This command includes the following parameters:

Parameter	Description
<code>&lt;mid&gt;</code>	Specify a link aggregation group number from 1 to 31.

**Command mode**

Global configuration mode

**interface mlt**

This command enters the MLT Interface Configuration command mode.

**Syntax**

```
interface mlt <1-31>
```

**Parameters**

This command includes the following parameters:

Parameter	Description
mlt<1-31>	Specifies the ID of the MLT to configure.

**Command mode**

Global configuration mode

**smlt**

This command creates an SMLT from an existing MLT.

**Syntax**

```
smlt <1-31>
```

**Parameters**

This command includes the following parameters:

Parameter	Description
smlt<1-31>	Specifies the SMLT ID.

**Command mode**

MLT Interface Configuration mode

**no smlt**

This command deletes the SMLT.

**Syntax**

```
no smlt <1-31>
```

**Command mode**

MLT Interface Configuration mode

**smlt**

This command configures an interface as a single-port SMLT.

**Syntax**

```
smlt <1-512>
```

## Parameters

This command includes the following parameters:

Parameter	Description
<code>smlt &lt;1-512&gt;</code>	Specifies the ID for the single-port SMLT

## Command mode

Interface Configuration mode

## no smlt

This command deletes the single-port SMLT.

## Syntax

`no smlt`

## Command mode

Interface Configuration mode

## mlt members

Use this command to add members to the MultiLink Trunking (MLT) on the switch.

## Syntax

`mlt <mId> member <slot/ports>`

## Parameter

This command includes the following options:

<code>mlt &lt;mId&gt; member</code>	
<b>followed by:</b>	
<code>&lt;mId&gt;</code>	Specifies the MLT ID. The range of values is 1 to 31.
<code>&lt;slots/ports&gt;</code>	Specifies the applicable members in member list form: <code>{ slot/port [- slot/port] [, ...]}</code> .

## Command mode

Global configuration mode

## mlt add-vlan

Use this command to add an existing VLAN to the MultiLink Trunking (MLT) on the switch.

**Syntax**

```
mlt <mid> add-vlan <vid>
```

**Parameter**

This command includes the following options:

<b>mlt &lt;mid&gt; add-vlan</b>	
<b>followed by:</b>	
<mid>	Specifies the MLT ID. The range of values is 1 to 31.
<vid>	Specifies the VLAN ID. The default range of values is 1 to 4000.

**Command mode**

Global configuration mode

**mlt name**

Use this command to name the MultiLink Trunk (MLT) on the switch. .

**Syntax**

```
mlt <mid> name <string>
```

**Parameters**

This command includes the following parameters:

<b>mlt &lt;mid&gt; name &lt;string&gt;</b>	
<b>followed by:</b>	
<mid>	Specifies the MLT ID. The range of values is 1 to 31.
<string>	Specifies the name of the MLT. The range of values is 0 to 20 alphanumeric characters.

**Command mode**

Global configuration mode

**no mlt members**

Use this command to remove members from the MultiLink Trunking (MLT) on the switch.

**Syntax**

```
no mlt <mid> member <slot/ports>
```

---

**Parameter**

This command includes the following options:

<b>no mlt &lt;mid&gt; member</b>	
<b>followed by:</b>	
<b>&lt;mid&gt;</b>	Specifies the MLT ID. The range of values is 1 to 31.
<b>&lt;ports&gt;</b>	Specifies the applicable members in member list form: <code>{ slot/port [- slot/port] [, ...]}</code> .

**Command mode**

Global configuration mode

**mlt remove-vlan**

Use this command to remove a VLAN from the MultiLink Trunking (MLT) on the switch.

**Syntax**

```
mlt <mid> remove-vlan <vid>
```

**Parameter**

This command includes the following options:

<b>mlt &lt;mid&gt; remove-vlan</b>	
<b>followed by:</b>	
<b>&lt;mid&gt;</b>	Specifies the MLT ID. The range of values is 1 to 31.
<b>&lt;vid&gt;</b>	Specifies the VLAN ID. The default range of values is 1 to 4000.

**Command mode**

Global configuration mode

**mlt create**

Use this command to create the specified MultiLink Trunking (MLT) on the switch.

**Syntax**

```
mlt <mid> create
```

where

<mid> specifies the MLT ID. The range of values is 1 to 31.

#### **Command mode**

Global configuration mode

### **mlt encapsulation**

Use this command to set tagging for the specified MultiLink Trunking (MLT) on the switch.

#### **Syntax**

```
mlt <mid> encapsulation dot1q
```

where

<mid> specifies the MLT ID. The range of values is 1 to 31.

#### **Command mode**

Global configuration mode

### **no mlt encapsulation**

Use this command to removes tagging for the specified MultiLink Trunking (MLT) on the switch.

#### **Syntax**

```
no mlt <mid> encapsulation dot1q
```

where

<mid> specifies the MLT ID. The range of values is 1 to 31.

#### **Command mode**

Global configuration mode

### **no mlt**

Use this command to delete the specified MultiLink Trunking (MLT) on the switch.

#### **Syntax**

```
no mlt <mid>
```

where

<mid> specifies the MLT ID. The range of values is 1 to 31.

#### **Command mode**

Global configuration mode

## show mlt

Use this command to display information about MultiLink Trunking (MLT) operation on the switch or the status of a specified MLT.

### Syntax

```
show mlt [ <mid> ]
```

where

[ <mid> ] is an optional parameter that specifies the MLT ID. The range of values is 1 to 31.

### Command mode

Privileged EXEC mode

## show mlt error

Use this command to display information about the types of Ethernet errors sent and received by all configured MultiLink Trunks (MLTs) or for the specified MLT.

### Syntax

```
show mlt error [ <mid> ]
```

where

[ <mid> ] is an optional parameter that specifies the MLT ID. The range of values is 1 to 31.

### Command mode

Privileged EXEC mode

## show mlt error collision

Use this command to display the number and type of Ethernet collision errors for all configured MultiLink Trunks (MLTs) or for the specified MLT.

### Syntax

```
show mlt error collision [ <mid> ]
```

where

[ <mid> ] is an optional parameter that specifies the MLT ID. The range of values is 1 to 31.

### Command mode

Privileged EXEC mode

## show smlt

This command shows the SMLT and single-port SMLT configurations on the switch.

### Syntax

```
show smlt <mlt | fastethernet>
```

### Parameters

This command includes the following parameters:

Parameter	Description
mlt	Displays only the MLT-based SMLTs.
fastethernet	Displays only the port-based SMLTs.

## show ist

This command shows the IST configuration on the switch.

### Syntax

```
show ist
```

### Command mode

User Exec mode

## show ist stat

This command shows the IST statistics for the switch.

### Syntax

```
show ist stat
```

### Command mode

User Exec mode

## show mlt stats

Use this command to display statistics about MultiLink Trunking (MLT) operation on the switch or statistics for a specified MLT.

### Syntax

```
show mlt stats [ <mld> ]
```

where

[ <mld> ] is an optional parameter that specifies the MLT ID. The range of values is 1 to 31.

### Command mode

Privileged EXEC mode

## show spanning-tree

Use this command to display spanning-tree group information about the specified ports or port.

### Syntax

```
show spanning-tree [port <ports>]
```

where

[**port <ports>**] specifies the applicable ports in port list form:  
 { slot/port [- slot/port] [, ...]}.

### Command mode

Privileged EXEC mode

## show spanning-tree config

Use this command to display configuration and status information for a spanning-tree group.

### Syntax

```
show spanning-tree config [<sid>]
```

where

<**sid**> specifies the spanning tree group ID. The range of values is 1 to 64.

### Command mode

Privileged EXEC mode

## show interface vlan

Use this command to display protocol, configuration, and parameter information for all Virtual LANs (VLANs) on the switch or for a specified VLAN.

### Syntax

```
show interface vlan [<vid>]
```

where

[<**vid**>] is an optional parameter that specifies the VLAN ID. The default range of values is 1 to 2000, unless the flag vid-max4k is set, and it becomes 4000.

### Command mode

Privileged EXEC mode

## show vlan advance

Use this command to display protocol, configuration, and parameter information all Virtual LANs (VLAN) for a specified VLAN.

### Syntax

```
show vlan vid <vid> advance
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000, unless the flag vid-max4k is set, and it becomes 4000.

### Command mode

Global configuration mode

## show ip arp interface

Use this command to display Address Resolution Protocol (ARP) configurations for all Virtual LANs (VLANs) on the switch or for a specified VLAN.

### Syntax

```
show ip arp interface[ <vid> ]
```

where

[ <vid> ] is an optional parameter that specifies the VLAN ID. The default range of values is 1 to 2000, unless the flag vid-max4k is set, and it becomes 4000.

### Command mode

Privileged EXEC mode

## show vlan autolearn-mac

Use this command to display the Mac addresses that were autolearned for the switch.

### Syntax

```
show vlan autolearn-mac
```

### Command mode

Global configuration mode

## show vlan vid basic

Use this command to display the basic Mac addresses for the switch.

### Syntax

```
show vlan [vid <vid>] basic
```

where

**[vid <vid>]** specifies the VLAN ID. The range of values is 1 to 4000.

#### Command mode

Global configuration mode

### show vlan vid fdb-entry

Use this command to display forwarding database information for the specified Virtual LAN (VLAN).

#### Syntax

```
show vlan vid <vid> fdb-entry
```

where

**<vid>** specifies the VLAN ID. The range of values is 1 to 4000.

#### Command mode

Global configuration mode

### show vlan vid fdb-filter

Use this command to display the forwarding database filters for the specified Virtual LAN (VLAN).

#### Syntax

```
show vlan vid <vid> fdb-filter
```

where

**<vid>** specifies the VLAN ID. The range of values is 1 to 4000.

#### Command mode

Global configuration mode

### show vlan vid fdb-static

Use this command to display the forwarding database MAC addresses that have been manually (statically) configured by the user. This is used in situations where the device does not actively advertise its address. For example, a device that does not participate in ARP.

#### Syntax

```
show vlan vid <vid> fdb-static
```

where

**<vid>** specifies the VLAN ID. The range of values is 1 to 4000.

**Command mode**

Global configuration mode

**show interfaces vlan ip**

Use this command to display the Internet Protocol (IP) address configuration for all Virtual LANs (VLANs) on the switch or for a specified VLAN.

**Syntax**

```
show interfaces vlan ip [ <vid> ]
```

where

<vid> specifies the VLAN ID. The range of values is 1 to 4000.

**Command mode**

Privileged EXEC mode

**show vlan manual-edit-mac**

Use this command to display the manually entered Media Access Control (MAC) addresses and their associated ports.

**Syntax**

```
show vlan manual-edit-mac
```

**Command mode**

Interface VLAN mode

**show vlan members**

Use this command to display Virtual LAN (VLAN) information for a specified port or ports.

**Syntax**

```
show vlan [vid <vid>] members
```

where

<vid> specifies the VLAN ID. The range of values is 1 to 4000.

**Command mode**

Global configuration mode

**show vlan static-mcastmac**

Use this command to display the Layer 2 multicast Media Access Control (MAC) filters for any Virtual LANs (VLANs) on the switch or for a specified VLAN.

## Syntax

```
show vlan [vid <vid>] static-mcastmac
```

where

[ vid <vid>] specifies the VLAN ID.  
The range of values is 1 to 4000.

## Command mode

Privileged EXEC mode

## spanning-tree stp

Use this command to set general Spanning Tree environment variables.

## Syntax

```
spanning-tree stp <sid>
[forward-delay <timeval> ]
[group-stp <enable|disable> ]
[hello-interval <timeval> ]
[max-age <timeval> ]
[priority <number> ]
[trap-stp <enable|disable> ]
```

## Parameters

This command includes the following options:

<b>spanning-tree stp &lt;sid&gt;</b> <b>followed by:</b>	
<sid>	Specifies the STG ID. The range of values is 1 to 64.
[forward-delay <timeval> ]	Specifies the bridge forward delay time in 1/100 seconds. The range of values is 400 to 3000. The default is 1500 (15 seconds).
[group-stp <enable disable> ]	Enables or disables the spanning tree protocol on the specified STG. The default is enable.
[hello-interval <timeval> ]	Specifies the bridge hello time in 1/100 seconds. The range of values is 100 to 1000. The default is 200 (2 seconds).

<b>spanning-tree stp &lt;sid&gt;</b> followed by:	
[max-age <timeval> ]	Specifies the bridge maximum age time in 1/100 seconds.  The range of values is 600 to 4000. The default is 2000 (20 seconds).
[priority <number> ]	Specifies the bridge priority number of the specified port. The range of values is 0 to 65535. The default is 32768.
[trap-stp <enable disable>]	Enables or disables the spanning tree protocol trap for the specified STG. The default is enable.

**Command mode**

Global configuration mode

**spanning-tree stp add-ports**

Use this command to add ports to a Spanning Tree Group (STG).

**Syntax**`spanning-tree stp <sid> add-ports <value>`**Parameters**

This command includes the following options:

<b>spanning-tree stp &lt;sid&gt; add-ports</b> followed by:	
<sid>	Specifies the STG ID. The range of values is 1 to 64.
<value>	Specifies the applicable ports in port list form: <code>{ slot/port [- slot/port ] [, ...] }</code> .

**Command mode**

Global configuration mode

## spanning-tree stp create

Use this command to create a new Spanning Tree Group (STG).

### Syntax

```
spanning-tree stp <sid> create
[ <ports> ] [vlan <value> ]
```

### Parameters

This command includes the following options:

<b>spanning-tree stp &lt;sid&gt; create</b> <b>followed by:</b>	
<sid>	Specifies the STG ID. The range of values is 1 to 64.
[ <ports> ]	Specifies the applicable ports in port list form: { slot/port [- slot/port] [, ...] }.
[vlan <value> ]	Specifies the VLAN ID.  <b>Note:</b> If a VLAN spans multiple switches, it must be within the same STG across all switches.

### Command mode

Global configuration mode

## spanning-tree stp remove-ports

Use this command to remove ports from a Spanning Tree Group (STG).

### Syntax

```
spanning-tree stp <sid> remove-ports <value>
```

### Parameters

This command includes the following parameters:

<b>spanning-tree stp &lt;sid&gt; remove-ports</b> <b>followed by:</b>
--

<b>&lt;sid&gt;</b>	Specifies the Spanning Tree group ID. The range of values is 1 to 64.
<b>&lt;value&gt;</b>	Specifies the applicable ports in port list form: <code>{ slot/port [- slot/port ] [, ...] }</code> .

### Command mode

Global configuration mode

## no spanning-tree

Use this command to delete the specified Spanning Tree Group (STG).

### Syntax

```
no spanning-tree <sid>
```

where

**<sid>** specifies the spanning tree group ID. The range of values is 1 to 64.

### Command mode

Global configuration mode

## telnet-access

Use this command to define parameters for the telnet login environment.

### Syntax

```
telnet-access <login-timeout> <sessions>
```

### Parameters

This command includes the following parameters:

<b>telnet-access</b> <b>followed by:</b>	
<b>login-timeout</b>	Specifies the login timeout. The range is 30 to 65535. The default is 900 seconds.
<b>sessions</b>	Specifies number of sessions. The range is 0 to 8. The default is 8.

**Command mode**

Global configuration mode

**vlan action**

Use this command to flush dynamically learned entries from a table.

**Syntax**

```
vlan action <vid>
<none | flush | MacFdb | flushArp | flushIp | all >
```

**Parameters**

This command includes the following parameters:

<b>vlan action &lt;vid&gt;</b> <b>followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<b>none</b>	Specifies no table is flushed.
<b>flush MacFdb</b>	Specifies flushing of MacFdb table.
<b>flushArp</b>	Specifies flushing of Arp table.
<b>flushIp</b>	Specifies flushing of the IP table.
<b>all</b>	Specifies flushing of all tables.

**Command mode**

Global configuration mode

**vlan add-mlt**

Use this command to add MultiLink Trunking (MLT) to a Virtual LAN (VLAN).

**Syntax**

```
vlan add-mlt <vid> <mld>
```

**Parameters**

This command includes the following parameters:

```
vlan <vid> add-mlt
followed by:
```

<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<mid>	Specifies the MLT ID. The range of values is 1 to 31.

### Command mode

Global configuration mode

## vlan members

Use this command to add one or more ports to an existing Virtual LAN (VLAN).

### Syntax

```
vlan members <add|remove> <vid> <ports> [ <member value>
]
```

### Parameters

This command includes the following parameters:

<pre>vlan members followed by:</pre>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<ports>	Specifies the applicable ports in port list form { slot/port [- slot/port] [, ...]}
[ <member value> ]	Specifies the port member type. The options are: <ul style="list-style-type: none"> <li>• <b>portmember</b> (always a member),</li> <li>• <b>static</b> (always a member), or</li> <li>• <b>notallowed</b> (never a member).</li> </ul>
<add   remove>	Add or remove a port from the VLAN.

### Command mode

Global configuration mode

## vlan name

Use this command to change the name of a Virtual LAN (VLAN).

### Syntax

```
vlan name <vid> <vname>
```

### Parameters

This command includes the following parameters:

vlan name followed by:	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<vname>	Specifies the VLAN name. The range of values is a string of 0 to 20 characters. The default VLAN name is VLAN <vid>.

### Command mode

Global configuration mode

## vlan qos-level

Use this command to set a Quality of Service (QoS) level for the specified Virtual LAN (VLAN).

### Syntax

```
vlan qos-level <vid> <integer>
```

### Parameters

This command includes the following parameters:

vlan qos-level followed by:	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<integer>	Specifies the QoS level. The range of values is 0 to 7. Level 7 is reserved and cannot be set.

### Command mode

Global configuration mode

## no vlan

Use this command to delete a Virtual LAN (VLAN).

**Syntax**

```
no vlan <vid>
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

**Command mode**

Global configuration mode

**vlan create type port**

Use this command to create a port-based Virtual LAN (VLAN).

**Syntax**

```
vlan create <vid> [name <value> ]
type port <sid>
[color <value> ]
```

**Parameters**

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type port</b> <b>followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters. The default name is VLAN <vid>.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

**Command mode**

Global configuration mode

**vlan create type protocol-ApltkEther2Snap**

Use this command to create an ApltkEther2Snap protocol-based Virtual LAN (VLAN).

**Syntax**

```
vlan create <vid> [name <value> ]
```

```
type protocol-ApkEther2Snap <sid>
[<value>]
```

### Parameters

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-ApkEther2Snap followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

### Command mode

Global configuration mode

## vlan create type protocol-decEther2

Use this command to create a decEther2 protocol-based Virtual LAN (VLAN).

### Syntax

```
vlan create <vid> [name <value> ]
type protocol-decEther2 <sid>
[<value>]
```

### Parameters

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-decEther2 followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.

```
vlan create <vid> type protocol-decEther2
followed by:
```

[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

### Command mode

Global configuration mode

## vlan create type protocol-decOtherEther2

Use this command to create a decOtherEther2 protocol-based Virtual LAN (VLAN).

### Syntax

```
vlan create <vid> [name <value> ]
type protocol-decOtherEther2 <sid>
[color <value> ]
```

### Parameters

This command includes the following parameters:

```
vlan create <vid> type protocol-decOtherEther2
followed by:
```

<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

**Command mode**

Global configuration mode

**vlan create type protocol-ipEther2**

Use this command to create an ipEther2 protocol-based Virtual LAN (VLAN).

**Syntax**

```
vlan create <vid> [name <value> ]
type protocol-ipEther2 <sid>
[color <value> ]
```

**Parameters**

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-ipEther2 followed by:</b>
--

<b>vlan create &lt;vid&gt; type protocol-ipEther2 followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

**Command mode**

Global configuration mode

**vlan create type protocol-ipv6Ether2**

Use this command to create an ipv6Ether2 protocol-based Virtual LAN (VLAN).

**Syntax**

```
vlan create <vid> [name <value> ]
type protocol-ipv6Ether2 <sid>
[color <value> ]
```

**Parameters**

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-ipv6Ether2 followed by:</b>
--

<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

### Command mode

Global configuration mode

## vlan create type protocol-ipx802.2

Use this command to create an ipx802.2 protocol-based Virtual LAN (VLAN).

### Syntax

```
vlan create <vid> [name <value> ]
type protocol-ipx802.2 <sid>
[color <value> ]
```

### Parameters

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type ipx802.2 followed by:</b>
---

<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.

<b>vlan create &lt;vid&gt; type ipx802.2 followed by:</b>	
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

### Command mode

Global configuration mode

## vlan create type protocol-ipx802.3

Use this command to create an ipx802.3 protocol-based Virtual LAN (VLAN).

### Syntax

```
vlan create <vid> [name <value> ]
type protocol-ipx802.3 <sid>
[<value>]
```

### Parameters

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type ipx802.3 followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

### Command mode

Global configuration mode

## vlan create type protocol-ipxEther2

Use this command to create an ipxEther2 protocol-based Virtual LAN (VLAN).

### Syntax

```
vlan create <vid> [name <value> ]
type protocol-ipxEther2 <sid>
[color <value> ]
```

### Parameters

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-ipxEther2</b> <b>followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

### Command mode

Global configuration mode

## vlan create type protocol-ipxSnap

Use this command to create an ipxSnap protocol-based Virtual LAN (VLAN).

### Syntax

```
vlan create <vid> [name <value> ]
type protocol-ipxSnap <sid>
[color <value> ]
```

### Parameters

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-ipxSnap followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

## Command mode

Global configuration mode

## vlan create type protocol-Netbios

Use this command to create a Netbios protocol-based Virtual LAN (VLAN).

### Syntax

```
vlan create <vid> [name <value> ]
type protocol-Netbios <sid>
[color <value> ]
```

### Parameters

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-Netbios followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

**Command mode**

Global configuration mode

**vlan create type protocol-RarpEther2**

Use this command to create a RarpEther2 protocol-based Virtual LAN (VLAN).

**Syntax**

```
vlan create <vid> [name <value> ]
type protocol-RarpEther2 <sid>
[color <value> ]
```

**Parameters**

This command includes the following parameters:

vlan create <vid> type protocol-RarpEther2 followed by:	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

**Command mode**

Global configuration mode

**vlan create type protocol-sna802.2**

Use this command to create a sna802.2 protocol-based Virtual LAN (VLAN).

**Syntax**

```
vlan create <vid> [name <value> ]
type protocol-sna802.2 <sid>
[color <value> ]
```

**Parameters**

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-sna802.2 followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

### Command mode

Global configuration mode

## vlan create type protocol-snaEther2

Use this command to create a snaEther2 protocol-based Virtual LAN (VLAN).

### Syntax

```
vlan create <vid> [name <value> ]
type protocol-snaEther2 <sid>
[<value> ]
```

### Parameters

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-snaEther2 followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

**Command mode**

Global configuration mode

**vlan create type protocol-Userdef**

Use this command to create a Userdef protocol-based Virtual LAN (VLAN).

**Syntax**

```
vlan create <vid> [name <value> ]
type protocol-Userdef <sid> <pid>
[<value>] [<value>]
```

**Parameters**

This command includes the following parameters:

vlan create <vid> type protocol-Userdef followed by:	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
<pid>	Specifies a user-defined protocol not included in the list.
[<value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).
[<value> ]	Specifies the frame encapsulation method. The values are ethernet-ii, llc, and snap. The default is all encapsulation types.

**Command mode**

Global configuration mode

**vlan create type protocol-vinesEther2**

Use this command to create a vinesEther2 protocol-based Virtual LAN (VLAN).

**Syntax**

```
vlan create <vid> [name <value> ]
type protocol-vinesEther2 <sid>
[<value>]
```

## Parameters

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-vinesEther2 followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

## Command mode

Global configuration mode

## vlan create type protocol-xnsEther2

Use this command to create a xnsEther2 protocol-based Virtual LAN (VLAN).

## Syntax

```
vlan create <vid> [name <value> ]
type protocol-xnsEther2 <sid>
[color <value> ]
```

## Parameters

This command includes the following parameters:

<b>vlan create &lt;vid&gt; type protocol-xnsEther2 followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000. The default name is VLAN <vid>.
[name <value> ]	Specifies the name of the VLAN. The range of values is 0 to 20 characters.

<b>vlan create &lt;vid&gt; type protocol-xnsEther2</b> <b>followed by:</b>	
<sid>	Specifies the spanning tree group ID. The range of values is 1 to 64 characters.
[color <value> ]	Specifies the color of the VLAN. The range of values is 0 to 32. System software uses the color attribute to display the VLAN. The default color is 0 (white).

**Command mode**

Global configuration mode

**vlan fdb-entry aging-time**

Use this command to set the forwarding database aging timer for a Virtual LAN (VLAN).

**Syntax****vlan fdb-entry <vid> aging-time <seconds>****Parameters**

This command includes the following parameters:

<b>vlan fdb-entry &lt;vid&gt; aging-time &lt;seconds&gt;</b> <b>followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<seconds>	Specifies the timeout period in seconds. The range of values is 10 to 1000000. The default is 300.

**Command mode**

Global configuration mode

**vlan fdb-entry flush**

Use this command to flush the forwarding database for a Virtual LAN (VLAN).

**Syntax****vlan fdb-entry <vid> flush**

where

&lt;vid&gt; specifies the VLAN ID. The default range of values is 1 to 2000, unless the flag vid-max4k is set, and it becomes 4000.

**Command mode**

Global configuration mode

**vlan fdb-entry qos-level**

Use this command to specify the parameters for the forwarding database and set the QoS Level of a Virtual LAN (VLAN). To set the QoS level, the entry must be in the forwarding database (FDB).

**Syntax**

```
vlan fdb-entry <vid> qos-level <mac> <0...7>
```

**Parameters**

This command includes the following parameters:

<b>vlan fdb-entry &lt;vid&gt; qos-level</b> <b>followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<mac>	Specifies the MAC address.
<0...7>	Specifies the QoS level. The range of values is 0 to 7. Level 7 is reserved and cannot be set.

**Command mode**

Global configuration mode

**vlan fdb-entry sync**

Use this command to synchronize the forwarding database of the switch with the forwarding database of the other aggregation switch.

**Syntax**

```
vlan fdb-entry <vid> sync
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

**Command mode**

Global configuration mode

**vlan fdb-filter add**

Use this command to create a filter that can be applied to an entry in the Forwarding Database (FDB).

**Syntax**

```
vlan fdb-filter <vid> add <mac> <port value> drop
<none|srcOnly|dstOnly|Both> qos <level>
```

**Parameters**

This command includes the following parameters:

vlan fdb-filter <vid> add followed by:	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<mac>	Specifies the MAC address.
<port value>	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}
action	none  srcOnly  dstOnly  Both

**Command mode**

Global configuration mode

**no vlan fdb-filter**

Use this command to remove Virtual LAN (VLAN) filter members.

**Syntax**

```
no vlan fdb-filter <vid> <mac>
```

**Parameters**

This command includes the following parameters:

no vlan fdb-filter followed by:	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<mac>	Specifies the MAC address.

**Command mode**

Global configuration mode

## vlan fdb-static add

Use this command to add a static member to a Virtual LAN (VLAN) bridge.

### Syntax

```
vlan fdb-static <vid> add
<mac> <port value> [ <qos value> ]
```

### Parameters

This command includes the following parameters:

<b>vlan fdb-static &lt;vid&gt; add</b> <b>followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<mac>	Specifies the multicast MAC address.
<port value>	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.
Operational parameter: [ <qos value> ]	Specifies the Quality of Service level. The QoS level range is 0 to 7. Level 7 is reserved. The default is 1.

### Command mode

Global configuration mode

## no vlan fdb-static

Use this command to remove Virtual LAN (VLAN) static members.

### Syntax

```
no vlan fdb-static <vid> <mac>
```

### Parameters

This command includes the following parameters:

<b>no vlan fdb-static</b> <b>followed by:</b>	
<vid>	Specifies the VLAN ID. The default range of values is 1 to 2000.
<mac>	Specifies the MAC address.

### Command mode

Global configuration mode

## vlan static-mcastmac add

Use this command to add static multicast Media Access Control (MAC) entries for a Virtual LAN (VLAN).

### Syntax

```
vlan static-mcastmac <vid> add <mac>
[mlt <mid>] [ports <ports>]
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

### Parameters

This command includes the following parameters:

<b>vlan static-mcastmac &lt;vid&gt; add followed by:</b>	
<mac>	Specifies the MAC address.
[mlt <mid>]	Specifies the MultiLink Trunking ID. The range is 1 to 31.
[ports <ports> ]	Specifies the port(s) to receive the multicast flooding.

### Command mode

Global configuration mode

For more information about configuring VLAN, see *Configuring IP Multicast Routing Protocols*.

## vlan static-mcastmac add-mlt

Use this command to add MultiLink Trunking (MLT) to static multicast Media Access Control (MAC) entries for a Virtual LAN (VLAN).

### Syntax

```
vlan static-mcastmac <vid> add-mlt <mid>
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

<mid> specifies the multilink trunk identifier. The default range of values is 1 to 31.

### Parameters

This command includes the following parameters:

<b>vlan static-mcastmac &lt;vid&gt; add-mlt &lt;mld&gt;</b>
<b>followed by:</b>

<mld>	Specifies the MultiLink Trunking ID. The range is 1 to 31.
<mac>	Specifies the MAC address.

### Command mode

Global configuration mode

## vlan static-mcastmac remove-mlt

Use this command to delete MultiLink Trunking (MLT) to static multicast Media Access Control (MAC) entries for a Virtual LAN (VLAN).

### Syntax

```
vlan static-mcastmac <vid> remove-mlt
ports <ports/slots> <mac>
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

### Parameters

This command includes the following parameters:

<b>vlan static-mcastmac &lt;vid&gt; remove-mlt</b>
<b>followed by:</b>

<mld>	Specifies the MultiLink Trunking ID. The range is 1 to 31.
<mac>	Specifies the MAC address.

### Command mode

Global configuration mode

## vlan static-mcastmac add-ports

Use this command to add ports to static multicast Media Access Control (MAC) entries for a Virtual LAN (VLAN).

### Syntax

```
vlan static-mcastmac <vid> add-ports <ports> <mac>
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

### Parameters

This command includes the following parameters:

---

Nortel Ethernet Routing Switch 8300  
Command Reference — NNCLI  
NN46200-306 03.01 Standard  
4.0 27 August 2007

<b>vlan static-mcastmac &lt;vid&gt; add-ports</b> <b>followed by:</b>	
<ports>	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.
<mac>	Specifies the MAC address.

**Command mode**

Global configuration mode

**vlan static-mcastmac remove**

Use this command to remove MAC-to-VLAN static multicast Media Access Control (MAC) entries for a Virtual LAN (VLAN).

**Syntax**

```
vlan static-mcastmac <vid> remove <mid> <mac>
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

**Parameters**

This command includes the following parameters:

<b>vlan static-mcastmac &lt;vid&gt; remove</b> <b>followed by:</b>	
<mid>	Specifies the MultiLink Trunking ID. The range is 1 to 31.
<mac>	Specifies the MAC address.

**Command mode**

Global configuration mode

For more information about configuring VLAN, see *Configuring IP Multicast Routing Protocols*.

**vlan static-mcastmac remove-mlt**

Use this command to remove MultiLink Trunking (MLT) from static multicast Media Access Control (MAC) entries for a Virtual LAN (VLAN).

**Syntax**

```
vlan static-mcastmac <vid> remove-mlt <mid> <mac>
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

### Parameters

This command includes the following parameters:

<b>vlan static-mcastmac &lt;vid&gt; remove-mlt followed by:</b>	
<mid>	Specifies the MultiLink Trunking ID. The range is 1 to 31.
<mac>	Specifies the MAC address.

### Command mode

Global configuration mode

## vlan static-mcastmac remove-ports

Use this command to delete ports from the Layer 2 multicast Media Access Control (MAC) entries on a Virtual LAN (VLAN).

### Syntax

```
no vlan static-mcastmac <vid> remove-ports <mid> <mac>
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

### Parameters

This command includes the following parameters:

<b>vlan static-mcastmac &lt;vid&gt; remove-ports followed by:</b>	
<mid>	Specifies the MultiLink Trunking ID.
<mac>	Specifies the MAC address.

### Command mode

Global configuration mode

## no vlan static-mcastmac

Use this command to delete Layer 2 multicast Media Access Control (MAC) entries on a Virtual LAN (VLAN).

### Syntax

```
no vlan static-mcastmac <vid> mac <mac>
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

<mac> specifies the MAC address.

**Command mode**

Global configuration mode

## Layer 3 Operations Commands

### interface vlan

Use this command to interface with a Virtual LAN (VLAN).

**Syntax**

```
interface vlan <vid>
```

where

<vid> specifies the VLAN ID. The default range of values is 1 to 2000.

**Command mode**

Global configuration mode

### ip address

Use this command to assign an IP address and subnet mask to a Virtual LAN (VLAN).

**Syntax**

```
ip address <ipaddr mask>
```

**Parameters**

This command includes the following parameters:

ip address followed by:	
<ipaddr>	Specifies the IP address.
<mask>	Specifies the subnet mask {a.b.c.d}.

**Command mode**

Interface configuration mode

### no ip address

Use this command to delete the specified IP address of a Virtual LAN (VLAN).

**Syntax**

```
no ip address <ipaddr>
```

where

<ipaddr> specifies the IP address of the VLAN.

### **Command mode**

Interface configuration mode

For more information about configuring VLAN, see *Nortel Ethernet Routing Switch 8300 Configuration — VLANs, Spanning Tree, and Static Link Aggregation using the NNCLI (NN46200-504)*.

## **ip arp proxy**

Use this command to enable a proxy Address Resolution Protocol (ARP) on a Virtual LAN (VLAN). A proxy ARP on a VLAN allows a router to answer a local ARP request for a remote destination.

### **Syntax**

```
ip arp proxy
```

### **Command mode**

Interface configuration mode

## **no ip arp proxy**

Use this command to disable a proxy Address Resolution Protocol (ARP) on a Virtual LAN (VLAN).

### **Syntax**

```
no ip arp proxy
```

### **Command mode**

Interface configuration mode

## **ip arp response**

Use this command to enable Address Resolution Protocol (ARP) responses on a Virtual LAN.

### **Syntax**

```
ip arp response
```

### **Command mode**

Interface configuration mode

## **no ip arp response**

Use this command to disable Address Resolution Protocol (ARP) responses on a Virtual LAN.

### **Syntax**

```
no ip arp response
```

**Command mode**

Interface configuration mode

## Route filters commands

This chapter describes NNCLI route filters commands and their parameters.

Route Filters Commands
"filter acl ip" (page 325)
"filter acl non-ip" (page 326)
"no filter acl" (page 330)
"filter acl ethernet" (page 331)
"filter acl ip-hdr" (page 332)
"filter acl port" (page 335)
"filter acl protocol" (page 336)
"filter acl debug" (page 337)
"filter acg" (page 338)
"filter acg modify" (page 339)
"no filter acg" (page 339)
"filter act ethernet" (page 339)
"filter act ip-hdr" (page 342)
"no filter act" (page 345)
"show filter acg" (page 346)
"show filter acl action" (page 346)
"show filter acl ethernet" (page 346)
"show filter acl ip" (page 346)
"show filter acl port" (page 347)
"show filter acl statistics" (page 347)
"show filter act ethernet" (page 347)
"show filter act ip" (page 348)

### filter acl ip

Use this command to create a new IP ACL.

## Syntax

```
filter acl <acl-id> ip [acl-name <value>] [act-id <value>]
```

where:

- <acl-id> is a unique identifier (from 1 to 512) for this ACL entry.
- act-id <value> specifies the ACT ID (from 1 to 2) for this ACL entry.

**Note:** ACLs can be of either type. Access Control Entities (ACEs) can match packets classified as 'ip' (ip header and below) or 'non-ip' (ethernet header).

## Parameter

This command includes the following options:

<code>filter acl &lt;acl-id&gt; ip &lt;act-id&gt;</code>	
<b>followed by:</b>	
<code>acl-name &lt;value&gt;</code>	A descriptive name that identifies this ACL.  If you do not assign a name, the system automatically assigns one.
<code>act-id</code>	Identifies the access control template (ACT) bound to this interface. act-id - the range is 1 to 2. If you do not assign a ACT, the system automatically uses act-id 1  <b>Note:</b> The rules in the ACL specified in AcldList must be a subset of the values defined in the ACT entry.

## Command mode

Global configuration mode

## filter acl non-ip

Use this command to create a new non-IP ACL.

## Syntax

```
filter acl <acl-id> non-ip <acl-name> <act-id>
```

where:

- <acl-id> is a unique identifier (from 1 to 512) for this ACL entry.
- <act-id> specifies the ACT ID (from 1 to 2) for this ACL entry.

**Note:** ACLs can be of either type. Access Control Entities (ACEs) can match packets classified as 'ip' (ip header and below) or 'non-ip' (ethernet header).

## Parameter

This command includes the following options:

<code>filter acl &lt;acl-id&gt; non-ip &lt;act-id&gt;</code>	
<b>followed by:</b>	
<code>acl-name &lt;value&gt;</code>	A descriptive name that identifies this ACL.  If you do not assign a name, the system automatically assigns one.
<code>act-id</code>	Identifies the access control template (ACT) bound to this interface. act-id - the range is 1 to 2. If you do not assign a ACT, the system automatically uses act-id 1  <b>Note:</b> The rules in the ACL specified in AcldList must be a subset of the values defined in the ACT entry.

## Command mode

Global configuration mode

## filter acl action

Use this command to create and configure an ACE.

### Syntax

```
filter acl <acl-id> action <ace-id> <mode> [trust-dscp <value>]
[remark-dscp <value>] [remark-user-priority <value>]
[police <value> <ace-name>] [precedence <value>]
[traffic-type <value>]
```

where:

- `<acl-id>` is a unique identifier (from 1 to 512) for this ACL entry.
- `<ace-id>` is a unique identifier (from 1 to 256) for this ACE entry.
- `<mode>` specifies the operating mode associated with this ACE. Enter one of the following modes to determine what action the ACE takes when it matches a packet:
  - `inactive`—no affect on traffic
  - `permit`—permits traffic

- **deny**—denies traffic
- **redirect**—redirects traffic
- **fwd2cpu**—forwards to the central processing unit (CPU)

The default setting is **deny**.

### Parameter

This command includes the following options:

<b>filter acl &lt;acl-id&gt; action &lt;ace-id&gt; &lt;mode&gt;</b>	
<b>followed by:</b>	
<b>trust-dscp &lt;enable disable&gt;</b>	Specifies trust dscp.
<b>remark-dscp &lt;value&gt;</b>	<p>Causes DSCP to re-mark non-standard traffic classes so it uses a local per hop behavior (PHB). The range is 0 to 63.</p> <p>&lt;value&gt; is one of the following choices:</p> <p>disable phbcs0 phbcs1 phbaf11</p> <p>phbaf12 phbaf13 phbcs2 phbaf21</p> <p>phbaf22 phbaf23 phbcs3 phbaf31</p> <p>phbaf32 phbaf33 phbcs4 phbaf41</p> <p>phbaf42 phbaf43 phbcs5 phbef</p> <p>phbcs6 phbcs7</p> <p>The default setting is <b>disable</b>.</p>

<pre>filter acl &lt;acl-id&gt; action &lt;ace-id&gt; &lt;mode&gt;</pre> <p><b>followed by:</b></p>	
<b>remark-user-priority</b> <i>&lt;value&gt;</i>	<p>Sets the User Priority as described by Layer 2 standards: 802.1Q, 802.1p.</p> <p><i>value</i> is one of the following choices:</p> <ul style="list-style-type: none"> <li>• ignore   zero   one   ...   seven</li> <li>• 0 ... 7</li> </ul> <p>The default setting is <b>ignore</b>.</p>
<b>police</b> <i>&lt;value&gt;</i>	<p><b>police</b> <i>&lt;value&gt;</i> sets the desired policing profile identifier in the range from 0 to 128.</p> <p>When policing is not desired, set to disable (0).</p>
<b>&lt;ace-name&gt;</b>	<p><b>&lt;ace-name&gt;</b> is a string that names the ACE. The range is 0 to 255.</p> <p>If you do not assign a name, the system automatically assigns one.</p>
<b>next-hop</b> <i>&lt;ipaddr&gt;</i>	<p><b>&lt;next-hop&gt;</b> is an IP address {a.b.c.d}.</p> <p>This value redirects matching IP traffic to the next hop, as specified by this IP address.</p>
<b>precedence</b> <i>&lt;0 to 255&gt;</i>	<p><b>precedence</b> sets the order for when each ACE is applied within an ACL. This value is in the range from 0 to 255, and the default is 0.</p> <p>An ACL can contain multiple ACEs that match a packet. The lower the value that you assign to an ACE increases its order of precedence. For example, the highest precedence that you can assign to an ACE is 0, and the lowest precedence (256) is reserved for the default ACE.</p>
<b>traffic-type</b> <i>&lt;value&gt;</i>	<p><b>&lt;traffic-type&gt;</b> <i>&lt;value&gt;</i> can be:</p>

	<pre>filter acl &lt;acl-id&gt; action &lt;ace-id&gt; &lt;mode&gt;</pre> <p><b>followed by:</b></p>
	<p>{all   bridged   routed   tagged   tagged-bridged   tagged-routed   untagged   untagged-bridged   untagged-routed}.</p> <ul style="list-style-type: none"> <li>• <b>all</b> - matches both bridged and routed packets.</li> <li>• <b>bridged</b> - matches bridged packets.</li> <li>• <b>routed</b> - matches IPv4 unicast routed packets.</li> <li>• <b>tagged</b></li> <li>• <b>untagged</b></li> <li>• <b>tagged-bridged</b></li> <li>• <b>tagged-routed</b></li> <li>• <b>untagged-bridged</b></li> <li>• <b>untagged-routed</b></li> </ul> <p>The default setting is <b>all</b>.</p> <p>This value indicates the type of packets that the ACE is set to match.</p>

### Command mode

Global configuration mode

## no filter acl

Use this command to delete an ACL or an ACE.

### Syntax

```
no filter acl <acl-id> [<ace-id>]
```

where:

- **<acl-id>** is a unique identifier (from 1 to 512) for this ACL entry.
- **<ace-id>** is a unique identifier (from 1 to 256) for this ACE entry.

### Command mode

Global configuration mode

## filter acl ethernet

Use this command to configure an ACE's Ethernet values.

### Syntax

```
filter acl <acl-id> ethernet <ace-id> src-mac <value>
<ace-op> <src-mac> dst-mac <value> <ace-op> <dst-mac>
ether-type <value> anyvlan vlan-id <value> user-priority
<value>
```

where:

- **<acl-id>** is a unique identifier (from 1 to 512) for this ACL entry.
- **<ace-id>** is a unique identifier (from 1 to 256) for this ACE entry.

### Parameter

This command includes the following options:

<pre>filter acl &lt;acl-id&gt; ethernet &lt;ace-id&gt;</pre> <p><b>followed by:</b></p>	
<b>src-mac &lt;value&gt; &lt;ace-op&gt;</b> <b>&lt;src-mac&gt;</b>	<p>Specifies the MAC source address to match {a:b:c:d}.</p> <p>&lt;ace-op&gt; specifies the logical operator: {any eq ne le ge range mask}.</p> <p>The default is <b>any</b>.</p> <p>&lt;src-mac&gt; sets the mask or higher address for MAC source address, when ace-op is set to mask or range.</p>
<b>dst-mac &lt;value&gt; &lt;ace-op&gt;</b> <b>&lt;dst-mac&gt;</b>	<p>Specifies the MAC source address to match {a:b:c:d:e:f}.</p> <p>&lt;ace-op&gt; specifies the logical operator: {any   eq   ne   le   ge   range   mask}.</p> <p>The default is <b>any</b>.</p> <p>&lt;dst-mac&gt; sets the mask or higher address for MAC destination address, when ace-op is set to mask or range.</p>

<pre>filter acl &lt;acl-id&gt; ethernet &lt;ace-id&gt;</pre> <p><b>followed by:</b></p>	
<b>ether-type &lt;value&gt;</b>	<p>Specifies the EtherType value from the Ethernet header.</p> <ul style="list-style-type: none"> <li>• ip</li> <li>• arp</li> <li>• rarp</li> <li>• appleTalk</li> <li>• decLat</li> <li>• ipv6</li> <li>• any (outside valid range)</li> </ul> <p>The default is <b>any</b>.</p>
<b>vlan-id &lt;value&gt;</b>	<p>Specifies the Vlan-ID to match. This value is in the range of 1 - 2000. If the flag vid-max4k is set the range is 1 to 4000.</p> <p>The default is 0.</p>
<b>user-priority &lt;value&gt;</b>	<p>Sets the Priority bits (3-bit value) from the 802.1Q/p.</p> <p>&lt;value&gt; is one of the following choices:</p> <ul style="list-style-type: none"> <li>• 0...7</li> <li>• 0x0...0x07</li> <li>• ignore zero one two three four five six seven</li> </ul> <p>The default setting is <b>ignore</b>.</p>

### Command mode

Global configuration mode

### filter acl ip-hdr

Use this command to configure an ACE's IP values.

## Syntax

```
filter acl <acl-id> ip <ace-id> [src-ip <value> <ace-op>
<src-ip>] [dst-ip <value> <ace-op> <dst-ip>] [dscp <value>
<ace-op> <dscp>] ipfragment <value>
```

where:

- <acl-id> is a unique identifier (from 1 to 512) for this ACL entry.
- <ace-id> is a unique identifier (from 1 to 256) for this ACE entry.

**Note:** ACLs can be of either type. The Access Control Entities (ACEs) can match packets classified as 'ip' (ip header and below) or 'non-ip' (ethernet header).

## Parameter

This command includes the following options:

<code>filter acl &lt;acl-id&gt; ip-hdr &lt;ace-id&gt;</code>	
<b>followed by:</b>	
<code>src-ip &lt;value&gt; &lt;ace-op&gt;</code> <code>&lt;src-ip&gt;</code>	<p>Specifies the IP source address to match {a.b.c.d} from the IP header.</p> <p>&lt;ace-op&gt; specifies the logical operator: {any eq ne le ge range mask}.</p> <p>The default is any.</p> <p>&lt;src-ip&gt; sets the mask or higher address for the IP source address, when: ace-op is set to mask or range.</p>
<code>dst-ip &lt;value&gt; &lt;ace-op&gt;</code> <code>&lt;dst-ip&gt;</code>	<p>Specifies the IP destination address to match from the IP header.</p> <p>&lt;ace-op&gt; specifies the logical operator: {any eq ne le ge range mask}.</p> <p>The default is any.</p> <p>&lt;dst-ip&gt; sets the mask or higher address for the IP destination address, when: ace-op is set to mask or range.</p>

<pre><b>filter acl &lt;acl-id&gt; ip-hdr &lt;ace-id&gt;</b></pre> <p><b>followed by:</b></p>	
<pre><b>dscp &lt;value&gt; &lt;ace-op&gt;</b>  <b>&lt;dscp&gt;</b></pre>	<p>Causes DSCP to re-mark non-standard traffic classes so it uses a local per hop behavior (PHB).</p> <p>&lt;value&gt; is one of the following choices:</p> <ul style="list-style-type: none"> <li>disable phbcs0 phbcs1 phbaf11</li> <li>phbaf12 phbaf13 phbcs2 phbaf21</li> <li>phbaf22 phbaf23 phbcs3 phbaf31</li> <li>phbaf32 phbaf33 phbcs4 phbaf41</li> <li>phbaf42 phbaf43 phbcs5 phbef</li> <li>phbcs6 phbcs7</li> </ul> <p>The default setting is <b>disable</b>.</p> <p>&lt;ace-op&gt; specifies the logical operator:  <b>any   eq   ne   le   ge   range   mask</b> The default is <b>any</b>.</p> <p>&lt;dscp&gt; sets the mask or higher address for the DSCP value, when:  <b>ace-op</b> is set to <b>mask</b> or <b>range</b>.</p>
<pre><b>i</b>  <b>pfragment&lt;value&gt;</b></pre>	<p>Set the match option for IP fragmented packets. The value is one of the following:</p> <ul style="list-style-type: none"> <li>• any = any packet</li> <li>• fragments = IP fragmented packets only</li> <li>• non-fragments = non-IP fragmented packets only</li> </ul> <p>The default is any.</p>

```
filter acl <acl-id> ip-hdr <ace-id>
```

**followed by:**

	<b>Note:</b> This option must be set whenever a match on an L4 field is required. This field will be automatically set to either 'non-fragments' or 'any' whenever an L4 field is set or unset.
--	---

## Command mode

Global configuration mode

## filter acl port

Use this command to configure an ACE's port values.

### Syntax

```
filter acl <acl-id> port <ace-id>
src-port <value> <ace-op> <src-port>
dst-port <value> <ace-op> <dst-port>
```

where:

- **<acl-id>** is a unique identifier (from 1 to 512) for this ACL entry.
- **<ace-id>** is a unique identifier (from 1 to 256) for this ACE entry.

### Parameter

This command includes the following options:

```
filter acl <acl-id> port <ace-id>
```

**followed by:**

<b>src-port &lt;value&gt;</b> <b>&lt;ace-op&gt; &lt;src-port&gt;</b>	Specifies the TCP or UDP source port to match. <b>&lt;value&gt;</b> is one of the following choices: <ul style="list-style-type: none"> <li>• 0...65535</li> <li>• 0x0...0xffff</li> </ul> <b>&lt;ace-op&gt;</b> specifies the logical operator: <b>{any   eq   ne   le   ge   range   mask}.</b> The default is <b>any</b> .
---	--

<b>filter acl &lt;acl-id&gt; port &lt;ace-id&gt;</b>	
<b>followed by:</b>	
	<p>&lt;src-port&gt; sets the TCP or UDP source port, when:  <b>ace-op</b> is set to mask or range.</p>
<b>dst-port &lt;value&gt; &lt;ace-op&gt; &lt;dst-port&gt;</b>	<p>Specifies the TCP or UDP destination port to match. &lt;value&gt; is one of the following choices:</p> <ul style="list-style-type: none"> <li>• 0...65535</li> <li>• 0x0...0xffff</li> <li>• any bgp bootstrap bootpd-dhcp dns echo ftpcontrol ftpdata hdot323 http rip rtp rtcp ssh telnet tftp</li> </ul> <p>&lt;ace-op&gt; specifies the logical operator: {any eq ne le ge range mask}.</p> <p>The default is any.</p> <p>&lt;dst-port&gt; sets the mask or higher address for the TCP or UDP destination port, when:  <b>ace-op</b> is set to mask or range.</p>

## Command mode

Global configuration mode

## filter acl protocol

Use this command to configure an ACE's protocol values.

### Syntax

```
filter acl <acl-id> protocol <ace-id> <ip-protocol>
<ace-op> <ip-protocol>
```

where:

- <acl-id> is a unique identifier (from 1 to 512) for this ACL entry.
- <ace-id> is a unique identifier (from 1 to 256) for this ACE entry.
- <ip-protocol> is the protocol name:

### Parameter

This command includes the following options:

<code>filter acl &lt;acl-id&gt; protocol &lt;ace-id&gt; &lt;ip-protocol&gt;</code>	
--	--

**followed by:**

<code>&lt;ace-op&gt; &lt;ip-protocol&gt;</code>	<code>&lt;ace-op&gt;</code> specifies the logical operator: {any eq ne le ge range mask}.
---	--

The default is any.

`<ip-protocol>` sets the protocol, when:  
ace-op is set to mask or range.

## Command mode

Global configuration mode

## filter acl debug

Use this command to debug an ACE.

### Syntax

```
filter acl <acl-id> debug <ace-id> match-count <value> mirror
<value>
```

where:

- `<acl-id>` is a unique identifier (from 1 to 512) for this ACL entry.
- `<ace-id>` is a unique identifier (from 1 to 255) for this ACE entry.

### Parameter

This command includes the following options:

<code>filter acl &lt;acl-id&gt; debug &lt;ace-id&gt;</code>	
---	--

**followed by:**

<code>match-count &lt;value&gt;</code>	Counts the packets and octets of matching traffic from all ports where the list is active.
--	--

`<value>` is one of the following choices:

- **disable** - Set this mode when counters are not required. This is the default.
- **bytes-pkts** - Set this mode when the count of octets is accurately required.

<b>filter acl &lt;acl-id&gt; debug &lt;ace-id&gt;</b>	
<b>followed by:</b>	
	<ul style="list-style-type: none"> <li>• <b>kbytes-pkts</b> - Set this mode when the octets count is desired in kilobytes.</li> </ul> <p><b>Note:</b> There is potential for an overflow of the octet counter. For example, consider an interface with a forwarding rate of 17 million 64-byte pkts per second. If the statistics are accumulated from 10 such interfaces in a 64-bit counter, the counter could overflow in approximately a year.</p>
<b>mirror &lt;value&gt;</b>	Mirrors matching packets. <value> is {enable   disable}. The default is disable.

### Command mode

Global configuration mode

## filter acg

Use this command to configure an Access Control Group (ACG), which may contain one each of ACL type ip and ACL type non-ip.

### Syntax

```
filter acg <acg-id> <acl-id> <acg-name>
```

where

<acg-id> is a unique identifier (from 1 to 1024) for this ACG entry.

### Parameter

This command includes the following options:

<b>filter acg &lt;acg-id&gt;</b>	
<b>followed by:</b>	
<b>&lt;acl-id&gt;</b>	<acl-id> is a unique identifier (from 1 to 512) for this ACG entry.
<b>&lt;acg-name&gt;</b>	<acg-name> is a descriptive name that identifies this ACG. If you do not assign a name, the system automatically assigns one.

**Command mode**

Global configuration mode

**filter acg modify**

Use this command to modify an ACG's acl-id-list.

**Syntax**

```
filter acg <acg-id> modify <acl-id> <acg-name>
```

where:

- <acg-id> is a unique identifier (from 1 to 1024) for this ACG entry
- <acl-id> is a unique identifier (from 1 to 512) for this ACG entry.

**Parameter**

This command includes the following options:

<b>filter acg &lt;acg-id&gt; modify</b>	
<b>followed by:</b>	
<acl-id>	Specifies a unique identifier (from 1 to 512) for this ACL entry.
<acg-name>	A descriptive name that identifies this ACG.

**Command mode**

Global configuration mode

**no filter acg**

Use this command to delete an ACG.

**Syntax**

```
no filter acg <acg-id>
```

where

&lt;acg-id&gt; is a unique identifier (from 1 to 1024) for this ACG entry.

**Command mode**

Global configuration mode

**filter act ethernet**

Use this command to create an Ethernet ACT.

## Syntax

```
filter act <act-id> ethernet <acl-type> src-mask <value>
dst-mask <value> ether-type <value> vlan-mask <value> name
<value>
```

where:

- <act-id> is a unique identifier (from 1 to 2) for this ACT.
- <acl-type> specifies the type of ACL: IP or non-IP. ACLs can be of either type because access control entities (ACEs) can match packets as 'ip' or 'non-ip'.

## Parameter

This command includes the following options:

<b>filter act &lt;act-id&gt; ethernet &lt;acl-type&gt;</b> <b>followed by:</b>	
<b>act-id</b>	Identifies the access control template (ACT) bound to this interface. The range is 1 to 2.  <b>Note 1:</b> The rules in the ACL specified in AcldIdList must be a subset of the values defined in the ACT entry. <b>Note 2:</b> Partial masking is not supported. Masks must be defined as either all 0's or all 1's.
<b>src-mask &lt;value&gt;</b>	Specifies a mask for the source MAC address. This mask is used by the ACEs that are members of the ACLs using this ACT.  <b>Note 1:</b> A MAC address with all zeros indicates this value is not desired in the match criteria. <b>Note 2:</b> Partial masking is not supported. Masks must be defined as either all 0's or all 1's.

<pre>filter act &lt;act-id&gt; ethernet &lt;acl-type&gt;</pre>	
--	--

**followed by:**

<b>dst-mask &lt;value&gt;</b>	<p>Specifies a mask for the destination MAC address. This mask is used by the ACEs that are members of the ACLs using this ACT.</p> <p><b>Note 1:</b> A MAC address with all zeros indicates this value is not desired in the match criteria.</p> <p><b>Note 2:</b> Partial masking is not supported. Masks must be defined as either all 0's or all 1's.</p>
-------------------------------	---

<b>ether-type &lt;value&gt;</b>	<p>Specifies a mask for the Ether type value to match. The range for this value is from 0 to 65535.</p> <p><b>Note 1:</b> An Ether type of zero indicates this value is not desired in the match criteria.</p> <p><b>Note 2:</b> Partial masking is not supported. Masks must be defined as either all 0's or all 1's.</p>
---------------------------------	--

<b>vlan-mask &lt;value&gt;</b>	<p>Specifies a mask for the VLAN tag information to match. This mask is for the first byte in 802.1Q/802.1p tagged frames that encode the VLAN ID in 12 bits. The range is 1 to 2.</p> <p><b>Note 1:</b> A value of zero indicates the VLAN Tag information is not desired in the match criteria.</p> <p><b>Note 2:</b> Partial masking is not supported. Masks must be defined as either all 0's or all 1's.</p>
--------------------------------	---

<b>filter act &lt;act-id&gt; ethernet &lt;acl-type&gt;</b>
--

**followed by:**

<b>name &lt;value&gt;</b>	A descriptive name that identifies this ACT. If you do not assign a name, the system automatically assigns one. The range is 0 to 255.
---------------------------	--

**Note:** Partial masking is not supported. Masks must be defined as either all 0's or all 1's.

### Command mode

Global configuration mode

## filter act ip-hdr

Use this command to configure an IP ACT.

### Syntax

```
filter act <act-id> ip-hdr src-mask <value> dst-mask <value>
protocol <value> tos <value> src-port <value> dst-port
<value> tcp-flags <value> icmp <value>
```

where

<act-id> is a unique identifier (from 1 to 2) for this ACT.

### Parameter

This command includes the following options:

<b>filter act &lt;act-id&gt; ip-hdr</b>
---

**followed by:**

<b>src-mask &lt;value&gt;</b>	src-mask - <value> is one of the following:
-------------------------------	---

- 0.0.0.0
- 255.255.255.255

Specifies a mask for the source IP address.

<pre>filter act &lt;act-id&gt; ip-hdr</pre> <p><b>followed by:</b></p>	
	<p><b>Note 1:</b> An IP address with all zeros indicates this value is not desired in the match criteria.</p> <p><b>Note 2:</b> Partial masking is not supported. Masks must be defined as either all 0's or all 1's.</p>
<b>dst-mask &lt;value&gt;</b>	<p>Specifies a mask for the destination IP address. dst-mask - &lt;value&gt; is one of the following:</p> <ul style="list-style-type: none"> <li>• 0.0.0.0</li> <li>• 255.255.255.255</li> </ul> <p><b>Note 1:</b> A destination IP address with all zeros indicates this value is not desired in the match criteria.</p> <p><b>Note 2:</b> Partial masking is not supported. Masks must be defined as either all 0's or all 1's.</p>
<b>protocol &lt;value&gt;</b>	<p>Specifies a mask for the protocol value in the IP header to match. &lt;value&gt; can be one of:</p> <ul style="list-style-type: none"> <li>• 0...255</li> <li>• 0x0...0xff.</li> </ul> <p><b>Note:</b> A value of zero indicates this value is not desired in the match criteria.</p>

<b>filter act &lt;act-id&gt; ip-hdr</b>
---

**followed by:**

<b>tos &lt;value&gt;</b>	Specifies a mask for the TOS byte (DSCP value) in the IP header to match. DSCP is encoded in the 6 most significant bits of the ToS byte (see RFC 2474). <value> can be one of:
--------------------------	---

- 0...255
- 0x0...0xff.

**Note:** A value of zero indicates this value is not desired in the match criteria.

<b>src-port &lt;value&gt;</b>	Specifies a mask for the source TCP/UDP port in TCP/UDP header to match. <value> can be one of:
-------------------------------	---

- 0...65535
- 0x0...0xffff.

**Note:** A value of zero indicates this value is not desired in the match criteria.

<b>dst-port &lt;value&gt;</b>	Specifies a mask for the destination TCP/UDP port in TCP/UDP header to match. <value> can be one of:
-------------------------------	--

- 0...65535
- 0x0...0xffff.

**Note:** A value of zero indicates this value is not desired in the match criteria.

<pre>filter act &lt;act-id&gt; ip-hdr</pre> <p><b>followed by:</b></p>	
<b>tcp-flags &lt;value&gt;</b>	<p>Specifies a mask for the 6 bits in the TCP flags value in the TCP header to match. &lt;value&gt; can be one of:</p> <ul style="list-style-type: none"> <li>• 0...63</li> <li>• 0x0...0x3f.</li> </ul> <p><b>Note:</b> A value of zero indicates this value is not desired in the match criteria.</p>
<b>icmp &lt;value&gt;</b>	<p>Specifies a mask for the ICMP message Type and Code to match. The 8-bit Type value is encoded in the MSB and the 8-bit Code value is encoded in the LSB. &lt;value&gt; can be one of:</p> <ul style="list-style-type: none"> <li>• 0...65535</li> <li>• 0x0...0xffff.</li> </ul> <p><b>Note:</b> A value of zero indicates this value is not desired in the match criteria.</p>

### Command mode

Global configuration mode

## no filter act

Use this command to delete an ACT.

### Syntax

```
no filter act <act-id> <acl-type>
```

where:

- <act-id> is a unique identifier (from 1 to 2) for the ACT entry.
- <acl-type> is either ip or non-ip.

### Command mode

Global configuration mode

**show filter acg**

Use this command to display the list of ACGs configured on the switch.

**Syntax**

```
show filter acg [<acg-id>]
```

where

<acg-id> is a unique identifier (from 1 to 1024) for this ACG entry.

**Command mode**

Global configuration mode

**show filter acl action**

Use this command to display the list of ACLs and their related ACE actions.

**Syntax**

```
show filter acl action [<acl-id>] [<ace-id>]
```

where:

- <acl-id> is a unique identifier (from 1 to 512) for this ACL entry.
- <ace-id> is a unique identifier (from 1 to 256) for this ACE entry.

**Command mode**

Global configuration mode

**show filter acl ethernet**

Use this command to display information about the Ethernet ACEs.

**Syntax**

```
show filter acl ethernet [<acl-id>] [<ace-id>]
```

where:

- <acl-id> is a unique identifier (from 1 to 512) for this ACL entry.
- <ace-id> is a unique identifier (from 1 to 256) for this ACE entry.

**Command mode**

Global configuration mode

**show filter acl ip**

Use this command to display information about the IP ACEs.

**Syntax**

```
show filter acl ip [<acl-id>] [<ace-id>]
```

where:

- <acl-id> is a unique identifier (from 1 to 512) for this ACL entry.
- <ace-id> is a unique identifier (from 1 to 256) for this ACE entry.

### **Command mode**

Global configuration mode

## **show filter acl port**

Use this command to display information about the ACEs port.

### **Syntax**

```
show filter acl port [<acl-di>] [<ace-id>]
```

<acl-id> is a unique identifier (from 1 to 512) for this ACL entry.

<ace-id> is a unique identifier (from 1 to 256) for this ACE entry.

### **Command mode**

Global configuration mode

## **show filter acl statistics**

Use this command to display the ACE statistics.

### **Syntax**

```
show filter acl statistics [<acl-id>] [<ace-id>]
```

where:

- <acl-id> is a unique identifier (from 1 to 512) for this ACL entry.
- <ace-id> is a unique identifier (from 1 to 256) for this ACE entry.

### **Command mode**

Global configuration mode

## **show filter act ethernet**

Use this command to display information about the Ethernet ACTs.

### **Syntax**

```
show filter act ethernet [<acl-id>]
```

where

<acl-id> is a unique identifier (from 1 to 512) for this ACL entry.

### **Command mode**

Global configuration mode

## show filter act ip

Use this command to display information about the IP ACTs.

### Syntax

```
show filter act ip [<acl-id>]
```

where

<acl-id> is a unique identifier (from 1 to 512) for this ACL entry.

### Command mode

Global configuration mode

# Test and diagnostic commands

This chapter describes NNCLI test and diagnostic commands and their parameters.

<b>Test and Diagnostic Commands</b>
<a href="#">"clear port-stats" (page 351)</a>
<a href="#">"clear telnet" (page 351)</a>
<a href="#">"monitor mlt error collision" (page 351)</a>
<a href="#">"monitor mlt error main" (page 351)</a>
<a href="#">"monitor mlt stats interface main" (page 352)</a>
<a href="#">"monitor mlt stats interface utilization" (page 352)</a>
<a href="#">"monitor ports error collision" (page 352)</a>
<a href="#">"monitor ports error extended" (page 353)</a>
<a href="#">"monitor ports error main" (page 354)</a>
<a href="#">"monitor ports stats interface extended" (page 354)</a>
<a href="#">"monitor ports stats interface extended" (page 354)</a>
<a href="#">"monitor ports stats interface extended" (page 354)</a>
<a href="#">"monitor ports stats interface main" (page 355)</a>
<a href="#">"monitor ports stats interface utilization" (page 355)</a>
<a href="#">"monitor ports stats rmon" (page 356)</a>
<a href="#">"monitor ports stats stp" (page 357)</a>
<a href="#">"port-mirroring" (page 357)</a>
<a href="#">"no port-mirroring" (page 359)</a>
<a href="#">"no port-mirroring" (page 359)</a>
<a href="#">"rmon alarm" (page 359)</a>
<a href="#">"rmon alarm" (page 359)</a>
<a href="#">"rmon alarm" (page 359)</a>
<a href="#">"no rmon alarm" (page 360)</a>
<a href="#">"rmon event" (page 360)</a>

<b>Test and Diagnostic Commands</b>
"no rmon event" (page 361)
"rmon history" (page 361)
"no rmon history" (page 362)
"rmon memsize" (page 362)
"rmon stats" (page 363)
"no rmon stats" (page 363)
"rmon trap-option" (page 364)
"rmon trap-option" (page 364)
"rmon util-method" (page 364)
"show port-mirroring" (page 365)
"show interface fast-ethernet or gigabit-Ethernet" (page 365)
"show interface statistics" (page 366)
"show rmon" (page 367)
"show spanning-tree config" (page 368)
"show spanning-tree port" (page 368)
"show sys-info" (page 368)
"show test" (page 369)
"show trace file" (page 369)
"show trace level" (page 370)
"test" (page 370)
"trace auto-enable" (page 371)
"trace auto-enable add-module" (page 372)
"trace auto-enable auto-trace" (page 373)
"trace auto-enable remove-module" (page 373)
"trace clear" (page 374)
"trace filter" (page 374)
"trace grep" (page 374)
"trace level" (page 375)
"trace off" (page 375)
"trace route-policy" (page 375)
"trace screen" (page 376)
"traceroute" (page 376)
"vct test" (page 377)

## **clear port-stats**

Use this command to clear port statistics from the switch counters.

### **Syntax**

```
clear port-stats [ <portlist> ]
```

where

[ <portlist> ] is an optional parameter that specifies the ports to be cleared in the port list form: {slot/ port[-slot/port] [, ...]}.

### **Command mode**

Privileged EXEC mode

## **clear telnet**

Use this command to end a Telnet session.

### **Syntax**

```
clear telnet <session id>
```

where

<session id> specifies the ID number of the Telnet session. The range of values is 0 to 7.

### **Command mode**

Privileged EXEC mode

## **monitor mlt error collision**

Use this command to monitor the number and type of Ethernet collision errors for all Multilink Trunks (MLT) or for a specified MLT. Sample interval and duration are set by the monitor command in Global configuration mode.

### **Syntax**

```
monitor mlt error collision [<mld>]
```

where

[<mld>] is an optional parameter that specifies the ID number of the MLT. The range is 1 to 31.

### **Command mode**

Privileged EXEC mode

## **monitor mlt error main**

Use this command to monitor basic information about the number of different types of Ethernet errors for all Multilink Trunks (MLT) or for a specified MLT.

**Syntax**

```
monitor mlt error main  
[ <mid> ]
```

where

[<mid>] is an optional parameter that specifies the ID number of the MLT.

**Command mode**

Privileged EXEC mode

**monitor mlt stats interface main**

Use this command to monitor interface statistics for all Multilink Trunking (MLT) or a specified MLT.

**Syntax**

```
monitor mlt stats interface main [ <mid> ]
```

where

[<mid>] is an optional parameter that specifies the ID number of the MLT.

**Command mode**

Privileged EXEC mode

**monitor mlt stats interface utilization**

Use this command to monitor interface utilization statistics for all Multilink Trunking (MLT) or for a specified MLT.

**Syntax**

```
monitor mlt stats interface utilization [ <mid> ]
```

where

[<mid>] is an optional parameter that specifies the ID number of the MLT.

**Command mode**

Privileged EXEC mode

**monitor ports error collision**

Use this command to monitor the number and type of Ethernet collision errors for all ports or for specified ports.

**Syntax**

```
monitor ports error collision
```

---

```
[ <ports> ]
[from <value> ]
```

## Parameters

This command includes the following options:

<b>monitor ports error collision</b>	
<b>followed by:</b>	
[ <ports> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.
[from <value> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.

## Command mode

Privileged EXEC mode

## monitor ports error extended

Use this command to monitor additional information about Ethernet errors for all ports or for specified ports.

## Syntax

```
monitor ports error extended
[ <ports> ]
[from <value> ]
```

## Parameters

This command includes the following options:

<b>monitor ports error extended</b>	
<b>followed by:</b>	
[ <ports> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.
[from <value> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.

## Command mode

Privileged EXEC mode

## monitor ports error main

Use this command to monitor basic information about the number of different types of Ethernet errors for all ports or for specified ports.

### Syntax

```
monitor ports error main[ <ports> ]
[from <value> ]
```

### Parameters

This command includes the following options:

<b>monitor ports error main</b>	
<b>followed by:</b>	
[ <ports> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.
[from <value> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.

### Command mode

Privileged EXEC mode

## monitor ports stats interface extended

Use this command to monitor extended port interface statistics for all ports or for specified ports.

### Syntax

```
monitor ports stats interface extended
[ <ports> ]
[from <value> ]
```

### Parameters

This command includes the following options:

<b>monitor ports stats interface extended</b>	
<b>followed by:</b>	
[ <ports> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.
[from <value> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.

**Command mode**

Privileged EXEC mode

**monitor ports stats interface main**

Use this command to monitor basic port interface statistics for all ports or for specified ports.

**Syntax**

```
monitor ports stats interface main
[ <ports> ]
[from <value> ]
```

**Parameters**

This command includes the following options:

<b>monitor ports stats interface main</b>	
<b>followed by:</b>	
[ <ports> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.
[from <value> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.

**Command mode**

Privileged EXEC mode

**monitor ports stats interface utilization**

Use this command to monitor port interface utilization statistics for all ports or for specified ports.

## Syntax

```
monitor ports stats interface utilization
[ <ports> ]
[from <value> ]
```

## Parameters

This command includes the following options:

<b>monitor ports stats interface utilization</b>	
<b>followed by:</b>	
[ <ports> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.
[from <value> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.

## Command mode

Privileged EXEC mode

## monitor ports stats rmon

Use this command to monitor Remote Network Monitoring (RMON) statistics for all ports or for specified ports.

## Syntax

```
monitor ports stats rmon [ <ports> ] [from <value> ]
```

**Note:** RMON must be enabled on the port or ports to be monitored.

## Parameters

This command includes the following options:

<b>monitor ports stats rmon</b>	
<b>followed by:</b>	
[ <ports> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.
[from <value> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.

**Command mode**

Privileged EXEC mode

**monitor ports stats stp**

Use this command to monitor Spanning Tree Protocol (STP) statistics for all ports or for specified ports.

**Syntax**

```
monitor ports stats stp
[ <ports> ]
[from <value> ]
```

**Parameters**

This command includes the following options:

<b>monitor ports stats stp</b>	
<b>followed by:</b>	
[ <ports> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.
[from <value> ]	Specifies the port(s) to be monitored in the port list form: {slot/port [-slot/port] [, ...]}.

**Command mode**

Privileged EXEC mode

**port-mirroring**

Use this command to create a new entry in the port mirroring table for a specified port. Also use this command to specify the mirroring mode. You can configure up to 10 mirroring ports and one mirroring monitor port.

**Note:** Nortel recommends that you disable port mirroring when not in use to reduce the load on the switch.

**Syntax**

```
port-mirroring <id> <enable|disable> mirror-port
<slot/port> monitor-port <port> mode <tx|rx|both>
```

**Parameters**

This command includes the following options:

<b>port-mirroring</b>	
<b>followed by:</b>	
<id>	Specifies the port mirroring ID. The range is 1 to 383.
<tx> [<enable disable>]	<p>Creates a new port mirroring table entry.</p> <ul style="list-style-type: none"> <li>• <b>tx</b> mirrors transmit packets.</li> <li>• <b>enable</b> enables the mirror-port.</li> <li>• <b>disable</b> disables the the mirror-port.</li> </ul>
<rx>  port <value>  port <value>  [{enable} {disable}]	<p>Creates a new port mirroring table entry.</p> <ul style="list-style-type: none"> <li>• <b>rx</b> mirrors receive packets</li> <li>• <b>port &lt;value&gt;</b> is the monitor port.</li> <li>• <b>port &lt;value&gt;</b> is the mirror-port</li> <li>• <b>enable</b> enables the mirror-port.</li> <li>• <b>disable</b> disables the the mirror-port.</li> </ul>
<both> [{enable} {disable}]	<p>Creates a new port mirroring table entry.</p> <ul style="list-style-type: none"> <li>• <b>both</b> mirrors both transmit and receive packets.</li> <li>• <b>enable</b> enables the mirror-port.</li> <li>• <b>disable</b> disables the the mirror-port.</li> </ul>
[mode] <tx rx both>	<p>Specifies the mirroring port mode.</p> <ul style="list-style-type: none"> <li>• <b>tx</b> mirrors transmit packets.</li> <li>• <b>rx</b> mirrors receive packets.</li> <li>• <b>both</b> mirrors both transmit and receive packets.</li> </ul>
<enable>	Enables a mirroring port already created in the mirror-by-port table.
<disable>	Disables a mirroring port already created in the mirror-by-port table.
[monitor-port <port> ]	Specifies the mirrored port.
[mirror-port <port> ]	Specifies the mirroring port.

**Note:** Nortel Networks recommend that you disable port mirroring when not in use to reduce the load on the switch.

### Command mode

Global configuration mode

## no port-mirroring

Use this command to delete an entry in the port mirroring table.

### Syntax

```
no port-mirroring <id>
```

where

<id> specifies the port mirroring ID. The range is 1 to 383.

### Command mode

Global configuration mode

## rmon alarm

Use this command to create an alarm interface for the Remote Monitoring (RMON) functions on the switch.

### Syntax

```
rmon alarm <1-65535> <WORD> <1-3600> {absolute|delta}
      rising-threshold <-32768-65535> ] falling-threshold
      <-32768-65535> ] [owner <value> ]
```

### Parameters

This command includes the following options:

<b>rmon alarm</b>	
<b>followed by:</b>	
<1-65535>	Specifies the alarm interface index number. The range of values is 1 to 65535.
<WORD>	Specifies the alarm name. The name is case sensitive and its range of values is a string of 1 to 1536 characters.
<1-3600>	Specifies the sample interval. The range of values is 1 to 3600.
{absolute delta}	Specifies the sample type. The options are: <b>absolute</b> and <b>delta</b> .

<b>rmon alarm</b>	
<b>followed by:</b>	
<b>rising-threshold</b> <i>&lt;-32768-65535&gt;</i>	Specifies the rising threshold. The range of values is -32768 to 65535.
[ <i>&lt;1-65535&gt;</i> ]	Specifies the rising event number.
<b>falling-threshold</b> <i>&lt;-32768-65535&gt;</i>	Specifies the falling threshold. The range of values is -32768 to 65535.
[ <i>&lt;1-65535&gt;</i> ]	Specifies the falling event number.
[ <b>owner</b> <i>&lt;value&gt;</i> ]	Specifies the name of the owner. The range of values is a string of 1 to 48 characters.

### Command mode

Global configuration mode

## no rmon alarm

Use this command to delete the specified Remote Monitoring (RMON) alarm.

### Syntax

```
no rmon alarm [ <1-65535> ]
```

where

[<1-65535>] is an optional parameter that specifies the alarm index number. The range of values is 1 to 65535.

### Command mode

Global configuration mode

## rmon event

Use this command to create a Remote Monitoring (RMON) event on the switch.

### Syntax

```
rmon event <1-65535> trap_src <value> trap_dest <value>
[log-type <value> ] [description <LINE> ] [community
<value> ] [owner <LINE> ]
```

### Parameters

This command includes the following options:

<b>rmon event</b>	
<b>followed by:</b>	
<1-65535>	Specifies the event index number. The range of values is 1 to 65535.
<b>trap_src &lt;value&gt;</b>	Specifies the trap source IP address.
<b>trap_dest &lt;value&gt;</b>	Specifies the trap destination IP address.
[log-type <value> ]	Specifies the event type. The options are: <code>none</code> , <code>log</code> , <code>snmp-trap</code> , or <code>log-and-trap</code> .
[description <LINE> ]	Specifies the event description. The range of values is a string of 0 to 127 characters.
[community <value> ]	Specifies the event community. The range of values is a string of 0 to 127 characters.
[owner <LINE> ]	Specifies the owner. The range of values is a string of 1 to 48 characters.

### Command mode

Global configuration mode

## no rmon event

Use this command to delete the specified Remote Monitoring (RMON) event.

### Syntax

```
no rmon event [ <1-65535> ]
```

where

[<1-65535>] is an optional parameter that specifies the event index number. The range of values is 1 to 65535.

### Command mode

Global configuration mode

## rmon history

Use this command to create a history control interface for Remote Monitoring (RMON) functions on the switch.

### Syntax

```
rmon history <1-65535> <ports> [buckets <value> ]
[intv <value> ] [owner <LINE> ]
```

## Parameters

This command includes the following options:

<b>rmon history</b>	
<b>followed by:</b>	
<1-65535>	Specifies the index number of the history control interface.  The range of values is 1 to 65535.
<ports>	Specifies the port(s) in the port list form: {slot/port [-slot/port] [, ...]}.
[buckets <value> ]	Specifies the number of buckets requested.  The range of values is 1 to 350. The default is - 50.
[intv <value> ]	Specifies the time interval in seconds over which the data is sampled for each bucket.  The range of values is 1 to 3600. The default is - 1800.
[owner <LINE> ]	Specifies the name of the owner. The range of values is a string of 1 to 48 characters. The default is cli.

## Command mode

Global configuration mode

## no rmon history

Use this command to delete the specified history control interface for the Remote Monitoring (RMON) functions on the switch.

## Syntax

```
no rmon history [ <1-65535> ]
```

where

[<1-65535>] is an optional parameter that specifies the index number for the history control interface. The range of values is 1 to 65535.

## rmon memsize

Use this command to specify the amount of Random Access Memory (RAM) in bytes to allocate for the Remote Monitoring (RMON) functions on the switch.

## Syntax

```
rmon memsize <memsize>
```

where

<memsize> specifies the memory size in bytes. The range of values is 250000 to 4000000.

## Command mode

Global configuration mode

## rmon stats

Use this command to create an ether-stats control interface for the Remote Monitoring (RMON) functions on the switch.

## Syntax

```
rmon stats <1-65535> <ports> [owner <value> ]
```

## Parameters

This command includes the following options:

<b>rmon stats</b>	
<b>followed by:</b>	
<1-65535>	Specifies the index number of the ether-stats control interface.  The range of values is 1 to 65535.
<ports>	Specifies the port(s) in the port list form: {slot/port [-slot/port] [, ...]}
[owner <value> ]	Specifies the name of the owner. The range of values is a string of 1 to 48 characters.

## Command mode

Global configuration mode

## no rmon stats

Use this command to delete the specified ether-stats control interface for the Remote Monitoring (RMON) functions on the switch.

## Syntax

```
no rmon stats [<1-65535> ]
```

where

1-65535 is an optional parameter that specifies the index number for the ether-stats control interface. The range of values is 1 to 65535.

### Command mode

Global configuration mode

## rmon trap-option

Use this command to specify whether the Remote Monitoring (RMON) traps are sent to the owner or all trap recipients.

### Syntax

```
rmon trap-option {toOwner|toAll}
```

### Parameters

This command includes the following options:

<b>rmon trap-option</b>	
<b>followed by:</b>	
<b>toOwner</b>	Specifies to send RMON traps to the owner.
<b>toAll</b>	Specifies to send RMON traps to all trap recipients.

### Command mode

Global configuration mode

## rmon util-method

Use this command to specify whether port utilization is calculated in half or full duplex for the Remote Monitoring (RMON) functions on the switch.

### Syntax

```
rmon util-method {half|full}
```

### Parameters

This command includes the following options:

<b>rmon util-method</b>	
<b>followed by:</b>	
<b>half</b>	Specifies that port utilization is calculated in half duplex.
<b>full</b>	Specifies that port utilization is calculated in full duplex.

**Command mode**

Global configuration mode

**show port-mirroring**

Use this command to display information about mirrored ports on the switch.

**Syntax**

```
show port-mirroring
```

**Command mode**

Privileged EXEC mode

**show interface fast-ethernet or gigabit-Ethernet**

Use this command to display information about the ports on the switch.

**Syntax**

```
show interface <fast-ethernet|gigabit-Ethernet>
```

where

**ports** is an optional parameter that specifies the applicable ports in port list form: { slot/port [- slot/port ] [, ...] }.

**Parameters**

This command includes the following options:

<pre>show interface &lt;fastEthernet gigabitEthernet&gt;</pre>	
<b>followed by:</b>	
<b>all [ &lt;ports&gt; ] [by &lt;value&gt; ]</b>	Displays general information about all ports or about specified ports.  [by <value> ] displays group information by ID number or by each feature {default ID}
<b>config [ &lt;ports&gt; ]</b>	Displays general configuration information about all ports or about specified ports.
<b>cp-limit</b>	Displays the port packet cp-limit commands.

```
show interface <fastEthernet|gigabitEthernet>
```

**followed by:**

<b>eapol [ &lt;ports&gt; ]</b>	Displays Extensible Authorization Protocol (EAP) information about all ports or about specified ports. There are 5 options: <ul style="list-style-type: none"><li>• auth-diags</li><li>• auth-stats</li><li>• config</li><li>• oper-stats</li><li>• session-stats</li></ul>
<b>error [ &lt;ports&gt; ]</b>	Displays general error information about all ports or about specified ports.
<b>igmp [ &lt;ports&gt; ]</b>	Displays Internet Group Management Protocol (IGMP) information about all ports or about specified ports.
<b>interface [ &lt;ports&gt; ]</b>	Displays information about the physical interface for all ports or for specified ports.
<b>name [ &lt;ports&gt; ]</b>	Displays general information, including the name or names for all ports or for specified ports.
<b>qos [ &lt;ports/slots&gt; ]</b>	Displays Quality of Service (QoS) information about all ports or about specified ports.
<b>tx-queue [ &lt;ports&gt; ]</b>	Displays the transmit queue for all ports or for specified ports.
<b>unknown-mac-discard [ &lt;ports&gt; ]</b>	Displays settings for the unknown MAC discard feature for all ports or for specified ports.

### Command mode

Privileged EXEC mode

## show interface statistics

Use this command to display statistics for the specified port or for all ports.

### Syntax

```
show interface <fastEthernet|gigabitEthernet> statistics
```

where

[<portlist>] is an optional parameter that specifies the port(s) in port list form: { slot/port [- slot/port ] [, ...]}.

### Parameters

This command includes the following options:

<code>show interface &lt;fastEthernet gigabitEthernet&gt; statistics</code>
---

**followed by:**

<code>show interface &lt;fastEthernet gigabitEthernet&gt; statistics</code>	
<b>followed by:</b>	
<code>rmon [ &lt;portlist&gt; ]</code>	Displays remote monitoring statistics about all ports or about specified ports.
<code>stg [ &lt;portlist&gt; ]</code>	Displays statistics about spanning tree groups for all ports or for specified ports.

### Command mode

Privileged EXEC mode

## show rmon

Use this command to display various Remote Monitoring (RMON) settings.

### Syntax

```
show rmon
```

### Parameters

This command includes the following options:

<code>show rmon</code>
------------------------

**followed by:**

<code>show rmon</code>	
<b>followed by:</b>	
<code>info</code>	Displays the status and general configuration of RMON on the switch.
<code>alarm</code>	Displays the RMON Alarm table entries.
<code>event</code>	Displays the RMON event table entries.
<code>history</code>	Displays the RMON history control table entries.
<code>log</code>	Displays the RMON log table entries.
<code>stats</code>	Displays the RMON statistics table entries.

### Command mode

Privileged EXEC mode

## show spanning-tree config

Use this command to display the Spanning-Tree Group (STG) status and configuration for the specified STG.

### Syntax

```
show spanning-tree config [<sid>]
```

where

<sid> is an optional parameter that specifies the STG ID. The range of values is 1 to 64.

### Command mode

Privileged EXEC mode

For more information about system tools, see *Configuring VLANs, Spanning Tree, and MultiLink Trunking using the NNCLI*.

## show spanning-tree port

Use this command to display the Spanning-Tree Group (STG) information about all ports or about specified ports.

### Syntax

```
show spanning-tree port [<portlist>]
```

where

[<portlist>] is an optional parameter that specifies the applicable ports in the port list form: { slot/port [- slot/port ] [, ...] }.

### Command mode

Privileged EXEC mode

## show sys-info

Use this command to display system information about status, hardware, software, and operation of the switch. The information available from the **show sys-info** command includes general information about the system (such as location), hardware (chassis, power supplies, fans, and modules), system errors, boot configuration, software versions, memory, port information (locking status, configurations, names, interface status), OSPF (area, interface, neighbors), and log and trace files.

### Syntax

```
show sys-info [asic] [card] [mda]
```

### Parameters

This command includes the following options:

<b>show sys-info</b>	
<b>followed by:</b>	
<b>asic</b>	Displays detailed information about the Application Specific Integrated Circuit (ASIC) trays in the switch.
<b>card</b>	Displays detailed information about the cards in the switch.
<b>mda</b>	Displays detailed information about the Media Dependent Adapters (MDAs) in the switch.

**Command mode**

Privileged EXEC mode

**show test**

Use this command to display test results for the switch.

**Syntax****show test [artable] [fabric] [loopback [<portlist>]]****Parameters**

This command includes the following options:

<b>show test</b>	
<b>followed by:</b>	
<b>loopback [&lt;portlist&gt;]</b>	Displays the results of the latest loopback test for the switch or for the specified port or ports.

**Command mode**

Privileged EXEC mode

**show trace file**

Use this command to display the trace message file when tracing is enabled.

**Syntax****show trace file [tail]**

where

**[tail]** is an optional parameter that displays the log file in reverse order with the most recent information first.

**Command mode**

Privileged EXEC mode

**show trace level**

Use this command to display trace information for the switch.

**Syntax**

```
show trace level
```

**Command mode**

Privileged EXEC mode

**test**

Use this command to perform a loopback test. The test and show test commands allow you to test an Ethernet Routing Switch 8300 while the switch is operating and show the test results. The tests do not interfere with normal bridging and routing activities in the switch, but they do occupy the CPU.

**Syntax**

```
test [loopback <port/slot>] [stop loopback <port/slot>]
```

**Parameters**

This command includes the following options:

<b>test</b>	
<b>followed by:</b>	
<b>loopback &lt;port/slot&gt; [&lt;int ext&gt;]</b>	Places the specified ports into internal or external loopback mode. <ul style="list-style-type: none"> <li>• <b>portlist</b> specifies one or more ports, shown as { slot/port [-slot/port] [,....] }.</li> <li>• <b>int ext</b> is a string between 1 and 1536.</li> </ul>
<b>stop loopback &lt;port/slot&gt;</b>	Stops the current loopback test. <b>ports</b> specifies one or more ports, shown as { slot/port [-slot/port] [,....] }.

**Note:** To test a port in loopback mode, put the port into the testing state using the command `state [port <ports>] test`. After the test is complete, return the port to its normal mode using the command `state [port <ports>] enable`.

### Command mode

Privileged EXEC mode

## trace auto-enable

Use this command to configure the switch to automatically enable a trace in the event that CPU usage reaches a pre-defined value.

### Syntax

```
trace auto-enable [high-percentage <percent>]
[high-track-duration <seconds> ]
[low-percentage <percent> ]
[low-track-duration <seconds> ]
```

### Parameters

This command includes the following optional parameters:

<code>trace auto-enable</code>	
<b>followed by:</b>	
<code>[high-percentage &lt;percent&gt;]</code>	Specifies the percentage of CPU utilization above which auto trace is started.  The range of values is 60 to 100. The default is 90.
<code>[high-track-duration &lt;seconds&gt; ]</code>	Specifies the time in seconds to monitor CPU utilization before triggering a trace.  The range of values is 3 to 10. The default is 5.
<code>[low-percentage &lt;percent&gt; ]</code>	Specifies the percentage of CPU utilization below which auto-trace is stopped.  The range of values is 50 to 90. The default is 75.
<code>[low-track-duration &lt;seconds&gt; ]</code>	Specifies the time in seconds to monitor CPU utilization before disabling the trace.  The range of values is 3 to 10. The default is 5.

**Note:** The enabling or disabling of auto-trace is not saved to the configuration file. When the switch re-boots, auto-trace functionality is disabled.

### Command mode

Privileged EXEC mode

## trace auto-enable add-module

Use this command to add a software module to the automatic trace configuration.

### Syntax

```
trace auto-enable add-module <modid> <level>
```

### Parameters

This command includes the following parameters:

<b>trace auto-enable add-module</b>	
<b>followed by:</b>	
<modid>	Specifies the module to be traced. The range is 0 to 66. For example, 3 = Port Manager, 20 = Topology Discovery. For a complete list of module IDs, enter: <b>trace auto-enable add-module ?</b> .
<level>	<p>Specifies the level of detail for the trace. The options are:</p> <ul style="list-style-type: none"> <li>• 0 = Disabled</li> <li>• 1 = Very terse</li> <li>• 2 = Terse</li> <li>• 3 = Verbose</li> <li>• 4 = Very verbose</li> </ul>

**Note:** The enabling or disabling of auto-trace is not saved to the configuration file. When the switch re-boots, auto-trace functionality is disabled.

### Command mode

Privileged EXEC mode

## trace auto-enable auto-trace

Use this command to configure the switch to automatically enable a trace in the event that CPU usage reaches a pre-defined value.

### Syntax

```
trace auto-enable auto-trace <enable|disable>
```

### Parameters

This command includes the following parameters:

<b>trace auto-enable auto-trace</b>	
<b>followed by:</b>	
<b>enable</b>	Enables auto-trace. The default is disable.
<b>disable</b>	Disables auto-trace. The default is disable.

**Note:** The enabling or disabling of auto-trace is not saved to the configuration file. When the switch re-boots, auto-trace functionality is disabled.

### Command mode

Privileged EXEC mode

## trace auto-enable remove-module

Use this command to remove a module from the automatic trace configuration.

### Syntax

```
trace auto-enable remove-module <modid> <level>
```

### Parameters

This command includes the following parameters:

<b>trace auto-enable remove-module</b>	
<b>followed by:</b>	
<b>&lt;modid&gt;</b>	Specifies the module for disabling of auto-trace. For example, 3 = Port Manager, 20 = Topology Discovery. For a complete list of module IDs, enter: <b>trace auto-enable add-module ?</b>
<b>&lt;level&gt;</b>	Specifies the level of the trace. The options are: <ul style="list-style-type: none"><li>• 0 = Disabled</li></ul>

<code>trace auto-enable remove-module</code>	
--	--

<b>followed by:</b>	
---------------------	--

- |  |  |
|--|--|
|  | <ul style="list-style-type: none"> <li>• 1 = Very terse</li> <li>• 2 = Terse</li> <li>• 3 = Verbose</li> <li>• 4 = Very verbose</li> </ul> |
|--|--|

**Note:** The enabling or disabling of auto-trace is not saved to the configuration file. When the switch re-boots, auto-trace functionality is disabled.

### **Command mode**

Privileged EXEC mode

## **trace clear**

Use this command to clear the trace file.

### **Syntax**

`trace clear`

### **Command mode**

Privileged EXEC mode

## **trace filter**

Use this command to filter trace messages.

### **Syntax**

`trace filter`

### **Command mode**

Privileged EXEC mode

## **trace grep**

Use this command to search and extract information from a text string.

### **Syntax**

`trace grep`

### **Command mode**

Privileged EXEC mode

## trace level

Use this command to specify the trace level for a software module with the specified module ID. Use ? to see a list of ID numbers.

### Syntax

```
trace level [ <modid> ] [ <level> ]
```

### Parameters

This command includes the following options:

<b>trace level</b>	
<b>followed by:</b>	
[ <modid> ]	<p>Specifies the module to be traced. For example, 3 = Port Manager, 20 = Topology Discovery. For a complete list of module IDs, enter:</p> <p><b>trace auto-enable add-module ?.</b></p>
[ <level> ]	<p>Specifies the level of detail for the trace. The options are:</p> <ul style="list-style-type: none"> <li>• 0 = Disabled</li> <li>• 1 = Very terse</li> <li>• 2 = Terse</li> <li>• 3 = Verbose</li> <li>• 4 = Very verbose</li> </ul>

### Command mode

Privileged EXEC mode

## trace off

Use this command to disable tracing on a module.

### Syntax

```
trace off
```

### Command mode

Privileged EXEC mode

## trace route-policy

Use this command to trace a route policy.

### Syntax

```
trace route-policy
```

**Command mode**

Privileged EXEC mode

**trace screen**

Use this command to display the trace on the screen.

**Syntax**

```
trace screen [<setting>]
```

where

[<setting>] is an optional parameter that specifies whether the trace is displayed on the screen. The options are: **on** or **off**.

**Command mode**

Privileged EXEC mode

**traceroute**

Use this command to trace the route to a remote host. It is a valuable tool for troubleshooting because it shows all the routes that are used or indicates that the remote network cannot be reached.

**Syntax**

```
traceroute <ipaddr> [<datasize>] [-m <value>]
[-p <value>] [-q <value>] [-w <value>] [-v]
```

**Parameters**

This command includes the following options:

<b>traceroute</b>	
<b>followed by:</b>	
<ipaddr>	Specifies the IP address of the remote host.
[<datasize>]	Specifies the size of the probe packet. The range of values is 1 to 1464.
[-m <value>]	Specifies the maximum time-to-live (TTL) value. The range of values is 1 to 255.
[-p <value>]	Specifies the base UDP port number. The range of values is 0 to 65535

<b>traceroute</b>	
<b>followed by:</b>	
<b>[ -q &lt;value&gt; ]</b>	Specifies the number of probes per TTL.  The range of values is 1 to 255.
<b>[ -w &lt;value&gt; ]</b>	Specifies the wait time per probe.  The range of values is 1 to 255.
<b>[ -v ]</b>	Specifies the verbose mode for displaying extensive trace information.

### Command mode

Privileged EXEC mode

## vct test

Use this command to configure and enable the Virtual Cable Tester (VCT).

**Note:** The following message will appear:

WARNING: VCT test will impact the traffic flow. Do you want to continue y/n?

### Syntax

**vct test <ports>**

where

<**ports**> specifies the port(s) in port list form:  
{ slot/port [- slot/port ] [, ...] }.

### Command mode

Global Configuration mode



## Multicast services commands

This chapter describes NNCLI multicast services commands and their parameters.

Multicast Services Command
"debug ip pim" (page 381)
"interface vlan" (page 382)
"ip igmp " (page 383)
"no ip igmp" (page 386)
"default ip igmp" (page 387)
"ip igmp generate-log" (page 389)
"no ip igmp generate-log" (page 390)
"default ip igmp generate-log" (page 390)
"ip igmp generate-trap" (page 390)
"no ip igmp generate-trap" (page 390)
"default ip igmp generate-trap" (page 390)
"ip igmp immediate-leave-mode" (page 382)
"default ip igmp immediate-leave-mode" (page 383)
"ip igmp mrdisc" (page 391)
"no ip igmp mrdisc " (page 391)
"default ip igmp mrdisc" (page 392)
"ip igmp snoop-querier" (page 392)
"no ip igmp snoop-querier" (page 392)
"ip igmp snoop-querier-addr" (page 392)
"no ip igmp snoop-querier-addr" (page 393)
"ip igmp stream-limit" (page 393)
"no ip igmp stream-limit" (page 393)
"ip igmp stream-limit-group enable max-streams" (page 394)
"no ip igmp stream-limit-group " (page 394)

Multicast Services Command
"default ip igmp stream-limit-group" (page 394)
"ip igmp stream-limit-max-streams" (page 394)
"default ip igmp stream-limit-max-streams" (page 395)
"ip mroute static-source-group " (page 395)
"no ip mroute static-source-group" (page 395)
"ip pim" (page 396)
"ip pim enable" (page 399)
"no ip pim " (page 400)
"ip pim interface virtual neighbor " (page 400)
"ip pim rp-candidate group rp" (page 401)
"no ip pim rp-candidate group rp" (page 401)
"ip pim static-rp" (page 402)
"no ip pim static-rp " (page 403)
"show debug ip pim" (page 403)
"show interfaces vlan igmp" (page 403)
"show ip igmp" (page 403)
"show ip igmp access" (page 404)
"show ip igmp cache" (page 404)
"show ip igmp group" (page 405)
"show ip igmp group " (page 405)
"show ip igmp interface" (page 406)
"show ip igmp mrdisc" (page 406)
"show ip igmp router-alert" (page 406)
"show ip igmp sender" (page 406)
"show ip igmp snooping" (page 407)
"show ip igmp snoop-trace" (page 407)
"show ip igmp static" (page 408)
"show ip igmp stream-limit " (page 408)
"show ip igmp sys" (page 408)
"show ip mroute static-source-group" (page 408)
"show ip pim" (page 409)
"show ip pim active-rp" (page 409)
"show ip pim bsr" (page 409)
"show ip pim interface" (page 409)
"show ip pim interface vlan" (page 410)

Multicast Services Command
"show ip pim mroute" (page 410)
"show ip pim neighbor" (page 410)
"show ip pim rp-candidate" (page 410)
"show ip pim virtual-neighbor" (page 411)

## debug ip pim

Use this command to configure PIM-SM protocol traces for troubleshooting.

### Syntax

```
debug ip pim
```

### Parameters

This command includes the following parameters:

debug ip pim followed by:	
assert / no debug ip pim assert	Allows you to set the switch to display the assert debug traces
bstrap /no debug ip pim bstrap	Allows you to set the switch to display bootstrap debug traces.
group<ipaddress>	Allows you to set the switch to display debug traces from a specific group ip-address.
hello / no debug ip pim hello	Allows you to set the switch to display hello debug traces.
joinprune /no debug ip pim joinprune	Allows you to set the switch to display join/prune debug traces.
pimdbgtrace /no debug ip pim pimdbgtrace	Allows you to set the switch to display PIM-SM debug traces.
pimdbglog /no debug ip pim pimdbglog	Allows you to control whether the switch logs debug traces.
register /no debug ip pim register	Allows you to set the switch to display register debug traces.

<b>debug ip pim followed by:</b>	
<b>regstop /no ip debug ip pim regstop</b>	Allows you to set the switch to display register stop debug traces.
<b>rp-adv / no debug ip pim rp-adv</b>	Allows you to set the switch to display rp advertisement debug traces.
<b>send-trace /no debug ip pim send-trace</b>	Allows you to set the switch to display send debug traces.
<b>rcv-dbg-trace /no debug ip pim rcv-dbg-trace</b>	Allows you to set the switch to display received debug traces.
<b>source&lt;ipaddress&gt;</b>	Allows you to set the switch to display debug traces from a specific source ip-address.

**Command mode**

Global configuration mode

**interface vlan**

Use this command to access the interface on a Virtual LAN (VLAN).

**Syntax****interface vlan <vid>**

where

**<vid>** is a VLAN ID from 1 to 4000. (Note that 1 to 2000 is the default, while 1 to 4000 is valid when the *vid-max4k* flag is set to true).**Command mode**

Interface configuration mode

**ip igmp immediate-leave-mode**

Use this command to set the immediate leave mode.

**Syntax****ip igmp immediate-leave-mode <multiple-user|one-user mode>**

where

**<multiple-user|one-user mode>** specifies the immediate leave mode as multiple user or one user.

**Command mode**

Global configuration mode

**default ip igmp immediate-leave-mode**

Use this command to set the immediate leave mode to the default setting.

**Syntax**

```
default ip igmp immediate-leave-mode
```

**Command mode**

Global configuration mode

**ip igmp**

Use this command to configure IGMP on a VLAN.

**Syntax**

```
ip igmp
```

**Parameters**

This command includes the following parameters:

<b>ip igmp</b>	
<b>followed by;</b>	
<b>access-list WORD &lt;1-64&gt; &lt;HostAddress&gt; &lt;MaskAddress&gt; &lt;deny-tx deny-rx deny-both allow-only-tx allow-only-rx allow-only-both&gt;</b>	Sets the IP multicast access group list parameters. <ul style="list-style-type: none"> <li>• &lt;1-64&gt; is an IP prefix-list entry name in a 1 to 64 character string.</li> <li>• &lt;deny-tx deny-rx deny-both allow-only-tx allow-only-rx allow-only-both&gt; indicates the action you want for the specified IGMP interface. For example, if you specify deny-both, the interface denies both transmitted and received traffic.</li> </ul>
<b>immediate-leave</b>	Enables IGMP immediate-leave mode on the interface. The default is enabled.
<b>immediate-leave-members {slot/port [-slot/port] [, ...]}</b>	If you enable immediate-leave, this parameter configures IGMP immediate-leave members. The default is added.

<pre>ip igmp</pre> <p><b>followed by:</b></p>	
<b>last-member-query-interval</b>	Configures the IGMP last member query interval (in 1/10 seconds).  .
<b>mrouter {slot/port [-slot/port] [, ...]}</b>	Adds multicast router ports.  <b>Note:</b> When IGMP join or multicast data ingress to an Ethernet Routing Switch 8300 snoop VLAN port, they are only forwarded upstream via the querier port. You can use this parameter to create your own mrouter ports statically. After you create static mrouter ports, join and data are also forwarded to these static mrouter ports.
<b>proxy</b>	Enables the proxy option for the VLAN.  <b>Note:</b> When IGMP report messages come from different clients, all of these messages are sent to the querier. If you enable IGMP proxy snoop, then only one report message is sent to the querier for that group. As a result, this parameter allows you to suppress control messages going to the CPU.
<b>query-interval</b>	Sets the frequency (in seconds) at which host query packets are transmitted on the VLAN.  <b>Note:</b> In the case of IGMP snoop, be sure that the query-interval is configured the same as the multicast router (IGMP querier).
<b>query-max-response &lt;0-255&gt;</b>	The maximum response time (in 1/10 seconds) advertised in IGMPv2 general queries on this interface.

<b>ip igmp</b> <b>followed by:</b>	
<b>robust-value</b>	<p>Allows tuning for the expected packet loss on a network.</p> <p><b>Note:</b> In the case of IGMP snoop, be sure that the robustval parameter is configured the same as the multicast router (IGMP querier).</p>
<b>router-alert</b>	<p>Enables the router alert feature. When enabled, this parameter instructs the router to drop packets without the router-alert flag in the IP header.</p> <p><b>Note:</b> To maximize your network performance, Nortel Networks recommends that you set this parameter according to the version of IGMP currently in use.</p> <ul style="list-style-type: none"> <li>• IGMPv1 - Disable</li> <li>• IGMPv2 - Enable</li> <li>• IGMPv3 - Enable (not supported in the Ethernet Routing Switch 8300)</li> </ul>
<b>snooping</b>	<p>Enables the snooping option for the VLAN.</p> <p><b>Note:</b> When multicast data enters a Layer 2 VLAN, data packets are flooded to all ports in that VLAN. If you enable IGMP snoop on the VLAN, these packets are only forwarded to the ports on which IGMP joins have been received. In other words, data packets are forwarded only on multicast client ports.</p>

<b>ip igmp</b>	
<b>followed by:</b>	
<b>static-group &lt;groupAddress&gt; port {slot/port [-slot/port] [, ...]} &lt;static blocked&gt;</b>	Configures IGMP static members on a VLAN. The Ethernet Routing Switch 8300 allows you to configure static receivers, or members, for given multicast groups on specific VLANs using the VLAN IP address. Static receivers allow multicast traffic to be sent for the configured groups on the VLAN without IGMP receivers having to be attached to this VLAN.
<b>version &lt;1 2&gt;</b>	Specifies the version of IGMP as IGMPv1 or IGMPv2. The default is IGMPv2.

**Command mode**

Interface VLAN mode

**no ip igmp**

Use the following command to disable IGMP features on a VLAN.

**Syntax****no ip igmp****Parameters**

This command includes the following parameters:

<b>no ip igmp</b>	
<b>followed by:</b>	
<b>access-list &lt;grpAddr&gt; WORD &lt;1-64&gt;</b>	Deletes the selected multicast access group.
<b>immediate-leave</b>	Disables IGMP fast-leave mode on the interface.
<b>immediate-leave-members {slot/port [-slot/port] [, ...]}</b>	If you disable fast-leave, this parameter disables IGMP fast-leave members.
<b>mrouter {slot/port [-slot/port] [, ...]}</b>	Deletes specific multicast router ports.
<b>proxy</b>	Disables the proxy option for the VLAN.
<b>router-alert</b>	Disables the router alert feature.

<b>no ip igmp</b>	
<b>followed by:</b>	
<b>snooping</b>	Disables the snooping option for the VLAN.

  

<b>static-group &lt;groupAddress&gt;</b>	Configures IGMP static members on a VLAN.
--	---

**Command mode**

Interface VLAN mode

**default ip igmp**

Use this command to set the IGMP parameters to the default values

**Syntax****default ip igmp****Parameters**

This command includes the following parameters:

<b>default ip igmp</b>	
<b>followed by:</b>	
<b>access-list WORD&lt;1-64&gt; &lt;HostAddress&gt; &lt;MaskAddress&gt; &lt;deny-tx deny-rx deny-both allow-only-tx allow-only-rx allow-only-both&gt;</b>	<p>Sets the IP multicast access group list parameters to default values.</p> <ul style="list-style-type: none"> <li>• &lt;1-64&gt; is an IP prefix-list entry name in a 1 to 64 character string.</li> <li>• &lt;deny-tx deny-rx deny-both allow-only-tx allow-only-rx allow-only-both&gt; indicates the action you want for the specified IGMP interface. For example, if you specify deny-both, the interface denies both transmitted and received traffic.</li> </ul>
<b>immediate-leave</b>	Enables IGMP immediate-leave mode on the interface. The default is enabled.
<b>immediate-leave-members {slot/port [-slot/port] [, ...]}</b>	If you enable immediate-leave, this parameter configures IGMP immediate-leave members. The default is added.

<pre>default ip igmp followed by;</pre>	
<b>last-member-query-interval</b>	Configures the IGMP last member query interval (in 1/10 seconds).
<b>proxy</b>	<p>Enables the proxy option for the VLAN.</p> <p><b>Note:</b> When IGMP report messages come from different clients, all of these messages are sent to the querier. If you enable IGMP proxy snoop, then only one report message is sent to the querier for that group. As a result, this parameter allows you to suppress control messages going to the CPU.</p>
<b>query-interval</b>	<p>Sets the frequency (in seconds) at which host query packets are transmitted on the VLAN.</p> <p><b>Note:</b> In the case of IGMP snoop, be sure that the query-interval is configured the same as the multicast router (IGMP querier).</p>
<b>query-max-response &lt;0-255&gt;</b>	The maximum response time (in 1/10 seconds) advertised in IGMPv2 general queries on this interface.
<b>robust-value</b>	<p>Allows tuning for the expected packet loss on a network.</p> <p><b>Note:</b> In the case of IGMP snoop, be sure that the robustval parameter is configured the same as the multicast router (IGMP querier).</p>

<pre>default ip igmp followed by;</pre>	
<b>router-alert</b>	<p>Enables the router alert feature. When enabled, this parameter instructs the router to drop packets without the router-alert flag in the IP header.</p> <p><b>Note:</b> To maximize your network performance, Nortel Networks recommends that you set this parameter according to the version of IGMP currently in use.</p> <ul style="list-style-type: none"> <li>• IGMPv1 - Disable</li> <li>• IGMPv2 - Enable</li> <li>• IGMPv3 - Enable (not supported in the Ethernet Routing Switch 8300)</li> </ul>
<b>snooping</b>	<p>Enables the snooping option for the VLAN.</p> <p><b>Note:</b> When multicast data enters a Layer 2 VLAN, data packets are flooded to all ports in that VLAN. If you enable IGMP snoop on the VLAN, these packets are only forwarded to the ports on which IGMP joins have been received. In other words, data packets are forwarded only on multicast client ports.</p>
<b>default ip igmp version</b>	Sets IGMP to the default version. The default is IGMPv2.

**Command mode**

Interface VLAN mode

**ip igmp generate-log**

Use this command to configure on IGMP generate log.

**Syntax**`ip igmp generate-log`**Command mode**

Global configuration mode

**no ip igmp generate-log**

Use this command to disable an IGMP generate log.

**Syntax**

```
no ip igmp generate-log
```

**Command mode**

Global configuration mode

**default ip igmp generate-log**

Use this command to set an IGMP generate log to default values.

**Syntax**

```
default ip igmp generate-log
```

**Command mode**

Global configuration mode

**ip igmp generate-trap**

Use this command to configure an IGMP generate trap.

**Syntax**

```
ip igmp generate-trap
```

**Command mode**

Global configuration mode

**no ip igmp generate-trap**

Use this command to disable an IGMP generate log.

**Syntax**

```
no ip igmp generate-trap
```

**Command mode**

Global configuration mode

**default ip igmp generate-trap**

Use this command to set an IGMP generate log to default values.

**Syntax**

```
default ip igmp generate-trap
```

**Command mode**

Global configuration mode

## ip igmp mrdisc

Use this command to configure multicast router discovery parameters on a VLAN.

### Syntax

```
ip igmp mrdisc
```

### Parameters

This command uses the following parameters:

<b>ip igmp mrdisc</b> <b>followed by:</b>	
<cr>	Enables multicast router discovery parameters on a VLAN. <ul style="list-style-type: none"><li>• &lt;cr&gt; is a carriage return.</li></ul>
<b>maxadvertinterval &lt;value&gt;</b>	Specifies the maximum interval in seconds between successive advertisements.
<b>maxinitadvertinterval &lt;value&gt;</b>	Specifies the maximum advertisement interval in seconds between successive initial advertisements.
<b>maxinitadvertisements &lt;value&gt;</b>	Specifies the maximum advertisements after initialisation.
<b>minadvertinterval &lt;value&gt;</b>	Specifies the minimum interval in seconds between successive advertisements.
<b>neighdeadinterval &lt;value&gt;</b>	Specifies the maximum time in seconds allowed before a neighbor is declared dead.

### Command mode

Interface VLAN mode

## no ip igmp mrdisc

Use this command to disable multicast router discovery on a VLAN.

**Syntax**

```
no ip igmp mrdisc
```

**Command mode**

Interface VLAN mode

**default ip igmp mrdisc**

Use this command to set the default values for multicast router discovery on a VLAN.

**Syntax**

```
default ip igmp mrdisc
```

**Command mode**

Interface VLAN mode

**ip igmp snoop-querier**

Use this command to enable IGMP snoop querier.

**Syntax**

```
ip igmp snoop-querier
```

**Command mode**

Interface VLAN mode

**no ip igmp snoop-querier**

Use this command to disable IGMP snoop querier.

**Syntax**

```
no ip igmp snoop-querier
```

**Command mode**

Interface VLAN mode

**ip igmp snoop-querier-addr**

Use this command to configure the source IP address used in the query message.

**Syntax**

```
ip igmp snoop-querier-addr<ipaddr>
```

where

<ipaddr> is the source IP address used in the query message.

**Command mode**

Interface VLAN mode

**no ip igmp snoop-querier-addr**

Use this command to return the source IP address to the default value, 0.0.0.0.

**Syntax**

```
no ip igmp snoop-querier-addr
```

**Command mode**

Interface VLAN mode

**ip igmp stream-limit**

Use this command to configure multicast stream limitation on a VLAN.

**Syntax**

```
ip igmp stream-limit
```

**Parameters**

This command includes the following parameters:

<b>ip igmp stream-limit</b>	
<b>followed by:</b>	
<b>&lt;cr&gt;</b>	<p>Enables multicast stream limitation on a VLAN.</p> <ul style="list-style-type: none"> <li>• &lt;cr&gt; is carriage return.</li> </ul>
<b>stream-limit-max-streams &lt;value&gt;</b>	<p>Sets the maximum number of streams allowed on an interface.</p> <ul style="list-style-type: none"> <li>• &lt;value&gt; is an integer in a range from 0 to 65535 and the default is 4.</li> </ul>

**Command mode**

Interface VLAN mode

**no ip igmp stream-limit**

Use this command to disable multicast stream limitation on a VLAN.

**Syntax**

```
no ip igmp stream-limit
```

**Command mode**

Interface VLAN mode

## ip igmp stream-limit-group enable max-streams

Use this command to enable the multicast stream limit group and set the maximum streams.

### Syntax

```
ip igmp stream-limit-group <ports> enable max-streams <value>
```

where

<ports> is a port list in the format {slot/port [..slot/port]}. These are the member ports of the multicast stream limit group.

<value> sets the maximum number of streams allowed on an interface. The range is from 0 to 65535, and the default is 4.

### Command mode

Interface VLAN mode

## no ip igmp stream-limit-group

Use this command to disable a multicast stream limit member.

### Syntax

```
no ip igmp stream-limit-group <ports>
```

where

<ports> is a port list in the format {slot/port [..slot/port]}. These are the member ports of the multicast stream limit group.

### Command mode

Interface VLAN mode

## default ip igmp stream-limit-group

Use this command to set a multicast stream limit group parameters to the default values.

### Syntax

```
default ip igmp stream-limit-group <ports>
```

where

<ports> is a port list in the format {slot/port [..slot/port]}. These are the member ports of the multicast stream limit group.

## ip igmp stream-limit-max-streams

Use this command to configure the stream limitation maximum streams.

### Syntax

```
ip igmp stream-limit-max-streams <0-65535>
```

where

<0-65535> is the value of the maximum streams.

#### Command mode

Interface VLAN mode

### default ip igmp stream-limit-max-streams

Use this command to set the stream imitation maximum streams to the default values.

#### Syntax

```
default ip igmp stream-limit-max-streams
```

#### Command mode

Interface VLAN mode

### ip mroute static-source-group

Use this command to add a static source-group entry to the PIM multicast routing table.

#### Syntax

```
ip mroute static-source-group <A.B.C.D> <A.B.C.D/0-32>
```

where

<A.B.C.D> is the multicast source address for this static source-group entry. How you configure the source address depends on the protocol you are using and in what mode.

<A.B.C.D/0-32> is the subnet mask of the source for this static source-group entry.

#### Command mode

Global configuration mode

### no ip mroute static-source-group

Use this command to remove a static source-group entry from the PIM multicast routing table.

#### Syntax

```
no ip mroute static-source-group <A.B.C.D> <A.B.C.D/0-32>
```

where

<A.B.C.D> is the multicast source address for this static source-group entry. How you configure the source address depends on the protocol you are using and in what mode.

<A.B.C.D/0-32> is the subnet mask of the source for this static source-group entry.

---

## ip pim

Use this command to:

- configure PIM-SM globally.
- configure PIM-SM on a VLAN

### Configuring PIM-SM globally

Use this command to configure PIM-SM globally on a switch.

#### Syntax

`ip pim`

#### Parameters

This command includes the following parameters:

<code>ip pim</code> followed by:	
<code>bootstrap-period&lt;integer&gt;</code>	<p>Specifies the interval (in seconds) that the elected BSR waits between originating bootstrap messages.</p> <ul style="list-style-type: none"> <li>• <code>integer</code> is an integer in the range of 5–32757. The default is 60.</li> </ul>
<code>rp-c-adv-timeout&lt;integer&gt;</code>	<p>Specifies how often (in seconds) that routers configured as candidate RPs send C-RP advertisement messages. When this timer expires, the C-RP sends an advertisement message to the elected BSR.</p> <ul style="list-style-type: none"> <li>• <code>integer</code> is an integer in the range of 5–26214. The default is 60.</li> </ul>
<code>disc-data-timeout &lt;integer&gt;</code>	<p>Specifies how long (in seconds) to discard data until the Join is received from the RP. An ipmc discard record is created after a register packet is sent, until the the timer expires or when a Join is received.</p> <ul style="list-style-type: none"> <li>• <code>integer</code> is an integer in the range of 5–65535. The default is 60.</li> </ul>

<p><b>ip pim</b> followed by:</p>	<p><b>activity-chk-interval &lt;15 30 210&gt;</b></p> <p>Specifies how often (in seconds) to check traffic activity for a multicast group. The lower the value, the more often the switch checks the activity.</p> <ul style="list-style-type: none"> <li>The default is 210.</li> </ul> <p><b>Notes:</b></p> <ul style="list-style-type: none"> <li>Before you can change the activity-chk-interval, you must disable PIM-SM globally.</li> <li>Nortel recommends an activity check interval of 30 seconds.</li> <li>Nortel recommends that you set the activity check interval to 210 seconds for systems that have a large number (200+) of S,G streams.</li> <li>When one of the timer activity-chk-interval or fwd-cache-timeout is configured with a nondefault value, the other cannot be configured.</li> </ul>
<p><b>join-prune-interval &lt;integer&gt;</b></p>	<p>Specifies how long to wait (in seconds) before the PIM-SM router sends out the next join/prune message to its upstream neighbors.</p> <ul style="list-style-type: none"> <li><b>integer</b> is an integer in the range of 1–18724. The default is 60.</li> </ul>
<p><b>fwd-cache-timeout&lt;integer&gt;</b></p>	<p>Configures the forward cache timeout globally. The default is 210</p> <ul style="list-style-type: none"> <li><b>integer</b> is an integer in the range 10–86400. The default is 210</li> </ul>

<b>ip pim</b> <b>followed by:</b>	
<b>register-suppression-timeout &lt;integer&gt;</b>	Sets the PIM-SM register suppression timeout. The default is 60. <ul style="list-style-type: none"> <li>• <b>integer</b> is an integer in the range 6–65535. The default is 60</li> </ul>
<b>unicast-route-change-timeout &lt;integer&gt;</b>	Sets the PIM-SM unicast route change timeout. <ul style="list-style-type: none"> <li>• <b>integer</b> is an integer in the range 2–65535. The default is 5.</li> </ul>

**Command mode**

Global configuration mode

**Configuring PIM-SM on a VLAN**

Use this command to configure PIM-SM on a VLAN.

**Syntax****ip pim****Parameters**

This command includes the following parameters:

<b>ip pim</b> <b>followed by:</b>	
<b>bsr-candidate preference &lt;integer&gt;</b>	Enables the BSR candidate. <ul style="list-style-type: none"> <li>• <b>integer</b> is an integer with a range of 0 to 255. The default is -1, which indicates that the current interface is not a Candidate BSR</li> </ul>
<b>enable</b>	Enables PIM on a particular VLAN.

<b>ip pim</b> <b>followed by:</b>	
<b>interface-type &lt;active passive&gt;</b>	Sets the interface type on a particular VLAN. <ul style="list-style-type: none"> <li>• <b>active</b> allows PIM-SM control traffic to be transmitted and received.</li> <li>• <b>passive</b> prevents PIM-SM control traffic from being transmitted or received, thereby reducing the load on a system. This feature is useful when a high number of PIM-SM interfaces exist and are connected to end users, not to other switches.</li> </ul>
<b>join-prune-interval&lt;seconds&gt;</b>	Specifies how long to wait (in seconds) before the PIM-SM switch sends out the next join/prune message to its upstream neighbors. The range is 1 to 18724 seconds and the default is 60 seconds.
<b>query-interval&lt;seconds&gt;</b>	Sets the hello interval to a particular VLAN. The range is 0 to 18724 seconds and the default is 30 seconds.

**Command mode**  
Interface VLAN mode

## ip pim enable

You can use this command to:

- enable Protocol Independent Multicast-Sparse Mode (PIM-SM) globally.
- enable PIM-SM on a selected VLAN

When you enable PIM-SM on a selected VLAN, you must also enable it globally.

### Enabling PIM-SM globally

You can use this command to enable PIM globally on the switch

#### Syntax

**ip pim enable**

#### Command mode

Global configuration mode

**Enabling PIM-SM on a VLAN**

You can use this command to enable PIM on a VLAN.

**Syntax**

```
ip pim enable
```

**no ip pim**

Use this command to:

- disable PIM-SM globally.
- disable PIM-SM on a VLAN

**Disabling PIM-SM globally**

You can use this command to disable PIM globally on the switch

**Syntax**

```
no ip pim
```

**Command mode**

Global configuration mode

**Disabling PIM-SM on a VLAN**

You can use this command to disable PIM on a VLAN.

**Syntax**

```
no ip pim
```

**Command mode**

Interface VLAN mode

**ip pim interface virtual neighbor**

Use this command to enable a virtual neighbor. A virtual neighbor is a PIM-SM neighbor IP address on the Ethernet Routing Switch 8300 neighbor table. A virtual neighbor is typically used where the next-hop for a static route cannot run PIM-SM, such as the virtual VRRP address on an adjacent device.

**Syntax**

```
ip pim interface <ipaddr> virtual-neighbor <ipaddr>
```

where

<ipaddr> is the IP address of the interface.

<ipaddr> is the IP address of the virtual neighbor.

**Command mode**

Global configuration mode

**no ip pim interface virtual neighbor**

Use this command to disable a virtual neighbor.

**Syntax**

```
no ip pim interface <ipaddr> virtual-neighbor
```

where

<ipaddr> is the IP address of the interface.

**ip pim rp-candidate group rp**

Use this command to add a rendezvous point (RP) in the RP set.

**Syntax**

```
ip pim rp-candidate group<ipaddr> <mask> rp <ipaddr>
```

where

<ipaddr> is the IP address of the multicast group. When combined with the group mask, it identifies the prefix that the local router uses to advertise itself as a C-RP.

<mask> is the address mask of the multicast group. When combined with the group address, it identifies the prefix that the local router uses to advertise itself as a C-RP.

<ipaddr> is the IP address of the C-RP. This address must be one of the local PIM-SM enabled interfaces.

**Command mode**

Global configuration mode

**no ip pim rp-candidate group rp**

Use this command to remove a rendezvous point (RP) in the RP set.

**Syntax**

```
no ip pim rp-candidate group <ipaddr> <mask>
```

where

<ipaddr> is the IP address of the multicast group. When combined with the group mask, it identifies the prefix that the local router uses to advertise itself as a C-RP.

<mask> is the address mask of the multicast group. When combined with the group address, it identifies the prefix that the local router uses to advertise itself as a C-RP.

**Command mode**

Gobal configuration mode

**ip pim static-rp**

Use this command to enable a static RP.

**Syntax**

```
ip pim static-rp
```

When you enter this command, the following message appears:

WARNING: RP information learnt dynamically through BSR functionality will be lost.

Do you wish to enable Static RP? (y/n) ?

**Command mode**

Global configuration mode

**no ip pim static-rp**

Use this command to disable a static RP.

**Syntax**

```
no ip pim static-rp
```

When you enter this command, the following message appears:

WARNING: Static RP information will be lost.

Do you wish to disable Static RP? (y/n) ?

**Command mode**

Global configuration mode

**ip pim static-rp**

Use this command to add a static RP to the RP set.

**Syntax**

```
ip pim static-rp <group> <mask> <rp>
```

where

<group> is the IP address of the multicast group. When combined with the group mask, it identifies the range of the multicast addresses that the RP handles.

<mask> is the address mask of the multicast group. When combined with the group address, it identifies the range of the multicast addresses that the RP handles.

<rp> is the IP address of the static RP.

**Command mode**

Global configuration mode

## no ip pim static-rp

Use this command to remove a static RP.

### Syntax

```
no ip pim static-rp <group> <mask> <rp>
```

where

**<group>** is the IP address of the multicast group. When combined with the group mask, it identifies the range of the multicast addresses that the RP handles.

**<mask>** is the address mask of the multicast group. When combined with the group address, it identifies the range of the multicast addresses that the RP handles.

**<rp>** is the IP address of the static RP.

### Command mode

Global configuration mode

## show debug ip pim

Use this command to display the current PIM-SM debug trace flag settings on the switch.

### Syntax

```
show debug ip pim
```

### Command mode

Privileged EXEC mode

## show interfaces vlan igmp

This command allows you to view the IGMP VLAN interfaces.

### Syntax

```
show interfaces vlan igmp [<vid>]
```

where

**vid** is a VLAN ID from 1 to 4000. (Note that 1 to 2000 is the default, while 1 to 4000 is valid when the *vid-max4k* flag is set to true).

### Command mode

User EXEC mode

## show ip igmp

Use this command to display information about IGMP.

### Syntax

```
show ip igmp
```

## Parameters

This command includes the following options:

<b>show ip igmp</b>	
<b>followed by:</b>	
<b>access</b>	Displays information about IGMP multicast access filters.
<b>cache</b>	Displays information about IGMP cached groups.
<b>[&lt;count&gt;]group [&lt;count&gt;]</b>	Displays information about IGMP groups per port.
<b>interface</b>	Displays information about the IGMP interface (i.e., the IGMP querier).
<b>mrdisc</b>	Displays information about the multicast router discovery.
<b>router-alert</b>	Displays the IGMP router alert check status.
<b>[]sender [&lt;count&gt;]</b>	Displays information about the IGMP sender list.
<b>snoop</b>	Displays the status of IGMP snoop and proxy-snoop.
<b>static</b>	Displays information about the static and blocked ports for the IGMP-enabled interfaces.

## Command mode

Privileged EXEC mode

For more information about IGMP operations, see *Configuring IP Multicast Routing Protocols*.

## show ip igmp access

Once the access filter has been configured, this command allows you to view it.

### Syntax

```
show ip igmp access
```

### Command mode

Privileged EXEC mode

## show ip igmp cache

This command allows you to view the IGMP cache.

**Syntax**

```
show ip igmp cache
```

**Command mode**

User EXEC mode

**show ip igmp group**

This command allows you to view an IGMP group. This command displays dynamic and static groups, with both dynamic and static groups being counted separately. For example, if the same group has dynamic and static members, that group is counted twice.

**Syntax**

```
show ip igmp group [<count>]
```

where

<count> shows the total number of dynamic groups and the number of static group ports. For example, in the case of a static group, each static member port is counted.

**Command mode**

User EXEC mode

**show ip igmp group**

You can use this command to view the count of IGMP group entries.

**Syntax**

```
show ip igmp group
```

**Parameters**

This command includes the following parameters:

<b>show ip igmp group</b>	
<b>followed by:</b>	
<b>group &lt;A.B.C.D&gt;</b>	Specifies the IP multicast group address.
<b>member-subnet &lt;a.b.c.d/x a.b.c.d/x.x.x.x default&gt;</b>	Specifies the IP multicast group address.
<b>&lt;cr&gt;</b>	Indicates a Carriage return.

**Command mode**

User EXEC mode

## show ip igmp interface

Use this command to view the IGMP interface such as the IGMP querier.

### Syntax

```
show ip igmp interface
```

### Parameters

This command includes the following parameters:

<b>show ip igmp interface</b>	
<b>followed by:</b>	
<cr>	Indicates a Carriage return.
[{fastethernet gigabitetherent} {slot/port [-slot/port] [, ...]}]	Specifies the ports.
[vlan <1-4000>]	Specifies the VLAN ID in the range 1 to 4000.

### Command mode

User EXEC mode

## show ip igmp mrdisc

You can use this command to view the IGMP multicast router discovery parameters on a specific VLAN.

### Syntax

```
show ip igmp mrdisc
```

### Command mode

User EXEC mode

## show ip igmp router-alert

This command allows you to view the router alert check status.

### Syntax

```
show ip igmp router-alert
```

### Command mode

User EXEC mode

## show ip igmp sender

You can use this command to view the IGMP sender.

**Syntax**

```
show ip igmp sender
```

**Parameters**

This command includes the following parameters:

<b>show ip igmp sender</b> <b>followed by:</b>	
<b>count</b>	Shows the number of entries.
<b>&lt;cr&gt;</b>	Shows the IP sender with the host and the multicast group.
<b>group &lt;A.B.C.D&gt;</b>	Specifies the IP address of the multicast group address.
<b>member-subnet &lt;a.b.c.d/x a.b.c.d/x.x.x.x default&gt;</b>	Specifies the member IP address and network mask.

**Command mode**

User EXEC mode

**show ip igmp snooping**

You can use this command to view the IGMP snoop, snoop queriers and proxy status.

**Syntax**

```
show ip igmp snooping
```

**Command mode**

User Exec mode

**show ip igmp snoop-trace**

Use this command to show multicast hardware information.

**Syntax**

```
show ip igmp snoop-trace [source <value>] [group  
<value>]
```

where

[source <value>] specifies the source IP address in the format a.b.c.d.

[group <value>] specifies the group IP address in the format a.b.c.d.

**Command mode**

User EXEC mode

**show ip igmp static**

Once static member members have been added, this command allows you to view the static entries.

**Syntax**

```
show ip igmp static
```

**Command mode**

User EXEC mode

**show ip igmp stream-limit**

Use this command to show multicast stream limitation members on an interface.

**Syntax**

```
show ip igmp stream-limit {interface}
```

where

{interface} shows multicast stream limitation members on an interface.

**Command mode**

Privileged EXEC mode

**show ip igmp sys**

You can use this command to view the IGMP system parameters.

**Syntax**

```
show ip igmp sys
```

**Command mode**

User EXEC mode

**show ip mroute static-source-group**

Use this command to display information about the static source-groups on the current interface.

**Syntax**

```
show ip mroute static-source-group [<A.B.C.D>]
```

where

<A.B.C.D> is the multicast source address for the specific static source-group entry.

#### **Command mode**

Privileged EXEC mode

### **show ip pim**

Use this command to display the global status of PIM-SM on the switch.

#### **Syntax**

```
show ip pim
```

#### **Command mode**

Privileged EXEC mode

### **show ip pim active-rp**

Use this command to display information about the active rendezvous point (RP) for a specific group.

#### **Syntax**

```
show ip pim active-rp [>ipaddr]
```

where

**ipaddr** is the IP address of the multicast group.

#### **Command mode**

Privileged EXEC mode

### **show ip pim bsr**

Use this command to display information for a bootstrap router.

#### **Syntax**

```
show ip pim bsr
```

#### **Command mode**

Privileged EXEC mode

### **show ip pim interface**

Use this command to display information about a PIM-SM interface.

#### **Syntax**

```
show ip pim interface
```

#### **Command mode**

Privileged EXEC mode

**show ip pim interface vlan**

Use this command to display information about the PIM-SM interface setup for VLANs.

**Syntax**

```
show ip pim interface vlan
```

**Command mode**

Privileged EXEC mode

**show ip pim mroute**

Use this command to display information from the route table.

**Syntax**

```
show ip pim mroute
```

**Command mode**

Privileged EXEC mode

**show ip pim static-rp**

Use this command to display information about a static RP.

**Syntax**

```
show ip pim static-rp
```

**Command mode**

Privileged EXEC mode

**show ip pim neighbor**

Use this command to display information for the PIM-SM virtual neighbor.

**Syntax**

```
show ip pim neighbor
```

**Command mode**

Privileged EXEC mode

**show ip pim rp-candidate**

Use this command to display candidate RP information.

**Syntax**

```
show ip pim rp-candidate
```

**Command mode**

Privileged EXEC mode

## show ip pim virtual-neighbor

Use this command to display information about the neighboring routers configured with PIM-SM.

### Syntax

```
show ip pim virtual-neighbor
```

### Command mode

Privileged EXEC mode



# Quality of Service commands

This chapter describes NNCLI Quality of Service (Qos) commands and their parameters.

Quality of Service Commands
<a href="#">"interface FastEthernet/GigabitEthernet" (page 414)</a>
<a href="#">"qos" (page 414)</a>
<a href="#">"qos 8021p-override" (page 416)</a>
<a href="#">"no qos 8021p-override" (page 416)</a>
<a href="#">"qos shaper" (page 416)</a>
<a href="#">"qos shaper rate" (page 416)</a>
<a href="#">"qos shaper burst size" (page 416)</a>
<a href="#">"no qos shaper" (page 417)</a>
<a href="#">"qos trust-dscp enable" (page 417)</a>
<a href="#">"no qos trust-dscp enable" (page 417)</a>
<a href="#">"qos update-dynamic-mac-qos-level" (page 417)</a>
<a href="#">"no qos update-dynamic-mac-qos-level" (page 417)</a>
<a href="#">"qos map" (page 418)</a>
<a href="#">"qos policy create" (page 420)</a>
<a href="#">"no qos policy" (page 421)</a>
<a href="#">"qos policy action" (page 421)</a>
<a href="#">"no qos policy action" (page 422)</a>
<a href="#">"qos policy modify" (page 423)</a>
<a href="#">"qos egress-counter-set" (page 423)</a>
<a href="#">"no qos egress-counter-set" (page 424)</a>
<a href="#">"show qos egress-stats" (page 424)</a>
<a href="#">"show qos egress-counter-set" (page 425)</a>
<a href="#">"qos map-qos-level-override" (page 425)</a>
<a href="#">"show qos policy" (page 425)</a>

Quality of Service Commands
<a href="#">"show qos policy-stats" (page 425)</a>
<a href="#">"show qos map 8021p-to-class-map" (page 426)</a>
<a href="#">"show qos map 8021p-to-drop-precedence-map" (page 426)</a>
<a href="#">"show qos map class-to-8021p-map" (page 426)</a>
<a href="#">"show qos map class-to-8021p-policed-map" (page 426)</a>
<a href="#">"show qos map dscp-to-cos-policed-map" (page 427)</a>

For more information about QoS, see *Nortel Ethernet Routing Switch 8300 Configuration — QoS and Filter using the NNCLI* (NN46200-501).

## interface FastEthernet/GigabitEthernet

Use this command to enter the interface configuration mode for Fast Ethernet interfaces.

### Syntax

```
interface FastEthernet <ports>
interface GigabitEthernet <ports>
```

where

<ports> specifies the applicable ports associated with FastEthernet interfaces in port list form: {slot/port [-slot/port] [, ...]}.

### Command mode

Global configuration mode

### Next command mode

Interface configuration mode

For more information about configuring port interfaces, see *Nortel Ethernet Routing Switch 8300 Configuration — QoS and Filter using the NNCLI* (NN46200-501).

## qos

Use this command to configure the QoS level on a port. The default is level 1, and level 7 is reserved for network traffic.

### Syntax

```
qos
```

### Parameter

This command includes the following options:

<b>qos</b>	
<b>followed by:</b>	
<b>port &lt;ports&gt;</b>	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.
<b>8021p-override</b>	Enables the Differentiated Service IEEE 802.1P override feature.
<b>qos-level &lt;level&gt;</b>	Sets the QoS level (0 to 7) associated with the traffic service class. Level 7 is reserved and cannot be set.
<b>shaper [rate &lt;value&gt;] [burst-size &lt;value&gt;]</b>	<p>Enables or disables shaper on the port.</p> <p>[rate &lt;value&gt; ] sets the shaping rate in Mbps.</p> <p><b>Note 1:</b> The actual shaping rate might be different from the configured rate due to the rate granularity of the shaper. The range is from 1 to 10000Mbps and the default is 10.</p> <p><b>Note 2:</b> The actual burst size might be different from the configured size due to the granularity of the shaper. The range is from 4 to 16000KB, and the default is 4.</p>
<b>trust-dscp enable</b>	<p>Enables or disables DSCP being trusted in an IPv4/6 packet. When enabled the <b>dscp-to-cos-map</b> will be used to decide on packet's traffic class and 802.1p value. This allows applications to activate Layer-3 based CoS on trusted interface. Default is disabled.</p> <p><b>Note:</b> Trust DSCP can only be enabled on either 8348GTX or 8348GTX-PWR modules when in the GigabitEthenet level of NNCLI</p>
<b>update-dynamic-mac-qos-level</b>	Enables or disable updating of the the qos level. The default is disable.

## Command mode

Interface configuration mode

**qos 8021p-override**

Use this command to enable the Differentiated Service IEEE 802.1P override feature.

**Syntax**

```
qos 8021p-override
```

**Command mode**

Interface configuration mode

**no qos 8021p-override**

Use this command to disable the Differentiated Service IEEE 802.1P override feature.

**Syntax**

```
no qos 8021p-override
```

**Command mode**

Interface configuration mode

**qos shaper**

Use this command to enable the shaper configured on a port.

**Syntax**

```
qos shaper
```

**Command mode**

Interface configuration mode

**qos shaper rate**

Use this command to set the shaper rate

**Syntax**

```
qos shaper rate <1-10000>
```

**Command mode**

Interface configuration mode

**qos shaper burst size**

Use this command to set the shaper burst size

**Syntax**

```
qos shaper burst-size <4-16000>
```

**Command mode**

Interface configuration mode

**no qos shaper**

Use this command to disable the shaper configured on a port.

**Syntax**

```
no qos shaper
```

**Command mode**

Interface configuration mode

**qos trust-dscp enable**

Use this command to enable DSCP being trusted in an IPv4/6 packet.

**Note 1:** Trust DSCP can only be enabled on either 8348GTX or 8348GTX-PWR modules when in the GigabitEthernet level of NNCLI

**Note 2:** Trust DSCP should be enabled on the filter associated with the same port for consistent trust dscp operation.

**Syntax**

```
qos trust-dscp enable
```

**Command mode**

Interface GigabitEthernet configuration mode

**no qos trust-dscp enable**

Use this command to disable DSCP being trusted in an IPv4/6 packet.

**Syntax**

```
no qos trust-dscp enable
```

**Command mode**

Interface GigabitEthernet configuration mode

**qos update-dynamic-mac-qos-level**

Use this command to enable the MAC QoS level and override the port's QoS level.

**Syntax**

```
qos update-dynamic-mac-qos-level
```

**Command mode**

Interface configuration mode

**no qos update-dynamic-mac-qos-level**

Use this command to disable the MAC QoS level and override the port's QoS level.

**Syntax**

```
no qos update-dynamic-mac-qos-level
```

**Command mode**

Interface configuration mode

**qos map**

Use this command to configure QoS mapping tables.

**Syntax**

```
qos map [8021p-to-class-map <802.1p> <traffic-class> ]
[8021p-to-drop-precedence-map <802.1p> <drop-precedence>
] [class-to-8021p-map <traffic-class> <802.1p> ]
[class-to-8021p-policed-map <conformance-level> <dscp>
<traffic-class> <8021p>] [dscp-to-cos-policed-map
<conformance-level> <dscp> <traffic-class> <8021p>
<drop-precedence>]
```

**Parameter**

This command includes the following options:

<b>qos map</b>	
<b>followed by:</b>	
<b>8021p-to-class-map &lt;802.1p&gt; &lt;traffic-class&gt;</b>	Maps the value of the IEEE802.1 p bit (0 to 7) of the incoming packet to one of the traffic classes (0 to 7).
<b>8021p-to-drop-precedence-map &lt;802.1p&gt; &lt;drop-precedence&gt;</b>	<p>Maps the value of the IEEE802.1 p bit (0 to 7) of the incoming packet to one of the following levels:</p> <ul style="list-style-type: none"> <li>• low</li> <li>• medium</li> <li>• high</li> </ul> <p>Packets marked with a higher drop precedence will be dropped first during periods of congestion.</p>
<b>class-to-8021p-map &lt;traffic-class&gt; &lt;802.1p&gt;</b>	Maps the value of the traffic class (0 to 7) to the IEEE802.1 p bit (0 to 7) of the incoming packet.

<b>qos map</b>  <b>followed by:</b>	
<pre>class-to-8021p- policed-map &lt;conformance-level&gt; &lt;traffic-class&gt; &lt;802.1p&gt;</pre>	<p>Maps the value of the traffic class (0 to 7) to the IEEE802.1 p bit (0 to 7) of the incoming packet based on one of the following conformance levels.</p> <ul style="list-style-type: none"> <li>• <b>red</b> means the packet exceeds the PIR (Peak Information Rate).</li> <li>• <b>yellow</b> means the packet does not exceed the PIR, but it does exceed the CIR (Committed Information Rate).</li> <li>• <b>green</b> means the packet does not exceed the CIR.</li> </ul> <p>The conformance level is the outcome of policing and indicates the behavior of a traffic flow.</p>
<pre>dscp-to-cos-policed- map &lt;conformance-level&gt; &lt;dscp&gt; &lt;traffic-class&gt; &lt;8021p&gt; &lt;drop- precedence&gt;</pre>	<p>Maps the value of the DSCP (0 to 63) to the CoS of the incoming packet based on one of the following conformance levels.</p> <ul style="list-style-type: none"> <li>• <b>red</b> means the packet exceeds the PIR (Peak Information Rate).</li> <li>• <b>yellow</b> means the packet does not exceed the PIR, but it does exceed the CIR (Committed Information Rate).</li> <li>• <b>green</b> means the packet does not exceed the CIR.</li> </ul> <p>DSCP has the following options: cs0, af11, af12, af13, cs3, c4.</p> <p>The conformance level is the outcome of policing and indicates the behavior of a traffic flow.</p> <p>After the conformance level, enter the p bit value (0 to 7), the traffic class value (0 to 7), and the drop precedence level (low   medium   high).</p>

**Command mode**

Global configuration mode

**qos policy create**

Use this command to create a Quality of Service policy.

**Syntax**

```
qos policy <policy-id> create [<enable|disable>] [name <value>] [cir <value>] [cbs <value>] [pir <value>] [pbs <value>]
```

where

**<policy-id>** specifies the QoS policy ID number and is a unique ID in the range from 1 to 128.

**Parameter**

This command includes the following options:

<b>qos policy &lt;policy-id&gt; create</b>	
<b>followed by:</b>	
<b>&lt;enable disable&gt;</b>	Enables or disables the policy you just created. The default is disable.
<b>name &lt;value&gt;</b>	Names the policy. You can use up to 33 characters to identify the policy. The range is 0 to 32. If you do not assign a name, the switch automatically assigns one.
<b>cir &lt;value&gt;</b>	Sets the Committed Information Rate (CIR) in Kbps. The CIR is used to measure against a traffic stream. The CIR specifies the rate at which incoming traffic is measured against to be considered at a high level of conformance. The range is from 64 to 10000000, and the default is 1000.
<b>cbs &lt;value&gt;</b>	Sets the Committed Burst Size (CBS) in Kbps. The CBS is used to measure against a traffic stream. The CBS specifies the maximum burst size that is supported for flows to be considered to be at a high level of conformance. The range is from 2 to 512000, and the default is 200.

<pre><b>qos policy &lt;policy-id&gt; create</b></pre> <p><b>followed by:</b></p>	
<b>pir &lt;value&gt;</b>	Sets the Peak Information Rate (PIR) in Kbps. The PIR is used to measure against a traffic stream. The PIR specifies the rate at which incoming traffic can arrive to be considered at a medium level of conformance. The range is from 64 to 10000000, and the default is 1000.
<b>pbs &lt;value&gt;</b>	Sets the Peak Burst Size (PBS) in Kbps. The PBS is used to measure against a traffic stream. The PBS specifies the maximum burst size that is supported for flows to be considered to be at a medium level of conformance. The range is from 2 to 512000, and the default is 200.

**Command mode**

Global configuration mode

**no qos policy**

Use this command to delete a Quality of Service policy.

**Syntax**

```
no qos policy <policy-id>
```

**Command mode**

Interface configuration mode

**qos policy action**

Use this command to configure an existing Quality of Service policy.

**Syntax**

```
qos policy <policy-id> action [drop rmk-cos] [rmk-8021p]  
[rmk-dp]
```

**Parameter**

This command includes the following options:

<b>qos policy &lt;policy-id&gt; action</b>	
<b>followed by:</b>	
<b>drop</b>	Configures the policy to drop non-conforming traffic.
<b>rmk-cos</b>	Configures the policy to re-mark CoS parameters. The CoS parameters are re-marked according to the DSCP to CoS mapping table.
<b>rmk-8021p</b>	Configures the policy to re-mark the 802.1 user priority parameters. The user priority is re-marked according to the TrafficClass to 8021p mapping table.
<b>rmk-dp</b>	Configures the policy to re-mark drop precedence according to the conformance level.

### Command mode

Global configuration mode

## no qos policy action

Use this command to delete a Quality of Service policy.

### Syntax

```
no qos policy <policy-id>action [drop] [rmk-cos] [rmk-8021p]
[rmk-dp]
```

### Parameter

This command includes the following options:

<b>no qos policy &lt;policy-id&gt; action</b>	
<b>followed by:</b>	
<b>drop</b>	Configures the policy to drop non-conforming traffic.
<b>rmk-cos</b>	Configures the policy to re-mark CoS parameters. The CoS parameters are re-marked according to the DSCP to CoS mapping table.
<b>rmk-8021p</b>	Configures the policy to re-mark the 802.1 user priority parameters. The user priority is re-marked according to the TrafficClass to 8021p mapping table.
<b>rmk-dp</b>	Configures the policy to re-mark drop precedence according to the conformance level.

**Command mode**

Interface configuration mode

**qos policy modify**

Use this command to configure an existing Quality of Service policy.

**Syntax**

```
qos policy <policy-id> modify [name <value>] [cir <value>] [cbs <value>] [pir <value>] [pbs <value>]
```

**Parameter**

This command includes the following options:

<b>qos policy &lt;policy-id&gt; modify</b>	
<b>followed by:</b>	
<b>name &lt;value&gt;</b>	Changes the name of the policy. The range is 0 to 32 characters to identify the policy.
<b>cir &lt;value&gt;</b>	Changes the Committed Information Rate (CIR) in Kbps. The range is from 64 to 10000000, and the default is 1000.
<b>cbs &lt;value&gt;</b>	Changes the Committed Burst Size (CBS) in Kbps. The range is from 2 to 512000, and the default is 200.
<b>pir &lt;value&gt;</b>	Changes the Peak Information Rate (PIR) in Kbps. The range is from 64 to 10000000, and the default is 1000.
<b>pbs &lt;value&gt;</b>	Changes the Peak Burst Size (PBS) in Kbps. The range is from 2 to 512000, and the default is 2.

**Command mode**

Global configuration mode

**qos egress-counter-set**

Use this command to configure an egress counter that displays the statistics you want to monitor.

**Syntax**

```
qos egress-counter-set <counter_set_id> [port <port_num>] [vlan <vlan_id>] [queue <vlan_id>] [dp <dp_level>]
```

where

`<counter_set_id>` is a value in the range from 1 to 40.

### Parameter

This command includes the following options:

<code>qos egress-counter-set &lt;counter_set_id&gt;</code>	
<b>followed by:</b>	
<code>port &lt;port_num&gt;</code>	Configures the port(s) that you want the counter set to monitor. If you configure one or more ports, the switch disables MONITOR ALL PORTS, which is enabled by default.
<code>vlan &lt;vlan_id&gt;</code>	Configures the VLAN that you want the counter set to monitor. If you configure a VLAN, the switch disables MONITOR ALL VLANS, which is enabled by default.
<code>queue &lt;vlan_id&gt;</code>	Configures the tx queue ID (0 to 7) that you want the counter set to monitor. If you configure a queue, the switch disables MONITOR ALL Qs, which is enabled by default.
<code>dp &lt;dp_level&gt;</code>	Configures the Drop Precedence level (low, medium or high) that you want the counter set to monitor. If you configure a Drop Precedence level, the switch disables MONITOR ALL DPs, which is enabled by default.

### Command mode

Global configuration mode

## no qos egress-counter-set

Use this command to delete an egress counter set.

### Syntax

```
no qos egress-counter-set <counter_set_id>
```

### Command mode

Interface configuration mode

## show qos egress-stats

Use this command to display information about the QoS egress counter set.

### Syntax

```
show qos egress-stats [ <counter_set_id> ]
```

where

`<counter_set_id>` is a value in the range from 1 to 40.

#### Command mode

Privileged EXEC mode

### show qos egress-counter-set

Use this command to display information about the QoS egress counter set.

#### Syntax

```
show qos egress-counter-set [ <counter_set_id> ]
```

where

`<counter_set_id>` is a value in the range from 1 to 40.

#### Command mode

Privileged EXEC mode

### qos map-qos-level-override

Use this command to map the MAC QoS-level override setting.

#### Syntax

```
qos map-qos-level-override
```

#### Command mode

Global configuration mode

### show qos policy

Use this command to display information about the QoS policies.

#### Syntax

```
show qos policy [ <policy-id> ]
```

where

`<policy-id>` specifies the QoS policy ID number. The range is 1 to 128.

#### Command mode

Privileged EXEC mode

### show qos policy-stats

Use this command to display the QoS policy statistics.

#### Syntax

```
show qos policy-stats [ <policy-id> ]
```

where

<policy-id> specifies the QoS policy ID number. The range is 1 to 128.

**Command mode**

Privileged EXEC mode

## **show qos map 8021p-to-class-map**

Use this command to display how the switch maps 802.1p user priority to traffic class levels.

**Syntax**

```
show qos map 8021-to-class-map
```

**Command mode**

Privileged EXEC mode

## **show qos map 8021p-to-drop-precedence-map**

Use this command to display how the switch maps 802.1p bits to drop precedence.

**Syntax**

```
show qos map 8021-to-drop-precedence-map
```

**Command mode**

Privileged EXEC mode

## **show qos map class-to-8021p-map**

Use this command to display how the switch maps traffic class levels to an 802.1p user priority.

**Syntax**

```
show qos map class-to-8021p-map
```

**Command mode**

Privileged EXEC mode

## **show qos map class-to-8021p-policed-map**

Use this command to display how the switch maps traffic class levels to an 802.1p user priority.

**Syntax**

```
show qos map class-to-8021p-policed-map
```

**Command mode**

Privileged EXEC mode

## show qos map dscp-to-cos-policed-map

Use this command to display how the switch maps DSCP to layer 2 Class of Service (CoS).

### Syntax

```
show qos map dscp-to-cos-policed-map
```

where

<conformance-level> is the outcome of policing and indicates the behavior of a traffic flow.

### Command mode

Privileged EXEC mode



# Web server commands

This chapter describes NNCLI web server commands and their parameters.

Web Server Commands
<a href="#">"web-server" (page 429)</a>
<a href="#">"web-server password" (page 430)</a>
<a href="#">"no web-server" (page 430)</a>
<a href="#">"no web-server" (page 430)</a>

## web-server

Use this command to enable and manage or disable the Web server interface.

### Syntax

```
web-server [def-display-rows <integer>] [help-tftp
<filename>] [http-port <integer>]
```

### Parameters

This command includes the following optional parameters:

web-server	
followed by:	
[def-display-rows <integer>]	Specifies the number of rows displayed per page. The range of values is 10 to 100.
[help-tftp <filename>]	Specifies the file name, location, and path for the Web server HTML Help file. The target can be flash, pcmcia, or a TFTP IP address.  The range of values is a string of 0 to 256 characters.
[http-port <integer>]	Specifies the http port of the Web server. The range of values is 1 to 49151.

**Command mode**

Global configuration mode

**web-server password**

Use this command to specify passwords for access to the Web server interface.

**Syntax**

```
web-server password <ro> <username> <passwd>
```

**Parameters**

This command includes the following parameters:

<b>web-server password</b>	
<b>followed by:</b>	
<ro>	Specifies a read-only access level to the Web server interface.
<username>	Specifies the user's login name. The range of values is a string up to 20 characters. The default is <b>ro</b> .
<passwd>	Specifies the password associated with <username>. The range of values is a string up to 20 characters. The default is <b>ro</b> .

**Command mode**

Global configuration mode

**no web-server**

Use this command to turn off Web access.

**Syntax**

```
no web-server
```

**Command mode**

Privileged EXEC mode

**show web-server**

Use this command to display whether or not Web access is enabled, as well as password and access information.

**Syntax**

```
show web-server
```

## Command mode

Privileged EXEC mode



# POE commands

This chapter describes NNCLI POE commands and their parameters.

Quality of Service Commands
"interface FastEthernet/GigabitEthernet" (page 414)
"interface FastEthernet" (page 434)
"poe detect-control" (page 434)
"poe detection-control" (page 435)
"poe fw-upgrade slot" (page 435)
"poe limit" (page 436)
"poe limit" (page 436)
"poe notification slot" (page 436)
"no poe notification" (page 436)
"poe priority" (page 437)
"poe port admin" (page 437)
"poe priority" (page 437)
"poe priority" (page 437)
"poe priority" (page 437)
"poe shutdown" (page 438)
"no poe shutdown" (page 438)
"poe shutdown" (page 438)
"no poe shutdown" (page 438)
"no poe shutdown" (page 439)
"poe type" (page 439)
"poe type port" (page 439)
"poe usage-threshold" (page 440)
"show poe main-status" (page 440)
"show poe port-status" (page 440)
"show poe sys-status" (page 440)

<b>Quality of Service Commands</b>
<a href="#">"show poe port-stats" (page 441)</a>
<a href="#">"show poe power-measurement" (page 441)</a>

## interface FastEthernet/GigabitEthernet

Use this command to enter the interface configuration mode for the Fast Ethernet/Gigabit Ethernet interfaces

### Syntax

```
interface FastEthernet/GigabitEthernet <ports>
```

### Command mode

Global configuration mode

## interface FastEthernet

Use this command to enter into the interface configuration mode for Fast Ethernet interfaces.

### Syntax

```
interface FastEthernet <ports>
```

where

<ports> specifies the applicable ports associated with FastEthernet interfaces in port list form: {slot/port [-slot/port] [, ...]}.

### Command mode

Global configuration mode

## poe detect-control

Use this command to specify detect control for Power over Ethernet ports.

### Syntax

```
poe detect-control [port <ports>] <auto|test>
```

### Parameter

This command includes the following options:

<b>poe detect control</b>	
<b>followed by:</b>	
[ports <ports> ]	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.
auto   test	Specifies automatic or test detection.

**Command mode**

Interface configuration mode

**poe detection-control**

Use this command to configure power detection control for the Power over Ethernet ports.

**Syntax**`poe detection-control`**Parameter**

This command includes the following options:

<b>poe detection-control</b>	
<b>followed by:</b>	
[ports <ports> ]	Specifies the applicable ports in port list form: {slot/port [-slot/port] [, ...]}.
auto   test	Specifies automatic or test detection.

**Command mode**

Interface GigabitEthernet mode

**poe fw-upgrade slot**

Use this command to perform a firmware upgrade for a PoE card in a slot.

**Syntax**`poe fw-upgrade slot <slots>`**Command mode**

Global configuration mode

## poe limit

Use this command to configure the power limit for the Power over Ethernet ports.

### Syntax

```
poe limit [port <ports>] <3..16>
```

### Parameters

This command includes the following parameters:

<b>poe limit [port &lt;ports&gt;] &lt;3..16&gt; followed by:</b>	
[ports <ports> ]	Specifies the applicable ports in port list form: <code>{slot/port [-slot/port] [, ...]}</code> .
<3-16>	The value to set for the port PoE power limit.

### Command mode

Interface GigabitEthernet mode

## poe limit

Use this command to set the power limit for Power over Ethernet ports.

### Syntax

```
poe limit <3-16> [port <ports> ]
```

### Command mode

Interface configuration mode

## poe notification slot

Use this command to set the notification control for Power over Ethernet.

### Syntax

```
poe notification [slot <slots> ]
```

### Command mode

Global configuration mode

## no poe notification

Use this command to turn off notification control.

### Syntax

```
no poe notification [slot <slots> ]
```

**Command mode**

Global configuration mode

**poe port admin**

Use this command to configure the admin for the Power over Ethernet ports.

**Syntax**`poe port <ports> admin <enable|disable>`**Command mode**

Interface GigabitEthernet mode

**poe priority**

Use this command to configure the power priority for the Power over Ethernet ports.

**Syntax**`poe priority port <ports> <low|high|critical>`

where

`port<ports>` Specifies the applicable ports in port list form:  
`{slot/port [-slot/port] [, ...]}`  
`<low|high|critical>` specify the power priorities.

**Command mode**

Interface GigabitEthernet mode

**poe priority**

Use this command to set port priority for Power over Ethernet.

**Syntax**`poe priority [port <ports>] <low|high|critical>`**Command mode**

Interface configuration mode

**poe priority**

Use this command to enable Power over Ethernet on a particular slot or slots.

**Syntax**`poe priority [slot <slots>] <low|high|critical>`**Command mode**

Global configuration mode

**poe shutdown**

Use this command to shut down Power over Ethernet on specified ports.

**Syntax**

```
poe shutdown [port <ports>]
```

**Command mode**

Interface configuration mode

**no poe shutdown**

Use this command to specify no shutdown of Power over Ethernet.

**Syntax**

```
no poe shutdown [port <ports>]
```

**Command mode**

Interface configuration mode

**poe shutdown**

Use this command to disable Power over Ethernet for specified slots.

**Syntax**

```
poe shutdown slot <slots>
```

**Command mode**

Global configuration mode

**no poe shutdown**

Use this command to specify disabling the Power over Ethernet function for specified ports.

**Syntax**

```
no poe shutdown port [port <ports>]
```

**Parameters**

This command includes the following parameters:

<b>no poe shutdown port</b> <b>followed by:</b>
<portlist>

<portlist>	Selects the portlist {port[-port][,...]}.
------------	---

**Command mode**

Interface GigabitEthernet mode

## **no poe shutdown**

Use this command to specify disabling the Power over Ethernet function for specified slots.

### **Syntax**

```
no poe shutdown [slot <slots> ]
```

### **Command mode**

Global configuration mode

## **poe type**

Use this command to set the port type for Power over Ethernet.

### **Syntax**

```
poe type [port <ports>] <other|telephone|webcam|wireless>
```

### **Parameters**

This command includes the following parameters:

<b>poe type</b> <b>followed by:</b>	
<b>port &lt;ports&gt;</b>	Specifies ports as the poe port type.
<b>other</b>	Specifies another device as the poe port type.
<b>telephone</b>	Specifies a telephone poe port type.
<b>webcam</b>	Specifies webcam as the poe port type.
<b>wireless</b>	Specifies wireless as the poe port type.

## **poe type port**

Use this command to configure the type of Power over Ethernet ports.

### **Syntax**

```
poe type port <ports> <other|telephone|webcam|wireless>
```

### **Parameters**

This command includes the following parameters:

<b>config poe type</b> <b>followed by:</b>	
<b>port &lt;ports&gt;</b>	Specifies ports as the poe port type.
<b>other</b>	Specifies another device as the poe port type.

<b>config poe type</b> <b>followed by:</b>	
<b>telephone</b>	Specifies a telephone poe port type.
<b>webcam</b>	Specifies webcam as the poe port type.
<b>wireless</b>	Specifies wireless as the poe port type.

**Command mode**

Interface GigabitEthernet mode

**Command mode**

Interface configuration mode

**poe usage-threshold**

Use this command to set the usage threshold for Power over Ethernet for a particular slot or slots.

**Syntax**

```
poe usage-threshold [slot <slots>]
```

**Command mode**

Global configuration mode

**show poe main-status**

Use this command to show the poe main status by slot.

**Syntax**

```
show poe main-status [slot <slot id>]
```

**Command mode**

Privileged Exec mode

**show poe port-status**

Use this command to display the current status of the Power over Ethernet port.

**Syntax**

```
show poe port-status [<ports>]
```

**Command mode**

Privileged Exec mode

**show poe sys-status**

Use this command to display the system status for Power over Ethernet.

**Syntax**

```
show poe sys-status
```

**Command mode**

Privileged EXEC mode

**show poe port-stats**

Use this command to display the port statistics for the Power over Ethernet ports.

**Syntax**

```
show poe port-stats [port <ports>]
```

**Command mode**

Privileged EXEC mode

**show poe power-measurement**

Use this command to display power measurement for Power over Ethernet.

**Syntax**

```
show poe power-measurement [port <ports>]
```

**Command mode**

Privileged Exec mode



# VCT commands

This chapter describes NNCLI VCT commands and their parameters.

## VCT Commands

- ["show vct" \(page 443\)](#)
- ["vct test" \(page 443\)](#)

### show vct

This command displays a virtual cable test or displays Virtual Cable Tester (VCT) information for a range of ports.

#### Syntax

```
show vct <portlist>
```

#### Parameters

This command includes the following parameters:

<b>show vct</b>	
<b>followed by:</b>	
<portlist>	Displays a virtual cable test on the specified ports.  portlist specify the ports in the portlist form { slot/port [- slot/port ] [, ...] }.

#### Command mode

User EXEC mode

### vct test

This command specifies a virtual cable test.

#### Syntax

```
vct test <portlist>
```

Nortel Ethernet Routing Switch 8300  
Command Reference — NNCLI  
NN46200-306 03.01 Standard  
4.0 27 August 2007

**Parameters**

This command includes the following parameters:

<b>vct test</b>	
<b>followed by:</b>	
<portlist>	Starts a virtual cable test on the specified ports.  <b>portlist</b> specify the ports in the portlist form { slot/port [- slot/port ] [, ...] }.

**Command mode**

Global configuration mode

---

# Index

---

## A

access policy precedence 170  
 accessing  
   loopback interface mode 218  
   NNCLI 43  
 activity check interval 397  
 ARP table, clearing specified entries 52  
 auto-negotiate command (Run-Time  
   CLI) 358  
 automatic trace, configuring using the  
   NNCLI 68

## B

backup CPU, activating 66  
 Boot Monitor  
   configuration, displaying 109, 109, 109

## C

choice commands  
   Run-Time CLI 76, 77, 78  
 CLI  
   returning to, from NNCLI 44  
 commands  
   EAPol 153  
 commands, NNCLI  
   modes 42  
 config ip route-policy commands 251, 252  
 configuration  
   displaying  
     Boot Monitor 109, 109, 109  
 configuration file  
   debugging 82  
 conventions, text 44

counters, resetting 66

CPU  
   master 109

## D

daylight saving time, setting 81, 83  
 daylight-saving-time flag 81, 83  
 debug-config flag 82

## E

EAPoL  
   configuring ports 153

## F

factorydefaults flag 82  
 flag settings, displaying 109, 109  
 FTP, enabling 82, 84  
 ftpd flag 82

## I

IGMP NNCLI commands  
   show ip route 270  
 IP route-policy commands  
   configure 251, 252

## L

logging flag 82  
 loopback interface mode, accessing 218

## M

master CPU  
   displaying location 109

monitor commands 58

## N

NNCLI

accessing 43

returning to CLI 44

switching from CLI 43

NNCLI commands

EAPol 153

modes 42

## P

PIM-SM

activity check interval 397

precedence, access policy 170

priority, access policy 170

## R

reboot flag 82

RIP commands

show 268

## S

show ip rip command 268

show ip rip interface command 268

static routes, IP, displaying 270

switching

to CLI 44

to NNCLI 43

## T

table, flushing 52

Telnet sessions

ending 52

telnetd flag 82, 84

text conventions 44

tftpd flag 82, 84

timer, watchdog 83

## V

viewing the route table in the NNCLI 270

## W

watchdog timer 83

wdt flag 83



Nortel Ethernet Routing Switch 8300  
**Command Reference — NNCLI**

Copyright © 2007, Nortel Networks  
All Rights Reserved.

Publication: NN46200-306  
Document status: Standard  
Document version: 03.01  
Document date: 27 August 2007

To provide feedback or report a problem in the document, go to [www.nortel.com/documentfeedback](http://www.nortel.com/documentfeedback)

Sourced in Canada and the United States of America.

The information in this document is subject to change without notice. Nortel Networks reserves the right to make changes in design or components as progress in engineering or manufacturing may warrant.

\*Nortel, Nortel Networks, the Nortel logo and the Globemark are trademarks of Nortel Networks.



---