



# XT Commands Interface Specification for Avaya Scopia® XT Series

XT Series Control API  
For XT5000, XT4000, XT7000, XTE240  
v8.3.5  
For XT1200 v2.5  
For Solution 8.3.5  
May 2016

## Table of Contents

<b>1</b>	<b>GENERAL</b>	<b>1</b>
1.1	Scopia® XT configuration	1
1.2	Message Format	1
1.2.1	Serial port message format	2
1.2.2	IP message format	2
<b>2</b>	<b>INITIALIZATION MESSAGES</b>	<b>3</b>
2.1	Init Protocol (IP)	3
2.2	End Protocol (IE)	4
2.3	Init Protocol Error (IR)	4
<b>3</b>	<b>TERMINAL CONFIGURATION</b>	<b>6</b>
3.1	Terminal Generic Command (TA)	6
3.2	Terminal Date & Time (TT)	9
3.3	Terminal Date & Time Extended (TB)	10
3.4	Terminal Call/Answer Mode (TC)	11
3.5	Terminal User Setting (TU)	12
3.6	Terminal Video Camera Parameters (TV)	13
3.7	Terminal Monitor Settings (TG)	20
3.8	Terminal Monitor Settings Extended (TS)	20
3.9	Terminal Audio Delay (TY)	22
3.10	Terminal Mode Settings (TH)	23
3.11	Terminal Mode Settings Extended (TF)	25
3.12	Terminal Capabilities Settings (TI)	27
3.13	Terminal Location Parameters (TL)	31
3.14	Terminal Location Parameters Extended (TQ)	32
3.15	Terminal MCU configuration (TM)	34
3.16	Terminal Reload Default parameters (TR)	36
3.17	Terminal Encryption Configuration (TO)	37
3.18	Terminal License Management (TW)	38
3.19	Terminal configuration management (TK)	40
3.20	Terminal Audio Configuration (TN)	43
3.21	Terminal presentation configuration (TD)	47
3.22	Telepresence configuration (TP)	47
3.23	Recording Settings (TJ)	48
3.24	Terminal Error Indication (TE)	50
<b>4</b>	<b>NETWORK CONFIGURATION</b>	<b>51</b>
4.1	Network IP Configuration (NL)	51
4.2	Network IP Configuration Extended (ND)	51
4.3	Protocol SIP Configuration (NM)	53
4.4	Network NAT & Dynamic Ports Setting (NT)	57
4.5	Network LAN Settings (NB)	58
4.6	Network Protocols Setting (NA)	59
4.7	Network LAN H.323 Setting (NH)	59
4.8	Network Gatekeeper Authentication Setting (NJ)	61
4.9	Network SNMP Management (NS)	62
4.10	Network QoS Management (NQ)	64
4.11	Network ISDN Configuration (NO)	65
4.12	Predefined Party Configuration (NP)	66
4.13	Network Web Management (NK)	67
4.14	Network Error Indication (NE)	68
<b>5</b>	<b>REMOTE ACCESS CONFIGURATION</b>	<b>70</b>
5.1	Web Video Configuration (RW)	70
5.2	Download Configuration (RD)	71

5.3	Netlog Configuration (RN)	71
5.4	Audio Analyzer Configuration (RA)	72
5.5	Scopia® Management Configuration (RS)	73
5.6	Certificate Configuration (RC)	73
5.7	Screen link /Mobile link Configuration (RB)	74
5.8	SSH Configuration (RH)	75
5.9	Telnet Configuration (RT)	75
5.10	Remote Access Error Indication (RE)	76
<b>6</b>	<b>PHONE DIRECTORY CONFIGURATION</b>	<b>77</b>
6.1	File Descriptor (DF)	77
6.2	Read Record with index (DR)	78
6.3	Read Record with index (DL)	80
6.4	Delete Record with index (DD)	83
6.5	Insert New Record (DI)	83
6.6	Recent Call General Descriptor (DQ)	85
6.7	Read Recent calls Info with index (DT)	86
6.8	Delete Recent calls item (DV)	87
6.9	Generic LDAP information (DG)	87
6.10	Insert new LDAP server (DS)	88
6.11	Read LDAP server configuration (DP)	90
6.12	Modify LDAP server configuration (DM)	91
6.13	Delete LDAP server (DB)	93
6.14	Connect a LDAP server (DC)	93
6.15	Phone Directory Configuration Error Message (DE)	94
<b>7</b>	<b>CALL CONTROL MESSAGES</b>	<b>95</b>
7.1	Make a call (CD)	95
7.2	Make call at a specified rate (CM)	95
7.3	Send a DTMF digit (CF)	97
7.4	Answer an incoming call (CA)	97
7.5	Answer an incoming call extension (CG)	97
7.6	Disconnect a call (CH)	98
7.7	Connection Status (CB)	98
7.8	Connection H323 Status (CL)	99
7.9	Dual Video Management (CV)	101
7.10	Dual Video Status (CC)	102
7.11	Call Error Indication (CE)	102
<b>8</b>	<b>MULTIPOINT CONTROL MESSAGES</b>	<b>103</b>
8.1	Connect a terminal (MD)	103
8.2	Disconnect a terminal (MH)	103
8.3	Close a conference (MO)	104
8.4	Terminal status (MT)	104
8.5	Terminal audio status (MA)	105
8.6	Terminal information (MG)	106
8.7	Terminal video status (MV)	107
8.8	Conference finish time configuration (MF)	107
8.9	Conference video layout configuration (ML)	108
8.10	Conference indication messages (MS)	109
8.11	Multipoint Error Indication (ME)	111
<b>9</b>	<b>CONTROL &amp; INDICATION MESSAGES</b>	<b>113</b>
9.1	Call Status (SC)	113
9.2	Video Camera Command/Status (SF)	115
9.3	Video Camera Command (SY)	118
9.4	Board Reset (SG)	119
9.5	Conference Control (SH)	120
9.6	Mute Command/Status (SM)	122
9.7	Remote Video Indication (SO)	123
9.8	Privacy Command/Status (SP)	123
9.9	SelfView Command/Status (SS)	123

9.10 Picture In Picture Command/Status (ST) .....	124
9.11 Volume Command/Status (SV) .....	124
9.12 Infrared remote control emulation (SW).....	125
9.13 Send “Start” command (SJ) .....	126
9.14 DualVideo Status (SK) .....	126
9.15 Configuration System Status (SA).....	127
9.16 Screen Saver Activation (SL) .....	129
9.17 Layout Command/Status (SB) .....	129
9.18 Conference Gallery Layout configuration (SX).....	130
9.19 Multi image Command/Status (SD).....	131
9.20 JPEG image capture Command (SI) .....	132
9.21 Recording and Playing Command (SN).....	133
9.22 Local Presentation Command (SQ) .....	136
9.23 Do Not Disturb (DND) Command/Status (SR) .....	137
9.24 Control & Indication Error Message (SE) .....	138

## 10     **DIAGNOSTIC MESSAGES** ..... 139

10.1 Connection Status (PC).....	139
10.2 System’s serial numbers (PS) .....	144
10.3 Call Interface Status (PG).....	144
10.4 Download status (PD).....	145
10.5 Debug log file management (PL).....	146
10.6 Audio test (PA) .....	146
10.7 Generic System Info (PI) .....	147
10.8 System Model Name (PIS) .....	147
10.9 System component Status (PB).....	148
10.10 Diagnostic Error Message (PE) .....	150

© 2000-2014 Avaya Inc. All intellectual property rights in this publication are owned by Avaya Inc. and are protected by United States copyright laws, other applicable copyright laws and international treaty provisions. Avaya Inc. retains all rights not expressly granted.

All product and company names herein may be trademarks of their registered owners.

This publication is AVAYA Confidential & Proprietary. Use pursuant to your signed agreement or Avaya policy. No part of this publication may be reproduced in any form whatsoever or used to make any derivative work without prior written approval by Avaya Inc.

No representation of warranties for fitness for any purpose other than what is specifically mentioned in this guide is made either by Avaya Inc. or its agents.

Avaya Inc. reserves the right to revise this publication and make changes without obligation to notify any person of such revisions or changes. Avaya Inc may

make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

If there is any software on removable media described in this publication, it is furnished under a license agreement included with the product as a separate document. If you are unable to locate a copy, please contact Avaya Inc and a copy will be provided to you.

Unless otherwise indicated, Avaya registered trademarks are registered in the United States and other territories. All registered trademarks recognized.

For further information contact Avaya or your local distributor or reseller.

*XT Commands Interface Specification for Avaya  
Scopia® XT Series Version 8.3.5, May 9, 2016*

<http://support.avaya.com>

# 1 General

This document describes the protocol and the messages used for the configuration and the control of Scopia® XT series endpoint (we will call it **RTE**, **R**emote **T**ErMinal), using an external Personal Computer (we will call it **PC**).

This version of the protocol supports the following Avaya Scopia® XT endpoints:

- XT 1000 series v1.0.x, v2.0.x, v2.5.404 and above,
- XT5000/XT4200 Series v3.0.x, v3.1.0.28 and above,
- XTE240 Series v3.1.0.28 and above
- XT4300 Series v8.3.2.x and above
- XT7000 Series v8.3.2.x and above

---

## 1.1 Scopia® XT configuration

All Scopia® XT systems are configured by default to enable AT commands interface.

AT commands can be used by a serial port connected to the USB port of XT or remotely by an IP network.



If you are using a serial port, you must use the same baud rate configured in XT system, which by default it is **115200**. Moreover the system can be configured to avoid the need to send the AT initialization command.

The cable used should be a cross cable.

If you are using IP network, you can use SSH over IP enabling it in the XT configuration page. The user is **atadmin** and the default password is **1234**.

To increase security you can also limit IP clients configuring only a subset of IP addresses from which connection can be made.

---

## 1.2 Message Format

Messages exchanged between **RTE** and **PC** are all in ASCII format and must be terminated by the carriage return character (hexadecimal value 0x0d).

They are formatted in this way:

**AT[<mode><type><sub-type><data><cr>**

**<mode>** = is an ASCII character that identifies if the message is a read or a save or a response/indication message. Actually it can be:

‘?’ = status request (sent by PC)

‘&’ = command/storage request (sent by PC)

‘<’ = reply to a status request or indication (sent by RTE)

**<type>** = described in the single message. It is an ASCII character that identifies a family message like T for terminal configuration, C for Call control messages and so on.  
**<sub-type>** = described in the single message. It is an ASCII character that identifies each single command.  
**<data>** = described in the single message. It is a sequence of ASCII characters that identifies data of messages.  
**<cr>** = is the AT command terminator. It is the carriage return character (hexadecimal value 0x0d)

**WARNIG:** starting from version 8.3.2.x a space character can optionally be inserted between <sub-type> and <data>.

After every write command received, RTE answers with an **OK<cr>** message

After every read command received, RTE answers with the response message, formatted as explained above and then sends an **OK<cr>** message.

The first message the PC sends to the terminal must be always the AT[&IPV initialization message. Without this message no response comes from the system and no indication is sent.

---

## 1.2.1 Serial port message format

If you are using a serial port you can type messages directly as explained in in the above section.

For example if you want to send the AT[&IPV initialization command, you have to open a serial port connection and then send following bytes:

### Command

- 0x41 0x54 0x5b 0x26 0x49 0x50 0x56 0x0d

---

## 1.2.2 IP message format

If you are using a TCP/IP connection all ASCII messages exchanged between **RTE** and **PC** must be preceded by a header as explained below.

TCP/IP messages are based on a proprietary protocol (not Telnet protocol). The client must open a socket and connect to RTE at the port **55003**: the maximum number of allowed concurrent clients is nine (9) (before version 8.3.2.x they could be five).

The messages are constituted by any AT commands, preceded by a six bytes header, structured as follows:

- The first two bytes are always equal to 0xAA 0xAA, and indicate the beginning of the packet.
- The last four bytes contain the length of the AT command, expressed as a long integer in network format.

The header is also always present in the messages sent back by RTE by TCP/IP connection.

For example if you want to send the AT[&IPV initialization command, you have to open a TCP client socket on the PC, connect it to the remote 55003 port on the RTE, and then send the following bytes:

### Header

- 0xaa 0xaa 0x00 0x00 0x00 0x08

### Command

- 0x41 0x54 0x5b 0x26 0x49 0x50 0x56 0x0d

## 2 Initialization Messages

PC must send the initialization message before any other message, in order to enable the RTE to answer request, send indication and execute commands.

An end session message must be sent when PC wants to stop communication with RTE.

---

### 2.1 Init Protocol (IP)

This message is sent by PC in order to initialize the proprietary protocol. It is sent by RTE in reply and as confirmation.

Direction: PC -> RTE

Mode: '&'

Type: 'I'

Sub-Type: 'P'

Data: Terminal Type:

'V' = client receives all notifies

'F' = client receives all notifies except the SA notify (Starting from v3.x)

Direction: RTE -> PC

Mode: '<'

Type: 'I'

Sub-Type: 'P'

Data: Custom Board Detected

'40' = No additional boards

MCU Enabled

'0' = No

'1' = Yes

Board Revision ("A"/"B" etc)

Video Camera:

'0' = Unknown

'9' = Scopia® XT Premium camera or Standard II camera

'A' = Scopia® XT1000 Standard camera

'B' = Scopia® XT5000 Advanced camera

'C' = Scopia® XT5000 Flex camera

SystemType and SW version (Es: XT1000-01.00.0019)

#### Data Description:

##### **MCU Enabled:**

This field indicates if the license for MCU (Multiconference Unit) is enabled.

##### **Video Camera:**

Local Video Camera type used for HD1.

Example:

PC ----- AT[&IPV<cr> -----> RTE (Initialize the Interface)



PC     ←----- AT[<IP400A9XT1000-01.00.0019<cr> --- RTE  
(Interface init: No add boards, MCU, Rev=A, Premium camera, System XT1000 version 1\_0\_19)

PC     ←----- OK<cr> ----- RTE

---

## 2.2 End Protocol (IE)

This message is sent by PC in order to end the session of the proprietary protocol. It is sent by RTE in reply and as confirmation.

Direction:     PC -> RTE

Mode            '&'  
Type:            'I'  
Sub-Type        'E'  
Data:            None

Direction:     RTE -> PC

Mode            '<'  
Type:            'I'  
Sub-Type        'E'  
Data:            None

Example:

PC     ----- AT[&IE<cr> -----→ RTE     (End Session)  
PC     ←----- AT[<IE<cr> ----- RTE     (Session Ended)  
PC     ←----- OK<cr> ----- RTE

---

## 2.3 Init Protocol Error (IR)

This message is sent by RTE to notify an error on the received message:

Direction:     RTE -> PC

Mode            '<'  
Type:            'I'  
Sub-Type        'R'  
Data:            Message Type  
                 Sub-type  
                 Error:  
                 '1' = Bad parameter  
                 '2' = Unknown message  
                 '3' = wrong message length  
                 '4' = Bad mode  
                 '5' = Unable to execute command  
                 Sub-code  
                 If Unable to execute command  
                 '0' = system timeout  
                 '1' = system busy

If Bad parameter  
Index number of wrong parameter

# 3 Terminal Configuration

Terminal configuration messages can be used to change and/or read the configuration stored in the terminal.

The <mode> & command can be used to modify the configuration, while the <mode> ? can be used to read the related values.

---

## 3.1 Terminal Generic Command (TA)

This message is sent by PC to request storing/reading different parameters.

This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'T'

Sub-Type: 'A'

Data: Types of parameter:

'D' = Confirm disconnection

'S' = Screen saver

'V' = DVI resolution

'Q' = Video Quality (**Starting from v8.3.2.x no longer used**)

'B' = Video Quality (**Starting from v8.3.2.x**)

'O' = Video Position

'N' = Call-answer mode parameters

'A' = Set AutoAnswer and mute audio and video

'F' = Full screen (**only in write mode**)

'L' = Strip layout (**Starting from v8.3.x**)

'C' = Customization (**Starting from v8.3.2.x**)

'G' = Administrator PIN (**only in write mode by SSH interface**) (**Starting from v8.3.2.5xx**)

'H' = User PIN (**only in write mode by SSH interface**) (**Starting from v8.3.2.5xx**)

### Parameter type 'D'

Confirm disconnection:

'0' = no

'1' = yes

### Parameter type 'S'

Automatic screen saver:

'0' = no

'1' = yes

Timeout (2 bytes) in minutes:

Screen saver status:

'0' = no active

'1' = active

### Parameter type 'V'

DVI Resolution:

'0' = Automatic

'7' = 720p60

'8' = 1080p60

'1' = 720p50 (**Starting from v8.3.2.x**)  
'2' = 1080p50 (**Starting from v8.3.2.x**)  
'3' = 1080p30 (**Starting from v8.3.2.x**)  
'4' = 1080p25 (**Starting from v8.3.2.x**)

**Parameter type 'Q' (Starting from v8.3.2.x no longer used)**

Error resilience:

'0' = no  
'1' = yes

Bandwidth adapting reduction:

'0' = no  
'1' = yes

Error strategies:

'0' = no  
'1' = yes

Fluency (3 bytes):

"000".."256"

Video Quality/Speed (2 bytes):

"00".."64"

Video Sharpness:

'0' = no  
'1' = yes

**Parameter type 'B' (Starting from v8.3.2.x)**

NetSense:

'0' = no  
'1' = yes

Flow Control:

'0' = no  
'1' = yes

TMMBR RFC5104:

'0' = no  
'1' = yes

Sharpness :

'0' = no  
'1' = yes

Presentation sharpness:

'0' = no  
'1' = yes

Live video on presentation

'0' = no  
'1' = yes

Traffic Shaping (**Starting from v8.3.2.203**)

'0' = Disabled  
'1' = Low  
'2' = Medium  
'3' = High

Dummy (13 bytes, must be 0) (**for future expansion** )

**Parameter type 'O'**

Horizontal Position (4 bytes):

'0000'..'1280'

Vertical Position (4 bytes):

'0000'..'720'

Horizontal Dimension (4 bytes):

'0000'..'1280'

Vertical Dimension (4 bytes):

'0000'..'720'

**Parameter type 'N'**

Do not disturb:  
    '0' = no  
    '1' = yes  
VideoPrivacy:  
    '0' = no  
    '1' = yes  
Dummy (5 bytes, must be 0) (**for future expansion**):

**Parameter type 'A'**

AutoAnswer and mute audio-video:  
    '0' = No  
    '1' = Yes  
Dummy (5 bytes, must be 0) (**for future expansion**):

**Parameter type 'F'**

Full screen:  
    '0' = no  
    '1' = yes

**Parameter type 'L' (Starting from v8.3.x)**

Strip layout configuration:  
    '0' = disabled  
    '1' = enabled  
Strip layout allowed (**only for read operation**):  
    '0' = no  
    '1' = yes

**Customization type 'C' (Starting from v8.3.2.x)**

Home Screen Background:  
    '1' = Video  
    '2' = Image  
Privacy Option:  
    '0' = Automatic  
    '1' = Image  
    '2' = Hide Video  
IP address display:  
    '0' = No  
    '1' = Yes  
Dummy (10 bytes, must be 0) (**for future expansion**):

**Administrator PIN type 'G' (only in write mode by SSH interface) (Starting from v8.3.2.5xx)**

Enable PIN:  
    '0' = Disable  
    '1' = Enable  
Old PIN: (4 bytes)  
    "0000"...."9999"  
New PIN: (4 bytes)  
    "0000"...."9999"

**User PIN type 'H' (only in write mode by SSH interface) (Starting from v8.3.2.5xx)**

Enable PIN:  
    '0' = Disable  
    '1' = Enable  
Old PIN: (4 bytes)  
    "0000"...."9999"  
New PIN: (4 bytes)  
    "0000"...."9999"

Direction: RTE -> PC

Mode '<'  
Type: 'T'  
Sub-Type 'A'  
Data: See above

#### Data Description:

##### **Confirm disconnection:**

If this parameter is selected, when the user press the disconnect button a dialog box appears to ask him for a confirmation.

##### **Screen saver:**

It is possible to set the screen saver in automatic mode and the value of the relative timeout.

##### **Show local info:**

It is possible to show in all pages the own system name and IP address.

##### **Video Quality:**

This command can change the quality of the remote video received.

##### **Video Position:**

This command can change the video live position and dimension in the screen. Is implicit that the max dimension of the video is 640x480, so if the horizontal or vertical positions are different from 0, the horizontal o vertical dimension has to been changed proportionally to enter in the max dimension.

##### **Call-answer mode parameters:**

With the parameter "Do not disturb" it's possible to block all incoming calls. If this parameter is selected, all incoming calls are automatically discarded.

##### **Full screen:**

This command hides the graphic interface if full screen is yes. If full screen is no then graphic interface is visible.

##### **Strip layout**

This command is used to set flag to enable strip layout. This is a video mode for which MCU Elite send live video and dual video in a unique video stream composed in a unique video layout instead of two different video streams.

##### **Administrator and User PIN**

These commands are used to enable/disable PIN usage to access administrator or user configuration. They can also be used to change PIN. For any change old PIN must be furnished (if you don't change it, set new PIN equal to the old one).

---

## 3.2 Terminal Date & Time (TT)

This message is sent by PC to request storing/reading of date & time parameters  
This message is sent by RTE as reply to a reading request.

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'T'  
Sub-Type 'T'  
Data: Day ("01".."31")  
Month ("01".."12")  
Year (4 digit)

Hour ("00"..23")  
Minute ("00"..59")

Direction: RTE -> PC

Mode '<'  
Type: 'T'  
Sub-Type 'T'  
Data: See above

---

### 3.3 Terminal Date & Time Extended (TB)

This message is sent by PC to request storing/reading date & time parameters  
This message is sent by RTE as reply to a reading request.

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'T'  
Sub-Type 'B'  
Data: Types of parameter:  
      'I' = Internet Time  
      'S' =First Internet date and time server address  
      'R' =Second Internet date and time server address  
      'Z' = Time Zone

#### Parameter type 'I'

Enable:

0 = No  
1 = Yes

Use Default internet date and time servers:

0 = No  
1 = Yes

Refresh time (in minutes) (fixed 4 bytes): min value 10 max value 1000

#### Parameter type 'S'

First Internet date and time server address (max 30 ASCII chars)

#### Parameter type 'R'

Second Internet date and time server address (max 30 ASCII chars)

#### Parameter type 'Z'

Time Zone (2 bytes):

1 = GMT Greenwich  
2 = GMT + 1 (Amsterdam, Rome)  
3 = GMT + 2 (Athens, Bucarest, Tel Aviv)  
4 = GMT + 3 (Baghdad,Moscow)  
5 = GMT + 3.30 (Teheran)  
6 = GMT + 4 (Abu Dabhi, Muscat)  
7 = GMT + 4.30 (Kabul)  
8 = GMT + 5 (Islamabad,Karachi)  
9 = GMT + 5.30 (Mumbai, New Delhi)  
10 = GMT + 5.45 (Kathmandu)  
11 = GMT + 6.00 (Almaty, Novosibirsk)  
12 = GMT + 6.30 (Yangon-Rangoon)  
13 = GMT + 7 (Bangkok, Jakarta)

14 = GMT + 8 (Beijing,Hong Kong)  
 15 = GMT + 9 (Osaka, Tokyo, Seoul)  
 16 = GMT + 10 (Melbourne,Sydney)  
 17 = GMT + 11 (Magadan,Solomon Is.)  
 18 = GMT + 12.00h (Fiji,Auckland)  
 19 = GMT + 12.45h (Chatham Island)  
 20 = GMT + 13.00h (Nuku'alofa)  
 21 = GMT + 14.00h (Kiritimati)  
 22 = GMT - 1.00h (Azores,Cape Verde Is.)  
 23 = GMT - 2.00h (Mid. Atlantic)  
 24 = GMT - 3.00h (Buenos Aires,Brasilia)  
 25 = GMT - 3.30h (Newfoundland)  
 26 = GMT - 4.00h (Santiago)  
 27 = GMT - 4.30h (Caracas)  
 28 = GMT - 5.00h (USA,Canada,Bogotá,Lima,Quito)  
 29 = GMT - 6.00h (Mexico City)  
 30 = GMT - 7.00h (Arizona)  
 31 = GMT - 8.00h (Tijuana)  
 32 = GMT - 9.00h (Alaska)  
 33 = GMT - 10.00h (Hawaii)  
 34 = GMT - 11.00h (Samoa,Midway Is.)  
 35 = GMT - 12.00h (Eniwetok,Kwajalein)

Enable daylight time:

0 = No

1 = Yes

Daylight time day start (2 bytes) : "01"... "31"

Daylight time month start (2 bytes) : "01"... "12"

Daylight time day stop (2 bytes) : "01"... "31"

Daylight time month stop (2 bytes) : "01"... "12"

Direction: RTE -> PC  
 Mode: '<  
 Type: 'T'  
 Sub-Type: 'B'  
 Data: See above

---

## 3.4 Terminal Call/Answer Mode (TC)

This message is sent by the PC to request storing/reading of call/answer mode parameters

Direction: PC -> RTE  
 Mode: '&' / '?'  
 Type: 'T'  
 Sub-Type: 'C'  
 Data:  
 Dummy (1 byte, must be 0): **(for future expansion)**  
 Mute on power up:  
   '0' = No  
   '1' = Yes  
 Automatic Answer:  
   '0' = Never  
   '1' = Yes always  
   '2' = Yes if not in a call  
   '3' = Yes trusted always **(Starting from v8.3.2.212)**



'4' = Yes trusted if not in a call (**Starting from v8.3.2.212**)  
Number of rings: (**Starting from v8.3.2.5xx**)  
'00'.....'30'

Direction: RTE -> PC

Mode '<'  
Type: 'T'  
Sub-Type 'C'  
Data: See above

#### Data Description:

##### **Mute on power up:**

The terminal at the power on is set in mute ('1') or no ('0').

##### **Automatic Answer:**

The terminal receiving 1^ incoming call can answer automatically ('1') or wait user operation ('0').

---

## 3.5 Terminal User Setting (TU)

This message is sent by PC to request the storage/reading of some parameters of Using Setting page  
This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'T'  
Sub-Type 'U'  
Data: Volume Ringing Tone (1 byte):  
'0'..'9'  
Volume Audio Rx (3 bytes):  
"-44".."20"  
Dummy (2 bytes, must be 0): (**for future expansion**)  
"00"  
Camera Remote Control  
'0' = Disable  
'1' = Enable

Direction: RTE -> PC

Mode '<'  
Type: 'T'  
Sub-Type 'U'  
Data: See above

#### Data Description:

##### **Volume Ringing Tone**

Volume of Ringing Tone during an incoming call

##### **Volume Audio Rx**

Volume of audio received

##### **Camera Remote Control**

Enables ("1") or disables ("0") the remote control of local cameras.

---

## 3.6 Terminal Video Camera Parameters (TV)

This message is sent by PC to request storing/reading of video camera parameters.

This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&'

Type: 'T'

Sub-Type: 'V'

Data: Types of parameter:

'0' = Old command compatibility: to set only the default camera

'G' =Generic command

'C' =Camera specific configuration

'B' =Camera white balance configuration

'L' =Camera backlight, contrast and brightness configuration

'E' =Camera exposure compensation configuration

'F' =Camera focus configuration

'A' =Camera auto-exposure configuration

'S' =Camera saturation (**Starting from v3.2.x**)

'H' =HDMI switcher (**Starting from v3.2.x**)

'D' =Flex Parameters (**Starting from v8.3.2.222**)

### Parameter type '0'

Dummy (5 bytes must be 0) (**for future expansion**)

"00000"

Default Video Input:

'0' = HD1

'1' = USB or HD2 for XT1000

'2' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)

'3' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'4' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'5' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'7' = DVI Input

Dummy (1 byte, must be 0) (**for future expansion**)

Dummy (1 byte, must be 0) (**for future expansion**)

### Parameter type 'G'

Default camera (2 bytes):

'01' = HD1

'02' = USB or HD2 for XT1000

'03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)

'04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'08' = DVI Input

Camera driver:

'0' = Automatic  
'1' = Scopia® XT1000 Standard camera  
'2' = Scopia® XT Premium camera  
'3' = Scopia® XT Standard II camera  
'4' = Scopia® XT Advanced camera  
'5' = Scopia® XT Flex camera (**Starting from v8.3.2.222**)

Camera control by far site:

'0' = No  
'1' = Yes

Bring Back to place:

'0' = No  
'1' = Yes

Always power on camera:

'0' = No  
'1' = Yes

Camera privacy mode:

'0' = No  
'1' = Yes

Sharpness (**only for Standard camera driver**):

'1' = Low  
'2' = Medium  
'3' = High

Digital zoom (**only for Sony and Flex camera driver**):

'0' = No  
'1' = Yes

#### Parameter type 'C'

Video camera Num (2 bytes):

'01' = HD1  
'02' = USB or HD2 for XT1000  
'03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)  
'04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
'05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
'06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
'08' = DVI Input

Enable:

'0' = No  
'1' = Yes

Moving (PTZ):

'0' = No  
'1' = yes

#### Parameter type 'B'

Video camera Num (2 bytes):

'01' = HD1  
'02' = USB or HD2 for XT1000  
'03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)  
'04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
'05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
'06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
'08' = DVI Input

White balance mode:

'0' = Automatic  
'1' = Indoor

- '2' = Outdoor
- '3' = Manual
- '4' = Customize
- '5' = Wide Automatic (only for Flex driver) **(Starting from v8.3.2.222**

White balance red value (**only in White Balance Manual mode**) (2 bytes hexadecimal value)

White balance blue value (**only in White Balance Manual mode**) (2 bytes hexadecimal value)

White balance calibration (**only in White Balance Customize mode**):

- '0' = No calibration
- '1' = Calibration command

#### Parameter type 'L'

Video camera Num (2 bytes):

- '01' = HD1
- '02' = USB or HD2 for XT1000
- '03' = HD2 **(Starting from v3.2.x XT5000 with HDMI switcher) or (Starting from v8.3.2.222 XT7000)**
- '04' = HD3 **(Starting from v3.2.x XT5000 with HDMI switcher) or (Starting from v8.3.2.222 XT7000 with HDMI switcher)**
- '05' = HD4 **(Starting from v3.2.x XT5000 with HDMI switcher) or (Starting from v8.3.2.222 XT7000 with HDMI switcher)**
- '06' = HD5 **(Starting from v8.3.2.222 XT7000 with HDMI switcher)**
- '08' = DVI Input

Backlight compensation :

- '0' = No
- '1' = yes

Camera contrast value (2 bytes hexadecimal value)

Camera brightness value (2 bytes hexadecimal value)

Camera sharpness value (2 bytes hexadecimal value)

#### Parameter type 'E' (not valid for USB camera)

Video camera Num (2 bytes):

- '01' = HD1
- '03' = HD2 **(Starting from v3.2.x XT5000 with HDMI switcher) or (Starting from v8.3.2.222 XT7000)**
- '04' = HD3 **(Starting from v3.2.x XT5000 with HDMI switcher) or (Starting from v8.3.2.222 XT7000 with HDMI switcher)**
- '05' = HD4 **(Starting from v3.2.x XT5000 with HDMI switcher) or (Starting from v8.3.2.222 XT7000 with HDMI switcher)**
- '06' = HD5 **(Starting from v8.3.2.222 XT7000 with HDMI switcher)**
- '08' = DVI Input

Exposure compensation :

- '0' = No
- '1' = yes

Exposure level (**only if Exposure compensation yes**) (2 bytes hexadecimal value)

#### Parameter type 'F'

Video camera Num (2 bytes):

- '01' = HD1
- '02' = USB or HD2 for XT1000
- '03' = HD2 **(Starting from v3.2.x XT5000 with HDMI switcher) or (Starting from v8.3.2.222 XT7000)**
- '04' = HD3 **(Starting from v3.2.x XT5000 with HDMI switcher) or (Starting from v8.3.2.222 XT7000 with HDMI switcher)**
- '05' = HD4 **(Starting from v3.2.x XT5000 with HDMI switcher) or (Starting from v8.3.2.222 XT7000 with HDMI switcher)**
- '06' = HD5 **(Starting from v8.3.2.222 XT7000 with HDMI switcher)**
- '08' = DVI Input

Focus mode:

'0' = Automatic

'1' = Semiautomatic (**not valid for USB camera**)

'2' = Manual

Focus distance (**only if Focus mode is Manual**) (4 bytes hexadecimal value)

**Parameter type 'A' (not valid for USB camera)**

Video camera Num (2 bytes):

'01' = HD1

'03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)

'04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'08' = DVI Input

Auto Exposure:

'0' = Automatic

'1' = Manual

Shutter (**only if Auto Exposure is Manual**) (2 bytes hexadecimal value)

Iris (**only if Auto Exposure is Manual**) (2 bytes hexadecimal value)

Gain (**only if Auto Exposure is Manual**) (2 bytes hexadecimal value)

**Parameter type 'S'**

Video camera Num (2 bytes):

'01' = HD1

'02' = USB or HD2 for XT1000

'03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)

'04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'08' = DVI Input

Saturation: (2 bytes hexadecimal value) (**only for USB or Flex driver**)

White Balance Value: (4 bytes hexadecimal value) (**only for USB**) (**Starting from v8.3.2.222**)

Dummy (6 bytes, must be 0)

**Parameter type 'H' (only for XT5000 and XT7000)**

XT Camera Switch Detect Mode:

'1' = Yes

'2' = No

Dummy (10 bytes, must be 0)

**Parameter type 'D' (valid only for Flex camera driver) (Starting from v8.3.2.222)**

Video camera Num (2 bytes):

'01' = HD1

'03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)

'04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'08' = DVI Input

Picture:

'0' = Automatic

'1' = Manual  
 Hue (2 bytes hexadecimal value)  
 Wide Dynamic range  
 '0' = Off  
 '1' = Level-1  
 '2' = Level-2  
 '3' = Level-3  
 '4' = Level-4  
 '5' = Level-5  
 Ceiling Mount:  
 '0' = No  
 '1' = Yes  
 IR Receivers:  
 '0' = Off  
 '1' = Both  
 '2' = Right  
 '3' = Left  
 Dummy (10 bytes, must be 0)

Direction: PC -> RTE

Mode '0'

Type: 'T'

Sub-Type 'V'

Data: Types of parameter:

'0' = Old command compatibility: to get only the default camera  
 'G' = Generic command  
 'C' = Camera specific configuration  
 'B' = Camera white balance configuration  
 'L' = Camera backlight, contrast and brightness configuration  
 'E' = Camera exposure compensation configuration  
 'F' = Camera focus configuration  
 'A' = Camera auto-exposure configuration  
 'S' = Camera saturation configuration (**Starting from v3.2.x**)  
 'H' = HDMI switcher (**Starting from v3.2.x**)  
 'D' = Flex Parameters (**Starting from v8.3.2.222**)

#### Parameter type '0'

None

#### Parameter type 'G'

None

#### Parameter type 'C'

Video camera Num (2 bytes):

'01' = HD1  
 '02' = USB or HD2 for XT1000  
 '03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000)  
 '04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '08' = DVI Input

#### Parameter type 'B' (not valid for XT5000 USB camera)

Video camera Num (2 bytes):

'01' = HD1  
 '02' = USB or HD2 for XT1000  
 '03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000)  
 '04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '08' = DVI Input

#### Parameter type 'L'

Video camera Num (2 bytes):

'01' = HD1  
 '02' = USB or HD2 for XT1000  
 '03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000)  
 '04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '08' = DVI Input

#### Parameter type 'E' (not valid for USB camera)

Video camera Num (2 bytes):

'01' = HD1  
 '03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000)  
 '04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '08' = DVI Input

#### Parameter type 'F'

Video camera Num (2 bytes):

'01' = HD1  
 '02' = USB or HD2 for XT1000  
 '03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000)  
 '04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '08' = DVI Input

#### Parameter type 'A' (not valid for USB camera)

Video camera Num (2 bytes):

'01' = HD1  
 '03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000)  
 '04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '08' = DVI Input



**Parameter type 'H'**

None

**Parameter type 'S'**

Video camera Num (2 bytes):

'01' = HD1

'02' = USB or HD2 for XT1000

'03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)'04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)'05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)'06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'08' = DVI Input

**Parameter type 'D' (only for Flex driver)**

Video camera Num (2 bytes):

'01' = HD1

'03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)'04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)'05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)'06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'08' = DVI Input

Direction: RTE -&gt; PC

Mode '&lt;'

Type: 'T'

Sub-Type 'V'

Data: See above

Data Description:**Warning:** Scopia® XT1000 Standard driver camera must not be used with XT5000 system.**Parameter type 0**

Only for compatibility with the old message AT[&amp;TV000000

**Parameter type G**

The camera numeration is different from old command 0 to make it equal to the one used with SF and SY commands.

**Parameter type C**

The enable field doesn't work for the HD1 camera (it cannot be disabled).

**Parameter type B**

The white balance calibration is 1 only if white balance mode is Customize and you want to do the same thing as the "Calibration" key in the camera configuration page.

**Parameter type F**



The focus value is 4 bytes long in the format 'xxxx' where xx is the hexadecimal value of focus . For example, if from GUI you set value 1200, you must send these four bytes '4B0'.

---

## 3.7 Terminal Monitor Settings (TG)

This message is sent by PC to request storing/reading of monitor number in the system.  
This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode '&' / '?'

Type: 'T'

Sub-Type 'G'

Data: Monitor

'0' = Auto Detect

'3' = 1 monitor (HDTV1)

'7' = 2 monitors (HDTV1 (Video Rx) + HDTV2 (Menu & Present))

'9' = 2 monitors (HDTV1 (Menu & Present) + HDTV2 (Video Rx))

'B' = 1 monitors (HDTV2)

'C' = 2 monitors (HDTV1 Menu & Video Rx) + HDTV2 (Present))

'D' = 2 monitors (HDTV1 (Present) + HDTV2 (Menu & Video Rx))

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'G'

Data: See above

### Data Description:

Select the correct output configuration; Auto Detect allows the system to do it by detecting the connected monitors

---

## 3.8 Terminal Monitor Settings Extended (TS)

This message is sent by PC to request storing/reading monitor parameters

This message is sent by RTE as reply to a reading request.

**WARNING: Starting from v8.3.2.x**

Direction: PC -> RTE

Mode '&' / '?'

Type: 'T'

Sub-Type 'S'

Data: Types of parameter:

'G' = Generic

'A' = Graphic adjustments

'P' = PIP-PaP-PoP

## Parameter type 'G'

Numbers of monitors (2 bytes):

- '00' = Auto
- '01' = HD1
- '02' = HD2
- '03' = HD1 (Menu and Video Rx) + HD2 (Present.)
- '04' = HD1 (Menu and Present.) + HD2 (Video Rx)
- '05' = HD1 (Present.) + HD2 (Menu and Video Rx)
- '06' = HD1 (Video Rx) + HD2 (Menu and Present.)

Resolution monitor HD1 (2 bytes):

- '00' = Auto
- '01' = 1080p60
- '02' = 1080p50
- '03' = 1080p30
- '04' = 1080p25
- '05' = 720p60
- '06' = 720p50

Resolution monitor HD2 (2 bytes):

- '00' = Auto
- '01' = 1080p60
- '02' = 1080p50
- '03' = 1080p30
- '04' = 1080p25
- '05' = 720p60
- '06' = 720p50

Monitor Turn Off:

- '1' = Never
- '2' = Only on shut down
- '3' = On screen saver

Screen saver timeout (2 bytes):

- '00' = None
- '01' = 15 minutes
- '02' = 30 minutes
- '03' = 1 hour
- '04' = 2 hours
- '05' = 4 hours

Duplicate to HD2:

- '0' = No
- '1' = Yes

Dummy (10 bytes, must be 0) (**for future expansion**)

## Graphic Adjustments 'A'

Monitor:

- '1' = HD1
- '2' = HD2

Adjustment Mode:

- '1' = Menu and Presentation
- '2' = Menu, Presentation and Live Video
- '3' = Menu

Top (4 bytes):

'0000'.....'0100'

Left (4 bytes):

'0000'.....'0100'

Bottom (4 bytes):

'0000'.....'0100'

Right (4 bytes):

'0000'.....'0100'

Dummy (10 bytes, must be 0) (**for future expansion**)

### PIP-Pap-PoP 'P'

Multimage Mode:

'0' = Auto

'1' = On

'2' = Off

Multimage Type:

'0' = Auto

'1' = PIP

'2' = PaP

'3' = PoP

PIP Position:

'1' = Up/Left

'2' = Up/Right

'3' = Down/Right

'4' = Down/Left

PIP Rotation:

'1' = Clockwise

'2' = Counterclockwise

'3' = Fixed

Dummy (10 bytes, must be 0) (**for future expansion**)

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'S'

Data: See above

---

## 3.9 Terminal Audio Delay (TY)

This message is sent by PC to request storing/reading of audio delay parameters.

This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode '&' / '?'

Type: 'T'

Sub-Type 'Y'

Data: Automatic Audio Delay:

'0' = No

'1' = Yes

Audio Delay (3 bytes):

"000".."999"

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'Y'

Data: See above

Data Description:

### Audio Delay:

This parameter is used to achieve lips synchronization of remote user: the delay can be automatic (evaluated by the system) or manual (set by the user).

---

## 3.10 Terminal Mode Settings (TH)

This message is sent by PC to request storing/reading H.323 call parameters

This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'T'

Sub-Type: 'H'

Data: Network:

'1' = IP

'7' = ISDN (**Starting from v3.x**)

Audio Coding (**valid only for network IP**):

'0' = Automatic

'1' = G.722

'2' = G.728

'3' = G.711

'5' = G.722.1

'6' = MPEG4 AAC-LD

'7' = G.719

'8' = G.722.1 Annex C

'9' = G.729 A

'A' = MPEG4 AAC-LC (**Starting from v8.3.x**)

Video Coding (**valid only for network IP**):

'0' = automatic

'1' = H.261 CIF (**not valid for XT5000**)

'3' = H.263 CIF

'5' = H.263 4CIF

'6' = H.264 CIF

'8' = H.264 4CIF

'9' = H.263+ SIF

'A' = H.263+ 4SIF

'B' = H.263+ 1024x768

'C' = H.264+ SIF

'D' = H.264+ 4SIF

'E' = H.264 640x480 (VGA)

'F' = H.264 800x600 (SVGA)

'G' = H.264 1024x768 (XGA)

'H' = H.264 1280x1024 (SXGA)

'I' = H.264 1440x900 (WSXGA)

'J' = H.264 1920x1200 (**not valid for XT5000**)

'K' = H.264 w224p

'L' = H.264 w288p

'M' = H.264 w448p

'N' = H.264 w576p

'O' = H.264 720p

'P' = H.264 1080p

'Q' = H.264 1600x1200 (**not valid for XT5000**)

'R' = H.264 1280x768 (WXGA)

'S' = H.264 352p

'T' = H.264 576x336

'U' = H.264 640x400  
'V' = H.264 480p (Starting from v8.3.x)  
'X' = H.264 240p (Starting from v8.3.x)

Rate:

'1' = 64  
'2' = 128  
'3' = 192  
'4' = 256  
'5' = 320  
'6' = 384  
'7' = 448  
'8' = 512  
'C' = 768  
'D' = 1920  
'E' = 1152 (valid only for network IP)  
'F' = 1472  
'G' = 1536  
'H' = 2560 (valid only for network IP)  
'I' = 3072 (valid only for network IP)  
'J' = 3584 (valid only for network IP)  
'K' = 4096 (valid only for network IP)  
'L' = 5120 (valid only for network IP)  
'M' = 5632 (valid only for network IP)  
'N' = 6144 (valid only for network IP)  
'O' = 1728  
'P' = 4608 (valid only for network IP)  
'Q' = 2048 (valid only for network IP)  
'R' = 896 (valid only for network IP) (Starting from v3.2.x)  
'S' = 1024 (valid only for network IP) (Starting from v3.2.x)  
'T' = 1280 (valid only for network IP) (Starting from v3.2.x)  
'U' = 1408 (valid only for network IP) (Starting from v3.2.x)  
'V' = 6656 (valid only for network IP) (Starting from v8.3.x)  
'Z' = 7168 (valid only for network IP) (Starting from v8.3.x)  
'X' = 7680 (valid only for network IP) (Starting from v8.3.x)  
'Y' = 8128 (valid only for network IP) (Starting from v8.3.x)  
'W' = 8192 (valid only for network IP) (Starting from v8.3.x)  
'9' = 10240 (valid only for network IP) (Starting from v8.3.x)

Dual Video Coding (valid only for network IP):

'0' = automatic  
'B' = H.263+ 1024x768 (not valid for XT5000)  
'E' = H.264 640x480  
'F' = H.264 800x600  
'G' = H.264 1024x768  
'H' = H.264 1280x1024  
'I' = H.264 1440x900  
'J' = H.264 1920x1200 (not valid for XT5000)  
'O' = H.264 720p  
'P' = H.264 1080p  
'Q' = H.264 1600x1200 (not valid for XT5000)  
'R' = H.264 1280x768

Direction: RTE -> PC

Mode: '<'

Type: 'T'

Sub-Type: 'H'

Data: See above

## Data Description:

### Audio Coding:

Audio codecs used in video communications.

G.711: 4kHz audio at 64/56 kbit/s

G.722: 7kHz audio at 48/56 kbit/s

G.728: audio at 16 kbit/s

Example:

```
PC ----- AT[?TH<cr> -----> RTE
PC <----- AT[<TH12371<cr> ----- RTE      (IP, G.728, H.263, 448, unused)
PC <----- OK<cr> ----- RTE
```

---

## 3.11 Terminal Mode Settings Extended (TF)

This message is sent by PC to request storing/reading H.323 call parameters

This message is sent by RTE to reply to a reading request.

**WARNING: Starting from v3.x**

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'T'

Sub-Type: 'F'

Data: Network:

'1' = IP

'7' = ISDN

Command:

'A' = Audio Coding (**valid only for network IP**)

'V' = Video Coding (**valid only for network IP**)

'D' = Dual Video Coding (**valid only for network IP**)

'R' = Rate

### If command type 'A'

Audio coding (2 bytes):

'00' = Automatic

'01' = G.722

'02' = G.728

'03' = G.711

'05' = G.722.1

'06' = MPEG4 AAC-LD

'07' = G.719

'08' = G.722.1 Annex C

'09' = G.729 A

'10' = MPEG4 AAC-LC (**Starting from v8.3.x**)

Dummy (10 bytes, must be 0) (**for future expansion**)

### If command type 'V'

Video Coding (3 bytes):

'000' = automatic

'001' = H.261 CIF (**not valid for XT5000**)

'002' = H.263 CIF

'003' = H.263 4CIF  
 '004' = H.263+ SIF  
 '005' = H.263+ 4SIF  
 '006' = H.263+ 1024x768 XGA  
 '007' = H.264/H.265 CIF  
 '008' = H.264/H.265 4CIF  
 '009' = H.264/H.265 SIF  
 '010' = H.264/H.265 4SIF  
 '011' = H.264/H.265 640x400  
 '012' = H.264/H.265 640x480 VGA  
 '013' = H.264/H.265 800x600 SVGA  
 '014' = H.264/H.265 1024x768  
 '015' = H.264/H.265 w224p  
 '016' = H.264/H.265 w288p  
 '017' = H.264/H.265 576x336  
 '018' = H.264/H.265 352p  
 '019' = H.264/H.265 w448p  
 '020' = H.264/H.265 w576p  
 '021' = H.264/H.265 720p  
 '022' = H.264/H.265 1280x768 WXGA  
 '023' = H.264/H.265 1280x1024 SXGA  
 '024' = H.264/H.265 1440x900 WSXGA  
 '025' = H.264/H.265 1600x1200 (**not valid for XT5000**)  
 '026' = H.264/H.265 1920x1200 (**not valid for XT5000**)  
 '027' = H.264/H.265 1080p  
 '028' = H.264/H.265 480p (**Starting from v8.3.x**)  
 '029' = H.264/H.265 240p (**Starting from v8.3.x**)

H.264/H.265 Profile:

'0' = H.264 base profile  
 '1' = H.264 High profile  
 '2' = H.264 TSVC profile  
 '3' = H.264 High and TSVC profile  
 '4' = H.265 base profile (**Starting from v8.3.2.222**)  
 '5' = H.265 TSVC profile (**Starting from v8.3.2.222**)

Dummy (10 bytes) (**for future expansion**)

#### If command type 'D'

Video Coding (3 bytes):

'000' = automatic  
 '006' = H.263+ 1024x768 (**not valid for XT5000**)  
 '012' = H.264 640x480 (VGA)  
 '013' = H.264 800x600 (SVGA)  
 '014' = H.264 1024x768 (XGA)  
 '021' = H.264 720p  
 '022' = H.264 1280x768  
 '023' = H.264 1280x1024 (SXGA)  
 '024' = H.264 1440x900 (WSXGA)  
 '025' = H.264 1600x1200 (**not valid for XT5000**)  
 '026' = H.264 1920x1200 (**not valid for XT5000**)  
 '027' = H.264 1080p  
 '030' = H.264 1360x765 (valid only for High Profile) (**Starting from v8.3.x**)

H.264 Profile:

'0' = Base profile  
 '1' = High profile

Dummy (10 bytes, must be 0) (**for future expansion**)

#### If command type 'R'

Rate (2 bytes):

'01' = 64  
 '02' = 128

'03' = 192  
 '04' = 256  
 '05' = 320  
 '06' = 384  
 '07' = 448  
 '08' = 512  
 '09' = 768  
 '10' = 1152 (valid only for network IP)  
 '11' = 1472  
 '12' = 1536  
 '13' = 1728  
 '14' = 1920  
 '15' = 2048 (valid only for network IP)  
 '16' = 2560 (valid only for network IP)  
 '17' = 3072 (valid only for network IP)  
 '18' = 3584 (valid only for network IP)  
 '19' = 4096 (valid only for network IP)  
 '20' = 4608 (valid only for network IP)  
 '21' = 5120 (valid only for network IP)  
 '22' = 5632 (valid only for network IP)  
 '23' = 6144 (valid only for network IP)  
 '24' = 896 (valid only for network IP) (Starting from v3.2.x)  
 '25' = 1024 (valid only for network IP) (Starting from v3.2.x)  
 '26' = 1280 (valid only for network IP) (Starting from v3.2.x)  
 '27' = 1408 (valid only for network IP) (Starting from v3.2.x)  
 '28' = 6656 (valid only for network IP) (Starting from v8.3.x)  
 '29' = 7168 (valid only for network IP) (Starting from v8.3.x)  
 '30' = 7680 (valid only for network IP) (Starting from v8.3.x)  
 '31' = 8128 (valid only for network IP) (Starting from v8.3.x)  
 '32' = 8192 (valid only for network IP) (Starting from v8.3.x)  
 '33' = 10240 (valid only for network IP) (Starting from v8.3.x)  
 Dummy (10 bytes, must be 0) (for future expansion)

Direction: RTE -> PC

Mode: '<'  
 Type: 'T'  
 Sub-Type: 'F'  
 Data: See above

---

## 3.12 Terminal Capabilities Settings (TI)

This message is sent by PC to enable parameters on H.323 working mode  
 This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'  
 Type: 'T'  
 Sub-Type: 'I'  
 Data: Network:  
     '1' = IP  
 Types of parameter:  
     'A' = H.264 capability



'B' = Dual video H.323 (H.239) capability  
 'C' = DuoVideo capability (**no longer used**)  
 'D' = G.722.1 capability  
 'E' = MP4 AAC-LD capability  
 'F' = G.719 capability  
 'G' = H.263 Annexes capability (**Starting from 8.3.2.x**)  
 'H' = H.263 60fps capability (**not valid for XT5000**)  
 'I' = H.264 4CIF capability  
 'J' = HD 720 capability  
 'K' = Dual video H.264 capability  
 'L' = Live 720p on dual video capability (**no longer used**)  
 'M' = Dual video SIP capability (**no longer used**)  
 'N' = Dual video SIP (BFCP) capability  
 'O' = DTMF RFC2833 (H.323)  
 'P' = RTP Firewall  
 'Q' = 720 60fps capability  
 'R' = HD 1080 capability  
 'S' = 1080 60fps (**only for XT5000**)  
 'T' = H.264 HiP (**only for XT5000**)  
 'U' = H.264 TSVC (**only for XT5000**)  
 'V' = H.264 HiP TSVC (**only for XT5000**)  
 'W' = MP4 AAC-LC capability (**Starting from 8.3.2.x**)  
 'X' = G.728 capability (**Starting from 8.3.2.x**)  
 'Y' = G.729 capability (**Starting from 8.3.2.x**)  
 'Z' = DTMF H.245 UII capability (**Starting from 8.3.2.x**)  
 '1' = Dialing number format mode (**Starting from 8.3.2.x**)  
 '2' = Separator (**Starting from 8.3.2.x**)  
 '3' = H.265 (**Starting from 8.3.2.222**)  
 '4' = H.265 SVC (**Starting from 8.3.2.222**)

**If type of parameter is 'A'**

Sends H.264 capability

'0' = no  
 '1' = yes

**If type of parameter is 'B'**

Sends dual video H.323 (H.239) capability

'0' = no  
 '1' = yes

**If type of parameter is 'C' (no longer used)**

Sends DuoVideo capability

'0' = no  
 '1' = yes

**If type of parameter is 'D'**

Sends G.722.1 capability

'0' = no  
 '1' = yes

**If type of parameter is 'E'**

Sends MP4 AAC-LD capability

'0' = no  
 '1' = yes

**If type of parameter is 'F'**

Sends G.719 capability

'0' = no  
 '1' = yes

**If type of parameter is 'G' (not valid for XT5000)**

Sends H.263 Annexes capability

'0' = no  
 '1' = yes

**If type of parameter is 'H' (not valid for XT5000)**

Sends H.263 60fps capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'I'**  
 Sends H.264 4CIF capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'J'**  
 Sends HD 720 capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'K'**  
 Sends dual video H.264 capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'L' (no longer used)**  
 Sends Live 720p on dual video capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'M' (no longer used)**  
 Sends dual video SIP capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'N'**  
 Sends BFCP SIP capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'O'**  
 Sends DTMF RFC2833 capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'P'**  
 Sends RTP Firewall capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'Q'**  
 Sends 720 60 fps capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'R'**  
 Sends HD 1080 capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'S' (only for XT5000)**  
 Sends 1080 60 fps capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'T' (only for XT5000)**  
 Sends H.264 High Profile capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'U' (only for XT5000)**  
 Sends H.264 Scalable Video Coding capability  
 '0' = no  
 '1' = yes

**If type of parameter is 'V' (only for XT5000)**  
 Sends H.264 High Profile and Scalable Video Coding capabilities  
 '0' = no  
 '1' = yes

**If type of parameter is 'W' (Starting from 8.3.2.)**

Sends MP4 AAC-LC capability

'0' = no

'1' = yes

**If type of parameter is 'X' (Starting from 8.3.2.x)**

Sends G.728 capability

'0' = no

'1' = yes

**If type of parameter is 'Y' (Starting from 8.3.2.x)**

Sends G.729 capability

'0' = no

'1' = yes

**If type of parameter is 'Z' (Starting from 8.3.2.x)**

Sends DTMF H.245 UUI capability

'0' = no

'1' = yes

**If type of parameter is '1' (Starting from 8.3.2.x)**

Define Dialing Number format mode:

'1' = Num + Sep + Ext

'2' = Ext + Sep + Num

**If type of parameter is '2' (Starting from 8.3.2.x)**

Define Separator (ASCII string null terminated max 3 characters):

**If type of parameter is '3' (Starting from 8.3.2.222)**

Sends H.265 capability

'0' = no

'1' = yes

**If type of parameter is '4' (Starting from 8.3.2.222)**

Sends H.265 SVC capability

'0' = no

'1' = yes

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'I'

Data: See above

Data Description:

**Network:**

Network type

**Types of parameter:**

Identify the type of capabilities that the system can or cannot send to remote site. For example if the system has not to send the G.722.1 audio capability to remote site, then you have to use the 'E' parameter.

Example:

```
PC ----- AT[&TIOE0<cr> -----> RTE disable the MP4 AACLD capability
PC <----- OK<cr> ----- RTE
```

---

## 3.13 Terminal Location Parameters (TL)

This message is sent by PC to request storing/reading of parameters about the terminal localization/Country.

Direction: PC -> RTE

Mode '8' / '?'  
Type: 'T'  
Sub-Type 'L'  
Data: Country Code ("000" ... "999" ) (**Starting from 8.3.2.x no longer used**)  
Audio Coding:  
    European = '0' (a law)  
    U.S.A = '1' ( $\mu$  law)  
Video Frequency:  
    '0' = 50Hz  
    '1' = 60Hz  
Dial Tone: (**Starting from 8.3.2.x no longer used**)  
    '0' = Standard  
    '1' = Continuous  
Language:  
    '1' = Italian  
    '2' = English  
    '3' = French  
    '4' = Spanish  
    '5' = German  
    '6' = Portuguese  
    '7' = Norwegian  
    '8' = Chinese  
    '9' = Swedish  
Terminal Name (max 30 chars)

Direction: RTE -> PC

Mode '<'  
Type: 'T'  
Sub-Type 'L'  
Data: See above

### Data Description:

#### **Audio Coding:**

Audio coding used in communications without video and generally used in user's own Country.

A-law PCM coding -> European

MU-law PCM coding -> U.S.A

#### **Video Standard:**

Video coding used in users's own Country. Generally 50Hz in Europe and 60Hz in U.S.A.

#### **Dial Tone:**

The Dial Tone can be Normal or forced to Continuous.

#### **Language:**

Select the language used in the terminal graphic user interface.

#### **Terminal Name:**

Name of terminal used as ALIAS.

#### **Example:**

PC ----- AT[?TL<cr> -----> RTE (Terminal Location Request)  
PC ←----- AT[<TL0011502TerminaleName<cr> ----- RTE (CC=001, μlaw, 60Hz, NI1, normal, English,name)  
PC ←----- OK<cr> ----- RTE

## 3.14 Terminal Location Parameters Extended (TQ)

This message is sent by PC to request storing/reading of parameters about the terminal localization/Country.  
**Starting from 8.3.2.x**

Direction: PC -> RTE

Mode '8' / '?'

Type: 'T'

Sub-Type 'Q'

Data: Type of configuration

'G' = Generic

'N' = First part System name

'M' = Second part System name

'P' = International Call Prefix (**Starting from 8.3.4.x**)

'W' = Save configuration

### If type of configuration 'G':

Country (three bytes):

'001' = Albania

'002' = Argentina

'003' = Australia

'004' = Austria

'005' = Bangladesh

'006' = Belgium

'007' = Bhutan

'008' = Brazil

'009' = Canada

'010' = Chile

'011' = China

'012' = Cyprus

'013' = Czech Rep.

'014' = Denmark

'015' = España

'016' = Estonia

'017' = Finland

'018' = France

'019' = Germany

'020' = Great Britain

'021' = Greece

'022' = Hungary

'023' = India

'024' = Ireland

'025' = Israel

'026' = Italy

'027' = Japan

'028' = Korea

'029' = Latvia

'030' = Lithuania

'031' = Luxembourg

'032' = Maldives

'033' = Malta  
'034' = Mexico  
'035' = Nepal  
'036' = Netherlands  
'037' = Norway  
'038' = Pakistan  
'039' = Poland  
'040' = Portugal  
'041' = Romania  
'042' = Russia  
'043' = Slovakia  
'044' = Slovenia  
'045' = South Africa  
'046' = Sri Lanka  
'047' = Sweden  
'048' = Switzerland  
'049' = USA  
'999' = Others

Language (three bytes):

'001' = Italian  
'002' = English  
'003' = French  
'004' = Spanish  
'005' = German  
'006' = Portuguese  
'007' = Norwegian  
'008' = Swedish  
'009' = Chinese  
'010' = Japanese  
'011' = Russian  
'012' = Korean  
'013' = Czech  
'014' = Hungarian  
'015' = Polish  
'016' = Finnish  
'017' = Thai  
'018' = Trad. Chinese  
'019' = Turkish  
'020' = Arabic  
'021' = Farsi  
'022' = Serbian  
'023' = Indonesia  
'024' = Slovak

Audio Coding:

'0' = European (a law)  
'1' = U.S.A (μ law)

Video Frequency:

'0' = Auto  
'1' = 50Hz  
'2' = 60Hz

System name Display Mode:

'0' = Automatic  
'1' = System Name Unicode  
'2' = SIP  
'3' = H.323  
'4' = System Name  
'5' = Hostname

**If type of configuration 'P' (Starting from 8.3.4.x):**

International Call Prefix (max 10 only numeric chars)

**If type of configuration 'N':**

First part System name (max 64 ASCII chars)

**If type of configuration 'M':**

Second part System name (max 64 ASCII chars)

**If command type 'W' (Save data) :**

Attention: without this command no one of previous commands will be saved

Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'Q'

Data: See above

Data Description:

**Audio Coding:**

Audio coding used in communications without video and generally used in user's own Country.

A-law PCM coding -> European

MU-law PCM coding -> U.S.A

**Video Frequency:**

Video coding used in users's own Country. Generally 50Hz in Europe and 60Hz in U.S.A.

**Language:**

Select the language used in the terminal graphic user interface.

---

## 3.15 Terminal MCU configuration (TM)

This message is sent by PC to request storing/reading of parameters about the MCU configuration.

**Starting from 8.3.2.x**

Direction: PC -> RTE

Mode '&' / '?'

Type: 'T'

Sub-Type 'M'

Data: Type of configuration  
'G' = Generic

**If type of configuration 'G':**

Enable:

'0' = No

'1' = Yes

Display Participants Name:

'0' = No

'1' = Yes

Meeting Time Limit (2 bytes):

'00' = Unlimited

'01' = 1 hour

'02' = 2 hours

'04' = 4 hours

'06' = 6 hours

'08' = 8 hours  
 '10' = 10 hours  
 '12' = 12 hours  
 '14' = 14 hours  
 '18' = 18 hours  
 '20' = 20 hours  
 '24' = 24 hours  
 Max calls limit:  
 '0' = No  
 '1' = Yes  
 Max Calls (2 bytes):  
 '02' = 2 terminals  
 '03' = 3 terminals  
 '04' = 4 terminals  
 '05' = 5 terminals  
 '06' = 6 terminals  
 '07' = 7 terminals  
 '08' = 8 terminals  
 Local Audio Video:  
 '0' = No  
 '1' = Yes  
 Hide Meeting:  
 '0' = No  
 '1' = Yes  
 Allow WEB Management:  
 '0' = No  
 '1' = Yes  
 Default layout (2 bytes):

'00' = Automatic  
 '01' = One terminal  
 '02' = Two terminals A  
 '03' = Two terminals B  
 '04' = Two terminals C  
 '05' = Two terminals D  
 '06' = Three terminals A  
 '07' = Three terminals B  
 '08' = Four terminals A  
 '09' = Four terminals B  
 '10' = Four terminals C  
 '11' = Five terminals





'12' = Six terminals

'13' = Seven terminals A

'14' = Seven terminals B

'15' = Seven terminals C

'16' = Eight terminals A

'17' = Eight terminals B

'18' = Eight terminals C

'19' = Eight terminals D

'20' = Nine terminals A

'21' = Nine terminals B

'22' = Nine terminals C

Default Lecturer Layout (2 bytes):

'01' = One terminal

'02' = Two terminals A



Direction: RTE -> PC

Mode '<'

Type: 'T'

Sub-Type 'M'

Data: See above

Data Description:

## 3.16 Terminal Reload Default parameters (TR)

This message is sent by PC to restore the terminal default parameters.

Direction: PC -> RTE

Mode '&'

Type: 'T'

Sub-Type 'R'

Data: None

---

## 3.17 Terminal Encryption Configuration (TO)

This message is sent by PC to request storing/reading of parameters about encryption configuration. It is sent by RTE to PC as an answer to reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'T'

Sub-Type: 'O'

Data: Command Type:

'G' = Generic Command (**Starting from 8.3.2.532 no longer used**)

'A' = Generic Command (**Starting from 8.3.2.532**)

### If command type 'G'

Use Encryption:

'0' = No

'1' = Yes

Dummy (1 byte, must be 0) (**for future expansion**)

Unprotected call:

'1' = Disconnect

'2' = Ask confirm

'3' = Inform

'4' = State

Dummy (1 byte, must be 0) (**for future expansion**)

Dummy (1 byte, must be 0) (**for future expansion**)

### If command type 'A' (**Starting from 8.3.2.532**)

Use Encryption:

'0' = No

'1' = Yes

Accepted Protected Calls:

'0' = No

'1' = Yes

Enable Encryption MCU

'0' = No

'1' = Yes

Unprotected call:

'1' = Disconnect

'2' = Ask confirm

'3' = Inform

'4' = State

Use proprietary encryption for SIP:

'0' = No

'1' = Yes

Dummies (20 bytes, must be 0) (**for future expansion**)

Direction: RTE -> PC

Mode: '<'

Type: 'T'

Sub-Type: 'O'

Data: See above

---

## 3.18 Terminal License Management (TW)

This message is sent by PC to RTE to read/store parameters about licenses status.  
It is sent by RTE to PC as an answer to reading request.

Direction: PC -> RTE

Mode ' & '  
Type: ' T '  
Sub-Type ' W '  
Data: Command Type:  
          ' B ' = Send license code  
          ' F ' = Read licenses from file

**If command type 'B'**  
          Encoded license option (**ASCII string**)

**If command type 'F'**  
          No data

Direction: PC -> RTE

Mode ' ? '  
Type: ' T '  
Sub-Type ' W '  
Data: Type info about license  
          None  
          ' L ' = Licenses status  
          ' S ' = License name and status (**Starting from v3.2.x**)  
          ' F ' = Upgrade Software status (**Starting from v8.3.2.x**)

**If command type none (empty request for old compatibility)**  
          No data : the command answers with TWL response explained below

**If command type 'L'**  
          No data : the command answers with TWL response explained below

**If command type 'S'**  
          No data : the command answers with the license name for any active license in the system

**If command type 'F'**  
          No data : the command answers with the software upgrade license status and info

Direction: RTE -> PC

Mode ' < '  
Type: ' T '  
Sub-Type ' W '  
Data: Command Type:  
          ' L ' = Information about system licenses status  
          ' S ' = License name and status (**Starting from v3.2.x**)  
          ' F ' = Upgrade Software status (**Starting from v8.3.2.x**)

**If command type 'L'**

MCU license  
    '0' = disabled  
    '1' = enabled

MCU demo license  
    '0' = disabled  
    '1' = enabled

MCU Site extension license  
    '0' = disabled  
    '1' = enabled

Rate extension license  
    '0' = disabled  
    '1' = enabled

Audio codec G.728 license:  
    '0' = disabled  
    '1' = enabled

LAN 10/100 license:  
    '0' = disabled  
    '1' = enabled

Scopia® control license:  
    '0' = disabled  
    '1' = enabled

Scopia® Desktop Demo license:  
    '0' = disabled  
    '1' = enabled

Scopia® Desktop license:  
    '0' = disabled  
    '1' = enabled

OEM1 license:  
    '0' = disabled  
    '1' = enabled

OEM2 license:  
    '0' = disabled  
    '1' = enabled

OEM3 license:  
    '0' = disabled  
    '1' = enabled

OEM4 license:  
    '0' = disabled  
    '1' = enabled

Telepresence license:  
    '0' = disabled  
    '1' = enabled

Video HD 1080p Tx/Rx  
    '0' = disabled  
    '1' = enabled

Zoom extension license  
    '0' = disabled  
    '1' = enabled

Encryption license  
    '0' = disabled  
    '1' = enabled

USB recording license (**Starting from v3.2.x**)  
    '0' = disabled  
    '1' = enabled

HDMI Input license (**Starting from v8.3.2.x**)  
    '0' = disabled  
    '1' = enabled

HDMI Output license (**Starting from v8.3.2.x**)  
    '0' = disabled  
    '1' = enabled

Dummy (1 byte, must be 0) (**for future license**):

'0' = disabled

'1' = enabled

.....  
Dummy (30 bytes , must be 0) (**for future license**):

'0' = disabled

'1' = enabled

#### If command type 'S'

Active license name string (max 64 ASCII chars)

#### If command type 'F'

Software Upgrade license status:

'0' = Current version is not running due to a lack of license

'1' = Current version is running and enabled

'2' = Current version is running in demo mode

Software upgrade demo in minutes (5 bytes):

Last software version enabled to run (ASCII chars)

---

## 3.19 Terminal configuration management (TK)

This message is sent by PC to RTE to request storing/reading of parameters about the system configuration management or to import and export the whole system configuration.

It is sent by RTE to PC as an answer to reading request.

Direction: PC -> RTE

Mode: '&'

Type: 'T'

Sub-Type: 'K'

Data: Command Type:

'E' = Export the system configuration (Mass configuration)

'I' = Import the system configuration (Mass configuration)

'L' = Export log file

'B' = Export the whole system configuration (without passwords) for a backup

'A' = Import the whole system configuration (without passwords) for a backup

'S' = Export only password (system, WEB and Telnet)

'P' = Import only password (system, WEB and Telnet)

'C' = Export the system configuration (included passwords) (Mass configuration)

'D' = Import the system configuration (included passwords) (Mass configuration)

'G' = Export the whole system configuration (included passwords) for a backup

'H' = Import the whole system configuration (included passwords) for a backup

'F' = Set FTP URL (**Starting from v8.3.2.x**)

'U' = Set FTP username (**Starting from v8.3.2.x**)

'V' = Set FTP password (**Starting from v8.3.2.x**)

'M' = Send CSPackage to FTP server configured with F action command (**Starting from v8.3.2.x**)

'N' = Send exported system configuration file to FTP server configured with F action command (**Starting from v8.3.2.x**)

'O' = Download system configuration file named c\_ini from FTP server configured with F action command (**Starting from v8.3.2.x**)

'Q' = Download new package version file named XTVersion.exe from FTP server configured with F action command (**Starting from v8.3.2.x**)

'T' = Start update of new package version previously downloaded by Q command (**Starting from v8.3.2.x**)

'R' = Configure Import/Export (**Starting from v8.3.2.x**)

**If command type 'E'**

No data required

**If command type 'I'**

No data required

**If command type 'L'**

No data required

**If command type 'B'**

No data required

**If command type 'A'**

No data required

**If command type 'S'**

No data required

**If command type 'P'**

No data required

**If command type 'C'**

No data required

**If command type 'D'**

No data required

**If command type 'G'**

No data required

**If command type 'H'**

No data required

**Action type 'F' (**Starting from v8.3.2.x**)**

FTP Server URL (max 60 ASCII chars)

**Action type 'U' (**Starting from v8.3.2.x**)**

FTP Username (max 60 ASCII chars)

**Action type 'V' (**Starting from v8.3.2.x**)**

FTP Password (max 60 ASCII chars):

**Action type 'M' (**Starting from v8.3.2.x**)**

No data required

**Action type 'N' (**Starting from v8.3.2.x**)**

No data required

**Action type 'O' (**Starting from v8.3.2.x**)**

No data required

**Action type 'Q' (**Starting from v8.3.2.x**)**

No data required

**Action type 'T' (**Starting from v8.3.2.x**)**

No data required

**Action type 'R' (Starting from v8.3.2.x)**

Enable to export the local configuration:

'0' = No

'1' = Yes

Enable to import another system configuration:

'0' = No

'1' = Yes

Direction: PC -> RTE

Mode: '?'

Type: 'T'

Sub-Type: 'K'

Data: Command Type:  
'R' = Generic Command

Direction: RTE -> PC

Mode: '<'

Type: 'T'

Sub-Type: 'K'

Data: Command Type:  
'R' = Generic Command

**If command type 'R'**

Enable to export the local configuration:

'0' = No

'1' = Yes

Enable to import another system configuration:

'0' = No

'1' = Yes

Data Description:**Commands 'E' 'B' 'S' 'C' 'G'**

After calling one of export command, the system creates the file contained all configurations. This file can be downloaded by HTTP protocol from the URL [http://xxx.xxx.xxx.xxx/web/download/c\\_ini](http://xxx.xxx.xxx.xxx/web/download/c_ini) or by FTP protocol with 'N' command.

**Commands 'I' 'A' 'P' 'D' 'H'**

Before performing the import command you must download the file c\_ini contained system configuration by the 'O' command. The file to download must be named c\_ini and must be in the same directory of the URL set by F command.

After calling one of import command, the system read the configuration file sent to the system before, and save all new configurations, and the restart.

**Command 'L'**

The log data file can be downloaded by HTTP protocol from the URL [http://xxx.xxx.xxx.xxx/web/download/g\\_slog](http://xxx.xxx.xxx.xxx/web/download/g_slog) or by FTP protocol with M command.

**Commands 'Q' 'T'**

The Q command is used to download the new version package for XT system form the URL previously specified by F command. XT version package must be renamed in XTVersion.exe and must be in the same directory of the URL set by F command.

The T command can be called after the Q command to update the system version.

**Command 'F'**

This command saves the FTP URL to which send configuration file or log file used by M and N commands. The same URL is used to take the configuration file for import operation by O command, or to take the new version system package for update system by T command.

For example if you want to configure system by [ftp://xxx.xxx.xxx.xxx/Configuration/c\\_ini](ftp://xxx.xxx.xxx.xxx/Configuration/c_ini) file, you must call 'F' command with <ftp://xxx.xxx.xxx.xxx/Configuration> URL.

For example if you want to update system with new version <ftp://xxx.xxx.xxx.xxx/Versions/XT5000.exe> file, you must call 'F' command with <ftp://xxx.xxx.xxx.xxx/Versions> URL.

---

## 3.20 Terminal Audio Configuration (TN)

This message is sent by PC to request storing/reading of audio inputs, outputs and echo canceller parameters. This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'T'

Sub-Type: 'N'

Data: Module:

'I' = Inputs

'O' = Outputs **Warning: starting from v8.3.x this command doesn't work. Use T and P modules**

'H' = Echo canceller

'D' = Load Default values

'T' = Tracks **(Starting from v8.3.x)**

'P' = Physical Output **(Starting from v8.3.x)**

'G' = General **(Starting from v8.3.x)**

### If Module = 'I'

Input: (2 bytes)

'01' = POD1

'02' = POD2

'03' = SPDIF/HD audio input (for XT5000 is Digital input)

'04' = Analog audio input

'05' = HD audio input **(Starting from v8.3.x)**

'06' = USB camera audio input **(Starting from v8.3.x)**

'07' = USB microphone audio input **(Starting from v8.3.x)**

'08' = HD audio input **(only for XT7000) (Starting from v8.3.2.222)**

Enable:

'0' = Disabled

'1' = Enabled

Gain: (2 bytes) '00' ... '24'

Echo:

'0' = Not Cancelled

'1' = Cancelled

Audio selection:

'1' = Associated to DVI

'2' = Always (this means SPDIF always for SPDIF/HD)

'3' = HD camera (used only with SPDIF/HD input)

Type: **(valid only for Analog input)**

'1' = Line

'2' = Microphone

Mode: **(valid only for Analog input)**

'1' = Stereo

'2' = Mono

Ignore Mute (used only with Digital and Analog input) **(Starting from v8.3.x)**



'0' = No  
'1' = Yes  
Dummy (1 byte, must be 0) (for future expansion):

**If Module = 'O' (Valid only for XT1000)**

Speakers: (1 byte)  
'0' = Auto  
'1' = HD1  
'2' = HD2  
'3' = All  
SPDIF/HD input to output:  
'0' = None  
'1' = HD1 + SPDIF + Analog  
'2' = HD2  
'3' = All  
Echo cancelled inputs to output :  
'0' = None  
'1' = HD1 + SPDIF + Analog  
'2' = HD2  
Rx Remote to output :  
'0' = None  
'1' = HD1 + SPDIF + Analog  
'2' = HD2  
'3' = All  
Analog to output :  
'0' = None  
'1' = HD1 + SPDIF + Analog  
'2' = HD2  
'3' = All

**If Module = 'H'**

Automatic Gain Control:  
'1' = Enabled  
'0' = Disabled  
Noise Reduction (Post Filter):  
'1' = Enabled  
'0' = Disabled  
Audio delay automatic estimation: **(Starting from v8.3.x)**  
'1' = Yes  
'0' = No  
Apply delay value: **(Starting from v8.3.x)**  
'1' = Yes  
'0' = No  
Dummy (1 byte, must be 0) (for future expansion)  
Dummy (1 byte, must be 0) (for future expansion)

**If Module = 'T' (Starting from v8.3.x)**

Track Number (2 bytes):  
'01' = Track 1  
'02' = Track 2  
Digital Audio:  
'1' = Yes  
'0' = No  
Echo cancelled inputs:  
'1' = Yes  
'0' = No  
Rx Remote:  
'1' = Yes  
'0' = No  
Analog Audio:

'1' = Yes  
'0' = No  
HD1:  
'1' = Yes  
'0' = No  
HD2: **only for XT7000 (Starting from v8.3.2.222):**  
'1' = Yes  
'0' = No  
Dummy (9 bytes) (**for future expansion**)::

**If Module = 'P' (Starting from v8.3.x)**

HD1 Output:  
'00' = Off  
'01' = Track 1  
'02' = Track 2  
HD2 Output:  
'00' = Off  
'02' = Track 2  
Digital Audio Output:  
'00' = Off  
'01' = Track 1  
'02' = Track 2  
Analog Audio Output:  
'00' = Off  
'01' = Track 1  
'02' = Track 2  
USB headset:  
'00' = Off  
'01' = Track 1  
'02' = Track 2  
Dummy (10 bytes, must be 0) (**for future expansion**)::

**If Module = 'D'**

Type:  
'1' = Load default values for audio input configuration  
'2' = Load default values for audio output configuration

**If Module = 'G' (Starting from v8.3.x)**

Audio Inputs Management:  
'0' = Automatic  
'1' = Manual  
Audio Outputs Management:  
'0' = Automatic  
'1' = Manual  
Dummy (10 bytes, must be 0) (**for future expansion**)::

Direction: RTE -> PC

Mode '<'  
Type: 'T'  
Sub-Type 'N'  
Data: See above

Data Description:

**Inputs:**

The input module selected the audio input to configure.  
XT1000 can have four different sources:

'01' = POD1 (audio digital)  
'02' = POD2 (audio digital)  
'03' = SPDIF/HD camera (exclusive: or from the current HD video input, or from SPDIF input)  
'04' = Analog (analog audio)

XT5000 can have 7 different sources:

'01' = POD1 (audio digital)  
'02' = POD2 (audio digital)  
'03' = Digital (optical connector)  
'04' = Analog audio input  
'05' = HD audio input  
'06' = USB camera audio input  
'07' = USB microphone audio input

The **Enable** parameter enables or disables the audio from that source.

The **Gain** increases or decreases the source volume.

The **Echo** parameter allows to choice if the echo canceller must cancel the audio source or not. It's useful to enable the canceller for those inputs that can capture remote signals, like a microphone.

The **Audio selection** parameter to choice if this input can be heard always or only when is selected the DVI input (this can be useful for example if the audio input comes from a PC). For SPDIF only you can choice to hear always SPDIF or HD, considering that only one of these can be selected at the same time.

The **Type** and **Mode** parameters are used only with the analog input to specify which kind of input has been connected (change automatically gain and power supply).

The **Ignore Mute** is used to send always this audio input to remote side also when the system is in Mute state

### Outputs:

The output module specifies how to configure audio outputs.

This command doesn't work for XT5000 starting from 8\_3\_X version due to a revision of management audio outputs. Instead use **Tracks** and **Physical** output modules.

XT1000 can have four different outputs

HD1 (digital)  
HD2 (digital)  
SPDIF (digital)  
Analog

HD1 ,SPDIF and Analog output have the same output signal.

This command allows to choice which audio signals can be heard in each output

### Tracks:

The Tracks module specifies which audio streams can be sent on output stream.

XT5000 can have two output streams, called Track1 and Track2.

Track1 is always used as room amplification.

### Physical Output:

The Physical Output module choices which output track can be sent to each physical outputs.

XT5000 can have six outputs:

HD1 monitor  
HD2 monitor (it never be used as room amplification)  
Analog output  
Digital output (optical connector)  
USB headset

### Echo canceller:

**Automatic Gain Control** (AGC) can be enabled/disabled by selecting '1' or '0'

**Noise Reduction** can be enabled/disabled by selecting '1' or '0'

**Audio delay automatic estimation** enable the automatic estimation of monitor audio delay and applies this delay to improve echo canceller performance.

**Apply delay value** applies only the last delay calculated, but stops its computation.

### Load default values

Leads back the system again to the factory default values for the audio inputs or outputs configuration.

### General

This module allows to activate or not some automatism on Inputs or Outputs like the mute of HD1 monitor when USB headset is plugged in the system.

---

## 3.21 Terminal presentation configuration (TD)

This message is sent by PC to request storing/reading of presentation parameters  
This message is sent by RTE as reply to a reading request.

**WARNING : Starting from v3.x**

Direction: PC -> RTE

Mode '8' / '?'  
Type: 'T'  
Sub-Type 'D'  
Data: Types of parameter:  
          'L' = Presentation Mode configuration  
          'D' = Dual video configuration

### Parameter type 'L'

Local presentation mode:  
0 = Manual  
1 = Automatic

Show warnings (local presentation mode) (**Starting from v8.3.2.x no longer used**):  
0 = No  
1 = Yes

Keep aspect ratio:  
0 = No  
1 = Yes

### Parameter type 'D'

Use manual DualVideo bandwidth:  
0 = No  
1 = yes

Dualvideo/live bandwidth (2 bytes):  
10 = 10% for dual video  
20 = 20% for dual video  
30 = 30% for dual video  
40 = 40% for dual video  
50 = 50% for dual video  
60 = 60% for dual video  
70 = 70% for dual video  
80 = 80% for dual video  
90 = 90% for dual video

Direction: RTE -> PC

Mode '<'  
Type: 'T'  
Sub-Type 'D'  
Data: See above

---

## 3.22 Telepresence configuration (TP)

This message is sent by PC to request reading of presentation parameters

This message is sent by RTE as reply to a reading request.

**WARNING : Starting from v3.2.x**

Direction: PC -> RTE

Mode: '?'

Type: 'T'

Sub-Type: 'P'

Data: Types of parameter:  
'G' = Generic Configuration

**If parameter type 'G'**

None

Direction: RTE -> PC

Mode: '<'

Type: 'T'

Sub-Type: 'P'

Data: Types of parameter:  
'G' = Generic Configuration

**If parameter type 'G'**

Enabled:

'0' = Telepresence is disabled

'1' = Telepresence is enabled

Type:

'0' = Unknown

'1' = System is primary (central)

'2' = System is auxiliary left

'3' = System is auxiliary right

MonitorSize:

'1' = Monitor 50 inch

'2' = Monitor 55 inch

'3' = Monitor 60 inch

'4' = Monitor 65 inch

Number of chair's raw:

'1' = One raw

'2' = Two raw

Primary IP address:

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Auxiliary left IP address:

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Auxiliary right IP address:

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Data Description:

**IP Address:**

In the primary system , the primary IP address is always 0

In the auxiliary system the two auxiliary IP address are always 0

---

## 3.23 Recording Settings (TJ)

This message is sent by PC to request storing/reading recording parameters

This message is sent by RTE to reply to a reading request.

**WARNING: Starting from v3.2.x**

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'T'

Sub-Type: 'J'

Data: Type:  
C = Configuration

**If command type 'C'**

Resolution (2 bytes):

'01' = H.264,1080p

'02' = H.264,720p

'03' = H.264,640x480

'04' = H.264,w360p

Bit rate (2 bytes):

'01' = 384

'02' = 448

'03' = 512

'04' = 768

'05' = 896

'06' = 1024

'07' = 1152

'08' = 1280

'09' = 1408

'10' = 1472

'11' = 1536

'12' = 1728

'13' = 1920

'14' = 2048

'15' = 2560

'16' = 3072

'17' = 3584

'18' = 4096

'19' = 4608

'20' = 5120

'21' = 5632

'22' = 6144

Audio Alert:

'0' = No

'1' = Yes

Location (**Starting from v8.3.2.x**):

'1' = No Recording

'2' = Automatic

'3' = USB storage

'4' = Scopia® Recording Server

Ignore Mute on Playback (**Starting from v8.3.2.x**) :

'0' = No

'1' = Yes

Dummy (8 bytes, must be 0)

Direction: RTE -> PC

Mode: '<'

Type: 'T'

Sub-Type: 'J'

Data: See above

---

## 3.24 Terminal Error Indication (TE)

This message is sent by RTE to notify an error on the received message:

Direction: RTE -> PC

Mode: '<'  
Type: 'T'  
Sub-Type: 'E'  
Data: Message Type  
Sub-type  
Error:  
    '1' = Bad parameter  
    '2' = Unknown message  
    '3' = wrong message length  
    '4' = Bad mode  
    '5' = Unable to execute command  
Sub-code  
    If Unable to execute command  
        '0' = system timeout  
        '1' = system busy  
    If Bad parameter  
        Index number of wrong parameter

### Data Description:

Example:

PC	----- AT[&TAF<cr> ----->	RTE	(Request the Full screen mode without the first parameter)
PC	←----- AT[<TETA12-----	RTE	(The first parameter of the message is wrong or missed)
PC	----- AT[&TAF1<cr> ----->	RTE	(Request the Full screen mode)
PC	←----- AT[<TETA50-----	RTE	(The command cannot be executed)

# 4 Network Configuration

Network configuration messages can be used to change and/or read the configuration stored in the terminal.

The <mode> & command can be used to modify the configuration, while the <mode> ? can be used to read the related values.

---

## 4.1 Network IP Configuration (NL)

This message is sent by PC to request storing/reading of some parameters about the IP Configuration.  
This message is sent by the RTE to reply to a reading request.

Direction: PC -> RTE

Mode ' & ' / ' ? '  
Type: ' N '  
Sub-Type ' L '  
Data: Automatic IP address:  
          ' 0 ' = No  
          ' 1 ' = Yes  
IP address:  
          xxx.xxx.xxx.xxx (fixed len = 15 chars)  
Subnet mask:  
          xxx.xxx.xxx.xxx (fixed len = 15 chars)  
Gateway IP address:  
          xxx.xxx.xxx.xxx (fixed len = 15 chars)

Direction: RTE -> PC

Mode '<'  
Type: ' N '  
Sub-Type ' L '  
Data: See above

Data Description:

**Automatic IP Address:**

Select Yes ("1") to get an IP address from a DHCP server; select No ("0") to assign a static IP address to the terminal.

Example: Static IP address, IP address 192.168.110.017, subnet mask 255.255.255.000, gateway IP address 192.168.110.001

PC	----- AT[?NL<cr> ----->	RTE (Network IP)
PC	<--- AT[<NL0192.168.110.017255.255.255.000192.168.110.001<cr> -----	RTE
PC	<----- OK<cr> -----	RTE

---

## 4.2 Network IP Configuration Extended (ND)



This message is sent by PC to request storing/reading of some parameters about the IP Configuration.  
This message is sent by the RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'N'

Sub-Type: 'D'

Data: Network type:

'1' = GLAN1 (fixed GLAN Network for XT1000)

'4' = GLAN2 (fixed 10/100 Lan Network for XT1000)

Command type:

'C' = Configuration

'M' = MacAddress (**only for read operation for Fixed networks**)

'T' = MTU size

'B' = Bandwidth (**Starting from v8.3.2.x no longer used, Use A instead**)

'A' = Bandwidth Extended (**Starting from v8.3.2.x**)

'S' = Speed/Duplex

'X' = 802.1x Parameters (**Starting from v8.3.2.x**)

'U' = 802.1x User (**Starting from v8.3.2.x**)

'P' = 802.1x Password (**Starting from v8.3.2.x**)

'V' = VLAN (**Starting from v8.3.2.x**)

#### If command type 'C'

Automatic IP address:

'0' = No

'1' = Yes

IP address:

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Subnet mask:

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Gateway IP address:

xxx.xxx.xxx.xxx (fixed len = 15 chars)

DNS IP address:

xxx.xxx.xxx.xxx (fixed len = 15 chars)

#### If command type 'M'

MAC-address:

xx : xx : xx : xx : xx : xx (fixed len = 17 chars)

#### If command type 'T'

MTU size (four bytes):

'1280' ..... '1500'

#### If command type 'B'

Enabled:

'0' = No

'1' = Yes

Max bandwidth Rx (KB) (fixed four bytes)

Max bandwidth Tx (KB) (fixed four bytes)

#### If command type 'A' (**Starting from v8.3.2.x**)

Enabled:

'0' = No

'1' = Yes

Max bandwidth Rx (KB) (fixed ten bytes)

Max bandwidth Tx (KB) (fixed ten bytes)

**If command type 'S'**

Speed/Duplex Mode:

'0' = Automatic

'1' = Manual

'2' = Auto – up to 100/Full (**Starting from v8.3.2.x**)'3' = Auto – up to 100/Half (**Starting from v8.3.2.x**)'4' = Auto – up to 10/Full (**Starting from v8.3.2.x**)'5' = Auto – up to 10/Half (**Starting from v8.3.2.x**)

Speed:

'1' = 10 Mbps

'2' = 100 Mbps

'3' = 1000 Mbps ( valid only for XT1000 )

Duplex Mode

'1' = Half

'2' = Full

**If command type 'X' (**Starting from v8.3.2.x**)**

Enable:

'0' = No

'1' = Yes

Dummy (20 bytes, must be 0)

**If command type 'U' (**Starting from v8.3.2.x**)**

802.1x User Name (max 64 ASCII chars)

**If command type 'P' (**Starting from v8.3.2.x**)**

802.1x Password (max 64 ASCII chars)

**If command type 'V' (**Starting from v8.3.2.x**)**

Enable:

'0' = No

'1' = Yes

ID (fixed four bytes):

'0001' ..... '4094'

Dummy (10 bytes, must be 0)

Direction: RTE -&gt; PC

Mode '&lt;'

Type: 'N'

Sub-Type: 'D'

Data: See above

Data Description:**Automatic IP Address:**

Select Yes ("1") to get an IP address from a DHCP server; select No ("0") to assign a static IP address to the terminal.

---

## 4.3 Protocol SIP Configuration (NM)

This message is sent by PC to request storing/reading of some parameters about the SIP Configuration.  
This message is sent by the RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'N'

Sub-Type: 'M'

Data: Command Type:

'G' = Generic Command

'N' = First part User

'F' = Second part User

'U' = First part Authentication Name (**Starting from v3.1.x**)

'V' = Second part Authentication Name (**Starting from v3.1.x**)

'P' = Password

'R' = Server 1 parameters (deprecated starting from **v8.3.2.x** version, use **O** command)

'X' = Server 1 parameters (deprecated starting from **v8.3.2.x** version, use **O** command)

'A' = Server 1 DNS name (deprecated starting from **v8.3.2.x** version, use **M** command)

'C' = First part Server 1 DNS name (deprecated starting from **v8.3.2.x** version, use **M** command)

'D' = Second part Server 1 DNS name (deprecated starting from **v8.3.2.x** version, use **Q** command)

'S' = Server Type (no longer used from **v3.1.x** version)

'I' = Index of type of server selected (**Starting from v3.1.x**)

'H' = Number of type of servers (**only in get mode**) (**Starting from v3.1.x**)

'L' = Server type name (**only in get mode**) (**Starting from v3.1.x**)

'T' = SIP TLS configuration (**Starting from v8.3.2.x**)

'O' = SIP Server configuration (**Starting from v8.3.2.x**)

'M' = First part Server DNS name (**Starting from v8.3.2.x**)

'Q' = Second part Server DNS name (**Starting from v8.3.2.x**)

'W' = Save

#### If command type 'G'

Transport TypeUse UDP:

'0' = TCP

'1' = UDP

'2' = TLS (**Starting from v8.3.2.x**)

UDP Listening Port (ASCII digit of fixed len = 5)

TCP Listening Port (ASCII digit of fixed len = 5)

#### If command type 'N'

First part User (max 64 ASCII chars)

#### If command type 'F'

Second part User (max 64 ASCII chars)

#### If command type 'U'

First part Authentication name (max 64 ASCII chars)

#### If command type 'V'

Second part Authentication name (max 64 ASCII chars)

#### If command type 'P'

Password (max 30 ASCII chars)

#### If command type 'R' (deprecated starting from **v8.3.2.x** version, use **O** command)

Use Server1:

'0' = no

'1' = Yes

Dummy (20 bytes, must be 0)

#### If command type 'X' (deprecated starting from **v8.3.2.x** version, use **O** command)

Use Server1:

'0' = no

'1' = Yes

Dummy (20 bytes, must be 0)

**If command type 'A'** (deprecated starting from **v8.3.2.x** version, use **M** command)

Server 1 DNS name (max 32 ASCII chars)

**If command type 'C'** (deprecated starting from **v8.3.2.x** version, use **M** command)

First part Server 1 DNS name (max 64 ASCII chars)

**If command type 'D'** (deprecated starting from **v8.3.2.x** version, use **Q** command)

Second part Server 1 DNS name (max 64 ASCII chars) (**This is used only if the Proxy name length is larger than 64**)

**If command type 'S' (no longer used)**

ServerType:

'00' = Automatic

'01' = Cisco UCM

'02' = Microsoft LCS

'03' = Microsoft OCS

'04' = Alcatel

'05' = Nortel

'06' = Siemens

'07' = Avaya

'08' = Asterisk

'09' = SER

'10' = Telio

'11' = Mns

'12' = BroadSoft

'13' = Minimal options

'14' = All options

**If command type 'I'**

Index of type of server selected (3 bytes )

'000' ....' Number of type of servers - 1'

**If command type 'H'**

Number of type of servers (3 bytes) (**not writable**)

**If command type 'L' (not writable, only with get command)**

Index of type of server (3 bytes)

'000' ....' Number of type of servers - 1'

Name of type of server (max 64 ASCII chars)

**If command type 'T'**

Use TLS:

'0' = no

'1' = Yes

TLS Listening Port (ASCII digit of fixed len = 5)

Verify certificate:

'0' = no

'1' = Yes

Transport Outbound BFCP: (**Starting from v8.3.2.212**)

'1' = TCP preferred

'2' = UDP preferred

'3' = TCP only

'4' = UDP only

Dummy (19 bytes, must be 0) (**for future expansion**):

**If command type 'O'**

Server Index (3 bytes):

'001'.. '003'

Use Server:

'0' = no

'1' = Yes

Dummy (20 bytes, must be 0) (**for future expansion**)**If command type 'M'**

Server Index (3 bytes):

'001'.. '003'

First part Server DNS name (max 64 ASCII chars)

**If command type 'Q'**

Server Index (3 bytes):

'001'.. '003'

Second part Server DNS name (max 64 ASCII chars) (**This is used only if the Server name length is larger than 64**)**If command type 'W' (Save data) :**Attention: without this command no one of previous commands will be saved

Direction: RTE -&gt; PC

Mode '&lt;'

Type: 'N'

Sub-Type 'M'

Data: See above

Data Description:**Server 1 parameters**

Starting from version 8\_3\_1\_X SIP configuration has been changed to manage more than one SIP server (for redundancy) and to simplify the procedure system removed Proxy and Registrar and inserted the unique Server concept. To maintain compatibility with old AT commands clients, Proxy and Registrar configuration is assumed to be the same as the new Server 1. These commands are deprecated : use **O** command.

**First part Server 1 DNS name**

To maintain compatibility with old AT commands clients, Proxy First part name or Registrar name are assumed to be the same as the new Server 1 first part DNS name. These commands are deprecated : use **M** command.

**Second part Server 1 DNS name**

To maintain compatibility with old AT commands clients, Proxy Second part name is assumed to be the same as the new Server 1 second part DNS name (to be used if Server1 DNS name is longer than 64 characters). This command is deprecated : use **Q** command.

**SIP Server configuration**

Index actually can be only '001', or '002' or '003'

**First part Server DNS name**

Index actually can be only '001', or '002' or '003'

**Second part Server DNS name**

Index actually can be only '001', or '002' or '003'

---

## 4.4 Network NAT & Dynamic Ports Setting (NT)

This message is sent by PC to request storing/reading of some parameters about the NAT (Network Address Translation) and Dynamic ports configuration.

This message is sent by the RTE to reply to a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'N'

Sub-Type: 'T'

Data: Command Type

'N' = NAT parameters

'S' = NAT server address

'K' = NAT parameters extended (**Starting from v8.3.2.x**)

'A' = Public address

'P' = Dynamic Ports

'T' = Refresh time (**Starting from v8.3.2.x**)

### If command type 'N'

NAT enable:

'0' = No

'1' = Yes

NAT Type:

'1' = Manual

'2' = HTTP autodiscovery

'3' = STUN autodiscovery

NAT autolearning :

'0' = No

'1' = Yes

Server port (5 bytes)

Refresh time (2 bytes) in seconds

### If command type 'S'

NAT server name (max 30 ASCII chars):

### If command type 'K' (**Starting from v8.3.2.x**)

Keep Alive:

'0' = No

'1' = Yes

Dummy (20 bytes, must be 0)

### If command type 'A'

Public IP address (max 15 ASCII chars):

### If command type 'P'

Auto Detect TCP port

'0' = No

'1' = Yes

TCP Port init number (ASCII digit of fixed len = 5)

Auto Detect UDP port

'0' = No

'1' = Yes

UDP Port init number (ASCII digit of fixed len = 5)

### If command type 'T'

Refresh time (4 bytes) in seconds

'0000' .... '9999'

Dummy (10 bytes, must be 0) (**for future expansion**)

Direction: RTE -> PC

Mode '<'  
Type: 'N'  
Sub-Type 'T'  
Data: See above

Data Description:

**NAT enable:**

Select Yes ("1") if a NAT (Network Address Translation) is used to go outside the local network.

**Nat server name:**

IP address of NAT device.

**Public IP Address:**

IP address to be used in an H.323 connection for calls outside local network.

**TCP Port init:**

Init TCP port value used in an H.323 connection for calls outside local network.

**UDP Port init:**

Init UDP port value used in an H.323 connection for calls outside local network.

---

## 4.5 Network LAN Settings (NB)

This message is sent by PC to request storing/reading generic network parameters  
It is sent by RTE to answer a reading request.

**WARNING: Starting from v8.3.2.x**

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'N'  
Sub-Type 'B'  
Data: Item:  
          'G' = Generic configuration

**If item 'G':**

Use IPV6:

'0' = No

'1' = Yes

Priority:

'1' = GLAN1

'2' = GLAN2

Dummy (10 bytes, must be 0) (**for future expansion**)

Direction: RTE -> PC

Mode            '<'  
Type:           'N'  
Sub-Type       'B'  
Data:           See above

Data Description:

---

## 4.6 Network Protocols Setting (NA)

This message is sent by PC to request storing/reading generic protocols parameters  
It is sent by RTE to answer a reading request.

**WARNING: Starting from v8.3.2.x**

Direction:      PC -> RTE

Mode            '&' / '?'  
Type:           'N'  
Sub-Type       'A'  
Data:           Item:  
                 'G' = Generic configuration

**If item 'G':**

Default Protocol:

'0' = Automatic

'1' = SIP

'2' = H323

'3' = ISDN

Use SIP:

'0' = No

'1' = Yes

Use H.323:

'0' = No

'1' = Yes

Use ISDN:

'0' = No

'1' = Yes

Dummy (10 bytes, must be 0 ) (**for future expansion**)

Direction:      RTE -> PC

Mode            '<'  
Type:           'N'  
Sub-Type       'A'  
Data:           See above

Data Description:

---

## 4.7 Network LAN H.323 Setting (NH)



This message is sent by PC to request storing/reading of some H.323 configuration parameters  
It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'N'

Sub-Type: 'H'

Data: Item:

'A' = First part of H.323 name  
'H' = Second part of H.323 name  
'B' = First part of H.323 number  
'I' = Second part of H.323 number  
'G' = Gatekeeper  
'C' = Refuse calls by IP address  
'D' = Advanced parameters  
'W' = Save All

**If item A (First part H.323 name) :**

First part name string (max 64 chars)

**If item H (Second part H.323 name) :**

Second part name string (max 64 chars)

**If item B (First part H.323 number) :**

First part number value (max 64 digits)

**If item I (Second part H.323 number) :**

Second part number value (max 64 digits)

**If item G (Gatekeeper) :**

Use Gatekeeper:

'0' = No

'1' = Yes

Automatic Gatekeeper IP address:

'0' = No

'1' = Yes

Gatekeeper IP address:

xxx.xxx.xxx.xxx (fixed len = 15 chars)

**If item C (Refuse calls by IP address) :**

Refuse calls:

'0' = No

'1' = Yes

**If item D (Advanced parameters) :**

Use H.460:

'0' = No

'1' = Yes

Automatic registration:

'0' = No

'1' = Yes

Registration expiration time in seconds (3 bytes):

'000' ... '300'

Registration interval time in seconds (3 bytes):

'10' ... '30'

**If item W (Write data) :**

Attention: without this command no one of previous commands will be saved

Direction: RTE -> PC

Mode '<'  
Type: 'N'  
Sub-Type 'H'  
Data: See above

#### Data Description:

##### **Name H.323**

Name used by the terminal to register to a gatekeeper

##### **Number H.323**

Identification number used by the terminal to register to a gatekeeper

##### **Gatekeeper**

A gatekeeper is a very useful, but optional, component of an H.323-enabled network. Gatekeepers are needed to ensure reliable, commercially feasible communications. A gatekeeper is often referred to as the brain of the H.323 enabled network because of the central management and control services it provides. When a gatekeeper exists all endpoints (terminals, gateways, and MCUs) must be registered with it. Registered endpoints' control messages are routed through the gatekeeper. The gatekeeper and the endpoints it administers form a management zone.

A gatekeeper provides several services to all endpoints in its zone. These services include:

- **Address translation:** A gatekeeper maintains a database for translation between aliases, such as international phone numbers, and network addresses.
- **Admission and access control of endpoints:** This control can be based on bandwidth availability, limitations on the number of simultaneous H.323 calls, or the registration privileges of endpoints.
- **Bandwidth management:** Network administrators can manage bandwidth by specifying limitations on the number of simultaneous calls and by limiting authorization of specific terminals to place calls at specified times.
- **Routing capability:** A gatekeeper can route all calls originating or terminating in its zone. This capability provides numerous advantages. First, accounting information of calls can be maintained for billing and security purposes. Second, a gatekeeper can re-route a call to an appropriate gateway based on bandwidth availability. Third, re-routing can be used to develop advanced services such as mobile addressing, call forwarding, and voice mail diversion.

Example:

```
PC ----- AT[?NH<cr> -----> RTE
PC <----- AT[<NHATerminalName<cr> ----- RTE (Name H.323: TerminalName)
PC <----- AT[<NHB1234<cr> ----- RTE (Number H.323: 1234)
PC <---- AT[<NHG00000.000.000.000<cr> ----- RTE (Gatekeeper: No)
PC <----- OK<cr> ----- RTE
```

---

## 4.8 Network Gatekeeper Authentication Setting (NJ)

This message is sent by PC to request storing/reading gatekeeper authentication parameters  
It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'N'

Sub-Type        'J'  
Data:            Item:  
                 'A' = Authentication parameters  
                 'U' = Authentication User name  
                 'P' = Authentication Password  
                 'W' = Save All

**If item A (Authentication parameters) :**

Enable:  
                 '0' = No  
                 '1' = Yes  
Mode:  
                 '00' = Automatic  
                 '01' = H.235 D  
                 '02' = MD5  
Gatekeeper ID (max 30 ASCII chars)

**If item U (Authentication user name) :**

UserName (max 30 ASCII chars)

**If item P (Authentication password) :**

UserName (max 30 ASCII chars)

**If item W (Write data) :**

Attention: without this command no one of previous commands will be saved

Direction:      RTE -> PC

Mode            '<'  
Type:           'N'  
Sub-Type       'J'  
Data:           See above

Data Description:

---

## 4.9 Network SNMP Management (NS)

This message is sent by PC to request storing/reading of some SNMP Management configuration parameters  
It is sent by RTE to answer a reading request.

Direction:      PC -> RTE

Mode            '&' / '?'  
Type:           'N'  
Sub-Type       'S'  
Data:           Item:  
                 'A' = Generic configuration  
                 'N' = Administrator Name  
                 'L' = Location  
                 'R' = Read configuration parameters  
                 'S' = Write configuration parameters  
                 'C' = Community Read  
                 'D' = Community Write  
                 'W' = Save All

**If item A (IP address) :**

SNMP Management:

'0' = No

'1' = Yes

Enable Traps:

'0' = No

'1' = Yes

Dummy (14 bytes, must be 0) (**for future expansion**)

**If item N :**

Administrator name (max 30 ASCII chars)

**If item L :**

Location (max 30 ASCII chars)

**If item R (Read Config parameters) :**

Enable all addresses:

'0' = No

'1' = Yes

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Address mask

xxx.xxx.xxx.xxx (fixed len = 15 chars)

**If item S (Save Config parameters) :**

Enable all addresses:

'0' = No

'1' = Yes

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Address mask

xxx.xxx.xxx.xxx (fixed len = 15 chars)

**If item C :**

Community Read (max 30 ASCII chars)

**If item D :**

Community Write (max 30 ASCII chars)

**If item W (Write data) :**

Attention: without this command no one of previous commands will be saved

Direction: RTE -> PC

Mode '<'

Type: 'N'

Sub-Type 'S'

Data: See above

Data Description:

**SNMP Active**

To enable SNMP (Simple Network Management Protocol) in the system.

**Administrator name**

The textual identification of the contact person for managed node

**Location**

The physical location of this node (e.g., "telephone closet, 3rd floor")

---

## 4.10 Network QoS Management (NQ)

This message is sent by PC to request storing/reading of some QoS Management configuration parameters  
It is sent by RTE to answer a reading request.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'N'

Sub-Type: 'Q'

Data: Item:

'G' = Generic configuration

'P' = Precedence/TOS parameters

'D' = DiffServe parameters

### If item G (Generic configuration) :

Use QoS:

'0' = No

'1' = Yes

Quality of service:

'1' = Precedence/TOS

'2' = DiffServe

### If item P (Precedence/TOS parameters) :

Audio TOS:

'1' = Normal

'2' = Minimize delay

'3' = Maximize Throughput

'4' = Maximize Reliability

'5' = Minimize Mon.Cost

Audio Precedence:

'0' = 0-Routine

'1' = 1-Priority

'2' = 2-Immediate

'3' = 3-Flash

'4' = 4-Flash Override

'5' = 5-CRITIC/ECP

'6' = 6-Internet Control

'7' = 7-Network Control

Video TOS:

'1' = Normal

'2' = Minimize delay

'3' = Maximize Throughput

'4' = Maximize Reliability

'5' = Minimize Mon.Cost

Video Precedence:

'0' = 0-Routine

'1' = 1-Priority

'2' = 2-Immediate

'3' = 3-Flash

'4' = 4-Flash Override

'5' = 5-CRITIC/ECP

'6' = 6-Internet Control

'7' = 7-Network Control

Data TOS:

'1' = Normal  
'2' = Minimize delay  
'3' = Maximize Throughput  
'4' = Maximize Reliability  
'5' = Minimize Mon.Cost

Data Precedence:

'0' = 0-Routine  
'1' = 1-Priority  
'2' = 2-Immediate  
'3' = 3-Flash  
'4' = 4-Flash Override  
'5' = 5-CRITIC/ECP  
'6' = 6-Internet Control  
'7' = 7-Network Control

Signal TOS:

'1' = Normal  
'2' = Minimize delay  
'3' = Maximize Throughput  
'4' = Maximize Reliability  
'5' = Minimize Mon.Cost

Signal Precedence:

'0' = 0-Routine  
'1' = 1-Priority  
'2' = 2-Immediate  
'3' = 3-Flash  
'4' = 4-Flash Override  
'5' = 5-CRITIC/ECP  
'6' = 6-Internet Control  
'7' = 7-Network Control

**If item D (DiffServe parameters):**

Audio DiffServe value (2 bytes) : "00"...63"  
Video DiffServe value (2 bytes) : "00"...63"  
Data DiffServe value (2 bytes) : "00"...63"  
Signal DiffServe value (2 bytes) : "00"...63"

Direction: RTE -> PC

Mode '<'  
Type: 'N'  
Sub-Type 'Q'  
Data: See above

Data Description:

---

## 4.11 Network ISDN Configuration (NO)

This message is sent by PC to request storing/reading of some ISDN configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v3.x**

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'N'  
Sub-Type 'O'

Data:           Item:

'G' = General  
 'S' = Service configuration  
 'Z' = Service number for all rates in automatic mode  
 'A' = Service number for 64k rate  
 'B' = Service number for 128k rate  
 'C' = Service number for 192k rate  
 'D' = Service number for 256k rate  
 'E' = Service number for 320k rate  
 'F' = Service number for 384k rate  
 'H' = Service number for 448k rate  
 'I' = Service number for 512k rate  
 'L' = Service number for 768k rate  
 'N' = Service number for 1472k rate  
 'O' = Service number for 1536k rate  
 'P' = Service number for 1728k rate  
 'Q' = Service number for 1920k rate

**If item G (General) :**

Enable:  
     '0' = No  
     '1' = Yes  
 Gateway IP address:  
     xxx.xxx.xxx.xxx                   (fixed len = 15 chars)

**If item S (Service configuration) :**

Service mode:  
     '0' = Manual  
     '1' = Automatic

**If item Z, A, B, C, D, E, F, H, I, L, N, O, P, Q (Service number) :**

Service number (max 32 ASCII chars)

Direction:       RTE -> PC

Mode            '<  
 Type:           'N'  
 Sub-Type        '0'  
 Data:           See above

Data Description:

---

## 4.12 Predefined Party Configuration (NP)

This message is sent by PC to request storing/reading predefined party configuration parameters  
 It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.x**

Direction:       PC -> RTE

Mode            '&' / '?'  
 Type:           'N'  
 Sub-Type        'P'  
 Data:           Item:  
                 'G' = General

**If item G:**

Enable:

'0' = No

'1' = Yes

Protocol:

'1' = IP

'6' = SIP

'7' = ISDN

Number (max 32 ASCII chars):

Direction: RTE -> PC

Mode '<'

Type: 'N'

Sub-Type: 'P'

Data: See above

Data Description:

---

## 4.13 Network Web Management (NK)

This message is sent by PC to request storing/reading of some Web Management configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.x**

Direction: PC -> RTE

Mode '&' / '?'

Type: 'N'

Sub-Type: 'K'

Data: Item:

G: Generic command

A: Address command

B: Extended parameters command

S: Password (**Only in write mode by SSH interface**) (**Starting from v8.3.2.5xx**)

**If Item G (Generic command):**

Web Management:

'0' = No

'1' = Yes

Disconnection due to inactivity:

'0' = Never

'1' = 5 minutes

'2' = 10 minutes

'3' = 15 minutes

'4' = 30 minutes

HTTPS:

'0' = No

'1' = Yes

**If Item A (Address command):**

Enable all addresses:

'0' = No



'1' = Yes  
Address  
                  xxx.xxx.xxx.xxx                  (fixed len = 15 chars)  
Sub-net mask  
                  xxx.xxx.xxx.xxx                  (fixed len = 15 chars)

**If Item B (Extended parameters command):**

Enable login attempts:  
                  '0' = No  
                  '1' = Yes  
Login denied time:  
                  '1' = 30 minutes  
                  '2' = 1 hour  
                  '3' = 2 hours  
                  '4' = 4 hours  
Enable download directory password: (**Starting from v8.3.2.5xx**)  
                  '1' = Yes  
                  '2' = No  
Dummy (9 bytes, must be 0) (**for future expansion**)

**If Item S (Password) (only in write mode by SSH interface): (**Starting from v8.3.2.5xx**)**

Password (max 30 ASCII chars)

Direction: RTE -> PC

Mode              '<'  
Type:              'N'  
Sub-Type          'K'  
Data:              See above

Data Description:

**Use Web**

System management from Web can be enabled ("1") or disabled ("0")

**IP Address**

All terminals can have access to the system using a Web Browser; it is possible to enable only a set of IP addresses to access the Web server.

---

## 4.14 Network Error Indication (NE)

RTE sends this message to show an error on the received message:

Direction: RTE -> PC

Mode              '<'  
Type:              'N'  
Sub-Type          'E'  
Data:              Message Type  
                    Sub-type  
                    Error:  
                    '1' = Bad parameter  
                    '2' = Unknown message  
                    '3' = wrong message length  
                    '4' = Bad mode

'5' = Unable to execute command  
Sub-code  
    If Unable to execute command  
        '0' = system timeout  
        '1' = system busy  
    If Bad parameter  
        Index number of wrong parameter

# 5 Remote access Configuration

Terminal configuration messages can be used to change and/or read the configuration stored in the terminal.

The <mode> & command can be used to modify the configuration, while the <mode> ? can be used to read the related values.

---

## 5.1 Web Video Configuration (RW)

This message is sent by PC to request storing/reading of some Web Video configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.x**

Direction: PC -> RTE

Mode ' & ' / ' ? '

Type: ' R '

Sub-Type: ' W '

Data: Item:

G: Generic command

A: Address command

**If Item G (Generic command):**

WEB video management:

' 0 ' = Disable

' 1 ' = Enable

Dummy (10 bytes, must be 0) (for future expansion)

**If Item A (Address command):**

Enable all IP addresses:

' 0 ' = No

' 1 ' = Yes

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Subnet mask

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Direction: RTE -> PC

Mode ' < '

Type: ' R '

Sub-Type: ' W '

Data: See above

Data Description:

---

## 5.2 Download Configuration (RD)

This message is sent by PC to request storing/reading of some Download configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.x**

Direction: PC -> RTE

Mode '8' / '?'

Type: 'R'

Sub-Type: 'D'

Data: Item:

G: Generic command

A: Address command

### If Item G (Generic command):

Download management:

'0' = Disable

'1' = Enable

Dummy (10 bytes, must be 0) (for future expansion)

### If Item A (Address command):

Enable all IP addresses:

'0' = No

'1' = Yes

Address

xxx.xxx.xxx.xxx

(fixed len = 15 chars)

Subnet mask

xxx.xxx.xxx.xxx

(fixed len = 15 chars)

Direction: RTE -> PC

Mode '<'

Type: 'R'

Sub-Type: 'D'

Data: See above

Data Description:

---

## 5.3 Netlog Configuration (RN)

This message is sent by PC to request storing/reading of some Netlog configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.x**

Direction: PC -> RTE

Mode '8' / '?'

Type: 'R'

Sub-Type: 'N'

Data: Item:

G: Generic command

**If Item G (Generic command):**

Enabled:

'0' = Disable

'1' = Enable

FTP enabled:

'0' = Disable

'1' = Enable

Dummy (10 bytes, must be 0) (**for future expansion**)

Direction: RTE -> PC

Mode '<'

Type: 'R'

Sub-Type 'N'

Data: See above

Data Description:

---

## 5.4 Audio Analyzer Configuration (RA)

This message is sent by PC to request storing/reading of some Audio analyzer configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.x**

Direction: PC -> RTE

Mode '&' / '?'

Type: 'R'

Sub-Type 'A'

Data: Item:

G: Generic command

**If Item G (Generic command):**

Enabled:

'0' = Disable

'1' = Enable

Automatic:

'0' = Disable

'1' = Enable

Dummy (10 bytes, must be 0) (**for future expansion**)

Direction: RTE -> PC

Mode '<'

Type: 'R'

Sub-Type 'A'

Data: See above

Data Description:

---

## 5.5 Scopia® Management Configuration (RS)

This message is sent by PC to request storing/reading of some Scopia® management configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.x**

Direction: PC -> RTE

Mode ' & ' / ' ? '

Type: ' R '

Sub-Type: ' S '

Data: Item:

G: Generic command

**If Item G (Generic command):**

Automatic IP Address:

' 0 ' = No

' 1 ' = Yes

IP Address:

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Dummy (10 bytes, must be 0) (**for future expansion**)

Direction: RTE -> PC

Mode ' < '

Type: ' R '

Sub-Type: ' S '

Data: See above

Data Description:

---

## 5.6 Certificate Configuration (RC)

This message is sent by PC to request storing/reading of some Certificate configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.x**

Direction: PC -> RTE

Mode ' & ' / ' ? '

Type: ' R '

Sub-Type: ' C '

Data: Item:

G: Generic command

**If Item G (Generic command):**

Key Length:

' 1 ' = High Security

' 2 ' = Very High Security

Dummy (10 bytes, must be 0) (**for future expansion**)

Direction: RTE -> PC

Mode            '<'  
Type:           'R'  
Sub-Type       'C'  
Data:           See above

Data Description:

---

## 5.7 Screen link /Mobile link Configuration (RB)

This message is sent by PC to request storing/reading of some Screen link//Mobile link configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.x**

Direction:      PC -> RTE

Mode            '&' / '?'  
Type:           'R'  
Sub-Type       'B'  
Data:           Item:  
                 G: Generic command  
                 A: Address command

**If Item G (Generic command):**

Mode:  
         '0' = Disable  
         '1' = Enabled - No PIN  
         '2' = Enabled - Ask PIN (manual paring)  
         '3' = Enabled - Ask PIN (always)  
Dummy (10 bytes, must be 0) (**for future expansion**)

**If Item A (Address command):**

Enable all IP addresses:  
         '0' = No  
         '1' = Yes  
Address  
         xxx.xxx.xxx.xxx            (fixed len = 15 chars)  
Subnet mask  
         xxx.xxx.xxx.xxx            (fixed len = 15 chars)

Direction:      RTE -> PC

Mode            '<'  
Type:           'R'  
Sub-Type       'B'  
Data:           See above

Data Description:

---

## 5.8 SSH Configuration (RH)

This message is sent by PC to request storing/reading of some SSH configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.5xx**

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'R'

Sub-Type: 'H'

Data: Item:

G: Generic command

P: Password command (**Only in write mode by SSH interface**)

### If Item G (Generic command):

Mode:

'0' = Disable

Dummy (10 bytes, must be 0) (**for future expansion**)

### If Item P (Password command) (Only in write mode by SSH interface):

Password (max 30 ASCII chars)

Direction: RTE -> PC

Mode: '<'

Type: 'R'

Sub-Type: 'H'

Data: See above

Data Description:

---

## 5.9 Telnet Configuration (RT)

This message is sent by PC to request storing/reading of some Telnet configuration parameters  
It is sent by RTE to answer a reading request.

**WARNING : Starting from v8.3.2.5xx**

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'R'

Sub-Type: 'T'

Data: Item:

G: Generic command

A: Address command

P: Password command (**Only in write mode by SSH interface**)

### If Item G (Generic command):

Telnet management:

'0' = Disable

'1' = Enable



Dummy (10 bytes, must be 0) (**for future expansion**)

**If Item A (Address command):**

Enable all IP addresses:

'0' = No

'1' = Yes

Address

xxx.xxx.xxx.xxx (fixed len = 15 chars)

Subnet mask

xxx.xxx.xxx.xxx (fixed len = 15 chars)

**If Item P (Only in write mode by SSH interface):**

Password (max 30 ASCII chars)

Direction: RTE -> PC

Mode '<'

Type: 'R'

Sub-Type: 'T'

Data: See above

Data Description:

---

## 5.10 Remote Access Error Indication (RE)

RTE sends this message to show an error on the received message:

Direction: RTE -> PC

Mode '<'

Type: 'R'

Sub-Type: 'E'

Data: Message Type

Sub-type

Error:

'1' = Bad parameter

'2' = Unknown message

'3' = wrong message length

'4' = Bad mode

'5' = Unable to execute command

Sub-code

If Unable to execute command

'0' = system timeout

'1' = system busy

If Bad parameter

Index number of wrong parameter

# 6 Phone Directory Configuration

Phone directory configuration messages can be used to change and/or read the phone directory entries stored in the terminal or to access data stored in a remote LDAP server.

These messages can be used also to configure LDAP servers and to retrieve information about last calls.

The <mode> & command can be used to modify the configuration, while the <mode> ? can be used to read the related values.

---

## 6.1 File Descriptor (DF)

PC sends this message to ask for the max number of records that can be stored in the Phone Directory (General information) and how many records have already been stored

Direction: PC -> RTE

Mode '?'  
Type: 'D'  
Sub-Type 'F'  
Data: Request :  
          '0' = General information  
          'A' = Number of records

Direction: RTE -> PC

Mode '<'  
Type: 'D'  
Sub-Type 'F'  
Data: Request :  
      See above  
      **if ( request '0' )**  
          MaxRecord (3 bytes)  
          '000' ... '999'  
          NameSize (3 bytes)  
          '000' ... '999'  
          CompanyNameSize (3 bytes)  
          '000' ... '999'  
          NumberSize (3 bytes)  
          '000' ... '999'  
      **if ( request 'A' )**  
          NumRecord (3 bytes)  
          '000' ... '999'

Data Description:

**MaxRecord:**

Max number of record that can be stored in the Phone Directory

**NumRecord:**

Number of record already stored in the Phone Directory

**NameSize:**

Max number of characters in Name

**CompanyNameSize:**

Max number of characters in Company Name

**NumberSize:**

Max number of characters of Number fields.

---

## 6.2 Read Record with index (DR)

PC sends this message to ask for the i-th record stored.

Direction: PC -> RTE

Mode 'P'  
Type: 'D'  
Sub-Type 'R'  
Data: Type of Information:  
          'A' = information about stored record  
          Index (3 bytes):  
          '000'...'NumRecord-1'

Direction: RTE -> PC

Mode '<'  
Type: 'D'  
Sub-Type 'R'  
Data: Item:  
          '0' = General information  
          'N' = User Name  
          'C' = Company Name  
          'A' = Other Flags  
          '1' = 1<sup>st</sup> number  
          '2' = 2<sup>nd</sup> number  
          .....  
          '8' = 8<sup>th</sup> number

**if item "0" (General Information)**

Type of information:  
          'A' = information about stored record  
Index (3 bytes)  
          '000'...'NumRecord-1'  
Found:  
          '1' = Yes  
          '2' = No  
Trusted: **(Starting from v8.3.2.212)**  
          '0' = No  
          '1' = Yes  
Type of Call:  
          'L' = IP (LAN)  
          'S' = SIP  
          'G' = ISDN **(Starting from v3.x)**  
Dummy (1 byte, must be 0) **(for future expansion)**  
Additional numbers ('0'..'7')

**if item "N" (User Name)**

Name (NameSize of ASCII chars)

**if item “C” (Company Name)**

Company (CompanyNameSize of ASCII chars)

**if item “A” (Other Flags)**

Rate (2 bytes): **(Starting from v8.3.2.212**

'01' = 64  
'02' = 128  
'03' = 192  
'04' = 256  
'05' = 320  
'06' = 384  
'07' = 448  
'08' = 512  
'09' = 768  
'10' = 1152 (valid only for network IP and SIP)  
'11' = 1472  
'12' = 1536  
'13' = 1728  
'14' = 1920  
'15' = 2048 (valid only for network IP and SIP)  
'16' = 2560 (valid only for network IP and SIP)  
'17' = 3072 (valid only for network IP and SIP)  
'18' = 3584 (valid only for network IP and SIP)  
'19' = 4096 (valid only for network and SIP)  
'20' = 4608 (valid only for network and SIP)  
'21' = 5120 (valid only for network and SIP)  
'22' = 5632 (valid only for network and SIP)  
'23' = 6144 (valid only for network and SIP)  
'24' = 896 (valid only for network and SIP)  
'25' = 1024 (valid only for network and SIP)  
'26' = 1280 (valid only for network and SIP)  
'27' = 1408 (valid only for network and SIP)  
'28' = 6656 (valid only for network and SIP)  
'29' = 7168 (valid only for network IP and SIP)  
'30' = 7680 (valid only for network IP and SIP)  
'31' = 8128 (valid only for network IP and SIP)  
'32' = 8192 (valid only for network SIP)  
'33' = 10240 (valid only for network SIP)

Dummy (1 byte, must be 0) (for future expansion)

Dummy (1 byte, must be 0) (for future expansion)

**if item “1” (1^ number)**

Number1 (NumberSize of ASCII chars)

**If ( Additional numbers not equal '0' )**

Item = '2'

AddNumber1 (NumberSize of ASCII chars)

.....

item = '8'

AddNumber8 (NumberSize of ASCII chars)

Note : If Found = '2' the other parameters are left out.

Data Description:

**Index:**

Record index

**Found:**

Flag to indicate if a record was found.

**Name:**

User Name.

**CompanyName:**

Company Name.

**Type of Call:**

Selects the network interface hosting the call.

**Rate:**

Selects the desired rate for the call.

**Number1:**

Number used to make 1^ call

**AdditionalNumber:**

Additional numbers for the additional calls to do

**Example:**

```

PC      ----- AT[?DRA001<cr> -----> RTE      Read the 2^ record in the directory
PC      <----- AT[<DR0A00110L00<cr> ----- RTE      General: index 1, found, audio-video
                                                Call, net LAN, , PC      <-----
AT[<DRNrossi<cr> ----- RTE      User name: rossi
PC      <----- AT[<DRCXXYYZZ<cr> ----- RTE      Company Name: XXYYZZ
PC      <----- AT[<DR10390712189701<cr> ----- RTE      First Number: 0390712189701
PC      <----- OK<cr> ----- RTE

```

---

## 6.3 Read Record with index (DL)

PC sends this message to ask for the i-th record stored.

**WARNING: Starting from v3.2.1.x**

**WARNING:** this message is the same as DR message except before call it, is necessary to call almost one time the DFA message

Direction: PC -> RTE

Mode 'D'  
 Type: 'D'  
 Sub-Type 'L'  
 Data: Type of Information:  
       'A' = information about stored record  
       Index (3 bytes):  
       '000'... 'NumRecord-1'

Direction: RTE -> PC

Mode '<'  
 Type: 'D'  
 Sub-Type 'L'  
 Data: Item:  
       '0' = General information  
       'N' = User Name

'C' = Company Name  
'A' = Other Flags  
'1' = 1^ number  
'2' = 2^ number  
.....  
'8' = 8^ number

**if item "0" (General Information)**

Type of information:

'A' = information about stored record

Index (3 bytes)

'000' ... 'NumRecord-1'

Found:

'1' = Yes

'2' = No

Trusted: **(Starting from v8.3.2.212)**

'0' = No

'1' = Yes

Type of Call:

'L' = IP (LAN)

'S' = SIP

'G' = ISDN **(Starting from v3.x)**

Dummy (1 byte, must be 0) **(for future expansion)**

Additional numbers ('0'..'7')

**if item "N" (User Name)**

Name (NameSize of ASCII chars)

**if item "C" (Company Name)**

Company (CompanyNameSize of ASCII chars)

**if item "A" (Other Flags)**

Rate (2 bytes): **(Starting from v8.3.2.212)**

'01' = 64

'02' = 128

'03' = 192

'04' = 256

'05' = 320

'06' = 384

'07' = 448

'08' = 512

'09' = 768

'10' = 1152 **(valid only for network IP and SIP)**

'11' = 1472

'12' = 1536

'13' = 1728

'14' = 1920

'15' = 2048 **(valid only for network IP and SIP)**

'16' = 2560 **(valid only for network IP and SIP)**

'17' = 3072 **(valid only for network IP and SIP)**

'18' = 3584 **(valid only for network IP and SIP)**

'19' = 4096 **(valid only for network and SIP)**

'20' = 4608 **(valid only for network and SIP)**

'21' = 5120 **(valid only for network and SIP)**

'22' = 5632 **(valid only for network and SIP)**

'23' = 6144 **(valid only for network and SIP)**

'24' = 896 **(valid only for network and SIP)**

'25' = 1024 **(valid only for network and SIP)**

'26' = 1280 **(valid only for network and SIP)**

'27' = 1408 **(valid only for network and SIP)**

'28' = 6656 (valid only for network and SIP)  
 '29' = 7168 (valid only for network IP and SIP)  
 '30' = 7680 (valid only for network IP and SIP)  
 '31' = 8128 (valid only for network IP and SIP)  
 '32' = 8192 (valid only for network SIP)  
 '33' = 10240 (valid only for network SIP)  
 Dummy (1 byte, must be 0) (for future expansion)  
 Dummy (1 byte, must be 0) (for future expansion)

**if item "1" (1^ number)**

Number1 (NumberSize of ASCII chars)

**If ( Additional numbers not equal '0' )**

Item = '2'  
 AddNumber1 (NumberSize of ASCII chars)  
 .....  
 item = '8'  
 AddNumber8 (NumberSize of ASCII chars)

Note : If Found = '2' the other parameters are left out.

Data Description:

**Index:**

Record index

**Found:**

Flag to indicate if a record was found.

**Name:**

User Name.

**CompanyName:**

Company Name.

**Type of Call:**

Selects the network interface hosting the call.

**Rate:**

Selects the desired rate for the call.

**Number1:**

Number used to make 1^ call

**AdditionalNumber:**

Additional numbers for the additional calls to do

**Example:**

PC	----- AT[?DRA001<cr> ----->	RTE	Read the 2^ record in the directory
PC	←----- AT[<DR0A00110L00<cr> -----	RTE	General: index 1, found, audio-video
			Call, net LAN, , PC ←-----
	AT[<DRNrossi<cr> -----	RTE	User name: rossi
PC	←----- AT[<DRCXXYYZZ<cr> -----	RTE	Company Name: XXYYZZ
PC	←----- AT[<DR10390712189701<cr> ----	RTE	First Number: 0390712189701
PC	←----- OK<cr> -----	RTE	

---

## 6.4 Delete Record with index (DD)

PC sends this message to delete the i-th record stored in the required list.

Note: after the update the indexes list must be updated.

Direction: PC -> RTE

Mode ' & '

Type: ' D '

Sub-Type ' D '

Data: Type of Information:  
' A ' = information about stored record  
Index (3 bytes)  
' 000 ' ... ' NumRecord-1 '

### Data Description:

Example:

1) Delete with success

PC	----- AT[&DDA000<cr> ----->	RTE	Delete 1^ record on the directory
PC	←----- OK<cr> -----	RTE	Record deleted

2) Delete with error

PC	----- AT[&DDA000<cr> ----->	RTE	Delete 1^ record on the directory
PC	←----- AT[<DEDD50<cr> -----	RTE	Error: unable to execute command.

---

## 6.5 Insert New Record (DI)

PC sends this message to ask for a new record creation. Is not possible to modify an existing record; you need to delete it and then create it again.

Direction: PC -> RTE

Mode ' & '

Type: ' D '

Sub-Type ' I '

Data: Item:  
' 0 ' = General information  
' N ' = User Name  
' C ' = Company Name  
' A ' = Other Flags  
' 1 ' = 1^ number  
' 2 ' = 2^ number  
' 3 ' = 3^ number  
...  
' 8 ' = 8^ number  
' W ' = Save record

**if item "0" (General Information)**



Trusted: **(Starting from v8.3.2.212)**

'0' = No

'1' = Yes

Type of Call:

'L' = IP

'S' = SIP

'G' = ISDN **(Starting from v3.x)**

Additional numbers ('0'..'7')

**if item "N" (User Name)**

Name (NameSize of ASCII chars)

**if item "C" (Company Name)**

Company (CompanyNameSize of ASCII chars)

**if item "A" (Other Flags)**

Rate (2 bytes): **(Starting from v8.3.2.212)**

'01' = 64

'02' = 128

'03' = 192

'04' = 256

'05' = 320

'06' = 384

'07' = 448

'08' = 512

'09' = 768

'10' = 1152 **(valid only for network IP and SIP)**

'11' = 1472

'12' = 1536

'13' = 1728

'14' = 1920

'15' = 2048 **(valid only for network IP and SIP)**

'16' = 2560 **(valid only for network IP and SIP)**

'17' = 3072 **(valid only for network IP and SIP)**

'18' = 3584 **(valid only for network IP and SIP)**

'19' = 4096 **(valid only for network and SIP)**

'20' = 4608 **(valid only for network and SIP)**

'21' = 5120 **(valid only for network and SIP)**

'22' = 5632 **(valid only for network and SIP)**

'23' = 6144 **(valid only for network and SIP)**

'24' = 896 **(valid only for network and SIP)**

'25' = 1024 **(valid only for network and SIP)**

'26' = 1280 **(valid only for network and SIP)**

'27' = 1408 **(valid only for network and SIP)**

'28' = 6656 **(valid only for network and SIP)**

'29' = 7168 **(valid only for network IP and SIP)**

'30' = 7680 **(valid only for network IP and SIP)**

'31' = 8128 **(valid only for network IP and SIP)**

'32' = 8192 **(valid only for network SIP)**

'33' = 10240 **(valid only for network SIP)**

Dummy (1 byte, must be 0) **(for future expansion)**

Dummy (1 byte, must be 0) **(for future expansion)**

**if item "1" (1^ number)**

Number1 (NumberSize of ASCII chars)

**If ( Additional numbers not equal '0' )**

Item = '2'

AddNumber2 (NumberSize of ASCII chars)

Item = '3'

AddNumber3 (NumberSize of ASCII chars)

...

item = '8'

AddNumber8 (NumberSize of ASCII chars)

#### Data Description:

PC	----- AT[&DI00L00<cr> ----->	RTE	General: audio-video call, net LAN, , no additional numbers
PC	<----- OK<cr> -----<	RTE	
PC	----- AT[&DINrossi<cr> ----->	RTE	User name: rossi
PC	<----- OK<cr> -----<	RTE	
PC	----- AT[<DICXXYYZZ<cr> ----->	RTE	Company Name: XXYYZZ
PC	<----- OK<cr> -----<	RTE	
PC	----- AT[<DI10390712189701<cr> --->	RTE	First Number: 0390712189701
PC	<----- OK<cr> -----<	RTE	
PC	----- AT[&DIW<cr> ----->	RTE	Save record
PC	<----- OK<cr> -----<	RTE	

---

## 6.6 Recent Call General Descriptor (DQ)

PC sends this message to ask for the max and current number of records in recent calls list.

**WARNING:** Starting from v3.2.1.x

Direction: PC -> RTE

Mode: '?'

Type: 'D'

Sub-Type: 'Q'

Data: Request :

'0' = General information

'A' = Number of records

Direction: RTE -> PC

Mode: '<'

Type: 'D'

Sub-Type: 'Q'

Data: Request :

See above

if ( request '0' )

MaxRecord (3 bytes)

'000' ... '999'

if ( request 'A' )

NumRecord (3 bytes)

'000' ... '999'

#### Data Description:

##### **MaxRecord:**

Max number of record that can be present in the recent calls list

##### **NumRecord:**

Number of record a present in the recent calls list

---

## 6.7 Read Recent calls Info with index (DT)

PC sends this message to ask for the i-th recent call record stored.

**WARNING: Starting from v3.2.1.x**

Direction: PC -> RTE

Mode '?'  
Type: 'D'  
Sub-Type 'T'  
Data: Type of Information:  
          'A' = information about stored item  
          Index (3 bytes):  
              '000'...'NumRecord-1'

Direction: RTE -> PC

Mode '<'  
Type: 'D'  
Sub-Type 'T'  
Data: Item:  
          '0' = General information  
          'N' = First Part Name  
          'M' = Second Part Name  
          'A' = First Part Number  
          'B' = Second Part Number  
          'D' = Date  
          'H' = Time  
          'T' = Duration

**if item "0" (General Information)**

Index (3 bytes)  
          '000'...'NumRecord-1'

Found:  
          '1' = Yes  
          '2' = No

Network:  
          'L' = IP (LAN)  
          'S' = SIP  
          'I' = ISDN

Type:  
          'I' = Incoming  
          'O' = Outgoing  
          'M' = Missed

Speech :  
          '0' = No  
          '1' = Yes

Total calls (fixed 10 bytes):

**if item "N"**

First part name (max 64 ASCII chars)

**if item "M"**

Second part name (max 64 ASCII chars)

**if item "A"**

First part number (max 64 ASCII chars)  
**if item "B"**  
 Second part number (max 64 ASCII chars)  
**if item "D"**  
 Date (ASCII string)  
**if item "H"**  
 Time (ASCII string)  
**if item "T"**  
 Duration (ASCII string)

Data Description:

**Index:**

Record index

**Found:**

Flag to indicate if a record was found.

**Name:**

Name of remote terminal

**Type of Call:**

Recognizes the network interface hosting.

**Rate:**

Selects the desired rate for the call.

---

## 6.8 Delete Recent calls item (DV)

PC sends this message to delete the i-th record stored in the required list.

Note: after the update the indexes list must be updated.

**WARNING: Starting from v3.2.1.x**

Direction: PC -> RTE

Mode '&'

Type: 'D'

Sub-Type 'V'

Data: Type:

'A'= Remove all items

'I'= Remove items by index

**if item "A" (Remove all items)**

None

**if item "I" (General Information)**

Index (3 bytes)

'000'...'NumRecord-1'

Data Description:

---

## 6.9 Generic LDAP information (DG)

This message is sent by PC to request some generic parameters about LDAP server configuration.

Direction: PC -> RTE

Mode '?'  
Type: 'D'  
Sub-Type 'G'  
Data: None

Direction: RTE -> PC

Mode '<'  
Type: 'D'  
Sub-Type 'G'  
Data: Index of selected LDAP server (3 bytes)  
'000'...'Number of configured servers -1'  
Number of configured servers (3 bytes)  
'000'...'999'  
Index of last connected LDAP server (3 bytes)  
'000'...'Number of configured servers -1'

#### Data Description:

This command is used to know if the local phonebook or a remote (LDAP) one is selected (if index of selected server is 0 then the phonebook is local, if a positive number then is the index of loaded LDAP server and it is equal to the index of last connected LDAP server).

Another useful information is the max number of servers configured in the system.

PC	----- AT[?DG<cr> -----> RTE	
PC	←----- AT[<DG000002001<cr> ----->	RTE Local phonebook selected, two server configured, server 1 is the last connected
PC	←----- OK<cr> -----	RTE

---

## 6.10 Insert new LDAP server (DS)

This message is sent by PC to request the storage of a new LDAP server configuration.

Direction: PC -> RTE

Mode '&'  
Type: 'D'  
Sub-Type 'S'  
Data: Command type:  
'T' = Server type and port  
'N' = Server name  
'P' = Server Password  
'B' = Server first part bind (user) value  
'C' = Server second part bind (user) value  
'L' = Server first part base value  
'M' = Server second part base value  
'Q' = Server first part filter value  
'R' = Server second part filter value

'F' = Server first part RootDN value (**Starting from v3.1.x**)  
'G' = Server second part RootDN value (**Starting from v3.1.x**)  
'W' = Save all

**If Command type is 'T':**

Server type

- 1 = Another Scopia® XTSeries system H.350 LDAP server
- 2 = iView H.350 LDAP server
- 3 = Generic H.350 LDAP server
- 4 = Third party H.350 LDAP server (**Starting from v8.3.2.x**)

Server port (5 bytes)

**If Command type is 'N':**

Name (NameSize of ASCII chars)

**If Command type is 'P':**

Password (PasswordSize of ASCII chars)

**If Command type is 'B':**

Server first part bind (user) value (max 83 ASCII chars)

**If Command type is 'C':**

Server second part bind (user) value (max 80 ASCII chars)

**If Command type is 'L':**

Server first part base value (max 83 ASCII chars)

**If Command type is 'M':**

Server second part base value (max 80 ASCII chars)

**If Command type is 'Q':**

Server first part filter value (max 83 ASCII chars)

**If Command type is 'R':**

Server second part filter value (max 80 ASCII chars)

**If Command type is 'F':**

Server first part RootDN value (max 83 ASCII chars)

**If Command type is 'G':**

Server second part RootDN value (max 80 ASCII chars)

**If Command type is 'W':**

Attention: without this command no one of previous commands will be saved

Data Description:

**Command type 'N'**

The server name .

**Command type 'B' and 'C'**

The LDAP server bind value can be 163 characters long, so the bind could be divided into two parts: first part is sent with command type 'B', second part is sent with command type 'C'. Command type 'C' has always to be sent after the command type 'B' and it must be used only if the bind value is longer than 83 characters. For Scopia® XT1000 LDAP server type the value is "*cn=Admin,dc=radvision,dc=com*".

**Command type 'L' and 'M'**

The LDAP server base value can be 163 characters long, so the base could be divided into two parts: first part is sent with command type 'L', second part is sent with command type 'M'. Command type 'M' has always to be sent after the command type 'L' and it must be used only if the base is longer than 83 characters. For Scopia® XT1000 LDAP server type the value is "*dc=radvision,dc=com*".

**Command type 'Q' and 'R'**

The LDAP server filter value can be 163 characters long, so the filter could be divided into two parts: first part is sent with command type 'Q', second part is sent with command type 'R'. Command type 'R' has always to be sent after the command type 'Q' and it must be used only if the filter is longer than 83 characters. The most common filter value is "*(objectClass=inetOrgPerson)*"

**Command type 'F' and 'G'**

The LDAP server filter value can be 163 characters long, so the filter could be divided into two parts: first part is sent with command type 'F', second part is sent with command type 'G'. Command type 'G' has always to be sent after the command type 'F' and it must be used only if the RootDN is longer than 83 characters.

```

PC ----- AT[&DSN192.168.114.197<cr> -----> RTE Name = 192.168.114.197
PC <----- OK<cr> ----- RTE
PC ----- AT[&DSP123456<cr> -----> RTE Password = 123456
PC <----- OK<cr> ----- RTE
PC ----- AT[&DSBcn=Admin,dc=radvision,dc=com<cr> -----> RTE Bind =
                                     cn=Admin,dc=radvision,dc=com
PC <----- OK<cr> ----- RTE
PC ----- AT[&DSLdc=radvision,dc=com <cr> -----> RTE Base =
                                     dc=radvision,dc=com
PC <----- OK<cr> ----- RTE
PC ----- AT[&DSQ(objectClass=inetOrgPerson)<cr> --> RTE Filter =
                                     (objectClass=inetOrgPerson)
PC <----- OK<cr> ----- RTE
PC ----- AT[&DSW <cr> -----> RTE Save new server
PC <----- OK<cr> ----- RTE

```

## 6.11 Read LDAP server configuration (DP)

This message is sent by PC to request a LDAP server configuration.  
This message is sent by RTE to reply to a reading request.

Direction: PC -> RTE

Mode '?'  
Type: 'D'  
Sub-Type 'P'  
Data: Index (3 bytes)  
'000'...'Number of configured servers -1'

Direction: RTE -> PC

Mode '<'  
Type: 'D'  
Sub-Type 'P'  
Data: Item:  
'G' = Generic Server info  
'T' = Server type and port  
'N' = Server name  
'P' = Server Password  
'B' = Server first part bind (user) value  
'C' = Server second part bind (user) value  
'L' = Server first part base value  
'M' = Server second part base value  
'Q' = Server first part filter value  
'R' = Server second part filter value  
'F' = Server first part RootDN value (**Starting from v3.1.1.x**)  
'H' = Server second part RootDN value (**Starting from v3.1.1.x**)

**If Command type is 'G':**

Index of LDAP server (3 bytes)  
'000'...'Number of configured servers -1'  
Locked (valid only for Local LDAP server): (**Starting from v8.3.2.x**)  
0 = Not locked  
1 = Locked

Dummy (4 bytes, must be 0) (for future expansion)

**If Command type is 'T':**  
 Server type  
     0 = Local LDAP server  
     1 = Another Scopia® XTSeries system H.350 LDAP server  
     2 = iView H.350 LDAP server  
     3 = Generic H.350 LDAP server  
     4 = Third party H.350 LDAP server (**Starting from v8.3.2.x**)

Server port (5 bytes)

**If Command type is 'N':**  
 Name (NameSize of ASCII chars)

**If Command type is 'P':**  
 Password (PasswordSize of ASCII chars)

**If Command type is 'B':**  
 Server first part bind (user) value (max 83 ASCII chars)

**If Command type is 'C':**  
 Server second part bind (user) value (max 80 ASCII chars)

**If Command type is 'L':**  
 Server first part base value (max 83 ASCII chars)

**If Command type is 'M':**  
 Server second part base value (max 80 ASCII chars)

**If Command type is 'Q':**  
 Server first part filter value (max 83 ASCII chars)

**If Command type is 'R':**  
 Server second part filter value (max 80 ASCII chars)

**If Command type is 'F':**  
 Server first part RootDN value (max 83 ASCII chars)

**If Command type is 'H':**  
 Server second part RootDN value (max 80 ASCII chars)

#### Data Description:

RTE	←----- AT[?DP001<cr> -----	PC	Request to view the LDAP server configuration with index 1
RTE	----- AT[<DPG00100000<cr>-----→	PC	Index 1
RTE	----- AT[<DPN192.168.114.197<cr> ----→	PC	Name: 192.168.114.197
RTE	----- AT[<DPP123456<cr>-----→	PC	Password: 123456
RTE	----- AT[<DPBcn=Admin,dc=radvision,dc=com<cr>-----→	PC	First part Bind: = cn=Admin,dc=radvision,dc=com
RTE	----- AT[<DPC <cr>-----→	PC	Second part Bind:
RTE	----- AT[<DPLdc=radvision,dc=com<cr>--→	PC	First part Base: = dc=radvision,dc=com
RTE	----- AT[<DPM <cr>-----→	PC	Second part Base:
RTE	----- AT[<DPQ(objectClass=inetOrgPerson)<cr>-→	PC	First part Filter: = (objectClass=inetOrgPerson)
RTE	----- AT[<DPR <cr>-----→	PC	Second part Filter:
RTE	----- OK<cr> -----→	PC	

## 6.12 Modify LDAP server configuration (DM)

This message is sent by PC to modify a LDAP server configuration.

Direction: PC -> RTE



Mode '8'  
Type: 'D'  
Sub-Type 'M'  
Data: Item:

Index of LDAP server (3 bytes)

'000'...'Number of configured servers -1'

Command type:

'T' = Server type and port

'A' = Server generic info (**Starting from v8.3.2.x**)

'N' = Server name

'P' = Server Password

'B' = Server first part bind (user) value

'C' = Server second part bind (user) value

'L' = Server first part base value

'M' = Server second part base value

'Q' = Server first part filter value

'R' = Server second part filter value

'F' = Server first part RootDN value (**Starting from v3.1.1.x**)

'G' = Server second part RootDN value (**Starting from v3.1.1.x**)

'W' = Save all

**If Command type is 'T':**

Server type

1 = Another Scopia® XTSeries system H.350 LDAP server

2 = iView H.350 LDAP server

3 = Generic H.350 LDAP server

4 = Third party H.350 LDAP server (**Starting from v8.3.2.x**)

Server port (5 bytes)

**If Command type is 'A': (Starting from v8.3.2.x)**

Locked (valid only for Local LDAP server):

0 = Not locked

1 = Locked

Dummy (10 bytes, must be 0) (**for future expansion**)

**If Command type is 'N':**

Name (NameSize of ASCII chars)

**If Command type is 'P':**

Password (PasswordSize of ASCII chars)

**If Command type is 'B':**

Server first part bind (user) value (max 83 ASCII chars)

**If Command type is 'C':**

Server second part bind (user) value (max 80 ASCII chars)

**If Command type is 'L':**

Server first part base value (max 83 ASCII chars)

**If Command type is 'M':**

Server second part base value (max 80 ASCII chars)

**If Command type is 'Q':**

Server first part filter value (max 83 ASCII chars)

**If Command type is 'R':**

Server second part filter value (max 80 ASCII chars)

**If Command type is 'F':**

Server first part RootDN value (max 83 ASCII chars)

**If Command type is 'G':**

Server second part RootDN value (max 80 ASCII chars)

**If Command type is 'W':**

Attention: without this command no one of previous commands will be saved

Data Description:

### Server Index'

If the index is '000', the server to modify is the local server, but for this server you can modify only the password.

```
PC ----- AT[&DM001N192.168.114.197<cr> -----> RTE Name =
192.168.114.197
PC <----- OK<cr> ----- RTE
PC ----- AT[&DM001P123456<cr> -----> RTE Password = 123456
PC <----- OK<cr> ----- RTE
PC ----- AT[&DM001Bcn=Admin,dc=radvision,dc=com<cr> -----> RTE Bind =
cn=Admin,dc=radvision,dc=com
PC <----- OK<cr> ----- RTE
PC ----- AT[&DM001Ldc=radvision,dc=com <cr> ---> RTE Base =
dc=radvision,dc=com
PC <----- OK<cr> ----- RTE
PC ----- AT[&DM001Q(objectClass=inetOrgPerson)<cr> -----> RTE Filter =
(objectClass=inetOrgPerson)
PC <----- OK<cr> ----- RTE
PC ----- AT[&DM001W <cr> -----> RTE Save new server
PC <----- OK<cr> ----- RTE
```

---

## 6.13 Delete LDAP server (DB)

This message is sent by PC to request to delete a LDAP server configuration.

Direction: PC -> RTE

Mode '8'  
Type: 'D'  
Sub-Type 'B'  
Data: Index of LDAP server to be deleted (3 bytes)  
'000'...'Number of configured servers -1'

#### Data Description:

The Local server with index '000' cannot be deleted.

---

## 6.14 Connect a LDAP server (DC)

This message is sent by PC to request to connect to a LDAP server.

To know the phonebook entries of a connected LDAP server, you have to use the usual DR command.  
You can't insert, delete or modify a record in a remote LDAP server (the DI and DD commands fail).

Direction: PC -> RTE

Mode '8'  
Type: 'D'  
Sub-Type 'C'  
Data: Index of LDAP server to connect (3 bytes)  
'000'...'Number of configured servers -1'

#### Data Description:

This command is used to connect to a LDAP server so that you can read all its records. This operation can require some time. Index value of "000" must be used to select local phonebook.

---

## 6.15 Phone Directory Configuration Error Message (DE)

This message is sent by RTE to notify an error on the received message:

Direction: RTE -> PC

Mode: '<'  
Type: 'D'  
Sub-Type: 'E'  
Data: Message Type  
Sub-type  
Error:  
    '1' = Bad parameter  
    '2' = Unknown message  
    '3' = wrong message length  
    '4' = Bad mode  
    '5' = Unable to execute command  
Sub-code  
    If Unable to execute command  
        '0' = system timeout  
        '1' = system busy  
    If Bad parameter  
        Index number of wrong parameter

# 7 Call Control Messages

The call control messages can manage actions related to calls.

---

## 7.1 Make a call (CD)

PC send this message to make a call.

Direction: PC -> RTE

Mode '8'

Type: 'C'

Sub-Type: 'D'

Data: Call: '1'..'F' (hexadecimal value)

CallType:

- '1' = Audio only
- '8' = Audio/Video
- 'R' = From last calls list (Starting from v3.2.1.X)
- 'C' = From contacts list (Starting from v3.2.1.X)

Interface :

- '1' = IP
- '5' = MCU (activation)
- '6' = SIP
- '7' = ISDN (Starting from v3.x)

Number (ASCII string)

### Data Description:

#### **Call:**

Call progressive number: first, second, etc. For additional calls this number must be different from 1, but it can be any number (valid only for ISDN additional calls).

#### **Number:**

Number to call.

#### **CallType:**

If CallType is R the number must be the index of the Recent Calls list element to call

If CallType is C the number must be the index of the Contacts list element to call

In these cases Interface field will not be taken in account.

---

## 7.2 Make call at a specified rate (CM)

PC sends this message to make a call at a specified rate, without changing the system rate.

Direction: PC -> RTE

Mode '8'

Type: 'C'  
 Sub-Type: 'M'  
 Data: CallType:  
     '1' = Audio only  
     '8' = Audio/Video  
 Interface :  
     '1' = IP  
     '6' = SIP  
     '7' = ISDN (**Starting from v3.x**)  
 Rate :  
     '1' = 64  
     '2' = 128  
     '3' = 192  
     '4' = 256  
     '5' = 320  
     '6' = 384  
     '7' = 448  
     '8' = 512  
     'C' = 768  
     'D' = 1152 (**valid only for network IP**)  
     'E' = 1472  
     'F' = 1536  
     'G' = 1920  
     'H' = 2560  
     'I' = 3072  
     'J' = 3584  
     'K' = 4096  
     'L' = 5120  
     'M' = 5632  
     'N' = 6144  
     'O' = 1728 (**valid only for network IP**) (**Starting from v3.2.x**)  
     'P' = 4608 (**valid only for network IP**) (**Starting from v3.2.x**)  
     'Q' = 2048 (**valid only for network IP**) (**Starting from v3.2.x**)  
     'R' = 896 (**valid only for network IP**) (**Starting from v3.2.x**)  
     'S' = 1024 (**valid only for network IP**) (**Starting from v3.2.x**)  
     'T' = 1280 (**valid only for network IP**) (**Starting from v3.2.x**)  
     'U' = 1408 (**valid only for network IP**) (**Starting from v3.2.x**)  
     'V' = 6656 (**valid only for network IP**) (**Starting from v8.3.0.88**)  
     'Z' = 7168 (**valid only for network IP**) (**Starting from v8.3.0.88**)  
     'X' = 7680 (**valid only for network IP**) (**Starting from v8.3.0.88**)  
     'Y' = 8128 (**valid only for network IP**) (**Starting from v8.3.0.88**)  
     'W' = 8192 (**valid only for network IP**) (**Starting from v8.3.0.88**)  
     '9' = 10240 (**valid only for network IP**) (**Starting from v8.3.0.88**)  
 Dummy (1 byte, must be 0) (**for future expansion**)  
 1^ Number (ASCII string)  
 Separator (='.')  
 2^ Number (difference with the 1^ Number)  
 ....  
 Separator (='.')  
 N^ Number (difference with the 1^ Number)

#### Data Description:

##### **Rate:**

It is possible to select the call rate. If channels are not aggregated, it is necessary to specify all the numbers to call.

##### **Numbers:**

The length of all numbers must be the same, the difference being referred to the first number (radix). If the numbers are equal, you have to repeat the last digit.

---

## 7.3 Send a DTMF digit (CF)

PC sends this message to make a call.

Direction: PC -> RTE

Mode ' & '  
Type: ' C '  
Sub-Type ' F '  
Data: ' 0 ' .. ' 9 ' , ' # ' , ' \* '

Data Description:

---

## 7.4 Answer an incoming call (CA)

PC sends this message to answer to an incoming call.

Direction: PC -> RTE

Mode ' & '  
Type: ' C '  
Sub-Type ' A '  
Data: Call:  
          ' 1 ' .. ' N '  
          Dummy (1 byte, must be 0) (**for future expansion**)

Data Description:

### **Call:**

Call progressive numbers: first, second, etc. (**at present the only call accepted is the first**).

---

## 7.5 Answer an incoming call extension (CG)

PC sends this message to answer to or reject an incoming call also in MCU mode.

Direction: PC -> RTE

Mode ' & '  
Type: ' C '  
Sub-Type ' G '  
Data: Action:  
          ' 0 ' = Reject  
          ' 1 ' = Accept  
          Call identification number (**10 fixed bytes**):  
          Dummy (1 byte , must be 0):

#### Data Description:

##### **Call identification number:**

Is the number of call that comes with SC "Incoming call in connection" notification message. If the SC message is "Incoming call in idle", that has no number, this parameter has to be always equal to '0000000001'.

##### **Action:**

If you want to accept the incoming call, this parameter has to be 1. If you want to reject the incoming call, this parameter has to be 0.

---

## 7.6 Disconnect a call (CH)

PC sends this message to disconnect a call.

Direction: PC -> RTE

Mode '8'  
Type: 'C'  
Sub-Type 'H'  
Data: Call: '1'..'N'  
Interface: '1' = IP

#### Data Description:

##### **Call:**

Call progressive numbers: first, second, etc. (**the whole connection is disconnected**).

---

## 7.7 Connection Status (CB)

PC sends this message to know the connection status.

Direction: PC -> RTE

Mode '?'  
Type: 'C'  
Sub-Type 'B'  
Data:

Direction: RTE -> PC

Mode '<'  
Type: 'C'  
Sub-Type 'B'  
Data: Current network type for the call:

'1' = SIP  
'5' = IP  
'6' = MCU

'7' = ISDN (**Starting from v3.x**)

Call status (2 bytes):

- "02" = idle
- "05" = first call started
- "06" = first setup sent to network
- "07" = the remote system is ringing after the first call
- "08" = first incoming call
- "09" = first call connected
- "10" = a following call is started
- "11" = a following setup has been sent to network
- "12" = the remote system is ringing after a following call
- "13" = following incoming call
- "14" = following call connected
- "20" = waiting the complete disconnection
- "31" = MCU IP active

Video active:

- '0' = no
- '1' = yes

Data channel active:

- '0' = no
- '1' = yes

Connected number (ASCII string). **Note:** not valid in MCU

#### Data Description:

This command can be used to know the connection status of a system at any time.

---

## 7.8 Connection H323 Status (CL)

PC sends this message to know the parameters of the active H.323 connection.

Direction: PC -> RTE

Mode '?'  
 Type: 'C'  
 Sub-Type 'L'  
 Data:

Direction: RTE -> PC

Mode '<'  
 Type: 'C'  
 Sub-Type 'L'  
 Data: Audio Coding (2 bytes):

- '00' = Audio Off
- '01' = G.723
- '02' = G.711 48k A-law
- '03' = G.711 56k A-law
- '04' = G.711 64 A-law
- '05' = G.711 48k Mu-law
- '06' = G.711 56k Mu-law
- '07' = G.711 64 Mu-law
- '08' = G.728
- '09' = G.722 48k
- '10' = G.722 56k



'11' = G.722 64k  
 '12' = PT 724  
 '13' = PT 716  
 '14' = G.722.1 24K  
 '15' = G.722.1 32K  
 '16' = G.722.1  
 '18' = MP4 AAC-LD  
 '19' = MP4 AAC-LD 48K  
 '20' = MP4 AAC-LD 56K  
 '21' = MP4 AAC-LD 64K  
 '22' = MP4 AAC-LD 128K  
 '23' = G.711  
 '24' = G.722  
 '25' = G.722.1 Annex C  
 '26' = G.722.1 Annex C 24K  
 '27' = G.722.1 Annex C 32K  
 '28' = G.722.1 Annex C 48K  
 '29' = G.719  
 '30' = G.719 32K  
 '31' = G.719 48K  
 '32' = G.719 64K  
 '33' = G.719 96K  
 '34' = G.719 128K  
 '35' = G.729 Annex A

Video Coding (2 bytes):

'00' = Video off  
 '01' = H.261 CIF  
 '02' = H.261 QCIF  
 '03' = H.263 CIF  
 '04' = H.263 QCIF  
 '05' = H.263 SQCIF  
 '06' = H.263 4CIF  
 '07' = H.263 1024x768  
 '08' = H.263 800x600  
 '09' = H.263 640x480  
 '10' = H.263 SIF  
 '11' = H.263 4SIF  
 '12' = H.263 ICIF  
 '13' = H.263 ISIF  
 '14' = H.264 CIF  
 '15' = H.264 QCIF  
 '16' = H.261  
 '17' = H.263  
 '18' = H.263 custom  
 '19' = H.263 1280x1024  
 '20' = H.263 1280x720  
 '21' = H.263 1024x576  
 '22' = H.263 768x448  
 '23' = H.263 576x448  
 '24' = H.263 528x400  
 '25' = H.263 512x288  
 '26' = H.263 320x240  
 '27' = H.264  
 '28' = H.264 4CIF  
 '29' = H.264 SQCIF  
 '30' = H.264 SIF  
 '31' = H.264 4SIF  
 '32' = H.264 1280x1024  
 '33' = H.264 1280x720  
 '34' = H.264 1024x768

'35' = H.264 1024x576  
 '36' = H.264 800x600  
 '37' = H.264 768x448  
 '38' = H.264 640x480  
 '39' = H.264 576x448  
 '40' = H.264 528x400  
 '41' = H.264 512x288  
 '42' = H.264 320x240  
 '43' = H.264 ICIF  
 '44' = H.264 ISIF  
 '45' = H.264 custom  
 '46' = H.264 sharpness  
 '47' = H.263 1920x1080  
 '48' = H.264 1920x1080  
 '49' = H.263 400x224  
 '50' = H.264 400x224  
 '51' = H.264 1920x1080p  
 '52' = H.264 1280x768  
 '53' = H.264 1440x900  
 '54' = H.264 1680x1050  
 '55' = H.264 1600x1200  
 '56' = H.264 1920x1200  
 '57' = H.264 624x352  
 '58' = H.264 576x336

Number of channels connected (2 bytes):

#### Data Description:

This command can be used to know some parameters related to current H.323 connection.

---

## 7.9 Dual Video Management (CV)

PC sends this message to start/stop or change the video source for Dual-Video streaming.

Direction: PC -> RTE  
  
 Mode: '&'  
 Type: 'C'  
 Sub-Type: 'V'  
 Data: Action (1 byte)  
     '0' = Stop dual video  
     '1' = Start dual video  
     '2' = Change video source  
     Video Source Index (2 bytes)  
     '08' = DVI Input

#### Data Description:

##### **Action**

If you want to start the dual video stream, you have to set Action to 1, and the video source to one of the available video inputs.

If you want to change the video source, you have to set Action to 2 and the video source to the desired one.

If you want stop the dual video stream, you have to set Action to 0.

---

## 7.10 Dual Video Status (CC)

PC sends this message to known the Dual-Video streaming status.

Direction: PC -> RTE

Mode '?'  
Type: 'C'  
Sub-Type 'C'  
Data:

Direction: RTE -> PC

Mode '<'  
Type: 'C'  
Sub-Type 'C'  
Data: Status (1 byte):  
          '0' = Inactive  
          '1' = Active  
      Video Source Index (2 bytes)  
          '08' = DVI Input

### Data Description:

#### **Status**

If dual video is disconnected Status is equal to 0.

If dual video is active, Status is equal to 1 and the video source index is the video input selected for this stream.

---

## 7.11 Call Error Indication (CE)

RTE sends this message to show an error on the received message:

Direction: RTE -> PC

Mode '<'  
Type: 'C'  
Sub-Type 'E'  
Data: Message Type  
      Sub-type  
      Error:  
          '1' = Bad parameter  
          '2' = Unknown message  
          '3' = wrong message length  
          '4' = Bad mode  
          '5' = Unable to execute command  
      Sub-code  
          If Unable to execute command  
              '0' = system timeout  
              '1' = system busy  
          If Bad parameter  
              Index number of wrong parameter

# 8 Multipoint Control Messages

The multipoint call control messages can manage actions related to calls in a Multipoint session.

---

## 8.1 Connect a terminal (MD)

PC sends this message to connect a terminal to a conference.

Direction: PC -> RTE

Mode: '&'

Type: 'M'

Sub-Type: 'D'

Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Call type:  
    '0' = Audio only  
    '8' = Audio/video  
Interface:  
    '1' = IP  
    '6' = SIP  
    '7' = ISDN (**Starting from v3.x**)  
1^ Number (ASCII string)  
Separator (='.')  
2^ Number (difference with the 1^ Number)  
.....  
Separator (='.')  
N^ Number (difference with the 1^ Number)

### Data Description:

#### **Conference:**

Conference number. At the moment it can be only '00'.

#### **Terminal:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.

#### **CallType:**

It is possible to select call type: audio only or audio/video.

#### **Number:**

Number to call.

If there is more than one number (in a not aggregate channel rate call), the length of all numbers must be the same, the difference being referred to the first number (radix).

If the numbers are equal, you have to repeat the last digit.

---

## 8.2 Disconnect a terminal (MH)

PC sends this message to disconnect a terminal from a conference.

Direction: PC -> RTE

Mode ' & '   
Type: ' M '   
Sub-Type ' H '   
Data: Conference: ' 00 '.....' NN ' ( 2 bytes )   
Terminal: ' 00 '.....' NN ' ( 2 bytes )

Data Description:

**Conference:**

Conference number. At the moment it can be only '00'.

**Terminal:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.

---

## 8.3 Close a conference (MO)

PC sends this message to close a conference.

Direction: PC -> RTE

Mode ' & '   
Type: ' M '   
Sub-Type ' O '   
Data: Conference: ' 00 '.....' NN ' ( 2 bytes )

Data Description:

**Conference:**

Conference number. At the moment it can be only '00'.

---

## 8.4 Terminal status (MT)

PC sends this message to ask for the status of a terminal in a multiconference.

RTE sends this message in reply.

Direction: PC -> RTE

Mode ' ? '   
Type: ' M '   
Sub-Type ' T '   
Data: Conference: ' 00 '.....' NN ' ( 2 bytes )   
Terminal: ' 00 '.....' NN ' ( 2 bytes )

Direction: RTE -> PC

Mode ' > '

Type: 'M'  
 Sub-Type: 'T'  
 Data: Conference: '00'.....'NN' (2 bytes)  
 Terminal: '00'.....'NN' (2 bytes)  
 Connection status:  
     '0' = disconnected  
     '1' = connected  
 Audio status:  
     '0' = disconnected  
     '1' = connected  
     '2' = connected, but disabled (in mute)  
 Video status:  
     '0' = disconnected  
     '1' = connected  
     '2' = active speaker  
     '3' = previous active speaker  
     '4' = chairman (broadcast video)  
 Channel status 1 (1 byte):  
     '0' = disconnected  
     '1' = connected synchronized  
     '2' = connected, but not synchronized  
 .....  
 Channel status 12 (1 byte):  
     '0' = disconnected  
     '1' = connected synchronized  
     '2' = connected, but not synchronized  
 Terminal Name: (ASCII string)

#### Data Description:

##### **Conference:**

Conference number. At the moment it can be only '00'.

##### **Terminal:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.

##### **Channel status:**

There are 12 channels maximum for each terminal.

---

## 8.5 Terminal audio status (MA)

PC sends this message to set the terminal audio status

Direction: PC -> RTE  
 Mode: '&'  
 Type: 'M'  
 Sub-Type: 'A'  
 Data: Conference: '00'.....'NN' (2 bytes)  
 Terminal: '00'.....'NN' (2 bytes)  
 Audio status:  
     '0' = disabled  
     '1' = not disabled

#### Data Description:

**Conference:**

Conference number. At the moment it can be only '00'.

**Terminal:**

Terminal number. '00' is the local terminal. At the moment the maximum number is '08'.

---

## 8.6 Terminal information (MG)

PC sends this message to ask for some information about the terminal.

Direction: RTE -> PC

Mode '?'

Type: 'M'

Sub-Type 'G'

Data: Conference: '00'.....'NN' (**2 bytes**)

Terminal: '00'.....'NN' (**2 bytes**)

Information:

'C' = Some connection information

Direction: RTE -> PC

Mode '>'

Type: 'M'

Sub-Type 'G'

Data: Conference: '00'.....'NN' (**2 bytes**)

Terminal: '00'.....'NN' (**2 bytes**)

Information:

'C' = Some connection information

**if Some connection information:**

Call network:

'1' = LAN

'6' = SIP

'7' = ISDN (**Starting from v3.x**)

Encryption status:

'0' = no encryption

'1' = disactivated

'2' = activated

'3' = asymmetric

H243 status:

'0' = none

'1' = chairman

'2' = on floor requested

Data Description:**Conference:**

Conference number. At the moment it can be only '00'.

**Terminal:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.

**Call network:**

Network used by terminal for the connection; information is valid only if the terminal is connected.

---

## 8.7 Terminal video status (MV)

PC sends this message to set terminal video status

Direction: PC -> RTE

Mode '8'  
Type: 'M'  
Sub-Type 'V'  
Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Video status:  
      '0' = normal  
      '1' = broadcast

### Data Description:

#### **Conference:**

Conference number. At the moment it can be only '00'.

#### **Terminal:**

Terminal number. '00' is the local terminal, always connected. At the moment the maximum number is '08'.

---

## 8.8 Conference finish time configuration (MF)

PC sends this message to ask for or save conference ending time.  
RTE send this message to reply.

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'M'  
Sub-Type 'F'  
Data: Conference: '00'.....'NN' (2 bytes)  
Unlimited time:  
      '0' = finish at the time and date specified  
      '1' = never finish  
Hour: (2 bytes)  
Minutes: (2 bytes)  
Day: (2 bytes)  
Month: (2 bytes)  
Year: (4 bytes)

Direction: RTE -> PC

Mode '>'  
Type: 'M'  
Sub-Type 'F'  
Data: See above



Data Description:

**Conference:**

Conference number. At the moment it can be only '00'.

**Unlimited time:**

If equal to '1', then the conference never ends and other parameters do not take any sense.

If equal to '0', then the conference ends at time/date specified in the other parameters

---

## 8.9 Conference video layout configuration (ML)

PC sends this message to set or get the MCU layout configuration.

RTE send this message to reply.

Direction: PC -> RTE

Mode '&' / '?'

Type: 'M'

Sub-Type 'L'

Data: Conference: '00'.....'NN' (**2 bytes**)

Layout type (2 bytes):

'00' = Automatic

'01' = One terminal

'02' = Two terminals A

'03' = Two terminals B

'04' = Two terminals C

'05' = Three terminals A

'06' = Three terminals B


'07' = Four terminals A

'08' = Four terminals B

'09' = Four terminals C

'10' = Seven terminals A

'11' = Eight terminals C



'12' = Nine terminals A

'13' = Nine terminals B

'14' = Two terminals D

'15' = Five terminals

'16' = Six terminals

'17' = Seven terminals B

'18' = Seven terminals C

'19' = Eight terminals A

'20' = Eight terminals B

'21' = Eight terminals D

'22' = Nine terminals C



(Starting from v3.x)

(Starting from v3.x)

(Starting from v3.x)

(Starting from v3.x)

(Starting from v3.x)

(Starting from v3.x)

(Starting from v3.x)

(Starting from v3.x)

(Starting from v3.x)

Direction: RTE -> PC

Mode '>'

Type: 'M'

Sub-Type 'L'

Data: See above

#### Data Description:

#### **Conference:**

Conference number. Currently, only '00'.

#### **Layout type:**

Define the video layout in MCU mode to see remote terminals.

A specific layout can be selected only if enough terminals are connected to the multipoint session (Ex. If are connected five terminals, you can't choose seven, eight and nine layouts).

---

## 8.10 Conference indication messages (MS)

RTE sends this message to notify some conference and terminals status.

Direction: RTE -> PC

Mode '<'

Type: 'M'

Sub-Type 'S'

Data:

Message Type:

- '1' = Terminal name indication
- '2' = Terminal video status
- '3' = Terminal audio status
- '4' = Terminal channel status
- '5' = Terminal connection status
- '6' = Terminal encryption status
- '7' = Terminal H243 status
- '8' = Conference video status
- '9' = Conference close indication

**if Terminal name indication:**

Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Terminal Name: (ASCII string)

**if Terminal video status:**

Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Video status:  
    '0' = disconnected  
    '1' = connected  
    '2' = active speaker  
    '3' = previous active speaker  
    '4' = chairman (broadcast video)

**if Terminal audio status:**

Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Audio status:  
    '0' = disconnected  
    '1' = connected  
    '2' = connected, but disabled (in mute)

**if Terminal channel status:**

Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Number of channels: '00'.....'NN' (2 bytes, actually this value is "12")  
1^ Channel Status:  
    '0' = disconnected  
    '1' = connected synchronized  
    '2' = connected, but not synchronized  
2^ Channel Status:  
    '0' = disconnected  
    '1' = connected synchronized  
    '2' = connected, but not synchronized  
.....  
NN^ Channel Status:  
    '0' = disconnected  
    '1' = connected synchronized  
    '2' = connected, but not synchronized

**if Terminal connection status:**

Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Connection status:  
    '0' = disconnected  
    '1' = connected

**if Terminal encryption status:**

Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
Encryption status:  
    '0' = no encryption  
    '1' = disactivated  
    '2' = activated  
    '3' = asymmetric

**if Terminal H243 status:**

Data: Conference: '00'.....'NN' (2 bytes)  
Terminal: '00'.....'NN' (2 bytes)  
H243 status:  
    '0' = none  
    '1' = chairman  
    '2' = on floor requested

**if Conference video status:**

Data: Conference: '00'.....'NN' (2 bytes)  
Video status:  
    '1' = continuous presence  
    '2' = voice switching

**if Conference close indication:**

Data: Conference: '00'.....'NN' (2 bytes)

Data Description:

**Conference:**

Conference number. At the moment it can be only '00'.

**Terminal:**

Terminal number.

**Message Type:**

If the message type is Encryption, then the information is never available for the local terminal

---

## 8.11 Multipoint Error Indication (ME)

RTE sends this message to show an error on the received message.

Direction: RTE -> PC

Mode: '<'  
Type: 'M'  
Sub-Type: 'E'  
Data: Message Type  
Sub-type  
Error:  
    '1' = Bad parameter  
    '2' = Unknown message  
    '3' = wrong message length  
    '4' = Bad mode  
    '5' = Unable to execute command  
Sub-code  
    If Unable to execute command

'0' = system timeout  
'1' = system busy  
If Bad parameter  
Index number of wrong parameter

# 9 Control & Indication Messages

The control and indication messages can be used by PC to perform some actions to manage the system. RTE sends these messages to notify some system's status changes.

---

## 9.1 Call Status (SC)

RTE sends this message to PC to show a status change on the call.

Direction: RTE -> PC

Mode: '<'

Type: 'S'

Sub-Type: 'C'

Data: Call:

'1'..'F' (**Hexadecimal number**)

Interface :

'1' = IP

'6' = SIP

'7' = ISDN (**Starting from v3.x**)

CallType:

'1' = Release Indication with Progress Indicator

'2' = Setup acknowledge

'3' = Call proceeding

'4' = Information element

'5' = Alerting

'6' = Incoming call in idle

'G' = Incoming call in connection

'7' = Call connected

'9' = Release Indication

'A' = Release Confirmation

'B' = Display Information Element

'C' = Charge advise information element

'D' = Suspend Confirm

'E' = Resume Confirm

'F' = Call Advice

**if Release Indication with progress indicator:**

SourceRelease:

'0' = Internal Error

'1' = Timeout

'2' = Network

Cause : (3 chars – See Appendix A Table)

Progress Indicator (3 chars)

008 = in band info

**if Incoming Call in idle:**

CallType:

'1' = Audio only

'8' = Audio/video

Calling Number (ASCII string)

**if Incoming Call in connection:**

CallType:

'1' = Audio only

'8' = Audio/video

Identification call number (fixed 10 bytes)

Calling Number (ASCII string)

**if Outgoing call connected :**

CallType:

'1' = Audio only

'8' = Audio/video

Dummy (1 byte, must be 0) (for future expansion)

Called Number (ASCII string)

**if Incoming call connected :**

CallType:

'1' = Audio only

'8' = Audio/video

Number of aggregate channels (1..F Hexadecimal)

Calling Number (ASCII string)

**if Release Indication :**

SourceRelease:

'0' = Internal Error

'1' = Timeout

'2' = Network

Cause : (3 chars - See ETS 300 Table 4.13)

**if Display Indication :**

ASCII string to display

**if Charge Advise :**

Charge advice string to display

**if Information element :**

information ( ASCII string)

**if Call Advice:**

CallType:

'1' = Audio only

'8' = Audio/video

Calling Number (ASCII string)

Data Description:

Examples:

Make an unrestricted undefined call at number 192.168.187.68 using the IP interface

```
PC ----- AT[&CD181192.168.187.86<cr> -----> RTE (Make a call at number 192.168.187.86)
PC <----- OK<cr> ----- RTE
```

PC	←----- AT[<SC113<cr> -----	RTE	(Call proceeding)
PC	←----- AT[<SC115<cr> -----	RTE	(Alerting)
PC	←----- AT[<SC11780Name<cr> -----	RTE	(Outgoing call connected)

## 9.2 Video Camera Command/Status (SF)

PC sends this message to select/manage local or remote cameras.

It is sent by RTE to indicate camera selection as an answer to PC request or to indicate an action executed by the remote terminal.

Direction: PC -> RTE

Mode: '&'

Type: 'S'

Sub-Type: 'F'

Data: VideoCameraNum (2 ASCII digits)

Site:

'0' = local

'1' = remote

Command:

'0' = select

'1' = pan with timeout

'2' = tilt with timeout

'3' = zoom with timeout

'5' = recall preset

'6' = store preset

'!' = stop action

'7' = pan continually

'8' = tilt continually

'9' = zoom continually

'B' = extended recall preset

'C' = extended store preset

'X' = DVI autoadjust (**valid only for local DVI input**)

'F' = pan-tilt with timeout

'G' = pan-tilt continually

'D' = Direct Pan and Tilt position

'Z' = Direct zoom position

if pan ('1' or '7'):

'R' = Right

'L' = Left

if tilt ('2' or '8'):

'U' = Up

'D' = Down

if zoom ('3' or '9'):

'+' = zoom in

'-' = zoom out

if preset or store ('5' or '6')

'0'..'F' (**Hexadecimal Number**)

if extended preset recall or store ('B' or 'C')

3 bytes (**Decimal Number**)

if pan-tilt ('F' or 'G'):

'1' = Up-Right

'2' = Up-Left

'3' = Down-Right



'4' = Down-Left  
 if Direct Pan and Tilt position ('D')  
     Pan Position 4 bytes (Four hexadecimal digits)  
     Tilt Position 4 bytes (Four hexadecimal digits)  
 if Direct Zoom position ('Z')  
     Zoom Position 4 bytes (Four hexadecimal digits)

Mode '?'  
 Type: 'S'  
 Sub-Type 'F'  
 Data: Type of information :  
     None: Current camera and site  
     'D': Current pan-tilt position for selected local camera (**Starting from v8.3.2.5xx**)  
     'Z': Current zoom position for selected local camera (**Starting from v8.3.2.5xx**)  
     'B': Current stored local presets (**Starting from v8.3.2.5xx**)

**If type of information: none:**  
     None

**If type of information 'D':**  
     None

**If type of information 'Z':**  
     None

**If type of information 'B':**  
     Group of 20 presets (2 bytes):  
     '01' .... '07' (max 122 presets)

Direction: RTE -> PC

Mode '<'  
 Type: 'S'  
 Sub-Type 'F'  
 Data: Type of information :  
     None: Current camera and site  
     'D': Current pan-tilt position for selected local camera (**Starting from v8.3.2.5xx**)  
     'Z': Current zoom position for selected local camera (**Starting from v8.3.2.5xx**)  
     'B': Current stored camera presets (**Starting from v8.3.2.5xx**)

**If type of information: none:**  
     VideoCameraNum (1 ASCII digits)  
     Site:  
         '0' = local  
         '1' = remote

**If type of information 'D':**  
     VideoCameraNum (2 ASCII digits)  
     Pan Position 4 bytes (Four hexadecimal digits)  
     Tilt Position 4 bytes (Four hexadecimal digits)

**If type of information 'Z':**  
     VideoCameraNum (2 ASCII digits)  
     Zoom Position 4 bytes (Four hexadecimal digits)

**If type of information 'B':**

Group of 20 presets (2 bytes):

'01' ....'07' (max 122 presets)

20 presets status (20 bytes). Each byte is the status of a preset

'0' = Preset free

'1' = Preset busy

Data Description:**VideoCameraNum:**

Number associated to the camera.

Possible numbers are :

'01' = HD1

'02' = USB or HD2 for XT1000

'03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)

'04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'08' = DVI Input For this input, selection and AutoAdjust are the only valid commands

If the number is 00, then the action is referred to the current selected camera.

The number associated to a camera of remote terminal may be obtained by receiving a camera information message.

**Site:**

This parameter indicates if message is for local ('0') or remote ('1') camera.

**Command:**

Command to be executed: select (select video-camera), pan, tilt, zoom, recall and store preset.

The commands with timeout move camera with a fixed timeout, than stop it; on the other hand pan, tilt and zoom commands continuously move camera until the stop command is sent. This is valid only for local site : remote site always uses timeout. So if you want to prevent this behavior, movement command must be sent more than one time with a frequency lower than the stop timeout.

Moreover if you move camera continually, it moves slower than you move with remote controller because the acceleration is made by internal camera driver only if it receives more than one movement command. Therefore also in this case if you want to increase speed you must send more than one movement continually command

For commands D and Z (direct movements) these are bytes values ranges:

- For Premium and Standard II cameras PAN position ranges from 0xFA60 to 0x05A0 (center 0x0000) while TILT position ranges from 0xFE98 to 0x0168 (center 0x0000). For example to move camera left-down you can send command AT[&SF010DFA600168. ZOOM position ranges from 0x0000 to 0x4000 for optical zoom and up to 0x7E80 for digital zoom.
- For Advanced camera PAN position ranges from 0xE1E5 to 0x1E1B (center 0x0000), TILT position ranges from 0xFC75 to 0x0FF0 (center 0x0000). ZOOM position ranges from 0x0000 to 0x4000 for optical zoom and up to 0x7aC0 for digital zoom.
- For FLEX camera PAN position ranges from 0xDDA0 to 0x2260 (center 0x0000), TILT position ranges from 0x0A00 to 0xF600 (center 0x0000). ZOOM position ranges from 0x0000 to 0x4000 for optical zoom and up to 0x406E for digital zoom.
- For XT1000 standard camera instead values for PAN ranges from 0x0000 to 0x3EB0 (center 0x1F58) while TILT position ranges from 0x0000 to 0x1100 (center 0x0880). ZOOM position ranges from 0x0000 to 0x4000.

**Group of preset:**

If you to know currently stored camera presets you can use the AT[?SFBxy command where xy are two bytes which indicates the group of 20 presets you want to know.

If you want to know state for presets from number 1 to 20, you must call command AT[?SFB01 and the response is like AT[<SFB01000000000000000000000000000000 where each 0 means that preset 1 is free, preset2 is free preset 3 is

free and so on until the twentieth. If you want to know status for other preset you must send command AT[?SFB02, AT[?SFB03 and so on until AT[?SFB07 which return only the last two presets state (121 e 122).

Example: move the main camera (01) to right

```
PC ----- AT[&SF0101R<cr> -----> RTE
PC <----- OK<cr> ----- RTE
```

Example: ask preset status for presets from 21 to 40

```
PC ----- AT[?SFB02<cr> -----> RTE
PC <----- AT[<SFB0200001000000010000000<cr> ----- RTE Presets number
                                     25 and 33 are busy, all other are free
PC <----- OK<cr> ----- RTE
```

## 9.3 Video Camera Command (SY)

PC sends this message to move local cameras without changing the current video source

Direction: PC -> RTE

Mode '8' / '?'

Type: 'S'

Sub-Type: 'Y'

Data: VideoCameraNum (2 ASCII digits)

Command:

- '1' = pan with timeout
- '2' = tilt with timeout
- '3' = zoom with timeout
- '5' = recall preset
- '6' = store preset
- '!' = stop action
- '7' = pan continually
- '8' = tilt continually
- '9' = zoom continuously
- 'F' = pan-tilt with timeout
- 'G' = pan-tilt continually
- 'D' = Direct Pan and Tilt position
- 'Z' = Direct zoom position

if pan :

- 'R' = Right
- 'L' = Left

if tilt:

- 'U' = Up
- 'D' = Down

if zoom:

- '+' = zoom in
- '-' = zoom out

if preset or store (3 bytes)

if pan-tilt ('F' or 'G'):

- '1' = Up-Right
- '2' = Up-Left
- '3' = Down-Right
- '4' = Down-Left

- if Direct Pan and Tilt position ('D')
  - Pan Position 4 bytes (Four hexadecimal digits)
  - Tilt Position 4 bytes (Four hexadecimal digits)
- if Direct Zoom position ('Z')
  - Zoom Position 4 bytes (Four hexadecimal digits)

#### Data Description:

##### **VideoCameraNum:**

Number associated to the camera.

Possible numbers are :

'01' = HD1

'02' = USB or HD2 for XT1000

'03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000)

'04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
(**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)

'08' = DVI Input For this input, selection and AutoAdjust are the only valid commands

If the number is 00, then the action is referred to the current selected camera.

##### **Command:**

Command to be executed: pan, tilt, zoom, recall and store preset.

The commands with timeout move camera with a fixed timeout (500 ms), than stop it; on the other hand pan, tilt and zoom commands continuously move camera until the stop command is sent

Example: move the main camera (01) to right

```
PC      ----- AT[&SY011R<cr> ----->      RTE
PC      <----- OK<cr> ----->      RTE
```

---

## 9.4 Board Reset (SG)

PC sends this message to reset or shutdown the board.

RTE send this message to notify a reset or shutdown system.

Direction: PC -> RTE

Mode: '&' / '>'

Type: 'S'

Sub-Type: 'G'

Data: Command:

'1' = reset

'2' = shutdown

#### Data Description:

Example: reset the board

```
PC      ----- AT[&SG1<cr> ----->      RTE
PC      <----- OK<cr> ----->      RTE
```

---

## 9.5 Conference Control (SH)

This message is sent by PC to RTE to take the control over a conference from a terminal in a multi-point connection.

This message is sent by RTE to PC to indicate a status or ack in a conference in a multi-point connection or to respond to a request.

Direction: PC -> RTE

Mode: '&'

Type: 'S'

Sub-Type: 'H'

Data: Command:

'C' = Chair control request

'F' = Floor request

'B' = Send a video terminal in broadcast (make a lecturer)

'V' = Request to view a terminal video

'D' = Drop a terminal

'A' = Drop all terminals

**if command 'C' (Request chair control)**

Action:

'1' = request chair control

'0' = release chair control

**if command 'F' (Request floor)**

none

**if command 'B' (Send a video terminal in broadcast)**

Terminal Idx ("000"... "999" index of Terminal in list)

Action:

'1' = request to start video broadcast

'0' = request to end video broadcast

**if command 'V' (Request to view a terminal video)**

Terminal Idx ("000"... "999" index of Terminal in list)

Action:

'1' = request to start view locally the terminal video

'0' = request to end view locally the terminal video

**if command 'D' (Drop a terminal)**

Terminal Idx ("000"... "999" index of Terminal in list)

**if command 'A' (Drop all terminals)**

none

Direction: PC -> RTE

Mode: '?'

Type: 'S'

Sub-Type: 'H'

Data: Command:

'N' = Request number of terminal in list

'L' = Request terminal info

'C' = Request chair control status

'B' = Request local video broadcast status

**if command 'N' (Request number of terminal in list)**

none

**if command 'L' (Request terminal info)**

none (all the terminals in the list) or

Terminal Idx ("000"... "999" index of Terminal in list)  
**if command 'C' (Request chair control status)**  
 none  
**if command 'B' (Request local video broadcast status)**  
 none

Direction: RTE -> PC

Mode '<'  
 Type: 'S'  
 Sub-Type 'H'  
 Data: Type of message:  
       'R' = Response  
       'I' = Indication

**if type of message 'R' (Response)**

'N' = Number of terminals in list (Response to 'N' request command) (three bytes)  
 'L' = Terminal list (Response to 'L' request command)  
       Terminal Idx ("000"... "999" index of Terminal in list)  
       MCU Id ("000"... "999" MCU identification number for the terminal)  
       TE Id ("000"... "999" TE identification number for the terminal)  
       Broadcast:  
           '0' = not in broadcast  
           '1' = in broadcast  
       Locally Viewed:  
           '0' = not viewed  
           '1' = viewed  
       Floor:  
           '0' = not requested  
           '1' = requested  
       Terminal name string (max 30 chars)  
 'C' = Chair control status (Response to 'C' request command)  
       Status:  
           '0' = local terminal not owned chair control  
           '1' = local terminal owned chair control  
 'B' = Local video broadcast status (Response to 'B' request command)  
       Status:  
           '0' = not in broadcast  
           '1' = in broadcast

**if type of message 'I' (Indication)**

'07' = Terminal list is changed or the status of a remote terminal is changed  
 '08' = Local Terminal Chair or Broadcast status is changed

Data Description:

**Chair control request**

This message is sent when the terminal wishes to become conductor. If the terminal is already the conductor of the conference, this message can be used to release the conductor-ship.

**Floor Request**

This message is sent when the terminal wishes to go on air.

**Send a video terminal in broadcast**

This message is sent when the terminal wishes to put a terminal on air. To perform this action if the system is not the MCU manager, is necessary to send the chair control request before this command. Index is the same as the which one returned by AT[?SHL command. To send in broadcast the local terminal the index to use is 0.

**Request to view a terminal video**

This message is sent when the terminal wishes to view a terminal different from the one in broadcast (this command works for some type of multiconference unit only). The same message can be used to end the forced terminal display.

#### **Drop a terminal**

This message is sent from conductor to disconnect another terminal. This command has effect only if the applicant is the conductor.

#### **Drop all terminals**

This message is sent from conductor to disconnect all terminals. This command has effect only if the applicant is the conductor. This command close the conference too.

#### **Number of terminal in list**

This message is sent by participant wishing to know all terminals connected in the multiconference. The response is a number of messages, one for terminal, in each one being specified the index, the name and others information about the terminal status.

#### **Request terminal list**

This message is sent to know information about one or all terminals connected in the multiconference. The response is one or more messages, in each one being specified the index, the name and others information about the terminal status.

#### **Request chair control status**

This message is sent to know the chair status of the local terminal.

#### **Local video broadcast status**

This message is sent to know the floor status of a terminal.

#### **Terminal Idx**

It is the index returned with the response for the terminal list request. The local terminal has always index '000'.

#### **Indication messages**

When indication messages are numer '07' and '08', to known how is changed, call the AT[?SH messages.

---

## **9.6 Mute Command/Status (SM)**

This message is sent by RTE to PC to indicate the status of mute.  
PC send this message to modify or know the status of mute.

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'S'

Sub-Type: 'M'

Data: Mute:  
          '0' = Disable  
          '1' = Enable

Direction: RTE -> PC

Mode: '<'

Type: 'S'

Sub-Type: 'M'

Data: Mute:  
          '0' = Disable  
          '1' = Enable

---

## 9.7 Remote Video Indication (SO)

This message is sent by RTE to PC as indication of remote video status.

This message should be used to know whether the remote video is displayed or not on the monitor.

Direction: RTE -> PC

Mode '<'  
Type: 'S'  
Sub-Type 'O'  
Data: Remote Video:  
          '0' = Off  
          '1' = On

---

## 9.8 Privacy Command/Status (SP)

This message is sent by RTE to PC as response to a Privacy Status Request (SP).

PC sends this message to modify or know the video privacy status.

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'S'  
Sub-Type 'P'  
Data: Privacy:  
          '0' = Disable  
          '1' = Enable

Direction: RTE -> PC

Mode '<'  
Type: 'S'  
Sub-Type 'P'  
Data: Privacy:  
          '0' = Disable  
          '1' = Enable

---

## 9.9 SelfView Command/Status (SS)

This message is sent by RTE to PC to indicate the self-view status.

PC sends this message to modify or know the self-view status.

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'S'  
Sub-Type 'S'



Data: SelfView:  
          '0' = Disable  
          '1' = Enable

Direction: RTE -> PC

Mode       '<'  
Type:       'S'  
Sub-Type   'S'  
Data:       SelfView:  
              '0' = Disable  
              '1' = Enable

---

## 9.10 Picture In Picture Command/Status (ST)

This message is sent by RTE to PC to indicate the picture in picture (PIP) status.

PC sends this message to modify or know the picture in picture (PIP) status.

**Warning** : for XT5000 this command is obsolete. Use SD command

Direction: PC -> RTE

Mode       '&' / '?'  
Type:       'S'  
Sub-Type   'T'  
Data:       Picture in Picture:  
              '0' = Disable  
              '1' = Enable

Direction: RTE -> PC

Mode       '<'  
Type:       'S'  
Sub-Type   'T'  
Data:       Picture in Picture:  
              '0' = Disabled  
              '1' = Enabled

### Data Description:

During a call, the local image of your own camera can be displayed in one corner of the screen by selecting the position and removed by selecting '0'.

---

## 9.11 Volume Command/Status (SV)

This message is sent by PC to RTE to change/request the value of audio volume in Rx during a connection.

RTE sends this message as response to a status request.

Direction: PC -> RTE

Mode       '&' / '?'

Type: 'S'  
Sub-Type 'V'  
Data: Volume Audio Rx (3 bytes):  
"-44".."20"

Direction: RTE -> PC

Mode '<'  
Type: 'S'  
Sub-Type 'V'  
Data: Volume Audio Rx (3 bytes):  
"-44".."20"

---

## 9.12 Infrared remote control emulation (SW)

This message is sent by PC to RTE to emulate a remote control key pressure.

Direction: PC -> RTE

Mode '&'  
Type: 'S'  
Sub-Type 'W'  
Data: Key (3 bytes):  
'000' = key '0'  
'001' = key '1'  
'002' = key '2'  
'003' = key '3'  
'004' = key '4'  
'005' = key '5'  
'006' = key '6'  
'007' = key '7'  
'008' = key '8'  
'009' = key '9'  
'010' = key '\*'  
'011' = key '#'  
'013' = key Power  
'014' = key '?'  
'015' = key Call  
'016' = key Disconnect  
'017' = key 'C'  
'018' = key Contacts  
'025' = key 'layouts'  
'026' = key 'pip'  
'027' = key Arrow Up  
'028' = key Arrow Right  
'029' = key Arrow Down  
'030' = key Arrow Left  
'031' = key 'ok'  
'032' = key 'memo'  
'033' = key 'select'  
'035' = key 'near'  
'036' = key 'far'  
'037' = key Zoom '-'  
'038' = key Zoom '+'  
'039' = key Video privacy  
'040' = key Volume '-'

'041' = key Volume '+'  
 '042' = key Mute  
 '043' = key 'presentation'  
 '044' = key Back  
 '045' = key 'inputs'  
 '046' = key red (circle)  
 '047' = key yellow (square)  
 '048' = key blue (star)  
 '049' = key green (triangle)  
 '060' = key '0' held down  
 '061' = key '1' held down  
 '062' = key '2' held down  
 '063' = key '3' held down  
 '064' = key '4' held down  
 '065' = key '5' held down  
 '066' = key '6' held down  
 '067' = key '7' held down  
 '068' = key '8' held down  
 '069' = key '9' held down  
 '070' = key Video privacy held down  
 '071' = key Power held down  
 '072' = key 'C' held down  
 '073' = key 'layouts' held down  
 '074' = key Call held down

Data Description:

---

## 9.13 Send “Start” command (SJ)

This message is sent by PC to RTE to allow the current not licensed and not running version to enter the temporary mode.

Direction: PC -> RTE  
 Mode: '&'  
 Type: 'S'  
 Sub-Type: 'J'  
 Data: None

---

## 9.14 DualVideo Status (SK)

RTE sends this message to PC to inform it the current dual video status.

Direction: RTE -> PC  
 Mode: '<'  
 Type: 'S'  
 Sub-Type: 'K'  
 Data: Status (2 bytes):  
     '00' = Dual Video Unknown status  
     '01' = Dual Video Transmission Active

'02' = Dual Video Transmission Stopped  
 '03' = Dual Video Received Active  
 '04' = Dual Video Received Stopped  
 '05' = Dual Video Transmission Request Failed  
 Video Source Index (2 bytes)  
 '08' = DVI Input  
 Cause (2 bytes)  
 '01' = Mode MCU  
 '02' = No call in progress  
 '03' = Broadcast in use  
 '04' = Seq. A in progress  
 '05' = Token busy  
 '06' = Not available  
 Dummy (2 bytes, must be 0) (**for future expansion**)

#### Data Description:

##### **Status**

If the dual video transmission request fails the status is equal to '05' and the param Cause is setted. Video Source Index is equal to '00'.

If dual video transmission is active, the status is equal to '01' and the Video Source Index is the video input selected for this stream. Cause is setted to '00'.

If dual video transmission is stopped, the status is equal to '02' and the Video Source Index and Cause are both setted to '00'.

If dual video reception is active, the status is equal to '03' and the Video Source Index and Cause are both setted to '00'.

If dual video reception is stopped, the status is equal to '04' and the Video Source Index and Cause are both setted to '00'.

##### **Cause**

This parameter makes sense only if status is equal to '05'.

---

## 9.15 Configuration System Status (SA)

RTE sends this message to PC to inform it that some configuration parameters has been changed.

**WARNING : Starting from v3.x**

Direction: RTE -> PC

Mode '<'

Type: 'S'

Sub-Type 'A'

Data: Mute (1 byte):

'0' = Off

'1' = On

Privacy (1 byte)

'0' = Off

'1' = On

Layout (2 bytes)

'01' = Local and Local (PiP), one monitor

'02' = Remote and local (PiP), one monitor

'03' = Local and remote (PiP), one monitor

'04' = DualVideo remote and remote (PiP), one monitor

'05' = DualVideo remote and local (PiP), one monitor

'06' = Remote and DualVideo remote (PiP), one monitor

'07' = Local and DualVideo remote (PiP), one monitor  
 '08' = DualVideo local and remote (PiP), one monitor  
 '09' = DualVideo local and local (PiP), one monitor  
 '10' = Remote and DualVideo local (PiP), one monitor  
 '11' = Local and DualVideo local (PiP), one monitor  
 '12' = Local and local (PiP) (graphical monitor) and local (other monitor)  
 '13' = Remote and local (PiP) (graphical monitor) and local (other monitor)  
 '14' = Local and remote (PiP) (graphical monitor) and remote (other monitor)  
 '15' = DualVideo remote and remote (PiP) (graphical monitor) and local (other monitor)  
 '16' = Remote and DualVideo remote (PiP) (graphical monitor) and local (other monitor)  
 '17' = DualVideo remote and local (PiP) (graphical monitor) and remote (other monitor)  
 '18' = Local and DualVideo remote (PiP) (graphical monitor) and remote (other monitor)  
 '19' = Remote and local (PiP) (graphical monitor) and DualVideo remote (other monitor)  
 '20' = Local and remote (PiP) (graphical monitor) and DualVideo remote (other monitor)  
 '21' = DualVideo local and remote (PiP) (graphical monitor) and local (other monitor)  
 '22' = Remote and DualVideo local (PiP) (graphical monitor) and local (other monitor)  
 '23' = DualVideo local and local (PiP) (graphical monitor) and remote (other monitor)  
 '24' = Local and DualVideo local (PiP) (graphical monitor) and remote (other monitor)  
 '25' = Remote and local (PiP) (graphical monitor) and DualVideo local (other monitor)  
 '26' = Local and remote (PiP) (graphical monitor) and DualVideo local (other monitor)

Multi Image (2 bytes)

'00' = Not visible  
 '01' = PiP LeftUp  
 '02' = PiP RightUp  
 '03' = PiP RightDown  
 '04' = PiP LeftDown  
 '05' = PaP  
 '06' = PoP

Local Video Camera Num (2 bytes)

'01' = HD1  
 '02' = USB or HD2 for XT1000  
 '03' = HD2 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000)  
 '04' = HD3 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '05' = HD4 (**Starting from v3.2.x** XT5000 with HDMI switcher) or  
 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '06' = HD5 (**Starting from v8.3.2.222** XT7000 with HDMI switcher)  
 '08' = DVI Input

Screen saver status (1 byte):

'0' = Off  
 '1' = On

RX Volume value (3 bytes):

'-44' ... '020'

Do Not Disturb (DND) (1 byte) : (**Starting from v8.3.x**)

'0' = Off  
 '1' = On

Recording Status (1 byte) : (**Starting from v8.3.2.5xx**)

'1' = Idle  
 '2' = Recording on USB  
 '3' = Pause  
 '4' = Recording on Scopia® Recording Server  
 '5' = Recording initiating on Scopia® Recording Server (**Starting from v8.3.4.x**)

Playing Status (1 byte) : (**Starting from v8.3.2.5xx**)

'1' = Idle  
 '2' = Playing  
 '3' = Pause

Dummy (17 bytes, must be 0) (**for future expansion**)

## Data Description:

### **Example:**

```
PC <----- AT[<SA100103010-16000000000000000000<cr>----- RTE
dove:
Mute=1, Privacy=0, Layout=0, Pip=1, Local Input=HD1, Screensaver=inactive, Rx Volume=-
16db, Dummy = 0.
```

---

## 9.16 Screen Saver Activation (SL)

This message is sent by PC to RTE to change/request the status of screen saver.  
RTE sends this message as response to a status request.

**WARNING : Starting from v3.x**

Direction: PC -> RTE

Mode '8' / '?'

Type: 'S'

Sub-Type 'L'

Data: Screen saver status (1 byte):  
      '0' = deactivated  
      '1' = activated

Direction: RTE -> PC

Mode '<'

Type: 'S'

Sub-Type 'L'

Data: See above

## Data Description:

---

## 9.17 Layout Command/Status (SB)

This message is sent by PC to RTE to change/request the status of video layout.  
RTE sends this message as response to a status request.

**WARNING : Starting from v3.x**

Direction: PC -> RTE

Mode '8' / '?'

Type: 'S'

Sub-Type 'B'

Data: Layout (2 bytes)  
      '01' = Local and Local (PiP), one monitor  
      '02' = Remote and local (PiP), one monitor  
      '03' = Local and remote (PiP), one monitor  
      '04' = DualVideo remote and remote (PiP), one monitor  
      '05' = DualVideo remote and local (PiP), one monitor  
      '06' = Remote and DualVideo remote (PiP), one monitor

'07' = Local and DualVideo remote (PiP), one monitor  
 '08' = DualVideo local and remote (PiP), one monitor  
 '09' = DualVideo local and local (PiP), one monitor  
 '10' = Remote and DualVideo local (PiP), one monitor  
 '11' = Local and DualVideo local (PiP), one monitor  
 '12' = Local and local (PiP) (graphical monitor) and local (other monitor)  
 '13' = Remote and local (PiP) (graphical monitor) and local (other monitor)  
 '14' = Local and remote (PiP) (graphical monitor) and remote (other monitor)  
 '15' = DualVideo remote and remote (PiP) (graphical monitor) and local (other monitor)  
 '16' = Remote and DualVideo remote (PiP) (graphical monitor) and local (other monitor)  
 '17' = DualVideo remote and local (PiP) (graphical monitor) and remote (other monitor)  
 '18' = Local and DualVideo remote (PiP) (graphical monitor) and remote (other monitor)  
 '19' = Remote and local (PiP) (graphical monitor) and DualVideo remote (other monitor)  
 '20' = Local and remote (PiP) (graphical monitor) and DualVideo remote (other monitor)  
 '21' = DualVideo local and remote (PiP) (graphical monitor) and local (other monitor)  
 '22' = Remote and DualVideo local (PiP) (graphical monitor) and local (other monitor)  
 '23' = DualVideo local and local (PiP) (graphical monitor) and remote (other monitor)  
 '24' = Local and DualVideo local (PiP) (graphical monitor) and remote (other monitor)  
 '25' = Remote and local (PiP) (graphical monitor) and DualVideo local (other monitor)  
 '26' = Local and remote (PiP) (graphical monitor) and DualVideo local (other monitor)

Direction: RTE -> PC

Mode: '<'

Type: 'S'

Sub-Type: 'B'

Data: See above

## 9.18 Conference Gallery Layout configuration (SX)

PC sends this message to set or get the external MCU gallery layout configuration.  
 RTE send this message to reply.

**Starting from v8.3.2.5xx**

Direction: PC -> RTE

Mode: '&' / '?'

Type: 'S'

Sub-Type: 'X'

Data: Gallery Layout active (**valid only in read mode**):

'0' = no

'1' = yes

Gallery Layout type (2 bytes):

'01' = Vertical

'02' = Horizontal

'03' = Presentation

'04' = Continuous presence





'05' = Video Full  
Dummies (10 bytes, must be 0) (for future expansion)

Direction: RTE -> PC

Mode ' > '  
Type: ' S '  
Sub-Type ' X '  
Data: See above

#### Data Description:

#### **Gallery Layout active:**

This is only a read field and is 1 if gallery layout is active, is 0 if it is not .

#### **Gallery Layout type:**

Define the video layout in the external MCU to see remote terminals and presentation in Gallery layout mode in which remotes video and presentation are sent in the same video flow. This field has no meaning if Gallery layout active is 0.

---

## 9.19 Multi image Command/Status (SD)

This message is sent by PC to RTE to change/request the multi image status.

RTE sends this message as response to a status request.

**WARNING : Starting from v3.x**

Direction: PC -> RTE

Mode ' & ' / ' ? '  
Type: ' S '  
Sub-Type ' D '  
Data: Multi image mode (2 bytes):  
          '00'=Not visibile  
          '01'=PiP LeftUp  
          '02'=PiP RightUp  
          '03'=PiP RightDown  
          '04'=PiP LeftDown  
          '05'=PaP  
          '06'=PoP

Direction: RTE -> PC

Mode ' < '  
Type: ' S '  
Sub-Type ' D '  
Data: See above

#### Data Description:

Pay attention that PiP position must be coherently with PiP Position and Rotation configuration.



---

## 9.20 JPEG image capture Command (SI)

This message is sent by PC to RTE to capture video and store it in a jpg image and sent it to a FTP server.

**WARNING : Starting from v3.1.x**

Direction: PC -> RTE

Mode: '&'

Type: 'S'

Sub-Type: 'I'

Data: Action:

'F' = Set FTP URL

'U' = Set FTP username

'P' = Set FTP password

'J' = Capture image and send it to FTP server configured with F action command  
(**Deprecated starting from 3\_1\_1\_37 version**)

'T' = Capture local/remote live/presentation image and send it to FTP server configured with F action command

**Action type 'F'**

FTP Server URL (max 60 ASCII chars)

**Action type 'U'**

FTP Username (max 60 ASCII chars)

**Action type 'P'**

FTP Password (max 60 ASCII chars):

**If Action J**

JPEG capture Password (max 29 ASCII chars):

**If Action T**

Type (2 bytes):

'01' = Local video live

'02' = Local presentation

'03' = Remote video live

'04' = Remote presentation

JPEG capture Password (max 29 ASCII chars):

Data Description:

**FTP Server URL:**

Is the URL of server FTP, for example ftp://192.168.187.5

**FTP Username:**

Is username to access the server FTP

**FTP Password:**

Is password to access the server FTP

**JPEG capture Password:**

Is the password selected in the JPEG capture configuration to avoid that everyone can capture image from system.

This password is empty by default and it can be set in Configure/Advanced/Utilities/Remote Access/Web Video

**NOTES:**

The file saved on FTP server is named image.jpg.

Before the first calling to the 'J' or 'T' command, please configure FTP parameters with 'F', 'U' and 'P' commands.

Other calls to 'J' or 'T' commands can be made without reconfiguring FTP parameters.

Another way to capture the image is to call this HTTP URL  
<https://xxx.xxx.xxx.xxx/web/utls/GetSnapshotEx.php?pw=password> where xxx.xxx.xxx.xxx is the IP address of the XT system and password is the password set in Configure/Advanced/Utilities/Remote Access/Web Video configuration page (by default it is empty).  
 Starting from version 3\_2\_1\_52 you can also use this URL  
<https://xxx.xxx.xxx.xxx/web/utls/GetSnapshotEx.php?pw=password&type=video> where xxx.xxx.xxx.xxx and password are the same as above, and type selects the video source to capture. If video=1 you can capture the local video live, if video=2 you can capture the remote video live, if video = 3 you can capture the local dual video, if video=4 you can capture the remote dual video.  
 Every time you call the HTTP URL, a new image is captured.  
 If SI AT command is used, the image can be downloaded only from FTP site.  
 If HTTP protocol is used, you must not use the SI command.  
 Pay attention that the image could not be downloaded or sent to FTP if the configuration doesn't allow it (not enabled, or IP address constraints or password wrong) or if the system is in power safe state.

---

## 9.21 Recording and Playing Command (SN)

This message is sent by PC to RTE to start or stop recording.  
 RTE sends this message as response to a status request.

**WARNING : Starting from v3.2.x**

Direction: PC -> RTE

Mode: '&'

Type: 'S'

Sub-Type: 'N'

Data: Command:

- 'A' = Action related to recording
- 'P' = Action related to playing (**Starting from v8.3.2.x**)
- 'B' = Set FTP URL (**Starting from v8.3.2.x**)
- 'U' = Set FTP username (**Starting from v8.3.2.x**)
- 'V' = Set FTP password (**Starting from v8.3.2.x**)
- 'C' = Send recorded file to FTP server configured with B action command (**Starting from v8.3.2.x**)

### Command type 'A'

Action type :

- '1' = Start recording
- '2' = Pause recording
- '3' = Resume recording
- '4' = Stop recording

Location:

- '1' = USB storage
- '2' = Scopia® Recording Server

### Command type 'P' (**Starting from v8.3.2.x**)

Index of file to play (5 bytes):

'00001'...'number of files'

Action type :

- '1' = Start playing
- '2' = Pause playing
- '3' = Resume playing
- '4' = Forward playing
- '5' = Backward playing
- '6' = Stop playing

Step for forward or backward: each step is 30 seconds (two bytes) :  
'00' ... '99'

**Command type 'B' (Starting from v8.3.2.x)**  
FTP Server URL (max 60 ASCII chars)

**Command type 'U' (Starting from v8.3.2.x)**  
FTP Username (max 60 ASCII chars)

**Command type 'V' (Starting from v8.3.2.x)**  
FTP Password (max 60 ASCII chars):

**Command type C (Starting from v8.3.2.x)**  
File Index (5 bytes) :  
'00001' .... 'number of files'

Direction: PC -> RTE

Mode '?'

Type: 'S'

Sub-Type 'N'

Data: Command:

'A' = Status of action related to recording

'S' = Availability of recording

'T' = Time left on USB device

'P' = Playing information (Starting from v8.3.2.x)

'F' = File to play information (Starting from v8.3.2.x)

'N' = Number of files which can play (Starting from v8.3.2.x)

'B' = Total space on USB device (Starting from v8.3.2.5xx)

'D' = Space left on USB device (Starting from v8.3.2.5xx)

**Command type 'A'**  
None

**Command type 'S'**  
None

**Command type 'T'**  
None

**Command type 'P' (Starting from v8.3.2.x)**  
None

**Command type 'F' (Starting from v8.3.2.x)**  
Index of file (5 bytes):  
'00001' ... 'number of files'

**Command type 'N' (Starting from v8.3.2.x)**  
None

**Command type 'B' (Starting from v8.3.2.5xx)**  
None

**Command type 'D' (Starting from v8.3.2.5xx)**  
None

Direction: RTE -> PC

Mode '<'

Type: 'S'

Sub-Type 'N'

Data: Command:

'A' = Status of action related to recording

'S' = Availability of playing/recording

'T' = Time left on USB device

'P' = Playing information (**Starting from v8.3.2.x**)

'F' = File to play information (**Starting from v8.3.2.x**)

'N' = Number of files which can play (**Starting from v8.3.2.x**)

'B' = Total space on USB device (**Starting from v8.3.2.5xx**)

'D' = Space left on USB device (**Starting from v8.3.2.5xx**)

#### Command type 'A'

Status:

'1' = idle

'2' = recording on USB

'3' = paused

'4' = recording on Scopia® Recording Server (**Starting from v8.3.2.5xx**)

'5' = recording initiating on Scopia® Recording Server  
(**Starting from v8.3.4.x**)

Dummy (10 bytes, must be 0)

#### Command type 'S'

Recording Available:

'1' = yes

'0' = no

Playing Available:

'1' = yes

'0' = no

Dummy (9 bytes, must be 0)

#### Command type 'T'

ASCII string in format hh:mm (5 bytes)

#### Command type 'P' (**Starting from v8.3.2.x**)

Status:

'1' = idle

'2' = playing

'3' = paused (**Starting from v8.3.2.5xx**)

Playing time elapsed in seconds (8 bytes) :

'00000000' ... '99999999'

Dummy (10 bytes, must be 0)

#### Command type 'F' (**Starting from v8.3.2.x**)

Index of file (5 bytes):

'00001' ... 'number of files'

Playing time duration in format hh:mm:ss (8 bytes)

Dummy (10 bytes, must be 0)

#### Command type 'N' (**Starting from v8.3.2.x**)

Number of files in the system (5 bytes)

'00000' ... '99999'

#### Command type 'B' (**Starting from v8.3.2.5xx**)

ASCII string in format "number unit-of-measure"

**Command type 'D' (Starting from v8.3.2.5xx)**  
ASCII string in format "number unit-of-measure"

Data Description:

**Location**

This parameter specifies where recording must done. Pay attention that this must be coherent with location set in recording configuration, so if in configuration location is equal to USB, if this command requests to register on Scopia® Recording Server, the command fails.

**Action type:**

After pausing recording only resume or stop action can be performed.

**Time Left on USB device**

This is valid only if recording is available

**Step for forward or backward**

Every step is about 30 second, so if step is '05' playing go forward or backward 2 minutes and 30 seconds

**FTP Server URL:**

Is the URL of server FTP, for example <ftp://192.168.187.5>

**FTP Username:**

Is username to access the server FTP

**FTP Password:**

Is password to access the server FTP

**NOTES:**

The file saved on FTP server has the same name as the original file saved on XT system.

Before the first calling to the 'S' command, please configure FTP parameters with 'B', 'U' and 'V' commands.

Other calls to 'S' commands can be made without reconfiguring FTP parameters.

**Command type 'B' and 'D'**

The total space and the space free left on USB device are expressed as an ASCII string like "10 MB" or "1,5 GB" depending on the number of bytes

---

## 9.22 Local Presentation Command (SQ)

This message is sent by PC to RTE to start or stop recording.

RTE sends this message as response to a status request.

**WARNING : Starting from v3.2.1.x**

Direction: PC -> RTE

Mode: '&'

Type: 'S'

Sub-Type: 'Q'

Data: Command:

'0' = Activation of local Presentation

**Command type '0'**

Action type :

'1' = Start presentation

'0' = Stop presentation

Video Source Index (2 bytes)

'08' = DVI Input

Direction: PC -> RTE

Mode '?'  
Type: 'S'  
Sub-Type 'Q'  
Data: Command:  
          '0' = Local presentation status

**Command type '0'**  
None

Direction: RTE -> PC

Mode '<'  
Type: 'S'  
Sub-Type 'Q'  
Data: Command:  
          '0' = Local presentation status

**Command type 'A'**  
Status:  
          '0' = not activated  
          '1' = activated  
Video Source Index (2 bytes)  
          '08' = DVI Input

Data Description:

---

## 9.23 Do Not Disturb (DND) Command/Status (SR)

This message is sent by RTE to PC to indicate the self-view status.  
PC sends this message to modify or know the self-view status.

**WARNING : Starting from v8.3.x**

Direction: PC -> RTE

Mode '&' / '?'  
Type: 'S'  
Sub-Type 'R'  
Data: Do not disturb (DND):  
          '0' = Disable  
          '1' = Enable

Direction: RTE -> PC

Mode '<'  
Type: 'S'  
Sub-Type 'R'  
Data: Do not disturb (DND):

'0' = Disable

'1' = Enable

---

## 9.24 Control & Indication Error Message (SE)

This message is sent by RTE to notify an error on the received message:

Direction: RTE -> PC

Mode '<'

Type: 'S'

Sub-Type 'E'

Data: Message Type

Sub-type

Error:

'1' = Bad parameter

'2' = Unknown message

'3' = wrong message length

'4' = Bad mode

'5' = Unable to execute command

Sub-code

If Unable to execute command

'0' = system timeout

'1' = system busy

If Bad parameter

Index number of wrong parameter

# 10 Diagnostic Messages

The Diagnostic messages are used to know some HW, SW or feature status.

---

## 10.1 Connection Status (PC)

This message is sent by PC to RTE in order to know the connection status and the status of the local and remote terminal's parameters.

Direction: PC->RTE

Mode: '?'  
Type: 'P'  
Sub-Type: 'C'  
Data: Terminal Number (2 ASCII digits):

Direction: RTE -> PC

Mode: '<'  
Type: 'P'  
Sub-Type: 'C'  
Data: Terminal Number (2 bytes):  
Type (2 bytes):  
    'G0' = Generic Information  
    'N0' = Call number  
    'M0' = Terminal name  
    'RT' = Rate Tx parameters  
    'RR' = Rate Rx parameters  
    'AT' = Audio Tx parameters  
    'AR' = Audio Rx parameters  
    'VT' = Video Tx parameters  
    'VR' = Video Rx parameters  
    'HT' = Dual Video Tx parameters  
    'HR' = Dual Video Rx parameters  
    'PR' = Packet Rx percentage lost (**Starting from v3.1.1.x**)  
    'PT' = Packet Tx percentage lost (**Starting from v3.1.1.x**)  
    'JR' = Packet Rx jitter (**Starting from v8.3.2.x**)  
    'JT' = Packet Tx jitter(**Starting from v8.3.2.x**)

**If Type = 'G0'**

Interface (2 bytes):  
    '01' = LAN  
    '06' = SIP  
Mcu (1 byte):  
    '0' = point-to-point  
    '1' = multiconference activated  
Outgoing (1 byte):  
    '0' = incoming  
    '1' = outgoing  
Dummy (1 byte, must be 0) (**for future expansion**)  
Audio Loop Mode (1 byte):  
    '1' = audio looped



'0' = audio not looped  
 Video Loop Mode (1 byte):  
 '1' = video looped  
 '0' = video not looped  
 Dual Video Loop Mode (1 byte):  
 '1' = dual video looped  
 '0' = dual video not looped  
 H.239(1 byte):  
 '1' = dual video with H.239 protocol  
 '0' = dual video with a proprietary protocol

**If Type = 'N0'**

Call number (max 64 ASCII chars)

**If Type = 'M0'**

Terminal Name (max 64 ASCII chars)

**If Type = 'RT' or Type = 'RR'**

Rate value (fixed to 10 digits)

'000000000' = no rate  
 '0000000001' = 64K  
 '0000000002' = 2x64K  
 '0000000003' = 3x64K  
 '0000000004' = 4x64K  
 '0000000005' = 5x64K  
 '0000000006' = 6x64K  
 '0000000007' = 7x64K  
 '0000000008' = 8x64K  
 '0000000009' = 9x64K  
 '0000000010' = 10x64K  
 '0000000011' = 11x64K  
 '0000000012' = 12x64K  
 '0000000013' = 128K  
 '0000000014' = 192K  
 '0000000015' = 256K  
 '0000000016' = 320K  
 '0000000017' = 384K  
 '0000000018' = 448K  
 '0000000019' = 512K  
 '0000000020' = 768K  
 '0000000021' = 1152K  
 '0000000022' = 1472K  
 '0000000023' = 1536K  
 '0000000024' = 1920K  
 '0000000025' = 2560K  
 '0000000026' = 3072K  
 '0000000027' = 3584K  
 '0000000028' = 4096K  
 '0000000029' = 4608K  
 '0000000030' = 5120K  
 '0000000031' = 5632K  
 '0000000032' = 6144K  
 '0000000033' = 6656K  
 '0000000034' = 7168K  
 '0000000035' = 7680K  
 '0000000036' = 8192K  
 '0000000037' = 8704K  
 '0000000038' = 9216K  
 '0000000039' = 9728K  
 '0000000040' = 10240K  
 '0000000041' = 10752K  
 '0000000042' = 11264K

'0000000043' = 1024K  
'0000000044' = 1280K  
'0000000045' = 1408K  
'0000000046' = 8128K  
'0000000047' = 10240K

All other values represent the real rate value.

Current rate value (fixed to 10 digits)

Same as rate value

**If Type = 'AT' or Type = 'AR'**

Audio Coding (2 bytes)

'00' = Automatic  
'01' = G.711 64K U low  
'02' = G.711 56K U low  
'03' = G.711 48K U low  
'04' = G.711 64K A low  
'05' = G.711 56K A low  
'06' = G.711 48K A low  
'07' = G.722 64K  
'08' = G.722 56K  
'09' = G.722 48K  
'10' = G.728  
'11' = G.722\_1  
'12' = G.722\_1 32K  
'13' = G.722\_1 24K  
'14' = G.723  
'15' = MP4-AACLD  
'16' = MP4-AACLD 48K  
'17' = MP4-AACLD 56K  
'18' = MP4-AACLD 64K  
'19' = MP4-AACLD 128K  
'20' = PT 724  
'21' = PT 716  
'22' = G.722\_1 Annex C  
'23' = G.722\_1 Annex C 24K  
'24' = G.722\_1 Annex C 32K  
'25' = G.722\_1 Annex C 48K  
'26' = G.729 A  
'28' = G.719 32K  
'29' = G.719 48K  
'30' = G.719 64K  
'31' = G.719 96K  
'32' = G.719 128K  
'27' = Audio Off

Audio bit rate value (fixed to 10 digits)

Audio frame/packet value (fixed to 5 digits)

Audio lost packets value (fixed to 5 digits)

**If Type = 'VT' or Type = 'VR'**

Video Coding (2 bytes)

'00' = Automatic  
'01' = H.261  
'02' = H.261 CIF  
'03' = H.261 QCIF  
'04' = H.263  
'05' = H.263 CIF  
'06' = H.263 QCIF  
'07' = H.263 SQCIF  
'08' = H.263 4QCIF  
'09' = H.263 1280x1024  
'10' = H.263 1024x768  
'11' = H.263 800x600

'12' = H.263 640x480  
 '13' = H.263 SIF  
 '14' = H.263 4SIF  
 '15' = H.263 ICIF  
 '16' = H.263 ISIF  
 '17' = H.264/H.265  
 '18' = H.264/H.265 CIF  
 '19' = H.264/H.265 QCIF  
 '20' = H.264/H.265 SQCIF  
 '21' = H.264/H.265 4CIF  
 '22' = H.264/H.265 1280x1024  
 '23' = H.264/H.265 1024x768  
 '24' = H.264/H.265 800x600  
 '25' = H.264/H.265 640x480  
 '26' = H.264/H.265 SIF  
 '27' = H.264/H.265 4SIF  
 '28' = H.264/H.265 ICIF  
 '29' = H.264/H.265 ISIF  
 '30' = H.263 320x240  
 '31' = H.263 528x400  
 '32' = H.263 576x448  
 '33' = H.263 512x288  
 '34' = H.263 768x448  
 '35' = H.263 1024x576  
 '36' = H.263 1280x720  
 '37' = H.263 Custom  
 '38' = H.264/H.265 320x240  
 '39' = H.264/H.265 528x400  
 '40' = H.264/H.265 576x448  
 '41' = H.264/H.265 512x288  
 '42' = H.264/H.265 768x448  
 '43' = H.264/H.265 1024x576  
 '44' = H.264/H.265 1280x720  
 '45' = H.264/H.265 Custom  
 '46' = H.264/H.265 Sharpness  
 '48' = H.261 Custom  
 '49' = H.264/H.265 1920x1080  
 '50' = H.263 1920x1080  
 '51' = H.264/H.265 400x224  
 '52' = H.263 400x224  
 '53' = H.264/H.265 1280x768  
 '54' = H.264/H.265 1440x900  
 '55' = H.264/H.265 1680x1050  
 '56' = H.264/H.265 1600x1200  
 '57' = H.264/H.265 1920x1200  
 '58' = H.264/H.265 624x352  
 '59' = H.264/H.265 576x336  
 '47' = Video Off

Video used bit rate value (fixed to 10 digits)

Video max bit rate value (fixed to 10 digits)

Video frame rate value (fixed to 5 digits)

Video lost packets value (fixed to 5 digits)

Video Annex F:

'1' = used

'0' = not used

Video Annex I:

'1' = used

'0' = not used

Video Annex J:

'1' = used

'0' = notused  
 Video Annex T:  
 '1' = used  
 '0' = notused  
 Video width value in pixels (fixed to 5 digits)  
 Video height value in pixels (fixed to 5 digits)  
 Video H.264/H.265 Profile Type (2 bytes) **(Starting from v3.x)**:  
 '00' = H.264 base Profile  
 '01' = H.264 High Profile  
 '02' = H.264 TSVC Profile  
 '03' = H.264 High-TSVC Profile  
 '04' = H.265 base Profile **(Starting from v8.3.2.222)**  
 '05' = H.265 TSVC Profile **(Starting from v8.3.2.222)**

**If Type = 'HT' or Type = 'HR'**

Dual video Coding (2 bytes)  
**See video coding values used for video**  
 Dual video used bit rate value (fixed to 10 digits)  
 Dual video max bit rate value (fixed to 10 digits)  
 Dual video frame rate value (fixed to 5 digits)  
 Dual video lost packets value (fixed to 5 digits)  
 Dual video Annex F:  
 '1' = used  
 '0' = not used  
 Dual video Annex I:  
 '1' = used  
 '0' = not used  
 Dual video Annex J:  
 '1' = used  
 '0' = not used  
 Dual video Annex T:  
 '1' = used  
 '0' = not used  
 Dual video width value in pixels (fixed to 5 digits)  
 Dual video height value in pixels (fixed to 5 digits)  
 Video H.264/H.265 Profile Type (2 bytes) **(Starting from v3.x)**:  
 '00' = H.264 base Profile  
 '01' = H.264 High Profile  
 '02' = H.264 TSVC Profile  
 '03' = H.264 High-TSVC Profile  
 '04' = H.265 base Profile **(Starting from v8.3.2.222)**  
 '05' = H.265 TSVC Profile **(Starting from v8.3.2.222)**

**If Type = 'DT' or Type = 'DR'**

T.120 opened:  
 '1' = opened  
 '0' = closed  
 H.224 opened:  
 '1' = opened  
 '0' = closed  
 Dummy (10 bytes, must be 0) **(for future expansion)**  
 Dummy (10 bytes, must be 0) **(for future expansion)**  
 Dummy (10 bytes, must be 0) **(for future expansion)**  
 Dummy (10 bytes, must be 0) **(for future expansion)**

**If Type = 'PT' or Type = 'PR' (Starting from v3.1.1.x)**

Video lost packet percentage (fixed to 2 digits)  
 Dual Video lost packet percentage (fixed to 2 digits)  
 Audio lost packet percentage (fixed to 2 digits)

If Type = 'JT' or Type = 'JR' (Starting from v8.3.2.x)

Video jitter (msec) :

ASCII string NOT null terminated 4 bytes in format x.xx

Dual Video Video jitter (msec))

ASCII string NOT null terminated 4 bytes in format x.xx

Audio jitter (msec)

ASCII string NOT null terminated 4 bytes in format x.xx

Dummy (40 bytes, must be 0) (for future expansion)

Data Description:

**Terminal Number:**

If the system is connected point-to-point, this value is always "00". If the system manage a multiconference, this value can be the number of the terminal connected (the same number that you can see in the system interface).

---

## 10.2 System's serial numbers (PS)

This message is sent by PC to RTE in order to know system's serial numbers.

Direction: PC->RTE

Mode '?'

Type: 'P'

Sub-Type 'S'

Data: Serial number type

'1' = Codec serial number

'2' = Board serial number

Direction: RTE -> PC

Mode '<'

Type: 'P'

Sub-Type 'S'

Data: Serial number type :

'1' = Codec serial number

'2' = Board serial number

Serial number (max 32 ASCII chars)

---

## 10.3 Call Interface Status (PG)

This message is sent by PC to RTE in order to know if there are some errors on the call interface.

Direction: PC->RTE

Mode '?'

Type: 'P'

Sub-Type 'G'

Data: Call interface:

'E' = Link Eth0

'F' = Link Eth1  
'G' = Gatekeeper  
'P' = Proxy  
'R' = Registrar

Direction: RTE -> PC

Mode: '<'  
Type: 'P'  
Sub-Type: 'G'  
Data: Call Interface:

**If Call Interface = 'E'**

Status :

'0' = Physical is down  
'1' = Physical is up  
'2' = Address conflict (**Starting from v8.3.2.x**)

**If Call Interface = 'F'**

Status :

'0' = Physical is down  
'1' = Physical is up  
'2' = Address conflict (**Starting from v8.3.2.x**)

**If Call Interface = 'G'**

Status :

'0' = Gatekeeper is not connected or disabled  
'1' = Gatekeeper is connected  
'2' = Gatekeeper registration is in progress (**Starting from v8.3.2.x**)

**If Call Interface = 'P'**

Status :

'0' = Proxy is not connected  
'1' = Proxy is connected  
'2' = Proxy registration is in progress (**Starting from v8.3.2.x**)

**If Call Interface = 'R'**

Status :

'0' = Registrar is not connected  
'1' = Registrar is connected  
'2' = Registrar registration is in progress (**Starting from v8.3.2.x**)

---

## 10.4 Download status (PD)

This message is sent by PC to RTE in order to know if a download is finished in a correct manner.

Direction: PC->RTE

Mode: '?'  
Type: 'P'  
Sub-Type: 'D'  
Data: None

Direction: RTE -> PC

Mode '<'  
Type: 'P'  
Sub-Type 'D'  
Data: Status:  
          '0' = Download not completed  
          '1' = Download completed  
          Dummy (1 byte, must be 0) (**for future expansion**)

---

## 10.5 Debug log file management (PL)

This message is sent by PC to RTE in order to set the log debug file enabled and levels of debug.

Direction: PC->RTE

Mode '&'  
Type: 'P'  
Sub-Type 'L'  
Data: Enable Log:  
          '0' = not enable  
          '1' = enable  
      Module to debug:  
          '0' = Automatic  
          '1' = Call  
          '2' = Graphic  
          '3' = System  
      Level of debug:  
          '0' = Level 0  
          '1' = Level 1  
          '2' = Level 2  
          '3' = Level 3  
          '4' = Level 4  
          '5' = Level 5

---

## 10.6 Audio test (PA)

This message is sent by PC to RTE in order to produce a sound.

Direction: PC->RTE

Mode '&'  
Type: 'P'  
Sub-Type 'A'  
Data: Sound Type:  
          '1' = Continuous tone  
          '2' = Ring  
      Status:

'0' = Stop  
'1' = Start  
Dummy (1 byte, must be 0) (for future expansion)

---

## 10.7 Generic System Info (PI)

This message is sent by PC to RTE in order to get some system generic info.

Direction: PC->RTE

Mode '?'  
Type: 'P'  
Sub-Type 'I'  
Data: None

Direction: RTE -> PC

Mode '<'  
Type: 'P'  
Sub-Type 'I'  
Data: System Type (2 bytes):  
      '01' = XT1000  
      '02' = XT5000  
      '03' = XT7000 (**Starting from v8.3.7.x**)  
      System Sub-Type (2 bytes):  
          '00' = No subtype  
          '01' = Piccolo or XT4200  
          '02' = Executive (**Starting from v3.1.1.x**)  
          '03' = IP Office (**Starting from v3.2.x**)  
          '04' = 720p (**Starting from v3.2.x**)  
          '05' = XT3100 (**Starting from v8.3.2.x**)  
          '06' = XT4300 (**Starting from v8.3.2.x**)  
      System Board (2 bytes):  
          '01' = Hermes  
          '02' = Phoenix  
      Dummy (5 bytes, must be 0) (for future expansion)

---

## 10.8 System Model Name (PIS)

This message is sent by PC to RTE in order to get the system model name.  
**WARNING : Starting from v3.1.1.x**

Direction: PC->RTE

Mode '?'  
Type: 'P'  
Sub-Type 'I'



Data: Information:  
'S' = System model name

Direction: RTE -> PC

Mode '<'

Type: 'P'

Sub-Type 'I'

Data: Information:  
'S' = System model name

**If Information = S**

System model name (max 64 ASCII chars)

---

## 10.9 System component Status (PB)

This message is sent by PC to RTE in order to get system component status info.

Direction: PC->RTE

Mode '?'

Type: 'P'

Sub-Type 'B'

Data: Type of component:

'B' = Remote control battery state

'T' = Internal Temperature

'A' = Audio input/output connection status (**Starting from v8.3.2.201**)

'V' = Video input/output connection status (**Starting from v8.3.2.201**)

'P' = Audio input/output peak and noise level (**Starting from v8.3.2.5xx**)

**If type of component 'B':**

None

**If type of component 'T':**

None

**If type of component 'A':**

None

**If type of component 'V':**

None

**If type of component 'P': (**Starting from v8.3.2.5xx**)**

Audio source (2 bytes):

'01' = POD1 audio input

'02' = POD2 audio input

'03' = Digital audio input

'04' = HD1 audio input

'05' = HD2 audio input (valid only for XT7000)

'06' = Analog audio input

'07' = USB camera audio input

'08' = USB microphone audio input

'09' = Track1 audio output

'10' = Track2 audio output

'11' = Tx audio stream  
'12' = Rx audio stream

Direction: RTE -> PC

Mode: '<'

Type: 'P'

Sub-Type: 'B'

Data: Type of component:

'B' = Remote control battery state

'T' = Internal Temperature

'A' = Audio input/output connection status (**Starting from v8.3.2.201**)

'V' = Video input/output connection status (**Starting from v8.3.2.201**)

'P' = Audio input/output peak and noise level (**Starting from v8.3.2.5xx**)

**If component 'B':**

'1' = Charged

'2' = Half Charged

'3' = Not Charged

**If component 'T':**

Temperature in Celsius degrees (2 bytes):

'00' ... '99'

**If component 'A':**

POD1 input:

'0' = no cable

'1' = connected

POD2 input:

'0' = no cable

'1' = connected

HD1 input:

'0' = no cable

'1' = connected

HD2 input (only XT7000):

'0' = no cable

'1' = connected

USB camera input:

'0' = no cable

'1' = connected

USB microphone input:

'0' = no cable

'1' = connected

Digital input:

'0' = no cable

'1' = connected

Analog input:

'0' = no cable

'1' = connected

HD1 output:

'0' = no cable

'1' = connected

HD2 output:

'0' = no cable

'1' = connected

USB headset output:

'0' = no cable

'1' = connected

Digital output:  
    '0'= no cable  
    '1'= connected  
Analog output:  
    '0'= no cable  
    '1'= connected  
Dummy (7 bytes, must be 0) (**for future expansion**)

**If component 'V':**  
    HD1 camera:  
        '0'= no cable  
        '1'= connected  
    HD2 camera (only XT7000):  
        '0'= no cable  
        '1'= connected  
    DVI camera:  
        '0'= no cable  
        '1'= connected  
    USB camera:  
        '0'= no cable  
        '1'= connected  
    HD1 monitor:  
        '0'= no cable  
        '1'= connected  
    HD2 monitor:  
        '0'= no cable  
        '1'= connected  
    Dummy (14 bytes, must be 0) (**for future expansion**)

**If type of component 'P': (Starting from v8.3.2.5xx)**  
    Audio source (2 bytes) (see above):  
    Peak value channel 1 (2 bytes):  
        '00'...'60'  
    Peak value channel 2 (2 bytes)  
        '00'...'60'  
    Peak value channel 3 (2 bytes)  
        '00'...'60'  
    Noise value channel 1 (2 bytes)  
        '00'...'60'  
    Noise value channel 2 (2 bytes)  
        '00'...'60'  
    Noise value channel 3 (2 bytes)  
        '00'...'60'

---

## 10.10 Diagnostic Error Message (PE)

This message is sent by RTE to notify an error on the received message:

Direction:     RTE -> PC  
  
Mode            '<'  
Type:           'D'  
Sub-Type       'E'  
Data:           Message Type  
                Sub-type

Error:

- '1' = Bad parameter
- '2' = Unknown message
- '3' = wrong message length
- '4' = Bad mode
- '5' = Unable to execute command

Sub-code

If Unable to execute command

'0' = system timeout

'1' = system busy

If Bad parameter

Index number of wrong parameter