



Avaya Solution & Interoperability Test Lab

---

## **Application Notes for Configuring the Linksys WRT55AG Dual-band A+G Wireless Router to Support Avaya Communication Manager, Avaya IP Wireless Telephones and Avaya IP Softphone - Issue 1.0**

### **Abstract**

These Application Notes describe the procedure for configuring the Linksys WRT55AG Dual-band A+G Wireless Router to support Avaya Communication Manager, Avaya IP Wireless Telephones and Avaya IP Softphone. Features and functionality were validated.

# 1. Introduction

These Application Notes describe the steps to configure Linksys WRT55AG Dual-band A+G Wireless Router to support Avaya Communication Manager, Avaya IP Wireless Telephones and Avaya IP Softphone. The Linksys WRT55AG Wireless Router supports WEP encryption, but not 802.1x authentications. These Application Notes cover the following areas:

- System IP and Wireless 802.11a and 802.11g radio configuration.
- Wired Equivalent Privacy (WEP) encryption configuration
- Windows XP Wireless Client configuration

These Application Notes do not cover the configuration for Avaya IP Wireless Telephones and Avaya IP Softphone. For detailed configuration of these devices, refer to the Application Notes listed in the Section 8.

The version of Linksys firmware validated in these Application Notes does not support Spectralink Voice Priority (SVP), which is a requirement for guaranteeing over the air Quality of Service (QoS). The lack of support for this feature limits deployment options for this solution.

**Figure 1** shows the network configuration used for verification.




**Figure 1: Network Configuration**

**Table 1** lists the IP addresses and subnet masks for the tested devices.

| Device                                                                                                               | VLAN            | IP Address/Mask                           | Gateway                          |
|----------------------------------------------------------------------------------------------------------------------|-----------------|-------------------------------------------|----------------------------------|
| Avaya S8500 Media Server                                                                                             | VLAN 1          | 50.1.1.5 /24                              | 50.1.1.1                         |
| Avaya G650 Media Gateway <ul style="list-style-type: none"> <li>• IPSI</li> <li>• C-LAN</li> <li>• MEDPRO</li> </ul> | VLAN 1          | 50.1.1.6/24<br>50.1.1.7/24<br>50.1.1.8/24 | 50.1.1.1<br>50.1.1.1<br>50.1.1.1 |
| Avaya Voice Priority Processor                                                                                       | VLAN 1          | 50.1.1.9/24                               | 50.1.1.1                         |
| Avaya C360 Switch                                                                                                    | VLAN20          | 20.1.1.2/24                               | 20.1.1.1                         |
| Linksys Dual-band A+G Wireless Router                                                                                | VLAN 20         | 20.1.1.11/24                              | 20.1.1.1                         |
| Extreme Alpine 3804 Switch                                                                                           | VLAN1<br>VLAN20 | 50.1.1.1/24<br>20.1.1.1/24                | N/A<br>N/A                       |
| Avaya 3626 Wireless Telephone                                                                                        | VLAN20          | 20.1.1.100                                | 20.1.1.1                         |
| Avaya 3616 Wireless Telephone                                                                                        | VLAN20          | 20.1.1.101                                | 20.1.1.1                         |
| Avaya IP Softphone installed on Windows XP Laptop                                                                    | VLAN20          | 20.1.1.122                                | 20.1.1.1                         |

**Table 1: Devices IP Address and Gateway**

## 2. Equipment and Software Validated

**Table 2** lists the equipment and software version used for the configuration.

| Equipment                                                                                                                      | Software                                     |
|--------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------|
| Avaya S8500 Media Server/G650 Media Gateway with                                                                               | Communication Manager 2.2 (R012x.02.0.111.4) |
| Avaya IP Softphone                                                                                                             | V5.0.1.2                                     |
| Avaya 4620SW/4610SW IP telephones                                                                                              | R2.01                                        |
| Avaya 3616/3626 Wireless IP Phone                                                                                              | 96.024                                       |
| Avaya Voice Priority Processor                                                                                                 | R32/21                                       |
| Avaya C360 Stackable Switch                                                                                                    | R4.3.12                                      |
| Linksys Dual-band A+G Wireless Router WRT55AG                                                                                  | V1.04                                        |
| Extreme Alpine 3804 Switch                                                                                                     | V7.2.0b25                                    |
| Dell Latitude D800 Laptop with <ul style="list-style-type: none"> <li>▪ Windows XP Professional with Service Pack 1</li> </ul> | Version 2002                                 |


**Table 2: Equipment and Software Validated**

### 3. Configure the Linksys Dual-band A+G Wireless Router



The configuration can be done using a web-based interface. Assume that the IP address 20.1.1.11 has been pre-configured on the WRT55AG Router. The following sessions display the related configuration using web-based interface.

#### 3.1. Basic System and Wired Equivalent Privacy (WEP) Configuration

This section presents the steps necessary for basic system and WEP configuration. The WRT55AG has both 802.11a and 802.11g radio interfaces. In these Application Notes, the “g” radio is configured to accept both 802.11b and 802.11g clients in order to support the Avaya IP 3616 and 3626 IP Wireless Telephones. Note that the Avaya 3626 and 3616 series Wireless Telephones currently only operate in b mode. WEP encryption is only enabled on the 802.11g radio interface since the configuration for the 802.11a radio interface is the same.


| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.   | <ul style="list-style-type: none"><li>Launch a web browser with the URL http://20.1.1.11. Log into the Access Point with proper user name and password as shown below.</li></ul> <div data-bbox="506 837 1302 1346"></div>                                                                                                                                                                                                                                                                                                                                                                                                                            |
| 2.   | <ul style="list-style-type: none"><li>After login, click the <b>Setup</b> tab.</li><li>Verify that the IP address <b>20.1.1.11</b> and Subnet mask <b>255.255.255.0</b> are in the corresponding fields.</li><li>Select <b>Enable</b> mode for 802.11a radio and enter <b>linksysa</b> as its <b>SSID</b>.</li><li>Leave <b>WEP</b> disabled, the default setting.</li><li>Select <b>Mixed</b> mode for 802.11g radio. (Note that the Mixed mode allows “802.11g” radio to accept both 802.11b and 802.11g clients).</li><li>Enter <b>linksysb</b> as its <b>SSID</b> and select <b>Enable</b> for <b>SSID Broadcast</b>.</li><li>Click <b>Enable</b> for <b>WEP</b> and click <b>Edit WEP Settings</b> button as shown below.</li></ul> |


| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      |  <p>The screenshot displays the Linksys 802.11AG Wireless Router Setup interface within a Microsoft Internet Explorer browser window. The browser's address bar indicates the URL <code>http://20.1.1.11/setup_dhcp.asp</code>. The setup page features a blue sidebar on the left with a 'Setup' tab selected. The main content area includes tabs for 'Setup', 'Security', 'System', 'DHCP', and 'SNMP'. The 'Setup' tab is active, showing configuration options for the router. The 'Firmware Version' is 1.04, Jun. 30, 2003. The 'Time Zone' is set to (GMT-08:00) Pacific Time (USA &amp; Canada), with a checkbox for 'Automatically adjust clock for daylight saving changes' checked. The 'Internet' section shows the MAC Address as 00:0C:41:D8:8A:7B, and the 'Connection Type' is set to 'Automatic Configuration - DHCP'. The 'LAN' section shows the MAC Address as 00:0C:41:D8:8A:7A, and the IP Address is 20.1.1.11. The 'Wireless' section shows the 5GHz 802.11a and 2.4GHz 802.11g modes, with the SSID set to 'linksysa' and 'linksysg' respectively. The 'WEP' section shows 'Enable' and 'Disable' options. The 'MAC Address' field is 00:0F:66:ED:B2:83. The 'SSID Broadcast' is set to 'Enable'. The 'Apply', 'Cancel', and 'Help' buttons are at the bottom.</p> |

| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | <ul style="list-style-type: none"> <li>Click <b>1</b> for the <b>Default Transmit Key</b>.</li> <li>Select 64 bits/10 hex digits as <b>WEP Encryption</b> key.</li> <li>Enter the key in the <b>Key 1</b> field. In this configuration, the key <b>1234567890</b> is used.</li> <li>Click <b>Apply</b>.</li> </ul>  <ul style="list-style-type: none"> <li>Click the <b>Continue</b> button to go back to the configuration menu.</li> </ul>  |


## 3.2. Windows XP Wireless Client Configuration


This section presents the Windows XP Wireless client configuration on the Dell Latitude D800 laptop. The Dell Latitude D800 laptop has a built-in Wireless interface. This configuration verifies that the Avaya IP Softphone can use this client to communicate with Avaya Communication Manager with WEP enabled.

| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.   | <p>Assume that the IP address <b>20.1.1.160/24</b> and default gateway <b>20.1.1.1</b> have been configured on the Wireless interface. The laptop will use “802.11g” radio to connect to the Access Point.</p> <p>From the Laptop desktop, click <b>Start → Connect To → Wireless Network Connection</b> to open the <b>Wireless Network Connection Status</b> menu as shown below.</p> <ul style="list-style-type: none"><li>Click the <b>Properties</b> button as shown below.</li></ul>  |

| Step | Description                                                                                                                                                                   |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2.   | <ul style="list-style-type: none"> <li>Click the <b>Wireless Networks</b> tab.</li> </ul>  |

| Step | Description                                                                                                                                                                                                                                            |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3.   | <ul style="list-style-type: none"> <li>• Check the <b>Use Windows to configure my network settings</b> box.</li> <li>• Under the <b>Available networks</b>, highlight <b>linksysg</b> and click the <b>Configure</b> button as shown below.</li> </ul> |



| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4.   | <ul style="list-style-type: none"> <li>Click the <b>Association</b> tab.</li> <li>Select <b>Open</b> in the <b>Network Authentication</b> field.</li> <li>Select <b>WEP</b> in the <b>Data encryption</b> field.</li> <li>Select <b>1</b> in the <b>Key index (advanced)</b> field. Make sure to match the key 1 configured in Linksys AP.</li> <li>Click <b>OK</b>.</li> </ul>  |

## 4. Configure the Avaya Voice Priority Processor

The Avaya Voice Priority Processor (AVPP) functions as a Wireless VoIP gateway and provides voice priority service for IP Wireless telephones. The following steps describe the configuration. Each IP network (subnet) requires one Avaya Voice Priority Processor.

| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.   | Using a console cable, connect the Avaya Voice Priority Processor to the PC.                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| 2.   | <p>Start a HyperTerminal session to the Avaya Voice Priority Processor.</p> <ul style="list-style-type: none"><li>• Bits per second <b>9600</b></li><li>• Data bits <b>8</b></li><li>• Parity <b>None</b></li><li>• Stop bits <b>1</b></li><li>• Flow control <b>None</b></li></ul>                                                                                                                                                                                                                                                       |
| 3.   | <p>Provide the <b>User Name</b> and <b>Password</b> to access the Avaya Voice Priority Processor.</p> <ul style="list-style-type: none"><li>• The <b>Gateway Connection Selection</b> window will be displayed.</li></ul> <div><pre>NetLink SVP-II System Hostname: [slnk_00d07e], Address: 0.0.0.0  System Status SVP-II Configuration <b>Network Configuration</b> Change Password Exit  Enter=Select          X=Exit      Use Arrow Keys to Move Cursor</pre></div> <p>Select <b>Network Configuration</b> and press <b>Enter</b>.</p> |
| 4.   | <p>The <b>Network Configuration</b> window will be displayed.</p> <ul style="list-style-type: none"><li>• Provide the following information:<ul style="list-style-type: none"><li>o <b>IP Address</b> = 50.1.1.9</li><li>o <b>Subnet Mask</b> = 255.255.255.0</li><li>o <b>Default Gateway</b> = 50.1.1.1</li></ul></li></ul>                                                                                                                                                                                                             |

| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | <pre> Network Configuration Hostname: [slnk_00d07e], Address: 0.0.0.0  Ethernet Address (fixed):      00:90:7A:00:D0:7E <b>IP Address:</b>                  <b>50.1.1.9</b> Hostname:                      slnk_00d07e <b>Subnet Mask:</b>                <b>255.255.255.0</b> <b>Default Gateway:</b>           <b>50.1.1.1</b> SVP-II TFTP Download Master:  NONE Primary DNS Server:           NONE Secondary DNS Server:         NONE DNS Domain:                   NONE WINS Server:                  NONE Workgroup:                    WORKGROUP Syslog Server:                NONE Maintenance Lock:             N  Enter=Change      Esc=Exit      Use Arrow Keys to Move Cursor  • Press <b>Enter</b> </pre> |
| 5.   | <p>On the <b>NetLink SVP-II System</b> window:</p> <ul style="list-style-type: none"> <li>Select <b>SVP-II Configuration</b>, and press <b>Enter</b>.</li> </ul> <pre> NetLink SVP-II System Hostname: [slnk_00d07e], Address: 50.1.1.9  System Status <b>SVP-II Configuration</b> Network Configuration Change Password Exit  Enter=Select      X=Exit      Use Arrow Keys to Move Cursor </pre>                                                                                                                                                                                                                                                                                                                      |
| 6.   | <p>On the <b>SVP-II Configuration</b> window:</p> <ul style="list-style-type: none"> <li>Select <b>Reset System</b>, and press <b>Enter</b>.</li> </ul> <p>This will reconfigure the AVPP with current settings.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

| Step | Description                                                                                                                                                                                                                                                                                       |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|      | <p>SVP-II Configuration</p> <p>Hostname: [slnk_00d07e], Address: 50.1.1.9</p> <p>Phones per Access Point: 5</p> <p>SVP-II Mode: Netlink IP</p> <p>System Locked: N</p> <p>Maintenance Lock: N</p> <p>Reset System</p> <p>Enter=Change      Esc=Exit      Use Arrow Keys to Move</p> <p>Cursor</p> |


## 5. Avaya S8500 Media Server and G650 Media Gateway


This section describes the steps necessary to configure the Avaya S8500 Media Server with a G650 Media Gateway.

### 5.1. Configuring Avaya S8500 Media Server Ethernet Interfaces

The Avaya S8500 Media Server is configured using a web interface. To access the web interface, connect a computer's Ethernet interface to the services port of the Avaya S8500 Media Server with a crossover Ethernet cable. The services port uses the pre-configured IP address 192.11.13.6 with mask 255.255.255.252. Configure the computer's IP address as 192.11.13.5 with mask 255.255.255.252. Launch a web browser with the URL <http://192.11.13.6>. After logging in, click **Launch Maintenance Web Interface** to get to the main menu on the left hand side. Click **Configure Server** from the lower left of this main menu.

The Avaya S8500 Media Server has two IP interfaces. Ethernet 1 is used for the control network to communicate with the IPSI circuit pack of the Avaya G650 Media Gateway. Ethernet 2 is dedicated to the services port.

| Step | Description                                                                                                                                                                                                                                                                                                                                        |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.   | <p data-bbox="269 268 704 304"><b>Configuring S8500 Media Server</b></p> <ul data-bbox="318 346 1133 415" style="list-style-type: none"> <li>• Click <b>Set Identities</b> and enter the information shown below.</li> <li>• Click <b>Continue</b>.</li> </ul>  |

| Step | Description                                                                                                                                                                                                                                                                                                                                                         |
|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2.   | <p data-bbox="269 233 846 268"><b>Configuring S8500 Media Server Interfaces</b></p> <ul data-bbox="318 310 1235 380" style="list-style-type: none"> <li>• Click <b>Configure Interfaces</b> and enter the information shown below.</li> <li>• Click <b>Continue</b>.</li> </ul>  |

## 5.2. Configuring IPSI on the Avaya G650 Media Gateway

The IP address of an IPSI board has to be configured via its services port. To configure the IPSI board, connect the computer (already configured with the services IP address and mask as above) to the services port of the IPSI. Telnet to 192.11.13.6 and supply the appropriate login credentials. The following screenshot illustrates the appropriate commands. The IPSI IP address is configured to **50.1.1.6** with default gateway **50.1.1.1**.

| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.   | <p><b>Configuring IPSI</b></p> <pre>TN2312 IPSI IP Admin Utility Copyright Avaya Inc, 2000, 2001, All Rights Reserved [IPSI]: ipsilogin Login: craft Password: [IPADMIN]: set control interface 50.1.1.6 255.255.255.0 WARNING!! The control network interface will change upon exiting IPADMIN [IPADMIN]: set control gateway 50.1.1.1 WARNING!! The control network interface will change upon exiting IPADMIN [IPADMIN]: set VLAN tag off [IPADMIN]: set diffserv 46  [IPADMIN]: show control interface  Control Network IP Address = 50.1.1.6 Control Network Subnetmask = 255.255.255.0 Control Network Default Gateway = 50.1.1.1 IPSI is not configured for DHCP IP address administration  [IPADMIN]: show qos  QoS values currently in use: VLAN tagging      :      off VLAN id           :      0 VLAN user priority :      6 Diffserv value    :      46</pre> |

### 5.3. Configuring the Avaya Media Server and Media Gateway

This section presents the relevant configuration for Avaya Communication Manager software to administer an Avaya S8500 Media Server with Avaya G650 Media Gateway. The Avaya Communication Manager SAT screens can be accessed using “telnet 192.11.13.6 5023” from a computer connected to the server’s services port, or “telnet 50.1.1.5 5023” through the control network.

| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1.   | <p><b>Enable IPSI</b></p> <p>Use the command <b>change system-parameters ipserver-interface</b> to globally enable the server to control the IPSI installed in slot A1 on the gateway. Set the field <b>IPSI Control of Port Networks</b> to <b>enabled</b> as shown below.</p> <pre>change system-parameters ipserver-interface       IP SERVER INTERFACE (IPSI) SYSTEM PARAMETERS  SERVER INFORMATION        IPSI Host Name Prefix: Primary Control Subnet Address: . . . . Secondary Control Subnet Address: . . . .  OPTIONS        Switch Identifier: A       IPSI Control of Port Networks: enabled</pre> |
| 2.   | <p><b>Add data-module for C-LAN</b></p> <p>Use the command <b>add data-module</b> to enable the C-LAN. Set the field <b>Type</b> to <b>ethernet</b> and the field <b>Port</b> to the C-LAN circuit pack (from <b>list configuration all</b>) location with port 17. The following snapshot displays the C-LAN configuration.</p> <pre>display data-module 20000  DATA MODULE  Data Extension: 20000      Name: C-LAN Type: ethernet Port: 01A0317 Link: 1</pre>                                                                                                                                                 |

| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3.   | <p><b>Add Cabinet</b></p> <p>Use the command <b>add cabinet X</b> (X is the cabinet number) to add a cabinet for the G650 gateway. <b>Cabinet Layout</b> must be configured as <b>G650-rack-mount-stack</b> for the Avaya G650 Media Gateway.</p> <pre> add cabinet 1 CABINET CABINET DESCRIPTION     Cabinet: 1     Cabinet Layout: G650-rack-mount-stack     Cabinet Type: expansion-portnetwork      Location: 1  Rack:          Room:          Floor:          Building:  CARRIER DESCRIPTION Carrier      Carrier Type      Number E            not-used D            not-used C            not-used B            not-used A            G650-port </pre>                                                                                                                                                                                                                                                           |
| 4.   | <p><b>Add G650 Media Gateway</b></p> <p>Use the command <b>add ipserver-interface X</b> (X is the cabinet number) to add a G650 Media Gateway. Type the IPSI IP address (50.1.1.6 in this sample configuration) in the <b>Host</b> field. The following displays the ipserver-interface configuration. Note that QoS parameters are configured for the communication from the Avaya S8500 Media Server to the IPSI of the Avaya G650 Media Gateway.</p> <pre> display ipserver-interface 1 IP SERVER INTERFACE (IPSI) ADMINISTRATION - PORT NETWORK 1  IP Control? y                               Socket Encryption? n                                            Enable QoS? y  Primary IPSI                                QoS Parameters ----- Location: 1A02                               Call Control 802.1p: 6 Host: 50.1.1.6                               Call Control DiffServ: 46 DHCP ID: ipsi-A01a </pre> |

| Step | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5.   | <p data-bbox="269 262 737 298"><b>Configuring C-LAN and MEDPRO</b></p> <p data-bbox="269 300 1461 443">Use the command <b>add ip-interface</b> to add and configure the C-LAN and the MEDPRO of the Avaya G650 Media Gateway. The following two screens display the configurations of the C-LAN (01A03) and the MEDPRO (01A04). Note that the C-LAN and MEDPRO are assigned to Network Region 1.</p> <div data-bbox="269 516 1461 995"> <pre data-bbox="269 543 683 573">display ip-interface 01A03</pre> <div data-bbox="808 604 1016 632">IP INTERFACES</div> <div data-bbox="298 663 857 961"> <pre data-bbox="298 663 857 961"> Type: C-LAN Slot: 01A03 Code/Suffix: TN799  D Node Name: C-LAN IP Address: 50.1.1.7 Subnet Mask: 255.255.255.0 Gateway Address: 50.1.1.1 Enable Ethernet Port? y Network Region: 1 VLAN: </pre> </div> <div data-bbox="1159 663 1414 722"> <pre data-bbox="1159 663 1414 722"> ETHERNET OPTIONS Auto? y </pre> </div> </div> <div data-bbox="269 1056 1461 1535"> <pre data-bbox="269 1083 683 1113">display ip-interface 01A04</pre> <div data-bbox="808 1144 1016 1171">IP INTERFACES</div> <div data-bbox="298 1203 857 1501"> <pre data-bbox="298 1203 857 1501"> Type: MEDPRO Slot: 01A04 Code/Suffix: TN2302 Node Name: MedPro IP Address: 50.1.1.8 Subnet Mask: 255.255.255.0 Gateway Address: 50.1.1.1 Enable Ethernet Port? y Network Region: 1 VLAN: </pre> </div> <div data-bbox="1159 1203 1414 1262"> <pre data-bbox="1159 1203 1414 1262"> ETHERNET OPTIONS Auto? y </pre> </div> </div> |
| 6.   | <p data-bbox="269 1629 1461 1808">Use the command <b>change ip-network-region</b> to configure the QoS and other parameters for a network region. Note that Avaya components including C-LAN, MEDPRO, IP telephones, Softphone, and Media Gateways can be configured to a network region. These components will receive QoS and other parameters from their IP network regions' configuration upon their registration.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

Step

Description

change ip-network-region 1

Page1 of 19

IP NETWORK REGION

Region: 1

Location: 1

Home Domain:

Name: Location A

Intra-region IP-IP Direct Audio: yes

Inter-region IP-IP Direct Audio: yes

IP Audio Hairpinning? y

AUDIO PARAMETERS

UDP Port Min: 2048

UDP Port Max: 3028

RTCP Reporting Enabled? y

RTCP MONITOR SERVER PARAMETERS

Use Default Server Parameters? y

DIFFSERV/TOS PARAMETERS

Call Control PHB Value: 34

Audio PHB Value: 46

802.1P/Q PARAMETERS

Call Control 802.1p Priority: 6

Audio 802.1p Priority: 6

AUDIO RESOURCE RESERVATION PARAMETERS

H.323 IP ENDPOINTS

H.323 Link Bounce Recovery? y

Idle Traffic Interval (sec): 20

Keep-Alive Interval (sec): 5

Keep-Alive Count: 5

RSVP Enabled? n

7.

Configure IP codec

Use the command **change ip-codec-set** to select **G.711MU**.

change ip-codec-set 1

Page1 of 1

IP Codec Set

Codec Set: 1

|    | Audio Codec | Silence Suppression | Frames Per Pkt | Packet Size(ms) |
|----|-------------|---------------------|----------------|-----------------|
| 1: | G.711MU     | n                   | 2              | 20              |
| 2: |             |                     |                |                 |
| 3: |             |                     |                |                 |
| 4: |             |                     |                |                 |

8.

Use the **save translation** command to save the configuration.

## 6. Verification Steps

The following verification steps were used in these Application Notes to verify correct system operation:

- Verify network connectivity by launching pings between the S8500 Media Server and Wireless laptop PC. Verify that all pings are successful.
- Power up the Avaya 3616 and 3626 IP Wireless Telephones and verify that they can register with the S8500 Media Server.
- Launch IP Softphone and verify that the IP Softphone can register with the S8500 Media Server.
- Make calls between the two IP Telephones and verify that the voice quality is good.
- Make a call from the 3626 IP Wireless Telephone to the 4620SW IP Telephone, and verify that the voice quality is good
- Enable WEP on both IP Wireless Telephones and verify the call can be placed between these two phones and that the voice quality is good.
- While the call is up, make a conference call to the 4620SW IP Telephone. Verify that all three parties are in conference call and voice quality is good.
- Make a call from IP Softphone to the 4610SW IP Telephone and verify that voice quality is good.

## 7. Conclusion

These Application Notes illustrate the procedures necessary for configuring the Linksys WRT55AG Dual-band A+G Wireless Router to support Avaya IP Wireless Telephones and Avaya IP Softphone. The Linksys WRT55AG Dual-band A+G Wireless Router is able to support 802.11 a/b/g clients and WEP encryption.

## 8. References

Use this URL <http://avaya.com/gcm/master-usa/en-us/pillars/iptelephony/index.htm> to access these Application Notes.

- [1] Configuring the Avaya IP Softphone with Compatible 802.11b Access Points from Avaya and Other Vendors– Issue 1.0
- [2] Configuring the Avaya 3606 Wireless Telephone with Compatible 802.11b Access Points from Avaya and Other Vendors - Issue 1.0
- [3] Application Notes for Configuring 3Com Wireless LAN Access Point 8750 to Support Avaya Communication Manager, Avaya IP Wireless Telephone and Avaya IP Softphone - Issue 1.0

---

**©2005 Avaya Inc. All Rights Reserved.**

Avaya and the Avaya Logo are trademarks of Avaya Inc. All trademarks identified by ® and ™ are registered trademarks or trademarks, respectively, of Avaya Inc. All other trademarks are the property of their respective owners. The information provided in these Application Notes is subject to change without notice. The configurations, technical data, and recommendations provided in these Application Notes are believed to be accurate and dependable, but are presented without express or implied warranty. Users are responsible for their application of any products specified in these Application Notes.

Please e-mail any questions or comments pertaining to these Application Notes along with the full title name and filename, located in the lower right corner, directly to the Avaya Solution & Interoperability Test Lab at [interoplabnotes@list.avaya.com](mailto:interoplabnotes@list.avaya.com).