

Avaya Microsoft Lync Integration and Microsoft Office Communicator Add-in Fundamentals for Avaya Aura[®]

Release 6.2.2 NN10850-014 Issue 02.04 July 2013 All Rights Reserved.

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked websites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on its hardware and Software ("Product(s)"). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support website: http://support.avaya.com. Please note that if you acquired the Product(s) from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya. "Software" means computer programs in object code, provided by Avaya or an Avaya Channel Partner, whether as stand-alone products, or modified versions.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, HTTP://SUPPORT.AVAYA.COM/LICENSEINFO ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC. ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH ÀVAYA OR AN AÚTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Avaya grants you a license within the scope of the license types described below, with the exception of Heritage Nortel Software, for which the scope of the license is detailed below. Where the order documentation does not expressly identify a license type, the applicable license will be a Designated System License. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a different number of licenses or units of capacity is specified in the documentation or other materials available to you. "Designated Processor" means a Single stand-alone computing device. "Server" means a Designated Processor that hosts a software application to be accessed by multiple users.

License types

CPU License (CP). End User may install and use each copy of the Software on a number of Servers up to the number indicated in the order provided that the performance capacity of the Server(s) does not exceed the performance capacity specified for the Software. End User may not re-install or operate the Software on Server(s) with a larger performance capacity without Avaya's prior consent and payment of an upgrade fee.

Named User License (NU). You may: (i) install and use the Software on a single Designated Processor or Server per authorized Named User (defined below); or (ii) install and use the Software on a Server so long as only authorized Named Users access and use the Software. "Named User", means a user or device that has been expressly authorized by Avaya to access and use the Software. At Avaya's sole discretion, a "Named User" may be, without limitation, designated by name, corporate function (e.g., webmaster or helpdesk), an e-mail or voice mail account in the name of a person or corporate function, or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software.

Heritage Nortel Software

"Heritage Nortel Software" means the software that was acquired by Avaya as part of its purchase of the Nortel Enterprise Solutions Business in December 2009. The Heritage Nortel Software currently available for license from Avaya is the software contained within the list of Heritage Nortel Products located at <u>http://support.avaya.com/</u> <u>LicenseInfo</u> under the link "Heritage Nortel Products". For Heritage Nortel Software, Avaya grants Customer a license to use Heritage Nortel Software provided hereunder solely to the extent of the authorized activation or authorized usage level, solely for the purpose specified in the Documentation, and solely as embedded in, for execution on, or (in the event the applicable Documentation permits installation on non-Avaya equipment) for communication with Avaya equipment. Charges for Heritage Nortel Software may be based on extent of activation or use authorized as specified in an order or invoice.

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third Party Components

"Third Party Components" mean certain software programs or portions thereof included in the Software that may contain software (including open source software) distributed under third party agreements ("Third Party Components"), which contain terms regarding the rights to use certain portions of the Software ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed Linux OS source code) and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply is available in the Documentation or on Avaya's website at: <u>http://support.avaya.com/Copyright</u>. You agree to the Third Party Terms for any such Third Party Components.

Preventing Toll Fraud

"Toll Fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud intervention

If you suspect that you are being victimized by Toll Fraud and you need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support website: http://support.avaya.com. Suspected security vulnerabilities with Avaya products should be reported to Avaya by sending mail to: security@avaya.com.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation and Product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation and Product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

Avaya Aura is a registered trademark of Avaya Inc.

Avaya ACE is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners, and "Linux" is a registered trademark of Linus Torvalds.

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support website: <u>http://support.avaya.com</u>.

Contact Avaya Support

See the Avaya Support website: <u>http://support.avaya.com</u> for product notices and articles, or to report a problem with your Avaya product. For a list of support telephone numbers and contact addresses, go to the Avaya Support website: <u>http://support.avaya.com</u>, scroll to the bottom of the page, and select Contact Avaya Support.

Contents

Chapter 1: New in this Release	9
Chapter 2: Introduction	11
Support	. 12
Avaya Mentor videos	. 12
Chapter 3: Avaya Microsoft Lync Integration overview	13
Language support	13
Lync Integration features	14
Lync Integration network	
Lync Integration support for Microsoft Office 365	
Chapter 4: Overview of Lync Integration for CS 1000 Collaboration Pack with Avaya	I.
Aura [®]	19
Collaboration Pack features	
Collaboration Pack administration	
Chapter 5: Lync Integration key components	
Microsoft Lync 2010 client	
Avaya Microsoft Lync Integration	
Microsoft Lync Server	
Microsoft Office Communicator	
Avaya Microsoft Communicator Add-in	
Microsoft Office Communicator Server 2007 R2.	
Service providers	
Supported desk phones (hardware)	
Approved headsets.	
Camera.	
Client workstation.	
Chapter 6: Lync Integration services	
Telephony services with Lync Integration.	
Lync Integration desktop life cycle	
Lync Integration operational modes.	
Lync Integration telephony service limitations Telephony presence with Lync Integration	
Lync Integration presence service limitations	
Video telephony services with Lync Integration	
Video telephony service limitations	
Chapter 7: Dialing rules fundamentals	
Supported phone number formats.	
Supported phone number format limitations.	
Simple dial plan	
Simple dial plan examples.	
Advanced dial plan.	
Advanced dial plan examples.	
The dialingRules.xml file	
Chapter 8: Work flow for deploying Lync Integration	
Chapter 9: Port configuration	

Chapter 10: Service provider configuration	. 57
Avaya Aura [®] requirements	
Configuring Lync Integration as an H.323 endpoint on Communication Manager	58
Configuring Lync Integration as a video endpoint on Communication Manager	59
Chapter 11: Configure a dial plan	61
Configuring a simple dial plan	63
Dial plan checklist	63
Configuring an advanced dial plan	65
Creating a dialingRules.xml file using the Centralized Administration Tool	. 65
Chapter 12: Deploy Lync Integration on the desktop	
Installing the Configurator	
Building the install package	. 71
Installing Lync Integration locally	74
Installing the Lync Integration on multiple machines from a remote server	76
Chapter 13: Replacing the dialingRules.xml file on the workstation where Lync Integration is installed	79
Chapter 14: Troubleshooting Lync Integration	
Add-in disappears when Conversation window is maximized	
Application crashes.	
Application does not launch	
Call and video status not updated after network connection is lost	
Calls fail to originate when the phone is off the hook and the Headset button is lit	
Chained call forwarding: only the first forwarding instruction is processed	
Different behaviors for calls made from the right-click menu and from the green phone icon	
Enabling debug when Lync Integration is not starting	. 85
G729 or G722 Codec negotiation fails	85
Install or uninstall failure: script could not be run	86
Invalid phone number format: published phone number does not appear to My Contacts	87
Lync Integration cannot connect to Servers in Phone Mode (Shared Control) or Computer Mode	88
Lync Integration Communicator Bar does not appear	
Lync Integration may disable PC	
Lync Integration icons do not appear on the Microsoft Office Communicator	
Lync Integration Share Now window is displayed instead of Conversation window	
Lync video pane has excessive black border around video frame when using H.264 video codec	
Making a call displays Call number is not defined dialog	
No microphone sound in computer mode	
Presence state flickers when the user is on a call.	
Privacy settings block contact display: published phone number does not appear to My Contacts	
Scripting access to WMI is not working.	
User receives error messages after making a second call	
Video calls cause high CPU usage	
Chapter 15: Troubleshooting the one-X engine	
Chapter 16: Uninstall Lync Integration	
Uninstalling Lync Integration from the local desktop	
Uninstalling Lync Integration from multiple machines	
Chapter 17: Upgrade Lync Integration.	
Uninstalling one-X Communicator	104

Upgrading Lync Integration	104
Chapter 18: Migrating from Communicator Add-in to Lync Integration	

Chapter 1: New in this Release

The following sections describe what's new in *Avaya Microsoft Lync Integration and Microsoft Office Communicator Add-in Fundamentals for Avaya Aura*[®] (NN10850-014) for release 6.2.2.

Support for CS 1000 Collaboration Pack

Lync Integration now includes a CS 1000 Collaboration Pack offer. The Collaboration Pack supports Computer mode and includes video capabilities.

New in this Release

Chapter 2: Introduction

Avaya Microsoft Lync Integration and Microsoft Office Communicator Add-in Fundamentals for Avaya Aura[®] (NN10850-014) provides the information needed to administer Avaya Aura deployments on:

- Avaya Microsoft Lync Integration
- Avaya Microsoft Communicator Add-in

The Avaya Lync Integration is intended for a network environment where Microsoft Lync Server 2010 is deployed. Avaya Lync Integration is a client side add-in to Microsoft Lync 2010. The Avaya Communicator Add-in is intended for a network environment where Microsoft OCS is deployed. Avaya Communicator Add-in is a client side add-in to Microsoft Communicator.

Important:

Avaya Lync Integration is only supported on the Microsoft Lync 2010 client. Other versions of the Lync client do not support Lync Integration.

The Communicator Add-in is only supported on the Microsoft Office Communicator 2007 R2 client.

Terminology

In this document, the term Avaya Lync Integration will be used to refer to both Avaya Lync Integration and Avaya Communicator Add-in unless specific Avaya Communicator Add-in features are being highlighted.

Avaya product names:

The following product names are used for Avaya Microsoft Lync Integration.

- Avaya Lync Integration
- Lync Integration

The following product names are used for Avaya Microsoft Communicator Add-in.

- · Avaya Communicator Add-in
- Communicator Add-in

Microsoft product names:

The following product names are used for the Microsoft Lync solution.

- Microsoft Lync Server 2010
- Lync Server 2010
- Microsoft Lync 2010 (client)
- Lync 2010 (client)

The following product names are used for the Microsoft Office Communicator (MOC) solution.

- Microsoft Office Communication Server 2007 R2
- Office Communication Server 2007 R2
- Microsoft Office Communicator 2007 R2 (client)
- Office Communicator 2007 R2 (client)
- Communicator (client)

Support

Visit the Avaya Support website at <u>http://support.avaya.com</u> for the most up-to-date documentation, product notices, and knowledge articles. You can also search for release notes, downloads, and resolutions to issues. Use the online service request system to create a service request. Chat with live agents to get answers to questions, or request an agent to connect you to a support team if an issue requires additional expertise.

Avaya Mentor videos

Avaya Mentor is an Avaya-run channel on YouTube that includes technical content on how to install, configure, and troubleshoot Avaya products.

Go to http://www.youtube.com/AvayaMentor and perform one of the following actions:

- Enter a key word or key words in the Search Channel to search for a specific product or topic.
- Scroll down Playlists, and click the name of a topic to see the available list of videos posted on the site.

Chapter 3: Avaya Microsoft Lync Integration overview

Network administrators can use their Microsoft Lync or Microsoft Office Communications Server (OCS) 2007 R2 network infrastructure to enhance existing communication services. Administrators of Microsoft networks can provide unified communication services to clients utilizing their Avaya Aura[®] Communication Manager service provider.

Avaya Lync and OCS integration is client side. The Avaya Lync Integration is an add-in application that extends Microsoft Lync or Microsoft Office Communicator client functionality using Microsoft supported APIs. When deployed with Avaya Aura, the Avaya Lync Integration extends to the Microsoft Lync Client providing two telephony modes, Phone and Computer mode. Phone mode allows the user to control the desktop phone, with media going over existing PBX telephony equipment. Computer mode allows the user to use the computer as a phone, using the media capabilities of the computer. For a description of the services available in Phone and Computer mode, see <u>Telephony services with Lync Integration</u> on page 29

The Avaya Lync Integration interacts with the Lync 2010 client directly using Microsoft Supported APIs. All telephony capabilities are integrated directly between Avaya Lync Integration and the Microsoft Lync 2010 client. The Avaya solutions telephony capabilities with Lync 2010 requires only an OCS 2007 R2 Standard CAL (license), eliminating the need for a Microsoft voice infrastructure and the Microsoft OCS Enterprise CAL. Remote Call Control and Enterprise Voice must be disabled on the Lync or OCS server.

Language support

Avaya Lync Integration supports the following languages:

- English
- French, International
- German
- Italian
- Japanese
- Korean
- · Portuguese, Brazilian
- Russian

- Spanish, International
- Chinese, Simplified

Lync Integration features

The Lync Integration solution uses the Lync 2010 Microsoft Office Communicator user interface to provide voice services.

😵 Note:

For a detailed description of each voice service and a list of the services supported by each service provider, see <u>Telephony services with Lync Integration</u> on page 29.

The solution supports the following functionality:

- Support for Computer (soft client), Phone (CTI control of Desk phone), and Other Phone modes.
- Make Calls from Contact list, or search dialog box utilizing contacts published numbers.
- In conjunction with the Office Add-in and Web Browser Add-in applications, you can make calls from Microsoft Office applications and Internet Explorer (see Avaya Configurator for Desktop Communication Enablement Fundamentals (NN10850-031)
- Translation of E.164 numbers to customer dial plan including insertion or deletion of appropriate digits.
- Publish Telephony Presences on behalf of the user when their client is signed in and on a call.
- Display a conversation window with the following mid-call functionality:
 - Release/End call.
 - Place call on Hold and Retrieve call.
 - Insert DTMF digit in to an established call.
 - Speaker volume control and speaker mute function (Computer mode).
 - Microphone mute function (Computer mode).
 - Escalate to a video call.
- Handling multiple calls
 - Support for multiple Consult calls
 - While on a Consult call, instigate a Call Transfer.
 - While on a Consult call, merge another call to form a Conference call.
 - Add additional Consult calls to this Conference call.

- Call Waiting popup display.
- Display an incoming call window with the following functionality:
 - Indicate the Incoming Caller line ID or Caller name.
 - Allow the user to Answer the call or Deflect (Phone mode with Restful Session Control) to one of their specified devices.
 - While On a call, indicate that another call is waiting. Answering this call places the first call on Hold.
 - Graphically indicate which device (Computer or Phone mode) the call will be answered on.
- Set Call Forward options.
- Make a video call
 - Escalate an existing call to a video call.
 - Initiate a video call.
 - Mid call control ability to pause, resume, or stop video.
 - Incoming video call prompting to accept, decline, or view incoming video.

Lync Integration network

Microsoft Lync 2010 may be deployed within an Enterprise, on premise, or within a Hosted Office 365 deployment. Microsoft Office Communication System 2007 R2 may be deployed within an Enterprise or as a hosted Office 365 service. Avaya Microsoft Lync Integration will inter-operate with Lync 2010 or Communicator 2007 R2 clients deployed on the user's PC. The following diagram represents Avaya Lync Integration deployed within an Enterprise. For more information about Lync Integration deployed in a hosted service configuration, see Lync Integration support for Microsoft Office 365 on page 17.





Figure 1: Avaya Lync Integration deployed in an Enterprise



Lync Integration support for Microsoft Office 365

Figure 2: Avaya Lync Integration deployed in a Microsoft Office 365 environment

Authentication within an Office 365 deployment for Avaya Aura®

Lync Integration launches once the Lync client is successfully logged in. After verifying that the published work number of the user matches the Lync Integration extension, authentication occurs between the Avaya UC engine and the Avaya Communication Manager.

Avaya Microsoft Lync Integration overview

Chapter 4: Overview of Lync Integration for CS 1000 Collaboration Pack with Avaya Aura[®]

The Collaboration Pack for Avaya Communication Server 1000 solution is based on the Avaya Aura[®] Midsize Enterprise Release 6.2. This solution supports standard deployments of up to 2000 users or discrete Avaya Aura[®] Communication Manager and Session Manager servers for deployments with more than 2000 users.

The Collaboration Pack is used to extend Lync Integration for Avaya Aura[®] functionality to CS 1000 users. This solution is suitable for users who want to retain their CS 1000 desk phone and use the Avaya Collaboration pack to add additional functionality such as point-to-point video support with Lync Integration. The Collaboration Pack solution does not use the Avaya ACE[™] server. Solution features include support for:

- Computer mode with point to point video
- Other Phone mode

With the Collaboration Pack feature, Avaya Aura[®] Communication Manager controls calls over the user's extension, providing support for Computer mode. Lync Integration registers directly to Avaya Aura[®] Communication Manager as an H.323 endpoint and voice and video calls are presented on the user's computer.

The following image provides an overview of the Collaboration Pack solution.




Figure 3: Topology for CS 1000 Collaboration Pack

Collaboration Pack features

The Collaboration Pack solution uses the Lync 2010 client for Presence and Instant Messaging, and leverages Lync Integration for voice and video call functionality.

Collaboration Pack support for Other Phone mode is the same as in a standard Lync Integration for Avaya Aura[®] deployment, and is described in detail in <u>Other Phone mode</u> on page 32.

The Collaboration Pack solution also includes the following functionality.

- · Support for video calls between peers is integrated into the Lync client
- Support for Computer mode
- Ability to make a Lync Integration voice or video call from:
 - Lync contact list
 - Microsoft applications, including Outlook, Word, Excel, and PowerPoint
 - Internet Explorer
- Ability to escalate and de-escalate from an IM conversation to a video call or from a voice call to a video call
- · Video call options for Auto-answer or manual Accept and Decline

- Support for mid call control operations through the Lync Integration Conversation window. These mid call control operations include:
 - Mute voice
 - Pause and play video
 - Hold and retrieve voice and video calls
 - Enter DTMF digits in an active call
 - Multi-call handling such as video call transfer and escalation or de-escalation of a video conference to an audio conference
- Video interoperability with Avaya Aura[®], Radvision Scopia, and Polycom

Important:

Video functionality is supported in Computer mode, but a video call cannot be started when Other Phone mode is being used to control the user's CS 1000 desk phone, mobile phone, or other device.

Collaboration Pack administration

Lync Integration administration with the CS 1000 Collaboration Pack is similar to the administration described in this document. However, there are some differences such as:

- PSTN trunking is done through CS 1000 and not Avaya Aura®
- The primary work phone number for the user must be published in the Collaboration Pack. The user's primary work phone number is the Collaboration Pack phone number and not the standard CS 1000 desk phone number.

For more information about administering the CS 1000 Collaboration Pack, see *Application Note: Collaboration Pack 1.1 with Avaya Client Applications for Lync Integration*.

Overview of Lync Integration for CS 1000 Collaboration Pack with Avaya Aura®

Chapter 5: Lync Integration key components

Lync Integration features the following key components.

Microsoft Lync 2010 client

Microsoft's Lync 2010 is the unified communication desktop client providing IM and presence capabilities to the overall solution. Microsoft's Lync Server delivers IM and presence aggregation services to the end user.

Avaya Microsoft Lync Integration

This is a client side add-in to Microsoft Lync 2010. It utilizes the Lync Client User interface to drive Avaya Voice capabilities to the end user. The Lync Integration operates in two modes. In Computer mode, it utilizes the Avaya Unified Communication (UC) desktop engine to deliver soft client functionality. In Phone mode, it provides CTI control over the end user's desk phone.

Microsoft Lync Server

The Microsoft Lync Server provides the end user with IM and Presence aggregation functionality. The Avaya Microsoft Lync Integration builds on this Lync functionality and its Lync client user interface to deliver an Avaya voice experience.

Microsoft Office Communicator

Microsoft Office Communicator is the unified communication desktop client providing IM and presence capabilities to the overall solution. Microsoft's Office Communications Server delivers IM and presence aggregation services to the end user.

Avaya Microsoft Communicator Add-in

This is a client side add-in to Microsoft Office Communicator 2007 R2. It utilizes the Office Communicator User interface to drive Avaya Voice capabilities to the end user. The Communicator Add-in operates in two modes. In Computer mode, it utilizes the Avaya Unified Communication (UC) desktop engine to deliver soft client functionality. In Phone mode, it provides CTI control over the end user's desk phone.

Microsoft Office Communicator Server 2007 R2

Microsoft's Office Communicator Server (OCS) 2007 R2 provides the end user with IM and Presence aggregation functionality. The Avaya Microsoft Communicator Add-in builds on this OCS functionality and its Communicator client user interface to deliver an Avaya voice experience.

Service providers

The following service provider is supported with Avaya Aura[®] based Lync deployments:

• Avaya Aura® Communication Manager (Computer and Phone mode)

Supported desk phones (hardware)

Avaya phone series 46xx, 24xx, 64xx, and 96xx (except 9610) are supported with Avaya Aura[®] based Lync deployments.

All 16xx phones configured as 46xx phones on the Communication Manager server are also supported. All phones not listed here are not supported in the Desk Phone mode. For more information about aliasing one telephone model as another, see **Using an Alias** in *Administering Avaya Aura*[®] *Communication Manager* (03-300509).

Approved headsets

To obtain a list of approved headsets, perform the following steps.

- 1. Open a web browser and go to the DevConnect web site at <u>http://www.avaya.com/</u> <u>devconnect</u>.
- 2. In the navigation list on the left, select **Tested Solutions**.
- 3. Select the Solution tab.
- 4. Under Solution Platform, click the one-X Communicator check box.
- 5. Click Search.

A list of approved headsets is displayed.

Camera

Recommended USB cameras are listed below.

😵 Note:

Where possible, follow Microsoft Windows Operating System Recommended Hardware requirements based on the Operating System version information.

Table 1: Driver versions with HD cameras

HD Camera	Driver version
Creative Live! Cam Socialize HD	1.2.1.0
Microsoft Lifecam Cinema	3.20.240.0
Logitech [®] Webcam C905	13.0.1788.0

Table 2: Driver versions with non HD cameras

Non HD Camera	Driver version
Logitech [®] Webcam Pro 5000	12.0.1278.0
Logitech [®] Quick Cam Messenger	12.0.1278.0
Creative Live! Cam Notebook Pro	1.2.6.627
Logitech [®] Webcam Pro 9000	13.0.1783.0

Client workstation

The machine where Lync Integration is installed must meet the following requirements:

Table 3: Hardware requirements

Processor	1.8 GHz
Memory	1 GB (Windows XP) 2 GB (Windows 7)
Disk space	100 MB
Audio device	An audio device must be available on the computer to use Lync Integration in Computer mode.
Connectivity	Download bandwidth: 80 kbps Upload bandwidth: 80 kbps
Video	For deployments with video enabled, the following hardware requirements must be met:
	Intel Dual Core or higher processor
	• 100 MB video RAM
	minimum 2 GB memory
	 digital video camera (up to 720p is supported)

Table 4: Software requirements

Operating system	Microsoft Windows XP Service Pack 3, or higher Microsoft Windows 7
Microsoft .Net	For Lync, release 4.0 or higher. For Office Communicator, release 3.5, 4.0, or higher.
Microsoft Lync 2010 or Microsoft Communicator	Microsoft Lync 2010 version 4.0.7577.4103 or higher
	Microsoft Office Communicator 2007 R2, version 3.5.6907.253 or higher

Lync Integration key components

Chapter 6: Lync Integration services

Avaya Lync Integration is client side. Avaya Lync Integration is an add-in application that extends Microsoft Office Lync 2010 functionality using Lync supported APIs. Lync Integration extends Lync 2010 by providing two telephony modes: Phone mode and Computer mode.

Integrating Lync Integration with Microsoft Lync 2010 enables telephony services in Lync 2010. Lync Integration customizes and configures Lync 2010 as part of its installation.

😵 Note:

If you are using Lync 2010 over a Microsoft Remote Desktop session, it is recommended that you use Remote Desktop client version 6.1.7600.16385 or higher. Remote Desktop client software is available from the Microsoft web site. You should download the latest available version of the client as well as any available updates.

This chapter contains the following sections:

- Telephony services with Lync Integration on page 29
- Telephony presence with Lync Integration on page 35
- Video telephony services with Lync Integration on page 36

Telephony services with Lync Integration

Lync Integration controls a single line, based on the user's primary line. If the user's desk phone supports multiple lines, non-primary lines will not be represented by Lync Integration.

The following table lists supported functionality.

😵 Note:

The following features are not supported for Lync Integration with Avaya Aura®:

- Call History
- Single Step Transfer (Blind Transfer)

Capability	Description
Make Call	Users can make a call on their phone by clicking on a contact in their contact list or entering a number in the Lync 2010 dialog box.
Release Call	Users can Release a phone call by clicking on the End Call icon in Lync Integration Conversation Bar.
Answer Call	Users can accept an incoming call that is presented to them via a popup window.
Decline Call	Users can decline a phone call by clicking the Decline Call icon in the Lync Integration Incoming Call Notification dialog box. On the PBX line, the call is treated as an unanswered call.
	😒 Note:
	In Phone mode, the desk phone continues ringing after the called party clicks the Decline Call icon. To stop the phone from ringing, the calling party must end the call or the called party must manually hang up the desk phone.
Caller ID	Users receive Calling Party Name or Caller line ID in a popup window.
Forward Line	Users can activate Call Forward on their PBX line for incoming calls by selecting the Call Forward icon from the Lync Integration Lync 2010 Bar.
Call Hold and Retrieve	User can place call on hold using the hold button within the Lync Integration Conversation Bar. The call may be retrieved by clicking somewhere within the text line when the call is in a held state.
Generate Digits (DTMF)	Users can initiate sending of DTMF digits through the PBX system by selecting the dial pad icon on the Add-in Conversation Bar.
Consult Call	When on an active call, the user can:
	• answer a call
	 instigate a second call by clicking on a contact in their contact list or entering a number in the Lync 2010 dialog box
	When an additional call is answered or initiated, the previously active call is placed on hold. Multiple consult calls can be created.
Consult Transfer	When one or more consult calls are established, users are able to select, from a list of held calls, the call they wish to transfer their active call to.

Capability	Description
Consult Conference	When one or more consult calls are established, users are able to select, from a list of held calls, the call they wish to merge into a Conference call.
Call Waiting	When on an active call, a toast pop up is presented indicating that an alternative call is waiting. If the user decides to answer this call, then current active call is placed on hold. The new call now becomes the active call.
Receiver Mute	Users can select to mute or un-mute the PC speaker(s) or headset receiver. This feature is only applicable in Computer mode.
Receiver Volume Control	Users can select to adjust the volume of the PC speaker(s) or headset receiver. This feature is only applicable in Computer mode.
Audio Devices Mute	Users can select to mute or un-mute the PC speaker(s) or headset microphone. This feature is only applicable in Computer mode.
Codecs supported	G.711A G.711MU G.722-64K G.722.1-24K G.722.1-32K G.729
Make Video Call	Users can make a video call by clicking on a contact in their contact list and selecting Make Video Call .

Lync Integration desktop life cycle

Once installed, Lync Integration is launched as an end-user service when the user signs into Windows. The service waits in an idle state for the Lync 2010 client to launch, and for the user's Lync client to successfully sign in to the Lync server. At this point, Lync Integration will attempt to bind to its service provider. This takes between 5 seconds and 2 minutes, depending on network latency and workstation capacity. When the user signs out of the Lync client, Lync Integration will unbind from the active service provider and transition to the idle state.

Lync Integration can be launched from the Lync client's **Tools** menu by selecting **Avaya Microsoft Lync Integration**. If the menu option is not available, exit the Lync client and then relaunch.

The Lync Add-in may be restarted after the computer returns from sleep or after an intermittent network outage. When the Lync Add-in is restarted, the Add-in's conversation bar is attached to each conversation window. This makes the conversation window appear active even though nothing has changed in the window.

Lync Integration operational modes

Avaya Lync Integration supports the following operational modes:

- Phone
- Computer
- Other Phone

Select the mode from the Lync Integration bar. In order to select the Devices mode, you must specify a telephone number in the Lync Integration **Settings** > **Devices** window. You can specify multiple devices, but only one device can be selected as your active device.

Computer mode

Computer mode allows the Lync or Communicator client to use the computer as a phone. Lync Integration uses Avaya UC Desktop Engine capabilities to use the media capabilities of the computer.

Phone mode

Phone mode allows Lync Integration to control the user's desk phone and is implemented using the following method:

• Phone mode using Shared Control: Shared Control allows Lync Integration to control the desk phone. The Lync Integration uses Avaya UC Desktop Engine capabilities to remotely control media anchored on the phone.

Other Phone mode

Use Other Phone mode when you are away from the office and would like to use Avaya Lync Integration to make and receive calls in conjunction with another device such as your mobile, home, or hotel phone, or with a device at another office location. This mode enables you to use the full feature set of your company's telephone system from a location other than your office. You place and handle calls via the Lync Integration interface, and use a separate telephone line at your remote location to speak and listen. Unlike Computer mode, this mode is configured for toll-quality audio and optimizes audio through the other phone. To use this mode, you must have a separate telephone line at your remote location.

It is not possible to answer the call from an incoming call notification. Instead, you must answer the call on the device directly.

Lync Integration telephony service limitations

😵 Note:

- While Microsoft states that the Microsoft Communicator can connect and properly function with Microsoft Lync Server, this configuration was not tested.
- Avaya Lync Integration does not integrate with Microsoft Communicator.
- Avaya Communicator Add-in does not integrate with Microsoft Lync 2010.

Lync Integration telephone service has the following limitations.

Audio controls

- When a conversation is initiated, if the audio device setting is already at the lowest setting, Lync Integration does not present the conversation as muted.
- Audio Device settings may appear unsynchronized with the PC settings.
- Audio Settings cannot be adjusted from the **Settings** panel when a call is in progress.
- Lync Integration does not support call control using the headset directly. Call control must be invoked on the phone set, or using the Lync Integration application.

Lync server restarts

Avaya Lync Integration does not function during a Lync server outage. Within Phone mode, mid-call control may return when Lync becomes available. Users retain the ability to use their desk phone to make calls until full functionality is restored.

If a user is on a Computer mode call when the Lync server becomes unavailable, the call will be maintained, but mid-call control may be lost. The ability to end the call is maintained by a popup window. If the Lync client is able to reconnect to the Lync server prior to the call being completed, Lync Integration will begin providing service once the existing call is completed.

Lync client machine restarts

Active Computer mode calls are not terminated when a machine running the Lync 2010 client is restarted. The remote party can either wait for the call to reconnect or terminate the call. If the telephony infrastructure detects that the endpoint is no longer sending media, the call may be terminated.

Call Forwarding

An incoming call originated by the user, which is eventually routed back to the originator, is not presented to the user. For example, a user sets call forwarding from device B to device A. The user then uses device A to call device B. Device A receives a ringback, but the user cannot accept the call. The call may route to No Answer treatment.

Consult Transfer and Consult Conference

- Transferring into a conference is not supported.
- Presentation of only one conference is supported.

- It is not possible to add a call that is in the ringing state into a conference call. The call must be in the established state.
- Conference participants that are not Lync Integration users are removed from the conference leader's window if the conference leader sends an IM.
- The conversation window of a conference participant does not show the other conference participants.
- Consult Conference behavior is not guaranteed if the conference is initiated or manipulated via the phone or hard client.

DTMF in Computer Mode

When entering DTMF digits into a conversation, the DTMF tone played back on the speaker may be picked up by the microphone. In this case, the digit sequence may be corrupted. There are two workarounds:

- Use a headset when inserting DTMF digits into a conversation.
- Mute the microphone while DTMF digits are being inserted.

Multiple Avaya Unified Communication clients

Multiple Avaya UC Clients, with the exception of Avaya IP softphone, may be deployed on a user workstation, but only a single UC client can be used for telephony services at any time. Having multiple Avaya soft phone clients (such as Avaya one-X Communicator and Avaya Flare) logged in simultaneously on the same work station is not supported.

Multiple Lync Integration sessions

Microsoft Lync supports multiple client sessions for each user. However, Avaya Lync Integration does not. For each user, only a single Lync Integration session can be running.

Lync Integration cannot be deployed on a shared computer. To avoid contention for telephony resources, only a single session of Lync Integration can run on a workstation at any time.

Chained call forwarding

When user A forwards a call to user B, and user forwards the call to user C, only the first forward instruction is acted upon. The incoming call to user A rings on user B's line, but the call does not ring on user C's line as expected.

Multiple published work phone numbers

Avaya Lync Integration cannot support multiple published work phone numbers. The published work phone number must match the number defined in Active Directory.

This limitation does not apply to the Avaya Office Communicator Add-in.

Common phone numbers for multiple users

Multiple Lync Integration users should not publish the same Home, Mobile, or Other phone number in the Lync client. If multiple users have a common phone number, such as a reception or hunt group phone number, the users must create a new contact for the common phone number.

Multiple calls to the same contact

Only one Conversation window can be active against a Lync contact at a time. If a user needs to make a second call to the same contact while already on another active call with that contact,

the user must make the call by entering the contact's alternative phone number in the Lync Search bar or by creating a separate contact for the phone number.

Unique work phone numbers for all users

All Lync Integration users must publish unique phone numbers in the Microsoft Address Book. Multiple users cannot publish the same work phone number in their Lync clients.

Conference calls with the People Options button

In a Lync or Communicator Conversation window, users cannot use the **People Options** button to escalate a call or an instant messaging conversation to a conference call. The **People Options** button can only be used to add people to an instant messaging conversation.

Telephony service limitations specific to Avaya Aura[®]

Avaya Bridge Call Appearance Integration with Lync Integration

The Lync Integration application is not supported on lines with the Bridged Call Appearance feature on Avaya Communication Manager.

Hold and Retrieve operations when Lync Integration is set to Other Phone mode

If Lync Integration is set to Other Phone mode and the other device is another Communication Manager extension, invoking the Hold and Retreive operations on the desk phone results in the call being unmanageable. This is not an issue if the Hold and Retrieve operations are invoked on the Lync client directly or if the other device is a non Communication Manager device, such as a home or mobile phone number.

Telephony presence with Lync Integration

The Lync Integration telephony presence implementation enables the **Busy – In A Call** status for a Lync 2010 user. Other Lync 2010 users see the appropriate presence status depending on their relative level of access. Lync Integration publishes the **Busy – In A Call** status when the user initiates a call, or when the user answers an incoming call. If the user has a call on hold, then **Busy – In a Call** is still published. If the user is part of multiple calls, **Busy – In A Call** is published until Lync Integration detects that the user is not part of any call. The **Busy – In a Call** presence is an application state that should not be selected manually. If the user is not in a call and manually changes the presence state to **Busy – In a Call**, Lync Integration automatically changes the presence state back to **Available**.

The Custom Presence definition file is provided as a configuration item within the Lync Integration installation package. When custom presence is enabled on Lync 2010, the presence option **Busy – In A Call** is available in the list of presence options.

Do Not Disturb

While the Lync 2010 user presence status is **Do Not Disturb**, incoming call notifications are not displayed on the user's computer. If the user's phone line is supported by Avaya Aura[®]

Communication Manager using Shared Control or Computer mode, the incoming call will be treated with the Ignore command automatically. In Phone mode, the telephony device will continue to ring, and can be answered.

Lync Integration presence service limitations

When in Phone mode, even if the presence status is **Do Not Disturb**, the phone will ring.

Video telephony services with Lync Integration

Lync Integration deployed with the Avaya Aura[®] communication system can support video telephony services.

😵 Note:

Video telephony services are not supported with the Communicator Add-in.

The following table lists the functionality supported for Avaya Lync Integration.

Capability	Description
Make Video Call	Users can make a video call by clicking on a contact in their contact list and selecting Make Video Call .
Escalate to video call	Users can escalate a current call to a video call by clicking on the video icon in the Conversation Bar.
Pause and Resume video	Users can pause and resume video using the Video window menu.
Stop video	Users can stop video using the Video window menu. Stopping video does not end the call.
Codecs supported	• H.263
	• H.264
	• H.263-1998

Table 6: Video telephony feature descriptions

Video telephony service limitations

The following limitations apply to video calls.

Transferring video calls

Active video calls with a Radvision endpoint using Lync Integration cannot be transferred to any other Radvision endpoints.

Video calls with Radvision endpoints and Polycom HDX H.323 endpoints

On a video call with Radvision endpoints registered to IView Gatekeeper or with Polycom HDX H.323 endpoints registered to Polycom CMA:

- Video cannot be restarted once stopped.
- Sending DTMF digits causes video to drop. Audio is unaffected.

No video support for Polycom HDX SIP endpoints

Video calls with Polycom HDX SIP-only endpoints are not currently supported.

Lync Integration services

Chapter 7: Dialing rules fundamentals

By default, Lync Integration uses the configured dial plan information specified in the Configurator or defined within the Lync Integration **Settings** panel. These dial plan settings normalize phone numbers and match presented phone numbers with Lync contacts. Dialing between users must be either extension dialing or E.164 dialing. In this document, this is referred to as a simple dial plan.

Simple dial plans are not always specific enough to handle all types of phone numbers. For these scenarios, an advanced dial plan must be configured. With an advanced dial plan, it is possible to manipulate incoming and outgoing phone numbers by creating a dialingRules.xml file.

- <u>Supported phone number formats</u> on page 39
- Simple dial plan on page 41
- Advanced dial plan on page 43

Supported phone number formats

Lync Integration normalizes phone numbers, as presented when a call is ringing, into a format that matches Lync contacts. Lync Integration also takes the phone numbers of Lync contacts and makes them dialable for the call server. Simple and advanced dialing rules must be configured for Lync Integration to perform these normalizations and dialable transformations.

Phone numbers published in the Lync client can be entered in one of the following formats as long as the appropriate dial plan is in place to support it:

- E.164 DID
- Extension
- E.164 non-DID

The following table provides an example and a description for each of the number formats listed above.

Table 7: Supported phone number formats

Format	Example	Description
E.164 DID	+17776671234	A number in the E.164 format with no extension at the end.

Format	Example	Description
Extension	1234	An extension number. These types of numbers are not preceded by a +. Phone numbers entered in this format are not fully qualified and require dialing rules.
E.164 non- DID	+17776670000 x1234	A number in the E.164 format with an extension at the end. The first part of the number describes the switchboard or reception from which you can request the extension number.

Even though advanced dial plan transformations could theoretically allow for any mixture of number formats in Lync contacts, in practice a limited number of transformations will be put in place to normalize all numbers into the same format within an enterprise. This means that all Lync contact numbers within an enterprise should be presented in the same format so that a search and match can be performed.

Important:

The three supported number formats for Lync Integration are not all immediately supported by the Microsoft Lync Address Book. The Microsoft Lync server needs to be configured to understand the allowable number formats when obtaining numbers from the Active Directory and inserting them in the Lync Address Book. See documentation on the Microsoft web site for more information about the Company_Phone_Number_Normalization_Rules.txt file and the Lync Server Resource Kit Tools – ABSConfig Tool.

Phone numbers for contacts outside the enterprise are always presented in E.164 DID format so that the default simple dial plan will normalize and correctly match those numbers with the Lync contacts.

Supported phone number format limitations

Supported phone number formats in Lync Integration have the following limitations.

- Microsoft Lync supports E.164 DID phone numbers, extensions, and E.164 non-DID phone numbers. However, the display of E.164 non-DID phone numbers is incorrect if the phone number is not a North American phone number starting with +1. When deploying systems outside North America, use the extension phone number format or the E.164 DID format.
- Microsoft Office Communicator R2 only supports E.164 DID and extension phone number formats. The Communicator client does not support the E.164 non-DID phone number format.

Recommendations

Do not leave users to publish their own phone numbers in the Lync or Communicator clients. Instead, enter the work phone number for all users in the enterprise in Active Directory. This allows for consistent phone number formatting throughout the enterprise.

Simple dial plan

You must configure a dial plan to enable the telephony features of Avaya Lync Integration. You can configure a default dial plan in the Configurator when building the Lync Integration install package. Users can also modify the dial plan in the Lync Integration **Settings** window by selecting the **Dialing Rules** tab.

Simple dial plan examples

North American dial plan example

E.164 Number +1 613 77[67] xxxx	
Number to dial to access an outside line	9
Your country code	1
Your area/city code	613
PBX Main Prefix	777
Number to dial for long distance calls	1
Number to dial for international calls	011
Extension length for internal extensions calls	4
Length of national phone numbers (including area/city code)	10
Include area/city code when making a local call	check

Results using a simple dial plan: North America

Dialed number is	Dialing number as	Entered number	Dialed number
Extension	E.164	+16133568293	8293
	International	01116133568293	901116133568293
	National	6133568293	8293
	Local	3568293	8293
	Extension	8293	8293
	Short code	500	500

Dialed number is	Dialing number as	Entered number	Dialed number
Local	E.164	+16139078177	96139078177 (Include area code) or 99078177
	International	01116139078177	901116139078177
	National	6139078177	96139078177 (Include area code) or 99078177
	Local	9078177	99078177
National	E.164	+19088485596	919088485596
	International	01119088485596	901119088485596
	National	19088485596	919088485596
	Short code	911	911
International	E.164	+441628515068	9011441628515068
	International	011441628515068	9011441628515068

United Kingdom dial plan example

E.164 Number +44 1628 5xxxxx	
Number to dial to access an outside line	9
Your country code	44
Your area/city code	01628
PBX Main Prefix	5
Number to dial for long distance calls	0
Number to dial for international calls	00
Extension length for internal extensions calls	5
Length of national phone numbers (including area/city code)	10, 11
Include area/city code when making a local call	uncheck

Results using a simple dial plan: United Kingdom

Dialed number is	Dialing number as	Entered number	Dialed number
Extension	E.164	+441628515068	15068
	International	00441628515068	900441628515068
	National	01628515068	15068

Dialed number is	Dialing number as	Entered number	Dialed number
	Local	515068	15068
	Extension	15068	15068
	Short code	4190	4190
Local	E.164	+441628777700	901628777700 (Include area code) or 9777700
	International	00441628777700	900441628777700
	National	01628777700	901628777700 (Include area code) or 9777700
	Local	777700	9777700
National	E.164	+441483308721	901483308721
	International	00441483308721	900441483308721
	National	01483308721	901483308721
	Special number	08001111	908001111
	Short code	999	999
International	E.164	+16133568293	90016133568293
	International	0016133568293	90016133568293

Advanced dial plan

Simple dialing rules may not be specific enough to handle all situations. Advanced dialing rules may be needed to:

- Interpret any numbers dialed and convert them into a form that can be used by the PBX.
- Match call progress updates with the display of the call in progress.
- Take incoming numbers and normalize them into the correct form to find the associated Lync contact.
- Match the normalized numbers to contacts from the user's Outlook or Active Directory contact list.

Simple dialing rules alone may not be enough to perform these operations. See the following examples.

Operation	Extensions cannot be defined as a number of digits at the end of full E.164 numbers.
Example	E.164: +441628433000 - +441628434999 > Extension: 3000 - 4999
Operation	There is not a direct relation between extensions and their E.164 representations.
Example	E.164: +441628515000 - +441628515999 > Extension: 55000 - 55999
Operation	The PBX serves a number of locations with different country and area/city codes.
Example	Extension: 3000 > E.164: +441628433000 Extension: 4000 > E.164: +35391734000
Operation	A company uses private network dialing between sites.
Example	Local Extension: 3000 > E.164: +441628433000 Remote Extension: 3563000 > E.164: +35391733000
Operation	The PBX presents other special numbers to the phones that are not directly convertible into E.164 form.
Operation	The PBX presents a number that should not be turned into an E.164 number when looking for a Lync contact because the contact's phone number is expected to contain an extension number.
Example	Extension: 3000 > Extension: 3000. This is an example of an advanced rule that matches an extension and leaves the number unchanged so that the simple dial plan does not get a chance to normalize the extension to an E.164 number.

When the simple dialing rules are not sufficient, it is possible to manipulate incoming and outgoing phone numbers by creating a dialingRules.xml file. This file defines patterns used to match incoming or outgoing numbers which are then manipulated by inserting and removing digits.

Dialing plans may differ per site or region and must be managed appropriately.

When crafting the advanced dialing rules, you must consider all of the possible number forms that are to be sent and received. See <u>Simple dial plan examples</u> on page 41 for examples of dialable translations, and the advanced dial plan examples below for the normalized translations.

Important:

Advanced dialing rules must be tested before they are deployed. Lync Integration will not generate error messages if the dialingRules.xml file contains incorrect dialing rules.

Advanced dial plan examples

North American dial plan example

E.164 Number + 1 613 77[67] xxxx	
Number to dial to access an outside line	9
Your country code	1
Your area/city code	613
PBX Main Prefix	777
Number to dial for long distance calls	1
Number to dial for international calls	011
Extension length for internal extensions calls	4
Length of national phone numbers (including area/city code)	10
Include area/city code when making a local call	check

Example of outside line digit not removed in number received to displayed number: North America

Received number is	Received number as	Number received	Number displayed
Extension	Extension	8293	+16133568293
Short code	Short code	500	500
Local	National	96139078177	+16139078177
	Local	99078177	+16139078177
National	National	919088485596	+19088485596
Short code	Short code	9911	911
International	International	011441628515068	+441628515068

United Kingdom dial plan example

E.164 Number + 44 1628 5xxxxx		
Number to dial to access an outside line	9	
Your country code	44	
Your area/city code	01628	

PBX Main Prefix	5
Number to dial for long distance calls	0
Number to dial for international calls	00
Extension length for internal extensions calls	5
Length of national phone numbers (including area/city code)	10, 11
Include area/city code when making a local call	uncheck

Example of outside line digit not removed in number received to displayed number: United Kingdom

Received number is	Received number as	Number received	Number displayed
Extension	Extension	55068	+441628515068
Short code	Short code	4190	4190
Local	National	901628777700	+441628777700
	Local	9777700	+441628777700
National	National	901483308721	+441483308721
Special number	Special number	908001111	08001111
Short code	Short code	9999	999
International	International	90016133568293	+16133568293

The dialingRules.xml file

The dialingRules.xml file contains the advanced dialing rules. This file is read by the Lync Integration at start up. The following conditions apply to an advanced dial plan using a dialingRules.xml file.

- Rules defined in the dialingRules.xml file have to match and complete any digit manipulation on their own. If a number is matched and transformed by a dialingRules.xml pattern then no further change will be made by the simple dialing rules.
- The order of the rules in the dialingRules.xml file is important as these are checked in order and only the first match takes effect.
- If no dialingRules.xml patterns are matched then the simple dialing rules are applied.

Dialing rules contained in the dialingRules.xml file are applied only when using Lync Integration. They are not applied when using the desk phone. As a result, telephone numbers may be presented differently in Lync Integration and the desk phone.

You can create a dialingRules.xml file using the Avaya one-X[®] Communicator Centralized Administration Tool (CAT) or by using a text editor.

Deploy the dialingRules.xml using the Configurator. When you are performing the procedure to build the install package using the Configurator, you can specify the dialingRules.xml file to be included.

You can make changes to the dialingRules.xml file without reinstalling the Lync Integration software. Modify the dialingRules.xml using the CAT and deploy the new file using the updateRules.wsf tool. Changes to this file will take effect at the next Lync 2010 sign in.

😵 Note:

If the new dial plan rules are not applied after a Lync 2010 client restart, reboot the workstation to ensure that the Lync Integration process has been restarted.

Pattern	Туре	Prefix	Delete Length	Min Length	Max Length
\+441628515[0-4]	Dialable	5	9	13	13
4190	Normalize	+441483309700	4	4	4
^55[0-4]	Normalize	+44162851	1	5	5
^5[89]	Normalize	+44148330	1	5	5

dialingRules.xml file example

Below is a sample dialingRules.xml file based on the above table.

😵 Note:

The DialingRulesPatternList string that begins on the second line is a single string on one line. Do not introduce carriage return characters into the string. If you cut and paste from this document, the string will contain carriage returns. Ensure that you remove any carriage returns that are introduced.

The DialingRulesPatternList string is composed of four segments separated by spaces. The line below indicates the location of the spaces.

```
<DialingRulesPatternList<space>xmlns:xsi="http://www.w3.org/2001/
XMLSchema-instance"<space>xmlns:xsd="http://www.w3.org/2001/
XMLSchema"<space>xmlns="http://xml.avaya.com/endpointAPI">
```

<?xml version="1.0" encoding="utf-8"?> <DialingRulesPatternList xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns="http://xml.avaya.com/ endpointAPI"> <!-- Turn extensions dialed as E.164 numbers into extensions --> <DialingRulesPattern>

```
<type>0</type>
    <pattern>\+441628515[0-4]</pattern>
    <subString>5</subString>
    <minLength>13</minLength>
   <maxLength>13</maxLength>
   <deleteLength>9</deleteLength>
 </DialingRulesPattern>
 <!-- Displayed number when calling voicemail, display as voicemail E.164 number -->
 <DialingRulesPattern>
   <type>1</type>
   <pattern>4190</pattern>
   <subString>+441483309700</subString>
   <minLength>4</minLength>
   <maxLength>4</maxLength>
    <deleteLength>4</deleteLength>
 </DialingRulesPattern>
 <!-- Displayed number is local extension, display as E.164 number -->
 <DialingRulesPattern>
    <type>1</type>
   <pattern>^55[0-4]</pattern>
   <subString>+44162851</subString>
   <minLength>5</minLength>
   <maxLength>5</maxLength>
    <deleteLength>1</deleteLength>
 </DialingRulesPattern>
 <!-- Displayed number is extension from another site, display as E.164 number -->
 <DialingRulesPattern>
   <type>1</type>
   <pattern>^5[89]</pattern>
   <subString>+44148330</subString>
   <minLength>5</minLength>
   <maxLength>5</maxLength>
   <deleteLength>1</deleteLength>
 </DialingRulesPattern>
 <DialingRulesPattern>
   <type>1</type>
   <pattern>^9[1-9]</pattern>
   <subString>+441628</subString>
   <minLength>7</minLength>
   <maxLength>7</maxLength>
   <deleteLength>1</deleteLength>
 </DialingRulesPattern>
   <DialingRulesPattern>
   <type>1</type>
   <pattern>^90[1-9]</pattern>
   <subString>+44</subString>
   <minLength>11</minLength>
   <maxLength>12</maxLength>
   <deleteLength>2</deleteLength>
 </DialingRulesPattern>
  <DialingRulesPattern>
   <type>1</type>
   <pattern>^900[1-9]</pattern>
   <subString>+</subString>
   <minLength>7</minLength>
   <maxLength>32</maxLength>
   <deleteLength>3</deleteLength>
 </DialingRulesPattern>
</DialingRulesPatternList>
```

Additional dialing rule scenarios

Incoming calls from 6133568 prefix cannot be normalized to match the E.164 numbers.

Incoming rule: Insert the +1 to properly normalize the incoming dialed number. **Example:**

```
<DialingRulesPattern>
<type>1</type>
<pattern>^6133568</pattern>
<subString>+1</subString>
<minLength>10</minLength>
<maxLength>10</maxLength>
<deleteLength>0</deleteLength>
</DialingRulesPattern>
```

Outgoing calls to the 1613967 require the leading 1 to be passed to Communication Manager because 613967 is a toll call, but other calls to 1613 are not toll calls.

E.164 number: +1613967XXXX Outgoing rule: Detect pattern and pass number. Example:

Incoming call from extension 4190 to be presented as +35391733380

Incoming rule: Detect pattern and replace with +35391733380. **Example:**

```
<!-- Short code expansion -->
<DialingRulesPattern>
<type>1</type>
<pattern>4190</pattern>
<subString>+35391733380</subString>
<minLength>4</minLength>
<maxLength>4</maxLength>
<deleteLength>4</deleteLength>
</DialingRulesPattern>
```

```
These rules apply when the internal extension is not a subset of the published E.164 number.
```

Outgoing rule: Change published E.164 prefixes of 16137778xxx to extension 9xxx. **Example:**

```
<DialingRulesPattern>
<type>0</type>
<pattern>16137778</pattern>
<subString>9</subString>
<minLength>10</minLength>
```

These rules apply when the internal extension is not a subset of the published E.164 number.

Outgoing rule: Variation on change published E.164 prefixes of 16137778xxx to extension 9xxx.

Example:

```
<DialingRulesPattern>
<type>0</type>
<pattern>16137778</pattern>
<subString>9</subString>
<minLength>10</minLength>
<maxLength>12</maxLength>
<deleteLength>8</deleteLength>
</DialingRulesPattern>
```

Outgoing rule: Incoming notification, with a 4 digit extension starting with 99xx, will be converted to 161377789xx.

Example:

```
<DialingRulesPattern>
<type>1</type>
<pattern>99</pattern>
<subString>+16137778</subString>
<minLength>4</minLength>
<maxLength>4</maxLength>
<deleteLength>1</deleteLength>
</DialingRulesPattern>
```

Advanced dialing rules when an enterprise is using extensions for Lync enterprise contact phone numbers

If using extensions for enterprise contacts' phone numbers, then the simple and advanced dialing rules should aim to normalize all enterprise numbers into extensions when possible. All numbers outside the enterprise should resolve to E.164 numbers. The dialable rules should similarly turn all enterprise numbers into extensions and all non-enterprise numbers into numbers that can be dialed with the appropriate prefixes. The simple dialling rules will try to normalize all numbers into E.164 numbers so advanced rules are needed to convert enterprise numbers into extensions.

Example:

The following normalization rule keeps 4 digits extensions starting with 5 unchanged rather than converting them to E.164 numbers (normalize: 5xxx -> 5xxx)

```
<?xml version="1.0" encoding="utf-8" ?>
<DialingRulesPatterList xmlns:xsi="http://www.w3.org/2001/XMLSchema-
instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns="http://
xml.avaya.com/endpointAPI">
<DialingRulesPattern>
<type>1</type>
<pattern>^5</pattern>
<subString />
<minLength>4</minLength>
<deleteLength>0</deleteLength>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPatternList>
```

Advanced dialing rules when an enterprise is using non-DID extensions for Lync enterprise contact phone numbers

Example:

+441628515000 x5001

If using non-DID E.164 numbers with extensions for enterprise contacts then the simple and advanced dialling rules should aim to normalize all enterprise numbers into extensions when possible except for the common reception or IVR E.164 number. All numbers outside the enterprise should resolve to E.164 numbers. The dialable rules should similarly turn all enterprise numbers into extensions and all non-enterprise numbers into numbers that can be dialed with the appropriate prefixes. The simple dialing rules will try and normalise all numbers into E.164 numbers so advanced rules are needed to convert enterprise numbers into extensions.

If non-DID E.164 numbers with extensions are used in an enterprise then all Lync users must have their work numbers set in this format.

Example:

This normalization rule converts the reception number into an E.164 format, but keeps the extension number unchanged. The following example shows the normalization rule for an E-164 number, with a 4 digit extension starting with 5 at the end (normalize: 5xxx -> 5xxx)

```
<?xml version="1.0" encoding="utf-8" ?>
<DialingRulesPatternList xmlns:xsi="http://www.w3.org/2001/XMLSchema-
instance" xmlns:xsd="http://www.w3.org/2001/XMLSchema" xmlns="http://
xml.avaya.com/endpointAPI">
<DialingRulesPattern>
<type>1</type>
<pattern>^5</pattern>
<subString />
<minLength>4</minLength>
<deleteLength>0</deleteLength>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPattern>
</DialingRulesPatternList>
```

Dialing rules fundamentals

Chapter 8: Work flow for deploying Lync Integration

This section illustrates the high level work flow required to deploy Avaya Lync Integration and lists the requirements for the network components.

In this document, the term Lync Integration will be used to refer to both Lync Integration and Communicator Add-in unless specific Communicator Add-in features are being highlighted. Unless specified, the Communicator Add-in installation steps are identical to that of Lync Integration.

Lync Integration deployment notes


The following limitations apply to deployment of Lync Integration.

- The Avaya Lync Integration builds on Lync's IM and Presence capabilities. This requires the Lync 2010 Standard CAL. Upon deployment of Lync Integration, the Microsoft Lync 2010 UC (Voice and Video) capabilities are disabled.
- Lync Integration cannot be installed in conjunction with any other Lync Extension.
- Lync Integration supports a single extension per end user.
- Lync Integration does not support SIP endpoints
- Lync Integration may not integrate with other 3rd party add-ins to the Microsoft Lync software. If Lync Integration fails to load after the installation of a 3rd party add-in, you must reinstall Lync integration.
- If Lync Integration and one-X Communicator are installed on the same machine, the one-X Communicator must be installed with the following functions set to **Disabled**:
 - ENABLECLICKTODIALIE
 - ENABLECLICKTODIALFF
 - ENABLEOUTLOOKADDIN

See the **Silent Installation** section in *Overview and Planning for Avaya one-X*[®] Communicator.

Deploying Lync Integration work flow

The work flow shows the tasks you perform to deploy Lync Integration.



Navigation

- Configure firewall ports for network connectivity: see Port configuration on page 55
- Install and configure service provider: see the requirements listed in <u>Service provider</u> <u>configuration</u> on page 57
- Configure a dial plan on page 61
- Deploy Lync Integration on the desktop on page 69

Chapter 9: Port configuration

Firewall rule configuration is required for the solution deployment to work. This may require advance planning in order to comply with customer site IT governance and policy enforcement.

Port configuration is required for the following network elements:

• Client PC: The Windows firewall is automatically traversed by Lync Integration. However, for Computer mode, a firewall rule may be required to traverse proprietary firewalls.

Port configuration

Chapter 10: Service provider configuration

Your service provider must be installed and functional. The service provider requirements are described in the following section:

• Avaya Aura requirements on page 57

Avaya Aura[®] requirements

• Avaya Lync Integration requires the following Communication Manager configuration settings. These settings allow Avaya IP soft phones to register with Communication Manager every minute, allowing reasonable switch mode behavior between Lync Integration Computer mode and Phone mode.

Configuration category	Variable	Setting
Communication Manager system parameters — features	Unnamed registrations and PSA for IP Telephones?	Ν
Communication Manager system parameters — features	Unhold?	Ν
Communication Manager system parameters ip- options	Periodic Registration Timer (min)	1

• The PBX user line name cannot contain single digits delineated by spaces, For example, "Line 1" will cause problems but "Line-1" will not.

If the user line name contains single digits, the call terminator does not get an incoming call notification for a call that is forwarded from another user. For a Computer mode user, the call is unanswerable.

- Perform the procedure <u>Configuring Lync Integration as an H.323 endpoint on</u> <u>Communication Manager</u> on page 58 for all Lync Integration endpoints.
- Perform the procedure <u>Configuring Lync Integration as a video endpoint on</u> <u>Communication Manager</u> on page 59 for all Lync Integration endpoints that use video.

Configuring Lync Integration as an H.323 endpoint on Communication Manager

Before you begin

You must know:

- the Communication Manager IP address
- a user ID and password for logging in to the Communication Manager server
- the terminal type you are logging in from

Procedure

- 1. Log in to the Communication Manager interface.
 - a. Use the Communication Manager IP address to establish an SSH session.
 - b. Log in to the Communication Manager.
 - c. Enter sat.
 - d. Enter your terminal type. For example, enter **W2KTT**.

The SAT **Command**: prompt displays.

- 2. Determine the maximum number of Avaya one-X[®] Communicator endpoints your voice system supports:
 - a. Use the display system-parameters customer-options command to access the Optional Features form.
 - b. On page 9 of the form, verify the **oneX_Comm** setting. This number is provided by the RFA license file.
- 3. Perform one of the following steps on Communication Manager:
 - If you want to add a new station that uses Lync Integration, use the add station command.
 - If you want to modify an existing station that uses Lync Integration, use the change station xxxx command, where xxxx is the number of the station you want to modify.

Communication Manager displays the Station form.

- 4. Enter the appropriate information for this station:
 - a. Set IP Softphone to y.
 - b. Set IP Video Softphone to y.
- 5. Repeat steps <u>3</u> on page 58 and <u>4</u> on page 58 for each Lync Integration endpoint you want to configure on Communication Manager.

Configuring Lync Integration as a video endpoint on Communication Manager

The following procedure works for both H.323 and SIP endpoints.

Before you begin

You must know:

- the Communication Manager IP address
- a user ID and password for logging in to the Communication Manager server
- the terminal type you are logging in from

Procedure

- 1. Log in to the Communication Manager interface.
 - a. Use the Communication Manager IP address to establish an SSH session.
 - b. Log in to the Communication Manager.
 - c. Enter sat.
 - d. Enter your terminal type. For example, enter **W2KTT**.

The SAT **Command**: prompt displays.

- 2. Use the display system-parameters customer-options command to verify the Maximum Video Capable IP Softphones (page 2 of form). This number is provided by the RFA license file.
- 3. Use the change cos command to set **Priority Video Calling** (page 2 of form) for the appropriate COS levels.
- 4. Use the add station command to add an Avaya IP Softphone station, and set the following parameters for that station:
 - a. Set **IP Softphone** to **y**.
 - b. Set IP Video Softphone to y.
 - c. If you want this station to be able to make priority video calls, make sure you select a COS level that has **Priority Video Calling** enabled.
 - d. On page 2 of the form, set **Direct IP-IP Audio Connections** to y.
- 5. Repeat steps <u>2</u> on page 59, <u>3</u> on page 59, and <u>4</u> on page 59 for each Lync Integration endpoint you want to configure for video calling.

Service provider configuration

Chapter 11: Configure a dial plan


You must configure a dial plan to enable the telephony features of Avaya Lync Integration. You can configure a simple or advanced dial plan. You create a simple dial plan by configuring the **Dialing Settings** in the Configurator. To create an advanced dial plan, you must configure the **Dialing Settings** in the Configurator and use the Configurator to deploy a dialingRules.xml file.

Prerequisites

You must understand the structure of a dial plan. For a description of dial plans, see <u>Dialing rules</u> fundamentals on page 39.

Configure a dial plan procedures

This task flow shows the procedures you perform to configure a dial plan.



Navigation

- Configuring a simple dial plan on page 63
- Configuring an advanced dial plan on page 65
- Creating a dialingRules.xml file using the Centralized Administration Tool on page 65
- For the procedure that covers entering dial plan settings in the Configurator and using the Configurator to deploy the dialingRules.xml file, see <u>Building the install package</u> on page 71
- All the procedures to install Lync Integration are contained in <u>Deploy Lync Integration on the</u> <u>desktop</u> on page 69
- <u>Replacing the dialingRules.xml file on the workstation where Lync Integration is installed</u> on page 79

Configuring a simple dial plan

You can configure a simple dial plan in the Configurator when building the Lync Integration install package. Users can modify the dial plan in the Lync Integration **Settings** window by selecting the **Dialing Rules** tab.

Use the dial plan checklist to create a simple dial plan. The settings are described in <u>Dial plan</u> <u>variables</u> on page 64.

For examples of a simple dial plan, see Simple dial plan examples on page 41

Dial plan checklist

Phone Settings	
IP address of the telephone server or servers	
Dialing Rules Settings	
Enable Call Forward	
Digit(s) you must dial to access an outside line	
Country code	
Area/city code	
PBX Main Prefix	
Digit(s) you must dial to make long- distance calls	

Digit(s) you must dial to make international calls	
Extension length for internal extensions	
Length of national phone numbers (Includes area and city codes)	
Do you have to dial the area/city code when making a local call?	
Extension Settings	
Phone Extension	
Phone Password	

Dial plan variables

Variable	Description
Enable Call Forward	When Call Forward is enabled, the Call Forward icon is displayed.
Number to dial to access an outside line	The digit or digits you must dial to access an outside line.
Your country code	The dialing code for your country.
Your area/city code	The area code or the city code where your phone server is located. You can enter multiple codes separated by commas. For example, 406, 208. In this example, Lync Integration treats all calls made the 406 or 208 regions as local calls.
PBX Main Prefix	The main prefix of your PBX. This is the digit(s) that comes after the area/city code and before the internal extension. If you cannot obtain the extension number by removing digits up to and including the PBX main prefix from an E.164 representation of the number, then this field should remain blank.
Number to dial for long distance calls	The digit or digits you must dial to make a long distance call.
Number to dial for international calls	The digit or digits you must dial to make an international call.
Extension length for internal extensions calls	The number of digits that comprise an internal extension. For example, if your internal extensions consist of five digits, enter 5. In this example, any number that consists of five digits or less would be treated as an internal extension. If your company

Variable	Description
	supports internal extensions of varying lengths, enter the length numbers separated by comas. For example, if you use three-digit, five-digit, and seven- digit extensions, enter 3, 5, 7.
	😵 Note:
	If you specify multiple extension lengths, Lync Integration performs exact matches. For example, if you specify 3, 5, 7, then a four-digit number will not be recognized as an internal extension.
Length of national phone numbers (including area/city code)	The number of digits you must dial (including area/city code) for a call within your country.
Include area/city code when making a local call	Check the box if you are required to prefix the area or city code while making a local call.

Configuring an advanced dial plan

In deployments where the simple dialing rules are not enough, you must manipulate incoming and outgoing phone numbers by creating a dialingRules.xml file. You can create a dialingRules.xml file using the Avaya one-X[®] Communicator Centralized Administration Tool (CAT) or by using a text editor. For examples of an advanced dial plan, see <u>Advanced dial plan examples</u> on page 45.

Deploy the dialingRules.xml using the Configurator. When you are performing the procedure to build the install package using the Configurator, you can specify the dialingRules.xml file to be included.

You can make changes to the dialingRules.xml file without reinstalling the Lync Integration software. Modify the dialingRules.xml using the CAT and deploy the new file using the updateRules.wsf tool. Changes to this file will take effect at the next Lync 2010 sign in. See Replacing the dialingRules.xml file on the workstation where Lync Integration is installed on page 79.

Creating a dialingRules.xml file using the Centralized Administration Tool

You can create or modify a dialingRules.xml file using a text editor or by using the Avaya one-X[®] Communicator Centralized Administration Tool (CAT). The CAT is distributed with the Avaya one-X Communicator. Download the Avaya one-X Communicator Admin Tool R6.1 SP2 or higher.

This document provides the procedures for working with a dialingRules.xml file. See the Avaya one-X Communicator Centralized Administration Tool documentation for further details. When creating dialing rules in CAT, only use the **Dialing Rules** tab. The remaining tabs are not used.

Dialing rules interface

Add

Click this button to open the Add Rule dialog box.

Add Rule window

Use this window to specify a pattern match rule.

Field	Description
Pattern	Field to enter a regular expression. The pattern can exist anywhere in the input string, not necessarily from the beginning or the end of the input string.
Туре	List box to specify whether to apply the Dialable rule to all the outgoing numbers before storing the number in the call log or to apply the Normalize rule to all the incoming numbers before storing the number in the call log. Specify 0 for Dialable or 1 for Normalize.
Prefix	Field to enter the string to be prefixed to the input string after deleting the specified number of characters.
Delete Length	Field to enter the number of characters, including the + character, to delete from the beginning of the input string.
Minimum Length	Field to enter the minimum length, including the + character, of the input string.
Maximum Length	Field to enter the maximum length, including the + character, of the input string.
ОК	Button to add the pattern match rule and close the Add Rule dialog box.
Cancel	Button to cancel adding the pattern match rule and close the Add Rule dialog box.

Remove

Click this button to remove an existing pattern match rule.

Save

Click this button to save the Avaya one-X Communicator dialing rules settings.

Open

Click this button to open the existing dialingRules.xml file.

Configuring dialing rules

Use the **Dialing Rules** tab to configure dialing rules.

Procedure

- 1. Click the **Dialing Rules** tab.
- 2. Click **Add** to open the Add Rule dialog box.
- 3. Enter the appropriate information.
- 4. Click **OK** to add a new pattern match rule.
- 5. Click **Save** to save the Dialing Rules settings.

Modifying dialing rules

Use the **Dialing Rules** tab to modify the existing dialing rules settings.

Procedure

- 1. Click the **Dialing Rules** tab.
- 2. Click Open.
- 3. Select the dialingRules.xml file.
- 4. If you want to add additional pattern match rules, click **Add** to open the Add Rule dialog box, enter the appropriate information, and click **OK**.
- 5. If you want to remove a pattern match rule, select a rule and click **Remove**.
- 6. Click **Save** to update the dialing rules settings.

Configure a dial plan

Chapter 12: Deploy Lync Integration on the desktop

Prerequisites

The machine where Lync Integration is installed must meet the following requirements:

Table 8: Hardware requirements

Processor	1.8 GHz
Memory	1 GB (Windows XP) 2 GB (Windows 7)
Disk space	100 MB
Audio device	An audio device must be available on the computer to use Lync Integration in Computer mode.
Connectivity	Download bandwidth: 80 kbps Upload bandwidth: 80 kbps
Video	For deployments with video enabled, the following hardware requirements must be met:
	Intel Dual Core or higher processor
	• 100 MB video RAM
	minimum 2 GB memory
	 digital video camera (up to 720p is supported)


Table 9: Software requirements

Operating system	Microsoft Windows XP Service Pack 3, or higher Microsoft Windows 7
Microsoft .Net	For Lync, release 4.0 or higher. For Office Communicator, release 3.5, 4.0, or higher.
Microsoft Lync 2010 or	Microsoft Lync 2010 version 4.0.7577.4103 or higher
Microsoft Communicator	Microsoft Office Communicator 2007 R2, version 3.5.6907.253 or higher

Deploy Lync Integration on the desktop procedures

This task flow shows the procedures you perform to deploy Lync Integration on the desktop.

This task flow applies to a first time installation of Lync Integration. If you previously installed Lync Integration and are upgrading to a new version, see <u>Upgrade Lync Integration</u> on page 103



Navigation

- Installing the Configurator on page 71
- <u>Building the install package</u> on page 71
- Installing Lync Integration locally on page 74
- Installing the Lync Integration on multiple machines from a remote server on page 76

Installing the Configurator

Install the Avaya DCE Configurator. The Configurator is an administrative tool used to configure and build the install packages for the Lync and Communicator Add-in applications prior to distribution of the add-ins to end users.

Before you begin

- You are running one of the following operating systems:
 - Microsoft Windows XP SP3
 - Microsoft Windows 7
- You have Microsoft .NET Framework 4.
- You have the DCE.configurator.msi file on your desktop. The Configurator installation package is available on the Avaya Applications disk in the Desktop Communications Enablement (DCE) folder.

Procedure

- 1. Double-click the DCE.Configurator.msi file to launch the Windows installer for the Avaya DCE Configurator.
- 2. When the Avaya DCE Configurator installer opens, click Next.
- 3. When the Avaya DCE Configurator setup wizard opens, click Next.
- 4. In the License Agreement window, click I Agree to accept the license agreement.
- 5. In the Select Installation Folder window, specify a path to the installation folder for the Avaya DCE Configurator and click **Next**.
- 6. In the Confirm Installation window, click **Next** to start the installation.
- In the Installation Complete window, click Close to exit the setup wizard. The Avaya DCE Configurator icon appears on your desktop.

Building the install package

Build the install package for Avaya Lync Integration or Avaya Communicator Add-in.

Lync Integration can integrate with the Avaya DCE Web Browser Add-in and the Avaya DCE Office Add-in applications to provide a unified user experience across all Avaya DCE desktop

applications. For more information, see *Avaya Configurator for Desktop Communication Enablement Fundamentals* (NN10850–031).

The Configurator builds the following files:

- LyncIntegration.zip The Lync Integration software.
- MCAddin.zip The Communicator Add-in software.

These files must be transferred to the machine where the Communicator Add-in is installed.

Before you begin

- You have installed the Avaya DCE Configurator.
- You must be able to define the following configuration variables:

Variable	Description
General Settings	
Communication System	The options are:
Туре	• Avaya Aura
	CS 1000 with ACE
	CS 1000 Collaboration Pack
Integration Type	For Avaya Aura [®] and CS 1000, the options are:
	Computer Only
	Phone Only
	Computer & Phone
	For CS 1000 Collaboration Pack, the available option is:
	Computer Only
Preferred Integration Type	This variable is enabled if the Integration Type is Computer & Phone . You can select which one of the two modes is presented to the user when they start the client.
Server List	Avaya Aura: A comma separated list of call servers applicable to the extension. Each server can be identified by IP address, FQDN, or host name.
	Important:
	Do not add call servers that are not applicable to the extension. The Lync Integration client may continue to search the call server list and become unresponsive.
Dialing Settings	
See <u>Configure a dial plan</u> on page 61 If you are configuring an advanced dialing plan and will be deploying a dialingRules.xml file, you must know the location of the file.	

Variable	Description
Additional Settings (For CS 1000 deployments if the Integration Type is Computer or Computer & Phone).	
Enable iSAC	Enables iSAC codec.
Super-wideband support	Enables super-wideband support for iSAC codec.
Enable G.722	Enables G.722 codec.
Enable G.729	Enables G.729.
Annex B support	Enables Annex B support for G.729 codec
Enable G.711 A-law	Enables G.711 A-law codec. Cannot be deselected.
Enable G.711 Mu-law	Enables G.711 A-law codec. Cannot be deselected.
Enable Comfort Noise	Enables Comfort Noise.
Enable SRTP	Enables Secure Real-Time Transport Protocol.
Cipher 1, Cipher 2	Ciphers to be negotiated when secure RTP is used. Cipher 2 can set only after Cipher 1.
Video Settings (For Avaya Aura [®] and CS 1000 Collaboration Pack deployments only)	
Enable Video For These Users	If you are deploying Lync Integration with the Avaya Aura [®] communication system, you can enable video communication. If you are deploying Lync Integration with the CS 1000 Collaboration Pack, video communication is enabled by default.
Enable Video	If selected, video is enabled by default in the Lync Integration deployment.
Answer Video Automatically	If selected, Answer Video Automatically is enabled by default in the Lync Integration deployment. When enabled, incoming video calls automatically open in a video call window. When disabled, you must accept the video call to open the window.
Enable Codecs	Enables the codecs supported for video transmission. H.263 is enabled and cannot be deselected.
Maximum Video Bit Rate	The maximum bit rate supported for video transmission.
Incoming Video Wait Timeout	The timeout period for incoming video communications.
Outgoing Video Wait Timeout	The timeout period for outgoing video communications.

Procedure

1. Double-click the Avaya DCE Configurator icon to open the Avaya DCE Configurator tool.

- 2. Read the information in the Welcome screen, and then click Next.
- 3. In the Client Deployment screen, select Microsoft Lync/ Communicator Client.
- In the Microsoft Lync/ Communicator Installers screen, select Build Lync Integration Installer, Build Communicator Add-in Installer, or both. Then click Next.
- 5. In the Microsoft Lync/ Communicator Settings screen, click Change.
- 6. In the Lync Integration Settings window, click the **General Settings** tab and enter the configuration details for your deployment.
- 7. Click the **Dialing Settings** tab and enter the details for your deployment.
- 8. If you are deploying a dialingRules.xml file, click the Specify Dialling Rules XML File check box under the Dialing Settings tab, and then click on the folder icon. Navigate to the file location and click Open.
- 9. If required, under the **Additional Settings** and **Video Settings** tabs, specify the settings that you want to use.
- 10. Click **OK** to return to the Configurator wizard.
- 11. In the Microsoft Lync/ Communicator Settings screen, click Next.
- 12. Follow the instructions in the Configurator wizard to finish configuring the installation packages. For more information, see **Configuring the installation packages for the DCE applications with Lync Integration** in *Avaya Configurator for Desktop Communication Enablement Fundamentals* (NN10850–031).
- 13. When you are ready to build the installation packages, in the Configurator wizard's **Build** screen, select the destination folder for the output and then click **Build**.
- 14. From the Avaya Client Applications folder, unzip the Lync Integration and Communicator Add-in files, and extract the .msi file.

Installing Lync Integration locally

Use this procedure to install Avaya Lync Integration where the installation software is local to the machine where it is being installed. The Lync Integration is installed on end user machines coresident with Lync 2010.

When using this procedure to install Lync Integration, no installation log file is created. If you experience problems with installation, perform the installation from the command line and view

the log file. See <u>Installing the Lync Integration on multiple machines from a remote server</u> on page 76.

Before you begin

- You must have administrative privileges on the local desktop.
- \bullet You must have the Lync Integration .msi file. Extract the .msi file from the .zip file created by the Configurator.
- The Microsoft Lync 2010 client must be installed before Avaya Lync Integration is installed.
- The Microsoft Communicator client must be installed before Avaya Communicator Addin is installed.

About this task

The log and support directories can be found in the APPDATA system property.

Procedure

- 1. If open, exit Microsoft Lync 2010.
- 2. If open, exit Internet Explorer.
- 3. Open the Windows Explorer tool and navigate to the location of the Lync Integration .zip file.
- 4. Unzip the file.
- 5. Perform one of the following options.
 - If you are installing Lync Integration:
 - Double click on the Microsoft Lync 2010 SDK installation file LyncSdkRedist-4.0.7577.124.msi and follow the instructions to complete the installation.
 - Double click on the Lync Integration installation file LyncIntegration-<release#>.msi and follow the instructions to complete the installation.
 - If you are installing Communicator Add-in, double click on the Communicator Add-in installation file MCAdd-in-<release#>.msi and follow the instructions to complete the installation.

You may receive a prompt to restart the system. If this occurs, you must reboot the machine to complete the installation.

- 6. Perform one of the following options.
 - If you installed Lync Integration:
 - Start Lync 2010.
 - Start Lync Integration. On Lync 2010, select **Tools** > **Avaya Microsoft Lync Integration**.

😵 Note:

You only need to start Lync Integration after the initial installation. For subsequent Lync 2010 startups, Lync Integration also starts.

- If you installed Communicator Add-in, start Office Communicator.
- 7. On some deployments, the Lync Integration Settings window opens with the **Phone** tab displayed. Enter your **Extension** number and the **Password** for your extension.

Installing the Lync Integration on multiple machines from a remote server

To facilitate the integration of the Avaya Lync Integration software into bulk software distribution and installation infrastructure, the Lync Integration software can be installed without end-user intervention, using the following command:

```
msiexec /i [LyncIntegration | MCAddin]-<release#>.msi
REBOOT=ReallySuppress /L*v [LyncIntegration | MCAddin].install.log /q
```

Installation notes

- The Microsoft Lync 2010 client must be installed before Avaya Lync Integration is installed.
- The Microsoft Communicator client must be installed before Avaya Communicator Addin is installed.
- You must have the Lync Integration .msi file. Extract the .msi file from the .zip file created by the Configurator.
- The /g parameter kills running Lync 2010 client, Lync Integration, and one-X engine processes. The installation cannot proceed if the Microsoft Lync Client is running.
- You may receive a prompt to restart the system. If this occurs, you must reboot the machine to complete the installation.
- Any interaction with the Microsoft Lync Client or Microsoft Communicator by an end user during the installation can result in a failed installation. The [LyncIntegration | MCAddin].install.log will indicate the operation is complete. Please allow enough time for completion of the operation prior to re-starting the Lync 2010 client (up to 1 minute,

for slower machines). Failure to do so will result in an unsuccessful installation and the installation process must be repeated.

- You must have administrator privileges to install the application. On Windows 7, you must open the Command Prompt window using the **Run as administrator** option. To run the Command Prompt as administrator:
 - a. From the Windows start menu, type Command Prompt in the Search programs and files box.

The Command Prompt application is displayed in the list under **Programs**.

b. Right click on Command Prompt and select Run as administrator.

Lync Integration will start the next time Microsoft Lync 2010 is started after logging into Windows. To start Lync Integration without restarting Windows, from the Lync 2010 **Tools** menu, select **Avaya Microsoft Lync Integration**.

To validate the installation, view the log file LyncIntegration.install.log or MCAddin.install.log. The file contains text readable output of the installation process and indicates successful install of Lync Integration.

Deploy Lync Integration on the desktop

Chapter 13: Replacing the dialingRules.xml file on the workstation where Lync Integration is installed

There are two ways of replacing the dialingRules.xml file used.

- Build a new Lync Integration installer including the updated file and then follow the procedures to uninstall and reinstall Lync Integration.
- Use the updateRules.wsf script to update the dialingRules.xml file on a workstation where Lync Integration is installed. This script is intended to be used in conjunction with a company's preferred workstation software deployment method; for example, run as a Microsoft SMS deployed script.

Before you begin

- You must have an updated dialingRules.xml file. See Modifying dialing rules on page 67
- You must be able to run the updateRules.wsf script with Administrative privileges.

😵 Note:

If the new dial plan rules are not applied after a Lync 2010 client restart, reboot the workstation to ensure that the Lync Integration process has been restarted.

Procedure

- 1. On the machine where Lync Integration is installed, open a command prompt window.
- 2. Navigate to the location of the updateRules.wsf tool. The tool is located in the ProgramFiles system property under the Avaya one-X Communicator for MSI folder.
- 3. Run the tool. Enter

```
cscript updateRules.wsf /?
```

Details on how to replace the dialingRules.xml file are displayed.

4. Once the new file is deployed, log out and log back in to the Lync 2010 client to apply the changes.

Replacing the dialingRules.xml file on the workstation where Lync Integration is installed

Chapter 14: Troubleshooting Lync Integration

Use the information in this chapter to help troubleshoot issues related to Lync Integration configuration.

For the most detailed log information, run Lync Integration in debug mode. Click * to open the Settings window and then select the **Support** tab.

For additional troubleshooting information, see *Avaya one-X*[®] *Communicator Troubleshooting* (16-603218).

Add-in disappears when Conversation window is maximized

User Alert

The Avaya Lync Integration add-in disappears when users click the 🔲 icon to maximize the Conversation window. The video screen is no longer visible and users cannot control calls with Lync Integration.

Logs/Alarms

None.

Root Cause

Microsoft takes control of the screen when windows are maximized in the Lync client.

Recovery Action

Minimize the Conversation window. Expand the window by stretching it manually.

Application crashes

User alert

Lync Integration suddenly stops working and shuts down.

Logs/Alarms

No Lync Integration logs for this issue.

The following error alert appears under Control Panel > Administrative Tools > Event Viewer > Applications and Services Logs: Faulting application name: LyncAddin.exe, version 1.0.0.0, time stamp: 0x12345678 Faulting module name: ntdll.dll, version 6.1.7601.17725, time stamp 0x12345678 Exception code: 0xc0000005....

Root Cause

Incompatible software is installed on the work station.

Recovery Action

Do the following:

- 1. Perform the Clean Boot operation to determine the issue. For more information, see http://support.microsoft.com/kb/929135.
- 2. Uninstall and re-install Lync Integration to make sure the issue is resolved.

Application does not launch

User Alert

Lync Integration does not launch when signing into Lync Client 2010, and the Lync 2010 **Tools** menu does not contain the Avaya Lync Integration menu item.

Logs/Alarms

None.

Root Cause

Lync Integration application was not installed successfully.

Recovery Action

Examine Lync Integration installation log, rectify the failing condition, and repeat the installation. Microsoft Installer (MSI) error codes can be found here: <u>http://support.microsoft.com/kb/229683</u>.

Call and video status not updated after network connection is lost

User Alert

If the other party is dropped from a call or video communication due to a failure, such as loss of network connection, the Lync conversation bar of the active party is not updated to show that the call or video is inactive.

Logs/Alarms

None.

Root Cause

The Lync Add-in may not be notified immediately when the other party drops from a call due to a failure.

Recovery Action

If no audio can be heard, the call can be ended. If video is frozen, but audio is still active, the video window can be closed.

Calls fail to originate when the phone is off the hook and the Headset button is lit

User Alert

Calls fail to originate if the Lync Add-in shuts down when the desk phone handset is off the hook or the **Headset** button on the phone is lit. Users cannot make calls.

Logs/Alarms

None.

Root Cause

This issue is caused by an inconsistency in the way that the one-X Communicator engine manages the hook state of the phone line. If the one-X Communicator engine is in the wrong state when it shuts down or when Lync Integration shuts down, the state is not updated correctly on recovery.

Recovery Action

Put the handset back in the cradle or press the **Headset** button on the phone to extinguish the light.

Chained call forwarding: only the first forwarding instruction is processed

User Alert

When the user attempts to use chained call forwarding with Lync Integration, only the first forwarding instruction is acted on. If user A forwards a call to user B, and user B forwards the call to user C, the call rings on user B's line but it does not ring on user C's line as expected.

Logs/Alarms

None.

Root Cause

The current Avaya Aura[®] Communication Manager for the H.323 device does not support the chained call forwarding feature.

Recovery Action

None.

Different behaviors for calls made from the right-click menu and from the green phone icon

User Alert

When a Lync Integration user makes a call by right-clicking on a contact and selecting **Make Voice Call**, the call fails. When the user makes the call by clicking on the green phone icon, the call is successful.

Logs/Alarms

The following example shows the type of information in the Lync Integration log file when the user makes a call by right-clicking on the contact and selecting **Make Voice Call**. For the most detailed log information, run Lync Integration in debug mode.

```
2012-09-06 12:13:18.499 10 Debug DiallingRules: NormalizeUri: incoming number 8672
to +75557778672 using default implementation
2012-09-06 12:13:18.499 10 Debug LyncClientManager: GetNativeContact for uri tel:
+75557778672
2012-09-06 12:13:18.604 10 Debug DiallingRules: GetTranformedString: matched rule:
+75557778672
2012-09-06 12:13:18.605 10 Debug DiallingRules: NormalizeUri: incoming number
+75557778672 to +85557778672 using pattern match
```

Root Cause

The normalized phone number is re-normalized a second time into a different phone number. For example:

- The default implementation normalizes 8672 to +75557778672.
- Pattern match then normalizes +75557778672 to +85557778672.

The number resulting from the first normalization operation should not be re-normalized. All numbers must be completely normalized by the first normalization operation.

Recovery Action

Remove the second normalization operation, and add another normalization rule to convert the first number format into the final form. From the example above, the new normalization rule must convert 8672 to +85557778672.

Enabling debug when Lync Integration is not starting

User Alert

The user cannot get Lync Integration running, and you require more logs and debug information to resolve the issue.

Logs/Alarms

You must enable debug mode.

Root Cause

Unknown.

Recovery Action

- 1. Uninstall Lync Integration.
- 2. Reinstall Lync Integration using the following command line parameter: msiexec /i LyncIntegration-6.2.0-SNAPSHOT.msi DEBUG=true
- 3. Restart Lync Integration.

G729 or G722 Codec negotiation fails

User Alert:

No User Alert Displayed

Logs/Alarms:

No log exceptions. QueryConnection Response missing connection state details.

Root Cause:

One or more endpoints or media elements has codecs disabled.

Recovery Action:

- Verify the G729 and G722 codecs are enabled on Communication Manager.
- Verify that the following four lines exist in the Lync Integration config.xml file :

```
<parameter>
<name>EnableG729</name>
<value>1</value>
</parameter>
```

The config.xml file can be found in the APPDATA system property under the Avaya one-X Communicator for MSI folder.

Install or uninstall failure: script could not be run

User Alert:

There is a problem with the Windows Installer package. A script required for this install to complete could not be run. Contact your support personnel or package vendor.

Logs/Alarms:

The Windows Installer log, if enabled, contains the following log entry.

```
Action start xx:xx: stopOneXClientsForUninstaller.
MSI (s) (B0:04) [xx:xx:xx:xx]: Product: Avaya MC Add-in - Error 1720. There is a
problem with this Windows Installer package. A script required for this install to
complete could not be run. Contact your support personnel or package vendor. Custom
action stopOneXClientsForUninstaller script error -2147217406, : Line 111, Column
15,
Scripting access to WMI is not working.
```

Root Cause:

The Windows Management Instrumentation (WMI) repository is corrupt.

Recovery Action:

Perform the following steps to complete the install or uninstall of Lync Integration. Note that this procedure may not resolve the underlying Windows operating system issue.

- 1. Open a command prompt window. Choose one of the following.
 - On Windows XP, from the Windows Start menu, select Run.

- On Windows 7, you must open an elevated command prompt window. From the Windows Start menu, select All Programs, then Accessories, then right click Command Prompt, and select Run as Administrator.
- 2. Type in the following command and press Enter.

net stop winmgmt

- 3. Open a Windows Explorer window and navigate to the folder C:\Windows \System32\Wbem\Repository.
- 4. Rename the Repository folder.
- 5. Return to the command prompt window and type in the following command and press Enter.

net start winmgmt

6. Type in the following command and press Enter.

EXIT

Invalid phone number format: published phone number does not appear to My Contacts

User Alert:

The Microsoft Lync Communicator presents the following warning: "This number is not a valid phone number. Check the number and try again."

Logs/Alarms:

None.

Root Cause:

The telephone number is not a valid phone number. Only direct inward dial numbers are supported with the solution.

Recovery Action:

Phone numbers must use a Microsoft supported phone number format. See the Microsoft Lync 2010 documentation for information on supported formats. The following is a link to an online document: <u>Set Phones options and numbers</u>.

Lync Integration cannot connect to Servers in Phone Mode (Shared Control) or Computer Mode

User Alert:

Server or connection to the server is down. Please contact your administrator.

The following message displays in the Configure Settings Window on the client: Communication servers are not available. Please contact your administrator.

Logs/Alarms:

2011-06-23 15:19:26.341 1 Debug PopupManager.ShowErrorMsgDialog: The selected mode cannot be accessed without configuring login settings.

Do you wish to exit the Lync Integration? Select **Yes** to exit the Lync Integration. To restart the Lync Integration, please sign-out and sign-in to the OCS Communicator. 2011-06-23 15:19:27.825 1 Debug PopupManager.ShowErrorMsgDialog: The selected mode cannot be accessed without configuring login settings.

Do you wish to exit the Lync Integration? Select **Yes** to exit the Lync Integration. To restart Lync Integration, please sign-out and sign-in to the OCS Communicator.

Root Cause:

No network connectivity between user's Lync Integration machine and Communication Manager.

Recovery Action:

- Use the ping command to ensure that the Communication Manager or Call Server is reachable. This may require establishing the VPN tunnel to the enterprise network.
- Check that Communication Manager is functioning and has no alarms.

Lync Integration Communicator Bar does not appear

User Alert:

No user alert displayed.

Logs/Alarms:

No Lync Integration logs.

Root Cause:

The Lync Integration process is not running because:

- The process was not started after a local install.
- The process has exited.

Recovery Action:

Start Lync Integration. From the Lync 2010 **Tools** menu, select **Avaya Microsoft Lync Integration**.

Lync Integration may disable PC

Lync Integration may disable the computer on which it is running. The computer displays a blue screen and is not responsive.

User Alert:

No user alert displayed.

Logs/Alarms:

No Lync Integration logs.

Root Cause:

The problem occurs because the computer graphics driver is not up to date and is conflicting with a Microsoft security update. The problem can be avoided by ensuring that the current graphics driver is installed.

Recovery Action:

- 1. Remove Security Update MS11-011 KB2393802.
- 2. Update graphics display driver to the latest manufacturer recommended version.
- 3. Reinstall the MS11-011 KB2393802 security patch.

If the workaround described above is not successful, do the following:

- 1. Restore a system update to a snapshot before installing the MS11-011 KB2393802 security patch.
- 2. Update graphics display driver to the latest manufacturer recommended version.
- 3. Reinstall the MS11-011 KB2393802 security patch.

Lync Integration icons do not appear on the Microsoft Office Communicator

User Alert:

No User Alert Displayed

Logs/Alarms:

No Lync Integration logs.

Root Cause:

Lync Integration has not launched on the Microsoft Office Communicator program.

Recovery Action:

- Sign out of Office Communicator and then sign back in.
- Review the Active Directory group policy settings.

Lync Integration Share Now window is displayed instead of Conversation window

User Alert

When making a call, a Share Now window appears instead of the Conversation window.

Logs/Alarms

None.

Root Cause

The issue is caused by a misconfiguration of the dialing rules.

Recovery Action

The dialing rules must be corrected.

- Users must update the dialing rules in Lync Integration by selecting the **Dialing Rules** tab in the Lync Integration **Settings** panel.
- If the issue still persists, you must update the dialingRules.xml file using the Avaya one- X^{\otimes} Communicator Centralized Administration Tool (CAT) or a text editor

See <u>Dialing rules fundamentals</u> on page 39 for more information.

Lync video pane has excessive black border around video frame when using H.264 video codec

User Alert

When using H.264 video encoding with certain video cameras, both the local video preview and the remote received video picture will be surrounded by a thick black border. As a result, the video picture presented in both the local preview and the picture presented to the remote user are smaller than desired.

Logs/Alarms

None.

Recovery Action

A different web camera may not present this issue. Disabling the H.264 video encoding option in the Lync Integration settings also prevents this behavior.

Making a call displays Call number is not defined dialog

User Alert

When making a call, the Call number is not defined dialog is displayed.

Logs/Alarms

None.

Root Cause

The dialing rules are not configured correctly.

Dialing rules should be defined so that the result of the normalization rule is the end result. The number should not be re-normalized to another number. If a normalized number is passed through dialable translations, the number should also be normalized back to the same form that it was in before the dialable translation.

Below is an example of an entry in the dialingRules.xml file that normalizes the number 3509 to 19876543210.

```
<DialingRulesPattern>
<type>1<type>
<pattern>^3509</pattern>
<subString>19876543210</subString>
<minLength>4</minLength>
<maxlegnth>4</maxLength>
<deleteLength>4</deleteLength>
</DialingRulesPattern>
```

With this example setup if a number is entered as 3509 it will first be normalized to 19876543210 using the dialingRules.xml file. This number can then be passed through the dialable rules before being sent to the call server. If the information in the simple dialing rules does not correspond with the normalized number; for example, if the number is longer than the national phone number length or if the area/city code in the simple dialing rules is different from the caller's number, then the number will be dialed unchanged as 19876543210 when it is passed through the dialable rules. If this number is normalized again, it will be discovered as an E.164 number (+19876543210) with the simple dialing rules. The E.164 number resulting from the re-normalization does not match the result of the initial normalization, so the dialing rules are incorrect.

Recovery Action

To fix the issue described above, perform one of the following actions.

• Make sure that the normalized number cannot be normalized again by making sure that the initial normalization converts the number to the E.164 form. To normalize the number in the example scenario above to the E.164 form, you must change the <code>subString</code> field in the dialingRules.xml file to:

<subString>+19876543210</subString>

• Make sure that the normalized number cannot be normalized again to a different number by adding a second rule to stop the simple dialing rules from affecting the normalized number.

After the example scenario above, you could add a rule to normalize the number 19876543210 to 19876543210, and to override the simple dialing rule normalization of 19876543210 to +19876543210.

No microphone sound in computer mode

User Alert:

No User Alert Displayed.

Logs/Alarms:

No log exceptions.

Root Cause:

Using a configured 6.0 version of One-X while installing a 3.0 Lync Integration may set the microphone to zero without any way to adjust the volume.

Recovery Action:

- 1. Exit Communicator.
- 2. Run the Audio Tuning Wizard from the **Settings** menu in the 6.0 version of One-X.

- 3. Sign in to Communicator.
- 4. Ensure that the correct microphone is selected in the Lync Integration Settings window.

Presence state flickers when the user is on a call

User Alert

The user's presence constantly switches from **Busy** — In a Call to another presence state while the user is on an active call.

Logs/Alarms

None.

Root Cause

In the Custom Presence definition file, another presence state has the same ID number as the **Busy** — In a Call state. As a result, when the user is on a call, the **Busy** — In a Call state is constantly overridden by another presence state.

Recovery Action

In the Custom Presence definition file, Lync Integration uses the ID number 1 for the **Busy** — In a Call state. Make sure all other presence states have a different ID number assigned to them.

Privacy settings block contact display: published phone number does not appear to My Contacts

User Alert:

When the user selects a contact and opens the Lync Integration contact card, or uses the **Make Voice Call** or **Make Video Call** buttons from the Lync Integration Conversation Bar, the user is presented with a "No call options available" message.

Logs/Alarms:

None.

Root Cause:

The contact has not published a phone number, or has not granted you access per the Microsoft Lync Privacy Relationship.

Recovery Action:

The rules that apply to Microsoft Lync 2010 presence and privacy relationships also apply to Avaya Lync Integration. For information on presence and privacy relationships, see the

Microsoft Lync 2010 documentation. The following is a link to an online document: Microsoft Communicator Presence and Privacy Relationships.

Scripting access to WMI is not working

User Alert

There is a problem with this Windows Installer package. A script required for this install to complete could not be run. Contact your support personnel or package vendor.

Logs/Alarms

None.

Root Cause

The WMI repository on Windows XP is corrupted.

Recovery Action

Use the following steps to fix a corrupted WMI repository on Windows XP. For more information, see Avaya one- X^{\otimes} Communicator Troubleshooting (16–603218).

- 1. From the Start menu, select Run.
- 2. In the Run window, type CMD.EXE.
- 3. Enter the following command net stop winmgmt. Then press Enter on your keyboard.
- 4. Rename the folder %windir%\System32\Wbem\Repository (for example, you can rename the folder as %windir%\System32\Wbem\Repository Bad).
 - 😵 Note:

<code>%windir% represents the path to the Windows directory, which is typically C: $\Mindows.</code></code>$

5. Open the Command Prompt window. To launch this window from the **Start** menu, do the following:

• Click Start > Programs > Accessories > Command Prompt.

6. Type the following command:

```
net start winmgmt
EXIT
```

Press Enter on your keyboard after each line.

User receives error messages after making a second call

User Alert

When the user makes a second call, Lync Integration attempts to retrieve the first call from the held state and terminate the second call. The user receives one of the following error messages:

- End call failed message on the call control bar.
- The Conversation window is closed. The call is still in progress. Do you wish to terminate the call? **pop-up message**.

Logs/Alarms

The following example shows the type of information that appears in the Lync Integration log file when the user makes the second call. For more detailed log information, run Lync Integration in debug mode.

```
SparkXMLProxy: SENT: <?xml version="1.0" encoding="utf-8"?>
<HoldSessionRequest xmlns="http://www.avaya.com/schemas/UISchema.xsd">
<clientId>1</clientId>
<requestId>18</requestId>
<targetId>-2</targetId>
<connectionId>1</connectionId>
</HoldSessionRequest>
SparkXMLProxy: SENT: <?xml version="1.0" encoding="utf-8"?>
CreateSessionRequest xmlns="http://www.avaya.com/schemas/UISchema.xsd">
<clientId>1</clientId>
<requestId>19</requestId>
<targetId>-2</targetId>
<mediaType>audio</mediaType>
<remoteAddress>211601</remoteAddress>
<subject>Make a call</subject>
<requestURL/>
<applyDialingRules>true</applyDialingRules>
<reuseDialingSession>false</reuseDialingSession>
<emergency>false</emergency>
<editDialing>false</editDialing>
<onhookDialing>false</onhookDialing>
</CreateSessionRequest>
OneXSparkXMLProvider: RECEIVED: <HeldEvent xmlns="http://xml.avaya.com/
endpointAPI">
<connectionId>1</connectionId>
</HeldEvent>
OneXSparkXMLProvider: RECEIVED: <HoldSessionResponse xmlns="http://xml.avaya.com/
endpointAPI">
<clientId>1</clientId>
<requestId>18</requestId>
<statusCode>0</statusCode>
<reason>success</reason>
<connectionId>1</connectionId>
</HoldSessionResponse>
OneXSparkXMLProvider: RECEIVED: <UnheldEvent xmlns="http://xml.avaya.com/
endpointAPI">
```

```
<connectionId>1</connectionId>
</UnheldEvent>
```

Root Cause

The **Unhold** dial plan parameter setting under **Conference/Transfer** in Avaya Aura[®] Communication Manager is set to Y. The logs display an unexpected <UnheldEvent> message.

Recovery Action

Change the Unhold setting in Communication Manager to N.

Video calls cause high CPU usage

User Alert

High CPU usage during video calls. The user's computer may appear inoperable.

Logs/Alarms

None.

Root cause

One or more of the following issues causes the user's computer to appear inoperable during Lync integration video calls:

- · The computer barely meets the minimum video hardware requirements
- · Video codec selection involves a high CPU utilization codec
- The computer is running many other programs at the same time, causing the computer to lag during video calls

Recovery Action

Action 1:

In the Lync Integration Settings panel, under the Video tab, disable H.264.

Action 2:

If the first recovery action does not resolve the problem, do the following:

1. Add or modify the following text in the config.xml file. The file is located in the APPDATA system property under the **one-X Communicator for MSI** folder.

```
<parameter>
<name>CPUUsageLimitVideoCall</name>
<value>35</value>
</parameter>
```

2. Sign out of the Lync client and then sign in again.

Chapter 15: Troubleshooting the one-X engine

Use this procedure to turn on debug logging for the one-X engine. The one-X logging levels are listed below. The default level is 3.

• 0 = EMERGENCY

Emergency only - essentially no logging - application crash events

• 1= ALERT

Alert Not used

• 2 = CRITICAL

Critical - Error that will cause instability in the application

• 3 = ERROR

Only error conditions - behavior that is not expected but will not cause application to crash

• 4 = WARNING

Unexpected behavior that is not an error but should be investigated

• 5 = NOTICE

Normal logging information that is essential operation of the program

• 6 = DEBUG

Only for debugging information that can possibly be activated in the field

• 7 = DEBUG

For very high level messages that are to occur potentially many times - for Message Logging

To turn on debug logging, you must edit the config.xml file located in the Avaya one-X Communicator for MSI installation folder. The folder is in the APPDATA system property.

To turn on default debug logging, add the following to the config.xml file.

```
<parameter>
<name>LocalLogLevel</name>
<value>6</value>
</parameter>
<parameter>
<name>LogCategoryList</name>
<value>ALL,</value>
</parameter>
<parameter>
<name>AudioLogLevel</name>
```

<value>6</value> </parameter> <parameter> <name>AudioCategoryList</name> <value> TRACE,API,DEBUG,</value> </parameter>

To turn on maximum debug logging, add the following to the config.xml file.

```
<parameter>
<name>LocalLogLevel</name>
<value>7</value>
</parameter><parameter>
<name>LogCategoryList</name>
<value>ALL,</value>
</parameter><parameter>
<name>AudioLogLevel</name>
</parameter><parameter>
<name>AudioCategoryList</name>
<value>TRACE,API,DEBUG,</value>
</parameter>
</parameter>
```

😵 Note:

To enable the new log setting, you must sign out and then sign back in to Communicator.

One-X Communicator log files are located in the user's Avaya one-X Communicator for MSI application data directory under the APPDATA system property.

The Log Files folder contains debug log files for several components. The main log file is EndpointLog.txt.

Chapter 16: Uninstall Lync Integration

This section contains the procedures for uninstalling the Avaya Lync Integration software deployed on the desktop.

Navigation

- Uninstalling Lync Integration from the local desktop on page 99
- Uninstalling Lync Integration from multiple machines on page 100

Uninstalling Lync Integration from the local desktop

😵 Note:

- Avaya Lync Integration must be uninstalled before the Microsoft Lync 2010 client is uninstalled.
- Avaya Communicator Add-in must be uninstalled before the Microsoft Communicator client is uninstalled.

Before you begin

- You must have administrator privileges to uninstall the application.
- Close Lync 2010 before performing the uninstall.

Uninstallation notes

- If you attempt to uninstall Lync Integration from the Control Panel while an instance launched by a different user is still running, you receive the following message:

```
The following application is running and cannot be terminated: Avaya
Microsoft Lync Integration. The uninstaller cannot proceed.
Continue by choosing one of the following options:
- Restart the system and repeat the uninstall from the Control
Panel.
- Uninstall using the command line procedure Uninstalling Lync
Integration from multiple machines.
```

- You may receive a prompt to restart the system. If this occurs, you must reboot the machine to complete the uninstallation.
- If a version of one-X Communicator lower than release 6.1 is installed on the same machine as Lync Integration, then the one-X Communicator software must be re-installed after the Lync Integration uninstallation.

Uninstallation notes

- Based on industry standard practise, the uninstall process does not remove the Lync Integration registry keys. The registry keys can be removed manually from HKey Current User\Software\Avaya\Avaya Microsoft Integration.
- The uninstall process does not remove the existing product log files. When upgrading from a previous version of the Lync client to a more recent version of the Lync client or from the Communicator client to the Lync client, the log destination folder changes. The log files from the previous client must be removed manually.

Procedure

- 1. From the Windows Start menu, select Settings, Control Panel, then Add or Remove Programs.
- 2. In the Add or Remove Programs window, select **Avaya Microsoft Lync** Integration and then click **Remove**.
- 3. You are prompted to confirm the uninstall. Click **Yes**.

Uninstalling Lync Integration from multiple machines

😵 Note:

- Avaya Lync Integration must be uninstalled before the Microsoft Lync 2010 client is uninstalled.
- Avaya Communicator Add-in must be uninstalled before the Microsoft Communicator client is uninstalled.

To facilitate the integration of the Avaya Lync Integration software into bulk software distribution and installation infrastructure, the Lync Integration software can be uninstalled without enduser intervention, using the following command.

```
msiexec /x [LyncIntegration | MCAddin]-<release#>.msi
REBOOT=ReallySuppress /L*v [LyncIntegration | MCAddin].uninstall.log /q
```

Uninstallation notes

- The /q parameter kills the running Lync 2010 client, Lync Integration, and one-X engine processes. The uninstallation cannot proceed if the Microsoft Lync Client is running.
- Any interaction with the Microsoft Lync client or Microsoft Communicator by an end user during the uninstallation can result in a failed uninstallation. The [LyncIntegration | MCAddin].install.log will indicate the operation is complete. Please allow enough time for completion of the operation prior to restarting the Lync 2010 client (up to 1 minute,

for slower machines). Failure to do so will result in an unsuccessful uninstallation and the uninstallation process must be repeated.

- You must have administrator privileges to uninstall the application. On Windows 7, you must open the Command Prompt window using the **Run as administrator** option. To run the Command Prompt as administrator:
 - a. From the Windows start menu, type Command Prompt in the Search programs and files box.

The Command Prompt application is displayed in the list under **Programs**.

- b. Right click on Command Prompt and select Run as administrator.
- You may receive a prompt to restart the system. If this occurs, you must reboot the machine to complete the uninstallation.
- If a version of one-X Communicator lower than release 6.1 is installed on the same machine as Lync Integration, then the one-X Communicator software must be re-installed after the Lync Integration uninstallation.
- Based on industry standard practise, the uninstall process does not remove the Lync Integration registry keys. The registry keys can be removed manually from HKey_Current_User\Software\Avaya\Avaya Microsoft Integration.
- The uninstall process does not remove the existing product log files. When upgrading from a previous version of the Lync client to a more recent version of the Lync client or from the Communicator client to the Lync client, the log destination folder changes. The log files from the previous client must be removed manually.

To validate the uninstallation, view the log file LyncIntegration.uninstall.log or MCAddin.uninstall.log. The file contains text readable output of the uninstallation process and indicates successful uninstall of Lync Integration.

Uninstall Lync Integration


Chapter 17: Upgrade Lync Integration

This section contains the procedures for upgrading the Avaya Lync Integration software deployed on the desktop.

Note that the Avaya one-X[®] engine is now embedded with the Lync Integration software. Since the one-X Communicator is no longer required by Lync Integration, you have the option to uninstall the one-X Communicator software. Uninstall one-X Communicator before upgrading Lync Integration.

Upgrade Lync Integration procedures

This task flow shows the procedures you perform to upgrade Lync Integration.



Uninstalling one-X Communicator

Use this procedure to uninstall the Avaya one-X Communicator.

Procedure

- 1. From the Windows Start menu, select Settings, Control Panel, then Add or Remove Programs.
- 2. In the Add or Remove Programs window, select **Avaya one-X Communicator** and then click **Remove**.
- 3. You are prompted to confirm the uninstall. Click **Yes**.

Upgrading Lync Integration

Before you begin

- Before upgrading Lync Integration, review the chapters listed under <u>Work flow for</u> <u>deploying Lync Integration</u> on page 53 to ensure that all prerequisites have been met.
- To upgrade Avaya Lync Integration, you must perform the procedure to uninstall the old version and then install the new version.

Note that all versions of both Lync Integration and Communicator Add-in must be uninstalled before proceeding to install the current version.

 \bullet Before you can install the new version, you must build the $\tt.msi$ file using the Configurator tool.

Note that if an earlier version of the Configurator is installed, it must be removed prior to installing the new Configurator.

• You must close Lync 2010 before performing the upgrade.

Procedure

- 1. Uninstall the old version of Lync Integration. Perform one of the following procedures:
 - <u>Uninstalling Lync Integration from the local desktop</u> on page 99
 - <u>Uninstalling Lync Integration from multiple machines</u> on page 100

- 2. Install the Configurator. Perform the procedure <u>Installing the Configurator</u> on page 71.
- 3. Build the .msi file. Perform the procedure <u>Building the install package</u> on page 71.
- 4. Install Lync Integration. Perform one of the following procedures:
 - Installing Lync Integration locally on page 74
 - <u>Installing the Lync Integration on multiple machines from a remote server</u> on page 76


Upgrade Lync Integration

Chapter 18: Migrating from Communicator Add-in to Lync Integration

This section describes the steps to follow when migrating from Microsoft Communicator with Communicator Add-in to Microsoft Lync 2010 with Lync Integration. Avaya Communicator Add-in and Avaya Lync Integration cannot be installed on the same workstation.

Upgrade Lync Integration procedures

This task flow shows the procedures you perform to upgrade Lync Integration.



Navigation

- The process to uninstall Communicator Add-in and Lync Integration is the same. See <u>Uninstall Lync</u> <u>Integration</u> on page 99.
- For the procedure to uninstall Microsoft Office Communicator, see the Microsoft documentation.
- For the procedure to install Microsoft Lync 2010, see the Microsoft documentation.
- Before installing Lync Integration, review the chapters listed under <u>Work flow for deploying Lync</u> <u>Integration</u> on page 53 to ensure that all prerequisites have been met. To install Lync Integration, see <u>Deploy Lync Integration on the desktop</u> on page 69