

DEFINITY AUDIX Migration Checklist

To migrate from a DEFINITY AUDIX R3.1, 3.2, or 4.0 system to an INTUITY AUDIX system, complete the following tasks:

Area	Task
Preparing for the migration	1. Gathering Materials and Information (page 3).
	2. Assemble the INTUITY AUDIX system.
	3. Restore power to the INTUITY AUDIX system.
	4. Recording the DEFINITY AUDIX™ Profile Information (page 5).
	5. Contact the MMIS for Running the File System Check (page 7).
	6. X-Porting the Switch Voice Ports (page 8).
	7. Busying Out the Switch Data Link (page 8).
	8. Removing the DEFINITY AUDIX Voice Ports (page 9) from the switch hunt group.
	9. Installing the Migration Software (page 10) on the INTUITY AUDIX system.
Migrate the data	10. Connecting the External Tape Drive (page 11).
	11. Backing Up the DEFINITY AUDIX Data (page 15).
	12. Preadministering the INTUITY AUDIX Extension Lengths (page 18).
	13. Connecting the Tape Drive and Transferring the Data (page 19). Note: If the INTUITY AUDIX is a MAP/5P, MAP/5PV3, or MAP/5PV4, the SCSI interface card is installed during this procedure.
	14. Verifying the Data Transfer (page 24).
	15. If the INTUITY AUDIX is a MAP/5P, MAP/5PV3, or MAP/5PV4, continue with Removing the SCSI Interface Card (page 27).

Area	Task
Complete the administration	16. Removing the Migration Software (page 29).
	17. Cabling the INTUITY AUDIX System (page 30).
	18. Administering for the Switch (page 32).
	19. Readministering the Voice Port Information (page 32).
	20. Confirming the Switch Link Information (page 33).
	21. Releasing the Switch Data Link (page 33).
	22. Completing Additional Installation Tasks (page 34).
