

# Migrating from AUDIX R1 V8

---

This section describes migrating from an AUDIX R1 V8 system to an Intuity AUDIX system. The new Intuity AUDIX system provides service for all new messages; however, this procedure includes allowing subscribers to retrieve their old messages from the AUDIX R1 for some time after the migration.

Follow these procedures in the given sequence to minimize the time the customer is without voice messaging service. This sequence of tasks also assumes the customer wants to:

- Minimize the purchase of additional voice ports
- Leave the AUDIX R1 mailboxes available for a short period of time after the migration

The tasks are grouped into these general areas:

- Preparing for the Data Transfer (page 2)
- Transferring the Data (page 2)
- Completing the Migration (page 2)

## Migration Checklist

To migrate from an AUDIX R1 V8 system to the Intuity AUDIX system:

|  | Task  |
|--|---|
| <b>Preparing for the Data Transfer</b> | 1. <a href="#">Gather the information and materials needed.</a>   |
|  | 2. Assemble the Intuity AUDIX system. For more information, select your MAP under <a href="#">Assembling the System</a> . |
|  | 3. <a href="#">Restore power</a> to the Intuity AUDIX system.   |
|  | 4. <a href="#">Record the AUDIX R1 profile information.</a>   |
|  | 5. <a href="#">Preadminister the Intuity AUDIX system.</a>  |
|  | 6. <a href="#">Install the migration software.</a>  |
| <b>Transferring the Data</b>           | 7. <a href="#">Set up the migration parameters.</a>   |
|  | 8. <a href="#">Prepare the modem connection.</a>  |
|  | 9. <a href="#">Setting up network machine data.</a>   |
|  | 10. <a href="#">Run the data transfer.</a>  |
|  | 11. <a href="#">Check the log file.</a>   |
|  | 12. <a href="#">Verify the data transfer.</a>   |
| <b>Completing the Migration</b>        | 13. <a href="#">Update the switch administration.</a>   |
|  | 14. <a href="#">Cable both systems.</a>   |
|  | 15. <a href="#">Readminister the AUDIX R1 system.</a>   |
|  | 16. <a href="#">Confirm the Intuity AUDIX configuration.</a>  |
|  | 17. <a href="#">Set up digital networking.</a>  |
|  | 18. <a href="#">Remove the migration software.</a>  |
|  | 19. <a href="#">Complete the migration.</a>   |