

System Programming																
System	SysRenumbr	Operator	LinesTrunks				Extensions	Options	Tables	AuxEquip	NightSrvce	Labeling	Data	Print	Cntr-Prg	Language
Restart	Default Numbering <ul style="list-style-type: none">• 2-Digit• 3-Digit• SetUp Space Single <ul style="list-style-type: none">• Lines*• Extensions*• Pools*• Group Page*• GrpCalling*• Adjuncts*• Park*• ARS DialOut• RemoteAccs• DSS Buttons*• ListDilrctNo Block <ul style="list-style-type: none">• Lines• Extensions• Adjuncts NonLocal UDP	Positions <ul style="list-style-type: none">• Direct Line*• Queued Call* Queued Call <ul style="list-style-type: none">• Hold Rtn<ul style="list-style-type: none">- Return to Queue- Remain On Hold• HoldRelease<ul style="list-style-type: none">- Auto Hold- Auto Release• Threshold• ElvatePrior• InQue Alert*<ul style="list-style-type: none">- InQue Alert Enable- InQue Alert Disable• Call Types<ul style="list-style-type: none">- Dial 0<ul style="list-style-type: none">- Priority- Operator*- ListedNumbr<ul style="list-style-type: none">- Priority- Operator*- QCC Ext- Returning<ul style="list-style-type: none">- Priority- Operator*- GrpCoverage<ul style="list-style-type: none">- Priority- Operator*• Msg Center *• ExtndComplt<ul style="list-style-type: none">- Automatic Complete- Manual Complete• Return Ring• QCC Backup• Voice AnncHold TimerDLC Hold<ul style="list-style-type: none">• Auto Hold Enable• Auto Hold Disable	LSGS/DS1 <ul style="list-style-type: none">• (DS1)<ul style="list-style-type: none">- Type<ul style="list-style-type: none">- T1*- GroundStart*- Loop Start*- TIE- TIE-PBX*- Toll*- S56- Unequipped- All Ground- All Loop- All TIE- TIE-PBX- Toll- S56- All Unequip- DID*- All DID- S56 Data<ul style="list-style-type: none">- Direction- Intype- Outtype- AnsSupv- Disconnect- Wink- All S56 Data- Direction- Intype- Outtype- AnsSupv- Disconnect- Inmode- Outmode- PRI- FrameFormat- D4 Compatible- Extended Super Frame- Suppression- AMI-ZCS- B8ZS- Signaling<ul style="list-style-type: none">- Robbed Bit- Common Channel- Line Comp- Clock Sync- Priority<ul style="list-style-type: none">- Primary- Secondary- Tertiary- None- Source<ul style="list-style-type: none">- Loop- Local- Activation<ul style="list-style-type: none">- Active- Not Active- Channel/Unit<ul style="list-style-type: none">- Foreign- Exchange- Special Access• (4xx GS/LS)<ul style="list-style-type: none">- GroundStart*- LoopStart*- All Ground- All Loop• (8xxGS/LS)<ul style="list-style-type: none">- GroundStart*- LoopStart*- All Ground- All Loop TIE Lines <ul style="list-style-type: none">• Direction<ul style="list-style-type: none">- Two Way- OutGoing- Incoming	Intype <ul style="list-style-type: none">- Wink- Delay- Immed- Auto Outtype <ul style="list-style-type: none">- Wink- Delay- Immed- Auto E&M Signal <ul style="list-style-type: none">- Type 1S- Type 1C- Type 5 Inmode†Outmode†Dialtone†AnsSupvrDisconnectTT/LS Disc <ul style="list-style-type: none">• OutMode†• LS Disconnect<ul style="list-style-type: none">- Yes- No DID <ul style="list-style-type: none">• Block†• Type<ul style="list-style-type: none">- Immed- Wink• Disconnect<ul style="list-style-type: none">- ExpectDigit• DeleteDigit• Add Digits• Signaling<ul style="list-style-type: none">- Rotary- Touch Tone• InvalDstn<ul style="list-style-type: none">- Send to Backup- Extension- Return Fast Busy PRI <ul style="list-style-type: none">• PhoneNumber• B-ChannelGrp<ul style="list-style-type: none">- B Channels*- Lines*†- NetworkServ- AT&T Toll<ul style="list-style-type: none">- Megacom WATS- ACCUNET SDS- Pattern- Soft DefNetw- Megacom 800- MULTI QUEST- Long distnce- 5ESS Local- OUTWATS- 56/64 digit- Virt PrivNet- INWATS- MCI Toll- MCI PRISM- MCI VNET- MCI 800- MCI 900- DMS-100Local- DMS-Private- DMS-OUTWATS- DMS-FX- DMS-TieTrk- Misc<ul style="list-style-type: none">- Other- CallByCall- Legend UDP- ElecTandNtwk- Copy Number- Copy PhnNum- to NumToSend- Do not Copy- Phone Number - IncomingRtg - Routing by Dial Plan - Route by Line Appearance - Route Directly to UDP	NumbrToSend <ul style="list-style-type: none">- Extension Only- Base Number with Ext- Line Telephone Number Test TelNumProtocol <ul style="list-style-type: none">- Timers<ul style="list-style-type: none">- T200 Timer- T203 Timer- N200 Counter- N201 Counter- K Counter- T303 Timer- T305 Timer- T308 Timer- T309 Timer- T313 Timer- T316 Timer- TEI DialPlanRtg <ul style="list-style-type: none">- Service<ul style="list-style-type: none">- AT&T Toll- Megacom 800- ACCUNET SDS- SoftDefNetw- MULTI QUEST- Megacom WATS- Long Distnce- 5ESS Local- INWATS- 56/64 Digtl- VirtPrivNet- Outwats- Misc<ul style="list-style-type: none">- Other- Call ByCall- DMS-100 Local- Patterns<ul style="list-style-type: none">- TotalDigits- DeleteDigits- Add Digits• Outgoing Tbl<ul style="list-style-type: none">- NetwkSelect- SpecialServ- Pattern- Operator- Local Operator- Presubscribed Carrier- No Operator- TypeOfNumber- National- International- DeleteDigit- CBC Service- Patterns- Voice/Data- Voice Only- Data Only- Voice/Data- NetworkServ- AT&T Toll- Megacom WATS- ACCUNET SDS- MCI PRISM- MCI VNET- MCI 800- MCI 900	LinesTrunks†Line Copy <ul style="list-style-type: none">• Single• Block Dial OutCd†Restriction <ul style="list-style-type: none">• Unrestricted• Outward Restrict• Toll Restrict RestrctCopy <ul style="list-style-type: none">• Single• Block Account*BIS/HFAI*Call Pickup*VoiceSignl*Ext Status*Group Page*Group Cover*Grp Calling* <ul style="list-style-type: none">• Hunt Type<ul style="list-style-type: none">- Circular- Linear- Most Idle• DelayAnnce<ul style="list-style-type: none">- Primary- Announcements- Secondary- Announcement- Announcement Interval- Repeat- Announcement• GrpCoverage†• Message<ul style="list-style-type: none">• Queue Alarm- Alarm Threshold 1- Alarm Threshold 2- Alarm Threshold 3• Xtnl Alert• Overflow<ul style="list-style-type: none">- Number Based- Time Based- Prompt Based• Members*• Line/Pool*• Group Type<ul style="list-style-type: none">- Auto Login- Auto Logout- Integ VMI- Generic VMI• Queue Control• Priority• Support ARS RestrctMic Disable*Remote Frwd*Auth CodeDelay FrwdTrkTransferCover Delay <ul style="list-style-type: none">• Primary• Secondary HotLineDisplayPref <ul style="list-style-type: none">• Calling Name• Calling Num• Both ServiceObs <ul style="list-style-type: none">• Observer• Warning• Yes- No • MembersRotary EnableETR	Transfer <ul style="list-style-type: none">• Return Time• One Touch<ul style="list-style-type: none">- Transfer- Manual- Automatic- Hold• Audible<ul style="list-style-type: none">- MusicOnHold- Ringback• Type<ul style="list-style-type: none">- Voice Announce- Ring CampOnCallParkRtnDelay RingCallbackExt Status <ul style="list-style-type: none">• Hotel• GrpCall/CMS SMDR <ul style="list-style-type: none">• Format<ul style="list-style-type: none">- Basic SMDR- Linear- ISDN SMDR• Call Length• Call Report<ul style="list-style-type: none">- In/Out- Out Only• New Page• Auth Code<ul style="list-style-type: none">- Home Extension Number- Authorization Code- Talk Time• UDP<ul style="list-style-type: none">- Log In/Out- Log None Inside Dial <ul style="list-style-type: none">• Inside• Outside ReminderSrvUnassigned <ul style="list-style-type: none">• QCC Queue• Extension• Grp Calling BehndSwitch <ul style="list-style-type: none">• Transfer• Conference• Drop RecallTimer <ul style="list-style-type: none">• 350 ms• 450ms• 650 ms• 1 sec Rotary <ul style="list-style-type: none">• Delay• No Delay Inter-DigitRinging FreqSecDTTimer	AllowListAllowTo†DisallowDisallowTo†ARS <ul style="list-style-type: none">• ARS1+7Dial<ul style="list-style-type: none">- Within Area Code- Not Within Area Code• ARS Input<ul style="list-style-type: none">- 6-Digit- Area Code†- Exchange†- 1+7†• Sub A Pools• Sub A FRL• Sub A Absorb• Sub A Digit• Sub B Start• Sub B Stop• Sub B Pool• Sub B FRL• Sub B Absorb• Sub B Digit• SpecdNumber<ul style="list-style-type: none">- ARS FRL- ARS Digit• Dial 0<ul style="list-style-type: none">- ARS Pool- ARS FRL- ARS Digits• Sub A Data<ul style="list-style-type: none">- Voice Only- Data Only- Voice/Data• Sub B Data<ul style="list-style-type: none">- Voice Only- Data Only- Voice/Data UDP Routing <ul style="list-style-type: none">• Pool• FRL• Absorb• Digits• Data<ul style="list-style-type: none">- Voice Only- Data Only- Voice/Data	MusicOnHoldLdspkr Pg*Fax <ul style="list-style-type: none">• Extension*• Msg Waiting*• Threshold MaintAlarmsVMS/AA <ul style="list-style-type: none">• TransferRtn• TT Duration• TT Interval CTI Link	Group Assign † <ul style="list-style-type: none">• Extensions*• Calling Grp• Lines• CoverContrl OutRestrictEmergencyExcludeList*Start*Stop*Time Control <ul style="list-style-type: none">- On- Off Cover Contrl	Directory <ul style="list-style-type: none">• System• Extension• Personal LinesTrunksPostMessageGrp Calling	Voice/Data*2B Data	AllSysSet-upDial PlanNon-Locl UDPLabelsTrunk Info <ul style="list-style-type: none">• TIE• DID• Loop/Ground• General• S56 Data T1 InfoPRI InfoRmoteAccessOper InfoAllowListAllowListToDisallowLstDisallowToARSExt DirectSys DirectGroup pageExt InfoGrpcoverageGrp CallingNight ServiceCall PickupError LogAuth CodeBRI InfoNon-Local UDPServiceObs	Program ExtCopy Ext	System Lang <ul style="list-style-type: none">• English• French• Spanish Extensions <ul style="list-style-type: none">• Single<ul style="list-style-type: none">- English- French- Spanish• Block<ul style="list-style-type: none">- English- French- Spanish SMDR <ul style="list-style-type: none">• English• French• Spanish Printer <ul style="list-style-type: none">• English• French• Spanish	
* The inspect feature can be used with this menu option. Press Inspect or PgDn.																
† The Inspect feature can be used in entry mode with this menu option. Press Inspect or PgDn while in entry mode.																