



## Avaya™ 3606 Wireless IP Telephone Quick Reference Guide

### Accessing the Function Menu

Press **FCN** followed by a digit (**1-4**, and \* or #) while off-hook to access the feature options programmed for your Wireless Telephone template.

When you are on a call, your Wireless Telephone display will show a solid number indicating which line you are currently using. If a second call comes in on another line, a flashing second number will appear to indicate which line is ringing.

The Line appearances administered for your extension are displayed by pressing the **LINE** key when the Wireless Telephone is off hook. If the > icon is on, additional appearances can be displayed by repeatedly pressing the **LINE** key. The line is selected by pressing the number key corresponding to the number to the left of the “=” in the menu. The line does not have to be on the current display to be selected.

The Wireless Telephone has two volume levels, low and high. You can set your low volume level by pressing **FCN** while your Wireless Telephone is on-hook, and selecting a volume **1** through **8**. While you are talking on the Wireless Telephone, press **VOL** once to switch your volume level from low to high and vice versa. The Wireless Telephone will reset to the low volume when powered off.

See User Options at right for additional options that can be configured at the end user level.

Press **START**, then **FCN** to access the Function Menu, which lists the feature options programmed in your Wireless Telephone.

Function Key Strokes	Fill In Your Feature Settings
FCN + 1	Mute
FCN + 2	Last Number Dialed
FCN + 3	Transfer
FCN + 4	Conference
FCN + 5	
FCN + 6	
FCN + 7	
FCN + 8	
FCN + 9	
FCN + 0	

For information on Battery Pack charging, see the Avaya™ 3606 Wireless IP Telephone User Guide.



### 3606 Wireless IP Telephone

<b>On/Off</b>	Press and hold <b>PWR</b> . Two chirps on, one chirp off
<b>Make a call</b>	Press <b>START</b> to get dial tone.
<b>Hang up</b>	Press <b>END</b> . Be sure to do this at the end of each call.
<b>Answer call</b>	Press <b>START</b> . Line indicator comes on steady when the call is answered.
<b>Answer second call</b>	Press <b>HOLD</b> to put your current call on hold, or <b>END</b> to hang up. Press <b>LINE</b> + the digit that is flashing.
<b>Headset answer</b>	Press any key (other than <b>PWR</b> or <b>END</b> ) to answer a call when a headset is plugged in
<b>Hold</b>	Press <b>HOLD</b>
<b>Take off Hold</b>	Press <b>LINE</b> followed by the digit for the line on hold, which will be flashing.
<b>Function</b>	Pressing <b>FCN</b> while off hook allows you to scroll through menu screens.
<b>User Options</b>	Press <b>FCN</b> while on hook to change handset settings (* shows current, follow display instructions to set): Volume level—1 (softest) to 8 (loudest) Ring Type (available types vary) High Noise Mode—select: Normal (for most office environments) High (for moderate background noise) Severe (for extremely noisy conditions)
<b>Silence while ringing</b>	Press the <b>END</b> key to silence the ring.
<b>Adjust Volume</b>	Press <b>VOL</b> while in a call to toggle between base and louder level
<b>Status/Tone Indicators</b>	
<b>NO SVC Alarm / Restore</b>	An alarm sounds when the Wireless Telephone cannot receive or place calls. You may be outside of the coverage area. Walk back into the covered area. A restore tone indicates service is re-established.
<b>BATT Beep</b>	Your Battery Pack charge is low. Your Battery Pack needs to be recharged or replaced.
<b>MSG</b>	You have a voice mail message.