



Avaya Call Management System
Release 13
Database Items and Calculations

07-300330
Issue 1.0
May 2005

Notice

While reasonable efforts were made to ensure that the information in this document was complete and accurate at the time of printing, Avaya Inc. can assume no liability for any errors. Changes and corrections to the information in this document may be incorporated in future releases.

Documentation disclaimer

Avaya Inc. is not responsible for any modifications, additions, or deletions to the original published version of this documentation unless such modifications, additions, or deletions were performed by Avaya. Customer and/or End User agree to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation to the extent made by the Customer or End User.

Link disclaimer

Avaya Inc. is not responsible for the contents or reliability of any linked Web sites and does not necessarily endorse the products, services, or information described or offered within them. We cannot guarantee that these links will work all of the time and we have no control over the availability of the linked pages.

Warranty

Avaya Inc. provides a limited warranty on this product. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product, while under warranty, is available through the following Web site:

<http://www.avaya.com/support>

Preventing toll fraud

"Toll fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, anyone who is not a corporate employee, agent, subcontractor, or person working on your company's behalf). Be aware that there may be a risk of toll fraud associated with your system and that, if toll fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya fraud intervention

If you suspect that you are being victimized by toll fraud and you need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Web site:

<http://www.avaya.com/support>

Providing telecommunications security

Telecommunications security (of voice, data, and video communications) is the prevention of any type of intrusion to (that is, either unauthorized or malicious access to or use of) your company's telecommunications equipment by some party.

Your company's "telecommunications equipment" includes both this Avaya product and any other voice/data/video equipment that could be accessed via this Avaya product (that is, "networked equipment").

An "outside party" is anyone who is not a corporate employee, agent, subcontractor, or person working on your company's behalf. Whereas, a "malicious party" is anyone (including someone who may be otherwise authorized) who accesses your telecommunications equipment with either malicious or mischievous intent.

Such intrusions may be either to/through synchronous (time-multiplexed and/or circuit-based) or asynchronous (character-, message-, or packet-based) equipment or interfaces for reasons of:

- Use (of capabilities special to the accessed equipment)
- Theft (such as, of intellectual property, financial assets, or toll-facility access)
- Eavesdropping (privacy invasions to humans)
- Mischief (troubling, but apparently innocuous, tampering)
- Harm (such as harmful tampering, data loss or alteration, regardless of motive or intent)

Be aware that there may be a risk of unauthorized intrusions associated with your system and/or its networked equipment. Also realize that, if such an intrusion should occur, it could result in a variety of losses to your company (including, but not limited to, human and data privacy, intellectual property, material assets, financial resources, labor costs, and legal costs).

Your responsibility for your company's telecommunications security

The final responsibility for securing both this system and its networked equipment rests with you, an Avaya customer's system administrator, your telecommunications peers, and your managers. Base the fulfillment of your responsibility on acquired knowledge and resources from a variety of sources, including, but not limited to:

- Installation documents
- System administration documents
- Security documents
- Hardware-/software-based security tools
- Shared information between you and your peers
- Telecommunications security experts

To prevent intrusions to your telecommunications equipment, you and your peers should carefully program and configure:

- Your Avaya-provided telecommunications systems and their interfaces
- Your Avaya-provided software applications, as well as their underlying hardware/software platforms and interfaces
- Any other equipment networked to your Avaya products.

Trademarks

Avaya is a trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners.

Document ordering information:

Avaya Publications Center

Voice: +1-207-866-6701
1-800-457-1764 (Toll-free, U.S. and Canada only)

Fax: +1-207-626-7269
1-800-457-1764 (Toll-free, U.S. and Canada only)

Write: Globalware Solutions
200 Ward Hill Avenue
Haverhill, MA 01835 USA
Attention: Avaya Account Manager

Web: <http://www.avaya.com/support>

E-mail: totalware@gwsmail.com

Order: Document No. 07-300330, Issue 1.0
May 2005

For the most current versions of documentation, go to the Avaya support Web site:

<http://www.avaya.com/support>

COMPAS

This document is also available from the COMPAS database. The COMPAS ID for this document is 108704.

Avaya support

Avaya provides a telephone number for you to use to report problems or to ask questions about your contact center. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site:

<http://www.avaya.com/support>

Avaya Call Management System

Release 13

Database Items and Calculations

Contents

| | |
|--|-----------|
| Preface | 19 |
| Purpose | 20 |
| Intended users | 20 |
| Overview | 21 |
| Conventions and terminology | 22 |
| Reasons for reissue | 22 |
| Availability | 23 |
| Related documentation | 24 |
| Change description | 24 |
| Software documents | 24 |
| Administration documents | 25 |
| Hardware documents | 25 |
| Call Center documents | 25 |
| Avaya CMS upgrade documents | 26 |
| Base load upgrades | 26 |
| Platform upgrades and data migration | 26 |
| Avaya Call Management System Upgrade Express (CUE) | 26 |
| Documentation Web sites | 27 |
| Support | 28 |
| Introduction | 29 |
| Availability of database items | 29 |
| Database tables | 30 |
| Database table names | 30 |
| Real-time database table names | 31 |
| Historical database table names | 32 |
| Database item types | 34 |
| Historical and real-time data | 34 |
| Call-based versus interval-based data | 34 |
| Call-based data | 35 |
| Interval-based data | 35 |
| Call-based and interval-based data in reports | 35 |
| Database item information for report types | 36 |
| Split/skill database items | 36 |
| Real-time database items | 36 |
| Historical database items | 36 |
| Agent database items | 37 |

Contents

| | |
|---|-----------|
| Real-time database items | 37 |
| Historical database items | 37 |
| Trunk group database items | 37 |
| Real-time database items | 37 |
| Historical database items | 37 |
| Trunk database items | 38 |
| Real-time database items | 38 |
| Historical database items | 38 |
| Vector database items | 38 |
| Real-time database items | 38 |
| Historical database items | 38 |
| VDN database items | 39 |
| Real-time database items | 39 |
| Historical database items | 39 |
| Call work codes database items | 39 |
| Real-time database items | 39 |
| Historical database items | 39 |
| Agent login/logout database items | 39 |
| Agent trace database items | 40 |
| Current day configuration database items | 40 |
| Current day report database items | 40 |
| Forecast data | 40 |
| Call record database items | 40 |
| Exceptions historical database items | 41 |
| Exception type storage | 41 |
| Selecting exception types for reports | 41 |
| Terminology | 42 |
| Communication server capabilities that impact CMS | 49 |
| Example of table layout | 49 |
| Communication server cross-reference | 50 |
| Key to tables | 50 |
| Agent database items | 51 |
| Agent login/logout database items | 57 |
| Agent trace database items | 59 |
| Call record database items | 60 |
| Call work codes database items | 63 |
| Current day configuration database items | 64 |
| Current day report database items | 65 |
| Split/skill database items | 66 |
| Trunk database items | 75 |
| Trunk group database items | 77 |
| VDN database items | 79 |
| Vector database items | 83 |
| Communication server features and capabilities and their impact on CMS data | 86 |
| Abandoned calls | 87 |
| Adjunct-placed calls and adjunct-routed calls | 87 |
| Agent state tracking at login | 88 |
| Agents in multiple splits/skills | 88 |

| | |
|---|-----|
| Real-time reports | 88 |
| Average Speed of Answer (ASA). | 89 |
| Audio difficulty | 89 |
| Best Service Routing | 90 |
| Avaya Business Advocate | 90 |
| Call handling preference. | 91 |
| Call pickup | 91 |
| Conference tracking. | 92 |
| “converse” vector command | 92 |
| Direct agent calling | 92 |
| Direct agent data in reports | 92 |
| Communication server-specific capabilities | 92 |
| Expanded Agent Capabilities | 93 |
| Forced disconnect | 93 |
| Forced multiple call handling. | 94 |
| Go to vector command | 94 |
| Hold tracking | 94 |
| Location | 94 |
| Location ID for agents | 94 |
| Location ID for trunks | 95 |
| Look-ahead interflow calls (BSR and NCR) | 95 |
| Move agent while staffed | 95 |
| Multiple call handling | 96 |
| Multiple split/skill queuing | 96 |
| Multiple split/skill queueing example | 96 |
| Outbound Call Management (OCM) | 97 |
| Personal call tracking | 98 |
| Tracking of AUXIN and AUXOUT time | 98 |
| Tracking for “Route To” calls | 98 |
| Data tracking capabilities | 98 |
| Hold tracking for supervisor assist example | 99 |
| Phantom-abandon calls | 99 |
| Phantom-abandon call timer | 99 |
| PHANTOMABNS database item. | 99 |
| Phantom-abandon call timer not enabled | 100 |
| Phantom-abandon exceptions. | 100 |
| Redirect on No Answer | 100 |
| Reserve Agent Work Time Tracking | 100 |
| STAFFTIME | 101 |
| Reserve Agent Work Time Tracking database items | 102 |
| Real-time Split/Skill Status items | 102 |
| Historical Split/Skill database items | 103 |
| Non-reserve Split/Skill Database Items | 104 |
| Agent database items. | 105 |
| TI database items | 107 |
| Non-reserve Agent database items | 107 |
| Ringing | 108 |
| Skill state. | 108 |
| Timed ACW. | 108 |
| Time/duration tracking. | 108 |
| Transfer tracking | 108 |

Contents

| | |
|---|------------|
| Transferred and conferenced calls | 109 |
| Trunk No Answer Timeout | 109 |
| Universal Call Identifier | 109 |
| VDN active calls | 110 |
| Vector Disconnect Timer | 110 |
| Wait Answer Supervision Timer | 110 |
| Dictionary of CMS database items | 111 |
| Organization | 111 |
| Availability of database items | 111 |
| ABNCALLS | 112 |
| ABNCALLS1 through ABNCALLS10 | 114 |
| ABNQUECALLS | 114 |
| ABNRINGCALLS | 115 |
| ABNTIME | 116 |
| ABNVECCALLS | 116 |
| ACCEPTABLE | 117 |
| ACD (index) | 117 |
| ACD_RELEASE | 120 |
| ACDAUXOUTCALLS | 120 |
| ACDCALLS | 121 |
| ACDCALLS1 through ACDCALLS10 | 122 |
| ACDCALLS_R1 | 122 |
| ACDCALLS_R2 | 123 |
| ACDONHOLD (real-time) | 124 |
| ACDTIME | 124 |
| ACTIVECALLS (real-time) | 125 |
| ACWINCALLS | 126 |
| ACWINTIME | 126 |
| ACWOUTADJCALLS | 127 |
| ACWOUTCALLS | 127 |
| ACWOUTOFFCALLS | 128 |
| ACWOUTOFFTIME | 128 |
| ACWOUTTIME | 129 |
| ACWTIME | 129 |
| ADJATTEMPTS | 130 |
| ADJROUTED | 131 |
| ADJUNCTOUT (real-time) | 131 |
| AGINRING (real-time) | 132 |
| AGOCC | 132 |
| AGSTATE (real-time) | 132 |
| AGT_RELEASED | 133 |
| AGDURATION (real-time) | 133 |
| AGTIME (real-time) | 133 |

| | |
|--------------------------------------|-----|
| ALLINUSE (real-time) | 134 |
| ALLINUSETIME | 134 |
| ANI_SID | 134 |
| ANSCONNCALLS1 through ANSCONNCALLS10 | 135 |
| ANSHOLDTIME | 135 |
| ANSLOCID | 135 |
| ANSLOGIN | 136 |
| ANSREASON | 136 |
| ANSRINGTIME | 136 |
| ANSTIME | 137 |
| ASA (real-time) | 137 |
| ASSIST (real-time) | 138 |
| ASSIST_ACTV | 138 |
| ASSISTS | 139 |
| ATAGENT (real-time) | 139 |
| AUDIO | 139 |
| AUXINCALLS | 140 |
| AUXINTIME | 140 |
| AUXOUTADJCALLS | 141 |
| AUXOUTCALLS | 141 |
| AUXOUTOFFCALLS | 142 |
| AUXOUTOFFTIME | 142 |
| AUXOUTTIME | 143 |
| AUXREASON (real-time) | 143 |
| AVAILABLE (real-time) | 144 |
| AVGAGSERV | 144 |
| AVGSPEEDANS | 144 |
| AWORKMODE (real-time) | 145 |
| BACKUPCALLS | 145 |
| BH_ABNCALLS (daily only) | 147 |
| BH_ACDCALLS (daily only) | 147 |
| BH_ACDTIME (daily only) | 148 |
| BH_ALLINUSETIME (daily only) | 148 |
| BH_BUSYCALLS (daily only) | 148 |
| BH_DISCCALLS (daily only) | 149 |
| BH_INCALLS (daily only) | 149 |
| BH_INTIME (daily only) | 149 |
| BH_OABNCALLS (daily only) | 150 |
| BH_OACDCALLS (daily only) | 150 |
| BH_OTHERCALLS (daily only) | 150 |
| BH_OTHERCALLS (daily only) | 151 |
| BH_OUTCALLS (daily only) | 151 |
| BH_OUTTIME (daily only) | 152 |

Contents

| | |
|---------------------------|-----|
| BH_STARTTIME (daily only) | 152 |
| BH_VDNCALLS (daily only) | 153 |
| BLOCKAGE | 153 |
| BSRPLAN | 153 |
| BUSYCALLS | 154 |
| BUSYTIME | 155 |
| CALLER_HOLD | 155 |
| CALLID | 156 |
| CALLING_II | 156 |
| CALLING_LOGID (real-time) | 157 |
| CALLING_PTY | 157 |
| CALLSOFFERED | 157 |
| CHANGE | 158 |
| CHANGED (real-time) | 158 |
| CHPROF | 158 |
| COMPLETED | 159 |
| CONFERENCE | 159 |
| CONNECTCALLS | 160 |
| CONNECTTIME | 160 |
| CONNTALKTIME | 160 |
| CONSULTTIME | 161 |
| CWC (index) | 161 |
| CWC1 through CWC5 | 161 |
| DA_ABNCALLS | 162 |
| DA_ABNTIME | 162 |
| DA_ACDCALLS | 162 |
| DA_ACDTIME | 163 |
| DA_ACWINCALLS | 163 |
| DA_ACWINTIME | 163 |
| DA_ACWOADJCALLS | 164 |
| DA_ACWOCALLS | 164 |
| DA_ACWOFFFCALLS | 165 |
| DA_ACWOFFFTIME | 165 |
| DA_ACWOTIME | 165 |
| DA_ACWTIME | 166 |
| DA_ANSTIME | 166 |
| DA_INACW (real-time) | 167 |
| DA_INQUEUE (real-time) | 167 |
| DA_INRING (real-time) | 167 |
| DA_OLDESTCALL (real-time) | 168 |
| DA_ONACD (real-time) | 168 |
| DA_OTHERCALLS | 169 |
| DA_OTHERTIME | 169 |

| | |
|-------------------------------------|-----|
| DA_QUEUED | 169 |
| DA_RELEASE | 170 |
| DA_SKILL (real-time) | 170 |
| DACALLS_FIRST (real-time) | 170 |
| DEFLECTCALLS | 171 |
| DEQUECALLS | 171 |
| DEQUETIME | 172 |
| DESTINATION (real-time) | 172 |
| DIALED_NUM | 172 |
| DIGITS_DIALED | 173 |
| DIRECTION (real-time) | 173 |
| DISCCALLS | 174 |
| DISCTIME | 175 |
| DISPIVECTOR | 175 |
| DISPOSITION | 176 |
| DISPPRIORITY | 177 |
| DISPSKLEVEL | 178 |
| DISPSPLIT | 178 |
| DISPTIME | 178 |
| DISPVDN | 179 |
| DURATION (real-time) | 179 |
| EQLOC | 180 |
| EVENT1 through EVENT9 | 181 |
| EVENT_TIME | 181 |
| EWTHIGH (real-time) | 182 |
| EWTLLOW (real-time) | 182 |
| EWTMEDIUM (real-time) | 183 |
| EWTTOP (real-time) | 183 |
| EXT_CALL_ORIG | 183 |
| EXTENSION | 184 |
| EXTN | 184 |
| EXTYPE | 185 |
| FAGINRING (real-time) | 189 |
| FAVAILABLE (real-time) | 190 |
| FCALLS | 190 |
| FINACW (real-time) | 190 |
| FINAUX (real-time) | 191 |
| FIRSTVDN | 191 |
| FIRSTIVECTOR | 191 |
| FMETHOD | 192 |
| FONACD (real-time) | 192 |
| FOTHER (real-time) | 192 |
| FSTAFFED (real-time) | 193 |

Contents

| | |
|---|-----|
| GNAGINRING (real-time) | 193 |
| GNAVAILABLE (real-time) | 193 |
| GNINACW (real-time) | 194 |
| GNINAUX (real-time) | 194 |
| GNINAUX0 (real-time) | 194 |
| GNINAUX1 through GNINAUX9 (real-time) | 195 |
| GNINAUX10 through GNINAUX99 (real-time) | 195 |
| GNONACD (real-time) | 196 |
| GNONACDAUXOUT (real-time). | 196 |
| GNONACDOUT (real-time) | 196 |
| GNONACWIN (real-time) | 197 |
| GNONACWOUT (real-time). | 197 |
| GNONAUXIN (real-time) | 198 |
| GNONAUXOUT (real-time) | 198 |
| GNDA_INACW (real-time) | 198 |
| GNDA_ONACD (real-time) | 199 |
| GNOTHER (real-time) | 199 |
| GNSKILL (real-time) | 200 |
| GNSTAFFED (real-time) | 200 |
| GOTOCALLS | 200 |
| GOTOTIME | 201 |
| HDATE1 through HDATE4 | 201 |
| HELD | 201 |
| HIGHCALLS | 202 |
| HOLDABN | 202 |
| HOLDABNCALLS | 202 |
| HOLDACDCALLS | 203 |
| HOLDACDTIME | 203 |
| HOLDCALLS | 204 |
| HOLDTIME | 204 |
| I_ACDAUXINTIME | 205 |
| I_ACDAUX_OUTTIME | 206 |
| I_ACDOTHERTIME | 206 |
| I_ACDTIME | 207 |
| I_ACDTIME_R1 | 207 |
| I_ACDTIME_R2 | 208 |
| I_ACWINTIME | 208 |
| I_ACWOUTTIME | 209 |
| I_ACWTIME | 210 |
| I_ACWTIME_R1 | 210 |
| I_ACWTIME_R2 | 211 |
| I_ARRIVED | 211 |
| I_AUTORESERVETIME | 211 |

| | |
|---|-----|
| I_AUXINTIME | 212 |
| I_AUXOUTTIME | 212 |
| I_AUXSTBYTIME | 213 |
| I_AUXSTBYTIME_R1 | 213 |
| I_AUXSTBYTIME_R2 | 214 |
| I_AUXTIME | 214 |
| I_AUXTIME_R1 | 215 |
| I_AUXTIME_R2 | 215 |
| I_AUXTIME0 | 216 |
| I_AUXTIME1 through I_AUXTIME9 | 216 |
| I_AUXTIME10 through I_AUXTIME99 | 216 |
| I_AVAILTIME | 217 |
| I_BEHINDTIME | 217 |
| I_DA_ACDTIME | 217 |
| I_DA_ACWTIME | 218 |
| I_INOCC | 218 |
| I_NORMTIME | 219 |
| I_OL1TIME | 219 |
| I_OL2TIME | 220 |
| I_OTHERSTBYTIME | 220 |
| I_OTHERSTBYTIME_R1 | 221 |
| I_OTHERSTBYTIME_R2 | 221 |
| I_OTHERTIME | 222 |
| I_OTHERTIME_R1 | 223 |
| I_OTHERTIME_R2 | 223 |
| I_OUTOCC | 224 |
| I_RINGTIME | 224 |
| I_RINGTIME_R1 | 225 |
| I_RINGTIME_R2 | 225 |
| I_STAFFTIME | 226 |
| I_TAUXTIME | 226 |
| I_TAVAILTIME | 227 |
| I_TOTHERTIME | 227 |
| II_DIGITS | 227 |
| ILN | 228 |
| INACW (real-time) | 228 |
| INAUX (real-time) | 228 |
| INAUX0 (real-time) | 229 |
| INAUX1 through INAUX9 (real-time) | 229 |
| INAUX10 through INAUX99 (real-time) | 229 |
| INBOUND (real-time) | 230 |
| INCALLS | 230 |
| INCOMPLETE | 231 |

Contents

| | |
|---|-----|
| INFLAG | 233 |
| INFLOWCALLS | 233 |
| INPROGRESS (real-time) | 234 |
| INQUEUE (real-time) | 235 |
| INRING (real-time) | 235 |
| INTERFLOWCALLS | 236 |
| INTIME | 236 |
| INTRVL | 238 |
| INVECTOR (real-time) | 239 |
| ITN | 239 |
| KEYBD_DIALED | 240 |
| LASTCWC | 240 |
| LASTDIGITS | 240 |
| LASTOBSERVER | 241 |
| LEVEL (real-time) | 241 |
| LOC_ID | 241 |
| LOGID | 242 |
| LOGIN | 243 |
| LOGONSKILL (real-time) | 244 |
| LOGONSKILL2 through LOGONSKILL20 (real-time) | 244 |
| LOGONSKILL21 through LOGONSKILL60 (real-time) | 245 |
| LOGONSTART (real-time) | 245 |
| LOGOUT | 245 |
| LOGOUT_DATE | 246 |
| LOGOUTREASON | 246 |
| LOOKATTEMPTS | 246 |
| LOOKFLOWCALLS | 247 |
| LOWCALLS | 248 |
| MALICIOUS (real-time) | 248 |
| MAXINQUEUE | 249 |
| MAXOCWTIME | 249 |
| MAXSTAFFED | 249 |
| MAXTOP | 250 |
| MAX_TOT_PERCENTS | 250 |
| MAXWAITING | 250 |
| MBUSY (real-time) | 251 |
| MBUSYTIME | 251 |
| MCT | 251 |
| MEDCALLS | 252 |
| MOVEPENDING (real-time) | 252 |
| NETDISCCALLS | 252 |
| NETINCALLS | 253 |
| NETINTIME | 253 |

| | |
|------------------------------------|-----|
| NETPOLLS | 253 |
| NOANSREDIR | 254 |
| NUMAGREQ | 255 |
| NUMINUSE (real-time) | 255 |
| NUMTGS (real-time) | 255 |
| NUMVDNS (real-time) | 256 |
| O_ABNCALLS | 256 |
| O_ACDCALLS | 257 |
| O_ACDTIME | 257 |
| O_ACWTIME | 258 |
| O_OTHERCALLS | 258 |
| OBSERVINGCALL | 259 |
| OBSLOCID | 259 |
| OLDESTCALL (real-time) | 260 |
| OLDEST_LOGON (real-time) | 260 |
| ONACD (real-time) | 260 |
| ONACDAUXOUT (real-time) | 261 |
| ONACDOUT (real-time) | 261 |
| ONACWIN (real-time) | 261 |
| ONACWOUT (real-time) | 262 |
| ON AUXIN (real-time) | 262 |
| ON AUXOUT (real-time) | 262 |
| ONHOLD (real-time) | 263 |
| ORIGHOLDTIME | 263 |
| ORIGIN (real-time) | 263 |
| ORIGLOCID | 264 |
| ORIGLOGIN | 264 |
| ORIGREASON | 264 |
| OTHER (real-time) | 265 |
| OTHERCALLS | 265 |
| OTHERTIME | 266 |
| OUTBOUND (real-time) | 267 |
| OUTCALLS | 267 |
| OUTFLAG | 268 |
| OUTFLOWCALLS | 268 |
| OUTFLOWTIME | 269 |
| OUTTIME | 270 |
| PENDINGSPILT (real-time) | 271 |
| PERCENT (real-time) | 271 |
| PERIOD1 through PERIOD9 | 271 |
| PERIODCHG | 272 |
| PHANTOMABNS | 272 |
| POSITION (real-time) | 273 |

Contents

| | |
|---|-----|
| POSITIONS (real-time) | 273 |
| PREFERENCE (real-time) | 274 |
| PRIORITY (real-time) | 274 |
| PRIORITY2 and PRIORITY3 (real-time) | 275 |
| QUECOUNT (real-time) | 275 |
| QUETYPE (real-time) | 276 |
| QUETYPE2 and QUETYPE3 (real-time) | 276 |
| R1AGINRING (real-time) | 276 |
| R1AVAILABLE (real-time) | 277 |
| R1INACW (real-time) | 277 |
| R1IN_AUX (real-time) | 277 |
| R1IN_AUXSTBY (real-time) | 278 |
| R1ONACD (real-time) | 278 |
| R1OTHER (real-time) | 278 |
| R1OTHERSTBY (real-time) | 279 |
| R1STAFFED (real-time) | 279 |
| R2AGINRING (real-time) | 280 |
| R2AVAILABLE (real-time) | 280 |
| R2INACW (real-time) | 280 |
| R2IN_AUX (real-time) | 281 |
| R2IN_AUXSTBY (real-time) | 281 |
| R2ONACD (real-time) | 281 |
| R2OTHER (real-time) | 282 |
| R2OTHERSTBY (real-time) | 282 |
| R2STAFFED (real-time) | 283 |
| RAGOCC | 283 |
| RAVGSPEED-ANS | 283 |
| REASON | 284 |
| REASON_CODE | 284 |
| RECONNECT | 285 |
| RETURNCALLS | 285 |
| RINGCALLS | 285 |
| RINGTIME | 286 |
| ROLE (real-time) | 287 |
| ROW_DATE (index) | 287 |
| ROW_TIME | 290 |
| RSERVLEVELP | 291 |
| RSV_LEVEL | 291 |
| SEGMENT | 291 |
| SEGSTART | 292 |
| SEGSTOP | 292 |
| SERVICELEVEL | 292 |
| SERVLEVELP | 293 |

| | |
|---|-----|
| SERVLEVELT | 293 |
| SETUPTIME | 293 |
| SHORTCALLS | 294 |
| SKILL1 through SKILL3. | 294 |
| SKILLACWTIME1 through SKILLACWTIME3 | 295 |
| SKILLCALLS1 through SKILLCALLS3. | 295 |
| SKILLTIME1 through SKILLTIME3. | 295 |
| SKILLTYPE | 296 |
| SKILLTYPE2 through SKILLTYPE4 | 296 |
| SKLEVEL | 297 |
| SKLEVEL2 through SKLEVEL20 | 297 |
| SKLEVEL21 through SKLEVEL60 (real-time) | 298 |
| SKPERCENT | 298 |
| SKPERCENT2 through SKPERCENT20. | 299 |
| SKPERCENT21 through SKPERCENT60 (real-time) | 299 |
| SKSTATE (real-time) | 300 |
| SLVLABNS | 300 |
| SLVLOUTFLOWS | 300 |
| SPLIT (index) | 301 |
| SPLIT1 | 303 |
| SPLIT2 and SPLIT3 | 303 |
| STAFFED (real-time) | 304 |
| STARTED (real-time) | 304 |
| STARTTIME (interval) | 304 |
| SVCLEVELCHG | 306 |
| TAGINRING (real-time) | 306 |
| TALKTIME | 307 |
| TARGETABNS | 307 |
| TARGETACDCALLS | 307 |
| TARGETOUTFLOWS. | 307 |
| TARGETPCTCHG | 308 |
| TARGETPERCENT | 308 |
| TARGETSECCHG | 308 |
| TARGETSECONDS | 308 |
| TAVAILABLE (real-time) | 309 |
| TDA_INACW (real-time) | 309 |
| TDA_ONACD (real-time) | 309 |
| THRESHOLD | 310 |
| TI_AUXTIME. | 311 |
| TI_AUXTIME0 | 311 |
| TI_AUXTIME1 through TI_AUXTIME9. | 312 |
| TI_AUXTIME10 through TI_AUXTIME99 | 312 |
| TI_AVAITIME | 313 |

Contents

| | |
|---|-----|
| TI_OTHERTIME | 313 |
| TI_STAFFTIME | 314 |
| TIME | 314 |
| TINACW (real-time) | 315 |
| TINAUX (real-time) | 316 |
| TINAUX0 (real-time) | 316 |
| TINAUX1 through TINAUX9 (real-time) | 316 |
| TINAUX10 through TINAUX99 (real-time) | 317 |
| TKGRP | 317 |
| TKSTATE (real-time) | 318 |
| TONACD (real-time) | 318 |
| TONACDAUXOUT (real-time) | 319 |
| TONACDOUT (real-time) | 319 |
| TONACWIN (real-time) | 319 |
| TONACWOUT (real-time) | 320 |
| TONAUXIN (real-time) | 320 |
| TONAUXOUT (real-time) | 320 |
| TOPCALLS | 321 |
| TOPSKILL (real-time) | 321 |
| TOT_PERCENTS (real-time) | 321 |
| TOTHER (real-time) | 322 |
| TRANSFERRED | 322 |
| TRENDBASE | 323 |
| TRUNKS | 324 |
| TSTAFFED (real-time) | 324 |
| TYPE (real-time) | 324 |
| UCID | 325 |
| USE_SVC_OBJ (real-time) | 325 |
| VDISCCALLS | 325 |
| VDN | 326 |
| VECTOR | 327 |
| WMODE_SEQ | 328 |
| WORKCODE | 328 |
| WORKMODE (real-time) | 328 |
| WORKSKILL (real-time) | 329 |
| WORKSKLEVEL (real-time) | 329 |
| WORKSPLIT (real-time) | 330 |
| WORKSPLIT2 and WORKSPLIT3 (real-time) | 330 |
| WORKSPLIT4 through WORKSPLIT20 (real-time) | 331 |
| WORKSPLIT21 through WORKSPLIT60 (real-time) | 331 |
| WT1 through WT4 | 331 |

| | |
|---|------------|
| Definitions of CMS calculations | 333 |
| Example standard dictionary calculations table | 333 |
| Search values | 333 |
| Agent state and row search values cross-reference tables | 334 |
| Call disposition and row search values cross-reference tables | 337 |
| Calculations | 338 |
| Standard CMS Dictionary calculations | 338 |
| Reports-specific calculations | 349 |
| Index | 351 |



Preface

Avaya Call Management System (CMS) is an application for businesses and organizations that use Avaya communication servers to process large volumes of telephone calls using the Automatic Call Distribution (ACD) feature. Avaya CMS supports solutions for routing and agent selection, multi-site contact centers, remote agents, reporting, interfaces to other systems, workforce management, desktop applications, system recovery, and quality monitoring.

Avaya CMS is part of the Operational Effectiveness solution of the Avaya Customer Interaction Suite.

This section includes the following topics:

- [Purpose](#) on page 20
- [Intended users](#) on page 20
- [Overview](#) on page 21
- [Conventions and terminology](#) on page 22
- [Reasons for reissue](#) on page 22
- [Availability](#) on page 23
- [Related documentation](#) on page 24
- [Support](#) on page 28

Purpose

The purpose of *Database Items and Calculations* is to provide CMS users with the knowledge that is necessary to understand, in detail, how the numbers displayed on CMS and Avaya CMS Supervisor (Supervisor) reports are calculated within the CMS database.

Use this document as a reference tool. It is the dictionary to the CMS database and gives you the definition to each database item and calculation that CMS tracks.

The two most common uses of this book are in conjunction with the Reports book and to help you define custom or designer reports. The Reports book lists which database items and calculations are used in each CMS report. You can use *Database Items and Calculations* to understand exactly how CMS tracks and stores each number that you see on the reports.

Intended users

This document is for CMS users who need to understand how CMS calculates numbers for reports. It is also written to help users decide which database items and calculations to use in custom reports.

Overview

Database Items and Calculations defines the Avaya Call Management System (CMS) database items and calculations that are used for standard and custom reports. It also describes communication server feature interactions that affect how the CMS tracks data.

This document includes the following sections:

- [Introduction](#) on page 29 - This section includes information on the different database tables that comprise the CMS database, including the names of all database tables and information that is specific to each type (split/skill, agent, agent login/logout and so on) of table. It also includes definitions of the different database item types (cumulative, administrative, status, and so on) and a list of terms that are used in the database item definitions.
- [Communication server capabilities that impact CMS](#) on page 49 - This section provides a set of tables that cross-reference which CMS database items are available on each of the Avaya communication servers. It also provides information on how communication server features and capabilities are tracked by CMS or can affect the data that CMS produces for reports.
- [Dictionary of CMS database items](#) on page 111 - This section provides a definition of each database item that resides in the CMS database.
- [Definitions of CMS calculations](#) on page 333 - This section provides a definition of each of the standard CMS calculations that are used in reports or are available for use in custom reports. It also provides row search information for specific data types.

Conventions and terminology

If you see any of the following safety labels in this document, take careful note of the information presented.



CAUTION:

Caution statements call attention to situations that can result in harm to software, loss of data, or an interruption in service.



WARNING:

Warning statements call attention to situations that can result in harm to hardware or equipment.



DANGER:

Danger statements call attention to situations that can result in harm to personnel.



SECURITY ALERT:

Security alert statements call attention to situations that can increase the potential for unauthorized use of a telecommunications system.

The following conventions are used throughout this document:

- DATABASE ITEM NAMES are in all capital letters.
- *Book titles* are italicized.
- “Chapter names” are surrounded by quotes.
- `File names` are in monospaced type.
- “Vector commands” are surrounded by quotes.

Reasons for reissue

This is the first issue of this document.

Availability

Copies of this document are available from one or both of the following sources:

Note:

Although there is no charge to download documents through the Avaya Web site, documents ordered from the Avaya Publications Center must be purchased.

- The Avaya online support Web site, <http://www.avayadocs.com>
- The Avaya Publications Center, which you can contact by:

Voice:

+1-207-866-6701

+1-800-457-1764 (Toll-free, U.S. and Canada only)

Fax:

+1-207-626-7269

+1-800-457-1764 (Toll-free, U.S. and Canada only)

Mail:

GlobalWare Solutions
200 Ward Hill Avenue
Haverhill, MA 01835 USA
Attention: Avaya Account Manager

E-mail:

totalware@gwsmail.com

Related documentation

You might find the following Avaya CMS documentation useful. This section includes the following topics:

- [Change description](#) on page 24
- [Software documents](#) on page 24
- [Administration documents](#) on page 25
- [Hardware documents](#) on page 25
- [Call Center documents](#) on page 25
- [Avaya CMS upgrade documents](#) on page 26
- [Documentation Web sites](#) on page 27

Change description

For information about the changes made in Avaya CMS R13, see:

- *Avaya Call Center 3.0 and Call Management System (CMS) Release 13 Change Description*, 07-300304

Software documents

For more information about Avaya CMS software, see:

- *Avaya Call Management System Release 13 Software Installation, Maintenance, and Troubleshooting Guide*, 07-300340
- *Avaya CMS Open Database Connectivity Version 4.2*, 585-780-701
- *Avaya Call Management System Release 13 LAN Backup User Guide*, 07-300338
- *Avaya Call Management System Release 13 External Call History Interface*, 07-300332
- *Avaya CMS Custom Reports*, 585-215-822
- *Avaya CMS Forecast User Guide*, 585-215-825
- *Avaya Visual Vectors Release 13 Installation and Getting Started*, 07-300353
- *Avaya Visual Vectors Release 13 User Guide*, 07-300354
- *Avaya Call Management System (CMS) Supervisor Release 13 Report Designer*, 07-300335

Administration documents

For more information about Avaya CMS administration, see:

- *Avaya Call Management System Release 13 Administration*, 07-300331
- *Avaya Call Management System (CMS) Release 13 Database Items and Calculations*, 07-300330
- *Avaya Call Management System Supervisor Release 13 Reports*, 07-300334
- *Avaya Call Management System (CMS) Supervisor Release 13 Installation and Getting Started*, 07-300333
- *Avaya Call Management System High Availability User Guide*, 07-300066
- *Avaya Call Management System High Availability Connectivity, Upgrade and Administration*, 07-300065

Hardware documents

For more information about Avaya CMS hardware, see:

- *Avaya Call Management System Sun Fire V880/V890 Computer Hardware Installation, Maintenance, and Troubleshooting*, 585-215-116
- *Avaya Call Management System Sun Blade 100/150 Workstation Hardware Installation, Maintenance, and Troubleshooting*, 585-310-783
- *Avaya Call Management System Terminals, Printers, and Modems*, 585-215-874

Call Center documents

For more information about Avaya Call Center documents, see:

- *Avaya Communication Manager Call Center Software Basic Call Management System (BCMS) Operations*, 07-300061
- *Avaya Call Management System Switch Connections, Administration, and Troubleshooting*, 585-215-876
- *Avaya Communication Manager Call Center Software Call Vectoring and Expert Agent Selection (EAS) Guide*, 07-300303
- *Avaya Communication Manager Call Center Software Automatic Call Distribution (ACD) Guide*, 07-300301
- *Avaya Business Advocate User Guide*, 07-300336

Avaya CMS upgrade documents

There are several upgrade paths supported with Avaya CMS. There is a document designed to support each upgrade.

This section includes the following topics:

- [Base load upgrades](#) on page 26
- [Platform upgrades and data migration](#) on page 26
- [Avaya Call Management System Upgrade Express \(CUE\)](#) on page 26

Base load upgrades

Use a base load upgrade when upgrading CMS to the latest load of the same version (for example, r13ak.g to r13al.k). A specific set of instructions is written for the upgrade. The instructions are shipped to the customer site with the CMS software CD-ROM as part of a Product Correction Notice (PCN).

For more information about base load upgrades, see:

- *Avaya Call Management System Release 13 Base Load Upgrade*

Platform upgrades and data migration

Use a platform upgrade when upgrading to a new hardware platform (for example, upgrading from a SPARCserver 5 to a Sun Blade 150). The new hardware platform is shipped from the Avaya factory with the latest CMS load. Therefore, as part of the upgrade you will have the latest CMS load (for example, R3V9 to R13).

For more information about platform upgrades and data migration, see:

- *Avaya Call Management System Release 13 Platform Upgrade and Data Migration*, 07-300339

Avaya Call Management System Upgrade Express (CUE)

Use CUE when CMS is being upgraded from an earlier version (for example, R3V9) to the latest version (for example, R13).

A specific set of upgrade instructions is written for the upgrade. These instructions are included on the CUE software CD-ROM that is shipped to the customer site with the CUE kit.

For information about customer requirements for CUE upgrades, see:

- *Avaya Call Management System Release 13 CMS Upgrade Express (CUE) Customer Requirements*, 700356744

For information about CUE upgrade procedures, see:

- *Avaya Call Management System Release 13 Sun Blade 100/150 Workstation Mirrored and Nonmirrored Systems CMS Upgrade Express (CUE)*, 07-300481
- *Avaya Call Management System Release 13 Sun Fire V880/V890 Computer CMS Upgrade Express (CUE)*, 07-300344

Documentation Web sites

For Avaya product documentation, go to <http://www.avayadocs.com>. Additional information about new software or hardware updates will be contained in future issues of this book. New issues of this book will be placed on the Web site when available.

Use the following Web sites to view related support documentation:

- Information about Avaya products and service
<http://www.avaya.com>
- Sun hardware documentation
<http://docs.sun.com>
- Informix documentation
<http://www.informix.com>
- Tivoli Storage Manager documentation
<http://www.tivoli.com>

Support

Contacting Avaya technical support

Avaya provides support telephone numbers for you to report problems or ask questions about your product.

For United States support:

1- 800- 242-2121

For international support:

See the [1-800 Support Directory](#) listings on the Avaya Web site.

Escalating a technical support issue

Avaya Global Services Escalation Management provides the means to escalate urgent service issues. For more information, see the [Escalation Management](#) listings on the Avaya Web site.

■ ■ ■ ■ ■ ■

Introduction

Introduction gives you foundational information about how the Avaya Call Management System (CMS) database is set up and what the different types of data are.

The topics covered in *Introduction* are as follows:

- [Availability of database items](#) on page 29
- [Database tables](#) on page 30
- [Database item types](#) on page 34
- [Database item information for report types](#) on page 36
- [Terminology](#) on page 42

Availability of database items

Unless noted in the definition of a database item, the database items defined in this document are available on all Avaya communication servers, including:

- DEFINITY Release 8
- DEFINITY Release 9
- Avaya Call Processing software Release 9.5 & Release 10
- Communication Manager 1.1 - 3.0

Database tables

The CMS database is comprised of several database tables. The categories of the database tables include the following:

- Agent
- Agent Login/Logout
- Agent Trace
- Call Record
- Call Work Codes
- Current Day Configuration (forecasting)
- Current Day Report (forecasting)
- Exceptions
- Split/Skill
- Trunk Group
- Trunk
- Vector
- VDN

Note:

The database item tables from which data is retrieved most frequently are the agent, split/skill, trunk group, trunk, vector, and VDN tables.

Database table names

To select data for custom reports, you must use the names that are listed in the tables in this section. For definitions of the individual database items that reside in each table, see [Dictionary of CMS database items](#) on page 111.

Real-time database table names

The following table lists the real-time database tables and the data that are stored in them:

| Name | Data stored | Interval |
|---------|----------------------|----------|
| csplit | split/skill | current |
| psplit | split/skill | previous |
| cagent | agent | current |
| pagent | agent | previous |
| ctkgrp | trunk group | current |
| ptkgrp | trunk group | previous |
| ctrunk | trunk | current |
| ptrunk | trunk | previous |
| cvector | vector | current |
| pvector | vector | previous |
| cvdn | VDN | current |
| pvdn | VDN | previous |
| ccwc | Call Work Code (CWC) | current |
| pcwc | CWC | previous |

Historical database table names

The following table lists historical database tables and the data that are stored in them:

| Name | Data stored | Interval |
|---------|-------------|-----------|
| hsplit | split/skill | intrahour |
| dsplit | split/skill | day |
| wsplit | split/skill | week |
| msplit | split/skill | month |
| hagent | agent | intrahour |
| dagent | agent | day |
| wagent | agent | week |
| magent | agent | month |
| htkgrp | trunk group | intrahour |
| dtkgrp | trunk group | day |
| wtkgrp | trunk group | week |
| mtkgrp | trunk group | month |
| htrunk | trunk | intrahour |
| dtrunk | trunk | day |
| wtrunk | trunk | week |
| mtrunk | trunk | month |
| hvector | vector | intrahour |
| dvector | vector | day |
| wvector | vector | week |
| mvector | vector | month |
| hvdn | VDN | intrahour |
| dvdn | VDN | day |
| wvdn | VDN | week |
| mvdn | VDN | month |
| hcwc | CWC | intrahour |

| Name | Data stored | Interval |
|-------------|--|-----------------|
| dcwc | CWC | day |
| wcwc | CWC | week |
| mcwc | CWC | month |
| call_rec | Call record | not applicable |
| agex | Agent exceptions | not applicable |
| spex | Split exceptions | not applicable |
| tgex | Trunk group exceptions | not applicable |
| vecex | Vector exceptions | not applicable |
| vdnex | VDN exceptions | not applicable |
| linkex | Link down exceptions | not applicable |
| mctex | Malicious call trace exceptions | not applicable |
| f_cday | Forecast current day configuration data by split/skill | not applicable |
| f_cdayrep | Current day forecast data by split/skill | not applicable |
| haglog | Agent login and logout information | not applicable |
| ag_actv | Agent activity trace data | not applicable |

Database item types

Each database item contains one of the following types of data:

Administrative data - Administered on the communication server or on CMS. For example, the database item INTRVL in the split/skill real-time table contains the number of minutes in the intrahour interval (15, 30, 60) currently assigned to the specified split/skill on CMS.

Busy Hour data - Data that is only meaningful for the busy hour.

Cumulative data - Accumulates throughout the collection interval. Most real-time database items contain cumulative data.

Maximum Interval Value data - The maximum reached for any value in the specified interval.

Row Identifier data - Shows data that is common to all tables, such as time, date, and split in the split/skill tables.

Special Table data - Shows data that belongs only to a specific table, such as the Historical Agent Login/Logout table or Current Day Forecast table.

Status data - Shows the current status (a snapshot of a particular ACD element). For example, the database item INQUEUE in the split/skill real-time table contains the number of split/skill calls currently waiting in queue.

The type of data that each database item contains is specified at the end of the database item definition in [Dictionary of CMS database items](#) on page 111.

Historical and real-time data

Cumulative, Administrative, Maximum Value, Row Identifier and Busy Hour data items apply to historical and real-time database items. **Status** items apply only to real-time database items.

Call-based versus interval-based data

In addition to the types of data described above, items in the CMS database can be either call-based or interval-based. Most CMS database items are call-based.

Call-based data

Call-based data is committed to the database after a call completes. Therefore, if a call starts and ends in different collection intervals, all of the data is recorded in the interval in which the call and any after call work is completed.

Interval-based data

Interval-based data represents the amount of time during a collection interval spent doing a particular activity. Interval-based items are updated throughout the collection interval and timing is restarted at the end of the interval. Most interval-based items start with I_ or TI_. The database items ALLINUSETIME (trunk-group tables) and MBUSYTIME (trunk and trunk-group tables) are also interval-based.

Interval-based items should be used only to calculate percentages such as the percentage of time staffed or in AUX work. Interval-based items should not be used, for example, to calculate average talk time; use call-based items for this type of calculation.

Call-based and interval-based data in reports

Because call-based and interval-based items may not track the same events, a calculation should use only one type of item and comparisons of call-based calculations and interval-based calculations may not be relevant or meaningful. For example, the call-based ACD time and interval-based ACD time for an agent will not be equal if the agent handled one or more ACD calls that crossed over interval boundaries.

Note:

Report data may not add up if the report has a combination of call-based and interval-based items.

Database item information for report types

This section includes the following topics:

- [Split/skill database items](#) on page 36
- [Agent database items](#) on page 37
- [Trunk group database items](#) on page 37
- [Trunk database items](#) on page 38
- [Vector database items](#) on page 38
- [VDN database items](#) on page 39
- [Call work codes database items](#) on page 39
- [Agent login/logout database items](#) on page 39
- [Agent trace database items](#) on page 40
- [Current day configuration database items](#) on page 40
- [Current day report database items](#) on page 40
- [Call record database items](#) on page 40
- [Exceptions historical database items](#) on page 41

Split/skill database items

Split/skill database item descriptions apply to real-time and historical items.

Real-time database items

Real-Time split/skill database items apply to the Current Interval Split/Skill (csplit) and Previous Interval Split/Skill (psplit) tables. The real-time indexes are ACD and SPLIT.

Historical database items

Historical split/skill database items apply to the Intrahour Split/Skill (hsplit), Daily Split/Skill (dsplit), Weekly Split/Skill (wsplit), and Monthly Split/Skill (msplit) tables, except as noted. Historical indexes are SPLIT and ROW_DATE.

Agent database items

Agent database item descriptions apply to real-time and historical items.

Real-time database items

Real-time agent database items apply to the Current Interval Agent (cagent) and Previous Interval Agent (pagent) tables. The real-time indexes are ACD, LOGID, POSITION, and SPLIT.

Historical database items

Historical agent database items apply to the Intrahour Agent (hagent), Daily Agent (dagent), Weekly Agent (wagent), and Monthly Agent (magent) tables, except as noted here. The historical indexes are LOGID, SPLIT, and ROW_DATE.

Trunk group database items

Trunk group database item descriptions apply to real-time and historical items.

Real-time database items

Real-time trunk group database items apply to the Current Interval Trunk Group (ctkgrp) and Previous Interval Trunk Group (ptkgrp) tables. The real-time indexes are ACD and TKGRP.

Historical database items

Historical trunk group database items apply to the Intrahour Trunk Group (htkgrp), Daily Trunk Group (dtkgrp), Weekly Trunk Group (wtkgrp), and Monthly Trunk Group (mtkgrp) tables, except as noted. The historical indexes are ROW_DATE and TKGRP.

Trunk database items

Trunk database item descriptions apply to real-time and historical items.

Real-time database items

Real-time trunk database items apply to the Current Interval Trunk (ctrunk) and Previous Interval Agent (ptrunk) tables. The real-time indexes are ACD, ITN, EQLOC, and TKGRP.

Historical database items

Historical trunk database items apply to the Intrahour Trunk (htrunk), Daily Trunk (dtrunk), Weekly Trunk Group (wtrunk), and Monthly Trunk (mtrunk) tables, except as noted. The historical indexes are EQLOC, ROW_DATE and TKGRP.

Vector database items

Vector database item descriptions apply to real-time and historical items. Vector database items are available only if you purchased the Vectoring feature and it has been authorized for use.

Real-time database items

Real-time vector database items apply to the Current Interval Vector (cvector) and Previous Interval Vector (pvector) tables. The real-time indexes are ACD and VECTOR.

Historical database items

Historical vector database items apply to the Intrahour Vector (hvector), Daily Vector (dvector), Weekly Vector (wvector), and Monthly Vector (mvector) tables. The historical indexes are ROW_DATE and VECTOR.

VDN database items

The VDN database item descriptions apply to real-time and historical items. VDN database items are available only if you purchased the vectoring feature and it is authorized for use.

Real-time database items

Real-time VDN database items apply to the Current Interval VDN (cvdn) and Previous Interval VDN (pvdn) tables. The real-time indexes are ACD, VDN, and VECTOR.

Historical database items

Historical VDN database items apply to the Intrahour VDN (hvdn), Daily VDN (dvdn), Weekly VDN (wvdn), and Monthly VDN (mvdn) tables, except as noted. The historical indexes are ROW_DATE and VDN.

Call work codes database items

Call work codes database item descriptions apply to real-time and historical items.

Real-time database items

Real-time call work codes apply to the Current Interval CWC (ccwc) and Previous Interval (pcwc) tables. The real-time indexes are ACD and CWC.

Historical database items

Historical call work codes database items apply to the Intrahour Call Work Codes (hcwc), Daily Call Work Codes (dcwc), Weekly Call Work Codes (wcwc), and Monthly Call Work Codes (mcwc) tables, except as noted. The indexes are ROW_DATE and CWC.

Agent login/logout database items

Agent login/logout database item descriptions apply to historical items that are specific to the Agent Login/Logout (haglog) table. The indexes are SPLIT and ROW_DATE.

Agent trace database items

Agent trace database item descriptions apply to historical items that are specific to the Agent Trace (ag_actv) table. The indexes are LOGID and ROW_DATE.

Current day configuration database items

Current day configuration database item descriptions apply to historical items that are used specifically to collect values that are entered in the Forecast: Current Day window. They apply to the Current Day (f_cday) table. The indexes are ACD, ROW_DATE and SPLIT.

Current day report database items

Current day report database item descriptions apply to historical items that are used specifically to collect values that are entered in the Forecast: Current Day window. They apply to the Current Day Report (f_cdayrep) table. The indexes are ACD, ROW_DATE and SPLIT.

Forecast data

Forecast data for a split/skill is automatically generated when the Forecast Manager runs if you have also completed a Current Day Configuration for the split/skill.

Call record database items

Call record database item descriptions apply to historical items, specifically to the Call Record (call_rec) table. The indexes are ACD and ROW_DATE.

Exceptions historical database items

Exception Database item descriptions apply to historical items that are specific to agent (agex), split (spex), trunk group (tgex), VDN (vdnex), vector (vecex), link (linkex), and Malicious Call Trace (mctex) exceptions.

Exception type storage

CMS stores exception types as numerical values in the EXTYPE or REASON database items.

When the standard exception reports are run, the numerical value is translated to the text string.

Selecting exception types for reports

To select specific exception types for a custom report, you must enter the numerical values in the `Select rows where: statement`.

Terminology

The following terms are used in the database item descriptions.

Abandoned call

A call in which the caller hangs up before the call is answered or connected. Calls also can be considered abandoned if certain timers in the communication server time out. See the explanations of the wait answer supervision time (WAST), the phantom abandon calls, and the trunk no answer timeout (NATO). These timers are used primarily in locations where the central office trunks lack disconnect supervision.

Calls may abandon during many phases of processing, including during vector processing, after being queued to a split/skill, and while they are ringing at an agent or station.

The calls that are counted as abandons differ from table to table as follows:

- The agent table counts as abandons those split/skill ACD calls that abandon while they are ringing at the agent.
- The split/skill table counts as abandons those calls that abandon while they are queued to the split/skill or while they are ringing at an agent in the split/skill.
- The VDN table counts as abandons those ACD calls that abandon while in the VDN, including calls in vector processing that are not yet queued to a split/skill. For example, calls that abandon while listening to an announcement, calls that are queued to one or more splits/skills, and calls that are ringing at agent stations (ACD calls).

When abandoned calls are included in a database item, the definition of that item states the type of abandoned calls that are included in that database item.

ACD call

A call that queues to a split/skill and is answered by an agent in that split/skill or a call that queues as a direct agent call and is answered by the agent to whom it was queued.

After Call Work (ACW)

Work that is done when an agent is not on a call. There are two types of after call work (ACW): call-related ACW and ACW that is not associated with a call. An agent enters a call-related ACW state by completing a manual-in call, or by pressing the ACW feature button during an automatic-in call, and then completing the call. CMS tracks call-related after call work in the call-based ACWTIME item and in the interval-based I_ACWTIME item.

An agent can enter the ACW state without having an associated call by pressing the ACW feature button while available or in the auxiliary (AUX) mode. CMS will track this ACW time in the I_ACWTIME item, but not in the ACWTIME item.

For Avaya communication servers without the Expert Agent Selection (EAS) feature, the ACW time that is not associated with an ACD call is tracked for the split for which the agent pressed the ACW feature button. For Avaya communication servers with EAS, the ACW time that is not associated with an ACD call is tracked for the first skill that is administered for and successfully logged in to by the agent.

An agent in ACW who reconnects to a held AUXIN or AUXOUT call returns to the ACW mode when the AUXIN/OUT call is terminated. The ACW time that accrues following the termination of the AUXIN/OUT call is ACW that is not associated with an ACD call and counts as I_ACWTIME, not as ACWTIME.

Agent

The login ID used by an individual to log into the splits or skills. This term is often extended to mean the person who used the ID to log in to the split or skill. In all cases, the term “agent” implies measurement by CMS.

Agent position (without EAS)

The combination of the agent login ID and the split to which the agent is logged in. Agents who are logged in to multiple splits have multiple positions associated with them. Because call data are collected separately for each combination of agent-split, reporting is possible on the calls that are handled and time spent by agents in each of the splits they were in. To report on the total work that is performed by the agent, call data must be summed for the agent over all of the splits in which the agent worked.

A person that logged in to splits or skills. The person logs in from an extension (voice terminal) using the person’s assigned login ID.

Agent position (with EAS)

The login ID of the agent, regardless of the number of skills that are assigned to the agent. Data are still collected for the agent by skill, so the total work for the agent must be summed over all skills in which the agent worked.

Answered call

The agent's state changes to ACD or Direct Agent ACD (DACD). The term “answered” is used only for split/skill and direct agent ACD calls. For manual answer agents, the call is answered when the agent selects the ringing line appearance. For automatic answer agents, the call is answered directly after the zip tone is applied.

See the definition of Connected for information on non-ACD calls.

Automatic-in mode (AI)

A call answering mode. With AI and if calls are in queue, the agent receives a new ACD call immediately after releasing the current call. If timed ACW is in use, then the agent receives the next call after the timed ACW period is complete.

AUX work mode

A work mode in which agents are engaged in non-ACD work. This may represent time that is taken for a break, eating, training, dealing with mail, attending team meetings, and so on.

Extension (non-ACD) calls that agents make or receive while available in auto-in or manual-in mode are tracked as AUXOUT or AUXIN calls.

Best Service Routing (BSR)

A method of automatic call distribution between communication servers that is based on the Expected Wait Time (EWT) at each communication servers. BSR can be used either as a single-site feature or as a multisite feature.

Call segment

Call records are made up of call segments, each of which represents a related call. A new call segment is started whenever a call is made or received, including whenever a call is made to transfer or conference another call. Call segments that are related share the same call ID. Unrelated call segments have different call IDs.

Connected call

A non-ACD call, not a split/skill or direct agent call, that rings and does not abandon at an extension. Only calls that are routed to an extension are tracked as connected calls.

Direct agent ACD call

A call that queues to a specific agent. Direct agent ACD calls can be generated by an ASAI adjunct or, with the EAS feature, by calling an agent's login ID. Direct agent ACD calls are tracked as ACD calls along with split/skill ACD calls in the trunk, trunk group, VDN, and vector tables. Direct agent ACD calls are tracked separately from split/skill ACD calls in the agent tables. Direct agent ACD calls are not tracked in the split/skill tables because they are not split/skill ACD calls.

Expert Agent Selection (EAS)

An Avaya communication server feature that makes it possible to assign an agent to certain capabilities (skills). Each call is then distributed to the appropriate skill and answered on the basis of which agents have the capability to best handle the call.

External call

A call that is made to an off-communication server destination. This includes calls to other communication server in a DCS network.

Extension call

A call that is originated by an agent or a non-ACD call that is received by an agent. This includes calls that an agent makes to set up a conference or a transfer.

Flex Agents

Agents whose ROLE is Backup, Allocated or Rove.

Hold

A call that is placed on hold as a result of the agent pressing the HOLD feature button or the hard hold feature access code, by pressing the TRANSFER or CONFERENCE feature button, or by flashing the switch hook.

Manual-in mode (MI)

A call answering mode. With MI, when an agent releases an ACD call, the agent is put into the ACW mode and must manually request another ACD call by pushing the MI button.

Multibyte character set

A mixed-width character set in which some characters consist of more than 1 byte. The Japanese kanji character set is an example of a Multibyte character set.

Nonprimary split/skill

The second and third splits/skills to which the call queues in a VDN are called “non-primary splits/skills.” They are also referred to as secondary and tertiary splits/skills, respectively.

Overload thresholds

Administered in the hunt group form on the communication server, the number of seconds at which Reserve Level 1 and Reserve Level 2 agents will be activated.

Primary split/skill

The first split/skill to which the call queues in a VDN. If the call leaves vector processing and queues to another split/skill (for example, if the call is routed to a split/skill extension or routed to another VDN), that new split/skill becomes the primary split/skill. If the call leaves vector processing and does not queue to another split/skill (for example, routes to an extension), there is no new primary split/skill.

Reserve Agent

An agent that receives calls for a skill only when the skill is in an overload 1 or 2. A reserve agent is considered activated while the overload 1 or 2 threshold is being exceeded. The agent is considered to be in standby when the skill is normal.

Queued

A split/skill or direct agent call that is directed to a split/skill. Even if a call is delivered immediately to an agent and never occupies a queue slot CMS is still notified that the call was queued to the split/skill.

Secondary split/skill

The second split/skill to which the call queues in a VDN.

Service Level Supervisor

An Avaya Business Advocate feature that can automatically override normal agent call handling preferences and activate reserve agents when preset thresholds are exceeded.

Skill level

The level of expertise of an agent with respect to all skills to which the agent is assigned. Skill level can be primary or secondary. The skill levels help to determine which call, that is waiting for one of the agent's skills, will be delivered to the agent first when the agent becomes available. Skill levels help determine the most expert agent who can handle a call to the skill.

Skill state

A level of use for each skill that is used to help determine when to add agents to a skill to handle a large volume of skills. Skills can be in one of four states: unknown, normal, overload 1, and overload 2. The state of the skill is based on the expected wait time (EWT) threshold. A skill is considered normal while the EWT is not exceeding the overload 1 or 2 threshold. The skill is considered to be in overload 1 while the EWT is exceeding this overload 1 threshold. While the overload 2 is being exceeded the skill is in overload 2. Time spent in each state except unknown is tracked in the CMS split table. The state is unknown when the link between the CMS and the communication server is down, the split is non-EAS, or when a new skill is added and the state message has not yet arrived from the communication server.

Split/skill ACD call

A call that queued to a split/skill and was answered by an agent in that split/skill.

Standby

Describes the time that Reserve Agents spend logged into a skill and not active because the skill is not in an overload 1 or 2 state.

Station

In a non-EAS environment, a station is an extension that is not a member of an unmeasured split/skill or hunt group. In an EAS environment, a station is an extension that is not associated with a logged in agent; that is, an agent did not log in via this extension.

Tertiary split/skill

The third split/skill to which the call queues in a VDN.

Top skill

The agent's first-administered, highest-level skill. This concept is most useful with agents who are using skill level call handling preference. In this case, the agent's top skill represents the skill for which the agent is most likely to receive a call. Agents for whom a given skill is the top skill are the agents whom a skill supervisor can depend on to handle calls for the skill.

This concept is not useful for agents using the greatest need or percent allocation call handling preference or for agents who are not EAS agents. For non-EAS agents, the top "skill" is the split the agent has been logged into the longest.

Uniform Call Distribution (UCD)

A method of agent selection that is available in both EAS and non-EAS environments, in which all idle agents are included in a single group. The least occupied (UCD-LOA) or most idle (UCD-MIA) agent is selected for call delivery. In an EAS environment, the selection is made regardless of skill level.

Universal Call Identifier (UCID)

A number that uniquely identifies a call in a network of nodes that support UCID. This number is a part of the records in the CMS Call History feature.

■ ■ ■ ■ ■ ■

Communication server capabilities that impact CMS

This section provides a set of tables that cross-reference which CMS database items are available on each of the Avaya communication servers. It also provides information on how communication server features and capabilities are tracked by the CMS or can affect the data that the CMS produces for reports.

Example of table layout

CMS database items apply to specific communication servers. The cross-reference tables that follow list each database item by communication server release. Below is an example of how the table information is presented. Communication server releases to which the listed database item applies are marked with X.

| Database Item | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Avaya Communication Manager 1.1-2.1 | Avaya Communication Manager 3.0 |
|---------------|--------------------------|--------------------------|--|--|--|
| DATABASE ITEM | X | X | X | X | X |

Communication server cross-reference

The following tables list which database items are supported by each of the communication server releases. The tables are presented in alphabetical order by database table name (Agent, Agent Login/Logout, Agent Trace, and so on).

The tables are presented alphabetically by database item type in the following order:

- Agent
- Agent Login/Logout
- Agent Trace
- Call Record
- Call Work Codes
- Current Day Configuration (forecasting)
- Current Day Report (forecasting)
- Exceptions
- Split/Skill
- Trunk Group
- Trunk
- Vector
- VDN

Note:

The database item tables from which data is retrieved most frequently are the agent, split/skill, trunk group, trunk, vector, and VDN tables.

Key to tables

Following is a key to the table:

- The items marked with an “X” indicate that the database item is supported by that communication server.
- The items marked with an “a” are populated for the releases shown, but the values are meaningful only for Avaya communication servers with the EAS feature and Avaya Business Advocate.
- The items marked with “RC” are populated for the releases shown, but the values are meaningful only for Avaya communication servers with the EAS feature and Reason Codes.

- The items marked with “EAS” require that the Expert Agent Selection feature be active on the communication server for the items to be populated.
- The items marked with “e” are populated for the releases shown, but the values are meaningful only for communication server with the EAS feature.
- The items marked with “NA” are populated for the releases shown, but the values might not be meaningful.
- The items marked with an “t” are populated for the releases shown, but the values are meaningful only for Avaya communication servers with the EAS feature and skill level distribution of calls.

Agent database items

The following table lists which agent database items are supported by each of the Avaya communication server releases. A link to a complete description of the database item is also provided. The database items without a CMS version were introduced in R3V1 or R3V2.

| Agent database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|------------------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ABNCALLS | | X | X | X | X | X |
| ABNTIME | | X | X | X | X | X |
| ACD | | X | X | X | X | X |
| ACD_RELEASE | R3V5 | X | X | X | X | X |
| ACDAUXOUTCALLS | | X | X | X | X | X |
| ACDCALLS | | X | X | X | X | X |
| ACDCALLS_R1 | R3V9 | a | a | a | a | a |
| ACDCALLS_R2 | R3V9 | a | a | a | a | a |
| ACDONHOLD | | X | X | X | X | X |
| ACDTIME | | X | X | X | X | X |
| ACWINCALLS | | X | X | X | X | X |
| ACWINTIME | | X | X | X | X | X |

Communication server capabilities that impact CMS

| Agent database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|------------------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ACWOUTADJCALLS | | X | X | X | X | X |
| ACWOUTCALLS | | X | X | X | X | X |
| ACWOUTOFFCALLS | | X | X | X | X | X |
| ACWOUTOFFTIME | | X | X | X | X | X |
| ACWOUTTIME | | X | X | X | X | X |
| ACWTIME | | X | X | X | X | X |
| AGDURATION | R3V6 | X | X | X | X | X |
| AGSTATE | | X | X | X | X | X |
| AGTIME | | X | X | X | X | X |
| ANSRINGTIME | | X | X | X | X | X |
| ASSIST | | X | X | X | X | X |
| ASSISTS | | X | X | X | X | X |
| AUXINCALLS | | X | X | X | X | X |
| AUXINTIME | | X | X | X | X | X |
| AUXOUTADJCALLS | | X | X | X | X | X |
| AUXOUTCALLS | | X | X | X | X | X |
| AUXOUTOFFCALLS | | X | X | X | X | X |
| AUXOUTOFFTIME | | X | X | X | X | X |
| AUXOUTTIME | | X | X | X | X | X |
| AUXREASON | R3V5 | RC | RC | RC | RC | RC |
| AWORKMODE | R3V5 | X | X | X | X | X |
| CHANGED | | X | X | X | X | X |
| CONFERENCE | | X | X | X | X | X |
| DA_ABNCALLS | | X | X | X | X | X |
| DA_ABNTIME | | X | X | X | X | X |

| Agent database items communication server cross-reference | | | | | | |
|---|----------------------------|--------------------------|--------------------------|---|-------------------------------------|---------------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| DA_ACDCALLS | | X | X | X | X | X |
| DA_ACDTIME | | X | X | X | X | X |
| DA_ACWINCALLS | | X | X | X | X | X |
| DA_ACWINTIME | | X | X | X | X | X |
| DA_ACWOADJCALLS | | X | X | X | X | X |
| DA_ACWOCALLS | | X | X | X | X | X |
| DA_ACWOOFFCALLS | | X | X | X | X | X |
| DA_ACWOOFFTIME | | X | X | X | X | X |
| DA_ACWOTIME | | X | X | X | X | X |
| DA_ACWTIME | | X | X | X | X | X |
| DA_ANSTIME | | X | X | X | X | X |
| DA_INQUEUE | | X | X | X | X | X |
| DA_OLDESTCALL | | X | X | X | X | X |
| DA_OTHERCALLS | | X | X | X | X | X |
| DA_OTHERTIME | | X | X | X | X | X |
| DA_RELEASE | R3V5 | X | X | X | X | X |
| DA_SKILL | R3V5 | EAS | EAS | EAS | EAS | EAS |
| DACALLS_FIRST | R3V6 | a | a | a | a | a |
| DESTINATION | | X | X | X | X | X |
| DIRECTION | | X | X | X | X | X |
| DURATION | | X | X | X | X | X |
| EVENT1-9 | | X | X | X | X | X |
| EXTENSION | | X | X | X | X | X |
| GNSKILL | R3V6 | EAS | EAS | EAS | EAS | EAS |
| HOLDABNCALLS | R3V5 | X | X | X | X | X |

Communication server capabilities that impact CMS

| Agent database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|------------------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| HOLDACDTIME | | X | X | X | X | X |
| HOLDCALLS | | X | X | X | X | X |
| HOLDTIME | | X | X | X | X | X |
| I_ACDAUXINTIME | | X | X | X | X | X |
| I_ACDAUX_OUTTIME | | X | X | X | X | X |
| I_ACDOTHERTIME | | X | X | X | X | X |
| I_ACDTIME | | X | X | X | X | X |
| I_ACWINTIME | | X | X | X | X | X |
| I_ACWOUTTIME | | X | X | X | X | X |
| I_ACWTIME | | X | X | X | X | X |
| I_AUXINTIME | | X | X | X | X | X |
| I_AUXOUTTIME | | X | X | X | X | X |
| I_AUXSTBYTIME | R3V11 | a | a | a | a | a |
| I_AUXTIME | R3V5 | X | X | X | X | X |
| I_AVAILTIME | | X | X | X | X | X |
| I_DA_ACDTIME | | X | X | X | X | X |
| I_DA_ACWTIME | | X | X | X | X | X |
| I_OTHERSTBYTIME | R3V11 | a | a | a | a | a |
| I_OTHERTIME | | X | X | X | X | X |
| I_RINGTIME | | X | X | X | X | X |
| I_STAFFTIME | | X | X | X | X | X |
| INCOMPLETE | | X | X | X | X | X |
| INTRVL | | X | X | X | X | X |
| LEVEL | R3V5 | EAS | EAS | EAS | EAS | EAS |

| Agent database items communication server cross-reference | | | | | | |
|---|----------------------------|--------------------------|--------------------------|---|-------------------------------------|---------------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| LOC_ID | R3V8 | X | X | X | X | X |
| LOGID | | X | X | X | X | X |
| LOGONSKILL | | e | e | e | e | e |
| LOGONSKILL2-4 | | EAS | EAS | EAS | EAS | EAS |
| LOGONSKILL5 | | EAS | EAS | EAS | EAS | EAS |
| LOGONSKILL6-20 | R3V5 | EAS | EAS | EAS | EAS | EAS |
| LOGONSKILL21-60 | R12 | | | | EAS | EAS |
| LOGONSTART | | X | X | X | X | X |
| MALICIOUS | | X | X | X | X | X |
| MOVEPENDING | R3V4 | X | X | X | X | X |
| NOANSREDIR | | X | X | X | X | X |
| O_ACDCALLS | | X | X | X | X | X |
| O_ACDTIME | | X | X | X | X | X |
| O_ACWTIME | | X | X | X | X | X |
| OLDEST_LOGON | | X | X | X | X | X |
| ONHOLD | | X | X | X | X | X |
| ORIGIN | | X | X | X | X | X |
| PENDINGSPILT | R3V4 | X | X | X | X | X |
| PERCENT | R3V6 | a | a | a | a | a |
| PHANTOMABNS | R3V4 | X | X | X | X | X |
| POSITION | | X | X | X | X | X |
| PREFERENCE | R3V5 | EAS | EAS | EAS | EAS | EAS |
| RINGCALLS | | X | X | X | X | X |
| RINGTIME | | X | X | X | X | X |

Communication server capabilities that impact CMS

| Agent database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|------------------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ROLE | R3V6 | X | X | X | X | X |
| ROW_DATE | | X | X | X | X | X |
| RSV_LEVEL | R3V11 | a | a | a | a | a |
| SKILLTYPE | | na | na | na | na | na |
| SKILLTYPE2-4 | | na | na | na | na | na |
| SKLEVEL | R3V5 | EAS | EAS | EAS | EAS | EAS |
| SKLEVEL2-4 | R3V5 | EAS | EAS | EAS | EAS | EAS |
| SKLEVEL5-20 | R3V5 | EAS | EAS | EAS | EAS | EAS |
| SKLEVEL21-60 | R12 | | | | EAS | EAS |
| SKPERCENT | R3V6 | a | a | a | a | a |
| SKPERCENT2-20 | R3V6 | a | a | a | a | a |
| SKPERCENT21-60 | R12 | | | | X | X |
| SPLIT | | X | X | X | X | X |
| STARTED | | X | X | X | X | X |
| STARTTIME | | X | X | X | X | X |
| TI_AUXTIME | | X | X | X | X | X |
| TI_AUXTIME0 | R3V5 | RC | RC | RC | RC | RC |
| TI_AUXTIME1-9 | R3V5 | RC | RC | RC | RC | RC |
| TI_AVAILTIME | | X | X | X | X | X |
| TI_OTHERTIME | | X | X | X | X | X |
| TI_STAFFTIME | | X | X | X | X | X |
| TOPSKILL | R3V5 | t | t | t | t | t |
| TRANSFERRED | | X | X | X | X | X |
| TYPE | R3V4 | NA | NA | NA | NA | NA |

| Agent database items communication server cross-reference | | | | | | |
|--|----------------------------|--------------------------|--------------------------|---|-------------------------------------|---------------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| USE_SVC_OBJ | R3V6 | a | a | a | a | a |
| VDN | | X | X | X | X | X |
| WORKMODE | | X | X | X | X | X |
| WORKSKLEVEL | R3V5 | EAS | EAS | EAS | EAS | EAS |
| WORKSKILL | | e | e | e | e | e |
| WORKSPLIT | | X | X | X | X | X |
| WORKSPLIT2-3 | | X | X | X | X | X |
| WORKSPLIT4 | | EAS | EAS | EAS | EAS | EAS |
| WORKSPLIT5 | | EAS | EAS | EAS | EAS | EAS |
| WORKSPLIT6-20 | R3V5 | EAS | EAS | EAS | EAS | EAS |
| WORKSPLIT21-60 | R12 | | | | EAS | EAS |

Agent login/logout database items

The following table lists which agent login/logout database items are supported by each of the Avaya communication server releases.

| Agent login/logout database items communication server cross-reference | | | | | | |
|---|----------------------------|--------------------------|--------------------------|---|-------------------------------------|---------------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ACD | | X | X | X | X | X |
| EXTN | | X | X | X | X | X |
| INFLAG | | X | X | X | X | X |
| LOC_ID | R3V8 | X | X | X | X | X |
| LOGID | | X | X | X | X | X |

Communication server capabilities that impact CMS

| Agent login/logout database items communication server cross-reference (Continued) | | | | | | |
|---|----------------------|--------------------|--------------------|------------------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| LOGIN | | X | X | X | X | X |
| LOGONSKILL2-4 | | EAS | EAS | EAS | EAS | EAS |
| LOGONSKILL5 | | EAS | EAS | EAS | EAS | EAS |
| LOGONSKILL6-20 | R3V5 | EAS | EAS | EAS | EAS | EAS |
| LOGONSKILL21-60 | R12 | | | | EAS | EAS |
| LOGOUT | | X | X | X | X | X |
| LOGOUT_DATE | | X | X | X | X | X |
| LOGOUTREASON | R3V5 | RC | RC | RC | RC | RC |
| OUTFLAG | | X | X | X | X | X |
| PREFERENCE | R3V6 | EAS | EAS | EAS | EAS | EAS |
| ROW_DATE | | X | X | X | X | X |
| SKILLTYPE | | NA | NA | NA | NA | NA |
| SKILLTYPE2-4 | | NA | NA | NA | NA | NA |
| SKLEVEL | R3V5 | EAS | EAS | EAS | EAS | EAS |
| SKLEVEL2-4 | R3V5 | EAS | EAS | EAS | EAS | EAS |
| SKLEVEL5-20 | | EAS | EAS | EAS | EAS | EAS |
| SKLEVEL21-60 | R12 | | | | EAS | EAS |
| SKPERCENT | R3V6 | a | a | a | a | a |
| SKPERCENT2-20 | R3V6 | a | a | a | a | a |
| SKPERCENT21-60 | R12 | | | | a | a |
| SPLIT | | X | X | X | X | X |

Agent trace database items

The following table lists which agent trace database items are supported by each of the Avaya communication server releases.

| Agent trace database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ACD | | X | X | X | X | X |
| AGT_RELEASED | R3V5 | X | X | X | X | X |
| ASSIST_ACTV | | X | X | X | X | X |
| AUXREASON | R3V5 | RC | RC | RC | RC | RC |
| CALLER_HOLD | | X | X | X | X | X |
| CALLING_II | R3V5 | X | X | X | X | X |
| CALLING_PTY | | X | X | X | X | X |
| CONFERENCE | | X | X | X | X | X |
| DIGITS_DIALED | | X | X | X | X | X |
| DIRECTION | | X | X | X | X | X |
| DURATION | | X | X | X | X | X |
| EVENT_TIME | | X | X | X | X | X |
| EXT_CALL_ORIG | | X | X | X | X | X |
| KEYBD_DIALED | | X | X | X | X | X |
| LOC_ID | R3V8 | X | X | X | X | X |
| LOGID (index) | | X | X | X | X | X |
| LOGOUTREASON | R3V5 | RC | RC | RC | RC | RC |
| MCT | | X | X | X | X | X |
| RECONNECT | | X | X | X | X | X |

Communication server capabilities that impact CMS

| Agent trace database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ROW_DATE | | X | X | X | X | X |
| SPLIT | | X | X | X | X | X |
| STARTTIME | | X | X | X | X | X |
| TRANSFERRED | | X | X | X | X | X |
| UCID | R3V6 | X | X | X | X | X |
| WMODE_SEQ | | X | X | X | X | X |
| WORKCODE | | X | X | X | X | X |
| WORKMODE | | X | X | X | X | X |

Call record database items

The following table lists which call record database items are supported by each of the Avaya communication server releases.

| Call record database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ACD | | X | X | X | X | X |
| ACWTIME | | X | X | X | X | X |
| AGT_RELEASED | R3V5 | X | X | X | X | X |
| ANSHOLDTIME | | X | X | X | X | X |
| ANSLOCID | R3V8 | X | X | X | X | X |
| ANSLOGIN | | X | X | X | X | X |
| ANSREASON | R3V5 | RC | RC | RC | RC | RC |
| ASSIST | | X | X | X | X | X |

| Call record database items communication server cross-reference | | | | | | |
|---|----------------------------|--------------------------|--------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| AUDIO | | X | X | X | X | X |
| CALLID | | X | X | X | X | X |
| CALLING_II | R3V5 | X | X | X | X | X |
| CALLING_PTY | | X | X | X | X | X |
| CONFERENCE | | X | X | X | X | X |
| CONSULTTIME | | X | X | X | X | X |
| CWC1 | R3V11 | X | X | X | X | X |
| CWC2 | R3V11 | X | X | X | X | X |
| CWC3 | R3V11 | X | X | X | X | X |
| CWC4 | R3V11 | X | X | X | X | X |
| CWC5 | R3V11 | X | X | X | X | X |
| DA_QUEUED | | X | X | X | X | X |
| DIALED_NUM | | X | X | X | X | X |
| DISPIVECTOR | | X | X | X | X | X |
| DISPOSITION | | X | X | X | X | X |
| DISPPRIORITY | | X | X | X | X | X |
| DISPSKLEVEL | R3V5 | EAS | EAS | EAS | EAS | EAS |
| DISPSPLIT | | X | X | X | X | X |
| DISPTIME | | X | X | X | X | X |
| DISPVDN | | X | X | X | X | X |
| DURATION | | X | X | X | X | X |
| EQLOC | | X (8 char) | X (8 char) | X (8 char) | X (8 char) | X (8 char) |
| EQLOCID | R3V8 | X | X | X | X | X |
| EVENT1-9 | | X | X | X | X | X |
| FIRSTIVECTOR | | X | X | X | X | X |

Communication server capabilities that impact CMS

| Call record database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| FIRSTVDN | | X | X | X | X | X |
| HELD | | X | X | X | X | X |
| HOLDABN | | X | X | X | X | X |
| LASTCWC | | X | X | X | X | X |
| LASTDIGITS | R3V5 | X | X | X | X | X |
| LASTOBSERVER | | X | X | X | X | X |
| MALICIOUS | | X | X | X | X | X |
| NETINTIME | R3V6 | X | X | X | X | X |
| OBSERVINGCALL | | X | X | X | X | X |
| OBSLOCID | R3V8 | X | X | X | X | X |
| ORIGHOLDTIME | R3V6 | X | X | X | X | X |
| ORIGLOCID | R3V8 | X | X | X | X | X |
| ORIGLOGIN | | X | X | X | X | X |
| ORIGREASON | R3V5 | RC | RC | RC | RC | RC |
| ROW_DATE | | X | X | X | X | X |
| ROW_TIME | | X | X | X | X | X |
| SEGMENT | | X | X | X | X | X |
| SEGSTART | | X | X | X | X | X |
| SEGSTOP | | X | X | X | X | X |
| SEQNUM | | X | X | X | X | X |
| SPLIT1 | | X | X | X | X | X |
| SPLIT2 | | X | X | X | X | X |
| SPLIT3 | | X | X | X | X | X |
| TALKTIME | | X | X | X | X | X |
| TKGRP | | X | X | X | X | X |

| Call record database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| TRANSFERRED | | X | X | X | X | X |
| UCID | R3V6 | X | X | X | X | X |

Call work codes database items

The following table lists the call work codes database items are supported by each of the Avaya communication server releases.

| Call work codes database items communication server cross-reference | | | | | |
|---|--------------------|--------------------|------------------------------------|-------------------------------|---------------------------|
| Database item | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ACD | X | X | X | X | X |
| ACDCALLS | X | X | X | X | X |
| ACDTIME | X | X | X | X | X |
| ACWTIME | X | X | X | X | X |
| CWC | X | X | X | X | X |
| INCOMPLETE | X | X | X | X | X |
| INTRVL | X | X | X | X | X |
| ROW_DATE | X | X | X | X | X |
| STARTTIME | X | X | X | X | X |

Current day configuration database items

The following table lists which current day configuration database items are supported by each of the Avaya communication server releases.

| Current day configuration database items communication server cross-reference | | | | | |
|---|--------------------------|--------------------------|---|-------------------------------------|---------------------------------|
| Database item | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ACD | X | X | X | X | X |
| CHANGE | X | X | X | X | X |
| CHPROF | X | X | X | X | X |
| FMETHOD | X | X | X | X | X |
| HDATE1 | X | X | X | X | X |
| HDATE2 | X | X | X | X | X |
| HDATE3 | X | X | X | X | X |
| HDATE4 | X | X | X | X | X |
| ROW_DATE | X | X | X | X | X |
| SPLIT | X | X | X | X | X |
| TRENDBASE | X | X | X | X | X |
| WT1 | X | X | X | X | X |
| WT2 | X | X | X | X | X |
| WT3 | X | X | X | X | X |
| WT4 | X | X | X | X | X |

Current day report database items

The following table lists which current day report database items are supported by each of the Avaya communication server releases.

| Current day report database items communication server cross-reference | | | | | |
|--|--------------------------|--------------------------|---|-------------------------------------|---------------------------------|
| Database item | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing Software R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ACD | X | X | X | X | X |
| AGOCC | X | X | X | X | X |
| AVGAGSERV | X | X | X | X | X |
| AVGSPEEDANS | X | X | X | X | X |
| FCALLS | X | X | X | X | X |
| INTRVL | X | X | X | X | X |
| NUMAGREQ | X | X | X | X | X |
| RAGOCC | X | X | X | X | X |
| RAVGSPEEDANS | X | X | X | X | X |
| ROW_DATE | X | X | X | X | X |
| RSERVLEVELP | X | X | X | X | X |
| SERVLEVELP | X | X | X | X | X |
| SERVLEVELT | X | X | X | X | X |
| SPLIT | X | X | X | X | X |
| STARTTIME | X | X | X | X | X |

Split/skill database items

The following table lists which split/skill database items are supported by each of the Avaya communication server releases.

| Split/skill database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ABNCALLS | | X | X | X | X | X |
| ABNCALLS1-10 | | X | X | X | X | X |
| ABNRINGCALLS | | X | X | X | X | X |
| ABNTIME | | X | X | X | X | X |
| ACCEPTABLE | | X | X | X | X | X |
| ACD (index) | | X | X | X | X | X |
| ACDAUXOUTCALLS | | X | X | X | X | X |
| ACDCALLS | | X | X | X | X | X |
| ACDCALLS_R1 | R3V9 | a | a | a | a | a |
| ACDCALLS_R2 | R3V9 | a | a | a | a | a |
| ACDCALLS1-10 | | X | X | X | X | X |
| ACDTIME | | X | X | X | X | X |
| ACWINCALLS | | X | X | X | X | X |
| ACWINTIME | | X | X | X | X | X |
| ACWOUTADJCALLS | | X | X | X | X | X |
| ACWOUTCALLS | | X | X | X | X | X |
| ACWOUTOFFCALLS | | X | X | X | X | X |
| ACWOUTOFFTIME | | X | X | X | X | X |
| ACWOUTTIME | | X | X | X | X | X |
| ACWTIME | | X | X | X | X | X |
| AGINRING | | X | X | X | X | X |

| Split/skill database items communication server cross-reference | | | | | | |
|---|----------------------------|--------------------------|--------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ANSTIME | | X | X | X | X | X |
| ASA | R3V4 | X | X | X | X | X |
| ASSISTS | | X | X | X | X | X |
| AUXINCALLS | | X | X | X | X | X |
| AUXINTIME | | X | X | X | X | X |
| AUXOUTADJCALLS | | X | X | X | X | X |
| AUXOUTCALLS | | X | X | X | X | X |
| AUXOUTOFFCALLS | | X | X | X | X | X |
| AUXOUTOFFTIME | | X | X | X | X | X |
| AUXOUTTIME | | X | X | X | X | X |
| AVAILABLE | | X | X | X | X | X |
| BACKUPCALLS | | X | X | X | X | X |
| BUSYCALLS | | X | X | X | X | X |
| BUSYTIME | | X | X | X | X | X |
| CALLSOFFERED | | X | X | X | X | X |
| CONFERENCE | | X | X | X | X | X |
| DA_ACWINCALLS | | X | X | X | X | X |
| DA_ACWINTIME | | X | X | X | X | X |
| DA_ACWOCALLS | | X | X | X | X | X |
| DA_ACWOTIME | | X | X | X | X | X |
| DA_INACW | | X | X | X | X | X |
| DA_INQUEUE | | X | X | X | X | X |
| DA_INRING | | X | X | X | X | X |
| DA_OLDESTCALL | | X | X | X | X | X |
| DA_ONACD | | X | X | X | X | X |

Communication server capabilities that impact CMS

| Split/skill database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| DEQUECALLS | | X | X | X | X | X |
| DEQUETIME | | X | X | X | X | X |
| DISCCALLS | | X | X | X | X | X |
| DISCTIME | | X | X | X | X | X |
| EVENT1-9 | | X | X | X | X | X |
| EWTHIGH | R3V4 | X | X | X | X | X |
| EWTLOW | R3V4 | X | X | X | X | X |
| EWTMEDIUM | R3V4 | X | X | X | X | X |
| EWTTOP | R3V4 | X | X | X | X | X |
| FAGINRING | R3V6 | X | X | X | X | X |
| FAVAILABLE | R3V6 | X | X | X | X | X |
| FINACD | R3V6 | X | X | X | X | X |
| FINAUX | R3V6 | X | X | X | X | X |
| FONACD | R3V6 | X | X | X | X | X |
| FOTHER | R3V6 | X | X | X | X | X |
| FSTAFFED | R3V6 | X | X | X | X | X |
| GNAGINRING | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNAVAILABLE | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNINACW | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNINAUX | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNINAUX0 | R3V6 | RC | RC | RC | RC | RC |
| GNINAUX1-9 | R3V6 | RC | RC | RC | RC | RC |
| GNONACD | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNONACDAUXOUT | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNONACDOUT | R3V6 | EAS | EAS | EAS | EAS | EAS |

| Split/skill database items communication server cross-reference | | | | | | |
|--|----------------------------|--------------------------|--------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| GNONACWIN | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNONACWOUT | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNONAUXIN | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNONAUXOUT | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNDAC_INACW | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNDAC_ONACD | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNOTHER | R3V6 | EAS | EAS | EAS | EAS | EAS |
| GNSTAFFED | R3V6 | EAS | EAS | EAS | EAS | EAS |
| HIGHCALLS | | X | X | X | X | X |
| HOLDABNCALLS | | X | X | X | X | X |
| HOLDCALLS | | X | X | X | X | X |
| HOLDTIME | | X | X | X | X | X |
| I_ACDAUXINTIME | | X | X | X | X | X |
| I_ACDAUX_OUTTIME | | X | X | X | X | X |
| I_ACDOTHERTIME | | X | X | X | X | X |
| I_ACDTIME | | X | X | X | X | X |
| I_ACDTIME_R1 | R3V11 | a | a | a | a | a |
| I_ACDTIME_R2 | R3V11 | a | a | a | a | a |
| I_ACWINTIME | | X | X | X | X | X |
| I_ACWOUTTIME | | X | X | X | X | X |
| I_ACWTIME | | X | X | X | X | X |
| I_ACWTIME_R1 | R3V11 | a | a | a | a | a |
| I_ACWTIME_R2 | R3V11 | a | a | a | a | a |
| I_ARRIVED | R3V5 | X | X | X | X | X |
| I_AUXINTIME | | X | X | X | X | X |

Communication server capabilities that impact CMS

| Split/skill database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| I_AUXOUTTIME | | X | X | X | X | X |
| I_AUXSTBYTIME_R1 | R3V11 | a | a | a | a | a |
| I_AUXSTBYTIME_R2 | R3V11 | a | a | a | a | a |
| I_AUXTIME | | X | X | X | X | X |
| I_AUXTIME_R1 | R3V11 | a | a | a | a | a |
| I_AUXTIME_R2 | R3V11 | a | a | a | a | a |
| I_AUXTIME0 | R3V5 | RC | RC | RC | RC | RC |
| I_AUXTIME1-9 | R3V5 | RC | RC | RC | RC | RC |
| I_AVAILTIME | | X | X | X | X | X |
| I_DA_ACDTIME | R3V5 | X | X | X | X | X |
| I_DA_ACWTIME | R3V5 | X | X | X | X | X |
| I_NORMTIME | R3V6 | a | a | a | a | a |
| I_OL1TIME | R3V6 | a | a | a | a | a |
| I_OL2TIME | R3V6 | a | a | a | a | a |
| I_OTHERSTBYTIME_R1 | R3V11 | a | a | a | a | a |
| I_OTHERSTBYTIME_R2 | R3V11 | a | a | a | a | a |
| I_OTHERTIME | | X | X | X | X | X |
| I_OTHERTIME_R1 | R3V11 | a | a | a | a | a |
| I_OTHERTIME_R2 | R3V11 | a | a | a | a | a |
| I_RINGTIME | | X | X | X | X | X |
| I_RINGTIME_R1 | R3V11 | a | a | a | a | a |
| I_RINGTIME_R2 | R3V11 | a | a | a | a | a |
| I_STAFFTIME | | X | X | X | X | X |
| I_TAUXTIME | R3V5 | t | t | t | t | t |

| Split/skill database items communication server cross-reference | | | | | | |
|--|----------------------------|--------------------------|--------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| I_TOTHERTIME | R3V6 | t | t | t | t | t |
| I_TAVAILABLE | R3V5 | t | t | t | t | t |
| INACW | | X | X | X | X | X |
| INAUX | | X | X | X | X | X |
| INAUX0 | R3V5 | RC | RC | RC | RC | RC |
| INAUX1-9 | R3V5 | RC | RC | RC | RC | RC |
| INCOMPLETE | | X | X | X | X | X |
| INFLOWCALLS | | X | X | X | X | X |
| INQUEUE | | X | X | X | X | X |
| INRING | | X | X | X | X | X |
| INTERFLOWCALLS | | X | X | X | X | X |
| INTRVL | | X | X | X | X | X |
| LOWCALLS | | X | X | X | X | X |
| MAXINQUEUE | | X | X | X | X | X |
| MAXOCWTIME | | X | X | X | X | X |
| MAXSTAFFED | | X | X | X | X | X |
| MAXTOP | R3V5 | t | t | t | t | t |
| MAX_TOT_PERCENTS | R3V6 | a | a | a | a | a |
| MEDCALLS | | X | X | X | X | X |
| NOANSREDIR | | X | X | X | X | X |
| O_ABNCALLS | | X | X | X | X | X |
| O_ACDCALLS | | X | X | X | X | X |
| O_ACDTIME | | X | X | X | X | X |
| O_ACWTIME | | X | X | X | X | X |
| O_OTHERCALLS | | X | X | X | X | X |

Communication server capabilities that impact CMS

| Split/skill database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| OLDESTCALL | | X | X | X | X | X |
| ONACD | | X | X | X | X | X |
| ONACDAUXOUT | | X | X | X | X | X |
| ONACDOUT | | X | X | X | X | X |
| ONACWIN | | X | X | X | X | X |
| ONACWOUT | | X | X | X | X | X |
| ONAUXIN | | X | X | X | X | X |
| ONAUXOUT | | X | X | X | X | X |
| ONHOLD | | X | X | X | X | X |
| OTHER | | X | X | X | X | X |
| OTHERCALLS | R3V5 | X | X | X | X | X |
| OTHERTIME | R3V5 | X | X | X | X | X |
| OUTFLOWCALLS | | X | X | X | X | X |
| OUTFLOWTIME | | X | X | X | X | X |
| PERIOD 1-9 | | X | X | X | X | X |
| PERIODCHG | | X | X | X | X | X |
| PHANTOMABNS | R3V4 | X | X | X | X | X |
| POSITIONS | | X | X | X | X | X |
| R1AGINRING | R3V6 | a | a | a | a | a |
| R1AVAILABLE | R3V6 | a | a | a | a | a |
| R1INACW | R3V6 | a | a | a | a | a |
| R1INAUX | R3V6 | a | a | a | a | a |
| R1INAUXSTBY | R3V11 | a | a | a | a | a |
| R1ONACD | R3V6 | a | a | a | a | a |
| R1OTHER | R3V6 | a | a | a | a | a |

| Split/skill database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| R1OTHERSTBY | R3V11 | a | a | a | a | a |
| R1STAFFED | R3V6 | a | a | a | a | a |
| R2AGINRING | R3V6 | a | a | a | a | a |
| R2AVAILABLE | R3V6 | a | a | a | a | a |
| R2INACW | R3V6 | a | a | a | a | a |
| R2INAUX | R3V6 | a | a | a | a | a |
| R2INAUXSTBY | R3V11 | a | a | a | a | a |
| R2ONACD | R3V6 | a | a | a | a | a |
| R2OTHER | R3V6 | a | a | a | a | a |
| R2OTHERSTBY | R3V11 | a | a | a | a | a |
| R2STAFFED | R3V6 | a | a | a | a | a |
| RINGCALLS | | X | X | X | X | X |
| RINGTIME | | X | X | X | X | X |
| ROW_DATE | | X | X | X | X | X |
| SERVICELLEVEL | | X | X | X | X | X |
| SKSTATE | R3V6 | a | a | a | a | a |
| SLVLABNS | R3V5 | X | X | X | X | X |
| SLVLOUTFLOWS | R3V5 | X | X | X | X | X |
| SPLIT | | X | X | X | X | X |
| STAFFED | | X | X | X | X | X |
| STARTTIME | | X | X | X | X | X |
| SVCLEVELCHG | | X | X | X | X | X |
| TAGINRING | R3V5 | t | t | t | t | t |
| TAVAILABLE | R3V5 | t | t | t | t | t |
| TDA_INACW | R3V5 | t | t | t | t | t |

Communication server capabilities that impact CMS

| Split/skill database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| TDA_ONACD | R3V5 | t | t | t | t | t |
| TINACW | R3V5 | t | t | t | t | t |
| TINAUX | R3V5 | t | t | t | t | t |
| TINAUX0 | R3V5 | RC and t | RC and t | RC and t | RC and t | RC and t |
| TINAUX1-9 | R3V5 | RC and t | RC and t | RC and t | RC and t | RC and t |
| TONACD | R3V5 | t | t | t | t | t |
| TONACDAUXOUT | R3V5 | t | t | t | t | t |
| TONACDOUT | R3V5 | t | t | t | t | t |
| TONACWIN | R3V5 | t | t | t | t | t |
| TONACWOUT | R3V5 | t | t | t | t | t |
| TONAUXIN | R3V5 | t | t | t | t | t |
| TONAUXOUT | R3V5 | t | t | t | t | t |
| TOPCALLS | | X | X | X | X | X |
| TOTHER | R3V5 | t | t | t | t | t |
| TOT_PERCENTS | R3V6 | a | a | a | a | a |
| TRANSFERRED | | X | X | X | X | X |
| TSTAFFED | R3V5 | t | t | t | t | t |

Trunk database items

The following table lists which trunk data base items are supported by each of the Avaya communication server releases.

| Trunk database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ABNCALLS | | X | X | X | X | X |
| ACD | | X | X | X | X | X |
| ACDCALLS | | X | X | X | X | X |
| ACDCALLS_R1 | R3V9 | a | a | a | a | a |
| ACDCALLS_R2 | R3V9 | a | a | a | a | a |
| AUDIO | | X | X | X | X | X |
| CALLING_LOGID | R3V5 | X | X | X | X | X |
| DIRECTION | | X | X | X | X | X |
| DURATION | | X | X | X | X | X |
| EQLOC | | X (8 char) | X (8 char) | X (8 char) | X (8 char) | X (8 char) |
| EXTENSION | | X | X | X | X | X |
| FAILURES | | | | | | |
| I_INOCC | | X | X | X | X | X |
| I_OUTOCC | | X | X | X | X | X |
| INCALLS | | X | X | X | X | X |
| INCOMPLETE | | X | X | X | X | X |
| INTIME | | X | X | X | X | X |
| INTRVL | | X | X | X | X | X |
| ITN | | X | X | X | X | X |
| LOC_ID | R3V8 | X | X | X | X | X |
| LOGID | | X | X | X | X | X |

Communication server capabilities that impact CMS

| Trunk database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| MBUSYTIME | | X | X | X | X | X |
| O_ABNCALLS | | X | X | X | X | X |
| O_ACDCALLS | | X | X | X | X | X |
| O_OTHERCALLS | | X | X | X | X | X |
| OTHERCALLS | | X | X | X | X | X |
| OUTCALLS | | X | X | X | X | X |
| OUTTIME | | X | X | X | X | X |
| PRIORITY | | X | X | X | X | X |
| PRIORITY2-3 | | X | X | X | X | X |
| QUECOUNT | | X | X | X | X | X |
| QUETYPE | | X | X | X | X | X |
| QUETYPE2-3 | | X | X | X | X | X |
| ROW_DATE | | X | X | X | X | X |
| SHORTCALLS | | X | X | X | X | X |
| SPLIT | | X | X | X | X | X |
| SPLIT2-3 | | X | X | X | X | X |
| STARTED | | X | X | X | X | X |
| STARTTIME | | X | X | X | X | X |
| TKGRP | | X | X | X | X | X |
| TKSTATE | | X | X | X | X | X |
| VDN | | X | X | X | X | X |
| VECTOR | | X | X | X | X | X |

Trunk group database items

The following table lists the trunk group database items are supported by each of the Avaya communication server releases.

| Trunk group database item communication server cross-reference | | | | | | |
|--|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ABNCALLS | | X | X | X | X | X |
| ABNQUECALLS | | X | X | X | X | X |
| ABNRINGCALLS | | X | X | X | X | X |
| ABNVECCALLS | | X | X | X | X | X |
| ACD (index) | | X | X | X | X | X |
| ACDCALLS | | X | X | X | X | X |
| ACDCALLS_R1 | R3V9 | a | a | a | a | a |
| ACDCALLS_R2 | R3V9 | a | a | a | a | a |
| ADJUNCTOUT | | X | X | X | X | X |
| ALLINUSE | | X | X | X | X | X |
| ALLINUSETIME | | X | X | X | X | X |
| AUDIO | | X | X | X | X | X |
| BH_ABNCALLS | | X | X | X | X | X |
| BH_ACDCALLS | | X | X | X | X | X |
| BH_ALLINUSETIME | | X | X | X | X | X |
| BH_BUSYCALLS | | X | X | X | X | X |
| BH_DISCCALLS | | X | X | X | X | X |
| BH_INCALLS | | X | X | X | X | X |
| BH_INTIME | | X | X | X | X | X |
| BH_OABNCALLS | | X | X | X | X | X |
| BH_OACDCALLS | | X | X | X | X | X |

Communication server capabilities that impact CMS

| Trunk group database item communication server cross-reference | | | | | | |
|--|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| BH_OOTHERCALLS | | X | X | X | X | X |
| BH_OTHERCALLS | | X | X | X | X | X |
| BH_OUTCALLS | | X | X | X | X | X |
| BH_OUTTIME | | X | X | X | X | X |
| BH_STARTTIME | | X | X | X | X | X |
| BACKUPCALLS | | X | X | X | X | X |
| BUSYCALLS | | X | X | X | X | X |
| COMPLETED | | X | X | X | X | X |
| CONNECTCALLS | | X | X | X | X | X |
| DISCCALLS | | X | X | X | X | X |
| I_INOCC | | X | X | X | X | X |
| I_OUTOCC | | X | X | X | X | X |
| INBOUND | | X | X | X | X | X |
| INCALLS | | X | X | X | X | X |
| INCOMPLETE | | X | X | X | X | X |
| INTIME | | X | X | X | X | X |
| INTRVL | | X | X | X | X | X |
| MBUSY | | X | X | X | X | X |
| MBUSYTIME | | X | X | X | X | X |
| NUMINUSE | | X | X | X | X | X |
| O_ABNCALLS | | X | X | X | X | X |
| O_ACDCALLS | | X | X | X | X | X |
| O_OTHERCALLS | | X | X | X | X | X |
| OTHERCALLS | | X | X | X | X | X |
| OUTBOUND | | X | X | X | X | X |

| Trunk group database item communication server cross-reference | | | | | | |
|--|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| OUTCALLS | | X | X | X | X | X |
| OUTTIME | | X | X | X | X | X |
| ROW_DATE | | X | X | X | X | X |
| SETUPTIME | | X | X | X | X | X |
| SHORTCALLS | | X | X | X | X | X |
| SPLIT | | X | X | X | X | X |
| STARTTIME | | X | X | X | X | X |
| TKGRP | | X | X | X | X | X |
| TRANSFERRED | | X | X | X | X | X |
| TRUNKS | | X | X | X | X | X |
| VDN | | X | X | X | X | X |
| VECTOR | | X | X | X | X | X |

VDN database items

The following table lists which VDN database items are supported by each of the Avaya communication server releases.

| VDN database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ABNCALLS | | X | X | X | X | X |
| ABNCALLS1-10 | | X | X | X | X | X |
| ABNQUECALLS | | X | X | X | X | X |
| ABNRINGCALLS | | X | X | X | X | X |
| ABNTIME | | X | X | X | X | X |

Communication server capabilities that impact CMS

| VDN database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ACCEPTABLE | | X | X | X | X | X |
| ACD | | X | X | X | X | X |
| ACDCALLS | | X | X | X | X | X |
| ACDCALLS_R1 | R3V9 | a | a | a | a | a |
| ACDCALLS_R2 | R3V9 | a | a | a | a | a |
| ACDTIME | | X | X | X | X | X |
| ACTIVECALLS | | X | X | X | X | X |
| ACWTIME | | X | X | X | X | X |
| ADJATTEMPTS | | X | X | X | X | X |
| ADJROUTED | | X | X | X | X | X |
| ANSCONNCALLS1-10 | | X | X | X | X | X |
| ANSTIME | | X | X | X | X | X |
| ASA | R3V4 | X | X | X | X | X |
| ATAGENT | | X | X | X | X | X |
| BH_ABNCALLS | | X | X | X | X | X |
| BH_ACDCALLS | | X | X | X | X | X |
| BH_ACDTIME | | X | X | X | X | X |
| BH_BUSYCALLS | | X | X | X | X | X |
| BH_DISCCALLS | | X | X | X | X | X |
| BH_OTHERCALLS | | X | X | X | X | X |
| BH_STARTTIME | | X | X | X | X | X |
| BH_VDNCALLS | | X | X | X | X | X |
| BACKUPCALLS | | X | X | X | X | X |
| BSRPLAN | R3V6 | X | X | X | X | X |
| BUSYCALLS | | X | X | X | X | X |

| VDN database items communication server cross-reference | | | | | | |
|---|----------------------------|--------------------------|--------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| BUSYTIME | | X | X | X | X | X |
| CONNECTCALLS | | X | X | X | X | X |
| CONNECTTIME | | X | X | X | X | X |
| CONNTALKTIME | | X | X | X | X | X |
| DEFLECTCALLS | R3V6 | X R8.3 | X | X | X | X |
| DISCCALLS | | X | X | X | X | X |
| DISCTIME | | X | X | X | X | X |
| HOLDABNCALLS | | X | X | X | X | X |
| HOLDACDCALLS | | X | X | X | X | X |
| HOLDACDTIME | | X | X | X | X | X |
| HOLDCALLS | | X | X | X | X | X |
| HOLDTIME | | X | X | X | X | X |
| I_ARRIVED | R3V5 | X | X | X | X | X |
| ILN | | X | X | X | X | X |
| INCALLS | | X | X | X | X | X |
| INCOMPLETE | | X | X | X | X | X |
| INFLOWCALLS | | X | X | X | X | X |
| INPROGRESS | | X | X | X | X | X |
| INQUEUE | | X | X | X | X | X |
| INRING | | X | X | X | X | X |
| INTERFLOWCALLS | | X | X | X | X | X |
| INTIME | | X | X | X | X | X |
| INTRVL | | X | X | X | X | X |
| INVECTOR | | X | X | X | X | X |
| LOOKATTEMPTS | | X | X | X | X | X |

Communication server capabilities that impact CMS

| VDN database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| LOOKFLOWCALLS | | X | X | X | X | X |
| MAXOCWTIME | | X | X | X | X | X |
| MAXWAITING | | X | X | X | X | X |
| NETDISCCALLS | R3V6 | X | X | X | X | X |
| NETINCALLS | R3V6 | X | X | X | X | X |
| NETINTIME | R3V6 | X | X | X | X | X |
| NETPOLLS | R3V6 | X | X | X | X | X |
| NOANSREDIR | | X | X | X | X | X |
| NUMTGS | | X | X | X | X | X |
| OLDESTCALL | | X | X | X | X | X |
| OTHERCALLS | | X | X | X | X | X |
| OTHERTIME | | X | X | X | X | X |
| OUTFLOWCALLS | | X | X | X | X | X |
| OUTFLOWTIME | | X | X | X | X | X |
| PERIOD1-9 | | X | X | X | X | X |
| PERIODCHG | | X | X | X | X | X |
| PHANTOMABNS | R3V4 | X | X | X | X | X |
| RETURNCALLS | R3V4 | X | X | X | X | X |
| RINGCALLS | | X | X | X | X | X |
| RINGTIME | | X | X | X | X | X |
| ROW_DATE | | X | X | X | X | X |
| SERVICELEVEL | | X | X | X | X | X |
| SKILL1-3 | | EAS | EAS | EAS | EAS | EAS |
| SKILLACWTIME1-3 | | EAS | EAS | EAS | EAS | EAS |
| SKILLCALLS1-3 | | EAS | EAS | EAS | EAS | EAS |

| VDN database items communication server cross-reference | | | | | | |
|--|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| SKILLTIME1-3 | | EAS | EAS | EAS | EAS | EAS |
| SLVLABNS | R3V5 | X | X | X | X | X |
| SLVLOUTFLOWS | R3V5 | X | X | X | X | X |
| STARTTIME | | X | X | X | X | X |
| SVCLEVELCHG | | X | X | X | X | X |
| TRANSFERRED | | X | X | X | X | X |
| VDISCCALLS | R3V4 | X | X | X | X | X |
| VDN | | X | X | X | X | X |
| VECTOR | | X | X | X | X | X |

Vector database items

The following table lists which vector database items are supported by each of the Avaya communication server releases.

| Vector database items communication server cross-reference | | | | | | |
|---|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ABNCALLS | | X | X | X | X | X |
| ABNQUECALLS | | X | X | X | X | X |
| ABNRINGCALLS | | X | X | X | X | X |
| ABNTIME | | X | X | X | X | X |
| ACD | | X | X | X | X | X |
| ACDCALLS | | X | X | X | X | X |
| ACDCALLS_R1 | R3V9 | a | a | a | a | a |
| ACDCALLS_R2 | R3V9 | a | a | a | a | a |

Communication server capabilities that impact CMS

| Vector database items communication server cross-reference | | | | | | |
|--|----------------------|--------------------|--------------------|---------------------------|-------------------------------|---------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| ADJATTEMPTS | | X | X | X | X | X |
| ADJROUTED | | X | X | X | X | X |
| ANSTIME | | X | X | X | X | X |
| BACKUPCALLS | | X | X | X | X | X |
| BUSYCALLS | | X | X | X | X | X |
| BUSYTIME | | X | X | X | X | X |
| DEFLECTCALLS | R3V6 | X R8.3 | X | X | X | X |
| DISCCALLS | | X | X | X | X | X |
| DISCTIME | | X | X | X | X | X |
| GOTOCALLS | | X | X | X | X | X |
| GOTOTIME | | X | X | X | X | X |
| INCALLS | | X | X | X | X | X |
| INCOMPLETE | | X | X | X | X | X |
| INFLOWCALLS | | X | X | X | X | X |
| INPROGRESS | | X | X | X | X | X |
| INQUEUE | | X | X | X | X | X |
| INRING | | X | X | X | X | X |
| INTERFLOWCALLS | | X | X | X | X | X |
| INTIME | | X | X | X | X | X |
| INTRVL | | X | X | X | X | X |
| LOOKATTEMPTS | | X | X | X | X | X |
| LOOKFLOWCALLS | | X | X | X | X | X |
| NETDISCCALLS | R3V6 | X | X | X | X | X |
| NETPOLLS | R3V6 | X | X | X | X | X |
| NUMVDNS | | X | X | X | X | X |

| Vector database items communication server cross-reference | | | | | | |
|--|----------------------------|--------------------------|--------------------------|---------------------------------|-------------------------------------|---------------------------------|
| Database item | CMS version or later | Avaya DEFINITY® R8 | Avaya DEFINITY® R9 | Avaya Call Processing R10 | Communication Manager 1.1-2.1 | Communication Manager 3.0 |
| OTHERCALLS | | X | X | X | X | X |
| OTHERTIME | | X | X | X | X | X |
| OUTFLOWCALLS | | X | X | X | X | X |
| OUTFLOWTIME | | X | X | X | X | X |
| PHANTOMABNS | R3V4 | X | X | X | X | X |
| RINGCALLS | | X | X | X | X | X |
| RINGTIME | | X | X | X | X | X |
| ROW_DATE | | X | X | X | X | X |
| STARTTIME | | X | X | X | X | X |
| VDISCCALLS | R3V4 | X | X | X | X | X |
| VECTOR | | X | X | X | X | X |

Communication server features and capabilities and their impact on CMS data

The following features and communication server capabilities have an impact on how the CMS tracks data from the communication server and on how the CMS creates the database item information for reports.

The communication server features and capabilities that can impact CMS tracking of data are dealt with in alphabetical order; they include:

- [Abandoned calls](#) on page 87
- [Adjunct-placed calls and adjunct-routed calls](#) on page 87
- [Agent state tracking at login](#) on page 88
- [Agents in multiple splits/skills](#) on page 88
- [Audio difficulty](#) on page 89
- [Average Speed of Answer \(ASA\)](#) on page 89
- [Best Service Routing](#) on page 90
- [Avaya Business Advocate](#) on page 90
- [Call handling preference](#) on page 91
- [Call pickup](#) on page 91
- [Conference tracking](#) on page 92
- [“converse” vector command](#) on page 92
- [Direct agent calling](#) on page 92
- [Expanded Agent Capabilities](#) on page 93
- [Forced disconnect](#) on page 93
- [Forced multiple call handling](#) on page 94
- [Go to vector command](#) on page 94
- [Hold tracking](#) on page 94
- [Location](#) on page 94
- [Look-ahead interflow calls \(BSR and NCR\)](#) on page 95
- [Move agent while staffed](#) on page 95
- [Multiple call handling](#) on page 96
- [Multiple split/skill queuing](#) on page 96
- [Outbound Call Management \(OCM\)](#) on page 97

- [Personal call tracking](#) on page 98
- [Phantom-abandon calls](#) on page 99
- [Redirect on No Answer](#) on page 100
- [Reserve Agent Work Time Tracking](#) on page 100
- [Ringing](#) on page 108
- [Skill state](#) on page 108
- [Timed ACW](#) on page 108
- [Time/duration tracking](#) on page 108
- [Transfer tracking](#) on page 108
- [Transferred and conferenced calls](#) on page 109
- [Trunk No Answer Timeout](#) on page 109
- [Universal Call Identifier](#) on page 109
- [VDN active calls](#) on page 110
- [Vector Disconnect Timer](#) on page 110
- [Wait Answer Supervision Timer](#) on page 110

Abandoned calls

In general, any call that hangs up before an agent or station answers is an abandoned call. VDN calls, whether they are ACD calls or not, that are routed to extensions and are then abandoned are counted as abandoned calls for the VDN. For more information see [Phantom-abandon calls](#) on page 99.

Adjunct-placed calls and adjunct-routed calls

For communication servers with the ASAI feature, CMS tracks outbound calls that are placed by an adjunct processor or host computer on behalf of an agent and adjunct-routed calls. Database items that start with O_ track outbound split/skill calls and database items that contain ADJ track adjunct-routed calls. Adjunct-placed outbound split/skill calls are also included as part of ACD database items, such as ACDCALLS, ACDTIME, and ACWTIME. Inbound split/skill calls can be calculated as ACDCALLS minus O_ACDCALLS.

Agent state tracking at login

Until it is notified by the communication server, CMS does not know what state agents are in. The communication server notifies CMS immediately after an agent logs in or right after the link to the communication server is operational after it was out of service. The time the agent spends in this “state” is tracked as I_OTHERTIME, I_OTHERSTBYTIME and TI_OTHERTIME and the agent's state displays as OTHER on reports.

The time between logging in and moving to the AUX state depends on the time that it takes for the agent who is logging in to release the call or go on-hook, or for the communication server to time the call out. This time is typically between 5 and 10 seconds.

Agents in multiple splits/skills

CMS requires agents to log in to multiple splits/skills using the same login ID for all splits/skills. This requirement allows CMS to track the agent as a single person and to coordinate the data for that agent.

An agent who is logged in to multiple splits/skills is tracked as a single agent, not as one agent for each split/skill. For non-EAS ACD operation, agents must log in with the same login ID for all splits. “TI_” database items have been added to indicate the time that the agent spent in various work states independent of the split/skill in which the agent is working. These are interval-based items.

When an agent is logged in to multiple splits/skills, the items counting AUXIN/AUXOUT calls and time are usually associated with the split/skill that the agent has been logged into the longest. In other words, the first split the agent logged into. However, when an agent puts a split/skill or direct agent ACD call on hold and then makes an AUXOUT call, the outgoing call and its talk time are counted for the split/skill that is associated with the ACD call.

Real-time reports

Real-time reports assume that agents can be in only one of the following states: AVAIL, ACD, ACW, AUX, DACD, DACW, RINGING, UNKNOWN, OTHER, or UNSTAFFED. When an agent logs into multiple splits/skills, the split/skill numbers are shown on the reports for the states that are associated with the call. For example, if an agent logged into split/skill 1 and split/skill 2 and answered an ACD call for split/skill 2, then the split/skill number shown in the standard real-time reports is “2.”

Splits shown on real-time reports

As long as the agent is not on a call or the agent is in AUX and is available in at least some splits, real-time reports show all of the splits in which the agent is available. For skills, the agent cannot be available in some skills and not available in others unless Multiple Call

Handling (MCH) is active or the agent is a reserve agent in some of the skills. The Skill Status report shows all of the agent's login skills. If an ACD call is ringing the agent's telephone, the real-time report shows the RINGING state. If a personal call is ringing at the agent's telephone, the real-time report shows the OTHER state. No split/skill is shown for the AUX and UNKNOWN states because these states are not split/skill related unless the agent is on a call (AUXIN or AUXOUT), in which case the split/skill is shown in the report. The agent is shown as being in AUX only if the agent is in AUX in all splits/skills.

Real-time split/skill reports

With real-time split/skill reports, if an agent is available in split 1 and in AUX in split 2 and the Split/Skill report that displays both splits is requested then the report shows the agent is AVAIL in split 1 and OTHER in split 2.

Average Speed of Answer (ASA)

Avaya communication servers calculate a rolling Average Speed of Answer (ASA) for splits/skills and for VDNs on real-time reports. This ASA can be used in vector conditionals to determine where to queue calls.

The ASA for a split/skill includes the time that is spent in the split/skill queue and the time ringing at an agent. The ASA for a VDN includes the time spent in vector processing, the time spent in queue, and the time ringing for the VDN associated with the call when it was answered. This server-generated, rolling ASA is a running, weighted average calculation. In general, the ASA will not match the average speed of answer on CMS.

Audio difficulty

CMS records the trunk associated with audio difficulty for personal calls if the trunk group is measured. Without personal call tracking, audio difficulty is restricted to ACD calls.

Best Service Routing

Best Service Routing (BSR) is available with Avaya communication servers. BSR allows calls to be balanced at a single site or between multiple sites. BSR is enhanced multisite routing that provides call vectoring functions that build upon the Look-Ahead Interflow feature to route a call to the “best” split/skill on a single communication server or to the “best” split/skill in a network of communication servers. The “best” split/skill is defined as the local split/skill or remote split/skill that offers the shortest waiting time for the call in a call surplus (calls queued) situation for the application. The waiting time is calculated by using the Expected Wait Time (EWT) predictor of the communication server, and can be adjusted by the user. In a situation where agents are idle, the “best” split/skill is determined on the basis of the assigned available agent strategy. BSR data is tracked in the vector, VDN, and call history tables.

Avaya Business Advocate

Avaya Business Advocate is available on Avaya communication servers. Avaya Business Advocate introduced database tracking items for CMS in the following areas:

- **Skill State** — Skills can now be in one of four states (unknown, normal, overload 1 or overload 2), based on the EWT threshold. Time spent in each state except “unknown” is tracked in the split/skill tables. The state is unknown when the link is down, or the split is non-EAS, or when a new skill is added and the state message has not yet arrived.
- **Reserve Agent** — Agents can have a skill level of Reserve 1 or Reserve 2 that corresponds to skill states overload 1 and overload 2. Only when the skill is in an overload state will the appropriate reserve agents serve that skill. These agents have a special agent “service” role.
- **Agent Counts** — The number of agents that are in various states is stored in the split/skill tables by agent type. Reserve agents are stored in the R1xxx and R2xxx database items. Top agents are stored in the Txxx database items and flex agents are stored in Fxxx database items. Flex agents can have a role of roving, backup, or allocated.
- **Agent Time in Skill** — Agents’ time spent logged into a skill, whether in the Available work mode, on an ACD call, or in the ACW work mode. Non-ACD time in standard skills is as follows: agents with the tracked skill as the top skill use 100%, whereas agents who are percent allocated use the same percentage for both ACD and non-ACD time. Backup, roving, or reserve agents track none of their non-ACD time toward this skill.
- **Agent Role** — The ROLE database item in the agent tables describes how an agent participates in a skill. The agent’s role is based on both the agent’s skill level, from 1 to 16, and call handling preference, which is skill level, greatest need, or percent allocation. Agents with a reserve skill have a role of reserve. Non-EAS agents and agents with greatest need call handling preference have a role of roving. Top agents have a role of top. Skill level call handling preference agents who are neither top or

reserve have a role of backup. Agents who are percent allocated have a role of allocated.

- Reserve Agents ACD Calls — ACD calls that are received by Reserve 1 and Reserve 2 agents can be tracked by the ACDCALLS_R1 and ACDCALLS_R2 real-time and historical database items.
- Reserve Agent Work Time Tracking - This feature provides real time and historical tracking of agents administered as Reserve Level 1 and Reserve Level 2. Reserve agents are eligible to take calls from a reserve skill only when that skill is in an overload state. Essentially, when the skill is not in an overload state, reserve agents who are logged into that skill and not needed are “standing by”. CMS tracks this reserve agent “standby time” separately from the time that the reserve agent is actively working in the skill. Only the time spent by reserve agents actively working in the overloaded skill is added to the skill’s STAFFTIME.

Call handling preference

The agent’s call handling preference determines which call the agent receives when there are calls waiting for more than one of the agent’s skills. It is also used to help determine which agent receives a call when multiple agents are available in a given skill. The possible call handling preferences are as follows:

- Skill level - An agent who is assigned the Skill Level call handling preference receives calls first on the basis of the level assigned to the skill and then on the basis of the queue priority and wait time of the call. This capability is available on Avaya communication servers with the EAS feature.
- Greatest need - An agent who is assigned the Greatest Need call handling preference receives calls on the basis of queue priority and the current wait time or predicted wait time of the call, not on the basis of the level that is assigned for the skill. This capability is available on Avaya communication servers with the EAS feature.
- Percent allocation - An agent who is assigned the Percent Allocation call handling preference receives calls on the basis of a comparison of the times that are spent on calls for each skill level and the percentage of time that the agent is allocated for each skill level. This capability is available on Avaya communication servers with the EAS feature.

Call pickup

CMS tracks ACD calls that are answered by an agent using the Call Pickup feature as AUXIN calls.

Conference tracking

CMS tracks conferenced calls. Agents who transfer a call by conferencing and then dropping off are credited with a conference, not a transfer.

“converse” vector command

The “converse” vector command is available on Avaya communication servers.

The “converse” vector command integrates Voice Response Units (VRUs) and the Vectoring feature. The “converse” command allows voice-response scripts to be executed while, for example, a call waits in queue. This command also allows data to be passed between the communication server and a VRU or from a VRU through the communication server to an ASAI adjunct processor.

There is no vector or VDN tracking for this command. If the VRU ports are administered as a measured split/skill, then agent and split/skill tracking is available.

Direct agent calling

Direct agent calls are tracked separately from other ACD calls in the CMS database tables. Because direct agent calls are not split/skill calls but rather are calls to a specific agent, most of the direct agent data are collected in the agent tables in items starting with DA_ or I_DA. Direct agent calls are counted as ACD calls in trunk, trunk group, VDN, and vector tables.

Direct agent data in reports

Reports can be customized to include direct agent data. In the real-time split/skill table, the number of agents on direct agent calls and the number of agents in ACW that is associated with direct agent calls are collected, but they are subsets of the number of agents in the OTHER agent state; that is, they are doing work but not for the split/skill. Only the OTHER value appears on standard real-time reports. The number of direct agent calls that are queued and ringing appears on the Queue/Agent Summary report.

Communication server-specific capabilities

A direct agent call can be initiated by an adjunct. For Avaya communication servers with the EAS feature, a direct agent call can be initiated by dialing the agent’s login number or through the “route to number” vector command. The call is treated like an ACD call and is delivered to the agent in front of any split/skill ACD calls queue.

Expanded Agent Capabilities

The Expanded Agent capabilities feature allows EAS agents to have up to 60 skills assigned. Each skill can be assigned a level from 1 to 16, where 1 is the highest level and 16 is the lowest. The numeric level, from 1 to 16, replaces the skill type, p for primary or s for secondary, that is used in earlier communication server releases. Agents can have a call handling preference that is based either on the skill level, on the greatest need, or percent allocation. A skill level call handling preference means that agents service the calls that are waiting for their highest level skill before servicing the calls that are waiting for any lower level skills. A greatest need call handling preferences means that agents serve the highest-priority, oldest call waiting for any of their skills, or percent allocation, based on the percent distribution of calls among the agent's skills, regardless of the agent's skill level in that skill. Percent Allocation call handling preference means that agents receive calls based on meeting an allocated percent for each skill.

The expanded agent capabilities feature also makes it possible to specify a skill that is used only for direct agent calls. Specifying a direct agent skill makes it possible to control when direct agent calls are delivered in relation to ACD calls. For example, if the direct agent skill has a skill level of 1 and the agent is assigned the skill level call handling preference, then direct agent call are always answered first. Also, if the direct agent skill has a skill level of 1 and the agent is assigned the greatest need call handling preference, then the direct agent calls will be answered on the basis of priority and time-in-queue.

The "top skill" can be useful in EAS implementations that use skill level call handling preference for the agents. An agent's first-administered, highest level skill is the agent's top skill because the agent is most likely to handle calls for this skill. Agents in a skill that is their "top skill" are "Top Agents" and are considered to be the most reliable and knowledgeable agents for that skill.

The expanded agent capabilities on the Avaya communication server include new options for Most Idle Agent (MIA) call distribution. The new options allow selection of MIA distribution across skills, rather than for each skill, and selection of whether agents in ACW are or are not included in the agent free list. These options have no direct impact on CMS because CMS does not track the most idle agent.

Forced disconnect

A call is counted as a forced disconnect call whenever the forced disconnect vector step is executed. The call is counted as a disconnected call even if the caller hangs up before listening to the entire announcement. A call that is dropped by the communication server because the vector disconnect timer timed out or reached the end of vector processing without being queued is also recorded as a forced disconnect call.

Forced multiple call handling

The forced multiple call handling feature makes it possible for an ACD call to ring at an agent's telephone even if that agent is already talking on an ACD call. The agent continues to accrue talk time until the agent puts the current call on hold or releases it.

Go to vector command

When a "go to vector" command is executed, an outflow and a "go to call" are counted for the first vector and an inflow is counted for the second vector. In addition, the timing and statistics that are associated with the first vector for that call stop and then start for the second vector. The call remains in the original VDN, however, and tracking in that VDN continues.

Hold tracking

CMS tracks and reports the hold state for all calls that are put on hold. CMS is notified by the communication server when an agent puts a call on hold.

Location

A location, or site, refers to a physical location. This can be a building, a section of a building, or it can be what was once a separate ACD before the ATM WAN capability was used to merge separate ACDs with other ACDs into one large call center. A location is typically assigned one location ID, although more than one location ID can be assigned. A location, despite being part of a larger call center, may continue to have sole responsibility for handling certain 800 numbers. A location may also share responsibility for handling an 800 number by having some of its agents be part of a larger split/skill that includes agents from other locations.

Location ID for agents

An agent location ID is the ID of the agent terminal to which the agent is logged in. It is associated with the Avaya communication server port network ID to which the agent terminal is attached. An agent cannot be assigned a location ID for reporting purposes until he or she logs into the ACD. This capability is available on Avaya communication servers with ATM. This capability is supported by the LOC_ID database item in the CMS.

Location ID for trunks

The location ID for a trunk is the communication server network location ID associated with a trunk. A location ID is not directly assigned to a trunk; instead, it is assigned to a port network on the Change Cabinet X form. Therefore, each trunk that has an equipment location that belongs to that port network is associated with that port network's location ID. The location ID for trunks is supported by the LOC_ID database item in the CMS.

Look-ahead interflow calls (BSR and NCR)

CMS tracks look-ahead interflow calls and Best Service Routing (BSR) interflow calls that are attempted and completed using database items that start with LOOK.

Network Call Redirection (NCR) attempts that are successful are counted as DEFLECTCALLS. NCR is available with DEFINITY R8.3 and later Avaya communication servers.

Look-ahead interflow calls, BSR interflow calls, and NCR calls are subsets of interflow calls.

Move agent while staffed

Avaya communication servers support moving a staffed agent between splits or changing the skill assignments for staffed agents. If the agent has any call on the telephone or is in ACW, the move cannot take place immediately and is pending until the agent calls have been terminated or the agent changes out of the ACW mode. CMS provides two real-time database items in the agent data, MOVEPENDING and PENDINGSPILT. These database items can be used in custom reports to provide information about whether agents have moves pending and, if so, the split/skill to which they are being moved. Note that in the case in which the agent's skills are being changed and the change adds more than one skill, the PENDINGSPILT item shows the first skill that is being added. It is also possible for MOVEPENDING to be set but for PENDINGSPILT to be blank (or 0). This can happen when the link to the communication server comes up and a move is pending for an agent. CMS will be notified by the communication server that the move is pending, but PENDINGSPILT will not be set.

Multiple call handling

The multiple call handling (MCH) feature allows an ACD agent to put a call on hold and push the Auto-In or Manual-In key to take another ACD call. CMS tracks the hold state as a call state, not an agent state. This means that hold time is counted for each call. For example, an agent who places two calls on hold for 5 minutes to answer a third call accrues 10 minutes hold time for the two calls in only 5 minutes of real clock time.

Multiple split/skill queuing

Calls can be queued to as many as three splits/skills simultaneously. For the first split/skill to which a call queues, CMS counts an answer, outflow (leaves vector processing or is answered by an agent in another split/skill), or abandon. For the second or third splits/skills to which a call queues, CMS counts an answer and an inflow if the call is answered in that split/skill. If the call is answered in another split, if the call outflows, or if the caller abandons, CMS counts the call as dequeued.


Note:

If a call rings in a second or third split and then abandons, an inflow and abandon are counted for that split; an outflow or dequeue is counted for the other splits.

Multiple split/skill queueing example

In the following Multiple-Split/Skill Queuing example, the call queues to split/skill 1 first, then queues to split/skill 2 after 15 seconds. After another 10 seconds, the call queues to split/skill 3. The call is now queued to splits/skills 1, 2, and 3 at the same time. See the

example for disposition of the call for all three splits if the call abandons, is answered, or is routed to a VDN.



| Call disposition | Split/skill 1 | Split/skill 2 | Split/skill 3 |
|--------------------------------------|----------------------------------|---|-------------------------------|
| Abandoned from queue | ABNCALLS ABNTIME = 30 | DEQUEUECALLS DEQUETIME = 15 | DEQUEUECALLS DEQUETIME = 5 |
| Split/skill 2 answered | OUTFLOWCALLS OUTFLOWTIME = 30 | ACDCALLS ANSTIME = 15 INFLOWCALLS | DEQUEUECALLS DEQUETIME = 5 |
| Route to VDN | OUTFLOWCALLS OUTFLOWTIME = 30 | DEQUEUECALLS DEQUETIME = 15 | DEQUEUECALLS DEQUETIME = 5 |
| Abandoned from ringing split/skill 2 | OUTFLOWCALLS OUTFLOWTIME = 30 | ABNCALLS ABNTIME = 15 | DEQUEUECALLS DEQUETIME = 5 |

Outbound Call Management (OCM)

Outbound call management (OCM) calls to splits/skills are included as a subset of the ACD call database items (talk time, ringing, ACW, and so on). OCM calls also have their own database items, which start with O_ in the agent, split/skill, trunk, and trunk group tables. Inbound split/skill calls can be calculated as ACDCALLS minus O_ACDCALLS. See “Adjunct-Placed and Adjunct-Routed Calls” for more information.

Personal call tracking

CMS tracks hold time, transfers, and conferences for personal calls (non-ACD or extension calls).

Tracking of AUXIN and AUXOUT time

CMS separately tracks the AUXIN and AUXOUT time for calls made and received when an agent has an ACD call on hold. These calls are now distinguished from time that is spent on other AUXIN or AUXOUT calls.

Tracking for “Route To” calls

In the VDN database tables, connect calls and abandoned calls and their times are tracked for calls that “route to” an extension. Call pickup calls are tracked as personal calls, even if an ACD call is picked up by an agent in the same split/skill.


Data tracking capabilities

Personal call tracking offers the following data-tracking capabilities:

- Data is available for calls on hold, time for calls on hold, and calls abandoned from hold.
- CMS split and agent data reflect calls that are made while another call is on hold.
- Agents who place calls on hold return to their previous state before the call unless the previous state was AVAIL. If an agent was in the AVAIL state, the agent is placed in the OTHER state until the agent dials a valid number (if the number dialed is invalid, the agent remains in OTHER), reconnects to the held call, or the held call abandons. When the agent reconnects to the held call, the agent returns to the original state for the call.
- Agents do not have a HOLD state. Hold time is associated with a call that is placed on hold. Agent states reflect the current activity of the agent.
- HOLDTIME is the time that the call spent on hold. HOLDCALLS is the number of calls that were placed on hold at least once, and HOLDABNCALLS is the number of calls abandoned while on hold.
- I_OTHERTIME is the time during the collection interval that the agent was doing other work. This includes time while in the Auto-In or Manual-In mode during which the agent put a call on hold and performed no further action, the agent placed a call or activated a feature, or a personal call rang with no further activity. When an agent dials a valid extension, the agent's state changes to AUXOUT if the agent was in AUX or OTHER, or to ACWOUT if the agent was in ACW.

Hold tracking for supervisor assist example

The following figure shows how CMS tracks hold calls.



Phantom-abandon calls

In countries where central offices do not provide the communication server with disconnect supervision, all calls with talk times that are less than an administrable threshold can be counted as abandoned calls. CMS supports a phantom-abandon call timer that can be administered to count calls with talk times less than 10 seconds as phantom-abandon calls.

Phantom-abandon call timer

The phantom-abandon call timer can be set from 1 to 10 seconds. Any calls for which the total talk time or connect time is less than the set number of seconds are pegged as PHANTOMABNS, instead of ACDCALLS. The abandon time for phantom calls is as follows:

- For splits, from the time that the call queues until the agent or answering station hangs up.
- For VDNs, from the time the call encounters the VDN until the agent or answering station hangs up.
- For vectors, from the time the call enters the vector until the agent or answering station hangs up. When a call leaves a vector by means of a “route to split” command, the call is not pegged as an outflow and can be pegged as a phantom- abandon call if the call duration is shorter than the administered phantom-abandon time.

PHANTOMABNS database item

The database item PHANTOMABNS records the total number of such calls. Also, these calls are counted as abandoned calls (ABNCALLS) rather than answered calls (ACDCALLS). The abandon time for these calls is equivalent to the time elapsed when the agent released the call.

Phantom-abandon call timer not enabled

When the phantom-abandon call timer is not enabled, short ACD calls are not counted as phantom-abandons, and the values of the PHANTOMABNS database items are 0.

Phantom-abandon exceptions

Any call that is put on hold, transferred, or conferenced is not recorded as a phantom-abandon, even if its duration is less than the setting of the phantom-abandon call timer.

Redirect on No Answer

When a ringing call times out, the call can be requeued to the same split/skill or to a Vector Directory Number (VDN) by the Redirect on No Answer (RONA) feature. When redirected to the same split/skill, an outflow and an inflow are counted for the split/skill. Thus, the redirected call appears as two offered calls to the split/skill. The database item NOANSREDIR is also incremented. The number of unique calls offered to the split/skill can then be calculated by subtracting the value of NOANSREDIR from CALLSOFFERED.

Note:

This assumes that the split/skill is set up so that normal split/skill calls do not requeue to the same split/skill except through the RONA feature. If they can cover back to the same split/skill, each call that does this is counted as an outflow and inflow to that same split/skill. In this case, NOANSREDIR is not incremented.

When a ringing call times out and is routed to a VDN an outflow and NOANSREDIR are incremented.

Reserve Agent Work Time Tracking

The Reserve Agent Work Time Tracking feature provides real time and historical CMS tracking of agents administered as Reserve Level 1 agents and Reserve Level 2 agents. Reserve agents are assigned and administered using the Avaya Business Advocate Service Level Supervisor feature.

Avaya Business Advocate Service Level Supervisor provides options to automate staffing during call center operation. One of these options is the ability to assign reserve agents and overload thresholds to skills to determine when those reserve agents will be activated.

These features simplify call center management and eliminate the need for moving agents from skill to skill to ensure coverage as call conditions change. The Reserve Agent Work

Time Tracking feature provides new split/skill and agent database items to help the call center manager understand the utilization of reserve agents, including:

- The portion of a particular skill's work that was performed by Reserve Agents
- The amount of an agent's time that was spent doing Reserve Agent work

Reserve agents are eligible to take calls from a reserve skill only when that skill is in overload 1 or 2. When the skill returns to normal, calls from that skill are not sent to reserve agents.

Essentially, when the skill is not in overload 1 or 2, reserve agents who are logged into that skill and not needed are "standing by." CMS tracks this reserve agent "standby time" separately from the time that the reserve agent is actively working in the skill. Reserve agents' standby time is not considered STAFFTIME for the skill. Only the time spent by reserve agents actively working in the overloaded skill is added to the skill's STAFFTIME.

CMS Reserve Agent Work Time Tracking considers reserve agents staffed only when activated. You can assign reserve agents so that they can assist with skills that might become overloaded during peak times. Reserve skills can be assigned in addition to an agent's standard skills or you can assign them to an agent who would not handle any calls unless contingency operations are in effect.

For best results in tracking the activities of agents with both standard skills and reserve skills, the standard skills should be administered first on the agent's EAS login ID.

For more information about the Avaya Business Advocate Service Level Supervisor feature and required communication server administration for Reserve Agents, see the Avaya Business Advocate User Guide.

STAFFTIME

STAFFTIME includes only the time that agents spend actively working in a skill. This approach provides a better idea of the number of agents required to handle the work for the skill.

The calculation for Average Positions Staffed for a skill uses the total accumulated STAFFTIME of all Reserve Level 1, Reserve Level 2, and Regular (Skill Level 1-16) agents who were staffed in the skill.

Reserve Level 1 and Reserve Level 2 agents do not accumulate STAFFTIME unless the skill is in overload 1 or 2. For example, if two regular agents and one Reserve 1 agent are staffed in Skill 1 and the skill was in overload 1 for 15 minutes, the accumulated STAFFTIME would be 75 minutes. The average positions staffed is 2.5:

$$(I_STAFFTIME) / (INTERVAL * 60)$$
$$((30 + 30 + 15) * 60) / (30 * 60) = 2.5$$

Reserve Agent Work Time Tracking database items

The Split/Skill database items for the Reserve Agent Work Time Tracking feature are:

| | | |
|---------------|--------------------|------------------|
| I_ACDTIME_R1 | I_OTHERTIME_R1 | I_AUXSTBYTIME_R1 |
| I_ACDTIME_R2 | I_OTHERTIME_R2 | I_AUXSTBYTIME_R2 |
| I_ACWTIME_R1 | I_AUXTIME_R1 | R1OTHERSTBY |
| I_ACWTIME_R2 | I_AUXTIME_R2 | R2OTHERSTBY |
| I_RINGTIME_R1 | I_OTHERSTBYTIME_R1 | R1INAUXSTBY |
| I_RINGTIME_R2 | I_OTHERSTBYTIME_R2 | R2INAUXSTBY |

The Agent database items for the Reserve Agent Work Time Tracking feature are:

| |
|-----------------|
| RSV_LEVEL |
| I_OTHERSTBYTIME |
| I_AUXSTBYTIME |

NOTE: The Reserve Agent Work Time Tracking feature database items are available in Avaya Business Advocate Service Level Supervisor working with CMS.

For more information see [Dictionary of CMS database items](#) on page 111.

Real-time Split/Skill Status items

The following items are included in the Real Time Split/Skill tables to provide real time status of Reserve Agents:

- R1OTHERSTBY – The number of Reserve Level 1 Agents who are logged in and available but in standby because the Skill State is Normal. The number of Reserve Level 1 Agents in R1OTHERSTBY is not included in R1OTHER. Reserve Level 1 Agents in R1OTHERSTBY are not considered staffed, therefore, are not included in R1STAFFED or STAFFED.
- R2OTHERSTBY – The number of Reserve Level 2 Agents who are logged in and available but in standby because the Skill State is Normal. The number of Reserve Level 2 Agents in R2OTHERSTBY is not included in R2OTHER. Reserve Level 2 Agents on R2OTHERSTBY are not considered staffed, therefore, are not included in R2STAFFED or STAFFED.
- R1INAUXSTBY – The number of Reserve Level 1 Agents in AUX Work in standby because the Skill State is Normal. The number of Reserve Level 1 Agents in R1INAUXSTBY is not included in R1INAUX, R1STAFFED, or STAFFED.

- R2INAUXSTBY – The number of Reserve Level 2 Agents in AUX Work in standby because the Skill State is Normal. The number of Reserve Level 2 Agents in R2INAUXSTBY is not included in R2INAUX, R2STAFFED, or STAFFED.

Because Reserve Level Agents are considered staffed only when active, the total number of Reserve 1 Agents logged in can be obtained as follows:

- Total R1 Agents Logged In = R1STAFFED + R1OTHERSTBY + R1INAUXSTBY
- Total R2 Agents Logged In = R2STAFFED + R2OTHERSTBY + R2INAUXSTBY

Historical Split/Skill database items

The determining factor for tracking Reserve Level 1 and Reserve Level 2 agent time at the skill level is the condition of the skill. The database items added to the Split/Skill tables track the amount of call-related time and non-call-related time in a skill that can be attributed to Reserve Level 1 or Reserve Level 2 positions.

Note:

The Split/Skill database items that are related to the Reserve Agent Work Time Tracking feature are all interval-based items. Interval-based data items are typically used to calculate percentages, such as percentage of time doing ACD related work for the skill or percentage of time in AUX work.

Tracking Reserve Agents time when the skill is not in overload 1 or 2

When the skill has not exceeded the overload 1 or 2 threshold the time for Reserve Agents in the skill is tracked as:

- I_OTHERSTBYTIME_R1 or I_OTHERSTBYTIME_R2
I_OTHERSTBYTIME_R1 or I_OTHERSTBYTIME_R2 tracks the length of time that Reserve Agents spend logged in and not in AUX while in standby for the current skill. This includes the time that Reserve Agents spend working on calls for other skill, while in standby in the current skill.
- I_AUXSTBYTIME_R1 or I_AUXSTBYTIME_R2
Tracks the length of time that Reserve Agents spend in AUX work while in standby for the current skill. This ensures that the skill does not accumulate I_AUXTIME for agents who are not contributing to the work being done for the current skill.

Tracking Reserve Agents when the skill is in Over Threshold 1 or 2 condition

When the skill is in overload 1 or 2, the active work time for Reserve Agents in the skill will be tracked as follows:

- ACD call-related time will be tracked as I_ACDTIME_R1/R2, I_ACWTIME_R1/R2 and I_RINGTIME_R1/R2. This tracking continues if the skill changes from overload 1 or 2 back to Normal (until the ACD call and associated ACW work is completed).

Communication server capabilities that impact CMS

- I_OTHERTIME_R1 or R2 is the time spent by Reserve Agents doing work for another skill (while activated by this skill).
- I_AUXTIME_R1 or R2 is the length of time spent by Reserve Agents in AUX while activated by this skill. I_AUXTIME_R1 and R2 database items include all AUX related time regardless of direction and AUX reason code.

Non-reserve Split/Skill Database Items

The following Standard Split/Skill time tracking database items include active reserve time:

- I_ACDTIME includes I_ACDTIME_R1 and I_ACDTIME_R2
- I_ACWTIME includes I_ACWTIME_R1 and I_ACWTIME_R2
- I_RINGTIME includes I_RINGTIME_R1 and I_RINGTIME_R2
- I_AUXTIME includes I_AUXTIME_R1 and I_AUXTIME_R2 (does not include I_AUXSTBYTIME_R1 or I_AUXSTBYTIME_R2)
- I_OTHERTIME includes I_OTHERTIME_R1 and I_OTHERTIME_R2 (does not include I_OTHERSTBYTIME_R1 or I_OTHERSTBYTIME_R2)
- I_STAFFTIME = I_AVAILTIME + I_ACDTIME + I_ACWTIME + I_AUXTIME + I_RINGTIME + I_OTHERTIME

NOTE: The time that Reserve Agents spend logged into a skill but not active is not included in the overall STAFFTIME for the skill.

If necessary, you can create a custom calculation to add the time that agents spend logged into a skill but not active into I_STAFFTIME. For example:

$$\text{Total Reserve Stafftime} = \text{I_STAFFTIME} + \text{I_OTHERSTBYTIME_R1} + \text{I_AUXSTBYTIME_R1} + \text{I_OTHERSTBYTIME_R2} + \text{I_AUXSTBYTIME_R2}$$

The following diagram shows the database items included in the Total Reserve Stafftime calculation:

Total Reserve Stafftime

```
|__I_STAFFTIME
|  |__I_AVAILTIME
|  |__I_ACDTIME
|  |  |__I_ACDTIME_R1
|  |  |__I_ACDTIME_R2
|  |__I_ACWTIME
|  |  |__I_ACWTIME_R1
|  |  |__I_ACWTIME_R2
|  |__I_RINGTIME
|  |  |__I_RINGTIME_R1
|  |  |__I_RINGTIME_R2
|  |__I_OTHERTIME
|  |  |__I_OTHERTIME_R1
|  |  |__I_OTHERTIME_R2
|  |__I_AUXTIME
|  |  |__I_AUXTIME_R1
|  |  |__I_AUXTIME_R2
|__I_OTHERSTBYTIME_R1
|__I_OTHERSTBYTIME_R2
|__I_AUXSTBYTIME_R1
|__I_AUXSTBYTIME_R2
```

Agent database items

Agent time for Reserve Level 1 and Reserve Level 2 Agents is not broken down into separate database items. Because the agent tables create records for each of the skills that an agent logs into, three database items are used to track Reserve Agent Work Time:

- RSV_LEVEL provides a way to separate the time an agent spends working as Reserve Level 1 or Reserve Level 2 from the time the agent spends working as a regular Skill Level 1-16 agent. At login, CMS records the agent's Reserve Level for the skill. Acceptable values for RSV_LEVEL are 0 for a non-reserve agent, 1 for a Reserve Level 1 Agent, and 2 for a Reserve Level 2 Agent.

Communication server capabilities that impact CMS

The following database items are used to track the time that an agent spends logged into a skill and in standby:

- I_OTHERSTBYTIME is the time accumulated by an agent who is logged into and available in a skill as Reserve Level 1 or Reserve Level 2 but in standby. When the skill is in overload 1 or 2, the agent stops accumulating I_OTHERSTBYTIME, receives the ACD call, and begins accumulating time for the appropriate state (i.e., I_ACDTIME, I_RINGTIME, and I_ACWTIME).
- I_AUXSTBYTIME is the time that an agent spends in AUX Work while logged into a skill that is Normal.

Note:

Reserve Agents are not considered staffed unless activated, so I_OTHERSTBYTIME and I_AUXSTBYTIME are not included in I_STAFFTIME for the agent.

Tracking Reserve Agents when a skill is in a Normal condition

When a skill is Normal, the individual time a Reserve Agent spends for that skill is tracked as:

- I_OTHERSTBYTIME – The time that an agent spends logged into the skill as Reserve Level 1 or Reserve Level 2 but is in standby (any state except AUX).
- I_AUXSTBYTIME – The time that an agent spends logged into the skill as Reserve Level 1 or Reserve Level 2 and is in AUX Work while in standby.

Tracking Reserve Agents when the skill is in Over Threshold 1 or 2 condition


When the skill is in overload 1 or 2, tracking of the individual Reserve Agent's time for that skill will be consistent with the tracking of a Regular Agent's time. For example:

- ACD call related time in the skill will be tracked as I_ACDTIME, I_ACWTIME, I_RINGTIME.
- I_OTHERTIME – The time that the agent spends working in another skill when activated in this skill.
- I_AUXTIME – The time that the agent spends in AUX Work when activated in this skill.

TI database items

No new TI items were added to the Agent Tables to support the Reserve Agent Work Time Tracking feature. TI_STAFFTIME and TI_AUXTIME include the time even if the agent is not needed.


The following diagram shows the database items included in the TI_STAFFTIME database item:



Non-reserve Agent database items

The time that a Reserve Agent spends logged into a skill and in standby is not included in the overall STAFFTIME for the agent. If necessary, a custom calculation can be created to provide a total of the time the agent accumulates in I_STAFFTIME plus the time the agent spends in standby. For example: Reserve Stafftime = I_STAFFTIME + I_OTHERSTBYTIME + I_AUXSTBYTIME.

The following diagram shows the database items included in the Reserve Stafftime custom calculation:



Ringling

CMS displays the number of agents with split/skill ACD calls and direct agent calls ringing at their telephones. This information is meaningful only if agents' telephones are administered to ring rather than receive zip tone. The communication server sends a message to CMS when a call is directed to an agent and alerting begins.

Skill state

Skills can be in different states based on Expected Wait Time (EWT) threshold. Time that is spent in each state except UNKNOWN is tracked in the split table. The state is UNKNOWN when the link is out of service or the split is non-EAS, or when a new skill is added and the state message has not yet arrived.

Timed ACW

The timed ACW feature provides Auto-In agents with a fixed ACW period after each Auto-In call. Timed ACW makes no changes in CMS tracking of ACW time. Timed ACW is tracked identically to manually entered ACW or ACW that results from Manual-In calls.

Time/duration tracking

In the trunk, trunk group, and VDN tables, the TIME items typically accumulate until the trunk drops at the end of the call, unless the items are queue time, ring time, other similar items.

In the split/skill and vector tables, the TIME items typically accumulate until the call leaves the split/skill or vector and the disposition is known, for example, when the call outflows or when the caller starts hearing the forced busy.

Transfer tracking

CMS tracks all transferred calls that are made by measured agents. The agent and split/skill reports display these transfers. Transfers into a split/skill, agent, or VDN are not tracked explicitly. For example, the party who initiates the transfer is credited with a transfer, not the party who receives the transfer.

Transferred and conferenced calls

With personal call tracking, CMS tracks transferred and conferenced calls as follows:

- Transferred and conferenced calls are tracked as held calls while the calls wait to be transferred or added to a conference.
- When agents end a conference call, they return to the call state they were in before they set up the conference.
- If an agent is talking, places the ACD call on hold to transfer the call, and then completes the transfer, the agent goes to the AVAIL state (Auto-In) or to the ACW state (Manual-In) following the transfer.
- Transferred or conferenced unmeasured split, trunk group, or VDN calls are now tracked. Without personal call tracking, these calls were not tracked.

Trunk No Answer Timeout

The Trunk No Answer Timeout timer starts when the communication server first seizes the trunk and stops when answer supervision is sent for the call. If it times out, the call is dropped by the communication server and the CMS counts the call as an abandoned call.

Note:

This timer is for communication servers in countries that lack disconnect supervision for trunks. The assumption is that the caller abandoned long ago.

Universal Call Identifier

A Universal Call Identifier (UCID) is a unique tag that is assigned to a call. The purpose of the UCID is to allow call-related data to be collected and aggregated from multiple sources and multiple sites. The UCID can then be used to group all the data from various sources about a particular call.

When this feature is enabled on the communication server, CMS receives the UCID that is assigned to calls by the communication server. The UCID is then stored, along with data about the call itself, by the Call History feature, which includes either Internal or External Call History. The data is available to both Custom Reports and the Report Designer. UCID data is stored in the call history and agent trace tables.

VDN active calls

Avaya communication servers provide a vector conditional that is based on a count of the active calls to a VDN. Incoming trunk calls that route directly to the VDN by Direct Inward Dialing (DID), DCS, PRI, tie or tandem trunks, or incoming trunk calls, where the VDN is considered to be the incoming destination, are considered active calls for a VDN. Incoming trunk night service calls where the VDN is the night service destination, or calls that forward or cover to the VDN, and that have not already routed to another VDN on this communication server are also considered active calls for a VDN.

The current active VDN call count is sent to the CMS, where it can be displayed on real-time reports. Note that the count of “active” calls on the communication server is not the same as the CMS count of INPROGRESS calls in the VDN, since the definition of “active in the VDN” differs between the communication server and CMS. That is, CMS counts calls as INPROGRESS in the VDN whether they are inbound trunk calls or internal calls and regardless of whether this is the first VDN for the call or not.

Vector Disconnect Timer

On Avaya communication servers, the vector disconnect timer starts when a call begins vector processing and stops when the call is routed successfully. This means that the call rings at a destination or the trunk is connected to a destination. In the case of adjunct routing, the timer is stopped when the call is routed successfully. If the timer times out, the call is dropped by the communication server and the CMS records a forced disconnect for the call.

Wait Answer Supervision Timer

The wait answer supervision timer (WAST) is started when a call begins ringing at an agent or station. It is stopped if the call is answered, connected, or redirected. Once a redirected call begins ringing, the timer is restarted. In the case of redirection on no answer, if the call cannot be redirected, the WAST is restarted. If the WAST times out, the call is dropped by the communication server and the CMS records an abandon (from ringing) for the call.

■ ■ ■ ■ ■ ■

Dictionary of CMS database items

This section provides a definition for each item that is contained in one of the CMS database tables.

Organization

The database items are listed in alphabetical order.

For information on which database tables individual items are stored in, see [Communication server capabilities that impact CMS](#) on page 49.

Availability of database items

Unless noted in the definition of a database item, the database items defined in this dictionary are available on all Avaya communication servers.

ABNCALLS

The ABNCALLS item is included in the following database tables:

Split/skill tables

The number of CALLSOFFERED that are abandoned while in queue or ringing at an agent position.

When a call is abandoned while it is queued to multiple splits/skills, only the primary split/skill increments ABNCALLS. If a split/skill ACD call is ringing at an agent and then abandons, the split/skill that routed the call to the agent gets credit for the abandon.

ABNCALLS includes PHANTOMABNS, which are ACD calls and calls routed to an agent or extension with talk times less than the value of the phantom-abandon call timer.

$$\text{ABNCALLS} = \text{ABNCALLS1} + \text{ABNCALLS2} + \text{ABNCALLS3} + \text{ABNCALLS4} + \text{ABNCALLS5} + \text{ABNCALLS6} + \text{ABNCALLS7} + \text{ABNCALLS8} + \text{ABNCALLS9} + \text{ABNCALLS10}$$

ABNCALLS includes ABNRINGCALLS, O_ABNCALLS, PHANTOMABNS, SLVLABNS.

This is a cumulative item.

Agent tables

The number of split/skill ACD calls that are abandoned while ringing the agent's telephone (after being directed to the agent telephone, but before being answered). ABNCALLS includes PHANTOMABNS, which are ACD calls and calls routed to an agent or extension with talk times less than the value of the phantom-abandon call timer.

This is a cumulative item.

Trunk group tables

The number of calls carried by this trunk group that are abandoned by the caller before being answered by an agent.

ABNCALLS includes PHANTOMABNS, which are ACD calls and calls routed to an agent or extension with talk times less than the value of the phantom-abandon call timer.

This is a cumulative item.

Trunk tables

The number of calls carried by this trunk that are abandoned by the caller before they are answered by an agent. Direct calls to unmeasured stations that do not go through a measured VDN or split/skill are not recorded. ABNCALLS includes all calls abandoned by the caller that are carried by this trunk, except for direct calls to unmeasured stations that do not go through a measured VDN or split/skill. ABNCALLS includes PHANTOMABNS, which are ACD calls and calls routed to an agent or extension with talk times less than the

value of the phantom-abandon call timer. Calls that abandon while listening to a forced disconnect are also included in ABNCALLS.

ABNCALLS includes ABNVECCALLS, ABNQUEUECALLS, ABNRINGCALLS, and PHANTOMABNS.

This is a cumulative item.

Vector tables

The number of INCALLS that are abandoned while INPROGRESS for this vector. This includes split/skill and direct agent ACD calls that abandon from queue or from ringing, and calls that abandon from vector processing.

ABNCALLS includes ABNQUEECALLS, ABNRINGCALLS, and PHANTOMABNS.

This is a cumulative item.

VDN tables

The number of INCALLS that are abandoned while INPROGRESS for this VDN. This includes split/skill and direct agent ACD calls that abandon from queue or from ringing, calls that abandon from vector processing, and calls that abandon after being routed to an extension by the "route to" vector command. ABNCALLS includes PHANTOMABNS, which are ACD calls and calls routed to an agent or extension with talk times less than the value of the phantom-abandon call timer.

ABNCALLS includes ABNCALLS1 through ABNCALLS10, ABNQUEECALLS, ABNRINGCALLS, PHANTOMABNS, and SLVLABNS.

This is a cumulative item.

ABNCALLS1 through ABNCALLS10

The ABNCALLS1 through ABNCALLS10 items appear in the following database tables:

Split/skill tables

The number of CALLSOFFERED that are abandoned during the collection interval in each of the service-level increments PERIOD1 through PERIOD9, as defined on the Call Center Administration: Split/Skill Call Profile window. If call profiles are not set, the data is stored in the first interval (ABNCALLS1). ABNCALLS10 counts calls that abandoned after PERIOD9.

This is a cumulative item.

VDN tables

The number of INCALLS that are abandoned in each of the service-level increments PERIOD1 through PERIOD9, as defined on the Call Center Administration: VDN Call Profile Setup window. ABNCALLS10 counts calls that abandoned after PERIOD9.

This is a cumulative item.

ABNQUECALLS

The ABNQUECALLS item is included in the following database tables:

Trunk group tables

The number of ABNCALLS that are abandoned while in a split/skill or direct agent ACD queue.

This is a cumulative item.

Vector tables

The number of ABNCALLS that are abandoned while in a split/skill or direct agent ACD queue.

This is a cumulative item.

VDN tables

The number of ABNCALLS that are abandoned while in a split/skill or direct agent ACD queue.

This is a cumulative item.

ABNRINGCALLS

The ABNRINGCALLS item is included in the following database tables:

Split/skill tables

The number of split/skill or direct agent ABNCALLS that are abandoned while ringing at an agent position.

This is a cumulative item.

Trunk group tables

The number of split/skill or direct agent ABNCALLS that are abandoned while ringing at an agent position.

This is a cumulative item.

Vector tables

The number of split/skill or direct agent ABNCALLS that are abandoned while ringing at an agent position.

This is a cumulative item.

VDN tables

The number of split/skill and direct agent ABNCALLS that are abandoned while ringing at an agent.

This is a cumulative item.

ABNTIME

The ABNTIME item is included in the following database tables:

Split/skill tables

The length of time that callers waited in queue and ringing at an agent's telephone before abandoning the call. For phantom abandons, ABNTIME includes the total time until the agent releases the call.

This is a cumulative item.

Agent tables

The length of time that split/skill ACD callers waited while ringing the agent's telephone before abandoning the call. For phantom abandons, ABNTIME includes the total time until the agent releases the call.

This is a cumulative item.

Vector tables

The length of time that a caller spent waiting while vector steps were executed, the call was queued and ringing before abandoning. For phantom abandons, ABNTIME includes the total time until the agent releases the call.

This is a cumulative item.

VDN tables

The length of time that a caller spent waiting while vector steps were executed, the call was queued and ringing before abandoning. For phantom abandon calls, ABNTIME includes the total time from entering the VDN until the agent releases the call.

This is a cumulative item.

ABNVECCALLS

The ABNVECCALLS item is included in the following database tables:

Trunk group tables

The number of ABNCALLS that abandoned while in vector processing. This includes vector calls that abandoned while in queue or while ringing at an agent position. The ABNVECCALLS item is available with the Vectoring feature.

ABNVECCALLS includes ABNQUECALLS and ABNRINGCALLS.

This is a cumulative item.

ACCEPTABLE

The ACCEPTABLE item is included in the following database tables:

Split/skill tables

The number of ACDCALLS that are answered by an agent within the predefined acceptable service level (SERVICELEVEL) as defined on the Call Center Administration: Split/Skill Call Profile window.

This is a cumulative item.

VDN tables

The number of ACDCALLS and CONNECTCALLS that are answered within the acceptable service level (SERVICELEVEL) as defined on the Call Center Administration: VDN Call Profile Setup window.

This is a cumulative item.

ACD (index)

The ACD (index) item is included in the following database tables:

Split/skill tables

The ACD number for which data was collected.

This is a row identifier item.

Agent tables

The ACD number for which data was collected.

This is a row identifier item.

Trunk group tables

The ACD number for which data was collected.

This is a row identifier item.

Trunk tables

The ACD number for which data was collected.

This is a row identifier item.

Vector tables

The ACD number for which data was collected.

This is a row identifier item.

VDN tables

The ACD number for which data was collected.

This is a row identifier item.

Call work codes tables

The ACD number for which data was collected.

This is a row identifier item.

Agent login/logout table

The ACD number for which data was collected.

This is a row identifier item.

Agent trace table

The ACD number for which data was collected.

This is a row identifier item.

Current day configuration table

The ACD number for which data was collected.

This is a row identifier item.

Current day report table

The ACD number for which data was collected.

This is a row identifier item.

Call record table

The ACD number for which data was collected.

This is a row identifier item.

Agent exception table

The ACD number for which data was collected.

This is a row identifier item.

Split/skill exception table

The ACD number for which data was collected.

This is a row identifier item.

Trunk group exception table

The ACD number for which data was collected.

This is a row identifier item.

VDN exception table

The ACD number for which data was collected.

This is a row identifier item.

Vector exception table

The ACD number for which data was collected.

Malicious call trace exception table

The ACD number for which data was collected.

This is a row identifier item.

Data collection exception table

The ACD number for which data was collected.

This is a row identifier item.

ACD_RELEASE

The ACD_RELEASE item is included in the following database tables:

Agent tables

The number of split/skill ACD calls that the agent released or dropped before the far end released. Calls that are transferred or conferenced are always recorded as agent-released calls.

This is a cumulative item.

ACDAUXOUTCALLS

The ACDAUXOUTCALLS item is included in the following database tables:

Split/skill tables

The number of AUXOUTCALLS that agents in the split/skill placed with at least one split/skill ACD call for this split/skill on hold. On Avaya communication servers with multiple call handling and agents in multiple skills, the call is recorded for the skill of the last ACD call that the agent put on hold. ACDAUXOUTCALLS includes calls placed to transfer or conference the ACD call.

This is a cumulative item.

Agent tables

The number of AUXOUTCALLS that the agent placed with at least one split/skill or direct agent ACD call on hold. On Avaya communication servers with multiple call handling and agents in multiple skills, the call is recorded for the skill of the last ACD call that the agent put on hold. This includes calls that are placed to transfer or conference the ACD call.

This is a cumulative item.

ACDCALLS

The ACDCALLS item is included in the following database tables:

Split/skill tables

The number of CALLSOFFERED calls that are answered by an agent in the split/skill.

$ACDCALLS = ACDCALLS1 + ACDCALLS2 + ACDCALLS3 + ACDCALLS4 + ACDCALLS5 + ACDCALLS6 + ACDCALLS7 + ACDCALLS8 + ACDCALLS9 + ACDCALLS10.$

ACDCALLS includes ACCEPTABLE, ACDCALLS1 through ACDCALLS10, ACDCALLS_R1, ACDCALLS_R2, BACKUPCALLS, CONFERENCE, HIGHCALLS, HOLDCALLS, LOWCALLS, MEDCALLS, O_ACDCALLS, TOPCALLS, and TRANSFERRED.

This is a cumulative item.

Agent tables

The number of calls that are queued to SPLIT and answered by this agent in this SPLIT.

ACDCALLS includes ACDCALLS_R1, ACDCALLS_R2, O_ACDCALLS and ACD_RELEASE.

This is a cumulative item.

Trunk group tables

The number of INCALLS that are answered by an agent as a split/skill or direct agent ACD call. ACDCALLS includes ACDCALLS_R1, ACDCALLS_R2, and BACKUPCALLS.

This is a cumulative item.

Trunk tables

The number of INCALLS that are answered by an agent as a split/skill or direct agent ACD call. ACDCALLS includes ACDCALLS_R1, ACDCALLS_R2.

This is a cumulative item.

Vector tables

The number of split/skill and direct agent ACD calls that are answered by an agent from “queue to,” “check,” “messaging split/skill,” “route to,” “split/skill” or “direct agent,” and “adj rout link” to split/skill or direct agent. ACDCALLS includes ACDCALLS_R1, ACDCALLS_R2, and BACKUPCALLS.

This is a cumulative item.

VDN tables

The number of split/skill and direct agent ACD calls that are answered by an agent from “queue to”, “check”, “messaging split/skill”, “route to” split/skill or direct agent, and “adj rout link” to split/skill or direct agent. ACDCALLS includes ACDCALLS_R1, ACDCALLS_R2, ACCEPTABLE, ANSCONNCALLS1 through ANSCONNCALLS10, BACKUPCALLS, and TRANSFERRED.

This is a cumulative item.

Call work codes tables

The number of times that this call work code was entered while an agent was on a split/skill or direct agent ACD call or in call-related ACW.

This is a cumulative item.

ACDCALLS1 through ACDCALLS10

The ACDCALLS1 through ACDCALLS10 items appear in the following database tables:

Split/skill tables

The number of ACDCALLS during the collection interval that are answered in each of the service level increments PERIOD1 through PERIOD9 as defined on the Call Center Administration: Split/Skill Call Profile window. ACDCALLS10 is the number of calls answered after the last increment PERIOD9. If call profiles are not set, then the data is stored in the first interval (ACDCALLS1).

This is a cumulative item.

ACDCALLS_R1

The ACDCALLS_R1 item is included in the following database tables:

Split/skill tables

The number of ACDCALLS calls that are answered by a Reserve 1 Agent in the split/skill.

This is a cumulative item.

Agent tables

The number of ACDCALLS that are queued to SPLIT and answered by this Reserve 1 Agent in this SPLIT.

This is a cumulative item.

Trunk group tables

The number of ACDCALLS that are answered by a Reserve 1 Agent as a split/skill ACD call.

This is a cumulative item.

Trunk tables

The number of ACDCALLS that are answered by a Reserve 1 Agent as a split/skill ACD call.

This is a cumulative item.

Vector tables

The number of ACDCALLS that are answered by a Reserve 1 Agent.

This is a cumulative item.

VDN tables

The number of ACDCALLS that are answered by a Reserve 1 Agent.

This is a cumulative item.

ACDCALLS_R2

The ACDCALLS_R2 item is included in the following database tables:

Split/skill tables

The number of ACDCALLS calls that are answered by a Reserve 2 Agent in the split/skill.

This is a cumulative item.

Agent tables

The number of ACDCALLS that are queued to SPLIT and answered by this Reserve 2 Agent in this SPLIT.

This is a cumulative item.

Trunk group tables

The number of ACDCALLS that are answered by a Reserve 2 Agent as a split/skill ACD call.

This is a cumulative item.

Trunk tables

The number of ACDCALLS that are answered by a Reserve 2 Agent as a split/skill ACD call.

This is a cumulative item.

Vector tables

The number of ACDCALLS that are answered by a Reserve 2 Agent.

This is a cumulative item.

VDN tables

The number of ACDCALLS that are answered by a Reserve 2 Agent.

This is a cumulative item.

ACDONHOLD (real-time)

The ACDONHOLD item is included in the following database tables:

Agent tables

The number of direct agent and split/skill ACD calls that are on hold for the agent.

This is a status item.

ACDTIME

The ACDTIME item is included in the following database tables:

Split/skill tables

The talk time of all ACDCALLS. ACDTIME includes O_ACDTIME but does not include HOLDTIME.

This is a cumulative item.

Agent tables

The talk time of all ACDCALLS. ACDTIME includes O_ACDTIME but does not include HOLDTIME.

This is a cumulative item.

VDN tables

The talk time of all ACDCALLS. ACDTIME does not include HOLDTIME. ACDTIME includes SKILLTIME1, SKILLTIME2, and SKILLTIME3.

This is a cumulative item.

Call work codes tables

The talk time of all ACDCALLS that are associated with this call work code.

This is a cumulative item.

ACTIVECALLS (real-time)

The ACTIVECALLS item is included in the following database tables:

VDN tables

The communication server-generated count of the number of calls that are active in the VDN. This includes only incoming trunk calls that go directly to the VDN. It does not include internal calls to the VDN, transfers to the VDN, or calls that route to the VDN or redirect from ringing to the VDN after having been through another VDN. The ACTIVECALLS item is available on Avaya communication servers with the Vectoring feature.

This is a status item.

ACWINCALLS

The ACWINCALLS item is included in the following database tables:

Split/skill tables

The number of inbound extension calls that are received by agents while they are in ACW. This includes ACW for split/skill, direct agent ACD calls, and ACW not associated with a call.

This is a cumulative item.

Agent tables

The number of inbound extension calls that are received by agents while they are in ACW. This includes ACW for split/skill, direct agent ACD calls, and ACW not associated with a call.

This is a cumulative item.

ACWINTIME

The ACWINTIME item is included in the following database tables:

Split/skill tables

The talk time of all ACWINCALLS. ACWINTIME includes DA_ACWINTIME but it does not include HOLDTIME.

This is a cumulative item.

Agent tables

The talk time of all ACWINCALLS. ACWINTIME includes DA_ACWINTIME but it does not include HOLDTIME.

This is a cumulative item.

ACWOUTADJCALLS

The ACWOUTADJCALLS item is included in the following database tables:

Split/skill tables

The number of ACWOUTCALLS that are placed by an adjunct on behalf of an agent (keyboard-dialed). If such calls are placed to off-communication server destinations, they are also counted as ACWOUTOFFCALLS. ACWOUTADJCALLS is available with the ASAI feature.

This is a cumulative item.

Agent tables

The number of ACWOUTCALLS that are placed by an adjunct on behalf of an agent (keyboard-dialed). If such calls are placed to off-communication server destinations, they are also counted as ACWOUTOFFCALLS. ACWOUTADJCALLS is available with the ASAI feature.

This is a cumulative item.

ACWOUTCALLS

The ACWOUTCALLS item is included in the following database tables:

Split/skill tables

The number of outbound extension calls that are placed by agents or on behalf of the agent while they are in ACW. This includes ACW for ACD calls and ACW that is not associated with a call. ACWOUTCALLS includes ACWOUTADJCALLS and ACWOUTOFFCALLS.

This is a cumulative item.

Agent tables

The number of outbound extension calls that are placed by the agent or on behalf of the agent while they are in ACW. This includes ACW for ACD calls and ACW that is not associated with a call. ACWOUTCALLS includes ACWOUTADJCALLS, ACWOUTOFFCALLS, and DA_ACWOCALLS.

This is a cumulative item.

ACWOUTOFFCALLS

The ACWOUTOFFCALLS item is included in the following database tables:

Split/skill tables

The number of ACWOUTCALLS that are placed to an off-communication server destination. If these calls are placed by an adjunct on behalf of an agent while the agent is in ACW, they are also counted as ACWOUTADJCALLS.

This is a cumulative item.

Agent tables

The number of ACWOUTCALLS that are placed to an off-communication server destination. If these calls are placed by an adjunct on behalf of an agent while the agent is in ACW, they are counted as ACWOUTADJCALLS.

This is a cumulative item.

ACWOUTOFFTIME

The ACWOUTOFFTIME item is included in the following database tables:

Split/skill tables

The talk time of all ACWOUTOFFCALLS. ACWOUTOFFTIME does not include HOLDTIME. ACWOUTTIME includes ACWOUTOFFTIME.

This is a cumulative item.

Agent tables

The talk time of all ACWOUTOFFCALLS. ACWOUTOFFTIME does not include HOLDTIME. ACWOUTTIME includes ACWOUTOFFTIME.

This is a cumulative item.

ACWOUTTIME

The ACWOUTTIME item is included in the following database tables:

Split/skill tables

Talk time of all ACWOUTCALLS. ACWOUTTIME does not include hold time. It does include time spent for the following activities:

- Non-ACD calls made while in ACW
- ACWOUTADJCALLS
- ACWOUTOFFCALLS

This is a cumulative item.

Agent tables

The talk time of all ACWOUTCALLS. ACWOUTTIME does not include HOLDDTIME. ACWOUTTIME includes time spent for the following activities:

- Non-ACD calls made while in ACW
- ACWOUTADJCALLS
- ACWOUTOFFCALLS

This is a cumulative item.

ACWTIME

The ACWTIME item is included in the following database tables:

Split/skill tables

The length of time that agents spend in ACW that is associated with ACDCALLS. The ACWTIME database item includes portions of ACWINTIME, ACWOUTTIME, and O_ACWTIME that are associated with ACD calls. Only the ACWINTIME and ACWOUTTIME associated with calls made or received while in ACW associated with Split/Skill ACD calls are included. This is a cumulative item.

Agent tables

The length of time that agents spend in ACW that is associated with ACDCALLS. ACWTIME does not include the time that is spent in ACW that is not associated with an

ACD call. ACWINTIME and ACWOUTTIME associated with calls made or received while in ACW associated with Split/Skill and direct agent ACD calls are included.

This is a cumulative item.

VDN tables

The length of time that agents spend in ACW that is associated with ACDCALLS. ACWTIME includes SKILLACWTIME1 through SKILLACWTIME3.

This is a cumulative item.

Call work codes tables

The length of time that agents spend in ACW for ACDCALLS that are associated with this call work code.

This is a cumulative item.

Call record tables

The length of time that agents spend in ACW that is associated with this call by the answering agent in this segment.

ADJATTEMPTS

The ADJATTEMPTS item is included in the following database tables:

Vector tables

The number of adjunct-routing attempts for calls in this VECTOR. ADJATTEMPTS includes ADJROUTED. ADJATTEMPTS is available with the vectoring and the ASAI feature.

This is a cumulative item.

VDN tables

The number of adjunct-routing attempts for calls in this VDN. ADJATTEMPTS includes ADJROUTED. ADJATTEMPTS is available with the vectoring and the ASAI feature.

This is a cumulative item.

ADJROUTED

The ADJROUTED item is included in the following database tables:

Vector tables

The number of adjunct-routing calls that are redirected by an adjunct processor or host computer. ADJROUTED is available with the Vectoring and the ASAI features.

This is a cumulative item.

VDN tables

The number of adjunct-routing calls that are redirected by an adjunct processor or host computer. ADJROUTED is available with the Vectoring and the ASAI features.

This is a cumulative item.

ADJUNCTOUT (real-time)

The ADJUNCTOUT item is included in the following database tables:

Trunk group tables

The number of OUTBOUND calls currently in progress that an adjunct processor originated. The ADJUNCTOUT item is available with the ASAI feature.

This is a status item.

AGINRING (real-time)

The AGINRING item is included in the following database tables:

Split/skill tables

The number of agents for which split/skill or direct agent calls are currently ringing. When an agent makes or answers a personal call while an ACD call is ringing, that position is no longer counted in AGINRING because the agent is then on an AUXIN or AUXOUT call. Agents who are talking on ACD calls and receive a forced MCH call are counted in ONACD and are not counted in AGINRING.

This is a status item.

AGOCC

The AGOCC item is included in the following database tables:

Current day report tables

The objective maximum percentage of time that an agent will be on ACD calls. This is known as agent occupancy.

This is an administrative item.

AGSTATE (real-time)

The AGSTATE item is included in the following database tables:

Agent tables

The agent's current WORKMODE and call DIRECTION, for example, AUXOUT.

This is a status item.

AGT_RELEASED

The AGT_RELEASED item is included in the following database tables:

Agent trace tables

The agent released or dropped the split/skill or direct agent ACD call, including transferred and conferenced calls. Valid values are n, which means that the call was not released or dropped, and y, which means that the call was released or dropped.

Call record tables

The agent released or dropped the split/skill or direct agent ACD call, including transferred and conferenced calls. Valid values are n, which means that the call was not released or dropped, and y, which means that the call was released or dropped.

AGDURATION (real-time)

The AGDURATION item is included in the following database tables:

Agent tables

The elapsed time since the last agent WORKMODE or DIRECTION change for any split/skill. For example, if the agent goes from AUX to AUXOUT to AUX, AGTIME resets for each DIRECTION change.

This is a status item.

AGTIME (real-time)

The AGTIME item is included in the following database tables:

Agent tables

The elapsed time since the last agent WORKMODE change for any split/skill. This item is not reset if the DIRECTION changes, but WORKMODE remains the same. For example, if the agent goes from AUX to AUXOUT to AUX, AGTIME continues without resetting.

This is a status item.

ALLINUSE (real-time)

The ALLINUSE item is included in the following database tables:

Trunk group tables

The current use status of all trunks in the trunk group. Usage for a trunk is on a call or maintenance busy. Values for ALLINUSE are YES and NO.

This is a status item.

ALLINUSETIME

The ALLINUSETIME item is included in the following database tables:

Trunk group tables

The length of time during the interval that all trunks in the trunk group are in use. Usage for a trunk is on a call or maintenance busy.

This is a cumulative item.

ANI_SID

The ANI_SID item is included in the following database tables:

Malicious call trace exception table

The billing number or phone number from which the malicious call originated. ANI_SID is available only if the communication server has ANI/SID service.

This is a status item.

ANSCONNCALLS1 through ANSCONNCALLS10

The ANSCONNCALLS1 through ANSCONNCALLS10 items appear in the following database tables:

VDN tables

The number of times that calls are answered (ACDCALLS) or connected (CONNECTCALLS) during each of the service level increments PERIOD1 through PERIOD9. The service level increments are defined in the Call Center Administration: VDN Call Profile Setup window. The ANSCONNCALLS10 item counts calls answered or connected after PERIOD9. Answered and connected calls include split/skill and direct agent ACD calls and extension calls by a “route to” or “adj rout link” vector command.

This is a cumulative item.

ANSHOLDTIME

The ANSHOLDTIME item is included in the following database tables:

Call record tables

The total time, in seconds, for which the call was put on hold by the answering agent in this call segment. In agent-to-agent calls, ANSHOLDTIME is accrued for the answering agent if the agent puts the call on hold. The other agent continues to accrue talk time. Hold time accrues for any type of call.

ANSLOCID

The ANSLOCID item is included in the following database tables:

Call record tables

The location ID that is associated with the EXTENSION at which the answering agent logged in.

This is an administrative item.

ANSLOGIN

The ANSLOGIN item is included in the following database tables:

Call record tables

The login ID of the agent who answered the call in this segment. This field is blank for unmeasured extensions when EAS is not active.

ANSREASON

The ANSREASON item is included in the following database tables:

Call record tables

The reason code, from 0 through 99, that is associated with the answering agent's mode if the agent is in the AUX mode. On Avaya communication servers without EAS and reason codes, ANSREASON is always 0.

ANSRINGTIME

The ANSRINGTIME item is included in the following database tables:

Agent tables

The length of time that split/skill and direct agent ACD calls spent ringing at the agent's telephone before being answered.

This is a cumulative item.

ANSTIME

The ANSTIME item is included in the following database tables:

Split/skill tables

The length of time that is spent by callers in queue or ringing before an agent answers the call.

This is a cumulative item.

Vector tables

The length of time that split/skill and direct agent ACD calls waited while vector steps are executed, in queue, and ringing before an agent answers the call. ANSTIME includes RINGTIME.

This is a cumulative item.

VDN tables

The length of time that split/skill and direct agent ACD calls waited while vector steps are executed, in queue, and ringing before an agent answers the call. ANSTIME includes RINGTIME.

This is a cumulative item.

ASA (real-time)

The ASA item is included in the following database tables:

Split/skill tables

The communication server-provided rolling average speed of answer for this split/skill. The communication server sends this value to CMS whenever the value changes on the communication server, such as when a call is answered. EWT and ASA should not be expected to match. ASA gives a historical perspective, while EWT changes constantly to match current conditions, such as queue length and staffing changes. The ASA item is available on Avaya communication servers with the Vectoring feature.

This is a status item.

VDN tables

The communication server-provided rolling average speed of answer for this VDN. The communication server sends this value to CMS whenever the value changes on the communication server when a call is answered. The ASA item is available on Avaya communication servers with the Vectoring feature.

This is a status item.

ASSIST (real-time)

The ASSIST item is included in the following database tables:

Agent tables

A request for supervisor assistance is active for this agent for any split/skill. Values for ASSIST are 0, which means that no request for assistance was made, and 1, which means that the agent requested assistance.

This is a status item.

Call record tables

An indication of whether the answering agent in this call segment requested supervisor assistance on this call. Values for ASSIST are 0, which means that no request for assistance was made, and 1, which means that the agent requested assistance.

ASSIST_ACTV

The ASSIST_ACTV item is included in the following database tables:

Agent trace tables

The agent requested supervisor assistance (pressed the ASSIST button).

ASSISTS

The ASSISTS item is included in the following database tables:

Split/skill tables

The number of times that agents requested supervisor assistance while they were on split/skill ACD calls, direct agent ACD calls, or in call-related ACW for this split/skill.

This is a cumulative item.

Agent tables

The number of times that agents requested supervisor assistance while they were on split/skill ACD calls, direct agent ACD calls, or in call-related ACW for this split/skill.

This is a cumulative item.

ATAGENT (real-time)

The ATAGENT item is included in the following database tables:

VDN tables

The number of INPROGRESS ACD and non-ACD calls that are answered by an agent or connected to a station.

This is a status item.

AUDIO

The AUDIO item is included in the following database tables:

Trunk group tables

The number of calls for which audio difficulty problems were reported for a trunk or for trunks in this trunk group.

This is a cumulative item.

Trunk tables

The number of calls for which audio difficulty problems were reported for this trunk.

This is a cumulative item.

Call record tables

An indication of whether an agent in this segment reported an audio difficulty problem.

Values for AUDIO are 0, which means that no audio difficulty was reported, and 1, which means that audio difficulty was reported.

AUXINCALLS

The AUXINCALLS item is included in the following database tables:

Split/skill tables

The number of inbound extension calls that are received by agents while they are in AUX or AVAILABLE, or while the agents have an ACD, AUXIN, or AUXOUT call on hold.

AUXINCALLS are recorded in the SPLIT that is the OLDEST_LOGON for agents in multiple splits/skills.

This is a cumulative item.

Agent tables

The number of inbound extension calls that are received by agents while they are in AUX or AVAILABLE, or while the agents have an ACD, AUXIN, or AUXOUT call on hold.

AUXINCALLS are recorded in the SPLIT that is the OLDEST_LOGON for agents in multiple splits/skills.

This is a cumulative item.

AUXINTIME

The AUXINTIME item is included in the following database tables:

Split/skill tables

The talk time of all AUXINCALLS. AUXINTIME does not include HOLDTIME.

This is a cumulative item.

Agent tables

The talk time of all AUXINCALLS. AUXINTIME does not include HOLDTIME.

This is a cumulative item.

AUXOUTADJCALLS

The AUXOUTADJCALLS item is included in the following database tables:

Split/skill tables

The number of AUXOUTCALLS that are placed by an adjunct on behalf of an agent (keyboard dialed). If such calls are placed to off-communication server destinations, they are also counted as AUXOUTOFFCALLS. AUXOUTADJCALLS is available with the ASAI feature.

This is a cumulative item.

Agent tables

The number of AUXOUTCALLS that are placed by an adjunct on behalf of an agent (keyboard dialed). If such calls are placed to off-communication server destinations, they are also counted as AUXOUTOFFCALLS. AUXOUTADJCALLS is available with the ASAI feature.

This is a cumulative item.

AUXOUTCALLS

The AUXOUTCALLS item is included in the following database tables:

Split/skill tables

The number of outbound extension calls that are placed by agents while they are in AUX or AVAILABLE, or while the agents have an ACD, AUXIN, or AUXOUT call on hold. AUXOUTCALLS are recorded in the SPLIT that is the OLDEST_LOGON, unless the agent placed the call with an ACD call on hold. In this case, AUXOUTCALLS are recorded for the split/skill of the ACD call. AUXOUTCALLS includes ACDAUXOUTCALLS, AUXOUTADJCALLS, and AUXOUTOFFCALLS.

This is a cumulative item.

Agent tables

The number of outbound extension calls that are placed by the agent or on behalf of the agent while the agent is in AUX or AVAILABLE, or while the agent has an ACD, AUXIN, or AUXOUT call on hold. Calls the agent makes to transfer or conference an ACD call are included as AUXOUT calls. AUXOUTCALLS includes ACDAUXOUTCALLS, AUXOUTADJCALLS, and AUXOUTOFFCALLS.

For agents with multiple skills AUXOUTCALLS are recorded in the SPLIT that is the OLDEST_LOGON, unless the agent placed the call with an ACD call on hold. In this case, AUXOUTCALLS are recorded for the split/skill of the ACD call.

This is a cumulative item.

AUXOUTOFFCALLS

The AUXOUTOFFCALLS item is included in the following database tables:

Split/skill tables

The number of AUXOUTCALLS that are placed to a destination outside the communication server. If such calls are placed by an adjunct on behalf of an agent, they are also counted as AUXOUTADJCALLS.

This is a cumulative item.

Agent tables

The number of AUXOUTCALLS that are placed to a destination outside the communication server. If such calls are placed by an adjunct on behalf of an agent, they are also counted as AUXOUTADJCALLS.

This is a cumulative item.

AUXOUTOFFTIME

The AUXOUTOFFTIME item is included in the following database tables:

Split/skill tables

The talk time of all AUXOUTOFFCALLS not including HOLDDTIME. AUXOUTOFFTIME is included in AUXOUTTIME.

This is a cumulative item.

Agent tables

The talk time of all AUXOUTOFFCALLS not including HOLDTIME. This time is included in AUXOUTTIME.

This is a cumulative item.

AUXOUTTIME

The AUXOUTTIME item is included in the following database tables:

Split/skill tables

The talk time of all AUXOUTCALLS. AUXOUTTIME does not include HOLDTIME. AUXOUTTIME includes AUXOUTOFFTIME.

This is a cumulative item.

Agent tables

The talk time of all AUXOUTCALLS.

AUXOUTTIME includes AUXOUTOFFTIME.

This is a cumulative item.

AUXREASON (real-time)

The AUXREASON item is included in the following database tables:

Agent tables

The reason code that is associated with the agent's current state. AUXREASON is blank if the agent is not in the AUX state. On Avaya communication servers that do not have EAS and reason codes active, AUXREASON is zero.

This is a status item.

Agent trace tables

The reason code that is associated with the agent's current state. AUXREASON is blank if the agent is not in the AUX state. On communication servers that do not have EAS and reason codes active, AUXREASON is zero.

This is a status item.

AVAILABLE (real-time)

The AVAILABLE item is included in the following database tables:

Split/skill tables

The number of agents that are currently available in this split/skill.

This is a status item.

AVGAGSERV

The AVGAGSERV item is included in the following database tables:

Current day report tables

The objective average number of seconds that it takes for an agent to service a call.

This is an administrative item.

AVGSPEEDANS

The AVGSPEEDANS item is included in the following database tables:

Current day report tables

The objective average speed of answer, in seconds, for this type of call.

This is an administrative item.

AWORKMODE (real-time)

The AWORKMODE item is included in the following database tables:

Agent tables

The work mode that the agent is currently using. This item is identical to WORKMODE, except when the agent is available in some, but not all, splits/skills. In this case, AWORKMODE is set to AVAIL only if the agent is available in this SPLIT. Otherwise, AWORKMODE is set to OTHER.

This is a status item.

BACKUPCALLS

The BACKUPCALLS item is included in the following database tables:

Split/skill tables

The number of ACDCALLS that are delivered by a vector command other than “queue to” and answered by this split/skill plus the number of ACDCALLS that are delivered to this split/skill by a “queue to” vector command and answered by an agent who has either Reserve 1 or Reserve 2 skill levels assigned for this skill.

This allows tracking of calls that are answered by agents with a Reserve 1 or Reserve 2 skill level assigned for a particular skill. This includes calls delivered by messaging split/skill, check, route to split/skill or direct agent, and redirect on no answer vector routing. Calls that are redirected back to the split/skill from ringing by the redirect on no answer feature that are subsequently answered by an agent in the split/skill are counted as BACKUPCALLS. To calculate the number of calls that are answered in a main split/skill (MAINCALLS), subtract BACKUPCALLS from ACDCALLS. Note that this calculation does not include direct agent calls. The BACKUPCALLS item is available with the Vectoring feature.

This is a cumulative item.

Trunk group tables

The number of ACDCALLS that are delivered by a vector command other than “queue to” and answered by this split/skill plus the number of ACDCALLS that are delivered to this split/skill by a “queue to” vector command and answered by an agent who has either Reserve 1 or Reserve 2 skill levels assigned for this skill.

This allows tracking of calls that are answered by agents with a Reserve 1 or Reserve 2 skill level assigned for a particular skill. This includes calls delivered by messaging split/skill, check, route to split/skill or direct agent, and redirect on no answer vector routing. Calls that are redirected back to the split/skill from ringing by the redirect on no answer feature and are subsequently answered by an agent in the split/skill are counted as BACKUPCALLS. To calculate the number of calls that are answered in a main split/skill (MAINCALLS), subtract BACKUPCALLS from ACDCALLS. Note that this calculation does not include direct agent calls. The BACKUPCALLS item is available with the Vectoring feature.

This is a cumulative item.

Vector tables

The number of ACDCALLS that are delivered by a vector command other than “queue to” and answered by this split/skill plus the number of ACDCALLS that are delivered to this split/skill by a “queue to” vector command and answered by an agent who has either Reserve 1 or Reserve 2 skill levels assigned for this skill.

This allows tracking of calls that are answered by agents with a Reserve 1 or Reserve 2 skill level assigned for a particular skill. This includes calls delivered by messaging split/skill, check, route to split/skill or direct agent, and redirect on no answer vector routing. Calls that are redirected back to the split/skill from ringing by the redirect on no answer feature and are subsequently answered by an agent in the split/skill are counted as BACKUPCALLS. To calculate the number of calls that are answered in a main split/skill (MAINCALLS), subtract BACKUPCALLS from ACDCALLS. Note that this calculation does not include direct agent calls. The BACKUPCALLS item is available with the Vectoring feature.

This is a cumulative item.

VDN tables

The number of ACDCALLS that are delivered by a vector command other than “queue to” and answered by this split/skill plus the number of ACDCALLS that are delivered to this split/skill by a “queue to” vector command and answered by an agent who has either Reserve 1 or Reserve 2 skill levels assigned for this skill.

This allows tracking of calls that are answered by agents with a Reserve 1 or Reserve 2 skill level assigned for a particular skill. This includes calls delivered by messaging split/skill, check, route to split/skill or direct agent, and redirect on no answer vector routing. Calls and are redirected back to the split/skill from ringing by the redirect on no answer feature that are subsequently answered by an agent in the split/skill are counted as BACKUPCALLS. To calculate the number of calls that are answered in a main split/skill (MAINCALLS), subtract BACKUPCALLS from ACDCALLS. Note that this calculation does not include direct agent calls. The BACKUPCALLS item is available with the Vectoring feature.

This is a cumulative item.

BH_ABNCALLS (daily only)

The BH_ABNCALLS item is included in the following database tables:

Trunk group tables

The number of incoming calls carried by the trunk group that are abandoned by callers during the busy hour.

This is a busy hour item.

VDN tables

The number of INCALLS that are abandoned by callers during the busy hour.

This is a busy hour item.

BH_ACDCALLS (daily only)

The BH_ACDCALLS item is included in the following database tables:

Trunk group tables

The number of incoming calls that are carried by this trunk group during the busy hour and are answered by an agent as split/skill or direct agent ACD calls.

This is a busy hour item.

VDN tables

The number of ACDCALLS that are completed during the busy hour.

This is a busy hour item.

BH_ACDTIME (daily only)

The BH_ACDTIME item is included in the following database tables:

VDN tables

The talk time for ACDCALLS that are completed during the busy hour.

This is a busy hour item.

BH_ALLINUSETIME (daily only)

The BH_ALLINUSETIME item is included in the following database tables:

Trunk group tables

The length of time during the busy hour that all trunks in the trunk group were in use.

This is a busy hour item.

BH_BUSYCALLS (daily only)

The BH_BUSYCALLS item is included in the following database tables:

Trunk group tables

The number of incoming calls that are carried by the trunk group during the busy hour and are given a busy signal by the communication server.

This is a busy hour item.

VDN tables

The number of INCALLS that are given a busy signal by the communication server during the busy hour.

This is a busy hour item.

BH_DISCCALLS (daily only)

The BH_DISCCALLS item is included in the following database tables:

Trunk group tables

The number of incoming calls that are carried by the trunk group during the busy hour and are forced by the communication server to disconnect.

This is a busy hour item.

VDN tables

The number of INCALLS that are disconnected by the communication server during the busy hour.

This is a busy hour item.

BH_INCALLS (daily only)

The BH_INCALLS item is included in the following database tables:

Trunk group tables

The number of incoming calls that are carried by this trunk group and complete during the busy hour. BH_INCALLS includes BH_ABNCALLS, BH_ACDCALLS, and BH_OTHERCALLS.

This is a busy hour item.

BH_INTIME (daily only)

The BH_INTIME item is included in the following database tables:

Trunk group tables

The trunk holding time of all incoming calls that are carried by this trunk group and complete during the busy hour.

This is a busy hour item.

BH_OABNCALLS (daily only)

The BH_OABNCALLS item is included in the following database tables:

Trunk group tables

The number of outgoing adjunct-originated calls that are carried by the trunk group and are abandoned during the busy hour. The BH_OABNCALLS item is available with the ASAI feature.

This is a busy hour item.

BH_OACDCALLS (daily only)

The BH_OACDCALLS item is included in the following database tables:

Trunk group tables

The number of outgoing adjunct-originated ACD calls that are carried by the trunk group, that are answered by an agent as split/skill or direct agent ACD calls, and that complete during the busy hour. The BH_OACDCALLS is available with the ASAI feature.

This is a busy hour item.

BH_OOTHERCALLS (daily only)

The BH_OOTHERCALLS item is included in the following database tables:

Trunk group tables

The number of outgoing calls that are carried by the trunk group during the busy hour and are not answered or abandoned as ACD calls. BH_OOTHERCALLS include extension out calls, outbound call management calls forced busy or forced disconnect, short outgoing calls, and outgoing calls with unknown disposition.

This is a busy hour item.

BH_OTHERCALLS (daily only)

The BH_OTHERCALLS item is included in the following database tables:

Trunk group tables

The number of incoming calls that are carried by the trunk group during the busy hour and are not answered or abandoned as ACD calls. BH_OTHERCALLS includes extension in calls, calls forced busy or disconnected, calls that outflowed off the communication server, short inbound calls, and inbound calls of unknown disposition. BH_OTHERCALLS includes BH_BUSYCALLS and BH_DISCCALLS.

This is a busy hour item.

VDN tables

The number of OTHERCALLS that completed during the busy hour. BH_OTHERCALLS includes forced-busy calls or force-disconnected calls, calls that outflow from the VDN, and non-ACD calls that were answered.

This is a busy hour item.

BH_OUTCALLS (daily only)

The BH_OUTCALLS item is included in the following database tables:

Trunk group tables

The number of outgoing calls that are carried by the trunk group and complete during the busy hour. BH_OUTCALLS includes BH_OABNCALLS, BH_OACDCALLS, and BH_OOTHERCALLS.

This is a busy hour item.

BH_OUTTIME (daily only)

The BH_OUTTIME item is included in the following database tables:

Trunk group tables

The trunk holding time of all outgoing calls that are carried by the trunk group and complete during the busy hour.

This is a busy hour item.

BH_STARTTIME (daily only)

The BH_STARTTIME item is included in the following database tables:

Trunk group tables

The starting time of the hour for which busy hour data was collected. The busy hour is that set of contiguous intervals during the day totaling an hour in which the trunk holding time for the trunk group was a maximum.

This is a busy hour item.

VDN tables

The starting time of the hour for which busy hour data was collected. The busy hour is that set of contiguous intervals during the day totaling one hour in which the number of INCALLS to the VDN was a maximum. This is a busy hour item.

BH_VDNCALLS (daily only)

The BH_VDNCALLS item is included in the following database tables:

VDN tables

The number of INCALLS to the VDN that are complete during the busy hour. BH_VDNCALLS includes answered calls that complete, calls that abandon, calls given a forced busy, calls that are forced to disconnect, and calls that outflow from the VDN during the busy hour.

This is a busy hour item.

BLOCKAGE

The BLOCKAGE item is included in the following database tables:

Trunk group tables

The number of outbound call attempts that are blocked because all trunks are busy. This item is available for G2 only and is no longer supported.

This is a cumulative item.

BSRPLAN

The BSRPLAN item is included in the following database tables:

VDN tables

The BSR numbers associated with the VDN.

This is an administrative item.

BUSYCALLS

The BUSYCALLS item is included in the following database tables:

Split/skill tables

The number of CALLSOFFERED that are given a busy signal by the communication server. This occurs when the “busy” vector command is executed while the call is queued to this split/skill and this is the primary split/skill to which the call is queued, or if a call queued to this split/skill forwards to another split/skill whose queue is full. A busy is given when a nonvector-controlled split has: a full queue, no queue and no available agents, or no agents that are staffed. This is a cumulative item.

Trunk Group tables

The number of INCALLS that are given a busy signal by the communication server. This occurs when the “busy” vector command executes. BUSYCALLS occurs if a call is routed to a split/skill with coverage set to “yes” and there are no agents available, the queue is full or there is no queue, there is no coverage, and an announcement has played or the trunk is not a CO trunk. BUSYCALLS can occur if a call is routed to a direct agent with coverage set to “yes”, the agent is not logged in, no coverage path is administered, and an announcement has played or the trunk is not a CO trunk. BUSYCALLS can occur without vectoring when a split queue is full or there are no queue slots available, no busy coverage is administered and an announcement has played, or the trunk is not a CO trunk.

This is a cumulative item.

Vector tables

The number of INCALLS that are given a busy signal by the communication server. This occurs when the “busy” vector command executes. In addition, BUSYCALLS occurs if a call is routed to a split/skill with coverage set to “yes” where there are no agents available, the queue is full or there is no queue, no coverage path is administered, and an announcement has played or the trunk is not a CO trunk. BUSYCALLS occurs if a call is routed to a direct agent with coverage set to “yes”, the agent is not logged in, there is no coverage path administered, and an announcement has played or the trunk is not a CO trunk.

This is a cumulative item.

VDN tables

The number of INCALLS that are given a busy signal by the communication server. This occurs when the “busy” vector command executes. BUSYCALLS also occurs if a call is routed to a split/skill with coverage set to “yes” where there are no agents available, the queue is full or there is no queue, no coverage path is administered, and an announcement has played or the trunk is not a CO trunk. BUSYCALLS occurs if a call is

routed to a direct agent with coverage set to “yes”, the agent is not logged in, there is no coverage path administered, and an announcement has played or the trunk is not a CO trunk.

This is a cumulative item.

BUSYTIME

The BUSYTIME item is included in the following database tables:

Split/skill tables

The length of time that callers wait in queue before hearing a busy tone for all BUSYCALLS.

This is a cumulative item.

Vector tables

The length of time that callers wait in queue before hearing a busy tone for all BUSYCALLS.

This is a cumulative item.

VDN tables

The duration of all BUSYCALLS before the trunk goes idle.

This is a cumulative item.

CALLER_HOLD

The CALLER_HOLD item is included in the following database tables:

Agent trace tables

An indication that the agent put the current call on hold.

CALLID

The CALLID item is included in the following database tables:

Call record tables

A unique number that is assigned to this call and all of its call segments. For conferenced and transferred calls, two (or more) calls are associated with each other. When the entire call is recorded, one CALLID is used to join all of the associated call segments. In “meet-me” conferences, this may result in a “later” segment of the call starting earlier than the first segment. CALLIDs are not strictly sequential, but will be unique for all calls recorded over the course of a day.

CALLING_II

The CALLING_II item is included in the following database tables:

Agent trace tables

The Information Indicator (II) digits that are associated with the call. These digits are a two-digit string that is provided by ISDN PRI to indicate the type of originating line of the caller. These digits supply information about the originator location, for example, pay phone, hospital, or prison. The column is blank if the call does not contain II digits.

Call record tables

The Information Indicator (II) digits that are associated with the call. These digits are a two-digit string that is provided by ISDN PRI to indicate the type of originating line of the caller. These digits supply information about the originator location, for example, pay phone, hospital, or prison. The column is blank if the call does not contain II digits.

CALLING_LOGID (real-time)

The CALLING_LOGID item is included in the following database tables:

Trunk tables

The login ID of the agent who originated the current call on this trunk. CALLING_LOGID is NULL when the trunk is idle.

This is a status item.

CALLING_PTY

The CALLING_PTY item is included in the following database tables:

Agent trace tables

The calling party identification. On communication servers without ISDN ANI delivery, the identification is the extension or trunk equipment location that identifies the originator of the call. On communication servers with ISDN ANI delivery, the identification is the ANI/SID. The CALLING_PTY item is blank if the trunk is not measured or, for internal calls, if the originating extension is not measured. This field can contain up to 12 digits.

Call record tables

The calling party identification. On communication servers without ISDN ANI delivery, the identification is the extension or trunk equipment location that identifies the originator of the call. On communication servers with ISDN ANI delivery, the identification is the ANI/SID. The CALLING_PTY item is blank if the trunk is not measured or, for internal calls, if the originating extension is not measured. This field can contain up to 12 digits.

CALLSOFFERED

The CALLSOFFERED item is included in the following database tables:

Split/skill tables

The number of calls that queued to the split/skill and that completed during the interval. This does not include calls that could not queue to the split/skill because the queue was full

or there was no queue. $\text{CALLSOFFERED} = \text{ACDCALLS} + \text{ABNCALLS} + \text{BUSYCALLS} + \text{DISCCALLS} + \text{OUTFLOWCALLS} + \text{DEQUECALLS}$.

CALLSOFFERED includes ABNCALLS, RINGCALLS, OTHERCALLS, and INFLOWCALLS.

This is a cumulative item.

CHANGE

The CHANGE item is included in the following database tables:

Current day configuration tables

Additional change factor (percent).

This is an administrative item.

CHANGED (real-time)

The CHANGED item is included in the following database tables:

Agent tables

The time of day at which new agent activity started. For example, when WORKMODE or DIRECTION is changed. Valid values for CHANGED are blank and the time-of-day.

This is a status item.

CHPROF

The CHPROF item is included in the following database tables:

Current day configuration tables

The number of the call handling profile that is used.

This is an administrative item.

COMPLETED

The COMPLETED item is included in the following database tables:

Trunk group tables

The number of OUTCALLS that are completed by being answered at the far end.

This is a cumulative item.

CONFERENCE

The CONFERENCE item is included in the following database tables:

Split/skill tables

The number of ACDCALLS that are conferenced at least once.

This is a cumulative item.

Agent tables

The number of times that the agent completed a conference. A conference is considered completed when the agent pushes the conference key a second time.

This is a cumulative item.

Agent trace tables

An indication that the agent activated a conference. Valid values for CONFERENCE are 0, which means that the agent did not initiate a conference, and 1, which means that the agent did initiate a conference.

Call record tables

An indication that the answering agent initiated a conference on this call segment. Valid values for CONFERENCE are 0, which means that the agent did not initiate a conference, and 1, which means that the agent did initiate a conference.

CONNECTCALLS

The CONNECTCALLS item is included in the following database tables:

Trunk group tables

The number of INCALLS that are answered at a station and are not split/skill or direct agent ACD calls.

This is a cumulative item.

VDN tables

The number of non-ACD INCALLS that are delivered to a station extension (other than a VDN or direct agent login ID) by a “route to” or “adj rout link” vector command and that do not abandon. CONNECTCALLS includes ANSCONNCALLS1 through ANSCONNCALLS10.

This is a cumulative item.

CONNECTTIME

The CONNECTTIME item is included in the following database tables:

VDN tables

The length of time that CONNECTCALLS waited before being answered.

This is a cumulative item.

CONNTALKTIME

The CONNTALKTIME item is included in the following database tables:

VDN tables

The talk time for all CONNECTCALLS. CONNTALKTIME does not include HOLDTIME.

This is a cumulative item.

CONSULTTIME

The CONSULTTIME item is included in the following database tables:

Call record tables

The length of time that an agent talks on any outbound call while in AUX work, ACW, or in OTHER with a call on hold. This includes the time the originating agent spent talking to the destination party while establishing a conference or transferring a call, which is the time between presses of the transfer or conference button. CONSULTTIME includes wait time if the agent is calling a VDN or split/skill extension, but the wait time can be subtracted out by subtracting the DISPTIME item from CONSULTTIME.

CWC (index)

The CWC item is included in the following database tables:

Call work codes tables

The Call Work Code for which data was collected.

This is a row identifier item.

CWC1 through CWC5

The CWC1 through CWC5 items are included in the following database tables:

Call record tables

The first, second, third, fourth, or fifth Call Work Code entered by an agent for the Call Segment.

Items CWC1 through CWC5 are supported by the Multiple Call Work Codes per Call Record feature that was implemented in CMS R3V11.

This is a row identifier item.

DA_ABNCALLS

The DA_ABNCALLS item is included in the following database tables:

Agent tables

The number of direct agent ACD calls that are abandoned by callers while in queue or ringing at an agent telephone. DA_ABNCALLS includes calls that are considered abandoned because their talk time was less than the phantom-abandon call timer. The DA_ABNCALLS item is available with the ASAI or EAS feature.

This is a cumulative item.

DA_ABNTIME

The DA_ABNTIME item is included in the following database tables:

Agent tables

The length of time that DA_ABNCALLS wait in queue or ring before abandoning. DA_ABNTIME includes the time that elapses before the agent releases the call on phantom abandon calls. DA_ABNTIME is available with the ASAI or EAS feature.

This is a cumulative item.

DA_ACDCALLS

The DA_ACDCALLS item is included in the following database tables:

Agent tables

The number of direct agent ACD calls that the agent answers. DA_ACDCALLS is available with the ASAI or EAS feature. DA_ACDCALLS includes DA_RELEASE.

This is a cumulative item.

DA_ACDTIME

The DA_ACDTIME item is included in the following database tables:

Agent tables

The length of time that agents spend talking on DA_ACDCALLS. DA_ACDTIME does not include HOLDTIME. DA_ACDTIME is available with the ASAI or EAS feature.

This is a cumulative item.

DA_ACWINCALLS

The DA_ACWINCALLS item is included in the following database tables:

Split/skill tables

The number of inbound extension calls answered by ACW agents, who entered that work mode as a result of direct agent calls from this split/skill. Requires a communication server with the ASAI or EAS feature for direct agent calling.

This is a cumulative item.

Agent tables

The number of inbound extension calls answered by the ACW agent, who entered that work mode as a result of a direct agent call. Requires a communication server with the ASAI or EAS feature for direct agent calling.

This is a cumulative item.

DA_ACWINTIME

The DA_ACWINTIME item is included in the following database tables:

Split/skill tables

The length of time that agents spent on inbound extension calls that they answered while in ACW for direct agent ACD calls that queued through this split/skill. DA_ACWINTIME is available with the ASAI or EAS feature for direct agent calling.

This is a cumulative item.

Agent tables

The length of time that is spent on all DA_ACWINCALLS. DA_ACWINTIME does not include HOLDTIME. DA_ACWINTIME is available with the ASAI or EAS feature.

This is a cumulative item.

DA_ACWOADJCALLS

The DA_ACWOADJCALLS item is included in the following database tables:

Agent tables

The number of DA_ACWOCALLS that an ASAI adjunct placed on behalf of the agent. If these calls are placed to off-communication server destinations, they are also counted as DA_ACWOFFCALLS. The DA_ACWOADJCALLS item is available with the ASAI feature.

This is a cumulative item.

DA_ACWOCALLS

The DA_ACWOCALLS item is included in the following database tables:

Split/skill tables

Number of outbound extension calls made by ACW agents, who entered that work mode as a result of direct agent calls from this split/skill. Requires a communication server with the ASAI or EAS feature for direct agent calling.

This is a cumulative item.

Agent tables

The number of outbound extension calls made by the ACW agent, who entered that work mode as a result of a direct agent call. Requires a communication server with the ASAI or EAS feature for direct agent calling. DA_ACWOCALLS includes DA_ACWOADJCALLS and DA_ACWOFFCALLS.

This is a cumulative item.

DA_ACWOOFFCALLS

The DA_ACWOOFFCALLS item is included in the following database tables:

Agent tables

The number of DA_ACWOCALLS that are placed to an off-communication server destination. If these calls are placed by an ASAI adjunct on behalf of the agent, they are also counted as DA_ACWOADJCALLS. The DA_ACWOOFFCALLS item is available with the ASAI feature.

This is a cumulative item.

DA_ACWOOFFTIME

The DA_ACWOOFFTIME item is included in the following database tables:

Agent tables

The length of time that agents spend talking on all DA_ACWOOFFCALLS. DA_ACWOOFFTIME does not include HOLDTIME. DA_ACWOOFFTIME is included in DA_ACWOTIME. The DA_ACWOOFFTIME item is available the ASAI or EAS feature.

This is a cumulative item.

DA_ACWOTIME

The DA_ACWOTIME item is included in the following database tables:

Split/skill tables

The length of time that agents talk on outbound extension calls that they place while in ACW for a direct agent ACD call. The DA_ACWOTIME item is available with the ASAI or EAS feature.

This is a cumulative item.

Agent tables

The length of time that agents spend on DA_ACWOCALLS. DA_ACWOTIME does not include HOLDTIME. DA_ACWOTIME includes DA_ACWOFFTIME. The DA_ACWOTIME item is available with the ASAI or EAS feature.

This is a cumulative item.

DA_ACWTIME

The DA_ACWTIME item is included in the following database tables:

Agent tables

The duration of ACW that is associated with DA_ACDCALLS, including time on DA_ACWINCALLS and DA_ACWOCALLS. The DA_ACWTIME item is available with the ASAI or EAS feature.

This is a cumulative item.

DA_ANSTIME

The DA_ANSTIME item is included in the following database tables:

Agent tables

The length of time that calls spend in the direct agent queue and ringing before being answered. The DA_ANSTIME item is available with the ASAI or EAS feature.

This is a cumulative item.

DA_INACW (real-time)

The DA_INACW item is included in the following database tables:

Split/skill tables

The number of agents that are currently in ACW that is associated with direct agent calls. This includes agents who are on ACWIN or ACWOUT calls. DA_INACW is a subset of OTHER. The total number of agents in after call work = INACW + DA_INACW. The DA_INACW item is available with the ASAI or EAS feature for direct agent calling.

This is a status item.

DA_INQUEUE (real-time)

The DA_INQUEUE item is included in the following database tables:

Split/skill tables

The number of direct agent ACD calls that are currently waiting in this split/skill queue. The DA_INQUEUE item is available with the ASAI or EAS feature. This is a status item.

Agent tables

The number of direct agent calls that are currently waiting in any split/skill queue for this agent. The DA_INQUEUE item is available with the ASAI or EAS feature.

This is a status item.

DA_INRING (real-time)

The DA_INRING item is included in the following database tables:

Split/skill tables

The number of direct agent ACD calls that are currently ringing at an agent's telephone and that queued in this split/skill. The DA_INRING item is available with the ASAI or EAS feature.

This is a status item.

DA_OLDESTCALL (real-time)

The DA_OLDESTCALL item is included in the following database tables:

Split/skill tables

The length of time that the oldest direct agent ACD call has been waiting in queue or ringing at an agent position. The DA_OLDESTCALL item is available with the ASAI or EAS feature.

This is a status item.

Agent tables

The length of time that the oldest direct agent call has been waiting in any split/skill queue for this agent. The DA_OLDESTCALL item is available with the ASAI or EAS feature.

This is a status item.

DA_ONACD (real-time)

The DA_ONACD item is included in the following database tables:

Split/skill tables

The number of agents that are currently on direct agent ACD calls. DA_ONACD is a subset of OTHER. The total number of agents on split/skill and direct agent ACD calls is ONACD plus DA_ONACD. The DA_ONACD item is available with the ASAI or EAS feature.

This is a status item.

DA_OTHERCALLS

The DA_OTHERCALLS item is included in the following database tables:

Agent tables

The number of direct agent calls that are redirected to another destination before they are answered. Calls can be redirected as a result of call pickup, coverage, or Redirection on No Answer. The DA_OTHERCALLS item is available with the ASAI or EAS feature.

This is a cumulative item.

DA_OTHERTIME

The DA_OTHERTIME item is included in the following database tables:

Agent tables

The length of time that is spent in queue or ringing by DA_OTHERCALLS before they are redirected. The DA_OTHERTIME item is available with the ASAI or EAS feature.

This is a cumulative item.

DA_QUEUED

The DA_QUEUED item is included in the following database tables:

Call record tables

An indication of whether the call queued as a direct agent call. Valid values for DA_QUEUED are 0, which means that the call did not queue as a direct agent call, or 1, which means that the call did queue as a direct agent call.

DA_RELEASE

The DA_RELEASE item is included in the following database tables:

Agent tables

The number of direct agent ACD calls that are released or dropped by the agent before the far end releases. The DA_RELEASE item is available with the ASAI or EAS feature.

This is a cumulative item.

DA_SKILL (real-time)

The DA_SKILL item is included in the following database tables:

Agent tables

The skill that is currently assigned as the agent's direct agent skill. Direct agent calls to the agent are queued to this skill. The DA_SKILL item is available with the ASAI or EAS feature.

This is an administrative item.

DACALLS_FIRST (real-time)

The DACALLS_FIRST item is included in the following database tables:

Agent tables

An indication of whether a percent allocated agent (PCNT) has requested direct agent calls first to be delivered first. Valid values for DACALLS_FIRST are 0, which means that the agent has not made the request, and 1, which means that the agent has made a request for direct agent calls to be delivered first. The DACALLS_FIRST item is available on Avaya communication servers with the EAS or ASAI feature.

This is a administrative item.

DEFLECTCALLS

The DEFLECTCALLS item is included in the following database tables:

Vector tables

The number of calls that are deflected to the network using Network Call Redirection (NCR). Each NCR invoke attempt is counted in LOOKATTEMPTS and in INTERFLOWCALLS.

This is a cumulative item.

VDN tables

The number of calls that deflected to the network using NCR. Each NCR invoke attempt is counted in LOOKATTEMPTS and in INTERFLOWCALLS. The DEFLECTCALLS item is available on the DEFINITY® ECS R8.3 and later Avaya communication servers.

This is a cumulative item.

DEQUECALLS

The DEQUECALLS item is included in the following database tables:

Split/skill tables

The number of calls that queued to this split/skill as a nonprimary split/skill and whose disposition was recorded in another split/skill as answered, abandoned, outflowed, busy, or forced disconnect. The DEQUECALLS item is available with the Vectoring feature.

This is a cumulative item.

DEQUETIME

The DEQUETIME item is included in the following database tables:

Split/skill tables

The length of time that DEQUECALLS waited in this split/skill queue before dequeuing. The DEQUETIME item is available with the Vectoring feature.

This is a cumulative item.

DESTINATION (real-time)

The DESTINATION item is included in the following database tables:

Agent tables

The type of outbound call destination for the call on which the agent is active for any split/skill. Valid values can be PBX (internal call), OFF (external call), or as defined in the Dictionary. If the agent is not on an outbound call, the value is blank.

This is a status item.

DIALED_NUM

The DIALED_NUM item is included in the following database tables:

Call record tables

The number that the caller dialed. This number can be up to 24 digits long. DIALED_NUM is the VDN for inbound vectoring calls, blank for inbound calls without vectoring, and dialed digits for outbound calls.

DIGITS_DIALED

The DIGITS_DIALED item is included in the following database tables:

Agent trace tables

The digits that the agent dialed to originate a call. Trunk access codes, feature access codes, account codes, and authorization codes are not included.

DIRECTION (real-time)

The DIRECTION item is included in the following database tables:

Agent tables

The direction of the call that the agent is currently handling for any split/skill. Valid values are blank, IN, OUT, or as defined in Dictionary. If the agent is not on a call, the value is blank (NULL).

This is a status item.

Trunk tables

The current call direction of the trunk. Valid values are blank, IN, OUT, or as defined in Dictionary. The value is blank (NULL) if the trunk is idle.

This is a status item.

Agent trace tables

The direction of the call that the agent is currently handling for any split/skill. Valid values are blank, IN, OUT, or as defined in Dictionary. If the agent is not on a call, the value is blank (NULL).

DISCCALLS

The DISCCALLS item is included in the following database tables:

Split/skill tables

The number of CALLSOFFERED that executed the “disconnect” vector command. DISCCALLS also includes calls that are disconnected by the communication server when the vector disconnect timer expires.

This is a cumulative item.

Trunk group tables

The number of INCALLS that are disconnected by the communication server by the “disconnect” vector command. DISCCALLS also includes calls that are disconnected by the communication server when the vector disconnect timer expires or calls that reached the end of vector processing without being queued.

This is a cumulative item.

Vector tables

The number of INCALLS that executed the “disconnect” and “reply best” vector command. DISCCALLS also includes calls that are disconnected by the communication server when the vector disconnect timer expires or calls that reached the end of vector processing without being queued. DISCCALLS includes VDISCCALLS.

This is a cumulative item.

VDN tables

The number of INCALLS that were disconnected by the “disconnect” or “reply best” vector command. DISCCALLS also includes calls that are disconnected by the communication server when the vector disconnect timer expires or calls that reached the end of vector processing without being queued. DISCCALLS includes VDISCCALLS.

This is a cumulative item.

DISCTIME

The DISCTIME item is included in the following database tables:

Split/skill tables

The length of time that all DISCCALLS spent in this split's/skill's queue. If the call is disconnected because the vector disconnect timer expires, this is the time until the call is disconnected by the communication server.

This is a cumulative item.

Vector tables

The length of time that all DISCCALLS spent in this VECTOR. DISCTIME includes the time that elapses until the trunk drops following the forced disconnect command, or when the caller hangs up without listening to the entire announcement. When the caller listens to the entire announcement, DISCTIME is the length of time until the announcement ends and the caller is disconnected by the communication server, or when the vector disconnect timer expires.

This is a cumulative item.

VDN tables

The length of time that all DISCCALLS spent in this VDN. DISCTIME includes the time that elapses until the trunk drops following the forced disconnect command, or when the caller hangs up without listening to the entire announcement. When the caller listens to the entire announcement, DISCTIME is the length of time until the announcement ends and the caller is disconnected by the communication server, or when the vector disconnect timer expires.

This is a cumulative item.

DISPIVECTOR

The DISPIVECTOR item is included in the following database tables:

Call record tables

The number of the first vector that is associated with the disposition VDN (DISPVDN).

DISPOSITION

The DISPOSITION item is included in the following database tables:

Call record tables

An indication of the call disposition. Valid values for DISPOSITION are shown in the following table

Values for DISPOSITION

| Value | Description |
|-------|---|
| 1 | The call is connected (CONN, non-ACD call to a measured agent). A connected call is a non-ACD call to a measured agent for which CMS receives an indication that the call was connected. |
| 2 | The call is answered (ANS, split/skill or direct agent call answered by an agent). An answered call is any split/skill or direct agent ACD call for which CMS receives an indication that the call was answered by an agent and was not a phantom abandon. |
| 3 | The call is abandoned (ABAN). An abandoned call is any ACD call in which a caller hangs up before receiving an answer from an agent and for which CMS receives notification that the caller abandoned. Phantom abandons (PHANTOMABNS) are included as abandoned calls. |
| 4 | The call is interflowed (IFLOW). Interflowed calls are calls that are interflowed to an off-communication server destination |
| 5 | The call is forced busy (FBUSY). Forced busy calls are calls that CMS records as BUSYCALLS for the trunk group that carried them. These calls can be VDN calls that received a forced busy from the vector command or a split/skill call for a nonvector-controlled split that received a busy indication from the communication server because the split queue was full. |

Values for DISPOSITION

| Value | Description |
|--------------|---|
| 6 | The call is forced disconnect (FDISC). Forced disconnect calls are VDN calls that are disconnected by the communication server due to the execution of a disconnect vector command. Forced disconnect calls also include calls disconnected because of the vector disconnect timer or because they reached the end of vector processing without being queued. |
| 7 | The call has another disposition (OTHER). Other calls include any other calls that do not fall into the categories listed above. See the definition of OTHERCALLS in this chapter for additional information. |

DISPPRIORITY

The DISPPRIORITY item is included in the following database tables:

Call record tables

The priority that the call had at its disposition in this segment. Priorities can be:

Values for DISPPRIORITY

| Value | Description |
|--------------|---|
| 1 | No priority was assigned to the call. This disposition applies to communication servers that do not have the Vectoring feature. |
| 2 | The call was a priority call. This disposition applies to communication servers that do not have the Vectoring feature. |
| 3 | The call was assigned a low priority (LOW). |
| 4 | The call was assigned a medium priority (MED). |
| 5 | The call was assigned a high priority (HIGH). |
| 6 | The call was assigned a top priority (TOP). |

If the call is never queued to a split/skill, the priority is not set. With the Vectoring feature, calls directed to split/skills using “route to” or “messaging split/skill” commands and calls

directly routed to splits/skills without going through a vector have a MED priority or HIGH priority, depending on the class of restriction of the originator of the call. The originator of the call can be an agent, an extension, a trunk group, or a VDN.

DISPSKLEVEL

The DISPSKLEVEL item is included in the following database tables:

Call record tables

The skill level, from 1 through 16, that is associated with the skill in which the agent answered the call or, for calls that abandoned from ringing or from a direct agent queue, associated with the agent from whom the call abandoned.

DISPSPLIT

The DISPSPLIT item is included in the following database tables:

Call record tables

The number of the split/skill that is associated with the call at its disposition in this call segment. Calls that are not queued to a split/skill at the time of disposition have DISPSPLIT set to null. Calls that are queued to an unmeasured split/skill at the time of disposition have DISPSPLIT set to zero.

DISPTIME

The DISPTIME item is included in the following database tables:

Call record tables

The wait time in the vector, in queue, and ringing that elapses until the disposition is recorded in DISPOSITION for the segment. For extension calls that are placed directly to agents and not through a VDN, this is always zero.

DISPVDN

The DISPVDN item is included in the following database tables:

Call record tables

The number of the VDN that is associated with the call at its disposition for this call segment. DISPVDN is blank for calls that are not associated with a VDN at their disposition.

DURATION (real-time)

The DURATION item is included in the following database tables:

Agent tables

The length of time of the current WORKMODE and DIRECTION for this SPLIT. For example, the length of time in current AGSTATE for this SPLIT, in which case, if the agent goes from AUX to AUXOUT and back to AUX, DURATION restarts with each change in work mode.

This is a status item.

Trunk tables

The length of time that the trunk has been in TKSTATE.

This is a status item.

Agent trace tables

The length of time of the current WORKMODE and DIRECTION for this SPLIT. For example, the length of time in current AGSTATE for this SPLIT, in which case, if the agent goes from AUX to AUXOUT and back to AUX, DURATION restarts with each change in work mode.

Call record tables

The total time that the trunk was in use. This is the overall trunk holding time from the beginning of the call segment until the caller is disconnected. For the first segment of a call, this is the trunk holding time for the caller for the entire call, from the time the trunk is seized until the trunk is idle. With a transfer, the original trunk remains associated with both call segments until the call ends.

Data collection exception table

The length of time for which data collection was off.

EQLOC

The EQLOC item was modified with R3V8 CMS to be only eight characters long. It is nine characters long in earlier releases of CMS.

The EQLOC database item appears in the following tables.

Trunk tables

The physical equipment location, or trunk number, for which data was collected.

In the trunk tables, EQLOC is an index item.

This is an administrative item.

Call record tables

The physical equipment location, or trunk number, for which data was collected or for which the exception occurred. This is blank if the trunk is not measured.

This is an administrative item.

Trunk group exception table

The physical equipment location, or trunk number, for which data was collected or the exception occurred. This is an administrative item.

Malicious call trace exception table

The physical equipment location, or trunk number, for which data was collected or for which the exception occurred. This is blank if the trunk is not measured.

This is a administrative item.

EVENT1 through EVENT9

The EVENT1 through EVENT9 items appear in the following database tables:

Split/skill tables

The number of times each event (stroke count) feature button (feature button 1 to 9) was pressed by agents on split/skill or direct agent ACD calls or in after call work associated with an ACD call for this split/skill.

This is a cumulative item.

Agent tables

The number of times each event, or stroke count, feature button from 1 to 9 was pressed while the agent was on an ACD call or in call-related ACW.

This is a cumulative item.

Call record tables

The number of times each event, or stroke count, feature button from 1 to 9 was entered for this call segment.

EVENT_TIME

The EVENT_TIME item is included in the following database tables:

Agent trace tables

The time of day, in hour, minute, and second format, at which the WORKMODE or DIRECTION changed.

EWTHIGH (real-time)

The EWTHIGH item is included in the following database tables:

Split/skill tables

The communication server-calculated expected wait time (EWT) for calls that are queued at high priority in this split/skill. The EWT is an estimate of how long a caller will wait in queue at HIGH priority until being served. Time that is spent ringing at the agent is not included in this estimate. EWT and ASA should not be expected to match. ASA gives a historical perspective, whereas EWT changes constantly to match the current conditions on the communication server, such as queue length and staffing changes. The EWTHIGH item is available on Avaya communication servers with the Vectoring feature.

This is a status item.

EWTLOW (real-time)

The EWTLOW item is included in the following database tables:

Split/skill tables

The communication server-calculated EWT for calls that are queued at low priority in this split/skill. The EWT is an estimate of how long a caller will wait in queue at LOW priority until being served. Time that is spent ringing at the agent is not included in this estimate. EWT and ASA should not be expected to match. ASA gives a historical perspective, whereas EWT changes constantly to match the current conditions on the communication server, such as queue length and staffing changes. The EWTLOW item is available on Avaya communication servers with the Vectoring feature.

This is a status item.

EWTMEDIUM (real-time)

The EWTMEDIUM item is included in the following database tables:

Split/skill tables

The communication server-calculated EWT for calls that are queued at medium priority in this split/skill. The EWT is an estimate of how long a caller will wait in queue at MED priority until being served. Time that is spent ringing at the agent is not included in this estimate. EWT and ASA should not be expected to match. ASA gives a historical perspective, whereas EWT changes constantly to match the current conditions on the communication server, such as queue length and staffing changes. The EWTMED item is available on Avaya communication servers with the Vectoring feature.

This is a status item.

EWTTOP (real-time)

The EWTTOP item is included in the following database tables:

Split/skill tables

The communication server-calculated EWT for calls that are queued at top priority in this split/skill. The EWT is an estimate of how long a caller will wait in queue at TOP priority until being served. Time that is spent ringing at the agent is not included in this estimate. EWT and ASA should not be expected to match. ASA gives a historical perspective, whereas EWT changes constantly to match the current conditions on the communication server, such as queue length and staffing changes. The EWTTOP item is available on Avaya communication servers with the Vectoring feature.

This is a status item.

EXT_CALL_ORIG

The EXT_CALL_ORIG item is included in the following database tables:

Agent trace tables

An indication that the agent originated an external, off-communication server call.

EXTENSION

The EXTENSION item is included in the following database tables:

Agent tables

The extension number for which data was collected.

This is an administrative item.

Trunk tables

The extension to which this trunk is currently queued, ringing, or connected.

In the trunk tables, EXTENSION is a real-time item. This is a status item.

EXTN

The EXTN item is included in the following database tables:

Agent login/logout tables

The extension number of the station that the agent uses to log in.

EXTYPE

The EXTYPE item is included in the following database tables:

Agent exception table

The type of exception that occurred. Valid values for EXTYPE in the agent exception table are:

EXTYPE in the agent exception table

| Value | Type |
|-------|---|
| 1 | Time available |
| 2 | Minimum time on an inbound ACD call |
| 3 | Maximum time on an inbound ACD call |
| 4 | Time in ACW |
| 5 | Time on an outbound ACW call |
| 6 | Time on an inbound ACW call |
| 7 | Time in AUX work |
| 8 | Time on an outbound AUX call |
| 9 | Time on an inbound AUX call |
| 10 | Number of outbound ACW calls per agent |
| 11 | Number of inbound ACW calls per agent |
| 12 | Number of outbound AUX calls per agent |
| 13 | Number of inbound AUX calls per agent |
| 14 | Login identification |
| 15 | Time the ACD call spent on hold |
| 16 | Number of ACD calls placed on hold |
| 17 | Number of ACD calls abandoned while on hold |
| 18 | Minimum time on an outbound ACD call |
| 19 | Maximum time on an outbound ACD call |
| 20 | Number of calls transferred |

EXTYPE in the agent exception table

| Value | Type |
|-------|--|
| 21 | Time on an external outbound ACW call |
| 22 | Time on an external outbound AUX call |
| 23 | Time on a direct agent call |
| 24 | Number of external outbound ACW calls per agent |
| 25 | Number of external outbound AUX calls per agent |
| 26 | Time an ACD call spends ringing |
| 27 | Multiple logins on same extension |
| 28 | Ringing call was automatically redirected from the agent |
| 29 | Agent logged out with active or held calls |
| 30 | Number of calls in the direct agent queue |
| 31 | Time the call waited in the direct agent queue |
| 32 | Number of calls that abandoned from the direct agent queue |
| 34 | Number calls that outflowed from the direct agent queue |
| 38 | Number of calls that the agent transferred |
| 48 | Logout attempt without a valid reason code |
| 49 | Agent could not be logged in |
| 59 | AUX attempt without a valid reason code |
| 60 | Time in AUX with a reason code of 0 (default) |
| 61 | Time in AUX with a reason code of 1 |
| 62 | Time in AUX with a reason code of 2 |
| 63 | Time in AUX with a reason code of 3 |
| 64 | Time in AUX with a reason code of 4 |
| 65 | Time in AUX with a reason code of 5 |
| 66 | Time in AUX with a reason code of 6 |
| 67 | Time in AUX with a reason code of 7 |
| 68 | Time in AUX with a reason code of 8 |
| 69 | Time in AUX with a reason code of 9 |

EXTYPE in the agent exception table

| Value | Type |
|-------|---------------------------------------|
| 98 | Agent was denied login to some skills |
| 99 | Invalid call work code was entered |

Split/skill exception table

The type of exception that occurred. Valid values for EXTYPE in the split/skill exception table are:

EXTYPE in the split/skill exception table

| Value | Type |
|-------|--|
| 30 | Number calls waiting |
| 31 | Time the call waited in queue |
| 32 | Number of calls that abandoned |
| 33 | Number of intraflowed-in calls |
| 34 | Number of intraflowed-out calls |
| 35 | Number interflowed-out calls |
| 36 | Number of calls that were offered while the queue was full |
| 37 | Number of calls handled as backup |
| 38 | Number calls that were transferred |
| 39 | Average speed of answer in seconds |
| 40 | Rolling average speed of answer in seconds |
| 41 | EWT for TOP priority calls |
| 42 | EWT for HIGH priority calls |
| 43 | EWT for MED priority calls |
| 44 | EWT for LOW priority calls |

Trunk group exception table

The type of exception that occurred. Valid values for EXTYPE are:

EXTYPE in the trunk group exception table

| Value | Type |
|-------|---|
| 50 | Minimum time the trunk was in use |
| 51 | Maximum time the trunk was in use |
| 52 | Number of trunks in use |
| 53 | Time that any trunk was in the maintenance busy state |
| 54 | Number of trunks that are in the maintenance busy state |
| 55 | Length of time that all trunks are busy |
| 56 | Number of trunk failures in the trunk group |
| 57 | Number failures on a single trunk |
| 58 | Audio difficulty on a trunk |

VDN exception table

The type of exception that occurred. Valid values for EXTYPE in the VDN exception table are:

EXTYPE in the VDN exception table

| Value | Type |
|-------|---|
| 2 | Minimum time at an agent |
| 3 | Maximum time at an agent |
| 30 | Number of calls in an ACD split queue |
| 32 | Number of calls that abandoned while in vector processing |
| 33 | Number of calls that flowed into the VDN |
| 34 | Number of calls that flowed out of the VDN |
| 35 | Number of calls that interflowed out of the VDN |
| 37 | Number of calls that were handled by a backup split |
| 71 | Maximum time that is spent in vector processing |
| 72 | Number calls that were forced busy |

EXTYPE in the VDN exception table

| Value | Type |
|-------|---|
| 73 | Number of calls that were disconnected |
| 74 | Number of unsuccessful lookahead attempts |
| 75 | Adjunct routing was attempted |
| 76 | Rolling average speed of answer |

Vector exception table

The type of exception that occurred. Valid values for EXTYPE in the vector exception table are:

EXTYPE in the vector exception table

| Value | Type |
|-------|--|
| 30 | Number of calls in an ACD split/skill queue |
| 32 | Number of calls that abandoned while in the vector |
| 72 | Number of calls that were forced busy |
| 73 | Number calls that were disconnected |
| 74 | Number unsuccessful lookahead interflow, BSR, and NCR attempts |
| 75 | Number of unsuccessful adjunct routing attempts |
| 81 | Maximum time that is spent in the vector |

FAGINRING (real-time)

The FAGINRING item is included in the following database tables:

Split/skill tables

The number of flex agents (agents whose role is BCKP, ALLC, or ROVE) to whom this skill ACD call is ringing.

This is a status item.

FAVAILABLE (real-time)

The FAVAILABLE item is included in the following database tables:

Split/skill tables

The number of flex agents who are available to receive calls.

This is a status item.

FCALLS

The FCALLS item is included in the following database tables:

Current day report tables

The number of forecast calls carried.

FINACW (real-time)

The FINACW item is included in the following database tables:

Split/skill tables

The number of flex agents who are in ACW for this skill.

This is a status item.

FINAUX (real-time)

The FINAUX item is included in the following database tables:

Split/skill tables

The number of flex agents who are in AUX for this skill.

This is a status item.

FIRSTVDN

The FIRSTVDN item is included in the following database tables:

Call record tables

The number of the first VDN that is associated with the call segment. This is blank for calls that are not associated with a VDN.

FIRSTVECTOR

The FIRSTVECTOR item is included in the following database tables:

Call record tables

The number of the first vector that is associated with the first VDN for the call segment. This is blank if no vector is involved.

FMETHOD

The FMETHOD item is included in the following database tables:

Current day configuration tables

The type of trending used for forecast. Valid values for FMETHOD are 0, which means that no trending is used, 1, which means that seasonal trending is used, and 2, which means that current trending is used.

This is an administrative item.

FONACD (real-time)

The FONACD item is included in the following database tables:

Split/skill tables

The number of flex agents who are on ACD calls for this skill.

This is a status item.

FOTHER (real-time)

The FOTHER item is included in the following database tables:

Split/skill tables

The number of flex agents who are in the OTHER work state.

This is a status item.

FSTAFFED (real-time)

The FSTAFFED item is included in the following database tables:

Split/skill tables

The number of agents who are staffing this skill as other than top or reserve agents.

This is a status item.

GNAGINRING (real-time)

The GNAGINRING item is included in the following database tables:

Split/skill tables

The number of greatest need agents logged into the split/skill who currently have ACD calls ringing. GNAGINRING is available on Avaya communication servers with EAS.

This is a status item.

GNAVAILABLE (real-time)

The GNAVAILABLE item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are logged into the split/skill and available in the split/skill. The GNAVAILABLE item is available on Avaya communication servers with EAS.

This is a status item.

GNINACW (real-time)

The GNINACW item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are logged into the split/skill and in ACW. This includes agents on call-related ACW, on ACWIN or ACWOUT calls, and agents who are in ACW that is not associated with an ACD call. The GNINACW item is available on Avaya communication servers with EAS.

This is a status item.

GNINAUX (real-time)

The GNINAUX item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are logged into the split/skill in AUX on inbound or outbound extension calls. The GNINAUX item is available on Avaya communication servers with EAS.

This is a status item.

GNINAUX0 (real-time)

The GNINAUX0 item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are currently in AUX with a reason code of 0 (zero) for all splits/skills, including greatest need agents on AUXIN or AUXOUT calls. On Avaya communication servers with the EAS feature and reason codes active, reason code 0 (zero) is used for “system” AUX work.

This is a status item.

GNINAUX1 through GNINAUX9 (real-time)

The GNINAUX1 through GNINAUX9 items appear in the following database tables:

Split/skill tables

The number of greatest need agents who are currently in AUX with the reason codes 1 through 9 for all splits/skills, including greatest need agents on AUXIN or AUXOUT calls. The GNINAUX1 through GNINAUX9 items are available on Avaya communication servers with EAS and reason codes.

This is a status item.

GNINAUX10 through GNINAUX99 (real-time)

Note:

The GNINAUX10 through 99 items are available if you purchased the expanded AUX reason codes feature.

The GNINAUX10 through GNINAUX99 items appear in the following database tables:

Split/skill tables

The number of greatest need agents who are currently in AUX with the reason codes 10 through 99 for all splits/skills, including greatest need agents on AUXIN or AUXOUT calls. The GNINAUX10 through GNINAUX99 items are available on Avaya communication servers with EAS and reason codes.

This is a status item.

GNONACD (real-time)

The GNONACD item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are currently on inbound and outbound ACD calls to this split/skill. The GNONACD item is available on Avaya communication servers with EAS.

This is a status item.

GNONACDAUXOUT (real-time)

The GNONACDAUXOUT item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are currently on AUXOUT calls with an ACD call on hold for this split/skill. For greatest need agents in multiple skills with multiple call handling, the last call the agent put on hold was for this skill. The GNONACDAUXOUT item is available on Avaya communication servers with EAS.

This is a status item.

GNONACDOUT (real-time)

The GNONACDOUT item is included in the following database tables:

Split/skill tables

The number of greatest need agents that are currently on outbound calls that were placed by an adjunct to this split/skill. GNONACDOUT is available with the ASAI feature.

This is a status item.

GNONACWIN (real-time)

The GNONACWIN item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are currently in ACW for this split/skill and on inbound extension calls. These greatest need agents are also counted in INACW. GNONACWIN includes agents who are receiving extension calls while in ACW that is associated with split/skill ACD calls and while in ACW that is not associated with an ACD call. The GNONACWIN item is available on Avaya communication servers with EAS.

This is a status item.

GNONACWOUT (real-time)

The GNONACWOUT item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are currently in ACW for this split/skill and on outbound extension calls. These greatest need agents are also counted in INACW. GNONACWOUT includes agents who are making extension calls while in ACW that is associated with split/skill ACD calls and while in ACW that is not associated with an ACD call. The GNONACWOUT item is available on Avaya communication servers with EAS.

This is a status item.

GNONAUXIN (real-time)

The GNONAUXIN item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are currently in AUX work, AVAILABLE, have an ACD, AUXIN, or AUXOUT call on hold, and are on inbound extension calls where SPLIT is OLDEST LOGON. The GNONAUXIN item is available on Avaya communication servers with EAS.

This is a status item.

GNONAUXOUT (real-time)

The GNONAUXOUT item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are currently in AUX work, AVAILABLE, have an ACD, AUXIN, or AUXOUT call attributed to this split/skill on hold, and are on outbound extension calls. The GNONAUXOUT item is available on Avaya communication servers with EAS.

This is a status item.

GNDA_INACW (real-time)

The GNDA_INACW item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are currently ACW that is associated with direct agent calls, including greatest need agents who are on ACWIN or ACWOUT calls. GNDA_INACW is a subset of GNOTHER. The total number of agents in ACW equals GNINACW plus GNDA_INACW. The GNDA_INACW item is available on Avaya communication servers with the ASAI or EAS feature.

This is a status item.

GNDA_ONACD (real-time)

The GNDA_ONACD item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are currently on direct agent ACD calls. GNDA_ONACD is a subset of GNOTHER. The total number of greatest need agents on split/skill and direct agent ACD calls equals GNONACD plus GNDA_ONACD. The GNDA_ONACD item is available on Avaya communication servers with the ASAI or EAS feature.

This is a status item.

GNOTHER (real-time)

The GNOTHER item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are doing other work. Agent POSITIONS show up in OTHER directly after the link to the communication server is initiated and directly after the agents log in before the CMS is notified of the agent's work state.

While the agent is in Auto-In or Manual-In, other work for this split/skill includes the amount of time that is spent doing any of the following:

- An agent puts any call on hold and performs no further action.
- The agent is on a direct agent call or in ACW for a direct agent call.
- The agent is dialing to place a call or to activate a feature.
- An extension call or a direct agent ACD call is ringing with no other activity.
- The length of time agents were logged into multiple splits/skills and doing work for a split/skill other than this one.

With the EAS feature and multiple call handling, agents are available in other multiple call handling skills, but not in this skill. The GNOTHER item is available on Avaya communication servers with EAS.

This is a status item.

GNSKILL (real-time)

The GNSKILL item is included in the following database tables:

Agent tables

The skill level that is assigned so that the greatest need agent handles calls in the preferred order. The agent's first-administered, highest-level, measured skill is the greatest need skill, in which a skill level of 1 is the highest call handling preference and skill level 16 is the lowest skill level preference. The GNSKILL item is available on Avaya communication servers with EAS.

This is an administrative item.

GNSTAFFED (real-time)

The GNSTAFFED item is included in the following database tables:

Split/skill tables

The number of greatest need agents who are currently staffed in SPLIT. The GNSTAFFED item is available on Avaya communication servers with EAS.

This is a status item.

GOTOCALLS

The GOTOCALLS item is included in the following database tables:

Vector tables

The number of OUTFLOWCALLS that are redirected to another vector by way of a "go to vector" command.

This is a cumulative item.

GOTOTIME

The GOTOTIME item is included in the following database tables:

Vector tables

The time that all GOTOCALLS spent in this vector before being redirected to another vector. This is a cumulative item.

HDATE1 through HDATE4

The HDATE1 through HDATE4 items appear in the following database tables:

Current day configuration tables

The date of the first (HDATE1), second (HDATE2), third (HDATE3), and fourth (HDATE4) days of historical data that is to be used.

This is an administrative item.

HELD

The HELD item is included in the following database tables:

Call record tables

The total number of times that this call was placed on hold by the answering agent in this call segment. With agent-to-agent calls, this count is incremented for the agent who puts the call on hold but not for the calling agent. The HELD item applies to all of the calls that the agent puts on hold.

HIGHCALLS

The HIGHCALLS item is included in the following database tables:

Split/skill tables

The number of ACDCALLS with high priority that are answered by agents in this split/skill, for example, answered calls that are queued to the split/skill with high priority by a “queue to” or “check” vector command. This includes calls that are queued to a split/skill with priority using the “route to” or “messaging split/skill” vector commands, and calls that queued directly to a split/skill with priority. Priority in these cases is determined by the class of restriction of the originator, which is an agent, an extension, a trunk group or a VDN. The HIGHCALLS item is available with the Vectoring feature.

This is a cumulative item.

HOLDABN

The HOLDABN item is included in the following database tables:

Call record tables

An indication of whether this call abandoned from hold in this call segment. Valid values for HOLDABN are 0, which means that the call did not abandon from hold, and 1, which means that “yes” the call did abandon from hold. The HOLDABN item applies to all of the calls that the agent put on hold.

HOLDABNCALLS

The HOLDABNCALLS item is included in the following database tables:

Split/skill tables

The number of times that split/skill ACD callers abandoned the call while on hold.

This is a cumulative item.

Agent tables

The number of times that callers abandoned while on hold. The HOLDABNCALLS item applies to all of the calls that the agent put on hold.

This is a cumulative item.

VDN tables

The number of times that callers abandoned while on hold. The HOLDABNCALLS item applies to all of the calls that the agent put on hold.

This is a cumulative item.

HOLDACDCALLS

The HOLDACDCALLS item is included in the following database tables:

VDN tables

The number of split/skill or direct agent ACD calls that are placed on hold at least one time.

This is a cumulative item.

HOLDACDTIME

The HOLDACDTIME item is included in the following database tables:

Agent tables

The length of time that split/skill and direct agent ACD calls spend on hold at the agent's telephone. This includes time that the agent spends on AUXIN or AUXOUT calls with the ACD call on hold.

This is a cumulative item.

VDN tables

The length of time that split/skill or direct agent ACD callers spend on hold.

This is a cumulative item.

HOLDCALLS

The HOLDCALLS item is included in the following database tables:

Split/skill tables

The number of split/skill ACD calls that are placed on hold at least once.

HOLDCALLS includes HOLDABNCALLS.

This is a cumulative item.

Agent tables

The number of calls that are placed on hold at least once. HOLDCALLS includes HOLDABNCALLS. The HOLDCALLS item applies to all of the calls that the agent put on hold.

This is a cumulative item.

VDN tables

The number of calls that are placed on hold at least once. HOLDCALLS includes HOLDABNCALLS and HOLDACDCALLS. The HOLDCALLS item applies to all of the calls that the agent put on hold.

This is a cumulative item.

HOLDTIME

The HOLDTIME item is included in the following database tables:

Split/skill tables

The length of time that split/skill ACD callers spend on hold.

This is a cumulative item.

Agent tables

The length of time that split/skill ACD callers spend on hold. HOLDTIME includes HOLDACDTIME.

This is a cumulative item.

VDN tables

The length of time that callers spend on hold. HOLDTIME includes HOLDACD TIME. HOLDTIME applies to all of the calls that the agent puts on hold.

This is a cumulative item.

I_ACDAUXINTIME

The I_ACDAUXINTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were talking on AUXIN calls with a split/skill ACD call on hold where SPLIT is OLDEST_LOGON.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent spent talking on AUXIN calls with at least one split/skill or direct agent ACD call on hold. For agents in multiple splits/skills, this time is recorded in the record in which SPLIT is OLDEST_LOGON.

This is a cumulative item.

I_ACDAUX_OUTTIME

The I_ACDAUX_OUTTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents spent dialing and talking on AUXOUT calls with a split/skill ACD call for this split/skill on hold. In a multiple call handling environment with agents in multiple skills, the ACD call for this skill must have been the last ACD call to have been put on hold before the agent placed the AUXOUT call.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent spent dialing and talking on AUXOUT calls with at least one split/skill or direct agent ACD call on hold.

This is a cumulative item.

I_ACDOOTHERTIME

The I_ACDOOTHERTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents spent in the OTHER state with a split/skill ACD call on hold. Instances of the OTHER state include, dialing an outgoing call, a ringing extension call, or having calls on hold and with no other state selected.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent spent in the OTHER state with at least one split/skill or direct agent ACD call on hold. Instances of the OTHER state include, dialing an outgoing call, a ringing extension call, or having calls on hold and with no other state selected.

This is a cumulative item.

I_ACDTIME

The I_ACDTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were on split/skill ACD calls. I_ACDTIME includes time on O_ACDCALLS and ACDCALLS. I_ACDTIME includes I_ACDTIME_R1 and I_ACDTIME_R2 when reserve agents are used.

I_ACDTIME_R1 and I_ACDTIME_R2 are available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent was talking on ACD calls for this SPLIT.

I_ACDTIME includes time on O_ACDCALLS. I_ACDTIME does not include HOLDDTIME.

This is a cumulative item.

I_ACDTIME_R1

The I_ACDTIME_R1 item appears in the following database table:

Split/skill tables

The time during the collection interval that Reserve Level 1 agents were on ACD calls for this skill. I_ACDTIME_R1 includes time on outgoing ACD calls placed by an adjunct. Reserve Level 1 agents will continue to accumulate I_ACDTIME_R1 if the skill returns to Normal while an ACD call is active.

I_ACDTIME_R1 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_ACDTIME_R2

The I_ACDTIME_R2 item appears in the following database table:

Split/skill tables

The time during the collection interval that Reserve Level 2 agents were on ACD calls for this skill. This includes time on outgoing ACD calls placed by an adjunct. Reserve Level 2 agents will continue to accumulate I_ACDTIME_R2 if the skill returns to Normal while an ACD call is active.

I_ACDTIME_R2 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_ACWINTIME

The I_ACWINTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were in ACW for this split/skill and on inbound extension calls. The ACW can be associated with a split/skill ACD call or not associated with a call. I_ACWINTIME does not include the time that inbound extension calls spend on hold.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent was in ACW and on inbound extension calls. I_ACWINTIME includes ACW for split/skill ACD calls and ACW that is not associated with a call. I_ACWINTIME does not include the time that inbound ACW calls spend on hold.

This is a cumulative item.

I_ACWOUTTIME

The I_ACWOUTTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were in ACW for this split/skill and on outbound extension calls. The ACW can be associated with a split/skill ACD call or not associated with a call. I_ACWOUTTIME does not include the time that outbound extension calls spend on hold.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent was in ACW and on outbound extension calls. I_ACWOUTTIME includes ACW for split/skill ACD calls and ACW that is not associated with a call. I_ACWOUTTIME does not include the time ACWOUT calls spend on hold.

This is a cumulative item.

I_ACWTIME

The I_ACWTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were in ACW for this split/skill. The ACW can be associated with a split/skill ACD call or not associated with a call.

I_ACWTIME includes I_ACWINTIME, I_ACWOUTTIME. I_ACWTIME includes I_ACWTIME_R1 and I_ACWTIME_R2 when reserve agents are used.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent is in ACW. This includes ACW for split/skill ACD calls and ACW that is not associated with a call. I_ACWINTIME and I_ACWOUTTIME include time for direct agent ACW in and out calls, but I_ACWTIME does not include this time. Therefore, the sum of I_ACWINTIME and I_ACWOUTTIME may be greater than I_ACWTIME. I_ACWTIME includes the portions of I_ACWINTIME and I_ACWOUTTIME that are not associated with direct agent calls.

This is a cumulative item.

I_ACWTIME_R1

The I_ACWTIME_R1 item is included in the following database tables:

Split/skill tables

The time during the collection interval that Reserve Level 1 agents were in ACW in this skill, either associated with a skill ACD call or not associated with a call. This item includes the time that agents in ACW spent on inbound extension calls or outbound extension calls. (ACWINTIME and ACWOUTTIME are included and not broken out in separate R1 database items.) Reserve Level 1 Agents will continue to accumulate I_ACWTIME_R1 if the skill returns to Normal while the agent is in ACW or an ACD call and goes into ACW upon completing the call.

I_ACWTIME_R1 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_ACWTIME_R2

The I_ACWTIME_R2 item is included in the following database tables:

Split/skill tables

The time during the collection interval that Reserve Level 2 agents were in ACW in this skill, either associated with a skill ACD call or not associated with a call. This item includes the time that agents in ACW spent on inbound extension calls or outbound extension calls. (ACWINTIME and ACWOUTIME are included and not broken out into separate R2 database items.) Reserve Level 2 Agents will continue to be tracked in I_ACWTIME_R2 if the skill returns to Normal while the agent is in ACW or on an ACD call and goes into ACW upon completing the call.

I_ACWTIME_R2 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_ARRIVED

The I_ARRIVED item is included in the following database tables:

VDN tables

The number of calls that reached this VDN during this interval.

This is a cumulative item.

Split/Skill tables

The number of calls that reached this Split/Skill during this interval. This is a cumulative item.

I_AUTORESERTIME

The I_AUTORESERTIME item appears in the split/skill tables

This item stores the time during the collection interval that at least one agent was auto-reserved for this skill.

I_AUXINTIME

The I_AUXINTIME item is included in the following database tables:

Agent tables

The length of time during the collection interval that the agent was in AUX work or AVAILABLE and on an inbound extension call. I_AUXINTIME includes the length of time when an ACD, AUXIN, or AUXOUT call is on hold and the time the agent is on inbound extension calls and SPLIT is the OLDEST_LOGON. I_AUXINTIME includes I_ACDAUXINTIME but does not include the time these calls spent on hold.

This is a cumulative item.

Split/Skill tables

The time during the collection interval that agents were in AUX work or AVAILABLE and on an inbound extension call. I_AUXINTIME includes the length of time when an ACD, AUXIN, or AUXOUT call is on hold and the time the agent is on inbound extension calls. I_AUXINTIME includes I_ACDAUXINTIME but does not include time inbound extension calls spent on hold.

This is a cumulative item.

I_AUXOUTTIME

The I_AUXOUTTIME item is included in the following database tables:

Agent tables

The length of time during the collection interval that the agent was in AUX work, AVAILABLE, had an ACD, AUXIN, or AUXOUT call on hold and on outbound extension calls. When the agent was in AUX work, AVAILABLE, or had an AUXIN or AUXOUT call on hold, the AUXOUT time and calls are recorded for the SPLIT that is the OLDEST_LOGON. When the agent had an ACD call on hold, SPLIT is the split/skill associated with the last ACD call put on hold. I_AUXOUTTIME includes I_ACDAUX_OUTTIME but does not include the time calls spent on hold.

This is a cumulative item.

Split/Skill tables

The length of time during the collection interval that the agent was in AUX work, AVAILABLE, or had an AUXIN or AUXOUT call is on hold, and on outbound extension calls. This does not include time outbound extension calls spent on hold.

This is a cumulative item.

I_AUXSTBYTIME

The I_AUXSTBYTIME item is included in the following database tables:

Agent tables

The time during the collection interval that an Agent was in AUX Work state while the skill was Normal. This database item is valid only for agents administered as Reserve Level 1 or Reserve Level 2 for a skill.

If the skill goes from Normal to Overload 1, or from Overload 1 to Overload, depending on if the Agent is Reserve 1 or Reserve 2, the agent will stop accumulating I_AUXSTBYTIME and start accumulating I_AUXTIME.

I_AUXSTBYTIME is not included in I_STAFFTIME or I_AUXTIME.

Note:

When the skill is Normal, the individual Reserve Agent's time for that skill is tracked as I_OTHERSTBYTIME and I_AUXSTBYTIME.

I_AUXSTBYTIME is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_AUXSTBYTIME_R1

The I_AUXSTBYTIME_R1 item is included in the following database tables:

Split/Skill tables

The time during the collection interval that Reserve Level 1 agents were in AUX Work and in standby because the skill is not in overload 1 or 2. Unlike I_AUXTIME, this item is not broken down into separate items, for call direction, or reason codes. If the skill goes from

Normal to overload 1 the agent will stop accumulating I_AUXSTBYTIME_R1 and start accumulating I_AUXTIME_R1.

I_AUXSTBYTIME_R1 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_AUXSTBYTIME_R2

The I_AUXSTBYTIME_R2 item is included in the following database tables:

Split/Skill tables

The time during the collection interval that Reserve Level 2 agents were in AUX Work and in standby because the skill is not in overload 2. Unlike I_AUXTIME, this item is not broken down into separate items, for call direction, or reason codes. If the skill goes from overload 1 to overload 2 the agent will stop accumulating I_AUXSTBYTIME_R2 and start accumulating I_AUXTIME_R2.

I_AUXSTBYTIME_R2 is available with Advocate Service Level Supervisor working with CMS R3V11 or later. This is a cumulative item.

I_AUXTIME

The I_AUXTIME item is included in the following database tables:

Split/Skill tables

The length of time during the collection interval that agents are in AUX in this skill. I_AUXTIME includes I_AUXTIME0, I_AUXTIME1 through I_AUXTIME9, I_AUXTIME10 through I_AUXTIME99, I_AUXINTIME, I_AUXOUTTIME, I_TAUXTIME.

I_AUXTIME includes I_AUXTIME_R1 and I_AUXTIME_R2 when the reserve agents are active. I_AUXTIME does not include I_AUXSTBYTIME_R1 and I_AUXSTBYTIME_R2.

This is a cumulative item.

Agent tables

The length of time that the agent spends in AUX work. When an agent is in AUX work in multiple splits/skills, this time is recorded in each split/skill in which the agent is in AUX.

Reserve Agents only accumulate I_AUXTIME when the skill is in overload 1, or when a reserve agent goes from active to standby I_AUXTIME stops accumulating and I_AUXSTBYTIME starts accumulating for that agent.

I_AUXTIME includes I_AUXINTIME and I_AUXOUTTIME. I_AUXTIME does not include I_AUXSTBYTIME.

This is a cumulative item.

I_AUXTIME_R1

The I_AUXTIME_R1 item is included in the following database tables:

Split/Skill tables

The time during the collection interval that Reserve Level 1 agents spent in AUX Work for this skill while the skill was in overload 1. Includes all AUX time including time on extension calls from the AUX state. Unlike I_AUXTIME, this item is not broken down into separate items for call direction, or reason codes. If the skill goes from overload 1 to Normal the agent will stop accumulating I_AUXTIME_R1 and start accumulating I_AUXSTBYTIME_R1.

I_AUXTIME_R1 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_AUXTIME_R2

The I_AUXTIME_R2 item is included in the following database tables:

Split/Skill tables

The time during the collection interval that Reserve Level 2 agents were in AUX in this skill while the skill was in overload 2. Includes all AUX time including time on extension calls from the AUX state. Unlike I_AUXTIME, this item is not broken down into separate items for call direction, or reason codes. If the skill goes from overload 2 to overload 1 the agent will stop accumulating I_AUXTIME_R2 and start accumulating I_AUXSTBYTIME_R2.

I_AUXTIME_R2 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_AUXTIME0

The I_AUXTIME0 item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were in AUX for reason code 0 in this split/skill. This includes time on extension calls from this AUX state. For communication servers with AUX reason codes active, this represents time agents spent in “system” AUX. For communication servers without the EAS feature and AUX reason codes active and prior to R5, I_AUXTIME0 is the same as I_AUXTIME.

This is a cumulative item.

I_AUXTIME1 through I_AUXTIME9

The I_AUXTIME1 through I_AUXTIME9 items appear in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were in AUX for each reason code 1 through 9 in this skill. This includes time on extension calls from each AUX state. This feature is available on Avaya communication servers with the EAS and AUX Reason Code feature.

This is a cumulative item.

I_AUXTIME10 through I_AUXTIME99

Note:

The I_AUXTIME10 through 99 items are available if you purchased the expanded AUX reason codes feature.

The I_AUXTIME10 through I_AUXTIME99 items appear in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were in AUX for each reason code 10 through 99 in this skill. This includes time on extension calls from each AUX state.

This feature is available on Avaya communication servers with the EAS and AUX Reason Code feature.

This is a cumulative item.

I_AVAILTIME

The I_AVAILTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were available for calls from this split/skill.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent was available for ACD calls in this split/skill. This is a cumulative item.

I_BEHINDTIME

The I_BEHINDTIME item appears in the split/skill tables.

This item stores the amount of time that a skill has the potential of not meeting the assigned target service level percentage and no agents were auto-reserved.

I_DA_ACDTIME

The I_DA_ACDTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that the agent spent talking on direct agent ACD calls queued through this split/skill. I_DA_ACDTIME is a subset of I_OTHERTIME.

The I_DA_ACDTIME item is available with the ASAI or EAS feature.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent spent talking on direct agent calls. I_DA_ACDTIME does not include HOLDDTIME. The I_DA_ACDTIME item is available with the ASAI or EAS feature.

This is a cumulative item.

I_DA_ACWTIME

The I_DA_ACWTIME item is included in the following database tables:

Split/skill tables

The length of time that agents spent in ACW for direct agent ACD calls that queued through this split/skill. I_DA_ACWTIME is a subset of I_OTHERTIME. The I_DA_ACWTIME is available with the ASAI or EAS feature.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent was doing ACW that was associated with direct agent ACD calls. The I_DA_ACWTIME item is available with the ASAI or EAS feature.

This is a cumulative item.

I_INOCC

The I_INOCC item is included in the following database tables:

Trunk group tables

The total length of time during the collection interval that trunks in the trunk group were occupied by incoming calls. If an incoming call on a measured trunk is transferred off of the communication server, the incoming trunk remains in use for the call and accrues trunk holding time until the caller drops or the call is released.

This is a cumulative item.

Trunk tables

The total length of time during the collection interval that the trunk was occupied by incoming calls. If an incoming call on a measured trunk is transferred off of the communication server, the incoming trunk remains in use for the call and accrues trunk holding time until the caller drops or the call is released.

This is a cumulative item.

I_NORMTIME

The I_NORMTIME item is included in the following database tables:

Split/skill tables

The length of time that the skill spent under all administered overload thresholds.

The I_NORMTIME item is available on Avaya communication servers with the EAS feature.

This is a cumulative item.

I_OL1TIME

The I_OL1TIME item is included in the following database tables:

Split/skill tables

The length of time that the skill spent in overload threshold 1.

The I_OL1TIME item is available on Avaya communication servers with the EAS feature.

This is a cumulative item.

I_OL2TIME

The I_OL2TIME item is included in the following database tables:

Split/skill tables

The length of time, that the skill spent in overload threshold 2.

The I_OL2TIME item is available on Avaya communication servers with the EAS feature.

This is a cumulative item.

I_OTHERSTBYTIME

The I_OTHERSTBYTIME item is included in the following database tables:

Agent tables

The time during the collection interval that the Agent was logged into the skill and in standby because the skill was not in overload 1 or 2. This database item is valid only for agents administered as Reserve Level 1 or Reserve Level 2 for a skill.

Note:

Reserve Level 1 agents that are working on a call for another skill when the reserve skill goes into an overload condition will stop being tracked as I_OTHERSTBYTIME_R1 and start being tracked as I_OTHERTIME_R1.

I_OTHERSTBYTIME is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

I_OTHERSTBYTIME is not included in I_STAFFTIME or I_OTHERTIME.

This is a cumulative item.

I_OTHERSTBYTIME_R1

The I_OTHERSTBYTIME_R1 item is included in the following database tables:

Split/skill tables

The time during the collection interval that Reserve Level 1 agents were logged into this skill and in standby. I_OTHERSTBYTIME_R1 accumulates while the skill (for which the agent is Reserve Level 1) is Normal.

I_OTHERSTBYTIME is not included in I_STAFFTIME, I_OTHERTIME or I_OTHERTIME_R1.

Note:

Reserve Level 1 agents that are working on a call for another skill when the reserve skill goes into an overload condition will stop being tracked as I_OTHERSTBYTIME_R1 and start being tracked as I_OTHERTIME_R1.

I_OTHERSTBYTIME_R1 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_OTHERSTBYTIME_R2

The I_OTHERSTBYTIME_R2 item is included in the following database tables:

Split/skill tables

The time during the collection interval that Reserve Level 2 agents were staffed in this skill and in standby. I_OTHERSTBYTIME_R2 accumulated while the skill (for which the agent is Reserve Level 2) is not in overload 2.

Note:

Reserve Level 2 agents that are working on a call for another skill when the reserve skill goes into an overload condition will stop being tracked as I_OTHERSTBYTIME_R2 and start being tracked as I_OTHERTIME_R2.

I_OTHERSTBYTIME_R2 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_OTHERTIME

The I_OTHERTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents spent doing other work. I_OTHERTIME is collected for the time period after the link to the communication server is initiated or after the agent logs in and before the CMS receives notification of the agent's state from the communication server.

While the agent is in Auto-In or Manual-In, other work for this split/skill includes the amount of time that is spent doing any of the following:

- An agent put any call on hold and perform no further action.
- The agent is on a direct agent call or in ACW for a direct agent call.
- The agent is dialing to place a call or to activate a feature.
- An extension call or a direct agent ACD call is ringing with no other activity.
- The length of time agents were logged into multiple splits/skills and doing work for a split/skill other than this one.

With the EAS feature and multiple call handling, agents are available in other multiple call handling skills, but not in this skill. I_OTHERTIME includes I_ACDOTHERTIME, I_DA_ACDTIME, I_DA_ACWTIME.

I_OTHERTIME includes I_OTHERTIME_R1 and I_OTHERTIME_R2.

I_OTHERTIME does not include I_OTHERSTBYTIME_R1 or I_OTHERSTBYTIME_R2.

Agent tables

The length of time that the agent was doing other work. Reserve agents only accumulate I_OTHERTIME when the skill is in overload 1 or 2.

I_OTHERTIME includes I_ACDOTHERTIME, I_DA_ACDTIME, and I_DA_ACWTIME.

I_OTHERTIME does not include I_OTHERSTBYTIME.

This is a cumulative item.

I_OTHERTIME_R1

The I_OTHERTIME_R1 item is included in the following database tables:

Split/skill tables

The time during the collection interval that Reserve Level 1 agents were doing other work while the skill is in overload 1.

I_OTHERTIME_R1 is collected for the time period after the link to the communication server comes up or after the agent logs in and before the CMS receives notification of the agent's state from the communication server. Other work includes: while in Auto-In or Manual-In mode, the agent put any call on hold and performed no further action; the agent had a direct agent call ringing, was on a direct agent call or in ACW for a direct agent call; the agent dialed to place a call or activate a feature; or an extension-in call rang at the agent's terminal with no other activity. Also includes the time Reserve agents were logged into multiple skills and doing work for a skill other than this one (with an ACD call ringing, talking on an ACD call, or in ACW for a skill other than this one.)

If the skill goes from overload 1 to Normal the agent will stop accumulating I_OTHERTIME_R1 and start accumulating I_OTHERSTBYTIME_R1.

I_OTHERTIME_R1 does not include I_OTHERSTBYTIME_R1.

I_OTHERTIME_R1 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_OTHERTIME_R2

The I_OTHERTIME_R2 item is included in the following database tables:

Split/skill tables

The time during the collection interval that Reserve Level 2 agents were doing other work while the skill is in overload 2.

I_OTHERTIME_R2 is collected for the time period after the link to the communication server comes up or after the agent logs in and before the CMS receives notification of the agent's state from the communication server. Other work includes: while in Auto-In or Manual-In mode, the agent put any call on hold and performed no further action; the agent had a direct agent call ringing, was on a direct agent call or in ACW for a direct agent call; the agent dialed to place a call or activate a feature; or an extension-in call rang at the agent's terminal with no other activity. Also includes the time Reserve agents were logged

into multiple skills and doing work for a skill other than this one (with an ACD call ringing, talking on an ACD call, or in ACW for a skill other than this one.)

If the skill goes from overload 2 to overload 1 the agent will stop accumulating I_OTHERTIME_R2 and start accumulating I_OTHERSTBYTIME_R2.

I_OTHERTIME_R2 does not include I_OTHERSTBYTIME_R2.

I_OTHERTIME_R2 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_OUTOCC

The I_OUTOCC item is included in the following database tables:

Trunk group tables

The length of time during the collection interval that trunks in this trunk group were occupied by outgoing calls.

This is a cumulative item.

Trunk tables

The length of time during the collection interval that this trunk was occupied by outbound calls.

This is a cumulative item.

I_RINGTIME

The I_RINGTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were in the ringing state for calls to this split/skill. If the agent changes work modes or answers/makes another call instead of answering the ringing call, I_RINGTIME will stop accumulating. RINGTIME is the length of time that the caller spends ringing and is independent of agent activity. With forced multiple call handling if an ACD call rings at the agent's telephone while the agent is

talking on another call, I_RINGTIME does not accumulate. I_RINGTIME includes I_RINGTIME_R1 and I_RINGTIME_R2 when the reserve agents are active.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent had split/skill and direct agent ACD calls ringing. If the agent changes work modes or makes/receives another call instead of answering the ringing call, I_RINGTIME will stop accumulating. RINGTIME is the length of time that the caller spends ringing and is independent of agent activity.

This is a cumulative item.

I_RINGTIME_R1

The I_RINGTIME_R1 item is included in the following database tables:

Split/skill tables

The time during the collection interval that Reserve Level 1 agents were in the ringing state for calls to this skill. Reserve Level 1 agents will continue to accumulate I_RINGTIME_R1 if the skill returns to Normal while a call is ringing.

I_RINGTIME_R1 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_RINGTIME_R2

The I_RINGTIME_R2 item is included in the following database tables:

Split/skill tables

The time during the collection interval that Reserve Level 2 agents were in the ringing state for calls to this skill. Reserve Level 2 agents will continue to accumulate I_RINGTIME_R2 if the skill returns to Normal while a call is ringing.

I_RINGTIME_R2 is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a cumulative item.

I_STAFFTIME

The I_STAFFTIME item is included in the following database tables:

Split/skill tables

The length of time during the collection interval that agents were logged in. I_STAFFTIME includes I_ACDTIME, I_ACWTIME, I_AUXTIME, I_AVAILTIME, I_OTHERTIME, and I_RINGTIME.

NOTE:

With Service Level Supervisor I_STAFFTIME includes only the time that reserve agents are activated in this skill. I_STAFFTIME does not include I_OTHERSTBYTIME_R1, I_OTHERSTBYTIME_R2, I_AUXSTBYTIME_R1, or I_AUXSTBYTIME_R2.

This is a cumulative item.

Agent tables

The length of time during the collection interval that the agent was logged in to this split/skill. Reserve agents only accumulate STAFFTIME when the skill is in overload 1 or 2.

I_STAFFTIME includes I_AUXTIME, I_AVAILTIME, I_ACDTIME, I_ACWTIME, I_DA_ACDTIME, I_DA_ACWTIME, I_OTHERTIME, and I_RINGTIME.

I_STAFFTIME does not include I_AUXSTBYTIME or I_OTHERSTBYTIME.

This is a cumulative item.

I_TAUXTIME

The I_TAUXTIME item is included in the following database tables:

Split/skill tables

The length of time that top agents in this split/skill were in AUX mode. This includes time on AUXIN or AUXOUT calls that were received or placed without an ACD call on hold. Time on AUXIN or AUXOUT calls with an ACD call on hold is tracked in I_ACDAUXINTIME and I_ACDAUX_OUTTIME. The I_TAUXTIME item is available with the EAS feature.

This is a cumulative item.

I_TAVAILTIME

The I_TAVAILTIME item is included in the following database tables:

Split/skill tables

The length of time that top agents in this split/skill were available to receive calls for this split/skill. The I_TAVAILTIME item is available with the EAS feature.

This is a cumulative item.

I_TOTHERTIME

The I_TOTHERTIME item is included in the following database tables:

Split/skill tables

The length of time that top agents spend in the OTHER state. The I_TOTHERTIME item is available with the EAS feature.

This is a cumulative item.

II_DIGITS

The II_DIGITS item is included in the following database tables:

Malicious call trace exception table

The Information Indicator digits that specify the type of originating line used by the caller.

ILN

The ILN item is included in the following database tables:

VDN tables

The internal line number (ILN) of the VDN extension. This number is used internally by the CMS to track data about the VDN.

This is an administrative item.

INACW (real-time)

The INACW item is included in the following database tables:

Split/skill tables

The number of agents that are currently in ACW for this split/skill. This includes agents on ACWIN or ACWOUT calls as well as agents in ACW not associated with an ACD call. It does not include agents in ACW for direct agent ACD calls. INACW includes ONACWIN and ONACWOUT.

This is a status item.

INAUX (real-time)

The INAUX item is included in the following database tables:

Split/skill tables

The number of agents that are currently in AUX work for all splits/skills, or on AUXIN or AUXOUT calls. INAUX includes INAUX0, INAUX1 through INAUX9, ONACDAUXOUT, ONAUXIN, and ONAUXOUT.

This is a status item.

INAUX0 (real-time)

The INAU0 item is included in the following database tables:

Split/skill tables

The number of agents that are currently in AUX with reason code 0 (zero) for all splits/skills including agents on AUXIN or AUXOUT calls. For Avaya communication servers with EAS and reason codes, reason code 0 (zero) is for “system” AUX work.

This is a status item.

INAUX1 through INAU9 (real-time)

The INAU1 through INAU9 items appear in the following database tables:

Split/skill tables

The number of agents that are currently in AUX with the reason codes 1 through 9 for all splits/skills including agents on AUXIN or AUXOUT calls. The INAU1 through INAU9 items are available on Avaya communication servers with the EAS and Reason Code features. This is a status item.

INAUX10 through INAU99 (real-time)

Note:

The INAU10 through 99 items are available if you purchased the expanded AUX reason codes feature.

The INAU10 through INAU99 items appear in the following database tables:

Split/skill tables

The number of agents that are currently in AUX with the reason codes 10 through 99 for all splits/skills including agents on AUXIN or AUXOUT calls. The INAU10 through INAU99 items are available on Avaya communication servers with the EAS and Reason Code features. This is a status item.

INBOUND (real-time)

The INBOUND item is included in the following database tables:

Trunk group tables

The number of trunks in the trunk group that are currently busy on inbound calls.

This is a status item.

INCALLS

The INCALLS item is included in the following database tables:

Trunk group tables

The number of inbound calls that are carried by this TKGRP and that completed during the collection interval. INCALLS includes ABNCALLS, ACDCALLS, OTHERCALLS, CONNECTCALLS, and TRANSFERRED. $\text{INCALLS} = \text{ACDCALLS} + \text{ABNCALLS} + \text{OTHERCALLS}$.

This is a cumulative item.

Trunk tables

The number of inbound calls carried by this trunk that completed during the collection interval. This includes calls with short holding times (SHORTCALLS). $\text{INCALLS} = \text{ABNCALLS} + \text{ACDCALLS} + \text{OTHERCALLS}$

This is a cumulative item.

Vector tables

The number of inbound calls that are processed by this vector. INCALLS includes ABNCALLS, RINGCALLS, INFLOWCALLS, and OTHERCALLS. $\text{INCALLS} = \text{ACDCALLS} + \text{ABNCALLS} + \text{OTHERCALLS}$

This is a cumulative item.

VDN tables

The number of inbound calls that are directed to this VDN. INCALLS includes ABNCALLS, INFLOWCALLS, OTHERCALLS, RETURNCALLS, and RINGCALLS. $\text{INCALLS} = \text{ABNCALLS} + \text{ACDCALLS} + \text{OTHERCALLS}$

This is a cumulative item.

INCOMPLETE

The INCOMPLETE item is included in the following database tables:

Split/skill tables

An indication of whether data is complete for this collection interval. Data is incomplete whenever the link goes down and whenever tracking is aborted for calls, because of the trunk going maintenance busy with a call active, protocol failures with data collection active, or when split/skill or VDN call profile is changed with data collection active. Valid values for the INCOMPLETE item are 1, which means that the data is incomplete, and 0, which means that the data is complete. The value in the daily, weekly, and monthly tables indicates the number of incomplete intervals in the day, week, or month.

This is a cumulative item.

Agent tables

An indication of whether data is complete for this collection interval. Data is incomplete whenever the link goes down and whenever tracking is aborted for calls, because of the trunk going maintenance busy with a call active, protocol failures with data collection active, or when split/skill or VDN call profile is changed with data collection active. Valid values for the INCOMPLETE item are 1, which means that the data is incomplete, and 0, which means that the data is complete. The value in the daily, weekly, and monthly tables indicates the number of incomplete intervals in the day, week, or month. Changing the split/skill or VDN call profile data while data collection is active only affects the respective split/skill or VDN data.

This is a cumulative item.

Trunk group tables

An indication of whether data is complete for this collection interval. Data is incomplete whenever the link goes down and whenever tracking is aborted for calls, because of the trunk going maintenance busy with a call active, protocol failures with data collection active, or when split/skill or VDN call profile is changed with data collection active. Valid values for the INCOMPLETE item are 1, which means that the data is incomplete, and 0,

which means that the data is complete. The value in the daily, weekly, and monthly tables indicates the number of incomplete intervals in the day, week, or month.

This is a cumulative item.

Trunk tables

An indication of whether data is complete for this collection interval. Data is incomplete whenever the link goes down and whenever tracking is aborted for calls, because of the trunk going maintenance busy with a call active, protocol failures with data collection active, or when split/skill or VDN call profile is changed with data collection active. Valid values for the INCOMPLETE item are 1, which means that the data is incomplete, and 0, which means that the data is complete. The value in the daily, weekly, and monthly tables indicates the number of incomplete intervals in the day, week, or month. Changing the split/skill or VDN call profile data while data collection is active only affects the respective split/skill or VDN data.

This is a cumulative item.

Vector tables

An indication of whether data is complete for this collection interval. Data is incomplete whenever the link goes down and whenever tracking is aborted for calls, because of the trunk going maintenance busy with a call active, protocol failures with data collection active, or when split/skill or VDN call profile is changed with data collection active. Valid values for the INCOMPLETE item are 1, which means that the data is incomplete, and 0, which means that the data is complete. The value in the daily, weekly, and monthly tables indicates the number of incomplete intervals in the day, week, or month.

This is a cumulative item.

VDN tables

An indication of whether data is complete for this collection interval. Data is incomplete whenever the link goes down and whenever tracking is aborted for calls, because of the trunk going maintenance busy with a call active, protocol failures with data collection active, or when split/skill or VDN call profile is changed with data collection active. Valid values for the INCOMPLETE item are 1, which means that the data is incomplete, and 0, which means that the data is complete. The value in the daily, weekly, and monthly tables indicates the number of incomplete intervals in the day, week, or month.

This is a cumulative item.

Call work codes tables

An indication of whether data is complete for this collection interval. Data is incomplete whenever the link goes down and whenever tracking is aborted for calls, because of the trunk going maintenance busy with a call active, protocol failures with data collection active, or when split/skill or VDN call profile is changed with data collection active. Valid values for the INCOMPLETE item are 1, which means that the data is incomplete, and 0,

which means that the data is complete. The value in the daily, weekly, and monthly tables indicates the number of incomplete intervals in the day, week, or month. Changing the split/skill or VDN call profile data while data collection is active affects only the data for the split/skill or VDN to which the change is made.

This is a cumulative item.

INFLAG

The INFLAG item is included in the following database tables:

Agent login/logout tables

An indication whether the agent is already logged in when the communication server link initiates. Valid values are NULL, which means that the agent is not logged in, and <, which means that the agent is logged in.

INFLOWCALLS

The INFLOWCALLS item is included in the following database tables:

Split/skill tables

The number of calls that are redirected to the split/skill's queue from another queue.

When a call leaves the VDN, for example, by routing to another VDN, or leaves vector processing, for example, by routing to a split/skill, the next split/skill to which a call queues will not be credited with an inflow. Calls that ring at an agent and are then requeued to the same split/skill by the Redirect on No answer feature are counted as inflows to that split/skill.

Without the Vectoring feature, an inflow is counted for calls that intraflow from one split queue to another split queue.

With the Vectoring feature, calls answered by an agent in a non-primary split/skill are counted as inflows to that split/skill. Calls that abandon from ringing at an agent's telephone in a non-primary split/skill are also counted as inflows to that skill.

This is a cumulative item.

Vector tables

The number of calls that are redirected to this vector by way of a “go to vector” command, a “route to” VDN command, or by the Redirection on No Answer feature to a VDN.

This is a cumulative item.

VDN tables

The number of calls that are redirected into the VDN by way of a “route to” VDN command or by Redirection on No Answer to this VDN.

This is a cumulative item.

INPROGRESS (real-time)

The INPROGRESS item is included in the following database tables:

Vector tables

The number of inbound calls that are currently being processed by this VECTOR. INPROGRESS applies until the disposition of the call is known. Calls are no longer counted as INPROGRESS on the vector when they have been answered, abandoned, outflowed from the vector, are at the beginning of a forced busy, or are dropped on a forced disconnect. INPROGRESS includes INQUEUE and INRING.

This is a status item.

VDN tables

The number of inbound calls that are currently associated with this VDN. Calls are considered to be INPROGRESS in the VDN until they route to another VDN, route off of the communication server, are transferred, or the trunk carrying them goes idle. INPROGRESS includes ATAGENT and INVECTOR.

This is a status item.

INQUEUE (real-time)

The INQUEUE item is included in the following database tables:

Split/skill tables

The number of split/skill ACD calls that are currently waiting in queue.

This is a status item.

Vector tables

The number of INPROGRESS calls that are currently in split/skill or direct agent ACD queues.

This is a status item.

VDN tables

The number of INPROGRESS calls that are currently in a split/skill or direct agent ACD queues.

This is a status item.

INRING (real-time)

The INRING item is included in the following database tables:

Split/skill tables

The number of split/skill ACD calls that are currently ringing at agent positions for this split/skill.

This is a status item.

Vector tables

The number of INPROGRESS split/skill and direct agent ACD calls that are currently ringing at agent positions.

This is a status item.

VDN tables

The number of INPROGRESS split/skill and direct agent ACD calls that are currently ringing at agent positions.

This is a status item.

INTERFLOWCALLS

The INTERFLOWCALLS item is included in the following database tables:

Split/skill tables

The number of OUTFLOWCALLS that are redirected to a destination outside the communication server.

This is a cumulative item.

Vector tables

The number of OUTFLOWCALLS that are redirected to a destination outside the communication server. INTERFLOWCALLS includes LOOKFLOWCALLS (successful Look-Ahead Interflow and BSR) and DEFLECTCALLS (successful NCR redirections).

This is a cumulative item.

VDN tables

The number of OUTFLOWCALLS that are redirected to a destination outside the communication server. INTERFLOWCALLS includes LOOKFLOWCALLS (successful Look-Ahead Interflow and BSR) and DEFLECTCALLS (successful NCR redirections).

This is a cumulative item.

INTIME

The INTIME item is included in the following database tables:

Trunk group tables

The trunk holding time for all INCALLS that are carried by trunks in this trunk group and complete during the collection interval. Trunk holding time is the length of time from the initial trunk seizure until the trunk goes idle. The trunk goes idle when the caller drops, the

agent releases the call, or the communication server disconnects the call. If an incoming call on a measured trunk is transferred off the communication server, the incoming trunk remains in use for the call and accrues trunk holding time until the caller drops or the call is released.

This is a cumulative item.

Trunk tables

The trunk holding time for all INCALLS that are carried by this trunk and complete during the collection interval. Trunk holding time is the length of time from the initial trunk seizure until the trunk goes idle. The trunk goes idle when the caller drops, the agent releases the call, or the communication server disconnects the call. If an incoming call on a measured trunk is transferred off the communication server, the incoming trunk remains in use for the call and accrues trunk holding time until the caller drops or the call is released. This is a cumulative item.

Vector tables

The length of time spent by INCALLS by this VECTOR executing steps. INTIME stops accruing in the following cases:

- When the STOP vector step is executed
- When a blank step in the vector is reached
- When busy or disconnect is sent
- When the call abandons
- When a “goto vector” command succeeds
- When a “rout to” vector command succeeds
- When a “messaging split/skill” or “adjunct routing” command succeeds
- Or when the split/skill or direct agent ACD call rings an agent

This is a cumulative item.

VDN tables

The time spent in the VDN by calls completed during this interval. This time includes: time in vector processing, ringing, and talking with an agent until the call is terminated or is routed to another VDN off the communication server. $INTIME = ACDTIME + ABNTIME + ANSTIME + HOLDTIME + OTHERTIME$.

This is a cumulative item.

INTRVL

The INTRVL item is included in the following database tables:

Split/skill tables

The number of minutes in the intrahour interval. The length of the intrahour interval can be 15, 30, or 60 minutes. INTRVL applies to intrahour tables only.

This is an administrative item.

Agent tables

The number of minutes in the intrahour interval. The length of the intrahour interval can be 15, 30, or 60 minutes. INTRVL applies to intrahour tables only.

This is an administrative item.

Trunk group tables

The number of minutes in the intrahour interval. The length of the intrahour interval can be 15, 30, or 60 minutes. INTRVL applies to intrahour tables only.

This is an administrative item.

Trunk tables

The number of minutes in the intrahour interval. The length of the intrahour interval can be 15, 30, or 60 minutes. INTRVL applies to intrahour tables only.

This is an administrative item.

Vector tables

The number of minutes in the intrahour interval. The length of the intrahour interval can be 15, 30, or 60 minutes. INTRVL applies to intrahour tables only.

This is an administrative item.

VDN tables

The number of minutes in the intrahour interval. The length of the intrahour interval can be 15, 30, or 60 minutes. INTRVL applies to intrahour tables only.

This is an administrative item.

Call work codes tables

The number of minutes in the intrahour interval. The length of the intrahour interval can be 15, 30, or 60 minutes. INTRVL applies to intrahour tables only.

This is an administrative item.

Current day report tables

The number of minutes in the intrahour interval. The length of the intrahour interval can be 15, 30, or 60 minutes. INTRVL applies to intrahour tables only.

This is an administrative item.

INVECTOR (real-time)

The INVECTOR item is included in the following database tables:

VDN tables

The number of INPROGRESS calls that are currently being processed by a vector. Calls that are in queue and calls that are ringing are still counted as INVECTOR. Calls are no longer counted as INVECTOR when they connect to a station, are answered by an agent, abandon, or outflow from the VDN. INVECTOR includes INQUEUE and INRING.

This is a status item.

ITN

The ITN item is included in the following database tables:

Trunk tables

The internal trunk number of the trunk.

This is a row identifier item.

KEYBD_DIALED

The KEYBD_DIALED item is included in the following database tables:

Agent trace tables

An indication that the call was keyboard dialed. The KEYBD_DIALED item is available with the ASAI feature.

LASTCWC

The LASTCWC item is included in the following database tables:

Call record tables

The last call work code, which can be comprised of up to 16 digits, that was entered by the answering agent in this call segment.

LASTDIGITS

The LASTDIGITS item is included in the following database tables:

Call record tables

The last set of collected digits that is sent to the CMS by the communication server for this call. These are digits that the communication server sends to the CMS when it executes a “collect” vector command. The digits may be digits that the caller was prompted to enter, either through the prompting feature on the communication server, through network-prompted caller-entered digits (CED), customer database-provided digits (CDPD) from the network, or digits that are collected through a “converse” vector command.

LASTOBSERVER

The LASTOBSERVER item is included in the following database tables:

Call record tables

The login ID of the last agent who service-observed or bridged on to this call.

LEVEL (real-time)

The LEVEL item is included in the following database tables:

Agent tables

The skill level, which is 1 through 16 for a normal skill, or reserve level, which is 1 or 2 for a reserve skill, that is associated with the SPLIT. The LEVEL item is available with the EAS feature.

This is a status item.

LOC_ID

The LOC_ID item is included in the following database tables:

Agent tables

The equipment location ID that is associated with a particular agent. This is the location ID of the terminal the agent is logged into. It is associated with a port network location ID on the communication server.

The LOC_ID is 0 if multiple locations are not enabled. A location ID is not assigned to an agent until that agent logs into a terminal. An agent may have multiple LOC_IDs if the agent logs into multiple terminals with different locations.

Agent Login/Logout table

The equipment location ID that is associated with a particular agent. This is the location ID of the terminal the agent is logged into. It is associated with a port network location ID on the communication server.

The LOC_ID is 0 if multiple locations are not enabled. A location ID is not assigned to an agent until that agent logs into a terminal. An agent may have multiple LOC_IDs if the agent logs into multiple terminals with different locations.

This is an administrative item.

Agent Trace table

The equipment location ID that is associated with a particular agent. This is the location ID of the terminal the agent is logged into. It is associated with a port network location ID on the communication server.

The LOC_ID is 0 if multiple locations are not enabled. A location ID is not assigned to an agent until that agent logs into a terminal. An agent may have multiple LOC_IDs if the agent logs into multiple terminals with different locations.

This is an administrative item.

Trunk tables

The communication server location ID that is associated with the trunk. The location ID is not directly assigned to a trunk but rather is assigned to a port network location on the communication server. Each trunk whose equipment location belongs to a specific port network will be associated with that port network's location ID.

The LOC_ID is 0 if multiple locations are not enabled. A location ID is not assigned to an agent until that agent logs into a terminal. An agent may have multiple LOC_IDs if the agent logs into multiple terminals with different locations.

This is an administrative item.

LOGID

The LOGID item is included in the following database tables:

Agent tables

The login ID the agent used to log in. Agents in multiple splits/skills have one LOGID.

This is an index item.

This is a row identifier item.

Trunk tables

The login ID of the agent who is handling the call that is currently carried by this trunk. This is blank (NULL) when the trunk is idle.

This is a real-time item.

This is a status item.

Agent trace tables

The login ID that the agent used to log in. Agents in multiple splits/skills have one LOGID.

This is a row identifier item.

Agent login/logout tables

The login ID that the agent used to log in. Agents in multiple splits/skills have one LOGID.

This is a row identifier item.

Agent exception tables

The login ID of the agent who had the exception.

This is a row identifier item.

Trunk group exception table

The login ID of the agent who is reporting audio difficulty. This is a row identifier item.

Malicious call trace exception table

The login ID of the agent who is initiating a malicious call trace.

This is a row identifier item.

LOGIN

The LOGIN item is included in the following database tables:

Agent login/logout tables

The time at which the agent logged into this extension and split/skill with the given login ID. This field is a standard UNIX time field; that is, the time is stored as the number of seconds since January 1, 1970.

LOGONSKILL (real-time)

The LOGONSKILL item is included in the following database tables:

Agent tables

The first split/skill with which the agent logged in. The LOGONSKILL item is available with the EAS feature.

This is a status item.

LOGONSKILL2 through LOGONSKILL20 (real-time)

The LOGONSKILL2 through LOGONSKILL20 items appear in the following database tables:

Agent tables

The second through twentieth skills to which the agent logged in. The number of skills per agent depends on the type of communication server. The LOGONSKILL 2 through LOGONSKILL20 items are available with the EAS feature.

This is a status item.

Agent login/logout tables

The second through twentieth skills to which the agent logged in. The number of skills per agent depends on the type of communication server. The LOGONSKILL 2 through LOGONSKILL20 items are available with the EAS feature.

LOGONSKILL21 through LOGONSKILL60 (real-time)

The LOGONSKILL2 through LOGONSKILL60 items appear in the following database tables:

Agent tables

The twenty-first through sixtieth skills to which the agent logged in. The number of skills per agent depends on the type of communication server. The LOGONSKILL21 through LOGONSKILL60 items are available with the EAS feature.

This is a status item.

Agent login/logout tables

The twenty-first through sixtieth skills to which the agent logged in. The number of skills per agent depends on the type of communication server. The LOGONSKILL21 through LOGONSKILL60 items are available with the EAS feature.

LOGONSTART (real-time)

The LOGONSTART item is included in the following database tables:

Agent tables

The time of day at which the agent logged into this SPLIT. This field is not set unless the agent is logged in. If the agent has not logged in during the collection interval, the value is blank. Valid values are null and time-of-day.

This is a status item.

LOGOUT

The LOGOUT item is included in the following database tables:

Agent login/logout tables

The time at which the agent logged out.

LOGOUT_DATE

The LOGOUT_DATE item is included in the following database tables:

Agent login/logout tables

The date on which the agent logged out. This field is a standard UNIX time field; that is, the time is stored as the number of seconds since January 1, 1970.

LOGOUTREASON

The LOGOUTREASON item is included in the following database tables:

Agent login/logout tables

The reason code, which can be 0 through 9, that is associated with the agent's logout. For Avaya communication servers that do not have the EAS feature and reason codes active, this field always contains a 0 when the agent has logged out.

Agent trace tables

The reason code, which can be 0 through 9, that is associated with the agent's logout. For Avaya communication servers that do not have the EAS feature and reason codes active, this field always contains a 0 when the agent has logged out.

LOOKATTEMPTS

The LOOKATTEMPTS item is included in the following database tables:

Vector tables

The number of times that Look-Ahead Interflow or BSR Interflow was attempted for calls in this vector. Network Call Redirection (Network call Deflection [NCD] or Network Call Transfer [NCT]) invoke attempts are also counted as LOOKATTEMPTS. Look-Ahead Interflow and BSR interflow attempts that are successful are also counted as LOOKFLOWCALLS. NCR attempts that are successful are also counted as DEFLECTCALLS. BSR poll calls are not counted as LOOKATTEMPTS. They are counted as NETPOLLS.

This is a cumulative item.

VDN tables

The number of times that Look-Ahead Interflow or BSR Interflow was attempted for calls in this VDN. Network Call Redirection (NCD or NCT) invoke attempts are also counted as LOOKATTEMPTS. Look-Ahead Interflow and BSR interflow attempts that are successful are also counted as LOOKFLOWCALLS. NCR attempts that are successful are also counted as DEFLECTCALLS. BSR poll calls are not counted as LOOKATTEMPTS. They are counted as NETPOLLS.

This is a cumulative item.

LOOKFLOWCALLS

The LOOKFLOWCALLS item is included in the following database tables:

Vector tables

The number of INTERFLOWCALLS that are redirected by way of the Look-Ahead Interflow or BSR features. The LOOKFLOWCALLS item is available with the Look-Ahead Interflow feature.

LOOKFLOWCALLS is a subset of INTERFLOWCALLS and includes LOOKATTEMPTS for the Look-Ahead Interflow or BSR interflows. With BSR interflow, every LOOKATTEMPTS should also be counted as a LOOKFLOWCALLS unless a failure occurs.

This is a cumulative item.

VDN tables

The number of INTERFLOWCALLS that are redirected by way of the Look-Ahead Interflow or BSR feature. LOOKFLOWCALLS item is available with the Look-Ahead Interflow feature.

LOOKFLOWCALLS is a subset of INTERFLOWCALLS and includes LOOKATTEMPTS for the Look-Ahead Interflow or BSR interflows. With BSR interflow, every LOOKATTEMPTS should also be counted as a LOOKFLOWCALLS unless a failure occurs.

This is a cumulative item.

LOWCALLS

The LOWCALLS item is included in the following database tables:

Split/skill tables

On communication servers with the Vectoring feature, LOWCALLS is the number of ACDCALLS with low priority that are answered by this split/skill.

On communication servers without the Vectoring feature, LOWCALLS is the number of ACDCALLS with no priority that are answered by this split/skill.

This is a cumulative item.

MALICIOUS (real-time)

The MALICIOUS item is included in the following database tables:

Agent tables

An indication of whether a malicious call trace (MCT) is active for the agent for any split/skill. Valid values for MALICIOUS are 0, which means that no MCT was activated, and 1, which means that a MCT was activated.

This is a status item.

Call record tables

An indication of whether a MCT was activated for this call segment. Valid values for MALICIOUS are 0, which means that no MCT was activated, and 1, which means that a MCT was activated.

MAXINQUEUE

The MAXINQUEUE item is included in the following database tables:

Split/skill tables

The maximum number of simultaneous calls that are in this split/skill queue during the collection interval.

This is a maximum value item.

MAXOCWTIME

The MAXOCWTIME item is included in the following database tables:

Split/skill tables

The maximum length of time that a call, recorded during the collection interval, waited in queue and ringing before an agent answered in this split/skill, the caller abandoned, or the call was redirected, received a busy signal, or was disconnected.

This is a maximum value item.

VDN tables

The maximum time that a call, recorded during the collection interval, waited in the VDN before being answered (ACD calls) or connected (non-ACD calls), abandoning, being redirected, receiving a busy signal or being disconnected. This applies only to the first disposition of the call. This is a maximum value item.

MAXSTAFFED

The MAXSTAFFED item is included in the following database tables:

Split/skill tables

The maximum number of agents that are simultaneously staffed during the collection interval. MAXSTAFFED includes MAXTOP.

This is a maximum value item.

MAXTOP

The MAXTOP item is included in the following database tables:

Split/skill tables

The maximum number of top agents who are staffed during the collection interval in this split/skill. This item is available with the EAS feature.

This is a maximum value item.

MAX_TOT_PERCENTS

The MAX_TOT_PERCENTS item is included in the following database tables:

Split/skill tables

The maximum total staffed agent percentages that are allocated to a skill. The MAX_TOT_PERCENTS item is available on Avaya communication servers with the EAS feature.

This is an administrative item.

MAXWAITING

The MAXWAITING item is included in the following database tables:

VDN tables

The maximum number of calls that are in queue, in vector processing and ringing simultaneously in the VDN during the collection interval.

This is a maximum value item.

MBUSY (real-time)

The MBUSY item is included in the following database tables:

Trunk group tables

The number of trunks in the trunk group that are currently maintenance busy.

This is a status item.

MBUSYTIME

The MBUSYTIME item is included in the following database tables:

Trunk group tables

The total time during the collection interval that trunks in the trunk group were maintenance busy.

This is a cumulative item.

Trunk tables

The total time during the collection interval that this trunk was maintenance busy.

This is a cumulative item.

MCT

The MCT item is included in the following database tables:

Agent trace tables

An indication that the agent activated a malicious call trace.

MEDCALLS

The MEDCALLS item is included in the following database tables:

Split/skill tables

On communication servers with the Vectoring feature, MEDCALLS is the number of ACDCALLS with medium priority that are answered by agents in the split/skill. For example, answered calls that are queued to the split/skill with medium priority by a “queue to” or “check” vector command. MEDCALLS includes calls that are queued to a split/skill with no priority using the “route to” or “messaging split” vector commands, calls that queued directly to a non-vector-controlled split with no priority, and calls that intraflowed to a split/skill with no priority.

On communication servers without the Vectoring feature, MEDCALLS is the number of ACDCALLS with the priority set to yes that are answered by agents in the split/skill.

This is a cumulative item.

MOVEPENDING (real-time)

The MOVEPENDING item is included in the following database tables:

Agent tables

An indication that a move to a new split/skill or a change of skills is pending for this agent. Valid values for MOVEPENDING are 0, which means that no move is pending, and 1, which means that a move is pending. MOVEPENDING is available on Avaya communication servers with the Move Agent While Staffed feature.

This is a status item.

NETDISCCALLS

The NETDISCCALLS item is included in the following database tables:

Vector tables

The number of calls that disconnected as a result of the reply step in BSR.

This is a cumulative item.

VDN tables

The number of calls that disconnected as a result of the BSR reply step.

This is a cumulative item.

NETINCALLS

The NETINCALLS item is included in the following database tables:

VDN tables

The number of calls that interflowed in from the network in BSR. This is a cumulative item.

NETINTIME

The NETINTIME item is included in the following database tables:

VDN tables

The time, in seconds, that the call was in a VDN somewhere else in the network.

This is a cumulative item.

Call record tables

The length of time that the call spends in a VDN while processing at a communication server that is located elsewhere in the network.

NETPOLLS

The NETPOLLS item is included in the following database tables:

Vector tables

The number of network polls for the “consider” vector steps in BSR.

This is a cumulative item.

VDN tables

The number of network polls for “consider” vector steps in BSR.

This is a cumulative item.

NOANSREDIR

The NOANSREDIR item is included in the following database tables:

Split/skill tables

The number of split/skill ACD calls that rang at agent positions in the split/skill and then were automatically redirected back to the split/skill queue or to a VDN by the Redirection on No Answer feature because they were not answered.

When a call is requeued to the same split/skill by the Redirection on No Answer feature, it is counted as an outflow from the split/skill and an inflow to the same split/skill. This is not true for calls that are redirected to a VDN by the Redirection on No Answer feature, rather than redirecting the call back to the same split/skill.

Such calls count as outflows from the original split or skill, but do not count as inflows to the next split/skill to which they are queued through the new VDN. It is also counted as a NOANSREDIR call and so can be subtracted out from the outflows and from the inflows to calculate the number of outflows and inflows that are not due to requeuing the call to the same split.

This is a cumulative item.

Agent tables

The number of split/skill and direct agent ACD calls that rang at this agent's telephone and then were automatically redirected by the Redirection on No Answer feature because they were not answered. Split/skill ACD calls are requeued to the split/skill or VDN, whereas direct agent ACD calls are redirected to the agent's coverage path.

This is a cumulative item.

VDN tables

The number of split/skill and direct agent ACD calls that rang at agent stations and then were automatically redirected by the Redirection on No Answer feature because they were not answered.

This is a cumulative item.

NUMAGREQ

The NUMAGREQ item is included in the following database tables:

Current day report tables

The number of agents required to handle FCALLS.

NUMINUSE (real-time)

The NUMINUSE item is included in the following database tables:

Trunk group tables

The number of TRUNKS that are currently on calls or maintenance busy. $\text{NUMINUSE} = \text{INBOUND} + \text{OUTBOUND} + \text{MBUSY}$

This is a status item.

NUMTGS (real-time)

The NUMTGS item is included in the following database tables:

VDN tables

The number of trunk groups that are assigned to this VDN.

This is an administrative item.

NUMVDNS (real-time)

The NUMVDNS item is included in the following database tables:

Vector tables

The number of VDNs that are currently assigned to this VECTOR.

This is an administrative item.

O_ABNCALLS

The O_ABNCALLS item is included in the following database tables:

Split/skill tables

The number of ABNCALLS that are placed by an adjunct, that is, the number of outbound predictive dialing calls that are abandoned by the far end. O_ABNCALLS is a subset of ABNCALLS. Available for outbound calls with the ASAI feature.

This is a cumulative item.

Trunk group tables

The number of OUTCALLS on this trunk group that are offered by an adjunct as split/skill or direct agent ACD calls and were answered and then abandoned by the far end. The O_ABNCALLS item is available with the ASAI feature.

This is a cumulative item.

Trunk tables

The number of OUTCALLS on this trunk that are offered by an adjunct as split/skill or direct agent ACD calls and were answered and then abandoned by the far end before talking to an agent. The O_ABNCALLS item is available with the ASAI feature. This is a cumulative item.

O_ACDCALLS

The O_ACDCALLS item is included in the following database tables:

Split/skill tables

The number of ACDCALLS that are placed by an adjunct (outbound predictive dialing). O_ACDCALLS includes DA_ACDCALLS. The O_ACDCALLS item is available with the ASAI feature.

This is a cumulative item.

Agent tables

The number of ACDCALLS and DA_ACDCALLS that are placed by an adjunct (predictive dialing). The O_ACDCALLS item is available with the ASAI feature.

This is a cumulative item.

Trunk group tables

The number of OUTCALLS from this trunk group that are offered by an adjunct to one or more splits/skills and were answered by an agent. The O_ACDCALLS item is available with the ASAI feature.

This is a cumulative item.

Trunk tables

The number of OUTCALLS from this trunk that are offered by an adjunct as split/skill or direct agent ACD calls and were answered by an agent. The O_ACDCALLS item is available with the ASAI feature.

This is a cumulative item.

O_ACDTIME

The O_ACDTIME item is included in the following database tables:

Split/skill tables

The talk time of all O_ACDCALLS. O_ACDTIME does not include HOLDDTIME. O_ACDTIME is included in ACDTIME. The O_ACDTIME item is available with the ASAI feature.

This is a cumulative item.

Agent tables

The talk time of all O_ACDCALLS. O_ACDTIME does not include HOLDTIME. O_ACDTIME is included in ACDTIME. The O_ACDTIME item is available with the ASAI feature.

This is a cumulative item.

O_ACWTIME

The O_ACWTIME item is included in the following database tables:

Split/skill tables

The duration of all ACW that is associated with O_ACDCALLS. O_ACWTIME is included in ACWTIME. The O_ACWTIME item is available with the ASAI feature.

This is a cumulative item.

Agent tables

The duration of all ACW that is associated with O_ACDCALLS. O_ACWTIME is included in ACWTIME. The O_ACWTIME item is available with the ASAI feature.

This is a cumulative item.

O_OTHERCALLS

The O_OTHERCALLS item is included in the following database tables:

Split/skill tables

The number of outbound calls that queued to this split/skill and are not answered or abandoned as ACD split/skill calls. O_OTHERCALLS includes forced busy calls and calls with unknown dispositions. The O_OTHERCALLS item is available with the ASAI feature.

This is a cumulative item.

Trunk group tables

The number of OUTCALLS on this trunk group that are not answered or abandoned as ACD split/skill calls. O_OTHERCALLS includes extension out calls, calls forced busy and forced disconnected, short outgoing calls, and calls with unknown dispositions. O_OTHERCALLS includes SHORTCALLS.

This is a cumulative item.

Trunk tables

The number of OUTCALLS on this trunk that are not answered or abandoned as ACD split/skill calls. O_OTHERCALLS includes extension out calls, calls forced busy and forced disconnected, short outgoing calls, and calls with unknown dispositions. O_OTHERCALLS includes SHORTCALLS. This is a cumulative item.

OBSERVINGCALL

The OBSERVINGCALL item is included in the following database tables:

Call record tables

An indication of whether this call represents an agent observing or bridging on to an existing call. Valid values for OBSERVINGCALL are 0, which means that no observing took place, and 1, which means that observing did take place.

OBSLOCID

The OBSLOCID item is included in the following database tables:

Call record tables

The location ID of an agent observing or bridging on to an existing call.

OLDESTCALL (real-time)

The OLDESTCALL item is included in the following database tables:

Split/skill tables

The number of seconds that the oldest split/skill ACD call has waited in queue or ringing.
This is a status item.

VDN tables

The number of seconds that the oldest call has waited in this VDN.
This is a status item.

OLDEST_LOGON (real-time)

The OLDEST_LOGON item is included in the following database tables:

Agent tables

The split/skill to which the agent has been logged in for the longest amount of time.
OLDEST_LOGON is always the first administered skill.
This is a status item.

ONACD (real-time)

The ONACD item is included in the following database tables:

Split/skill tables

The number of agents that are currently on inbound and outbound ACD calls to this split/skill. ONACD includes ONACDOUT.
This is a status item.

ONACDAUXOUT (real-time)

The ONACDAUXOUT item is included in the following database tables:

Split/skill tables

The number of agents that are currently on AUXOUT calls with an ACD call on hold for this split/skill. For agents in multiple skills with multiple call handling, the last call the agent put on hold was for this skill.

This is a status item.

ONACDOUT (real-time)

The ONACDOUT item is included in the following database tables:

Split/skill tables

The number of agents that are currently on outbound calls that were placed by an adjunct to this split/skill. The ONACDOUT item is available with the ASAI feature.

This is a status item.

ONACWIN (real-time)

The ONACWIN item is included in the following database tables:

Split/skill tables

The number of agents that are currently in ACW for this split/skill and on inbound extension calls. These agents are also counted in INACW. ONACWIN includes agents who are receiving extension calls from ACW that is associated with split/skill ACD calls and from ACW that is not associated with an ACD call.

This is a status item.

ONACWOUT (real-time)

The ONACWOUT item is included in the following database tables:

Split/skill tables

The number of agents that are currently in ACW for this split/skill and on outbound extension calls. These agents are also counted in INACW. ONACWOUT includes agents who are making extension calls from ACW that is associated with split/skill ACD calls and from ACW that is not associated with an ACD call.

This is a status item.

ONAUUXIN (real-time)

The ONAUUXIN item is included in the following database tables:

Split/skill tables

The number of agents that are currently in AUX work or AVAILABLE with an ACD or AUXIN/AUXOUT call on hold and on an inbound extension call where SPLIT is OLDEST_LOGON.

This is a status item.

ONAUUXOUT (real-time)

The ONAUUXOUT item is included in the following database tables:

Split/skill tables

The number of agents that are currently in AUX work or AVAILABLE with an ACD or AUXIN/AUXOUT call on hold, and on an outbound extension call.

This is a status item.

ONHOLD (real-time)

The ONHOLD item is included in the following database tables:

Split/skill tables

The number of split/skill ACD calls for this split/skill that are currently on hold at agent stations. ONHOLD includes all calls. This is a status item.

Agent tables

The number of calls for any split/skill that are currently on hold at the agent stations. ONHOLD includes ACDONHOLD. ONHOLD includes all calls.

This is a status item.

ORIGHOLDTIME

The ORIGHOLDTIME item is included in the following database tables:

Call record tables

The total length of time for which the call was put on hold by the originating agent.

ORIGIN (real-time)

The ORIGIN item is included in the following database tables:

Agent tables

The outbound call origination for the call on which the agent is currently talking for any split/skill. Valid values for ORIGIN are blank, PHONE, and KEYBOARD (adjunct-dialed).

This is a status item.

ORIGLOCID

The ORIGLOCID item is included in the following database tables:

Call record tables

The location ID of the agent who is originating the call.

ORIGLOGIN

The ORIGLOGIN item is included in the following database tables:

Call record tables

The login ID of the agent who is originating the call. This is used for calls that an agent originates to another agent, to an on-communication server extension, or to an external destination.

ORIGREASON

The ORIGREASON item is included in the following database tables:

Call record tables

The reason code, from 0 through 99, that is associated with the originating agent's mode, if the agent is in the AUX. For agents in AUX on Avaya communication servers that do not have EAS and reason codes active, ORIGREASON is always 0.

OTHER (real-time)

The OTHER item is included in the following database tables:

Split/skill tables

The number of agents that are currently doing OTHER work. Agents show up in OTHER directly after the link to the communication server is initiated and directly after the agents log in before the CMS is notified of the agent's work state.

While the agent is in Auto-In or Manual-In, other work for this split/skill includes the amount of time that is spent doing any of the following:

- An agent put any call on hold and perform no further action.
- The agent is on a direct agent call or in ACW for a direct agent call.
- The agent is dialing to place a call or to activate a feature.
- An extension call or a direct agent ACD call is ringing with no other activity.
- The length of time agents were logged into multiple splits/skills and doing work for a split/skill other than this one.

With the EAS feature and multiple call handling, agents are available in other multiple call handling skills, but not in this skill.

This is a status item.

OTHERCALLS

The OTHERCALLS item is included in the following database tables:

Split/skill tables

The number of calls offered to this split/skill that do not abandon and are not answered by an ACD agent for this split/skill. $OTHERCALLS = BUSYCALLS + DISCCALLS + OUTFLOWCALLS + DEQUEUECALLS$. This is a cumulative item.

Trunk group tables

The number of INCALLS carried by this trunk group that are not answered as split/skill or direct agent ACD calls or do not abandon. These include forced busy calls, forced disconnect calls, calls that are connected to a non-ACD destination, short inbound calls, calls that outflowed off the communication server, and calls with unknown dispositions.

OTHERCALLS includes BUSYCALLS, DISCCALLS, SHORTCALLS, and CONNECTCALLS. $OTHERCALLS = INCALLS - ACDCALLS - ABNCALLS$.

This is a cumulative item.

Trunk tables

The number of INCALLS carried by this trunk that are not answered as split/skill or direct agent ACD calls or do not abandon. These include forced busy calls, forced disconnect calls, calls that are connected to a non-ACD destination, short inbound calls, and calls with unknown dispositions. OTHERCALLS includes BUSYCALLS, DISCCALLS, SHORTCALLS and CONNECTCALLS. $OTHERCALLS = INCALLS - ACDCALLS - ABNCALLS$

This is a cumulative item.

Vector tables

The number of INCALLS that are redirected out of the vector, given a busy signal, or are disconnected. OTHERCALLS includes BUSYCALLS, DISCCALLS, and OUTFLOWCALLS. $OTHERCALLS = INCALLS - ACDCALLS - ABNCALLS$

This is a cumulative item.

VDN tables

The number of calls that are given a forced busy, forced disconnect, or outflowed from the communication server, and non-ACD calls that are answered (CONNECTCALLS). OTHERCALLS includes BUSYCALLS, CONNECTCALLS, DISCCALLS, and OUTFLOWCALLS. $OTHERCALLS = INCALLS - ACDCALLS - ABNCALLS$

This is a cumulative item.

OTHERTIME

The OTHERTIME item is included in the following database tables:

Split/skill tables

The length of time that OTHERCALLS wait in queue until the disposition is known and the call left the split/skill. OTHERTIME relates to time for OTHERCALLS and is not related to I_OTHERTIME, which is the time agents that spend in the OTHER state. OTHERTIME includes BUSYTIME, DEQUETIME, DISCTIME, and OUTFLOWTIME.

This is a cumulative item.

Vector tables

The length of time that OTHERCALLS spend in the vector until the disposition is known and the call leaves the vector. OTHERTIME includes BUSYTIME, DISCTIME, and OUTFLOWTIME.

This is a cumulative item.

VDN tables

The total length of time that OTHERCALLS spend in the VDN until the calls leave the VDN. Instances that cause the call to leave the VDN include when the call drops, when the call is sent to another VDN, when the call is transferred, or when the call is sent outside of the communication server. OTHERTIME includes BUSYTIME, CONNECTTIME, CONNTALKTIME, DISCTIME, and OUTFLOWTIME.

This is a cumulative item.

OUTBOUND (real-time)

The OUTBOUND item is included in the following database tables:

Trunk group tables

The number of trunks in this trunk group that are currently busy on outbound calls. OUTBOUND includes ADJUNCTOUT.

This is a status item.

OUTCALLS

The OUTCALLS item is included in the following database tables:

Trunk group tables

The number of outbound calls that are carried by this TKGRP and complete during the collection interval. OUTCALLS includes COMPLETED, O_ABNCALLS, O_ACDCALLS, O_OTHERCALLS, TRANSFERRED, and SHORTCALLS. $OUTCALLS = O_ACDCALLS + O_ABNCALLS + O_OTHERCALLS$.

This is a cumulative item.

Trunk tables

The number of outbound calls that are carried by the trunk and complete during the collection interval. OUTCALLS includes COMPLETED, O_ABNCALLS, O_ACDCALLS, O_OTHERCALLS, TRANSFERRED and SHORTCALLS. $OUTCALLS = O_ACDCALLS + O_ABNCALLS + O_OTHERCALLS$. This is a cumulative item.

OUTFLAG

The OUTFLAG item is included in the following database tables:

Agent login/logout tables

An indication of whether the agent log out while the link to the communication server was inactive. Valid values for OUTFLAG are NULL, which means that the agent did not log out, and >, which means that the agent did log out.

OUTFLOWCALLS

The OUTFLOWCALLS item is included in the following database tables:

Split/skill tables

The number of CALLSOFFERED that are redirected to another destination while queued to this split/skill. This can happen under different circumstances, depending on the communication server release and on whether the Vectoring feature is active or not.

On communication servers without the Vectoring feature, a call can be counted as OUTFLOWCALLS in any of the following instances:

- The call intraflowed or interflowed.
- The split/skill call forwarding was active.
- A ringing ACD call was answered using call pickup.
- A ringing ACD call redirected on no answer.

On communication servers with vectoring, a call can be counted as OUTFLOWCALLS in any of the following instances:

- A ringing ACD call redirected on no answer.
- The call rang at an agent in this split/skill and was answered using call pickup.

- The call was routed to another VDN.
- The call routed to a number or digits.
- The call queued to a messaging split/skill.
- The call queued to this split/skill as the primary split/skill and was answered by an agent in another split/skill, rang at an agent in another split/skill and then abandoned or was redirected by the Redirection on No Answer feature.

OUTFLOWCALLS includes INTERFLOWCALLS, NOANSREDIR, and SLVLOUTFLOWS.

This is a cumulative item.

Vector tables

The number of INCALLS that are redirected to another destination by way of a “go to” vector command or by a “route to” or “adj rout link” command to a destination other than a split/skill or direct agent. Calls that route to a split/skill or direct agent by way of a “route to”, “adj rout link”, or “messaging split/skill” vector command are still tracked in the vector. OUTFLOWCALLS includes GOTOCALLS and INTERFLOWCALLS.

This is a cumulative item.

VDN tables

The number of INCALLS that are redirected to another VDN or to a destination outside the communication server by way of a “route to” or “adj rout link” vector command, or calls that are redirected to another VDN by the Redirect on No Answer feature. Calls are only counted as outflows from the VDN when they are redirected to another VDN or to an off-communication server destination. Calls in the VDN that route to other destinations, such as split/skills or extensions, are not counted as outflows from the VDN. OUTFLOWCALLS includes INTERFLOWCALLS and SLVLOUTFLOWS.

This is a cumulative item.

OUTFLOWTIME

The OUTFLOWTIME item is included in the following database tables:

Split/skill tables

The length of time that all OUTFLOWCALLS wait in queue or ringing before being redirected.

This is a cumulative item.

Vector tables

The length of time that all OUTFLOWCALLS spend in the VECTOR before being redirected. OUTFLOWTIME includes GOTOTIME.

This is a cumulative item.

VDN tables

The length of time that all OUTFLOWCALLS spend in the VDN before being redirected.

This is a cumulative item.

OUTTIME

The OUTTIME item is included in the following database tables:

Trunk group tables

The trunk holding time for all OUTCALLS that are carried by trunks in this trunk group and complete during the collection interval. Trunk holding time is the time from the initial trunk seizure until the trunk goes idle. The trunk does not go idle until far end drops, the agent releases the call, or the communication server disconnects the call. OUTTIME includes SETUPTIME.

This is a cumulative item.

Trunk tables

The trunk holding time for all OUTCALLS that are carried by this trunk and complete during the collection interval. Trunk holding time is the time from the initial trunk seizure until the trunk goes idle. The trunk does not go idle until the far end drops, the agent releases the call, or the communication server disconnects the call.

This is a cumulative item.

PENDINGSPPLIT (real-time)

The PENDINGSPPLIT item is included in the following database tables:

Agent tables

The split/skill to which the agent will be moved. The move is pending until the agent is idle. In the case of a change of multiple skills in one request, PENDINGSPPLIT is set to the first new skill for the agent. It is possible for PENDINGSPPLIT to be blank or 0, even when MOVEPENDING is set. This can happen when the link to the communication server is initiated and a move is already pending for an agent.

This is a status item.

PERCENT (real-time)

The PERCENT item is included in the following database tables:

Agent tables

The percentage, from 0 to 100, of an agent's time that is to be spent in this skill. The PERCENT item is available on Avaya communication servers with the EAS feature. This is a administrative item.

PERIOD1 through PERIOD9

The PERIOD1 through PERIOD9 items appear in the following database tables:

Split/skill tables

The length, in seconds, of each service level increment as defined in the Call Center Administration: Split/Skill Call Profile window. Each increment represents a progressively longer wait time. CMS counts answered or abandoned calls that wait beyond the last increment, which is PERIOD9, in ACDCALLS10 or ABNCALLS10, as appropriate.

This is an administrative item.

VDN tables

The length, in seconds, of each service level increment as defined in the Call Center Administration: VDN Call Profile window. Each increment represents a progressively longer wait time. CMS counts answered or abandoned calls that wait beyond the last increment, which is PERIOD9, in ANSCONNCALLS10 or ABNCALLS10.

This is an administrative item.

PERIODCHG

The PERIODCHG item is included in the following database tables:

Split/skill tables

An indication of whether service level increments PERIOD1 through PERIOD9 changed during the collection interval. Service level is defined on the Call Center Administration: Split/Skill Call Profile window. Valid values for PERIODCHG are 0, which means that no change was made, and 1, which means that a change was made.

This is an administrative item.

VDN tables

An indication of whether service level increments PERIOD1 through PERIOD9 changed during the collection interval. Service level is defined on the Call Center Administration: VDN Call Profile window. Valid values for PERIODCHG are 0, which means that no change was made, and 1, which means that a change was made.

This is an administrative item.

PHANTOMABNS

The PHANTOMABNS item is included in the following database tables:

Split/skill tables

The number of split/skill ACD calls for which talk time is less than the value of the phantom-abandon call timer.

This is a cumulative item.

Agent tables

The number of ACD calls for which talk time is less than the value of the phantom-abandon call timer.

This is a cumulative item.

Vector tables

The number of split/skill and direct agent ACD calls and calls that were routed to an agent or extension for which talk time is less than the value of the phantom-abandon call timer.

This is a cumulative item.

VDN tables

The number of split/skill and direct agent ACD calls and calls that were routed to an agent or extension for which talk time is less than the value set for the phantom-abandon call timer.

This is a cumulative item.

POSITION (real-time)

The POSITION item is included in the following database tables:

Agent tables

The position number that is associated with this EXTENSION. On communication servers that do not have the EAS feature, agents who are in multiple splits have more than one POSITION. On communication servers that do have the EAS feature, agents who are in multiple skills have one POSITION.

POSITIONS (real-time)

The POSITIONS item is included in the following database tables:

Split/skill tables

On communication servers that do not have the EAS feature, POSITIONS is the number of agent positions that are currently assigned to this SPLIT.

On communication servers that do have the EAS feature, POSITIONS is the number of agent positions that are currently logged in to this skill.

This is an administrative item.

PREFERENCE (real-time)

The PREFERENCE item is included in the following database tables:

Agent tables

An indication of the agent's call handling preference. Valid values for PREFERENCE are blank, LVL (service level), NEED (greatest need), PCNT (percent allocation). The PREFERENCE item is available on Avaya communication servers with the EAS feature.

This is a administrative item.

Agent Login/Logout tables

An indication of the agent's call handling preference. Valid values for PREFERENCE are blank, LVL (service level), NEED (greatest need), PCNT (percent allocation). The PREFERENCE item is available on Avaya communication servers with the EAS feature.

This is an administrative item.

PRIORITY (real-time)

The PRIORITY item is included in the following database tables:

Trunk tables

The priority at which the call was queued.

On communication servers that do not have the Vectoring feature, the valid values for PRIORITY are YES, NO, or as defined in Dictionary.

On communication servers that do have the Vectoring feature, the valid values for PRIORITY are LOW, MED, HIGH, TOP, or as defined in Dictionary. MED is used for “no priority” and HIGH is used for “priority” calls that queue directly to a split/skill without going through a vector and for calls that queue to a split/skill by “route to” number or “messaging split/skill” vector commands.

PRIORITY is blank (NULL) when the call is dequeued, which means that the call rings at an agent, outflows or dequeues from the split/skill, the call abandons from queue, or the call gets a forced busy or a forced disconnect.

This is a status item.

PRIORITY2 and PRIORITY3 (real-time)

The PRIORITY2 and PRIORITY3 items appear in the following database tables:

Trunk tables

The priority at which the call was queued to a second or third split/skill. Valid values for PRIORITY are LOW, MED, HIGH, TOP, or as defined in Dictionary. PRIORITY is blank (NULL) when the call is dequeued, which means that the call rings at an agent, outflows or dequeues from the split/skill, the call abandons from queue, or the call gets a forced busy or a forced disconnect. The PRIORITY2 and PRIORITY3 items are available with the Vectoring feature.

This is a status item.

QUECOUNT (real-time)

The QUECOUNT item is included in the following database tables:

Trunk tables

The number of ACD splits/skills to which the call is queued. QUECOUNT is blank (NULL) when the trunk goes idle, gets forced busy, gets a forced disconnect, connects to a station or agent, or forwards out of the queue. Valid values for QUECOUNT are NULL, 1, 2, and 3.

This is a status item.

QUETYPE (real-time)

The QUETYPE item is included in the following database tables:

Trunk tables

An indication of whether this call entered the queue as a result of a “queue to” or another vector command. QUETYPE is blank (NULL) for direct agent calls, when vectoring is not used, and when the call dequeues. A call is removed from the queue when it is answered, abandoned, forced busy, or forced disconnected. Valid values for QUETYPE are NULL, MAIN, and BACKUP.

This is a status item.

QUETYPE2 and QUETYPE3 (real-time)

The QUETYPE2 and QUETYPE3 items appear in the following database tables:

Trunk tables

An indication of whether this call entered the second or third queue as a result of a “queue to” or another vector command. QUETYPE2 and QUETYPE3 are NULL when vectoring is not used and when the call dequeues. A call is removed from the queue when it is answered, abandoned, forced busy, or forced disconnected. Valid values for QUETYPE2 and QUETYPE3 are NULL, MAIN, and BACKUP.

This is a status item.

R1AGINRING (real-time)

The R1AGINRING item is included in the following database tables:

Split/skill tables

The number of Reserve 1 agents who have an ACD call ringing for this skill.

The R1AGINRING item is available on Avaya communication servers with the EAS feature.

This is a status item.

R1AVAILABLE (real-time)

The R1AVAILABLE item is included in the following database tables:

Split/skill tables

The number of Reserve 1 agents who are available to take a call.

The R1AVAILABLE item is available on Avaya communication servers with the EAS feature.

This is a status item.

R1INACW (real-time)

The R1INACW item is included in the following database tables:

Split/skill tables

The number of Reserve 1 agents who are in ACW for this skill.

The R1INACW item is available on Avaya communication servers with the EAS feature.

This is a status item.

R1INAUX (real-time)

The R1INAUX item is included in the following database tables:

Split/skill tables

The number of Reserve 1 agents who are in AUX work for this skill.

R1INAUX does not include the Reserve Level 1 Agents in R1INAUXSTBY.

The R1INAUX item is available on Avaya communication servers with the EAS feature.

This is a status item.

R1INAUXSTBY (real-time)

The R1INAUXSTBY item is included in the following database tables:

Split/skill tables

R1INAUXSTBY is the number of Reserve Level 1 agents who are in AUX Work when the skill is Normal.

The number of Reserve Level 1 agents in R1INAUXSTBY is not included in R1INAUX, R1STAFFED or STAFFED.

R1INAUXSTBY is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a status item.

R1ONACD (real-time)

The R1ONACD item is included in the following database tables:

Split/skill tables

The number of Reserve 1 agents who are on ACD calls for this skill.

The R1ONACD item is available on Avaya communication servers with the EAS feature.

This is a status item.

R1OTHER (real-time)

The R1OTHER item is included in the following database tables:

Split/skill tables

The number of Reserve 1 agents who are doing other work for this skill while activated.

The R1OTHER item is available on Avaya communication servers with the EAS feature.

R1OTHER does not include Reserve Level 1 Agents in R1OTHERSTBY.

This is a status item.

R1OTHERSTBY (real-time)

The R1OTHERSTBY item is included in the following database tables:

Split/skill tables

R1OTHERSTBY is the number of Reserve 1 Agents who are logged in and in standby because the skill is Normal.

R1OTHERSTBY is not included in R1OTHER, R1STAFFED or STAFFED.

R1OTHERSTBY is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a status item.

R1STAFFED (real-time)

The R1STAFFED item is included in the following database tables:

Split/skill tables

The number of agents who are logged in to this skill as Reserve 1 and the skill is not Normal.

R1STAFFED does not include Reserve Level 1 Agents in R1OTHERSTBY or R1INAUXSTBY.

The R1STAFFED item is available on Avaya communication servers with the EAS feature. This is a status item.

R2AGINRING (real-time)

The R2AGINRING item is included in the following database tables:

Split/skill tables

The number of Reserve 2 agents who have an ACD call ringing for this skill.

The R2AGINRING item is available on Avaya communication servers with the EAS feature.

This is a status item.

R2AVAILABLE (real-time)

The R2AVAILABLE item is included in the following database tables:

Split/skill tables

The number of Reserve 2 agents who are available to take a call.

The R2AVAILABLE item is available on Avaya communication servers with the EAS feature.

This is a status item.

R2INACW (real-time)

The R2INACW item is included in the following database tables:

Split/skill tables

The number of Reserve 2 agents who are in ACW for this skill.

The R2INACW item is available on Avaya communication servers with the EAS feature.

This is a status item.

R2INAUX (real-time)

The R2INAUX item is included in the following database tables:

Split/skill tables

The number of Reserve 2 agents who are in AUX work for this skill. R2INAUX does not include Reserve 2 agents in R2INAUXSTBY.

The R2INAUX item is available on Avaya communication servers with the EAS feature.

This is a status item.

R2INAUXSTBY (real-time)

The R2INAUXSTBY item is included in the following database tables:

Split/skill tables

The number of Reserve Level 2 Agents who are in AUX work when the skill state is Normal.

The number of Reserve Level 2 Agents in R2INAUXSTBY is not included in R2INAUX, R2STAFFED or STAFFED.

R2INAUXSTBY is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a status item.

R2ONACD (real-time)

The R2ONACD item is included in the following database tables:

Split/skill tables

The number of Reserve 2 agents who are on ACD calls for this skill.

The R2ONACD item is available on Avaya communication servers with the EAS feature.

This is a status item.

R2OTHER (real-time)

The R2OTHER item is included in the following database tables:

Split/skill tables

The number of Reserve 2 agents who are doing other work for this skill while activated.

The R2OTHER item is available on Avaya communication servers with the EAS feature.

R2OTHER does not include Reserve Level 2 agents in R2OTHERSTBY

This is a status item.

R2OTHERSTBY (real-time)

The R2OTHERSTBY item is included in the following database tables:

Split/skill tables

R2OTHERSTBY is the number of Reserve 2 Agents who are logged in and in standby because the skill is Normal. The number of Reserve Level 2 Agents in R2OTHERSTBY is not included in R2OTHER, R2STAFFED or STAFFED.

R2OTHERSTBY is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

This is a status item.

R2STAFFED (real-time)

The R2STAFFED item is included in the following database tables:

Split/skill tables

The number of agents who are logged into this skill as Reserve 2 and the skill is in overload 2.

The R2STAFFED item is available on Avaya communication servers with the EAS feature. R2STAFFED does not include Reserve Level 2 agents in R2OTHERSTBY or R2INAUXSTBY.

This is a status item.

RAGOCC

The RAGOCC item is included in the following database tables:

Current day report tables

The resulting maximum percentage of time for which an agent is on ACD calls.

RAVGSPEED-ANS

The RAVGSPEEDANS item is included in the following database tables:

Current day report tables

The resulting average speed of answer, in seconds, for this type of call.

REASON

The REASON item is included in the following database tables:

Data collection exception table

The reason for the interruption of data collection. Valid values for REASON are shown in the following table.

| Value | Reason |
|-------|---|
| 91 | Data collection started |
| 92 | Data collection of new translations started |
| 93 | Data collection turned off |
| 94 | Data collection busied out |
| 95 | Data collection timed out |
| 96 | Data collection clock reset |
| 97 | Data collection session down |
| 102 | Data collection link stalled |
| 103 | Data collection link back to normal |

REASON_CODE

The REASON_CODE item is included in the following database tables:

Agent exception table

The reason code that the agent was in when the exception occurred.

RECONNECT

The RECONNECT item is included in the following database tables:

Agent trace tables

An indication that the agent has reconnects to the call after putting it on hold.

RETURNCALLS

The RETURNCALLS item is included in the following database tables:

VDN tables

The number of calls that reached this VDN by way of the VDN return destination feature.

This is a cumulative item.

RINGCALLS

The RINGCALLS item is included in the following database tables:

Split/skill tables

The number of split/skill calls that rang at agent positions. RINGCALLS includes NOANSREDIR.

This is a cumulative item.

Agent tables

The number of split/skill and direct agent ACD calls that rang at the agent's position. RINGCALLS includes NOANSREDIR.

This is a cumulative item.

Vector tables

The number of split/skill and direct agent ACD calls that rang at agent positions.

This is a cumulative item.

VDN tables

The number of split/skill and direct agent ACD calls that rang at agent positions.

This is a cumulative item.

RINGTIME

The RINGTIME item is included in the following database tables:

Split/skill tables

The length of time that calls for this split/skill spend ringing at agent positions independent of the final disposition and other agent activity. I_RINGTIME is the time that agents spend with ringing calls and is affected by other agent activity. RINGTIME is the time the caller spends ringing at the agent station.

This is a cumulative item.

Agent tables

The length of time that split/skill and direct agent ACD calls spend ringing at the agent's position independent of disposition or other agent activity. I_RINGTIME is the time that the agent spends in the ringing state and is affected by other agent activity. RINGTIME is the time the caller spends ringing at the agent station. RINGTIME includes ANSRINGTIME.

This is a cumulative item.

Vector tables

The length of time that split/skill and direct agent ACD calls spend ringing at agent positions independent of disposition or other agent activity.

This is a cumulative item.

VDN tables

The length of time that split/skill and direct agent ACD calls spend ringing at agent positions independent of disposition or other agent activity.

This is a cumulative item.

ROLE (real-time)

The ROLE item is included in the following database tables:

Agent report tables

The agent's service role for the split. Valid values for ROLE are:

| ROLE values | Definition |
|-------------|--|
| Allocated | Percent allocated agent whose skill level is 1 through 16 |
| Backup | Skill level agent whose skill level is 1 through 16 and for whom this skill is not the top skill |
| Reserved | Agent whose skill level is R1 or R2 for this particular skill |
| Roving | Non-EAS agent or greatest need EAS agent whose skill level is 1 through 16 |
| Top | Skill level agent for whom this skill is the first-administered, highest level 1 through 16 |

The ROLE item is available on Avaya communication servers with the EAS feature.

This is a status item.

ROW_DATE (index)

The ROW_DATE item is included in the following database tables:

Split/skill tables

The date on which data was collected.

This is a row identifier item.

Agent tables

The date on which data was collected or the exception occurred.

This is a row identifier item.

Trunk group tables

The date on which data was collected or the exception occurred.
This is a row identifier item.

Trunk tables

The date on which data was collected or the exception occurred.
This is a row identifier item.

Vector tables

The date on which data was collected or the exception occurred.
This is a row identifier item.

VDN tables

The date on which data was collected or the exception occurred.
This is a row identifier item.

Call work codes tables

The date on which data was collected or the exception occurred.
This is a row identifier item.

Agent login/logout tables

The date on which data was collected or the exception occurred.
This is a row identifier item.

Agent trace tables

The date on which data was collected or the exception occurred.
This is a row identifier item.

Current day configuration tables

The date on which data was collected or the exception occurred.
This is a row identifier item.

Current day report tables

The date on which data was collected or the exception occurred.
This is a row identifier item.

Call record tables

The date on which data was collected or the exception occurred.

This is a row identifier item.

Agent exception table

The date on which data was collected or the exception occurred.

This is a row identifier item.

Split/skill exception table

The date on which data was collected or the exception occurred.

This is a row identifier item.

Trunk group exception table

The date on which data was collected or the exception occurred.

This is a row identifier item.

VDN exception table

The date on which data was collected or the exception occurred.

This is a row identifier item.

Vector exception table

The date on which data was collected or which the exception occurred.

This is a row identifier item.

Malicious call trace exception table

The date on which data was collected or the exception occurred.

This is a row identifier item.

Data collection exception table

The date on which data was collected or the exception occurred.

This is a row identifier item.

ROW_TIME

The ROW_TIME item is included in the following database tables:

Call record tables

The starting time for this segment.

Agent exception table

The time at which the exception occurred.

This is a row identifier item.

Split/skill exception table

The time at which the exception occurred.

This is a row identifier item.

Trunk group exception table

The time at which the exception occurred.

This is a row identifier item.

VDN exception table

The time at which the exception occurred.

This is a row identifier item.

Vector exception table

The time at which the exception occurred.

This is a row identifier item.

Malicious call trace exception table

The time at which the malicious call was reported.

This is a row identifier item.

Data collection exception table

The time at which data collection was interrupted.

This is a row identifier item.

RSERVLEVELP

The RSERVLEVELP item is included in the following database tables:

Current day report tables

The percentage of calls to be handled within SERVLEVELT seconds.

RSV_LEVEL

The RSV_LEVEL item is included in the following database tables:

Agent tables

RSV_LEVEL provides an indication of whether the skill assigned to the agent is a non-reserve or a reserve level skill. 0 is for a non-reserve skill, 1 is for a reserve level 1 skill, and 2 is for a reserve level 2 skill.

RSV_LEVEL is available with Advocate Service Level Supervisor working with CMS R3V11 or later.

SEGMENT

The SEGMENT item is included in the following database tables:

Call record tables

The identifying number of the call segment. Segment numbers begin with 1 and continue through the number of segments in the call.

SEGSTART

The SEGSTART item is included in the following database tables:

Call record tables

The UNIX time and date when the call segment started. The UNIX time and date is the number of seconds since midnight, 01/01/70. Call segments start when CMS receives the first message for the call because each call segment represents a call. Another segment starts when an agent transfers or conferences a call.

SEGSTOP

The SEGSTOP item is included in the following database tables:

Call record tables

The UNIX time and date when the call segment ended. The UNIX time and date is the number of seconds since midnight, 01/01/70. A call segment ends when all trunks and agents that are associated with the call segment have dropped off the call. This means that ACW time for the agent is included when calculating the call segment stop time.

SERVICELEVEL

The SERVICELEVEL item is included in the following database tables:

Split/skill tables

The number of seconds within which calls must be answered or connected in order to be considered acceptable. The acceptable service level is defined on the Call Center Administration: Split/Skill Call Profile window.

This is an administrative item.

VDN tables

The number of seconds within which calls must be answered or connected to be considered acceptable. The acceptable service level is defined on the Call Center Administration: VDN Call Profile Setup window.

This is an administrative item.

SERVLEVELP

The SERVLEVELP item is included in the following database tables:

Current day report tables

The objective percentage of calls that are to be handled within SERVLEVELT seconds.

This is an administrative item.

SERVLEVELT

The SERVLEVELT item is included in the following database tables:

Current day report tables

The number of seconds within which SERVLEVELP percent of calls are to be answered. This is the service level time.

This is an administrative item.

SETUPTIME

The SETUPTIME item is included in the following database tables:

Trunk group tables

The length of time from trunk seizure until OUTCALLS complete at the far end.

This is a cumulative item.

SHORTCALLS

The SHORTCALLS item is included in the following database tables:

Trunk group tables

The number of inbound and outbound calls that occupied a trunk in the trunk group for less than 2 seconds and that did not queue to a split/skill, forward to a split/skill, get answered by an agent, get a forced busy or forced disconnect from the communication server, or produce a trunk failure or maintenance busy. SHORTCALLS includes both inbound and outbound calls. Therefore, OTHERCALLS and O_OTHERCALLS may each include some SHORTCALLS.

This is a cumulative item.

Trunk tables

The number of inbound and outbound calls that occupied a trunk for less than 2 seconds and that did not queue to a split/skill, forward to a split/skill, get answered by an agent, get a forced busy or forced disconnect from the communication server, or produce a trunk failure or maintenance busy. SHORTCALLS includes both inbound and outbound calls. Therefore, OTHERCALLS and O_OTHERCALLS may each include some SHORTCALLS.

This is a cumulative item.

SKILL1 through SKILL3

The SKILL1 through SKILL3 items appear in the following database tables:

VDN tables

The first, second, and third VDN skills that are assigned to this VDN. The SKILL 1 through SKILL3 items are available with the EAS feature.

This is an administrative item.

SKILLACWTIME1 through SKILLACWTIME3

The SKILLACWTIME1 through SKILLACWTIME3 items appear in the following database tables:

VDN tables

The length of time that agents spend in ACW time for calls that are answered in each VDN skill preference. The SKILLACWTIME1 through SKILLACWTIME3 items are available with the EAS feature. This is a cumulative item.

SKILLCALLS1 through SKILLCALLS3

The SKILLCALLS1 through SKILLCALLS3 items appear in the following database tables:

VDN tables

The number of calls that are answered by agents in each VDN skill preference. The SKILLCALLS1 through SKILLCALLS3 items are available with the EAS feature.

This is a cumulative item.

SKILLTIME1 through SKILLTIME3

The SKILLTIME1 through SKILLTIME3 items appear in the following database tables:

VDN tables

The length of time that agents spend talking on calls that are answered in each VDN skill preference. The SKILLTIME1 through SKILLTIME3 items are available with the EAS feature

This is a cumulative item.

SKILLTYPE

The SKILLTYPE item is included in the following database tables:

Agent tables

The type, p for primary or s for secondary, of the first skill to which the agent logged in. The SKILLTYPE item is available with the EAS feature.

On Avaya communication servers with the EAS feature, skill level 1 is represented by p, skill level 2 is represented by s, and skill levels 3 through 16 are blank. Users of more than two skill levels should use the SKLEVEL items instead of SKILLTYPE.

In the agent tables, SKILLTYPE is a real-time item.

This is an administrative item.

Agent login/logout tables

The type, p for primary or s for secondary, of the first skill to which the agent logged in. The SKILLTYPE item is available with the EAS feature.

On Avaya communication servers with the EAS feature, skill level 1 is represented by p, skill level 2 is represented by s, and skill levels 3 through 16 are blank. Users of more than two skill levels should use the SKLEVEL items instead of SKILLTYPE.

This is an administrative item.

SKILLTYPE2 through SKILLTYPE4

The SKILLTYPE2 through SKILLTYPE4 items appear in the following database tables:

Agent tables

The type, p for primary or s for secondary, of the second, third, and fourth skills to which the agent logged in. The SKILLTYPE2 through SKILLTYPE4 items are available with the EAS feature.

On Avaya communication servers with the EAS feature, skill level 1 is represented by p, skill level 2 is represented by s, and skill levels 3 through 16 are blank. Users of more than two skill levels should use the SKLEVEL 2-20 items instead of SKILLTYPE 2-4.

In the agent tables, SKILLTYPE 2-4 is a real-time item.

This is an administrative item.

Agent login/logout tables

The type, p for primary or s for secondary, of the second, third, and fourth skills to which the agent logged in. The SKILLTYPE2 through SKILLTYPE4 items are available with the EAS feature.

On Avaya communication servers with the EAS feature, skill level 1 is represented by p, skill level 2 is represented by s, and skill levels 3 through 16 are blank. Users of more than two skill levels should use the SKLEVEL 2-20 items instead of SKILLTYPE 2-4.

SKLEVEL

The SKLEVEL item is included in the following database tables:

Agent tables

An indication of the agent's skill level, which is 1 through 16 for a normal skill, or reserve level, which is 1 or 2 for a reserve skill. SKLEVEL applies to LOGONSKILL. The SKLEVEL item is available with the EAS feature.

This is an administrative item.

Agent login/logout tables

An indication of the agent's skill level, which is 1 through 16 for a normal skill, or reserve level, which is 1 or 2 for a reserve skill. SKLEVEL applies to LOGONSKILL. The SKLEVEL item is available with the EAS feature.

SKLEVEL2 through SKLEVEL20

The SKLEVEL2 through SKLEVEL20 items appear in the following database tables:

Agent tables

An indication of the agent's skill level, which is 1 through 16 for a normal skill, or reserve level, which is 1 or 2 for a reserve skill. SKLEVEL2 through SKLEVEL20 apply to LOGONSKILL2 through LOGONSKILL20, respectively. The SKLEVEL2 through SKLEVEL20 items are available with the EAS feature.

This is an administrative item.

Agent login/logout tables

An indication of the agent's skill level, which is 1 through 16 for a normal skill, or reserve level, which is 1 or 2 for a reserve skill. This SKLEVEL2 through SKLEVEL20 applies to LOGONSKILL2 through LOGONSKILL20, respectively. The SKLEVEL2 through SKLEVEL20 items are available with the EAS feature.

SKLEVEL21 through SKLEVEL60 (real-time)

The SKLEVEL21 through SKLEVEL60 items appear in the following database tables:

Agent tables

This item is an indication of the skill level for an agent, which is 1 through 16 for a normal skill, or reserve level, which is 1 or 2 for a reserve skill. SKLEVEL21 through SKLEVEL60 apply to LOGONSKILL21 through LOGONSKILL60, respectively. These items are available with the EAS feature.

Agent login/logout tables

This item is an indication of the skill level for an agent, which is 1 through 16 for a normal skill, or reserve level, which is 1 or 2 for a reserve skill. SKLEVEL21 through SKLEVEL60 apply to LOGONSKILL21 through LOGONSKILL60, respectively. These items are available with the EAS feature.

SKPERCENT

The SKPERCENT item is included in the following database tables:

Agent tables

The percentage of time that is allocated for the agent to spend in LOGONSKILL. The SKPERCENT item is available on Avaya communication servers with the EAS feature.

This is an administrative item.

Agent login/logout tables

The percentage of time that is allocated for the agent to spend in LOGONSKILL. The SKPERCENT item is available on Avaya communication servers with the EAS feature.

This is an administrative item.

SKPERCENT2 through SKPERCENT20

The SKPERCENT2 through SKPERCENT20 items appear in the following database tables:

Agent tables

The percentage of time that is allocated for the agent to spend in LOGONSKILL2 through LOGONSKILL20. The SKPERCENT2 through SKPERCENT20 items are available on Avaya communication servers with the EAS feature.

This is an administrative item.

Agent login/logout tables

The percentage of time that is allocated for the agent to spend in LOGONSKILL2 through LOGONSKILL20. The SKPERCENT2 through SKPERCENT20 items are available on Avaya communication servers with the EAS feature.

This is an administrative item.

SKPERCENT21 through SKPERCENT60 (real-time)

The SKPERCENT21 through SKPERCENT60 items appear in the following database tables:

Agent tables

This item stores the percentage of time that is allocated for the agent to spend in LOGONSKILL21 through LOGONSKILL60. The SKPERCENT21 through SKPERCENT60 items are available on Avaya communication servers with the EAS feature.

This is an administrative item.

Agent login/logout tables

This item stores the percentage of time that is allocated for the agent to spend in LOGONSKILL21 through LOGONSKILL60. The SKPERCENT21 through SKPERCENT60 items are available on Avaya communication servers with the EAS feature.

This is an administrative item.

SKSTATE (real-time)

The SKSTATE item is included in the following database tables:

Split/skill tables

The state of the skill compared to all administered thresholds. Possible states are UNKNOWN, NORMAL, OVRLD1, OVRLD2, BEHIND, and AUTORSV.

The SKSTATE item is available on Avaya communication servers with the EAS feature.

SLVLABNS

The SLVLABNS item is included in the following database tables:

Split/skill tables

The number of ABNCALLS for which the time-to-abandon was less than or equal to the administered SERVICELEVEL for this split/skill.

This is a cumulative item.

VDN tables

The number of ABNCALLS for which the time-to-abandon was less than or equal to the administered SERVICELEVEL for this VDN.

This is a cumulative item.

SLVOUTFLOWS

The SLVOUTFLOWS item is included in the following database tables:

Split/skill tables

The number of OUTFLOWCALLS for which the time-to-outflow was less than or equal to administered SERVICELEVEL for this split/skill.

This is a cumulative item.

VDN tables

The number of OUTFLOWCALLS for which the time-to-outflow was less than or equal to the administered SERVICELEVEL for this VDN.

This is a cumulative item.

SPLIT (index)

The SPLIT item is included in the following database tables:

Split/skill tables

The number of the split/skill for which data was collected.

This is a row identifier item.

Agent tables

On communication servers without the EAS feature, SPLIT is the number of the split number to which the EXTENSION is assigned.

On communication servers with the EAS feature, SPLIT is the number of the skill to which the agent logged in.

This is an administrative item.

Trunk group tables

The number of the split/skill to which this TKGRP terminates.

This is an administrative item.

Trunk tables

The number of the first split/skill to which the call is currently queued or the number of the split/skill in which the call was answered. SPLIT is blank (NULL) when the trunk idles.

In the trunk tables, SPLIT is a real-time item.

This is a status item.

Agent trace tables

On communication servers without the EAS feature, SPLIT is the number of the split number to which the EXTENSION is assigned.

On communication servers with the EAS feature, SPLIT is the number of the skill to which the agent logged in.

This is an administrative item.

Current day report tables

The number of the split/skill for which data was collected.

This is a row identifier item.

Agent login/logout tables

On communication servers without the EAS feature, SPLIT is the number of the split number to which the EXTENSION is assigned.

On communication servers with the EAS feature, SPLIT is the number of the skill to which the agent logged in.

This is an administrative item.

Current day configuration tables

The number of the split/skill for which data was collected.

This is a row identifier item.

Agent exception tables

The split/skill in which the agent was doing work when the exception occurred.

This is an administrative item.

Split/skill exception table

The split/skill in which the exception occurred.

This is a row identifier item.

Malicious call trace table

The split/skill in which the agent was doing work when the malicious call was reported.

This is an administrative item.

SPLIT1

The SPLIT1 item is included in the following database tables:

Call record tables

The number of the first split/skill to which the call queued in the first VDN with which it was associated in the call segment.

This is an administrative item.

SPLIT2 and SPLIT3

The SPLIT2 and SPLIT3 items appear in the following database tables:

Trunk tables

The numbers of the second and third splits/skills to which the call is queued. This is blank (NULL) when the call dequeues. A call dequeues when it is answered, abandoned, forced busy, or forced disconnected. The SPLIT2 and SPLIT3 items are available with the Vectoring feature.

In the trunk tables, SPLIT2 and SPLIT3 are real-time items.

This is an administrative item.

Call record tables

The numbers of the second and third splits/skills to which the call is queued to in the first VDN with which it was associated in the call segment. The SPLIT2 and SPLIT3 items are available with the Vectoring feature.

This is an administrative item.

STAFFED (real-time)

The STAFFED item is included in the following database tables:

Split/skill tables

The number of POSITIONS that are currently logged in. $STAFFED = AVAILABLE + AGINRING + ONACD + INACW + INAUX + OTHER$.

STAFFED does not include R1OTHERSTBY, R2OTHERSTBY, and R2INAUXSTBY and R1INAUXSTBY.

This is a status item.

STARTED (real-time)

The STARTED item is included in the following database tables:

Agent tables

The time of day at which WORKMODE began. Valid values for STARTED are NULL and time of day. This is a status item.

Trunk tables

The time of day at which TKSTATE started. Valid values for STARTED are NULL and time of day.

This is a status item.

STARTTIME (interval)

The STARTTIME item is included in the following database tables:

Split/skill tables

The start time of the interval for which data was collected. STARTTIME applies only to the interval table.

This is a row identifier item.

Agent tables

The start time for the interval for which data was collected. STARTTIME applies only to the Interval table.

This is a row identifier item.

Trunk group tables

The start time of the interval for which data was collected. STARTTIME applies only to the interval table.

This is a row identifier item.

Trunk tables

The start time of the interval for which data was collected. STARTTIME applies only to the interval table.

This is a row identifier item.

Vector tables

The start time of the interval for which data was collected. STARTTIME applies only to the interval table.

This is a row identifier item.

VDN tables

The start time of the interval for which data was collected. STARTTIME applies only to the interval table.

This is a row identifier item.

Call work codes tables

The start time of the interval for which data was collected. STARTTIME applies to the only interval table.

This is a row identifier item.

Agent trace tables

The time of day (hour and minute) for which the agent trace is being ordered. This is the time of day you enter to request the report.

This is a row identifier item.

Current day report tables

The start time of the intrahour interval for which data was collected. STARTTIME applies only to the interval table.

This is a row identifier item.

SVCLEVELCHG

The SVCLEVELCHG item is included in the following database tables:

Split/skill tables

An indication of whether the service level was changed during the collection interval. Valid values for SVCLEVELCHG are 0, which means that no change was made, and 1, which means that a change was made.

This is an administrative item.

VDN tables

An indication of whether the service level was changed during the collection interval. Valid values for SVCLEVELCHG are 0, which means that no change was made, and 1, which means that a change was made.

This is an administrative item.

TAGINRING (real-time)

The TAGINRING item is included in the following database tables:

Split/skill tables

The number of top agents who are logged into the skill, have ACD calls ringing, and are not doing anything else. The TAGINRING item is available with the EAS feature.

This is a status item.

TALKTIME

The TALKTIME item is included in the following database tables:

Call record tables

The total talk time for the answering agent in this segment.

TARGETABNS

THE TARGETABNS item appears in the split/skill tables.

This item represents the number of abandoned calls that occurred within the administered target service level (TARGETSECONDS). This information is recorded for all splits.

TARGETACDCALLS

The TARGETACDCALLS item appears in the split/skill tables.

This item represents the number of ACD calls that were answered within the administered target service level (TARGETSECONDS). This information is recorded for all splits.

TARGETOUTFLOWS

The TARGETOUTFLOWS item appears in the split/skill tables.

This item represents the number of calls that outflowed within the administered target service level (TARGETSECONDS). This information is recorded for all splits.

TARGETPCTCHG

The TARGETPCTCHG items appears in the split/skill tables.

This item indicates if the target service level percentage was modified during the collection interval. Valid values for this field are 0, indicating that no change was made, and 1, indicating that a change was made. This is an administrative item.

TARGETPERCENT

The TARGETPERCENT item appears in the split/skill tables.

This item stores the percentage of the target service level that is specified on the Avaya communication server for a selected split/skill. The archiving process that transforms data for larger time intervals, such as daily to weekly, will record the maximum value of TARGETPERCENT.

TARGETSECCHG

The TARGETSECCHG item appears in the split/skill tables.

This item indicates if the number of target seconds was modified during the collection interval. Valid values for this field are 0, indicating that no change was made, and 1, indicating that a change was made. This is an administrative item.

TARGETSECONDS

The TARGETSECONDS item appears in the split/skill tables.

This item stores the number of target seconds specified on the Avaya communication server for the split/skill target service level. The archiving process that transforms data for larger time intervals, such as daily to weekly, will record the maximum value of TARGETSECONDS.

TAVAILABLE (real-time)

The TAVAILABLE item is included in the following database tables:

Split/skill tables

The number of top agents who are logged in and available in the skill. The TAVAILABLE item is available with the EAS feature.

This is a status item.

TDA_INACW (real-time)

The TDA_INACW item is included in the following database tables:

Split/skill tables

The number of top agents who are logged into the skill and in ACW that is associated with direct agent calls. TDA_INACW is a subset of TOTHER. The TDA_INACW item is available with the ASAI or EAS feature.

This is a status item.

TDA_ONACD (real-time)

The TDA_ONACD item is included in the following database tables:

Split/skill tables

The number of top agents who are logged into the skill and talking on direct agent calls. TDA_ONACD is a subset of TOTHER. The TDA_ONACD item is available with the ASAI or EAS feature.

This is a status item.

THRESHOLD

The THRESHOLD item appears in the following tables.

Agent exception table

The limit, given as a number of occurrences, that is administered for the exception type. An exception occurs when the agent's activity falls outside of the limit.

This is an administrative item.

Split/skill exception table

The limit, given as a number of occurrences, that is administered for the exception type. An exception occurs when activity in the split/skill falls outside of the limit.

This is an administrative item.

Trunk group exception table

The limit, given as a number of occurrences, that is administered for the exception type. An exception occurs when activity in the trunk group falls outside of the limit.

This is an administrative item.

VDN exception table

The limit, given as a number of occurrences, that is administered for the exception type. An exception occurs when activity in the VDN falls outside of the limit.

This is an administrative item.

Vector exception table

The limit, given as a number of occurrences, that is administered for the exception type. An exception occurs when activity in the vector falls outside of the limit.

This is an administrative item.

Data collection exception table

The limit, given as a number of occurrences, that is administered for the exception type. An exception occurs when data collection activity falls outside of that limit.

This is an administrative item.

TI_AUXTIME

The TI_AUXTIME item is included in the following database tables:

Agent tables

The length of time during the collection interval that the agent spends in AUX for all splits/skills, or on AUXINCALLS or AUXOUTCALLS and SPLIT was OLDEST_LOGON. “TI_” time is stored for the split/skill in which the agent has been logged in the longest. “TI_” needs to be summed across the splits/skills that the agent may log into in case the logon order changes during the collection interval.

NOTE: When OLDEST_SKILL is a Reserve Level Skill, the TI_AUXTIME (agent) database item includes the time that an agent was in AUX Work whether the skill is in a normal or an over-threshold condition.

TI_AUXTIME includes TI_AUXTIME0, TI_AUXTIME1 through 9, TI_AUXTIME10 through 99 (optional feature), I_AUXINTIME, and I_AUXOUTTIME.

SUM(TI_AUXTIME) equals the sum of all TI_AUXTIME items, 0-9, 10-99 (optional feature), over all splits/skills that the agent was logged into.

This is a cumulative item.

TI_AUXTIME0

The TI_AUXTIME0 item is included in the following database tables:

Agent tables

The length of time that the agent spends in AUX with a reason code of 0 (zero). “TI_” time is stored for the split/skill in which the agent has been logged in the longest. “TI_” needs to be summed across the splits/skills that the agent may log into in case the logon order changes during the collection interval. On communication servers with AUX reason codes active, TI_AUXTIME0 is the time that is spent in “system” AUX work. TI_AUXTIME0 is the same as TI_AUXTIME for communication servers without AUX reason codes active.

This is a cumulative item.

TI_AUXTIME1 through TI_AUXTIME9

The TI_AUXTIME1 through TI_AUXTIME9 items appear in the following database tables:

Agent tables

The length of time that the agent spends in AUX with reason codes of 1 through 9. "TI_" time is stored for the split/skill in which the agent has been logged in the longest. "TI_" needs to be summed across the splits/skills that the agent may log into in case the logon order changes during the collection interval. The TI_AUXTIME1 through TI_AUXTIME9 items are available on Avaya communication servers with the EAS feature.

This is a cumulative item.

TI_AUXTIME10 through TI_AUXTIME99

Note:

The TI_AUXTIME10 through 99 items are available if you purchased the expanded AUX reason codes feature.

The TI_AUXTIME10 through TI_AUXTIME99 items appear in the following database tables:

Agent tables

The length of time that the agent spends in AUX with reason codes of 10 through 99. "TI_" time is stored for the split/skill in which the agent has been logged in the longest. "TI_" needs to be summed across the splits/skills that the agent may log into in case the logon order changes during the collection interval. The TI_AUXTIME10 through TI_AUXTIME99 items are available on Avaya communication servers with the EAS feature.

This is a cumulative item.

TI_AVAILTIME

The TI_AVAILTIME item is included in the following database tables:

Agent tables

The length of time during the collection interval that the agent is in the AVAIL state for split/skill or direct agent ACD calls in any split/skill. TI_AVAILTIME is recorded for the split/skill in which the agent has been logged in the longest. "TI_" time needs to be summed across the splits/skills the agents may log in to, in case the logon order changes during the collection interval. On communication servers without the EAS feature, if an agent logs into multiple splits and is in AUX mode in one split and is available for ACD calls in another split, the agent accrues I_AVAILTIME for the split in which the agent is available and TI_AVAILTIME in the split that the agent has been logged into the longest.

This is a cumulative item.

TI_OTHERTIME

The TI_OTHERTIME item is included in the following database tables:

Agent tables

The length of time during the collection interval that the agent is in OTHER in any split/skill. TI_OTHERTIME is collected for the time period after the link to the communication server is initiated and directly after the agent logs in but before the CMS is notified of the agent's work state.

While the agent is in Auto-In or Manual-In, other work for this split/skill includes the amount of time that is spent doing any of the following:

- An agent put any call on hold and perform no further action.
- The agent is on a direct agent call or in ACW for a direct agent call.
- The agent is dialing to place a call or to activate a feature.
- An extension call or a direct agent ACD call is ringing with no other activity.
- The length of time agents were logged into multiple splits/skills and doing work for a split/skill other than this one.

"TI_" time is stored for the split/skill in which the agent has been logged in the longest. "TI_" needs to be summed across the splits/skills that the agent may log into in case the logon order changes during the collection interval. TI_OTHERTIME includes I_ACDOTHERTIME.

Note:

When OLDEST_SKILL is a Reserve Level Skill, the TI_OTHERTIME (agent) database item includes the time that an agent was in AUX Work whether the skill is in a normal or an over-threshold condition.

This is a cumulative item.

TI_STAFFTIME

The TI_STAFFTIME item is included in the following database tables:

Agent tables

The length of time during the collection interval that the agent is staffed in any split/skill. "TI_" time is stored for the split/skill in which the agent has been logged in the longest. "TI_" needs to be summed across the splits/skills that the agent may log into in case the logon order changes during the collection interval. $\text{sum}(\text{TI_STAFFTIME}) = \text{sum}(\text{I_ACDTIME} + \text{I_ACWTIME} + \text{I_DA_ACDTIME} + \text{I_DA_ACWTIME} + \text{I_RINGTIME} + \text{TI_AUXTIME} + \text{TI_AVAILTIME} + \text{TI_OTHERTIME})$, over all of the splits/skills that the agent was logged into.

NOTE: When OLDEST_SKILL is a Reserve Level Skill, the TI_STAFFTIME (agent) database item includes the time that an agent was in AUX Work whether the skill is in a normal or an over-threshold condition.

This is a cumulative item.

TIME

The TIME item is included in the following database tables:

Agent exception table

The limit, given as a number of seconds, that is administered for timed exception types. An occurrence is logged against the threshold when the agent's activity falls outside of the limit.

This is an administrative item.

Split/skill exception table

The limit, given as a number of seconds, that is administered for timed exception types. An occurrence is logged against the threshold when activity in the split/skill falls outside of the limit.

This is an administrative item.

Trunk group exception table

The limit, given as a number of seconds, that is administered for timed exception types. An occurrence is logged against the threshold when activity in the trunk group falls outside of the limit.

This is an administrative item.

VDN exception table

The limit, given as a number of seconds, that is administered for timed exception types. An occurrence is logged against the threshold when activity in the VDN falls outside of the limit.

This is an administrative item.

Vector exception table

The limit, given as a number of seconds, that is administered for timed exceptions types. An occurrence is logged against the threshold when activity in the vector falls outside of the limit.

This is an administrative item.

TINACW (real-time)

The TINACW item is included in the following database tables:

Split/skill tables

The number of top agents who are logged into the skill and in ACW for ACD calls to the skill. This includes top agents who are on ACWIN or ACWOUT calls and agents who are in ACW that is not associated with an ACD call. TINACW includes TONACWIN and TONACWOUT. The TINACW item is available with the EAS feature.

This is a status item.

TINAUX (real-time)

The TINAUX item is included in the following database tables:

Split/skill tables

The number of top agents who are logged into the skill and in the AUX work mode. This includes agents on AUXIN or AUXOUT calls. TINAUX includes TINAUX0, TINAUX1 through TINAUX9, TONACDAUXOUT, TONAUXIN, and TONAUXOUT. The TINAUX item is available with the EAS feature.

This is a status item.

TINAUX0 (real-time)

The TINAUX0 item is included in the following database tables:

Split/skill tables

The number of top agents who are logged into the skill and AUX work for reason code 0 (zero) for all splits/skills or on an AUXIN or AUXOUT call for AUX with reason code 0 (zero). On communication servers with AUX reason codes active, TINAUX0 is the time that is spent in “system” AUX work. The TINAUX0 item is available with the EAS feature.

This is a status item.

TINAUX1 through TINAUX9 (real-time)

The TINAUX1 through TINAUX9 items appear in the following database tables:

Split/skill tables

The number of top agents who are logged into the skill and in AUX work with the reason codes 1 through 9 for all splits/skills. This includes agents on AUXIN or AUXOUT calls from AUX with the appropriate reason code. The TINAUX1 through TINAUX9 items are available with the EAS feature.

This is a status item.

TINAUX10 through TINAUX99 (real-time)

Note:

The TINAUX10 through 99 items are available if you have purchased the expanded AUX reason codes feature.

The TINAUX10 through TINAUX99 items appear in the following database tables:

Split/skill tables

The number of top agents who are logged into the skill and in AUX work with the reason codes 10 through 99 for all splits/skills. This includes agents on AUXIN or AUXOUT calls from AUX with the appropriate reason code. The TINAUX10 through TINAUX99 items are available with the EAS feature.

This is a status item.

TKGRP

The TKGRP item is included in the following database tables:

Trunk group tables

The trunk group number for which data was collected. This is zero if the trunk group carrying the call is not measured.

This is a row identifier item.

Trunk tables

The trunk group number to which the trunk is assigned.

This is an administrative item.

Call record tables

The trunk group number for which data was collected or for which an exception occurred. This is zero if the trunk group carrying the call is not measured.

This is an administrative item.

Trunk group exception table

The trunk group number for which data was collected or for which an exception occurred. This is zero if the trunk group carrying the call is not measured.

This is a row identifier item.

Malicious call trace exception table

The trunk group number for which data was collected or for which an exception occurred.

This is zero if the trunk group carrying the call is not measured.

This is an administrative item.

TKSTATE (real-time)

The TKSTATE item is included in the following database tables:

Trunk tables

The state of the current call. Trunk states include: IDLE, SEIZED, QUEUED, CONN, RING, DABN, FBUSY, FDISC, HOLD, MBUSY, UNKNOWN, or as defined in Dictionary.

This is a status item.

TONACD (real-time)

The TONACD item is included in the following database tables:

Split/skill tables

The number of top agents who are logged into the skill and on inbound and outbound ACD calls for the skill. TONACD includes TONACDOUT. The TONACD item is available with the EAS feature.

This is a status item.

TONACDAUXOUT (real-time)

The TONACDAUXOUT item is included in the following database tables:

Split/skill tables

The number of top agents who are logged into the skill and on AUXOUT calls with an ACD call for the skill on hold. The TONACDAUXOUT item is available with the EAS feature.

This is a status item.

TONACDOUT (real-time)

The TONACDOUT item is included in the following database tables:

Split/skill tables

The number of top agents who are on outbound calls that were placed by an adjunct to this skill. The TONACDOUT item is available with the ASAI feature.

This is a status item.

TONACWIN (real-time)

The TONACWIN item is included in the following database tables:

Split/skill tables

The number of top agents who are in ACW for this skill and on inbound extension calls. These agents also appear in TINACW. The TONACWIN item is available with the EAS feature.

This is a status item.

TONACWOUT (real-time)

The TONACWOUT item is included in the following database tables:

Split/skill tables

The number of top agents who are in ACW for this skill and on outbound extension calls. These agents also appear in TINACW. The TONACWOUT item is available with the EAS feature.

This is a status item.

TONAUXIN (real-time)

The TONAUXIN item is included in the following database tables:

Split/skill tables

The number of top agents who are in AUX work, AVAILABLE or with an ACD, AUXIN, or AUXOUT call that is attributed to this split/skill on hold and on inbound extension calls. The TONAUXIN item is available with the EAS feature.

This is a status item.

TONAUXOUT (real-time)

The TONAUXOUT item is included in the following database tables:

Split/skill tables

The number of top agents who are in AUX work, AVAILABLE or with an ACD, AUXIN, or AUXOUT call that is attributed to this split/skill on hold and on inbound extension calls. The TONAUXOUT item is available with the EAS feature.

This is a status item.

TOPCALLS

The TOPCALLS item is included in the following database tables:

Split/skill tables

The number of ACDCALLS with top priority that are answered by agents in this split/skill. The TOPCALLS item is available with the Vectoring feature.

This is a cumulative item.

TOPSKILL (real-time)

The TOPSKILL item is included in the following database tables:

Agent tables

The agent's first-administered, highest level, measured skill, where skill level 1 is the highest and skill level 16 is the lowest. The TOPSKILL item is available with the EAS feature.

The TOPSKILL of an agent is 0 except when PREFERENCE is set to skill level (LVL). This means that an agent does not have a top skill and is not counted in any split/skill table Top Skill items if their call handling preference is greatest need (NEED) or percent allocation (PCNT). In addition, agents who have skill level preference but only reserve levels for all of their skills do not have a TOPSKILL.

This is a status item.

TOT_PERCENTS (real-time)

The TOT_PERCENTS item is included in the following database tables:

Split/Skill tables

The total staffed agent percentages that are allocated to the skill. The TOT_PERCENTS item is available on Avaya communication servers with the EAS feature.

This is an administrative item.

TOTHER (real-time)

The TOTHER item is included in the following database tables:

Split/skill tables

The number of top agents who are doing other work. This includes agents who are logged into multiple splits/skills and doing work for a split/skill other than this skill. Agent POSITIONS show up in OTHER directly after the link to the communication server is initiated and directly after the agents log in before the CMS is notified of the agent's work state.

While the agent is in Auto-In or Manual-In, other work for this split/skill includes the amount of time that is spent doing any of the following:

- An agent put any call on hold and perform no further action.
- The agent is on a direct agent call or in ACW for a direct agent call.
- The agent is dialing to place a call or to activate a feature.
- An extension call or a direct agent ACD call is ringing with no other activity.
- The length of time agents were logged into multiple splits/skills and doing work for a split/skill other than this one.

With the EAS feature and multiple call handling, agents are available in other multiple call handling skills, but not in this skill.

TOTHER includes TDA_INACW and TDA_ONACD. The TOTHER item is available with the EAS feature.

This is a status item.

TRANSFERRED

The TRANSFERRED item is included in the following database tables:

Split/skill tables

The number of ACDCALLS that are transferred to another destination. TRANSFERRED includes all split/skill calls that are transferred.

This is a cumulative item.

Agent tables

The number of calls that the agent transferred to another destination. TRANSFERRED includes all calls that are transferred.

This is a cumulative item.

Trunk group tables

The number of calls that the agent transferred to another destination. TRANSFERRED calls include both inbound and outbound calls. Therefore, OTHERCALLS and O_OTHERCALLS may each include some TRANSFERRED. TRANSFERRED includes all calls that are transferred.

This is a cumulative item.

VDN tables

The number of calls that are transferred to another destination. TRANSFERRED includes all of the VDN calls that are transferred.

This is a cumulative item.

Agent trace tables

An indication of whether the answering agent initiated a transfer for this call. Valid values for TRANSFERRED are 0, which means that “no” transfer was initiated, and 1, which means that “yes” a transfer was initiated. TRANSFERRED includes all calls that are transferred.

Call record tables

An indication of whether the answering agent initiated a transfer for this call. Valid values for TRANSFERRED are 0, which means that “no” transfer was initiated, and 1, which means that “yes” a transfer was initiated. TRANSFERRED includes all calls that are transferred.

TRENDBASE

The TRENDBASE item is included in the following database tables:

Current day configuration tables

The base date for seasonal trending.

This is an administrative item.

TRUNKS

The TRUNKS item appears in the following tables.

Trunk group tables

The number of trunks that are currently assigned to this TKGRP.

This is an administrative item.

TSTAFFED (real-time)

The TSTAFFED item is included in the following database tables:

Split/skill tables

The number of top agents who are currently staffed in SPLIT. $TSTAFFED = TAVAILABLE + TAGINRING + TONACD + TINACW + TINAUX + TOTHER$. The TSTAFFED item is available with the EAS feature.

This is a status item.

TYPE (real-time)

The TYPE item is included in the following database tables:

Agent tables

The skill type, p for primary or s for secondary, that is associated with the SPLIT. The TYPE item is available with the EAS and Vectoring features.

On Avaya communication servers with the EAS feature, skill level 1 is represented by p, skill level 2 is represented by s and skill levels 3 through 16 are blank. Users of more than two skill levels should use the SKLEVEL items instead of SKILLTYPE.

This is an administrative item.

UCID

The UCID item is included in the following database tables:

Agent trace tables

The UCID is the Universal Call Identifier, which is a unique number that is assigned to this call segment within the customer network.

Call record tables

The UCID is the Universal Call Identifier-a unique number assigned to this call segment within the customer network.

USE_SVC_OBJ (real-time)

The USE_SVC_OBJ item is included in the following database tables:

Agent tables

The agent requests receipt of calls based on the administered service objective for this skill. Valid values for USE_SVC_OBJ are 1, which means that the request is made, and 2, which means that no request is made. The USE_SVC_OBJ item is available on Avaya communication servers with the EAS feature.

This is an administrative item.

VDISCCALLS

The VDISCCALLS item is included in the following database tables:

Vector tables

The number of calls that are forced to disconnect because the vector disconnect timer expired or because the call reached a vector stop without being queued. A vector stop means that the “stop” vector command is executed, the end of the vector is reached, or the call executes 1000 vector steps.

This is a cumulative item.

VDN tables

The number of calls that are forced to disconnect because the vector disconnect timer expired or because the call reached a vector stop without being queued. A vector stop means that the “stop” vector command is executed, the end of the vector is reached, or the call executes 1000 vector steps.

This is a cumulative item.

VDN

The VDN item is included in the following database tables:

Agent tables

The VDN that is associated with the agent's current split/skill or direct agent ACD call. The VDN item is available with the Vectoring feature.

This is a status item.

Trunk group tables

The VDN to which the TKGRP terminates. The VDN item is available with the Vectoring feature.

This is an administrative item.

Trunk tables

The VDN that is associated with the current call. This stays set until the trunk idles, at which time it is set to NULL. The VDN item is available with the Vectoring feature.

This is a status item.

VDN tables

The vector directory number that is associated with this VDN.

This is a row identifier item.

VDN exception table

The VDN for which the exception occurred or that carried the malicious call. The VDN item is available with the Vectoring feature.

This is a row identifier item.

Malicious call trace exception table

The VDN for which the exception occurred or that carried the malicious call. The VDN item is available with the Vectoring feature.

This is an administrative item.

VECTOR

The VECTOR item is included in the following database tables:

Trunk tables (real-time)

The vector that is associated with the current call. This stays set until the trunk idles, at which time it is set to NULL. The VECTOR item is available with the Vectoring feature.

This is a real-time, status item.

Trunk Group tables

The VDN or vector that the trunk group terminates to.

This is an administrative item.

Vector tables

The vector number that this row represents. The VECTOR item is available with the Vectoring feature.

This is a row identifier item.

VDN tables

The vector number that is associated with this VDN.

This is an administrative item.

VDN exception table

The vector number that is associated with this VDN or for which the exception occurred.

This is an administrative item.

Vector exception table

The vector number that this row represents or for which the exception occurred.

This is a row identifier item.

WMODE_SEQ

The WMODE_SEQ item is included in the following database tables:

Agent trace tables

The sequence number for events that occur in the same second.

WORKCODE

The WORKCODE item is included in the following database tables:

Agent trace tables

The call work code that the agent entered for the call. The WORKCODE item is available when call work codes are implemented.

WORKMODE (real-time)

The WORKMODE item is included in the following database tables:

Agent tables

The work mode that the agent is currently using. Agent work modes include: AVAIL, ACD, ACW, AUX, DACD, DACW, RING, UNKNOWN, OTHER, and UNSTAFF. If the agent was not logged in during the collection interval, the value is blank.

This is a status item.

Agent trace tables

The work mode in which the agent was working during the trace. Agent work modes include: AVAIL, ACD, ACW, AUX, DACD, DACW, RING, UNKNOWN, OTHER, and UNSTAFF. If the agent was not logged in during the collection interval, the value is blank.

WORKSKILL (real-time)

The WORKSKILL item is included in the following database tables:

Agent tables

The number of the skill in which the agent is currently working.

Use WORKSKILL for the following call conditions:

- When an agent is on a split/skill or direct agent ACD call or in ACW (this is the split/skill associated with the call or ACW).
- When an agent is available, in AUX or in OTHER (this is null [blank]).
- When an agent is on an AUXIN call (this is OLDEST_LOGON split/skill).
- When an agent is on an AUXIN or AUXOUT call from the available state, while in AUX or with an AUXIN or AUXOUT call on hold (this is OLDEST_LOGON split/skill).
- When an agent is on an AUXOUT call with an ACD call on hold (this is the split/skill associated with the ACD call).

WORKSKILL differs from WORKSPLIT only when the agent is available, in which case WORKSKILL is blank and WORKSPLIT displays one of the split/skills in which the agent is available. Using WORKSKILL instead of WORKSPLIT in reports is recommended. The WORKSKILL item is available with the EAS feature.

This is a status item.

WORKSKLEVEL (real-time)

The WORKSKLEVEL item is included in the following database tables:

Agent tables

WORKSKLEVEL is the normal skill level 1 through 16 or a reserve skill level 1 or 2. The WORKSKLEVEL applies to WORKSKILL. The WORKSKLEVEL item is available with the EAS feature.

This is a status item.

WORKSPLIT (real-time)

The WORKSPLIT item is included in the following database tables:

Agent tables

The number of the split in which the agent is currently working.

Use WORKSPLIT for the following call conditions:

- When an agent is on a split/skill or direct agent ACD call or in ACW (this is the split/skill associated with the call or ACW).
- When an agent is available (this is the last split/skill the agent went available in).
- When an agent is on an AUXIN or AUXOUT call from the available state, while in AUX or with an AUXIN or AUXOUT call on hold (this is OLDEST_LOGON split/skill).
- When an agent is on an AUXIN call with an ACD call on hold (this is OLDEST_LOGON split/skill).
- When an agent is on an AUXOUT call with an ACD call on hold (this is the split/skill associated with the ACD call).

WORKSKILL differs from WORKSPLIT only when the agent is available, in which case WORKSKILL is blank and WORKSPLIT displays one of the split/skills in which the agent is available. Using WORKSKILL instead of WORKSPLIT in reports is recommended for EAS.

This is a status item.

WORKSPLIT2 and WORKSPLIT3 (real-time)

The WORKSPLIT2 and WORKSPLIT3 items appear in the following database tables:

Agent tables

The numbers of splits/skills other than WORKSPLIT in which the agent is available.

WORKSPLIT2 and WORKSPLIT3 apply to agents who are logged into more than one split/skill.

This is a status item.

WORKSPLIT4 through WORKSPLIT20 (real-time)

The WORKSPLIT4 through WORKSPLIT20 items appear in the following database tables:

Agent tables

The numbers of splits/skills other than WORKSPLIT in which the agent is available. WORKSPLIT4 through WORKSPLIT20 apply to agents who are logged into more than one split/skill.

This is a status item.

WORKSPLIT21 through WORKSPLIT60 (real-time)

The WORKSPLIT21 through WORKSPLIT60 items appear in the following database tables:

Agent tables

This item stores the numbers of splits/skills other than WORKSPLIT in which the agent is available. WORKSPLIT21 through WORKSPLIT60 apply to agents who are logged into more than one split/skill.

This is a status item.

WT1 through WT4

The WT1 through WT4 items appear in the following database tables:

Current day configuration tables

The weight that is given to date 1 (WT1), date 2 (WT2), date 3 (WT3), and date 4 (WT4), which are used in forecasting.

This is an administrative item.

■ ■ ■ ■ ■ ■

Definitions of CMS calculations

Definitions of CMS calculations includes definitions of the calculations that are used in the CMS and CMS Supervisor reports.

Definitions of CMS calculations also includes information and cross-reference tables for the search values used in calculations.

CMS uses calculations of database items in many reports. You can use standard calculations in custom reports, or you can create new ones. You should never modify standard calculations or the meaning of the data will be changed.

Example standard dictionary calculations table

Below is an example of how the definition of each calculation is presented in *Definitions of CMS calculations*.

| Calculation name | Calculation | Description |
|--|--|--------------------------------------|
| CALCULATION NAME (as it appears in the CMS Dictionary) | Mathematical definition of the calculation | Short description of the calculation |

Search values

Search values presents database search values. Use the tables in this section to identify how CMS stores the row search values.

Organization

There are two types of tables in *Search values*:

- [Agent state and row search values cross-reference tables](#) on page 334
- [Call disposition and row search values cross-reference tables](#) on page 337

Agent state and row search values cross-reference tables

Use the following tables to identify how CMS relates agent state database items to the row search values in the database.

Agent database items

| Status database items | State names | Values for row search |
|-----------------------|-------------|-----------------------|
| AG_DEST | PBX | 1 |
| | OFF | 2 |
| AG_DIR | OUT | 1 |
| | IN | 2 |
| AG_ORIG | (Blank) | 0 |
| | PHONE | 1 |
| | KEYBOARD | 2 |
| AG_PREF | LVL | 1 |
| | NEED | 2 |
| | PCNT | 3 |
| LEVEL | R1 | 51 |
| | R2 | 52 |

Agent database items

| Status database items | State names | Values for row search |
|------------------------------|--------------------|------------------------------|
| ROLE | ALLC | 1 |
| | BCKP | 3 |
| | ROVE | 0 |
| | RSRV | 4 |
| | TOP | 2 |
| WORKMODE | UNKNOWN | 0 |
| | UNSTAF | 10 |
| | AVAIL | 20 |
| | ACD | 30 |
| | ACW | 40 |
| | AUX | 50 |
| | DACD | 60 |
| | DACW | 70 |
| | OTHER | 220 |
| | RING | 80 |
| | LOGON | 100 |
| | LOGOFF | 110 |
| | TRACE ON | 120 |
| | TRACE OFF | 121 |

Definitions of CMS calculations

Trunk database items

| Status database items | State names | Values for row search |
|-----------------------|-------------|-----------------------|
| ALL_BUSY | YES | 1 |
| | NO | 0 |
| TKSTATE | UNKNOWN | 0 |
| | IDLE | 1 |
| | SEIZED | 2 |
| | QUEUED | 3 |
| | CONN | 4 |
| | DABN | 5 |
| | MBUSY | 6 |
| | FBUSY | 7 |
| | FDISC | 8 |
| | HOLD | 9 |
| | RING | 80 |
| TK_DIR | IN | 2 |
| | OUT | 1 |
| TK_PRI | YES | 1 |
| | NO | 0 |
| TK_QTYPE | MAIN | 1 |
| | BACKUP | 2 |
| TK_VPRI | LOW | 1 |
| | MED | 2 |
| | HIGH | 3 |
| | TOP | 4 |

Miscellaneous database items

| Status database items | State names | Values for row search |
|-----------------------|-------------|-----------------------|
| PER_CHG | YES | 1 |
| | NO | 0 |
| SLVL_CHG | YES | 1 |
| | NO | 0 |
| SKSTATE | UNKNOWN | 0 |
| | NORMAL | 1 |
| | OVRLD1 | 2 |
| | OVRLD2 | 3 |
| YES_NO | n | 0 |
| | y | 1 |

Call disposition and row search values cross-reference tables

Use the following table to identify how CMS relates call disposition database items to the row search values in the database.

| Status database items | State names | Values for row search |
|-----------------------|-------------|-----------------------|
| DISPOSITION | CONN | 1 |
| | ANS | 2 |
| | ABAN | 3 |
| | IFLOW | 4 |
| | FBUSY | 5 |
| | FDISC | 6 |
| | OTHER | 7 |

Calculations

The mathematical calculations defined in this section are the standard CMS Dictionary calculations that are used in real-time, historical, and integrated CMS and CMS Supervisor reports. The calculations can also be used in custom and designer reports.



CAUTION:

Do not modify any of the standard CMS Dictionary calculations. Doing so changes the meaning of the data that displays in reports.

This section includes the following topics:

- [Standard CMS Dictionary calculations](#) on page 338
- [Reports-specific calculations](#) on page 349

Standard CMS Dictionary calculations

The following table lists all of the standard CMS Dictionary calculations:

| Calculation name | Calculation | Description |
|---------------------------------|---|--|
| ACW_AUX_OUT_ADJ | ACWAUXOUTADJCALLS + AUXOUTADJCALLS | Off-communication server calls by adjunct while in ACW or AUX |
| ACW_AUX_OUT_CALLS | ACWOUTOFFCALLS + AUXOUTOFFCALLS | All off-communication server calls placed while in ACW or AUX |
| AGENTS_ON_EXT_CALLS | (ONACWIN + ONAUXIN + ONACWOUT + ONAUXOUT) | Agents on extension calls |
| ART (Actual Relative to Target) | (100*TARGETACDCALLS / CALLSOFFERED) - TARGETPERCENT | This calculation determines the actual service level as compared to the target service level percentage. |
| AVG_ABANDON_TIME | ABNTIME / ABNCALLS | Average time to abandon |
| AVG_ABANDON_TIME_SUM | sum(ABNTIME) / sum(ABNCALLS) | Total average abandon time |
| AVG_ACD_TALK_TIME | ACDTIME / ACDCALLS | Average ACD talk time |
| AVG_ACD_TALK_TIM_SUM | sum(ACDTIME) / sum(ACDCALLS) | Total average ACD talk time |

| Calculation name | Calculation | Description |
|----------------------|---|---|
| AVG_ACW_TIME | ACWTIME / ACDCALLS | Average ACW time |
| AVG_ACW_TIME_SUM | sum(ACWTIME) / sum(ACDCALLS) | Total average ACW time |
| AVG_ACWAUX_OUT_CALLS | sum(ACWOUTOFFTIME + AUXOUTOFFTIME) / sum(ACWOUTOFFCALLS + AUXOUTOFFCALLS) | Average time for off-communication server calls while in ACW or AUX |
| AVG_AGENT_ACW_SUM | sum(TOTAL_ACWTIME) / sum(TOTAL_ACDCALLS) | Total average agent ACW time |
| AVG_AGENT_ACW_TIME | TOTAL_ACWTIME / TOTAL_ACDCALLS | Average ACW time |
| AVG_AGENT_TALK_SUM | sum(TOTAL_ACDTIME) / sum(TOTAL_ACDCALLS) | Total average agent ACD talk time |
| AVG_AGENT_TALK_TIME | TOTAL_ACDTIME / TOTAL_ACDCALLS | Average agent ACD talk time |
| AVG_ANSWER_SPEED | ANSTIME / ACDCALLS | Average speed of answer |
| AVG_ANSWER_SPEED_SUM | sum(ANSTIME) / sum(ACDCALLS) | Total average answer speed |
| AVG_CONNECT_TIME | CONNECTTIME / CONNECTCALLS | Average amount of time for a non-ACD call to connect to agent |
| AVG_CONNECT_TIME_SUM | sum(CONNECTTIME) / sum(CONNECTCALLS) | Total average amount of time for a non-ACD call to connect to agent |
| AVG_DEQUE_ACD_TIME | DEQUETIME / DEQUECALLS | Average talk time for calls queued to a split and elsewhere |
| AVG_EQV_AGENTS_STFD | (TOTAL_I_ACDACW + TOTAL_T_ACDHOLD + TOP_AVAUXTIME + FTEA_AVAUX) / (INTRVL * 60) | Average positions staffed for this skill across all call handling preferences |
| AVG_HOLD_TIME | HOLDTIME / HOLDCALLS | Average hold time |
| AVG_HOLD_TIME_SUM | sum(HOLDTIME) / sum(HOLDCALLS) | Total average hold time |
| AVG_INB_ACD_TIME | (TOTAL_ACDTIME - O_ACDTIME) / (TOTAL_ACDCALLS - O_ACDCALLS) | Average inbound ACD time |

Definitions of CMS calculations

| Calculation name | Calculation | Description |
|----------------------|---|---|
| AVG_INB_ACW_TIME | $(TOTAL_ACWTIME - O_ACWTIME) / INBOUND_ACDCALLS$ | Average inbound ACW time |
| AVG_INB_ACD_TIME_SUM | $(sum(TOTAL_ACDTIME - O_ACDTIME)) / INBOUND_ACDCALLS$ | Average inbound ACD time |
| AVG_INB_ACW_TIME_SUM | $(sum(TOTAL_ACWTIME - O_ACWTIME)) / INBOUND_ACDCALLS$ | Average inbound ACW time |
| AVG_OUTB_ACD_SUM | $sum(O_ACDTIME) / sum(O_ACDCALLS)$ | Total outbound average ACD talk time |
| AVG_OUTB_ACD_TIME | $O_ACDTIME / O_ACDCALLS$ | Outbound average ACD talk time |
| AVG_OUTB_ACW_SUM | $sum(O_ACWTIME) / sum(O_ACDCALLS)$ | Total outbound average ACW talk time |
| AVG_OUTB_ACW_TIME | $O_ACWTIME / O_ACDCALLS$ | Outbound average ACW talk time |
| AVG_POS_STAFF | $I_STAFFTIME / (INTRVL * 60)$ | Average positions staffed |
| AVG_POS_STAFF_SUM | $sum(I_STAFFTIME) / sum(INTRVL * 60)$ | Total average positions staffed |
| AVG_TALK_TIME_IN | $(ACWINTIME + AUXINTIME) / (ACWINCALLS + AUXINCALLS)$ | Extension in calls average talk time |
| AVG_TALK_TIME_IN_SUM | $sum(ACWINTIME + AUXINTIME) / sum(ACWINCALLS + AUXINCALLS)$ | Extension in calls total average talk time |
| AVG_TALK_TIME_OUT | $(ACWOUTTIME + AUXOUTTIME) / (ACWOUTCALLS + AUXOUTCALLS)$ | Extension out calls average talk time |
| AVG_TALK_TIM_OUT_SUM | $sum(ACWOUTTIME + AUXOUTTIME) / sum(ACWOUTCALLS + AUXOUTCALLS)$ | Extension out calls total average talk time |
| AVG_TOP_STAFF | $(TOTAL_I_ACDACW + TOTAL_T_ACDHOLD + TOPAUAUXTIME) / (INTRVL * 60)$ | Average positions staffed for EAS, making use of the top agent concept to avoid double-counting agents' time when they are staffed in multiple skills |

| Calculation name | Calculation | Description |
|----------------------|--|--|
| AVG_TOP_STAFF_SUM | $\text{sum}(\text{TOT_I_ACDACW_SUM} + \text{TOT_I_ACDHOLD_SUM} + \text{TOP_AVAUXTIME_SUM}) / \text{sum}(\text{INTRVL} * 60)$ | Average positions staffed for EAS, summed over all records found in the search, making use of the top agent concept to avoid double-counting agents' time when they are staffed in multiple skills |
| AVG_TRK_HOLD_IN_SUM | $\text{sum}(\text{INTIME}) / \text{sum}(\text{INCALLS})$ | Inbound total average trunk holding time |
| AVG_TRK_HOLD_OUT_SUM | $\text{sum}(\text{OUTTIME}) / \text{sum}(\text{OUTCALLS})$ | Outbound total average trunk holding time |
| AVG_TRK_HOLD_TIME | $(\text{INTIME} + \text{OUTTIME}) / (\text{INCALLS} + \text{OUTCALLS})$ | Average trunk holding time |
| AVG_TRK_HOLD_TIME_IN | $\text{INTIME} / \text{INCALLS}$ | Inbound average trunk holding time |
| AVG_TRK_HOLD_TIM_OUT | $\text{OUTTIME} / \text{OUTCALLS}$ | Outbound average trunk holding time |
| AVG_VDN_ACD_SK1_TIME | $\text{SKILLTIME1} / \text{SKILLCALLS1}$ | Average time spent on calls for VDN skill preference 1 |
| AVG_VDN_ACD_SK2_TIME | $\text{SKILLTIME2} / \text{SKILLCALLS2}$ | Average time spent on calls for VDN skill preference 2 |
| AVG_VDN_ACD_SK3_TIME | $\text{SKILLTIME3} / \text{SKILLCALLS3}$ | Average time spent on calls for VDN skill preference 3 |
| AVG_VDN_ACW_SK1_TIME | $\text{SKILLACWTIME1} / \text{SKILLCALLS1}$ | Average time spent in ACW for VDN skill preference 1 |
| AVG_VDN_ACW_SK2_TIME | $\text{SKILLACWTIME2} / \text{SKILLCALLS2}$ | Average time spent in ACW for VDN skill preference 2 |
| AVG_VDN_ACW_SK3_TIME | $\text{SKILLACWTIME3} / \text{SKILLCALLS3}$ | Average time spent in ACW for VDN skill preference 3 |
| AVG_VDN_TIME | $\text{INTIME} / \text{INCALLS}$ | Average VDN time |
| AVG_VDN_TIME_SUM | $\text{sum}(\text{INTIME}) / \text{sum}(\text{INCALLS})$ | Total average time in VDN |
| AVG_VEC_TIME | $\text{INTIME} / \text{INCALLS}$ | Average vector time |

Definitions of CMS calculations

| Calculation name | Calculation | Description |
|-------------------|--|---|
| AVG_VEC_TIME_SUM | $\text{sum}(\text{INTIME}) / \text{sum}(\text{INCALLS})$ | Total average vector time |
| BUSY_DISCONNECT | $\text{BUSYCALLS} + \text{DISCCALLS}$ | Number of calls that were busy and disconnected |
| CALLS_PER_POS | $(60 * \text{INTRVL} * \text{ACDCALLS}) / \text{I_STAFFTIME}$ | Calls per position staffed |
| CALLS_PER_POS_SUM | $(\text{sum}(60 * \text{INTRVL}) * \text{sum}(\text{ACDCALLS})) / \text{sum}(\text{I_STAFFTIME})$ | Total calls per position |
| CALLS_WAITING | $\text{INQUEUE} + \text{INRING}$ | Number of calls ringing and queued for split/skill |
| CCS_TIME_INBOUND | $\text{I_INOCC} / 100$ | CCS trunk time attributed to inbound calls |
| CCS_TIME_OUTBOUND | $\text{I_OUTOCC} / 100$ | CCS trunk time attributed to outbound calls |
| DEDICATED_AGENT | $\text{FTE_AGENTS} + \text{TSTAFFED}$ | Number of agents considered dedicated to this skill |
| EXT_CALL_IN | $(\text{ACWINCALLS} + \text{AUXINCALLS})$ | Incoming extension calls |
| EXT_CALL_OUT | $(\text{ACWOUTCALLS} + \text{AUXOUTCALLS})$ | Outgoing extension calls |
| EXT_IN_TIME | $(\text{I_ACWINTIME} + \text{I_AUXINTIME})$ | Time on incoming extension calls |
| EXT_OUT_TIME | $(\text{I_ACWOUTTIME} + \text{I_AUXOUTTIME})$ | Time on outgoing extension calls |
| FACTIVE_AG | $\text{FAGINRING} + \text{FONACD} + \text{FINACW}$ | The number of flex agents on ACD calls, ringing, or in ACW for this skill |
| FTE_AGENTS | $\text{TOT_PERCENTS} / 100$ | Number of full-time equivalent agents staffed for this skill |
| FTEA_AVAUX | $(\text{I_AVAILTIME} + \text{I_AUXTIME}) * (\text{MAX_FTE_AGENTS} / \text{MAXSTAFFED})$ | Proportion of non-ACD time for this skill for percent allocated (PCNT) agents |
| I_SUM_TIME | $\text{I_ACDTIME} + \text{I_ACWTIME} + \text{I_OTHERTIME} + \text{I_RINGTIME} + \text{I_DA_ACDTIME} + \text{I_DA_ACWTIME}$ | Intermediate time used to calculate INT_AUXTIME |

| Calculation name | Calculation | Description |
|----------------------|--|--|
| IAUXTIME_REMAINING | $ \begin{aligned} &(\text{sum}(\text{I_AUXTIME}) \\ &-\text{sum}(\text{I_AUXTIME1}) \\ &-\text{sum}(\text{I_AUXTIME2}) \\ &-\text{sum}(\text{I_AUXTIME3}) \\ &-\text{sum}(\text{I_AUXTIME4}) \\ &-\text{sum}(\text{I_AUXTIME5}) \\ &-\text{sum}(\text{I_AUXTIME6}) \\ &-\text{sum}(\text{I_AUXTIME7}) \\ &-\text{sum}(\text{I_AUXTIME8}) \\ &-\text{sum}(\text{I_AUXTIME9}) \\ &-\text{sum}(\text{I_AUXTIME0})) \end{aligned} $ | The amount of time that agents have spent in the AUX work mode in a split/skill for AUX reason codes 10-99 |
| INAUX_REMAINING | $ \begin{aligned} &(\text{INAUX}-\text{INAUX0}-\text{INAUX1}-\text{INAUX2}-\text{INAUX3}-\text{INAUX4}-\text{INAUX5}-\text{INAUX6}-\text{INAUX7}-\text{INAUX8}-\text{INAUX9}) \end{aligned} $ | The number of agents in the AUX work mode in a split/skill for AUX reason codes 10-99 |
| INBOUND_ACDCALLS | $ (\text{sum}(\text{TOTAL_ACDCALLS} - \text{O_ACDCALLS})) $ | Total inbound ACD calls |
| INT_AUXTIME | $ \text{I_STAFFTIME} - \text{I_AVAILTIME} - (\text{I_SUM_TIME}) $ | Agent time in AUX work in a single split/skill |
| INTRVL_END_TIME | $ \text{STARTTIME} + \text{INTERVL} $ | Time of the end of an interval |
| MAIN_ACD_CALLS | $ \text{ACDCALLS} - \text{BACKUPCALLS} $ | Calls answered for main split/skill |
| MAX_DEDICATED_AGT | $ \text{MAX_FTE_AGENTS} + \text{MAXTOP} $ | Maximum agents (top agents plus full-time equivalent agents) considered dedicated to this skill |
| MAX_FTE_AGENTS | $ \text{MAX_TOT_PERCENTS} / 100 $ | Maximum number of full-time equivalent agents on this skill |
| NON_TOP_STAFFED_AGTS | $ \text{STAFFED} - \text{TSTAFFED} $ | Agents staffed who are not top agents |
| PERCENT_ACD_TIME | $ 100 * ((\text{I_ACDTIME} + \text{I_ACWTIME}) / \text{I_STAFFTIME}) $ | Percentage of time agents spend on split/skill ACD calls and in ACW |
| PERCENT_ACD_TIME_SUM | $ 100 * (\text{sum}(\text{I_ACDTIME} + \text{I_ACWTIME}) / \text{sum}(\text{I_STAFFTIME})) $ | Total percentage of time agents in spend on split/skill ACD calls and in ACW |

Definitions of CMS calculations

| Calculation name | Calculation | Description |
|----------------------|---|---|
| PERCENT_ALL_BUSY | $100 * (\text{ALLINUSETIME} / \text{SECS_PER_DAY})$ | Percentage of time all trunks in use |
| PERCENT_ALL_BUSY_D | $100 * (\text{ALLINUSETIME} / \text{d_secs.SECSPERDAY})$ | Percentage of time all trunks in use in the day |
| PERCENT_ALL_BUSY_I | $100 * (\text{ALLINUSETIME} / (\text{INTERVL} * 60))$ | Percentage of time all trunks were busy in interval |
| PERCENT_ALL_BUSY_M | $100 * (\text{ALLINUSETIME} / \text{m_secs.SECSPERMN})$ | Percentage of time all trunks in use in the month |
| PERCENT_ALL_BUSY_W | $100 * (\text{ALLINUSETIME} / \text{w_secs.SECSPERWK})$ | Percentage of time all trunks in use in the week |
| PERCENT_ALL_BUSY_SUM | $100 * (\text{sum}(\text{ALLINUSETIME}) / \text{sum}(\text{SECS_PER_DAY}))$ | Percentage of time all trunks in use |
| PERCENT_AL_BSY_SUM_D | $100 * (\text{sum}(\text{ALLINUSETIME}) / \text{sum}(\text{d_secs.SECSPERDAY}))$ | Percentage of time all trunks in use during the day |
| PERCENT_AL_BSY_SUM_M | $100 * (\text{sum}(\text{ALLINUSETIME}) / \text{sum}(\text{m_secs.SECSPERMN}))$ | Percentage of time all trunks in use during the month |
| PERCENT_AL_BSY_SUM_W | $100 * (\text{sum}(\text{ALLINUSETIME}) / \text{sum}(\text{w_secs.SECSPERWK}))$ | Percentage of time all trunks in use during the week |
| PERCENT_ALL_MBUSY_I | $100 * (\text{MBUSYTIME}) / (\text{INTERVL} * 60 * \text{TRUNKS})$ | Percent of time all trunks were maintenance busy |
| PERCENT_AUX_WORK | $100 * (\text{I_AUXTIME} / \text{I_STAFFTIME})$ | Percentage time agents spent in AUX |
| PERCENT_AUX_WORK_SUM | $100 * (\text{sum}(\text{I_AUXTIME}) / \text{sum}(\text{I_STAFFTIME}))$ | Total percentage time agents spent in AUX |
| PERCENT_CALL_ABAN | $100 * (\text{ABNCALLS} / (\text{CALLSOFFERED}))$ | Percentage of calls offered that abandoned |
| PERCENT_CALL_ANS | $100 * (\text{ACDCALLS} / \text{CALLSOFFERED})$ | Percentage of calls offered that were answered |
| PERCENT_CALL_ANS_SUM | $100 * (\text{sum}(\text{ACDCALLS}) / \text{sum}(\text{CALLSOFFERED}))$ | Total percentage of calls offered that were answered |

| Calculation name | Calculation | Description |
|----------------------|---|---|
| PERCENT_MBUSHY | $100 * (\text{MBUSYTIME} / (\text{SECS_PER_DAY} * \text{TRUNKS}))$ | Percent of time trunks maintenance busy NOTE: This calculation is obsolete. Do not use it. |
| PERCENT_MBUSHY_D | $100 * (\text{MBUSYTIME} / (\text{d_secs}.\text{SECSPERDAY} * \text{TRUNKS}))$ | Percent of time trunks were maintenance busy during the day |
| PERCENT_MBUSHY_M | $100 * (\text{MBUSYTIME} / (\text{m_secs}.\text{SECSPERMN} * \text{TRUNKS}))$ | Percent of time all trunks were maintenance busy during the month |
| PERCENT_MBUSHY_W | $100 * (\text{MBUSYTIME} / (\text{w_secs}.\text{SECSPERWK} * \text{TRUNKS}))$ | Percent of time all trunks were maintenance busy during the week |
| PERCENT_MBUSHY_SUM_D | $100 * (\text{sum}(\text{MBUSYTIME}) / (\text{avg}(\text{d_secs}.\text{SECSPERDAY}) * \text{sum}(\text{TRUNKS})))$ | Percent of time all trunks were maintenance busy during the day |
| PERCENT_MBUSHY_SUM_M | $100 * (\text{sum}(\text{MBUSYTIME}) / (\text{avg}(\text{m_secs}.\text{SECSPERMN}) * \text{sum}(\text{TRUNKS})))$ | Percent of time all trunks were maintenance busy during the month |
| PERCENT_MBUSHY_SUM_W | $100 * (\text{sum}(\text{MBUSYTIME}) / (\text{avg}(\text{w_secs}.\text{SECSPERWK}) * \text{sum}(\text{TRUNKS})))$ | Percent of time all trunks were maintenance busy during the week |
| PERCENT_MBUSHY_SUM | $100 * (\text{sum}(\text{MBUSYTIME}) / (\text{avg}(\text{SECS_PER_DAY}) * \text{sum}(\text{TRUNKS})))$ | Percent time trunks in were maintenance busy NOTE: This calculation is obsolete. Do not use it. |
| PERCENT_SERV_LVL_SPL | $100 * (\text{ACCEPTABLE} / \text{CALLSOFFERED})$ | Percentage of calls answered in service level for split/skill |
| PERCENT_SERV_LVL_VDN | $100 * (\text{sum}(\text{ACCEPTABLE}) / \text{sum}(\text{INCALLS}))$ | Percent of calls answered within service level for VDN |
| PERCENT_SERV_SPL_OUT | $100 - \text{PERCENT_SERV_LVL_SPL}$ | Percent of calls to a split/skill outside of the service level |
| PERCENT_SERV_VDN_OUT | $100 - \text{PERCENT_SERV_LVL_VDN}$ | Percent of calls to VDN outside service level |

Definitions of CMS calculations

| Calculation name | Calculation | Description |
|----------------------|---|--|
| PERCENT_SK_AVAIL | $100 * (\text{sum}(\text{I_AVAILTIME}) / \text{sum}(\text{TI_AVAILTIME})) / (\text{sum}(\text{I_STAFFTIME}) / \text{sum}(\text{TI_STAFFTIME}))$ | This calculation indicates the amount of time that an agent was available in all assigned skills. If an agent was assigned to the auto-reserve state for a skill, this number would be less than 100. For example, "83%" in this calculation indicates that the agent was available in all skills for 83% of the specified interval. In this calculation, a high number indicates that the auto-reserve state was rarely used while a low number indicates that the agent was almost entirely occupied with the auto-reserved skill. |
| PERCENT_SLVL_SPL_SUM | $100 * (\text{sum}(\text{ACCEPTABLE}) / \text{sum}(\text{CALLSOFFERED}))$ | Percent of total split calls answered in service level |
| PERCENT_VDN_ABAN | $100 * (\text{sum}(\text{ABNCALLS}) / \text{sum}(\text{INCALLS}))$ | Percent of calls abandoned |
| PERCENT_VDN_ANSCONN | $100 * (\text{sum}(\text{ACDCALLS} + \text{CONNECTCALLS}) / \text{sum}(\text{INCALLS}))$ | Percent of calls answered for VDN |
| R1ACTIVE_AGT | $\text{R1AGINRING} + \text{R1ONACD} + \text{R1INACW}$ | Number of Reserve 1 agents on ACD calls, ringing, or in ACW for this skill |
| R2ACTIVE_AGT | $\text{R2AGINRING} + \text{R2ONACD} + \text{R2INACW}$ | Number of Reserve 2 agents on ACD calls, ringing, or in ACW for this skill |
| SECS_PER_DAY | $(24 * 60 * 60)$ | Seconds per day NOTE: To use <SECS_PER_DAY>, data collection must be active 24 hours a day, seven days a week. |

| Calculation name | Calculation | Description |
|---------------------|--|---|
| TIAUXTIME_REMAINING | (sum(TI_AUXTIME) -sum(TI_AUXTIME1) -sum(TI_AUXTIME2) -sum(TI_AUXTIME3) -sum(TI_AUXTIME4) -sum(TI_AUXTIME5) -sum(TI_AUXTIME6) -sum(TI_AUXTIME7) -sum(TI_AUXTIME8) -sum(TI_AUXTIME9 -sum(TI_AUXTIME0)) | The length of time that top agents have spent in the AUX work mode in a split/skill for reason codes 10-99 |
| TINAUX_REMAINING | (TINAUX-TINAUX0-TINAUX1-TINAUX2-TINAUX3-TINAUX3-TINAUX4-TINAUX5-TINAUX6-TINAUX7-TINAUX8-TINAUX9) | The number of top agents in the AUX work mode in a split/skill for AUX reason codes 10-99 |
| TOP_AVAUXTIME | I_TAUXTIME+I_TAVAILTIME+I_TOTHERTIME | Subcalculation that supports the AVG_TOP_STAFF calculation Sum of the time top agents spent in AUX work and available |
| TOP_AVAUXTIME_SUM | sum (I_TAUXTIME+I_TAVAILTIME) | Subcalculation that supports the AVG_TOP_STAFF_SUM calculation Sum of the time top agents spent in AUX work and available |
| TOT_I_ACDACW_SUM | sum(I_ACDTIME + I_ACWTIME + I_DA_ACDTIME + I_DA_ACWTIME + I_RINGTIME) | Subcalculation that supports the AVG_TOP_STAFF_SUM calculation Sum of the ACD and ACW time for split/skill and direct agent calls, plus the (agent) ringing time for those calls |
| TOT_I_ACDHOLD_SUM | sum(I_ACDOTHERTIME + I_ACD_AUXINTIME + I_ACD_AUX_OUTTIME) | Subcalculation that supports the AVG_TOP_STAFF_SUM calculation Sum of the time agents spent with ACD calls on hold |

Definitions of CMS calculations

| Calculation name | Calculation | Description |
|------------------|--|---|
| TOTAL_I_ACDACW | (I_ACDTIME + I_ACWTIME +I_DA_ACDTIME+I_DA_ACWTIME +I_RINGTIME) | Subcalculation that supports the new AVG_TOP_STAFF calculation Sum of the ACD and ACW time for split/skill and direct agent calls, plus the (agent) ringing time for those calls |
| TOTAL_ACDCALLS | (ACDCALLS + DA_ACDCALLS) | Total split/skill and direct agent ACD calls |
| TOTAL_ACDTIME | (ACDTIME + DA_ACDTIME) | Total ACD time + DA ACD TIME |
| TOTAL_ACWTIME | (ACWTIME + DA_ACWTIME) | Total ACW time +DA |
| TOTAL_I_ACDTIME | (I_ACDTIME + I_DA_ACDTIME) | Total interval-based ACD time |
| TOTAL_I_ACDHOLD | I_ACDOTHERTIME + I_ACDAUXINTIME + I_ACD_ACDAUX_OUTTIME | Sum of the time agents spent with ACD calls on hold |
| TOTAL_I_ACWTIME | (I_ACWTIME + I_DA_ACWTIME) | Total interval-based ACW time |

Reports-specific calculations

The calculations in this section support reports that were modified for V8 CMS Supervisor. These calculations present information supporting Avaya Business Advocate and Virtual Routing. They are not standard CMS calculations and are not part of the CMS database, although they draw data from the database. These calculations are only available with R8 and newer releases of CMS Supervisor.

| Calculation name | Calculation | Description | Database tables |
|------------------|---|---|-----------------|
| % Aban | $100 * (\text{sum}(\text{ABNCALLS}) / \text{sum}(\text{INCALLS}))$ | The number of the total calls to all VDNs on a selected ACD that abandoned, expressed as a percentage. Used in daily reports. | vdn |
| % Busy | $100 * (\text{sum}(\text{BUSYCALLS}) / \text{sum}(\text{INCALLS}))$ | The number of the total calls to all VDNs on a selected ACD that were busy, expressed as a percentage. Used in daily reports. | vdn |
| % Disconnect | $100 * (\text{sum}(\text{DISCCALLS}) / \text{sum}(\text{INCALLS}))$ | The number of the total calls to all VDNs on a selected ACD that were disconnected, expressed as a percentage. Used in daily reports. | vdn |
| % Aban | $100 * \text{ABNCALLS} / \text{INCALLS}$ | The number of the total calls to a VDN that abandoned, expressed as a percentage. Used in interval, weekly, and monthly reports. | vdn |
| % Busy | $100 * \text{BUSYCALLS} / \text{INCALLS}$ | The number of the total calls to a VDN that were busy, expressed as a percentage. Used in interval, weekly, and monthly reports. | vdn |

Definitions of CMS calculations

| Calculation name | Calculation | Description | Database tables |
|-------------------------------|---|---|-----------------|
| % Flow Out | $100 * \text{OUTFLOWCALLS} / \text{INCALLS}$ | The number of the total calls to a VDN that were redirected to another VDN, expressed as a percentage. Used in interval, weekly, and monthly reports. | vdn |
| % Agent Occup (Group) w/ACW | $100 * (\text{sum}(\text{I_RINGTIME} + \text{I_ACD_TIME} + \text{I_ACD_OTHER_TIME} + \text{I_ACD_AUX_OUT_TIME} + \text{I_ACD_AUX_IN_TIME} + \text{I_ACW_TIME}) / (\text{sum}(\text{TI_STAFF_TIME} - \text{TI_AUX_TIME} + \text{I_ACD_AUX_OUT_TIME} + \text{I_ACD_AUX_IN_TIME})))$ | The percentage of an agent or agent group's occupancy, including after call work time. This calculation is used in interval, daily, weekly, and monthly Historical Agent Summary and Agent Group Summary reports. When it is used in an Agent Summary report, the field is % Agent Occup. | agent |
| % Agent Occup (Group) w/o ACW | $100 * (\text{sum}(\text{I_RINGTIME} + \text{I_ACD_TIME} + \text{I_ACD_OTHER_TIME} + \text{I_ACD_AUX_OUT_TIME} + \text{I_ACD_AUX_IN_TIME}) / (\text{sum}(\text{TI_STAFF_TIME} - \text{TI_AUX_TIME} + \text{I_ACD_AUX_OUT_TIME} + \text{I_ACD_AUX_IN_TIME})))$ | The percentage of an agent or agent group's occupancy, excluding after call work time. This calculation is used in interval, daily, weekly, and monthly Historical Agent Summary and Agent Group Summary reports. When it is used in an Agent Summary report, the field is % Agent Occup. | agent |

Index

Symbols

| | |
|---|-----|
| % Aban | 349 |
| % Agent Occup (Group) w/ACW | 350 |
| % Agent Occup (Group) w/o ACW | 350 |
| % Busy | 349 |
| % Disconnect | 349 |
| % Flow Out | 350 |

A

| | |
|---|-----|
| Abandoned Call | 42 |
| Abandoned Calls | 87 |
| ABNCALLS | 112 |
| ABNCALLS1-10 | 114 |
| ABNQUECALLS | 114 |
| ABNRINGCALLS | 115 |
| ABNTIME | 116 |
| ABNVECCALLS | 116 |
| ACCEPTABLE | 117 |
| ACD (index) | 117 |
| ACD Call | 42 |
| ACD_RELEASE | 120 |
| ACDAUXOUTCALLS | 120 |
| ACDCALLS | 121 |
| ACDCALLS_R1 | 122 |
| ACDCALLS_R2 | 123 |
| ACDCALLS1-10 | 122 |
| ACDONHOLD (real-time) | 124 |
| ACDTIME | 124 |
| active calls | 110 |
| ACTIVECALLS (real-time) | 125 |
| ACW | 42 |
| ACW_AUX_OUT_ADJ | 338 |
| ACW_AUX_OUT_CALLS | 338 |
| ACWINCALLS | 126 |
| ACWINTIME | 126 |
| ACWOUTADJCALLS | 127 |
| ACWOUTCALLS | 127 |
| ACWOUTOFFCALLS | 128 |
| ACWOUTOFFTIME | 128 |
| ACWOUTTIME | 129 |
| ACWTIME | 129 |
| ADJATTEMPTS | 130 |
| ADJROUTED | 131 |
| ADJUNCTOUT (real-time) | 131 |
| Adjunct-Placed and Adjunct-Routed Calls | 87 |

| | |
|---|---------|
| Administrative data | 34 |
| Administrative data, definition | 34 |
| Administrative data, definition | 34 |
| After Call Work | 42 |
| ag_actv | 33 |
| AG_DEST | 334 |
| AG_DIR | 334 |
| AG_ORIG | 334 |
| AG_PREF | 334 |
| AGDURATION (real-time) | 133 |
| Agent | 43 |
| Agent Counts | 90 |
| Agent database items | 51, 105 |
| Agent login/logout database items | 57 |
| Agent Position, EAS | 43 |
| Agent Position, No EAS | 43 |
| Agent Role | 90 |
| Agent State and Row Search Values Cross-Reference | 334 |
| Agent State Tracking at Login | 88 |
| Agent Time in Skill | 90 |
| Agent trace database items | 59 |
| Agents in Multiple Splits/Skills | 88 |
| AGENTS_ON_EXT_CALLS | 338 |
| agex | 33 |
| AGINRING (real-time) | 132 |
| AGOCC | 132 |
| AGSTATE (real-time) | 132 |
| AGT_RELEASED | 133 |
| AGTIME(real-time) | 133 |
| ALL_BUSY | 336 |
| ALLINUSE (real-time) | 134 |
| ALLINUSETIME | 134 |
| ANI_SID | 134 |
| ANSCONNCALLS1-10 | 135 |
| ANSHOLDTIME | 135 |
| ANSLOCID | 135 |
| ANSLOGIN | 136 |
| ANSREASON | 136 |
| ANSRINGTIME | 136 |
| ANSTIME | 137 |
| Answered Call | 43 |
| ART (Actual Relative to Target) | 338 |
| ASA (real-time) | 137 |
| ASSIST | 138 |
| ASSIST_ACTV | 138 |
| ASSISTS | 139 |
| ATAGENT (real-time) | 139 |
| AUDIO | 139 |
| Audio Difficulty | 89 |

| | |
|--|-----|
| Automatic-in mode (AI) | 43 |
| AUX work mode | 44 |
| AUXINCALLS | 140 |
| AUXINTIME | 140 |
| AUXOUTADJCALLS | 141 |
| AUXOUTCALLS | 141 |
| AUXOUTOFFCALLS | 142 |
| AUXOUTOFFTIME | 142 |
| AUXOUTTIME | 143 |
| AUXREASON | 143 |
| Availability of database items | 29 |
| AVAILABLE (real-time) | 144 |
| Avaya Business Advocate | 90 |
| Average Speed of Answer (ASA) | 89 |
| AVG_ABANDON_TIME | 338 |
| AVG_ABANDON_TIME_SUM | 338 |
| AVG_ACD_TALK_TIM_SUM | 338 |
| AVG_ACD_TALK_TIME | 338 |
| AVG_ACW_TIME | 339 |
| AVG_ACW_TIME_SUM | 339 |
| AVG_ACWAUX_OUT_CALLS | 339 |
| AVG_AGENT_ACW_SUM | 339 |
| AVG_AGENT_ACW_TIME | 339 |
| AVG_AGENT_TALK_SUM | 339 |
| AVG_AGENT_TALK_TIME | 339 |
| AVG_ANSWER_SPEED | 339 |
| AVG_ANSWER_SPEED_SUM | 339 |
| AVG_CONNECT_TIME | 339 |
| AVG_CONNECT_TIME_SUM | 339 |
| AVG_DEQUE_ACD_TIME | 339 |
| AVG_EQV_AGENTS_STFD | 339 |
| AVG_HOLD_TIME | 339 |
| AVG_HOLD_TIME_SUM | 339 |
| AVG_INB_ACD_TIME | 339 |
| AVG_INB_ACD_TIME_SUM | 340 |
| AVG_INB_ACW_TIME | 340 |
| AVG_INB_ACW_TIME_SUM | 340 |
| AVG_OUTB_ACD_SUM | 340 |
| AVG_OUTB_ACD_TIME | 340 |
| AVG_OUTB_ACW_SUM | 340 |
| AVG_OUTB_ACW_TIME | 340 |
| AVG_POS_STAFF | 340 |
| AVG_POS_STAFF_SUM | 340 |
| AVG_TALK_TIM_OUT_SUM | 340 |
| AVG_TALK_TIME_IN | 340 |
| AVG_TALK_TIME_IN_SUM | 340 |
| AVG_TALK_TIME_OUT | 340 |
| AVG_TOP_STAFF | 340 |
| AVG_TOP_STAFF_SUM | 341 |
| AVG_TRK_HOLD_IN_SUM | 341 |
| AVG_TRK_HOLD_OUT_SUM | 341 |
| AVG_TRK_HOLD_TIM_OUT | 341 |
| AVG_TRK_HOLD_TIME | 341 |
| AVG_TRK_HOLD_TIME_IN | 341 |
| AVG_VDN_ACD_SK1_TIME | 341 |

| | |
|--------------------------------|-----|
| AVG_VDN_ACD_SK2_TIME | 341 |
| AVG_VDN_ACD_SK3_TIME | 341 |
| AVG_VDN_ACW_SK1_TIME | 341 |
| AVG_VDN_ACW_SK2_TIME | 341 |
| AVG_VDN_ACW_SK3_TIME | 341 |
| AVG_VDN_TIME | 341 |
| AVG_VDN_TIME_SUM | 341 |
| AVG_VEC_TIME | 341 |
| AVG_VEC_TIME_SUM | 342 |
| AVGAGSERV | 144 |
| AVGSPEEDANS | 144 |
| AWORKMODE | 145 |

B

| | |
|--------------------------------------|-----|
| BACKUPCALLS | 145 |
| Best Service Routing | 90 |
| Best Service Routing (BSR) | 44 |
| BH_ABNCALLS | 147 |
| BH_ACDCALLS | 147 |
| BH_ACDTIME | 148 |
| BH_ALLINUSETIME | 148 |
| BH_BUSYCALLS | 148 |
| BH_DISCCALLS | 149 |
| BH_INCALLS | 149 |
| BH_INTIME | 149 |
| BH_OABNCALLS | 150 |
| BH_OACDCALLS | 150 |
| BH_OOTHERCALLS | 150 |
| BH_OTHERCALLS | 151 |
| BH_OUTCALLS | 151 |
| BH_OUTTIME | 152 |
| BH_STARTTIME | 152 |
| BH_VDNCALLS | 153 |
| BLOCKAGE | 153 |
| BSR | 95 |
| BSRPLAN | 153 |
| Busy Hour data, definition | 34 |
| BUSY_DISCONNECT | 342 |
| BUSYCALLS | 154 |
| BUSYTIME | 155 |

C

| | |
|--|-----|
| cagent | 31 |
| Calculations | 338 |
| Call Disposition | 97 |
| Call Disposition and Row Search Values Cross-Reference | 337 |
| Call handling preference | 91 |
| Call Pickup | 91 |
| Call Record | 161 |
| Call record database items | 60 |
| Call Segment | 44 |
| call work code | 161 |

| | |
|--|-----|
| Call work codes database items | 63 |
| call_rec | 33 |
| Call-based data, definition | 35 |
| CALLER_HOLD | 155 |
| CALLID | 156 |
| CALLING_II | 156 |
| CALLING_LOGID | 157 |
| CALLING_PTY | 157 |
| CALLS_PER_POS | 342 |
| CALLS_PER_POS_SUM | 342 |
| CALLS_WAITING | 342 |
| CALLSOFFERED | 157 |
| CCS_TIME_INBOUND | 342 |
| CCS_TIME_OUTBOUND | 342 |
| ccwc | 31 |
| CHANGE | 158 |
| CHANGED (real-time) | 158 |
| CHPROF | 158 |
| COMPLETED | 159 |
| CONFERENCE | 159 |
| Conference Tracking (G2.2 and G3) | 92 |
| CONNECTCALLS | 160 |
| Connected Call | 44 |
| CONNECTTIME | 160 |
| CONNTALKTIME | 160 |
| CONSULTTIME | 161 |
| Converse Vector Command (G3V2 and later) | 92 |
| csplit | 31 |
| ctkgrp | 31 |
| ctrunk | 31 |
| Cumulative data | |
| Cumulative data, definition | 34 |
| Cumulative data, definition | 34 |
| Current day configuration database items | 64 |
| Current day report database items | 65 |
| cvdn | 31 |
| cvector | 31 |
| CWC (index) | 161 |
| CWC1 | 161 |

D

| | |
|---------------------------|-----|
| DA_ABNCALLS | 162 |
| DA_ABNTIME | 162 |
| DA_ACDCALLS | 162 |
| DA_ACDTIME | 163 |
| DA_ACWINCALLS | 163 |
| DA_ACWINTIME | 163 |
| DA_ACWOADJCALLS | 164 |
| DA_ACWOCALLS | 164 |
| DA_ACWOFFFCALLS | 165 |
| DA_ACWOFFFTIME | 165 |
| DA_ACWOTIME | 165 |
| DA_ACWTIME | 166 |
| DA_ANSTIME | 166 |

| | |
|---|----------|
| DA_INACW (real-time) | 167 |
| DA_INQUEUE (real-time) | 167 |
| DA_INRING (real-time) | 167 |
| DA_OLDESTCALL (real-time) | 168 |
| DA_ONACD (real-time) | 168 |
| DA_OTHERCALLS | 169 |
| DA_OTHERTIME | 169 |
| DA_QUEUED | 169 |
| DA_RELEASE | 170 |
| DA_SKILL | 170 |
| DACALLS_FIRST | 170 |
| dagent | 32 |
| Database item types | 34 |
| Busy Hour data, definition | 34 |
| Maximum Interval Value data, definition | 34 |
| Row Identifier data, definition | 34 |
| Special Table data | 34 |
| Status data, definition | 34 |
| Database Items | |
| Terminology | 42 |
| Database Table Names | 30 |
| dcwc | 33 |
| DEDICATED_AGENT | 342 |
| DEFLECTCALLS | 171 |
| DEQUECALLS | 171 |
| DEQUETIME | 172 |
| DESTINATION (real-time) | 172 |
| DIALED_NUM | 172 |
| Dictionary | |
| Calculations | 338 |
| DIGITS_DIALED | 173 |
| Direct Agent ACD Call (G3) | 44 |
| Direct Agent Calling (G3) | 92 |
| DIRECTION | 173 |
| DISCCALLS | 174 |
| DISCTIME | 175 |
| DISPIVECTOR | 175 |
| DISPOSITION | 176, 337 |
| DISPPRIORITY | 177 |
| DISPSKLEVEL | 178 |
| DISPSPLIT | 178 |
| DISPTIME | 178 |
| DISPVDN | 179 |
| dsplit | 32 |
| dtkgrp | 32 |
| dtrunk | 32 |
| DURATION | 179 |
| dvdn | 32 |
| dvector | 32 |

E

| | |
|----------------------|-----|
| EQLOC | 180 |
| EVENT_TIME | 181 |
| EVENT1-9 | 181 |

| | |
|---|--------|
| EWTHIGH (real-time) | 182 |
| EWTLOW (real-time) | 182 |
| EWTMEDIUM (real-time) | 183 |
| EWTTOP (real-time) | 183 |
| Example standard dictionary calculations | 333 |
| Expert Agent Selection (EAS) | 44 |
| EXT_CALL_IN | 342 |
| EXT_CALL_ORIG | 183 |
| EXT_CALL_OUT | 342 |
| EXT_IN_TIME | 342 |
| EXT_OUT_TIME | 342 |
| EXTENSION | 184 |
| Extension Call | 44, 45 |
| External Call | 44 |
| EXTN | 184 |
| EXTYPE | 185 |
| EXTYPE in the agent exception table | 185 |
| EXTYPE in the split/skill exception table | 187 |
| EXTYPE in the trunk group exception table | 188 |
| EXTYPE in the VDN exception table | 188 |
| EXTYPE in the vector exception table | 189 |

F

| | |
|-----------------------------|-----|
| f_cday | 33 |
| f_cdayrep | 33 |
| FACTIVE_AG | 342 |
| FAGINRING | 189 |
| FAVAILABLE | 190 |
| FCALLS | 190 |
| FINACW | 190 |
| FINAUX | 191 |
| FIRSTVDN | 191 |
| FIRSTVECTOR | 191 |
| FMETHOD | 192 |
| FONACD | 192 |
| Forced disconnect | 93 |
| FOTHER | 192 |
| FSTAFFED | 193 |
| FTE_AGENTS | 342 |
| FTEA_AVAUX | 342 |

G

| | |
|--------------------------|-----|
| GNAGINRING | 193 |
| GNAVAILABLE | 193 |
| GNDA_INACW | 198 |
| GNDA_ONACD | 199 |
| GNINACW | 194 |
| GNINAUX | 194 |
| GNINAUX10-99 | 195 |
| GNINAUX1-9 | 195 |
| GNONACD | 194 |
| GNONACDAUX-OUT | 196 |
| GNONACDOUT | 196 |

| | |
|------------------------|----------|
| GNONACWIN | 197 |
| GNONACWOUT | 197 |
| GNONAUXIN | 198 |
| GNONAUXOUT | 198 |
| GNOTHER | 196, 199 |
| GNSKILL | 200 |
| GNSTAFFED | 200 |
| Go To Vector | 94 |
| GOTOCALLS | 200 |
| GOTOTIME | 201 |

H

| | |
|---|-----|
| hagent | 32 |
| haglog | 33 |
| hcwc | 32 |
| HDATE1-4 | 201 |
| HELD | 201 |
| helplines | 28 |
| HIGHCALLS | 202 |
| Hold | 45 |
| Hold Tracking (G3, G2, System 85) | 94 |
| HOLDABN | 202 |
| HOLDABNCALLS | 202 |
| HOLDACDCALLS | 203 |
| HOLDACDTIME | 203 |
| HOLDCALLS | 204 |
| HOLDTIME | 204 |
| hsplit | 32 |
| htkgrp | 32 |
| htrunk | 32 |
| hvdn | 32 |
| hvector | 32 |

I

| | |
|----------------------------|---------------|
| I | 102 |
| I_ACDAUX_OUTTIME | 206 |
| I_ACDAUXINTIME | 205 |
| I_ACDOOTHERTIME | 206 |
| I_ACDDTIME | 104, 207 |
| I_ACDDTIME_R1 | 102, 207 |
| I_ACDDTIME_R2 | 102, 208 |
| I_ACWINTIME | 208 |
| I_ACWOUTTIME | 209 |
| I_ACWTIME | 104, 210 |
| I_ACWTIME_R1 | 102 |
| I_ACWTIME_R2 | 102, 211 |
| I_ARRIVED | 211 |
| I_AUTORESERTIME | 211 |
| I_AUXINTIME | 212 |
| I_AUXOUTTIME | 212 |
| I_AUXSTBYTIME | 102, 106, 213 |
| I_AUXSTBYTIME_R1 | 102, 103, 213 |
| I_AUXSTBYTIME_R2 | 102, 103, 214 |

| | |
|---|---------------|
| I_AUXTIME | 104, 214 |
| I_AUXTIME_R1 | 102, 215 |
| I_AUXTIME_R2 | 102, 215 |
| I_AUXTIME0 | 216 |
| I_AUXTIME10-99 | 216 |
| I_AUXTIME1-9 | 216 |
| I_AVALTIME | 217 |
| I_BEHINDTIME | 217 |
| I_DA_ACDTIME | 217 |
| I_DA_ACWTIME | 218 |
| I_INOCC | 218 |
| I_NORMTIME | 219 |
| I_OL1TIME | 219 |
| I_OL2TIME | 220 |
| I_OTHERSTBYTIME | 102, 106, 220 |
| I_OTHERSTBYTIME_R1 | 102, 103, 221 |
| I_OTHERSTBYTIME_R2 | 102, 103, 221 |
| I_OTHERTIME | 98, 104, 222 |
| I_OTHERTIME_R1 | 102, 223 |
| I_OTHERTIME_R2 | 102, 223 |
| I_OUTOCC | 224 |
| I_RINGTIME | 104, 224 |
| I_RINGTIME_R1 | 102, 225 |
| I_RINGTIME_R2 | 102, 225 |
| I_STAFFTIME | 104, 226 |
| I_STAFFTIME_R1 | 226 |
| I_STANDBYTIME | 226 |
| I_SUM_TIME | 342 |
| I_TAUXTIME | 226 |
| I_TAVAILTIME | 227 |
| I_TOTHERTIME | 227 |
| IAUXTIME_REMAINING | 343 |
| II_DIGITS | 227 |
| ILN | 228 |
| INACW (real-time) | 228 |
| INAUX | 228 |
| INAUX (real-time) | 228 |
| INAUX0 | 229 |
| INAUX10-99 | 229 |
| INAUX1-9 | 229 |
| INBOUND (real-time) | 230 |
| INBOUND_ACDCALLS | 343 |
| INCALLS | 230 |
| INCOMPLETE | 231 |
| INFLAG | 233 |
| INFLOWCALLS | 233 |
| INPROGRESS (real-time) | 234 |
| INQUEUE (real-time) | 235 |
| INRING (real-time) | 235 |
| INT_AUXTIME | 343 |
| INTERFLOWCALLS | 236 |
| Interval-based data, definition | 35 |
| INTERVL_END_TIME | 343 |
| INTIME | 236 |
| Intrahour Interval | 94, 95 |

| | |
|--------------------------------|-----|
| INTRVL | 238 |
| INVECTOR (real-time) | 239 |
| ITN (index) | 239 |

K

| | |
|------------------------|-----|
| KEYBD_DIALED | 240 |
|------------------------|-----|

L

| | |
|--------------------------------------|----------|
| LASTCWC | 240 |
| LASTDIGITS | 240 |
| LASTOBSERVER | 241 |
| LEVEL | 241, 334 |
| linkex | 33 |
| LOC_ID | 241 |
| Location | 94 |
| LOGID | 242 |
| LOGIN | 243 |
| LOGONSKILL (real-time) | 244 |
| LOGONSKILL21-60 | 245 |
| LOGONSKILL2-20 | 244 |
| LOGONSTART (real-time) | 245 |
| LOGOUT | 245 |
| LOGOUT_DATE | 246 |
| LOGOUTREASON | 246 |
| Look-Ahead Interflow Calls | 95 |
| LOOKATTEMPTS | 246 |
| LOOKFLOWCALLS | 247 |
| LOWCALLS | 248 |

M

| | |
|---|-----|
| magent | 32 |
| MAIN_ACD_CALLS | 343 |
| MALICIOUS | 248 |
| Manual-in mode (MI) | 45 |
| MAX_DEDICATED_AGT | 343 |
| MAX_FTE_AGENTS | 343 |
| MAX_TOT_PERCENTS | 250 |
| Maximum Interval Value data, definition | 34 |
| MAXINQUEUE | 249 |
| MAXOCWTIME | 249 |
| MAXSTAFFED | 249 |
| MAXTOP | 250 |
| MAXWAITING | 250 |
| MBUSY (real-time) | 251 |
| MBUSYTIME | 251 |
| MCT | 251 |
| mctex | 33 |
| mcwc | 33 |
| MEDCALLS | 252 |
| Move agent while staffed | 95 |
| MOVEPENDING (real-time) | 252 |

| | |
|--|--------|
| msplit | 32 |
| mtkgrp. | 32 |
| mtrunk. | 32 |
| Multibyte Character Set. | 45 |
| Multiple Call Handling (G2, System 85, G3V4) | 94, 96 |
| Multiple Call Work Codes | 161 |
| Multiple split/skill queueing example | 96 |
| Multiple-Split/ Skill Queuing (G3) | 96 |
| mvdn | 32 |
| mvector | 32 |

N

| | |
|--|-----|
| NCR. | 95 |
| NETDISCCALLS | 252 |
| NETINCALLS | 253 |
| NETINTIME | 253 |
| NETPOLLS | 253 |
| Network Call Redirection (NCR). | 95 |
| NOANSREDIR. | 254 |
| Non-reserve Agent database items | 107 |
| NUMAGREQ | 255 |
| NUMINUSE (real-time) | 255 |
| NUMTGS | 255 |
| NUMVDNS | 256 |

O

| | |
|--|-----|
| O_ABNCALLS | 256 |
| O_ACDCALLS | 257 |
| O_ACDTIME. | 257 |
| O_ACWTIME | 258 |
| O_OTHERCALLS | 258 |
| OBSERVINGCALL | 259 |
| OBSLOCID | 259 |
| OLDEST_LOGON (real-time) | 260 |
| OLDESTCALL (real-time). | 260 |
| ONACD (real-time). | 260 |
| ONACDAUXOUT (real-time) | 261 |
| ONACDOUT (real-time) | 261 |
| ONACWIN (real-time) | 261 |
| ONACWOUT (real-time) | 262 |
| ONAXIN (real-time) | 262 |
| ONAXOUT (real-time). | 262 |
| ONHOLD (real-time) | 263 |
| ORIGHOLDTIME. | 263 |
| ORIGIN (real-time) | 263 |
| ORIGLOCID | 264 |
| ORIGLOGIN | 264 |
| ORIGREASON. | 264 |
| OTHER (real-time) | 265 |
| OTHERCALLS. | 265 |
| OTHERTIME | 266 |
| OUTBOUND (real-time) | 267 |
| Outbound Call Management (OCM) | 97 |

| | |
|------------------------|-----|
| OUTCALLS | 267 |
| OUTFLAG | 268 |
| OUTFLOWCALLS | 268 |
| OUTFLOWTIME | 269 |
| OUTTIME | 270 |

P

| | |
|---|-----|
| pagent | 31 |
| pcwc | 31 |
| PENDINGSPILT (real-time) | 271 |
| PER_CHG | 337 |
| PERCENT | 271 |
| PERCENT_ACD_TIME | 343 |
| PERCENT_ACD_TIME_SUM | 343 |
| PERCENT_AL_BSY_SUM_D | 344 |
| PERCENT_AL_BSY_SUM_M | 344 |
| PERCENT_AL_BSY_SUM_W | 344 |
| PERCENT_ALL_BUSY | 344 |
| PERCENT_ALL_BUSY_D. | 344 |
| PERCENT_ALL_BUSY_I | 344 |
| PERCENT_ALL_BUSY_M | 344 |
| PERCENT_ALL_BUSY_SUM | 344 |
| PERCENT_ALL_BUSY_W | 344 |
| PERCENT_ALL_MBUSY_I | 344 |
| PERCENT_AUX_WORK | 344 |
| PERCENT_AUX_WORK_SUM | 344 |
| PERCENT_CALL_ABAN | 344 |
| PERCENT_CALL_ANS | 344 |
| PERCENT_CALL_ANS_SUM | 344 |
| PERCENT_MBUSY. | 345 |
| PERCENT_MBUSY_D | 345 |
| PERCENT_MBUSY_M | 345 |
| PERCENT_MBUSY_SUM. | 345 |
| PERCENT_MBUSY_SUM_D | 345 |
| PERCENT_MBUSY_SUM_M | 345 |
| PERCENT_MBUSY_SUM_W | 345 |
| PERCENT_MBUSY_W | 345 |
| PERCENT_SERV_LVL_SPL | 345 |
| PERCENT_SERV_LVL_VDN | 345 |
| PERCENT_SERV_SPL_OUT | 345 |
| PERCENT_SERV_VDN_OUT | 345 |
| PERCENT_SK_AVAIL | 346 |
| PERCENT_SLVL_SPL_SUM | 346 |
| PERCENT_VDN_ABAN. | 346 |
| PERCENT_VDN_ANSCONN | 346 |
| PERIOD 1-9 | 271 |
| PERIODCHG. | 272 |
| Personal Call Tracking | 98 |
| Abandoned Calls | 87 |
| Audio Difficulty | 89 |
| Phantom Abandoned Calls | 99 |
| Transferred and Conferenced Calls | 109 |
| Phantom Abandon Calls. | 99 |
| PHANTOMABNS | 272 |

| | |
|---|-----|
| POSITION (index) | 273 |
| POSITIONS | 273 |
| PREFERENCE | 274 |
| Presentation | |
| Call-based data | 35 |
| Communication server reference tables | 49 |
| Inter-based data | 35 |
| PRIORITY (real-time) | 274 |
| PRIORITY2-3 (real-time) | 275 |
| psplit | 31 |
| ptkgrp. | 31 |
| ptrunk. | 31 |
| pvdn | 31 |
| pvector | 31 |

Q

| | |
|----------------------------------|-----|
| QUECOUNT (real-time) | 275 |
| QUETYPE (real-time) | 276 |
| QUETYPE2-3 (real-time) | 276 |
| Queued | 45 |

R

| | |
|---|---------------|
| R1ACTIVE_AGT | 346 |
| R1AGINRING | 276 |
| R1AVAILABLE | 277 |
| R1INACW. | 277 |
| R1INAUX | 277 |
| R1INAUXSTBY | 102, 278 |
| R1ONACD | 278 |
| R1OTHER | 278 |
| R1OTHERSTBY. | 102 |
| R1OTHERSTBY (real-time) | 279 |
| R1STAFFED | 279 |
| R2ACTIVE_AGT | 346 |
| R2AGINRING | 280 |
| R2AVAILABLE | 280 |
| R2INACW. | 280 |
| R2INAUX | 281 |
| R2INAUXSTBY | 102, 103, 281 |
| R2ONACD | 281 |
| R2OTHER | 282 |
| R2OTHERSTBY. | 102, 282 |
| R2OTHERSTBY (real-time) | 279 |
| R2STAFFED | 283 |
| RAGOCC | 283 |
| RAVGSPEEDANS. | 283 |
| REASON | 284 |
| REASON_CODE | 284 |
| RECONNECT | 285 |
| Redirection on No Answer (G3V2 and later) | 100 |
| Reports-specific calculations | 349 |
| Reserve Agent | 90 |
| Reserve Agent Work Time Tracking | 91, 100 |

| | |
|---|---------------|
| Reserve Agent Work Time Tracking database items | 102 |
| Reserve Agents ACD Calls | 91 |
| RETURNCALLS | 285 |
| RINGCALLS | 285 |
| Ringin (G3, G2, System 85) | 108 |
| RINGTIME. | 286 |
| ROLE | 287, 335 |
| RONA | 100 |
| Row Identifier data, definition | 34 |
| ROW_DATE (index) | 287 |
| ROW_TIME | 290 |
| RSERVLEVELP | 291 |
| RSV_LEVEL | 102, 105, 291 |

S

| | |
|---|----------|
| search values | 333 |
| SECS_PER_DAY | 346 |
| SEGMENT. | 291 |
| SEGSTART | 292 |
| SEGSTOP. | 292 |
| Service Routing (BSR) | 95 |
| SERVICELEVEL | 292 |
| SERVLEVELP | 293 |
| SERVLEVELT | 293 |
| SETUPTIME | 293 |
| SHORTCALLS. | 294 |
| Skill Level | 46 |
| Skill State | 46, 90 |
| Skill state | 108 |
| SKILL1-3 | 294 |
| SKILLACWTIME1-3 | 295 |
| SKILLCALLS1-3 | 295 |
| SKILLTIME1-3 | 295 |
| SKILLTYPE | 296 |
| SKILLTYPE2-4. | 296 |
| SKLEVEL | 297 |
| SKLEVEL21-60 | 298 |
| SKLEVEL2-20 | 297 |
| SKPERCENT | 298 |
| SKPERCENT21-60. | 299 |
| SKPERCENT2-20 | 299 |
| SKSTATE | 300, 337 |
| SLVL_CHG | 337 |
| SLVLABNS | 300 |
| SLVLOUTFLOWS | 300 |
| Special Table data | 34 |
| spex. | 33 |
| SPLIT | 301 |
| Split/Skill | |
| ACD Call | 46 |
| Nonprimary (G3 vectoring, G2.2 EAS) | 45 |
| Nonzero (G2.2 EAS) | 45 |
| Primary (G3 vectoring, G2.2 EAS) | 45 |
| Secondary (G3 vectoring, G2.2 EAS). | 46 |

| | |
|-----------------------------------|-----|
| Tertiary (G3 vectoring, G2.2 EAS) | 46 |
| Split/skill database items | 66 |
| SPLIT1 | 303 |
| SPLIT2 ... 3 | 303 |
| Splits | 88 |
| Splits shown on real-time reports | 88 |
| STAFFED (real-time) | 304 |
| Standard Dictionary Calculations | 338 |
| STARTED (real-time) | 304 |
| STARTTIME | 304 |
| Station | 46 |
| Status data, definition | 34 |
| SVCLEVELCHG | 306 |

T

| | |
|------------------------|-----|
| Table Names | 30 |
| TAGINRING | 306 |
| TALKTIME | 307 |
| TARGETABNS | 307 |
| TARGETACDCALLS | 307 |
| TARGETOUTFLOWS | 307 |
| TARGETPCTCHG | 308 |
| TARGETSECCHG | 308 |
| TARGETSECONDS | 308 |
| TAVAILABLE | 309 |
| TDA_INACW | 309 |
| TDA_ONACD | 309 |
| Terminology | 42 |
| tgex | 33 |
| THRESHOLD | 310 |
| TI database items | 107 |
| TI_AUXTIME | 311 |
| TI_AUXTIME0 | 311 |
| TI_AUXTIME10-99 | 312 |
| TI_AUXTIME1-9 | 312 |
| TI_AVAILTIME | 313 |
| TI_OTHERTIME | 313 |
| TI_STAFFTIME | 314 |
| TIME | 314 |
| Time/duration tracking | 108 |
| Timed ACW | 108 |
| TINACW | 315 |
| TINAUX | 316 |
| TINAUX0 | 316 |
| TINAUX10-99 | 317 |
| TINAUX1-9 | 316 |
| TK_DIR | 336 |
| TK_PRI | 336 |
| TK_QTYPE | 336 |
| TK_VPRI | 336 |
| TKGRP | 317 |
| TKSTATE | 336 |
| TKSTATE (real-time) | 318 |
| TONACD | 318 |

| | |
|--|-----|
| TONACDAUXOUT | 319 |
| TONACDOUT | 319 |
| TONACWIN | 319 |
| TONACWOUT | 320 |
| TONAUXIN | 320 |
| TONAUXOUT | 320 |
| Top skill | 47 |
| TOP_AVAUXTIME | 347 |
| TOP_AVAUXTIME_SUM | 347 |
| TOPCALLS | 321 |
| TOPSKILL | 321 |
| TOT_I_ACDACW_SUM | 347 |
| TOT_I_ACDHOLD_SUM | 347 |
| TOT_PERCENTS | 321 |
| TOTAL_ACDCALLS | 348 |
| TOTAL_ACDTIME | 348 |
| TOTAL_ACWTIME | 348 |
| TOTAL_I_ACDACW | 348 |
| TOTAL_I_ACDHOLD | 348 |
| TOTAL_I_ACDTIME | 348 |
| TOTAL_I_ACWTIME | 348 |
| TOTHER | 322 |
| Transfer Tracking | 108 |
| TRANSFERRED | 322 |
| Transferred and Conferenced Calls | 109 |
| TRENDBASE | 323 |
| Trunk database items | 75 |
| Trunk group database items | 77 |
| Trunk group exception table | 188 |
| Trunk No Answer Timeout (G3V2 and later) | 109 |
| TRUNKS | 324 |
| TSTAFFED | 324 |
| TYPE (real-time) | 324 |

U

| | |
|----------------------------------|-----|
| UCID | 325 |
| Uniform Call Distribution (UCD) | 47 |
| Universal Call ID | 109 |
| Universal Call Identifier (UCID) | 47 |
| USE_SVC_OBJ | 325 |

V

| | |
|--|-----|
| VDISCCALLS | 325 |
| VDN | 326 |
| VDN active calls | 110 |
| VDN database items | 79 |
| VDN exception table | 188 |
| vdnex | 33 |
| vecex | 33 |
| VECTOR | 327 |
| Vector database items | 83 |
| Vector Disconnect Timer (G3V2 and later) | 110 |
| Vector exception table | 189 |

W

| | |
|---|----------|
| wagent | 32 |
| Wait Answer Supervision Timer (WAST) | 110 |
| wcwc | 33 |
| WMODE_SEQ | 328 |
| WORKCODE | 328 |
| WORKMODE | 328, 335 |
| WORKSKILL (real-time) | 329 |
| WORKSKLEVEL (real-time) | 329 |
| WORKSPLIT (real-time) | 330 |
| WORKSPLIT2 and WORKSPLIT3 (real-time) | 330 |
| WORKSPLIT21-60 | 331 |
| WORKSPLIT2-3 (real-time) | 330 |
| WORKSPLIT4 through WORKSPLIT20 (real-time). | 331 |
| wsplit | 32 |
| WT1 ... 4 | 331 |
| wtkgrp | 32 |
| wtrunk | 32 |
| wvdm | 32 |
| wvector | 32 |

Y

| | |
|------------------|-----|
| YES_NO | 337 |
|------------------|-----|

